

A
B
C

SECTION **BL**

BODY, LOCK & SECURITY SYSTEM

CONTENTS

<p>PRECAUTIONS 4</p> <p style="padding-left: 20px;">Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 4</p> <p style="padding-left: 20px;">Precautions for work 4</p> <p style="padding-left: 20px;">Wiring Diagnosis and Trouble Diagnosis 4</p> <p>PREPARATION 5</p> <p style="padding-left: 20px;">Special Service Tool 5</p> <p style="padding-left: 20px;">Commercial Service Tool 5</p> <p>SQUEAK AND RATTLE TROUBLE DIAGNOSES..... 6</p> <p style="padding-left: 20px;">Work Flow 6</p> <p style="padding-left: 40px;">CUSTOMER INTERVIEW 6</p> <p style="padding-left: 40px;">DUPLICATE THE NOISE AND TEST DRIVE 7</p> <p style="padding-left: 40px;">CHECK RELATED SERVICE BULLETINS 7</p> <p style="padding-left: 40px;">LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE 7</p> <p style="padding-left: 40px;">REPAIR THE CAUSE 7</p> <p style="padding-left: 40px;">CONFIRM THE REPAIR 8</p> <p style="padding-left: 20px;">Generic Squeak and Rattle Troubleshooting 8</p> <p style="padding-left: 20px;">INSTRUMENT PANEL 8</p> <p style="padding-left: 20px;">CENTER CONSOLE 8</p> <p style="padding-left: 20px;">DOORS 8</p> <p style="padding-left: 20px;">TRUNK 9</p> <p style="padding-left: 20px;">SUNROOF/HEADLINING 9</p> <p style="padding-left: 20px;">OVERHEAD CONSOLE (FRONT AND REAR)..... 9</p> <p style="padding-left: 20px;">SEATS 9</p> <p style="padding-left: 20px;">UNDERHOOD 9</p> <p style="padding-left: 20px;">Diagnostic Worksheet 10</p> <p>HOOD 12</p> <p style="padding-left: 20px;">Fitting Adjustment 12</p> <p style="padding-left: 40px;">CLEARANCE AND SURFACE HEIGHT ADJUSTMENT 13</p> <p style="padding-left: 40px;">HOOD LOCK ADJUSTMENT 13</p> <p style="padding-left: 20px;">Removal and Installation of Hood Assembly 13</p> <p style="padding-left: 20px;">Removal and Installation of Hood Lock Control 14</p> <p style="padding-left: 40px;">REMOVAL 14</p> <p style="padding-left: 40px;">INSTALLATION 15</p> <p style="padding-left: 20px;">Hood Lock Control Inspection 15</p> <p>POWER DOOR LOCK SYSTEM 16</p> <p style="padding-left: 20px;">Component Parts and Harness Connector Location.. 16</p>	<p style="padding-left: 20px;">System Description 17</p> <p style="padding-left: 40px;">KING CAB 17</p> <p style="padding-left: 40px;">CREW CAB 18</p> <p style="padding-left: 40px;">OUTLINE 18</p> <p style="padding-left: 20px;">Schematic (King Cab) 20</p> <p style="padding-left: 20px;">Wiring Diagram - D/LOCK - (King Cab) 21</p> <p style="padding-left: 20px;">Schematic (Crew Cab) 26</p> <p style="padding-left: 20px;">Wiring Diagrams - D/LOCK - (Crew Cab) 27</p> <p style="padding-left: 20px;">Terminals and Reference Value for BCM 31</p> <p style="padding-left: 20px;">Work Flow 31</p> <p style="padding-left: 20px;">CONSULT-II Function 31</p> <p style="padding-left: 40px;">CONSULT-II INSPECTION PROCEDURE 32</p> <p style="padding-left: 40px;">DATA MONITOR 33</p> <p style="padding-left: 40px;">ACTIVE TEST 33</p> <p style="padding-left: 20px;">Trouble Diagnoses Symptom Chart 34</p> <p style="padding-left: 20px;">BCM Power Supply and Ground Circuit Check 34</p> <p style="padding-left: 20px;">Door Switch Check (King Cab) 35</p> <p style="padding-left: 20px;">Door Switch Check (Crew Cab) 37</p> <p style="padding-left: 20px;">Key Switch (Insert) Check (Column Shift) 39</p> <p style="padding-left: 20px;">Key Switch (Insert) Check (Floor Shift) 40</p> <p style="padding-left: 20px;">Door Lock/Unlock Switch Check (King Cab) 42</p> <p style="padding-left: 20px;">Door Lock/Unlock Switch Check (Crew Cab) 45</p> <p style="padding-left: 20px;">Door Lock Actuator Check (Front LH) 47</p> <p style="padding-left: 20px;">Door Lock Actuator Check (Front RH) 49</p> <p style="padding-left: 20px;">Door Lock Actuator Check (Rear RH/LH) 50</p> <p style="padding-left: 20px;">FrontDoorLockAssemblyLH(KeyCylinderSwitch) Check (King Cab) 51</p> <p style="padding-left: 20px;">FrontDoorLockAssemblyLH(KeyCylinderSwitch) Check (Crew Cab) 52</p> <p>REMOTE KEYLESS ENTRY SYSTEM 53</p> <p style="padding-left: 20px;">Component Parts and Harness Connector Location.. 53</p> <p style="padding-left: 20px;">System Description 54</p> <p style="padding-left: 40px;">INPUTS 54</p> <p style="padding-left: 40px;">OPERATED PROCEDURE 55</p> <p style="padding-left: 20px;">CAN Communication System Description 58</p> <p style="padding-left: 20px;">Schematic (King Cab) 59</p> <p style="padding-left: 20px;">Wiring Diagram — KEYLES — (King Cab) 60</p> <p style="padding-left: 20px;">Schematic (Crew Cab) 64</p> <p style="padding-left: 20px;">Wiring Diagram — KEYLES — (Crew Cab) 65</p> <p style="padding-left: 20px;">Terminals and Reference Value for BCM 68</p>
--	--

A
B
C
D
E
F
G
H
I
J
K
L
M

BL

Terminals and Reference Value for IPDM E/R	69	FrontDoorLockAssemblyLH(KeyCylinderSwitch)	
CONSULT-II Function	69	Check (Crew Cab)	120
CONSULT-II Inspection Procedure	70	Vehicle Security Horn Alarm Check	121
“MULTI REMOTE ENT”	70	Vehicle Security Headlamp Alarm Check	121
CONSULT-II Application Items	71	Door Lock/Unlock Switch Check	121
“MULTI REMOTE ENT”	71	DOOR	122
Trouble Diagnosis Procedure	73	Fitting Adjustment	122
Pre-Diagnosis Inspection	73	FRONT DOOR	123
BCM Power Supply and Ground Circuit Check	73	REAR DOOR	123
Trouble Diagnoses	74	STRIKER ADJUSTMENT	123
SYMPTOM CHART	74	Removal and Installation	124
Key Switch (Insert) Check (Column Shift)	77	KING CAB	124
Key Switch (Insert) Check (Floor Shift)	78	CREW CAB	125
Door Switch Check (King Cab)	80	Door Weatherstrip	126
Door Switch Check (Crew Cab)	81	FRONT DOOR LOCK	128
Key Fob Battery and Function Check	82	Component Structure	128
Remote Keyless Entry Receiver System Check	83	Removal and Installation	128
ACC Power Check	85	REMOVAL	128
IPDM E/R Operation Check	85	INSTALLATION	130
Check Hazard Function	87	Disassembly and Assembly	130
Check Horn Function	87	DOOR KEY CYLINDER ASSEMBLY	130
Check Headlamp Function	87	REAR DOOR LOCK	131
CheckFrontRoom/MapLampIlluminationFunction	87	Component Structure	131
ID Code Entry Procedure	88	Removal and Installation	132
KEY FOB ID SET UP WITH CONSULT-II	88	REMOVAL	132
KEY FOB ID SET UP WITHOUT CONSULT-II	90	INSTALLATION	133
Key Fob Battery Replacement	91	TAIL GATE	134
VEHICLE SECURITY (THEFT WARNING) SYSTEM.. 92		Removal and Installation	134
Component Parts and Harness Connector Location..	92	NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-	
System Description	93	NATS)	135
DESCRIPTION	93	Component Parts and Harness Connector Location	135
POWER SUPPLY AND GROUND CIRCUIT	93	System Description	136
INITIAL CONDITION TO ACTIVATE THE SYS-		System Composition	136
TEM	94	ECM Re-communicating Function	137
VEHICLE SECURITY SYSTEM ALARM OPER-		Wiring Diagram — NATS —	138
ATION	94	Terminals and Reference Value for BCM	139
VEHICLE SECURITY SYSTEM DEACTIVATION..	94	CONSULT-II	139
PANIC ALARM OPERATION	94	CONSULT-II INSPECTION PROCEDURE	139
CAN Communication System Description	95	CONSULT-II DIAGNOSTIC TEST MODE FUNC-	
Schematic (King Cab)	96	TION	140
Wiring Diagram -VEHSEC- (King Cab)	97	HOW TO READ SELF-DIAGNOSTIC RESULTS..	141
Schematic (Crew Cab)	103	NVIS (NATS) SELF-DIAGNOSTIC RESULTS	
Wiring Diagram -VEHSEC- (Crew Cab)	104	ITEM CHART	141
Terminals and Reference Value for BCM	109	Work Flow	142
Terminals and Reference Value for IPDM E/R	109	Trouble Diagnoses	143
CONSULT-II Function	110	SYMPTOM MATRIX CHART 1	143
DIAGNOSTIC ITEMS DESCRIPTION	110	SYMPTOM MATRIX CHART 2	144
CONSULT-II INSPECTION PROCEDURE	110	DIAGNOSTIC SYSTEM DIAGRAM	144
CONSULT-II APPLICATION ITEM	111	Diagnostic Procedure 1	145
Trouble Diagnosis	112	Diagnostic Procedure 2	146
WORK FLOW	112	Diagnostic Procedure 3	147
Preliminary Check	113	Diagnostic Procedure 4	148
Symptom Chart	114	Diagnostic Procedure 5	149
Door Switch Check (King Cab)	115	Diagnostic Procedure 6	152
Door Switch Check (Crew Cab)	116	How to Replace NATS Antenna Amp.	153
Security Indicator Lamp Check	118	INTEGRATED HOMELINK TRANSMITTER	154
FrontDoorLockAssemblyLH(KeyCylinderSwitch)		Wiring Diagram — TRNSCV —	154
Check (King Cab)	119	Trouble Diagnoses	155
		DIAGNOSTIC PROCEDURE	155

CAB AND REAR BODY	157	UNDERBODY	185	
Body Mounting, King Cab	157	PASSENGER COMPARTMENT	188	A
Body Mounting, Crew Cab	158	REAR BODY	194	
BODY REPAIR	159	Handling Precautions for Plastics	197	
Body Exterior Paint Color	159	LOCATION OF PLASTIC PARTS	198	B
Body Component Parts	160	Precautions in Repairing High Strength Steel	200	
UNDERBODY COMPONENT PARTS	160	HIGH STRENGTH STEEL (HSS) USED IN NIS-		
BODY COMPONENT PARTS	162	SAN VEHICLES	200	C
FRAME COMPONENT PARTS	166	Foam Repair	202	
Corrosion Protection	169	URETHANE FOAM APPLICATIONS	202	
DESCRIPTION	169	FILL PROCEDURES	202	D
ANTI-CORROSIVE WAX	170	Replacement Operations	203	
UNDERCOATING	171	DESCRIPTION	203	
Body Sealing	172	HOODLEDGE	206	E
DESCRIPTION	172	FRONT PILLAR	207	
Body Construction	176	CENTER PILLAR	210	
BODY CONSTRUCTION	176	OUTER SILL	212	
Body Alignment	178	REAR CAB PILLAR	216	F
BODY CENTER MARKS	178	REAR PANEL	220	
PANEL PARTS MATCHING MARKS	180	REAR FLOOR REAR	221	
DESCRIPTION	182	PICKUP BED	223	
ENGINE COMPARTMENT	183	CRUSH HORN	234	G

H

BL

J

K

L

M

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EIS002EY

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for work

EIS002EZ

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operation.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.

Wiring Diagnosis and Trouble Diagnosis

EIS002F0

When you read wiring diagrams, refer to the following:

- [GI-15, "How to Read Wiring Diagrams"](#)
- [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#)

When you perform trouble diagnosis, refer to the following:

- [GI-11, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-27, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)
Check for any Service bulletins before servicing the vehicle.

PREPARATION

PREPARATION



PF0:00002

Special Service Tool

EIS002F1

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.


Tool number (Kent-Moore No.) Tool name	Description
— (J-39570) Chassis ear	Locating the noise
— (J-43980) NISSAN Squeak and Rattle Kit	Repairing the cause of noise
— (J-43241) Remote Keyless Entry Tester	Used to test key fobs



Commercial Service Tool

EIS002F2

(Kent-Moore No.) Tool name	Description
(J-39565) Engine ear	Locating the noise



A
B
C
D
E
F
G
H
BL
J
K
L
M


SQUEAK AND RATTLE TROUBLE DIAGNOSES

SQUEAK AND RATTLE TROUBLE DIAGNOSES

PF0:0000

Work Flow

EIS003PD



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [BL-10, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from. Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise. Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks. Refer to [BL-8, "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-43980) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

Always check with the Parts Department for the latest parts information.

The following materials are contained in the NISSAN Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100×135 mm (3.94×5.31 in)/76884-71L01: 60×85 mm (2.36×3.35 in)/76884-71L02: 15×25 mm (0.59×0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50×50 mm (1.97×1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50×50 mm (1.97×1.97 in)

INSULATOR (Light foam block)

SQUEAK AND RATTLE TROUBLE DIAGNOSES

80845-71L00: 30 mm (1.18 in) thick, 30×50 mm (1.18×1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15×25 mm (0.59×0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll. The following materials not found in the kit can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used instead of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

EIS003PE

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-43980) to repair the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner. In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headliner and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lense loose.
3. Loose screws at console attachment points.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A

B

C

D

E

F

G

H

BL

J

K

L

M

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Diagnostic Worksheet

EIS003PF




SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Nissan Customer:

We are concerned about your satisfaction with your Nissan vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Nissan right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to the back of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

LIWA0276E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET- page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (check the boxes that apply)

- | | |
|--|---|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the sun |
| <input type="checkbox"/> 1 st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: _____ |

III. WHEN DRIVING:

- through driveways
- over rough roads
- over speed bumps
- only at about ____ mph
- on acceleration
- coming to a stop
- on turns : left, right or either (circle)
- with passengers or cargo
- other: _____
- after driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE?

- squeak (like tennis shoes on a clean floor)
- creak (like walking on an old wooden floor)
- rattle (like shaking a baby rattle)
- knock (like a knock on a door)
- tick (like a clock second hand)
- thump (heavy, muffled knock noise)
- buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	<u>YES</u>	<u>NO</u>	<u>Initials of person performing</u>
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name: _____

W.O. #: _____ Date: _____

SBT844

This form must be attached to Work Order





HOOD

PFP:F5100


EIS002F6

HOOD


Fitting Adjustment



A - A



B - B



C - C

CLEARANCE	a	8.0 (0.315)
	c	8.0 (0.315)
	e	5.0 (0.197)
SURFACE HEIGHT	b	2.0 (0.079)
	d	0.8 (0.031)
	f	0.0 (0.000)

Unit: mm (in)

: Apply body grease.

LIA1606E

HOOD

- | | | |
|------------------|---------------------|-----------------------|
| 1. Hood hinge | 2. Hood damper stay | 3. Hood lock assembly |
| 4. Hood assembly | 5. Front grille | 6. Headlamp |
| 7. Front fender | | |

CLEARANCE AND SURFACE HEIGHT ADJUSTMENT

- Remove the hood lock assembly and adjust the height by rotating the bumper rubber until the hood clearance of hood and fender becomes 1 mm (0.04 in) lower than fitting standard dimension.
- Temporarily tighten the hood lock, and position it by engaging it with the hood striker. Check the lock and striker for looseness, and tighten the lock mounting bolt to the specified torque.
- Adjust the clearance and surface height of hood and fender according to the fitting standard dimension by rotating right and left bumper rubbers.

CAUTION:

Adjust right/left gap between hood and each part to the following specification.

Hood and headlamp (B-B) : Less than 2.0 mm


HOOD LOCK ADJUSTMENT

- Move the hood lock to the left or right so that striker center is vertically aligned with hood lock center (when viewed from viewed from vehicle front).
- Make sure the secondary latch is properly engaged with the secondary striker with hood's own weight by dropping it from approx. 200 mm (7.87 in) height or by pressing it lightly approx. 3 kg (29 N, 7lb).

CAUTION:


Do not drop the hood from 300 mm (11.81 in) height or higher.

- After adjusting hood lock, tighten the lock mounting bolts to the specified torque.



Removal and Installation of Hood Assembly

EIS002F7



- Support the hood latch striker with proper material to prevent it from falling.

WARNING:

Body injury may occur if no supporting rod is holding the hood open when removing the hood damper stay.

- Remove the hinge mounting nuts on the hood to remove the hood assembly.

CAUTION:


Operate with two workers, because of its heavy weight.

HOOD

Installation in the reverse order of removal.

Removal and Installation of Hood Lock Control

EIS002F8



1. Hood lock assembly

2. Hood lock cable

LIA1080E

REMOVAL

1. Remove the front grill. Refer to [EI-20, "Removal and Installation"](#).
2. Remove the front fender protector (LH). Refer to [EI-24, "Removal and Installation"](#).
3. Disconnect the hood lock cable from the hood lock, and unclip it from the radiator core support upper and hood ledge.
4. Remove the mounting bolt, and remove the hood opener.
5. Remove the grommet on the dashboard, and pull the hood lock cable toward the passenger room.


CAUTION:

While pulling, be careful not to damage the outside of the hood lock cable.


HOOD

INSTALLATION

1. Pull the hood lock cable through the panel hole to the engine room.
Be careful not to bend the cable too much, keeping the radius 100mm (3.94 in) or more.
2. Make sure the cable is not offset from the positioning grommet, and push the grommet into the panel hole securely.
3. Apply the sealant to the grommet (at * mark) properly.



4. Install the cable securely to the lock.
5. After installing, check the hood lock adjustment and hood opener operation.




Hood Lock Control Inspection

EIS002F9


CAUTION:

If the hood lock cable is bent or deformed, replace it.

1. Make sure the secondary latch is properly engaged with the secondary striker with hood's own weight by dropping it from approx. 200 mm (7.87 in) height.
2. While operating the hood opener, carefully make sure the front end of the hood is raised by approx. 20 mm (0.79 in). Also make sure the hood opener returns to the original position.



3. Check the hood lock lubrication condition. If necessary, apply body grease to the points shown in the figure.



A
B
C
D
E
F
G
H
J
K
L
M

BL


POWER DOOR LOCK SYSTEM

POWER DOOR LOCK SYSTEM

PF2:24814

Component Parts and Harness Connector Location

EIS002FA



W11A0311E

POWER DOOR LOCK SYSTEM

EIS002FB

System Description

Power is supplied at all times

- through 50A fusible link (letter **f**, located in the fuse and fusible link box)
- to BCM terminal 70 and
- through 10A fuse [No. 19, located in the fuse block (J/B)]
- to key switch and key lock solenoid terminal 3
- through 15A fuse [No. 22, located in the fuse block (J/B)]
- to BCM terminal 57.

With ignition key inserted, power is supplied

- through key switch and key lock solenoid terminal 4
- to BCM terminal 37.

Ground is supplied to terminal 67 of BCM through body grounds M57, M61 and M79.

When the door is locked or unlocked with main power window and door lock/unlock switch, ground is supplied

- to CPU of main power window and door lock/unlock switch
- through main power window and door lock/unlock switch terminal 15 (King Cab) or 17 (Crew Cab)
- through grounds M57, M61 and M79.

Then main power window and door lock/unlock switch operation signal is supplied.

- to BCM terminal 22
- through main power window and door lock/unlock switch terminal 12 (King Cab) or 14 (Crew Cab).

When the door is locked or unlocked with power window and door lock/unlock switch RH, ground is supplied

- to CPU of power window and door lock/unlock switch RH
- through power window and door lock/unlock switch RH terminal 11
- through grounds M57, M61 and M79.

Then power window and door lock/unlock switch RH operation signal is supplied

- to BCM terminal 22
- through power window and door lock/unlock switch RH terminal 16.

When the door is locked with front door lock assembly LH (key cylinder switch), ground is supplied

- to main power window and door lock/unlock switch terminal 6 (King Cab) or 4 (Crew Cab)
- through key cylinder switch terminals 1 and 5
- through grounds M57, M61 and M79.

Then key cylinder switch operation signal is supplied

- to BCM terminal 22
- through main power window and door lock/unlock switch terminal 12 (King Cab) or 14 (Crew Cab).

When the door is unlocked with front door lock assembly LH (key cylinder switch), ground is supplied

- to main power window and door lock/unlock switch terminal 7 (King Cab) or 6 (Crew Cab)
- through key cylinder switch terminals 6 and 5
- through grounds M57, M61 and M79.

Then key cylinder switch operation signal is supplied

- to BCM terminal 22
- through main power window and door lock/unlock switch terminal 12 (King Cab) or 14 (Crew Cab).

KING CAB

BCM is connected to main power window and door lock/unlock switch and power window and door lock/unlock switch RH through a serial link.

When the front door switch LH is ON (door is open), ground is supplied

- to BCM terminal 47
- through front door switch LH terminals 2 and 3
- through grounds B7 and B19.

When the rear door switch upper LH is ON (door is open), ground is supplied

- to BCM terminal 47

A
B
C
D
E
F
G
H
BL
J
K
L
M

POWER DOOR LOCK SYSTEM

- through rear door switch upper LH terminals 1 and 2
- through grounds B7 and B19.

When the rear door switch lower LH is ON (door is open), ground is supplied

- to BCM terminal 47
- through rear door switch lower LH terminals 1 and 2
- through grounds B7 and B19.

When the front door switch RH is ON (door is open), ground is supplied

- to BCM terminal 12
- through front door switch RH terminals 2 and 3
- through grounds B117 and B132.

When the rear door switch upper RH is ON (door is open), ground is supplied

- to BCM terminal 12
- through rear door switch upper RH terminals 1 and 2
- through grounds B117 and B132.

When the rear door switch lower RH is ON (door is open), ground is supplied

- to BCM terminal 12
- through rear door switch lower RH terminals 1 and 2
- through grounds B117 and B132.

CREW CAB

When the front door switch LH is ON (door is open), ground is supplied

BCM is connected to main power window and door lock/unlock switch and power window and door lock/unlock switch RH through a serial link.

- to BCM terminal 47
- through front door switch LH terminal 2
- through front door switch LH case ground.

When the front door switch RH is ON (door is open), ground is supplied

- to BCM terminal 12
- through front door switch RH terminal 2
- through front door switch RH case ground.

When the rear door switch LH is ON (door is open), ground is supplied

- to BCM terminal 48
- through rear door switch LH terminal 2
- through rear door switch LH case ground.

When the rear door switch RH is ON (door is open), ground is supplied

- to BCM terminal 13
- through rear door switch RH terminal 2
- through rear door switch RH case ground.

OUTLINE

Functions available by operating the door lock and unlock switches on driver's door and passenger's door

- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all doors are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all doors are unlocked.

Functions available by operating the key cylinder switch on driver's door

- Interlocked with the locking operation of door key cylinder, door lock actuators of all doors are locked.
- When door key cylinder is unlocked, front door lock assembly LH is unlocked.
- When door key cylinder is unlocked for the second time within 5 seconds after the first operation, door lock actuators on all doors are unlocked.

POWER DOOR LOCK SYSTEM

Key reminder door system

When door lock and unlock switch is operated to lock doors with ignition key in key cylinder and any door open, all door lock actuators are locked and then unlocked.

A

B

C

D

E

F

G

H

BL

J

K

L


M

POWER DOOR LOCK SYSTEM

Schematic (King Cab)

EIS002FC

(FS) : FLOOR SHIFT
(CS) : COLUMN SHIFT







WIWA0273E

POWER DOOR LOCK SYSTEM

Wiring Diagram - D/LOCK - (King Cab)

EIS002FD

BL-D/LOCK-01




REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

WIWA0274E


POWER DOOR LOCK SYSTEM

BL-D/LOCK-02



41	42	43	44	45	46	47	48	49
50	51	52	53	54	55			

(M19) W



(B8) W

1 2

(B73) B

(B74) B

REFER TO THE FOLLOWING.


(M40) - SUPER MULTIPLE JUNCTION (SMJ)

LIWA0298E

POWER DOOR LOCK SYSTEM

BL-D/LOCK-03

A
B
C
D
E
F
G
H
BL
J
K
L
M



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M18)
W



1
2
3

(B108)
W

1 2

(B156)
B

(B157)
B



REFER TO THE FOLLOWING.
(M36) - SUPER MULTIPLE JUNCTION (SMJ)

LIWA0299E

POWER DOOR LOCK SYSTEM

BL-D/LOCK-04

— : DATA LINE




WIWA0300E






POWER DOOR LOCK SYSTEM

BL-D/LOCK-05

A
B
C
D
E
F
G
H
I
J
K
L
M



BL



REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


WIWA0275E

POWER DOOR LOCK SYSTEM

Schematic (Crew Cab)

EIS002QN

FS : FLOOR SHIFT
CS : COLUMN SHIFT







WIWA0299E

POWER DOOR LOCK SYSTEM

Wiring Diagrams - D/LOCK - (Crew Cab)

EIS002Q0

BL-D/LOCK-06





REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

WVWA0276E

POWER DOOR LOCK SYSTEM

BL-D/LOCK-07





REFER TO THE FOLLOWING.
 (M36), (M40) - SUPER MULTIPLE
 JUNCTION (SMJ)

WIWA0304E

POWER DOOR LOCK SYSTEM

BL-D/LOCK-09




REFER TO THE FOLLOWING.
 (M36), (M40) - SUPER MULTIPLE
 JUNCTION (SMJ)

W1WA0278E

POWER DOOR LOCK SYSTEM

Terminals and Reference Value for BCM

EIS002FE

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
12	R/L	Front door switch RH (All)	Door open (ON) → Door close (OFF)	0 → Battery voltage
		Rear door switch lower RH (King Cab)		
		Rear door switch upper RH (King Cab)		
13	GR	Rear door switch RH (Crew Cab)	Door open (ON) → Door close (OFF)	0 → Battery voltage
22	G	Anti-pinch serial link	When ignition switch is ON or power window timer operates	
37	B/R	Key switch (insert)	Key inserted in IGN key cylinder (ON) → Key removed from IGN key cylinder (OFF)	Battery voltage → 0
39	W	CAN-H	—	—
40	R	CAN-L	—	—
47	SB	Front door switch LH (All)	Door open (ON) → Door close (OFF)	0 → Battery voltage
		Rear door switch lower LH (King Cab)		
		Rear door switch upper LH (King Cab)		
48	R/Y	Rear door switch LH (Crew Cab)	Door open (ON) → Door close (OFF)	0 → Battery voltage
57	Y/R	Battery power supply	—	Battery voltage
59	G	Front door lock assembly LH (unlock)	Driver door lock knob (locked → unlocked)	0 → Battery voltage
65	V	All door lock actuator (lock)	Driver door lock knob (neutral → lock)	0 → Battery voltage
66	G/Y	Front door lock actuator RH and rear door lock actuators LH/RH (unlock)	Door lock and unlock switch (locked → unlocked)	0 → Battery voltage
67	B	Ground	—	—
70	W/B	BAT power supply	—	Battery voltage

Work Flow

EIS002FF

1. Check the symptom and customer's requests.
2. Understand the outline of system. Refer to [BL-17, "System Description"](#) .
3. According to the trouble diagnosis chart, repair or replace the cause of the malfunction. Refer to [BL-34, "Trouble Diagnoses Symptom Chart"](#) .
4. Does power door lock system operate normally? OK: GO TO 5, NG: GO TO 3.
5. INSPECTION END.

CONSULT-II Function

EIS002OY

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnosis part	Inspection item, self-diagnosis mode	Content
Door lock	Data monitor	Displays BCM input data on real-time basis.
	Active test	Sends drive signals to door lock actuator to perform operation check.

POWER DOOR LOCK SYSTEM


CONSULT-II INSPECTION PROCEDURE

"DOOR LOCK"


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.




3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "BCM".
If "BCM" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




6. Touch "DOOR LOCK".



POWER DOOR LOCK SYSTEM

7. Select diagnosis mode.
 "DATA MONITOR" and "ACTIVE TEST" are available.



DATA MONITOR

Monitor item "OPERATION"	Content
KEY ON SW	"ON/OFF" Indicates [ON/OFF] condition of key switch.
CDL LOCK SW	"ON/OFF" Indicates [ON/OFF] condition of lock signal from lock/unlock switch LH and RH.
CDL UNLOCK SW	"ON/OFF" Indicates [ON/OFF] condition of unlock signal from lock/unlock switch LH and RH.
KEY CYL LK-SW	"ON/OFF" Indicates [ON/OFF] condition of lock signal from key cylinder.
KEY CYL UN-SW	"ON/OFF" Indicates [ON/OFF] condition of unlock signal from key cylinder.
IGN ON SW	"ON/OFF" Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	"ON/OFF" Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	"ON/OFF" Indicates [ON/OFF] condition of front door switch RH.
DOOR SW-RR	"ON/OFF" Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	"ON/OFF" Indicates [ON/OFF] condition of rear door switch LH.

ACTIVE TEST

Test item	Content
ALL LOCK/UNLOCK	This test is able to check all door lock actuators lock operation. These actuators lock when "ON" on CONSULT-II screen is touched.
DR UNLOCK	This test is able to check front door lock assembly LH unlock operation. These actuators lock when "ON" on CONSULT-II screen is touched.
OTHER UNLOCK	This test is able to check door lock actuators (except front door lock assembly LH) unlock operation. These actuators unlock when "ON" on CONSULT-II screen is touched.

POWER DOOR LOCK SYSTEM

Trouble Diagnoses Symptom Chart

EIS0020Z

Symptom	Repair order	Refer to page
Key reminder door system does not operate properly.	1. Door switch check	BL-35
	2. Key switch (Insert) check	BL-39
	3. Replace BCM.	BCS-25
Power door lock does not operate with door lock and unlock switch on main power window and door lock/unlock switch or power window and door lock/unlock switch RH	1. Door lock/unlock switch check	BL-42
Front door lock assembly LH does not operate.	1. Door lock actuator check (Front LH)	BL-47
Specific door lock actuator does not operate.	1. Door lock actuator check (Front RH, Rear LH/ RH)	BL-49
Power door lock does not operate with front door key cylinder LH operation.	1. Front door lock assembly LH (key cylinder switch) check	BL-51
	2. Replace BCM.	BCS-25
Power door lock does not operate.	1. BCM power supply and ground circuit check	BL-34
	2. Door lock/unlock switch check	BL-42

BCM Power Supply and Ground Circuit Check

EIS002P0

1. CHECK FUSE

Check the following BCM fuses and fusible link.

Component Parts	Terminal No. (SIGNAL)	Ampere	No.	Location
BCM	57 (BAT power supply)	15A	22	Fuse block (J/B)
	70 (BAT power supply)	50A	f	Fuse and fusible link box

NOTE:

Refer to [BL-16, "Component Parts and Harness Connector Location"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse, refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

2. CHECK POWER SUPPLY CIRCUIT


- Turn ignition switch OFF.
- Disconnect BCM.
- Check voltage between BCM connectors M20 terminals 57, 70 and ground.

Connector	Terminals (Wire color)		Signal name	Ignition switch	Voltage
	(+)	(-)			
M20	70 (W/B)	Ground	Battery power supply	OFF	Battery voltage
	57 (Y/R)		Battery power supply	OFF	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM


3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M20 terminal 67 and ground.

Connector	Terminals (Wire color)		Continuity
	(+)	(-)	
M20	67 (B)	Ground	Yes

OK or NG

- OK >> Power supply and ground circuit is OK.
- NG >> Repair or replace harness.



Door Switch Check (King Cab)

1. CHECK DOOR SWITCHES INPUT SIGNAL

With CONSULT-II

Check door switches ("DOOR SW-DR", "DOOR SW-AS") in DATA MONITOR mode with CONSULT-II. Refer to [BL-33. "DATA MONITOR"](#).

- When any doors are open:


DOOR SW-DR :ON

DOOR SW-AS :ON

- When any doors are closed:

DOOR SW-DR :OFF

DOOR SW-AS :OFF




Without CONSULT-II

Check voltage between BCM connector M18 or M19 terminals 12, 47 and ground.

Connector	Item	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
		(+)	(-)		
M19	Door switches LH	47 (SB)	Ground	Open ↓	0 ↓
M18	Door switches RH	12 (R/L)		Closed	Battery voltage

OK or NG

- OK >> System is OK.
- NG >> GO TO 2.



POWER DOOR LOCK SYSTEM


2. CHECK DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door switch and BCM.
3. Check continuity between door switch connector B8 (Front LH), B108 (Front RH) terminal 2, B73 (Rear upper LH), B156 (Rear upper RH), B74 (Rear lower LH), B157 (Rear lower RH) terminal 1 and BCM connector M18, M19 terminals 12, and 47.

- 2 (SB) - 47 (SB) :Continuity should exist**
2 (R/L) - 12 (R/L) :Continuity should exist
1 (SB) - 47 (SB) :Continuity should exist
1 (R/L) - 12 (R/L) :Continuity should exist

4. Check continuity between door switch connector B8 (Front LH), B108 (Front RH) terminal 2, B73 (Rear upper LH), B156 (Rear upper RH), B74 (Rear lower LH), B157 (Rear lower RH) terminal 1 and ground.

- 2 (SB or R/L) - Ground :Continuity should not exist**
1 (SB or R/L) - Ground :Continuity should not exist



OK or NG

- OK >> GO TO 3.
 NG >> Repair or replace harness.


3. CHECK DOOR SWITCHES

1. Disconnect door switch.
2. Check continuity between door switch terminals.

Item	Terminal	Condition	Continuity
Door switches (front)	2 - 3	Open	No
		Closed	Yes
Door switches (rear upper and lower)	1 - 2	Open	No
		Closed	Yes

OK or NG

- OK >> Repair or replace harness.
 NG >> Replace door switch.



POWER DOOR LOCK SYSTEM

EIS002PY

Door Switch Check (Crew Cab)

1. CHECK DOOR SWITCHES INPUT SIGNAL

 With CONSULT-II

Check door switches ("DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR") in DATA MONITOR mode with CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).

- When any doors are open:

DOOR SW-DR :ON
DOOR SW-AS :ON
DOOR SW-RL :ON
DOOR SW-RR :ON

- When any doors are closed:

DOOR SW-DR :OFF
DOOR SW-AS :OFF
DOOR SW-RL :OFF
DOOR SW-RR :OFF


DATA MONITOR	
MONITOR	
DOOR SW - DR	OFF
DOOR SW - AS	OFF
DOOR SW - RR	OFF
DOOR SW - RL	OFF

PIIA6222E

 Without CONSULT-II

Check voltage between BCM connector M18 or M19 terminals 12, 13, 47, 48 and ground.

Connector	Item	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
		(+)	(-)		
M19	Front door switch LH	47 (SB)	Ground	Open ↓ Closed	0 ↓ Battery voltage
	Rear door switch LH	48 (R/Y)			
M18	Front door switch RH	12 (R/L)			
	Rear door switch RH	13 (GR)			



OK or NG

OK >> System is OK.
 NG >> GO TO 2.

POWER DOOR LOCK SYSTEM


2. CHECK DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door switch and BCM.
3. Check continuity between door switch connector B8 (Front LH), B108 (Front RH), B18 (Rear LH), B116 (Rear RH) terminal 2 and BCM connector M18, M19 terminals 12, 13, 47 and 48.

2 (SB) - 47 (SB) :Continuity should exist
2 (R/L) - 12 (R/L) :Continuity should exist
2 (R/Y) - 48 (R/Y) :Continuity should exist
2 (GR) - 13 (GR) :Continuity should exist

4. Check continuity between door switch connector B8 (Front LH), B108 (Front RH), B18 (Rear LH), B116 (Rear RH) terminal 2 and ground.

2 (SB, R/L, R/Y or GR) - Ground :Continuity should not exist



OK or NG

- OK >> GO TO 3.
 NG >> Repair or replace harness.


3. CHECK DOOR SWITCHES

1. Disconnect door switch.
2. Check continuity between door switch terminals.

	Terminal	Condition	Continuity
Door switch (front and rear)	2 – Ground	Open	Yes
		Closed	No

OK or NG

- OK >> Check door switch case ground condition.
 NG >> Replace door switch.



POWER DOOR LOCK SYSTEM

EIS002P2


Key Switch (Insert) Check (Column Shift)

1. CHECK KEY SWITCH INPUT SIGNAL

 With CONSULT-II

Check key switch "KEY ON SW" in DATA MONITOR mode with CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).


- When key is inserted to ignition key cylinder:
KEY ON SW :ON
- When key is removed from ignition key cylinder:
KEY ON SW :OFF



 Without CONSULT-II

Check voltage between BCM connector M18 terminal 37 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V)
	(+)	(-)		
M18	37 (B/R)	Ground	Key is inserted.	Battery voltage
			Key is removed.	0



OK or NG

- OK >> System is OK.
- NG >> GO TO 2.


2. CHECK KEY SWITCH (INSERT)

- Turn ignition switch OFF.
- Disconnect key switch connector.
- Check continuity between key switch connector M80 terminals 3 and 4.

Terminals	Condition	Continuity
3 - 4	Key is inserted.	Yes
	Key is removed.	No

OK or NG

- OK >> GO TO 3.
- NG >> Replace key switch.




POWER DOOR LOCK SYSTEM

3. CHECK KEY SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between the BCM harness connector M18 terminal 37 (B/R) and key switch harness connector M80 terminal 4 (B/R).
3. Check continuity between BCM harness connector M18 terminal 37 (B/R) and ground.

37 (B/R) - 4 (B/R) : Continuity should exist
37 (B/R) - Ground : Continuity should not exist



OK or NG

OK >> Check the following.

- 10A fuse [No. 19, located in fuse block (J/B)]
- Harness for open or short between key switch and key lock solenoid and fuse

NG >> Repair or replace harness.

Key Switch (Insert) Check (Floor Shift)


EIS002PZ

1. CHECK KEY SWITCH AND KEY LOCK SOLENOID INPUT SIGNAL

With CONSULT-II

Check key switch "KEY ON SW" in DATA MONITOR mode with CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).

- When key is inserted to ignition key cylinder:
KEY ON SW : ON
- When key is removed from ignition key cylinder:
KEY ON SW : OFF




Without CONSULT-II

Check voltage between BCM connector M18 terminal 37 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V)
	(+)	(-)		
M18	37 (B/R)	Ground	Key is inserted.	Battery voltage
			Key is removed.	0

OK or NG

- OK >> System is OK.
 NG >> GO TO 2.



POWER DOOR LOCK SYSTEM


2. CHECK KEY SWITCH (INSERT)

1. Turn ignition switch OFF.
2. Disconnect key switch and key lock solenoid connector.
3. Check continuity between key switch and key lock solenoid connector terminals 3 and 4.

Terminals	Condition	Continuity
3 - 4	Key is inserted.	Yes
	Key is removed.	No

OK or NG

- OK >> GO TO 3.
 NG >> Replace key switch and key lock solenoid.




3. CHECK KEY SWITCH AND KEY LOCK SOLENOID CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between the BCM harness connector M18 terminal 37 (B/R) and key switch and key lock solenoid harness connector M27 terminal 4 (B/R).
3. Check continuity between BCM harness connector M18 terminal 37 (B/R) and ground.

37 (B/R) - 4 (B/R) : Continuity should exist
37 (B/R) - Ground : Continuity should not exist

OK or NG

- OK >> Check the following.
- 10A fuse [No. 19, located in fuse block (J/B)]
 - Harness for open or short between key switch and key lock solenoid and fuse
- NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM

EIS002P3

Door Lock/Unlock Switch Check (King Cab)

1. CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

 With CONSULT-II

Check door lock/unlock switch ("CDL LOCK SW", "CDL UNLOCK SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).

- When door lock/unlock switch is turned to LOCK:

CDL LOCK SW :ON

- When door lock/unlock switch is turned to UNLOCK:


CDL UNLOCK SW :ON


DATA MONITOR	
MONITOR	
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF

PIIA6538E

 Without CONSULT-II

- Remove key from ignition key cylinder.
- Check the signal between BCM connector M18 terminal 22 and ground with oscilloscope when door lock/unlock switch is turned to LOCK or UNLOCK.
- Make sure the signals which are shown in the figure below can be detected during 10 seconds just after the door lock/unlock switch is turned to LOCK or UNLOCK.

Connector	Terminal (Wire color)		Signal (Reference value)
	(+)	(-)	
M18	22 (G)	Ground	 <p>PIIA1297E</p>



OK or NG

- OK >> Door lock and unlock switch circuit is OK.
- NG >> GO TO 2.

2. CHECK BCM OUTPUT SIGNAL

Check ("POWER WINDOW DOWN") in ACTIVE TEST mode for "REMOTE KEYLESS ENTRY SYSTEM" with CONSULT-II. Refer to [BL-71, "Active Test"](#).

When "ACTIVE TEST" is performed, are the front windows lowered?

OK or NG

- OK >> GO TO 3.
- NG >> Replace BCM. Refer to [BCS-25, "Removal and Installation of BCM"](#).

ACTIVE TEST	
POWER WINDOW DOWN	OFF
ON	


PIIA3080E

POWER DOOR LOCK SYSTEM

3. CHECK DOOR LOCK/UNLOCK SWITCH GROUND HARNESS

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch or power window and door lock/unlock switch RH.
3. Check continuity between main power window and door lock/unlock switch connector D7 terminal 15 and ground.

15 (B) - Ground : Continuity should exist




4. Check continuity between power window and door lock/unlock switch RH connector D105 terminal 11 and ground.

11 (B) - Ground : Continuity should exist

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness.




POWER DOOR LOCK SYSTEM

4. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Disconnect BCM.
2. Check continuity between BCM connector M18 terminal 22 and main power window and door lock/unlock switch connector D7 terminal 12.

22 (G) - 12 (LG/W) : Continuity should exist




3. Check continuity between BCM connector M18 terminal 22 and power window and door lock/unlock switch RH connector D105 terminal 16.

22 (G) - 16 (LG/W) : Continuity should exist

OK or NG

- OK >> Replace main power window and door lock/unlock switch or power window and door lock/unlock switch RH.
- NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM

EIS00200

Door Lock/Unlock Switch Check (Crew Cab)

1. CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

 With CONSULT-II

Check door lock/unlock switch ("CDL LOCK SW", "CDL UNLOCK SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).

- When door lock/unlock switch is turned to LOCK:

CDL LOCK SW :ON

- When door lock/unlock switch is turned to UNLOCK:


CDL UNLOCK SW :ON


DATA MONITOR	
MONITOR	
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF

PIIA6538E

 Without CONSULT-II

- Remove key from ignition key cylinder.
- Check the signal between BCM connector M18 terminal 22 and ground with oscilloscope when door lock/unlock switch is turned to LOCK or UNLOCK.
- Make sure the signals which are shown in the figure below can be detected during 10 seconds just after the door lock/unlock switch is turned to LOCK or UNLOCK.

Connector	Terminal (Wire color)		Signal (Reference value)
	(+)	(-)	
M18	22 (G)	Ground	 <p>PIIA1297E</p>



OK or NG

- OK >> Door lock and unlock switch circuit is OK.
- NG >> GO TO 2.

2. CHECK BCM OUTPUT SIGNAL

Check ("POWER WINDOW DOWN") in ACTIVE TEST mode for "REMOTE KEYLESS ENTRY SYSTEM" with CONSULT-II. Refer to [BL-71, "Active Test"](#).

When "ACTIVE TEST" is performed, are the front windows lowered?

OK or NG

- OK >> GO TO 3.
- NG >> Replace BCM. Refer to [BCS-25, "Removal and Installation of BCM"](#).

ACTIVE TEST	
POWER WINDOW DOWN	OFF
ON	


PIIA3080E

POWER DOOR LOCK SYSTEM

3. CHECK DOOR LOCK/UNLOCK SWITCH GROUND HARNESS

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch or power window and door lock/unlock switch RH.
3. Check continuity between main power window and door lock/unlock switch connector D8 terminal 17 and ground.

17 (B) - Ground : Continuity should exist




4. Check continuity between power window and door lock/unlock switch RH connector D105 terminal 11 and ground.

11 (B) - Ground : Continuity should exist

OK or NG

- OK >> GO TO 4.
NG >> Repair or replace harness.




POWER DOOR LOCK SYSTEM

4. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Disconnect BCM.
2. Check continuity between BCM connector M18 terminal 22 and main power window and door lock/unlock switch connector D7 terminal 14.

22 (G) - 14 (LG/W) : Continuity should exist




3. Check continuity between BCM connector M18 terminal 22 and power window and door lock/unlock switch RH connector D105 terminal 16.

22 (G) - 16 (LG/W) : Continuity should exist

OK or NG

OK >> Replace main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

NG >> Repair or replace harness.



Door Lock Actuator Check (Front LH)

1. CHECK DOOR LOCK ACTUATOR SIGNAL


Check voltage between BCM connector M20 terminals 59, 65 and ground.

Con- nec- tor	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M20	59 (G)	Ground	Driver door lock/unlock switch is turned to UNLOCK	0 → Battery voltage
	65 (V)		Driver door lock/unlock switch is turned to LOCK	0 → Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Replace BCM. Refer to [BCS-25, "Removal and Installation of BCM"](#) .



POWER DOOR LOCK SYSTEM


2. CHECK DOOR LOCK ACTUATOR HARNESS

1. Disconnect BCM and front door lock assembly LH.
2. Check continuity between BCM connector M20 terminals 59, 65 and front door lock assembly LH connector D14 terminals 2, 3.

Connector	Terminals (Wire color)	Connector	Terminals (wire color)	Continuity
M20	59 (G)	D14	2 (G)	Yes
	65 (V)		3 (V)	Yes

3. Check continuity between BCM connector M20 terminals 59, 65 and ground.

Connector	Terminals (Wire color)	Continuity
M20	59 (G)	No
	65 (V)	No



OK or NG

- OK >> Replace front door lock assembly LH. Refer to [BL-128, "Removal and Installation"](#) .
- NG >> Repair or replace harness.

POWER DOOR LOCK SYSTEM


EIS002P5

Door Lock Actuator Check (Front RH)

1. CHECK DOOR LOCK ACTUATOR SIGNAL

Check voltage between BCM connector M20 terminals 65, 66 and ground.

Con- nec- tor	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M20	65 (V)	Ground	Door lock/unlock switch is turned to LOCK	0 → Battery voltage
	66 (G/Y)		Door lock/unlock switch is turned to UNLOCK	0 → Battery voltage



OK or NG

OK >> GO TO 2.

NG >> Replace BCM. Refer to [BCS-25, "Removal and Installation of BCM"](#).


2. CHECK DOOR LOCK ACTUATOR HARNESS

1. Disconnect BCM and door lock actuator RH.
2. Check continuity between BCM connector M20 terminals 65, 66 and front door lock actuator RH terminals 2, 3.

Terminal	Terminal	Continuity
65 (V)	3 (V)	Yes
66 (G/Y)	2 (G/Y)	Yes

3. Check continuity between BCM connector M19 terminals 65, 66 and ground.

Terminals (Wire color)	Continuity
65 (V)	No
66 (G/Y)	No



OK or NG

OK >> Replace front door lock actuator RH. Refer to [BL-128, "Removal and Installation"](#).

NG >> Repair or replace harness.

POWER DOOR LOCK SYSTEM


EIS002P6

Door Lock Actuator Check (Rear RH/LH)

1. CHECK DOOR LOCK ACTUATOR SIGNAL

Check voltage between BCM connector M20 terminals 65, 66 and ground.

Con- nec- tor	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M20	65 (V)	Ground	Door lock/unlock switch is turned to LOCK	0 → Battery voltage
	66 (G/Y)		Door lock/unlock switch is turned to UNLOCK	0 → Battery voltage



OK or NG

OK >> GO TO 2.

NG >> Replace BCM. Refer to [BCS-25, "Removal and Installation of BCM"](#).


2. CHECK DOOR LOCK ACTUATOR HARNESS

1. Disconnect BCM and inoperative door lock actuator.
2. Check continuity between BCM connector M20 terminals 65, 66 and rear door lock actuator connector terminals 2, 3.

Terminal		Continuity
65 (V)	3 (V)	Yes
66 (G/Y)	2 (G/Y)	Yes

3. Check continuity between BCM connector M20 terminals 65, 66 and ground.

Terminals (Wire color)		Continuity
65 (V)	Ground	No
66 (G/Y)		No



OK or NG

OK >> Replace door lock actuator. Refer to [BL-132, "Removal and Installation"](#).

NG >> Repair or replace harness.

POWER DOOR LOCK SYSTEM

Front Door Lock Assembly LH (Key Cylinder Switch) Check (King Cab)


EIS002P7

1. CHECK DOOR KEY CYLINDER SWITCH LH

Ⓜ With CONSULT-II

Check front door lock assembly LH (key cylinder switch) ("KEY CYL LK-SW") and ("KEY CYL UN-SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).


- When key inserted in front key cylinder is turned to LOCK:
KEY CYL LK-SW : ON
- When key inserted in front key cylinder is turned to UNLOCK:
KEY CYL UN-SW : ON



⊗ Without CONSULT-II

Check voltage between main power window and door lock/unlock switch connector D7 terminals 6, 7 and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	6 (L)	Ground	Neutral/Unlock	5
			Lock	0
	7 (R)		Neutral/Lock	5
			Unlock	0



OK or NG

- OK >> Front door lock assembly LH (key cylinder switch) signal is OK.
- NG >> GO TO 2.


2. CHECK DOOR KEY CYLINDER SWITCH LH

- Disconnect front door lock assembly LH (key cylinder switch).
- Check continuity between door key cylinder switch LH connector terminals 1, 5 and 6.

Terminals	Condition	Continuity
1 - 5	Key is turned to LOCK.	Yes
6 - 5	Key is turned to UNLOCK.	Yes

OK or NG

- OK >> Check the following.
 - Front door lock assembly LH (key cylinder switch) ground circuit.
 - Harness for open or short between main power window and door lock/unlock switch and front door lock assembly LH (key cylinder switch).
- NG >> Replace front door lock assembly LH (key cylinder switch). Refer to [BL-128, "Removal and Installation"](#).



POWER DOOR LOCK SYSTEM

Front Door Lock Assembly LH (Key Cylinder Switch) Check (Crew Cab)

EIS002Q1

1. CHECK DOOR KEY CYLINDER SWITCH LH

Ⓟ With CONSULT-II

Check front door lock assembly LH (key cylinder switch) ("KEY CYL LK-SW") and ("KEY CYL UN-SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).

- When key inserted in front key cylinder is turned to LOCK:

KEY CYL LK-SW : ON

- When key inserted in front key cylinder is turned to UNLOCK:

KEY CYL UN-SW : ON


DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

LIIA0188E

ⓧ Without CONSULT-II

Check voltage between main power window and door lock/unlock switch connector D7 terminals 4, 6 and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	4 (L)	Ground	Neutral/Unlock	5
			Lock	0
	6 (R)		Neutral/Lock	5
			Unlock	0



OK or NG

- OK >> Front door lock assembly LH (key cylinder switch) signal is OK.
- NG >> GO TO 2.

2. CHECK DOOR KEY CYLINDER SWITCH LH

- Disconnect front door lock assembly LH (key cylinder switch).
- Check continuity between door key cylinder switch LH connector terminals 1, 5 and 6.


Terminals	Condition	Continuity
1 - 5	Key is turned to LOCK.	Yes
6 - 5	Key is turned to UNLOCK.	Yes

OK or NG

OK >> Check the following.

- Front door lock assembly LH (key cylinder switch) ground circuit.
- Harness for open or short between main power window and door lock/unlock switch and front door lock assembly LH (key cylinder switch).

NG >> Replace front door lock assembly LH (key cylinder switch). Refer to [BL-128, "Removal and Installation"](#).




REMOTE KEYLESS ENTRY SYSTEM

REMOTE KEYLESS ENTRY SYSTEM

Component Parts and Harness Connector Location

PFP:28596

EIS002FQ



A
B
C
D
E
F
G
H
I
J
K
L
M

BL

W1IA0320E

REMOTE KEYLESS ENTRY SYSTEM

EIS002FR

System Description

INPUTS

Power is supplied at all times

- to BCM terminal 70
- through 50A fusible link (letter f , located in the fuse and fusible link box).
- to BCM terminal 57
- through 15A fuse [No. 22, located in the fuse block (J/B)].

When the key switch and key lock solenoid is ON (inserted), power is supplied

- to BCM terminal 37
- through key switch and key lock solenoid terminals 3 and 4
- through 10A fuse [No. 19, located in the fuse block (J/B)].

When the ignition switch is ACC or ON, power is supplied

- to BCM terminal 11
- through 10A fuse [No. 4, located in the fuse block (J/B)].

When the ignition switch is ON or START, power is supplied

- to BCM terminal 38
- through 10A fuse (No. 59, located in the fuse and relay box).

KING CAB

BCM is connected to main power window and door lock/unlock switch and power window and door lock/unlock switch RH through a serial link.

When the front door switch LH is ON (door is open), ground is supplied

- to BCM terminal 47
- through front door switch LH terminals 2 and 3
- through grounds B7 and B19.

When the rear door switch upper LH is ON (door is open), ground is supplied

- to BCM terminal 47
- through rear door switch upper LH terminals 1 and 2
- through grounds B7 and B19.

When the rear door switch lower LH is ON (door is open), ground is supplied

- to BCM terminal 47
- through rear door switch lower LH terminals 1 and 2
- through grounds B7 and B19.

When the front door switch RH is ON (door is open), ground is supplied

- to BCM terminal 12
- through front door switch RH terminals 2 and 3
- through grounds B117 and B132.

When the rear door switch upper RH is ON (door is open), ground is supplied

- to BCM terminal 12
- through rear door switch upper RH terminals 1 and 2
- through grounds B117 and B132.

When the rear door switch lower RH is ON (door is open), ground is supplied

- to BCM terminal 12
- through rear door switch lower RH terminals 1 and 2
- through grounds B117 and B132.

CREW CAB

BCM is connected to main power window and door lock/unlock switch and power window and door lock/unlock switch RH through a serial link.

When the front door switch LH is ON (door is open), ground is supplied

- to BCM terminal 47

REMOTE KEYLESS ENTRY SYSTEM

- through front door switch LH terminal 2
- through front door switch LH case ground.

When the front door switch RH is ON (door is open), ground is supplied

- to BCM terminal 12
- through front door switch RH terminal 2
- through front door switch RH case ground.

When the rear door switch LH is ON (door is open), ground is supplied

- to BCM terminal 48
- through rear door switch LH terminal 2
- through rear door switch LH case ground.

When the rear door switch RH is ON (door is open), ground is supplied

- to BCM terminal 13
- through rear door switch RH terminal 2
- through rear door switch RH case ground.

Key fob signal is inputted to BCM from the remote keyless entry receiver.
The remote keyless entry system controls operation of the

- power door lock
- interior lamp and step lamps
- panic alarm
- hazard and horn reminder
- keyless power window down (open)
- auto door lock operation

OPERATED PROCEDURE

- When the key fob is operated, the signal from the key fob is sent and the remote keyless entry receiver receives the signal and sends it to the BCM. The BCM only locks/unlocks the doors if the ID number matches. (Remote control entry functions)
- Using the key fob, the transmitter sends radio waves to the remote keyless entry receiver, which then sends the received waves to the BCM. Only if the ID number matches does the BCM lock/unlock the doors. (Remote control door function)
- Unless the key is inserted into the ignition key cylinder or one of the doors is opened within 1 minute after the UNLOCK switch on the key fob is pressed, all the doors are automatically locked. (Auto lock function)
- When a door is locked or unlocked, the vehicle turn signal lamps flash and the horn sounds to verify operation. (Active check function)
- When the key is in the ignition key cylinder [when the key switch and key lock solenoid is ON (inserted)] and one of the doors is open, the door lock function does not work even when the door lock is operated with the key fob.
- Key fob ID set up is available.
- If a key fob is lost, a new key fob can be set up. A maximum of 5 IDs can be set up simultaneously.

Remote Control Entry Functions

Operation Description

- When a button on the key fob is operated, the signal is sent from the key fob and received by the keyless remote entry receiver.
- The received signal is sent to the BCM and compared with the registered ID number.
- If the ID number matches, the BCM uses communication to send the lock/unlock signal to each door lock actuator.
- When the door lock actuators receive this communication, each operates to lock/unlock its door.

Remote control entry operation conditions

A

B

C

D

E

F

G

H

BL

J

K

L

M

REMOTE KEYLESS ENTRY SYSTEM

Key fob operation	Operation condition
Door lock operation (locking)	<ul style="list-style-type: none"> ● With key removed (key switch: OFF) ● Closing all doors (door switch: OFF)
Door lock operation (unlocking)	With key removed (key switch: OFF)

Auto Lock Function

Operation Description

- Unless the key is inserted into the ignition key cylinder, one of the doors is opened, or the key fob is operated within 1 minute after a door lock is unlocked by key fob operation, all the doors are automatically locked.
The 1 minute timer count is executed by the BCM and after 1 minute, the BCM sends the lock signal to all doors.
Lock operations are the same as for the remote control entry function.

Active Check Function

Operation Description

When a door is locked or unlocked by key fob operation, the vehicle turn signals flash and the horn sounds to verify operation.

- When a button on the key fob is operated, the signal is sent from the remote controller and received by the keyless remote entry receiver.
- The received signal is sent to the BCM and compared with the registered ID number.
- If the ID number matches, the BCM uses communication to send the turn signal flashing and horn signal to the IPDM E/R.
- The IPDM E/R flashes the turn signal lamps and sounds the horn for each key fob operation.

Operating function of hazard and horn reminder

	C mode		S mode	
	Lock	Unlock	Lock	Unlock
Key fob operation	Lock	Unlock	Lock	Unlock
Hazard warning lamp flash	Twice	Once	Twice	—
Horn sound	Once	—	—	—

Hazard and Horn Reminder

BCM output to IPDM E/R for horn reminder signal as DATA LINE (CAN H line and CAN L line).
The hazard and horn reminder has C mode (horn chirp mode) and S mode (non-horn chirp mode).

Operating function of hazard and horn reminder

	C mode		S mode	
	Lock	Unlock	Lock	Unlock
Remote controller operation	Lock	Unlock	Lock	Unlock
Hazard warning lamp flash	Twice	Once	Twice	—
Horn sound	Once	—	—	—

How to change hazard and horn reminder mode


④ With CONSULT-II

Hazard and horn reminder can be changed using "WORK SUPPORT" mode in "MULTI ANSWER BACK SET".

⊗ Without CONSULT-II

REMOTE KEYLESS ENTRY SYSTEM

When LOCK and UNLOCK signals are sent from the key fob for more than 2 seconds at the same time, the hazard and horn reminder mode is changed and hazard warning lamp flashes and horn sounds as follows:



SEL153WA

Interior Lamp Operation

When the following input signals are both supplied:

- all door switches are in the OFF position. (when all the doors are closed);
- interior lamp switch is in DOOR position.

Remote keyless entry system turns on interior lamp and ignition illumination (for 30 seconds) with input of UNLOCK signal from key fob.

For detailed description, refer to [LT-132, "ROOM LAMP TIMER OPERATION"](#).

Panic Alarm Operation

When key switch is OFF (when ignition key is removed from the key cylinder), remote keyless entry system turns on and off horn and headlamp intermittently with input of PANIC ALARM signal from key fob.

The alarm automatically turns off after 25 seconds or when BCM receives any signal from key fob.

Keyless Power Window Down (open) Operation

When key fob unlock switch is turned ON with ignition switch OFF, and the switch is detected to be on continuously for 3 seconds, the driver's door and passenger's door power windows are simultaneously opened.

Power window is operated to open and the operation continues as long as the key fob unlock switch is pressed.

REMOTE KEYLESS ENTRY SYSTEM

CAN Communication System Description

EIS002FS


Refer to [LAN-8, "CAN COMMUNICATION"](#) .

REMOTE KEYLESS ENTRY SYSTEM

Schematic (King Cab)

EIS002FT

CS : COLUMN SHIFT
FS : FLOOR SHIFT



A
B
C
D
E
F
G
H
I
J
K
L
M





WIWA0279E

REMOTE KEYLESS ENTRY SYSTEM

EIS002FU

Wiring Diagram — KEYLES — (King Cab)

BL-KEYLES-01





REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


WIWA0280E

REMOTE KEYLESS ENTRY SYSTEM

BL-KEYLES-02





REFER TO THE FOLLOWING.
M40 - SUPER MULTIPLE JUNCTION (SMJ)



W1WA0281E

REMOTE KEYLESS ENTRY SYSTEM

BL-KEYLES-03



M18
W



B108
W



B156
B

B157
B


REFER TO THE FOLLOWING.
M36 - SUPER MULTIPLE JUNCTION (SMJ)

LIWA0305E

REMOTE KEYLESS ENTRY SYSTEM


BL-KEYLES-04

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
K
L
M

BL



REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)


W1WA0282E

REMOTE KEYLESS ENTRY SYSTEM

Schematic (Crew Cab)

EIS002QP

CS : COLUMN SHIFT
FS : FLOOR SHIFT





WIWA0283E

REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — KEYLES — (Crew Cab)

EIS002QQ

BL-KEYLES-05




REFER TO THE FOLLOWING.
 M31 - SUPER MULTIPLE JUNCTION (SMJ)

W1WA0284E



REMOTE KEYLESS ENTRY SYSTEM

BL-KEYLES-06

— : DATA LINE





REFER TO THE FOLLOWING.
 (M36), (M40) - SUPER MULTIPLE JUNCTION (SMJ)



WIWA0285E

REMOTE KEYLESS ENTRY SYSTEM

BL-KEYLES-07




REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

W1WA0286E

REMOTE KEYLESS ENTRY SYSTEM

EIS002FV

Terminals and Reference Value for BCM

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
11	O	Ignition switch (ACC)	Ignition switch in ACC	Battery voltage
12	R/L	Front door switch RH (All)	Door close (OFF) → Open (ON)	Battery voltage → 0
		Rear door switch upper RH (King Cab)		
		Rear door switch lower RH (King Cab)		
13	GR	Rear door switch RH (Crew Cab)	Door close (OFF) → Open (ON)	Battery voltage → 0
18	P	Ground	—	0
19	V/W	Remote keyless entry receiver power supply	—	5
20	G/W	Remote keyless entry receiver signal	—	
37	B/R	Key switch	Key inserted in IGN key cylinder → Key removed from IGN key cylinder	Battery voltage → 0
38	W/L	Ignition switch (ON)	Ignition switch ON	Battery voltage
39	W	CAN-H	—	—
40	R	CAN-L	—	—
47	SB	Front door switch LH (All)	Door close (OFF) → Open (ON)	Battery voltage → 0
		Rear door switch upper LH (King Cab)		
		Rear door switch lower LH (King Cab)		
48	R/Y	Rear door switch LH (Crew Cab)	Door close (OFF) → Open (ON)	Battery voltage → 0
56	R/G	Battery saver (Interior lamp)	Battery saver does operated → Does not operated (ON → OFF)	Battery voltage → 0
57	Y/R	Power source (BAT)	—	Battery voltage
59	G	Driver door lock actuator	Door lock & unlock switch (Neutral → Unlock)	0 → Battery voltage
60	G/B	Turn signal LH	When doors are locked or unlocked using key fob (OFF → ON) *2	0 → Battery voltage
61	G/Y	Turn signal RH	When doors are locked or unlocked using key fob (OFF → ON) *2	0 → Battery voltage
62	R/W	Step lamp LH and RH	Step lamp ON	0
			Step lamp OFF	Battery voltage
63	L	Room lamp	Room lamp ON *1	Battery voltage
			Room Lamp OFF *1	0
65	V	Door lock actuators	Door lock & unlock switch (Neutral → Lock)	0 → Battery voltage
66	G/Y	Passenger and rear doors lock actuator	Door lock & unlock switch (Neutral → Unlock)	0 → Battery voltage
67	B	Ground	—	0

REMOTE KEYLESS ENTRY SYSTEM

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
69	W/R	Power window power source	—	Battery voltage
70	W/B	Power source (BAT)	—	Battery voltage

- *1: when room lamp switch is in "DOOR" position.
- *2: when hazard reminder is ON.

Terminals and Reference Value for IPDM E/R

EIS002FW

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
38	B	Ground	—	0
39	W	CAN-H	—	—
40	R	CAN-L	—	—
45	G/W	Horn relay	When doors locks are operated using key fob (OFF → ON) *	Battery voltage → 0
59	B	Ground	—	0

*: when horn reminder is ON.

CONSULT-II Function

EIS002P8

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnosis position	Inspection items and diagnosis mode		Description
BCM C/U*	Self-diagnosis results		Carries out the self-diagnosis.
	Data monitor	Selection from menu	Displays the input data to BCM on real-time basis.
	CAN diagnostic support monitor		The results of transmit/receive diagnosis of CAN communication can be read.
MULTI REMOTE ENT	Data monitor		Displays the input remote keyless entry system data to BCM on real-time basis.
	Active test		Gives a drive to a load to check the operation.
	Work support		Changes the setting for each function.

*:Refer to [BCS-13, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#).

REMOTE KEYLESS ENTRY SYSTEM


EIS002P9

CONSULT-II Inspection Procedure "MULTI REMOTE ENT"


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.




3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "BCM".
If "BCM" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




6. Touch "MULTI REMOTE ENT".



REMOTE KEYLESS ENTRY SYSTEM

7. Select diagnosis mode.
 "DATA MONITOR", "ACTIVE TEST" and "WORK SUPPORT"
 are available.



CONSULT-II Application Items "MULTI REMOTE ENT"

EIS002PA

Data Monitor

Monitored Item	Description
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch LH.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
KEYLESS PANIC	Indicates [ON/OFF] condition of panic signal from key fob.
KEYLESS UNLOCK	Indicates [ON/OFF] condition of unlock signal from key fob.
KEYLESS LOCK	Indicates [ON/OFF] condition of lock signal from key fob.
KEY CYL LK-SW	Indicates [ON/OFF] condition of lock signal from door key cylinder switch.
KEY CYL UN-SW	Indicates [ON/OFF] condition of unlock signal from door key cylinder switch.
CDL UNLOCK SW	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch.
CDL LOCK SW	Indicates [ON/OFF] condition of lock signal from lock/unlock switch.
RKE LCK-UNLCK	Indicates [ON/OFF] condition of lock/unlock signal at the same time from key fob.
RKE KEEP UNLK	Indicates [ON/OFF] condition of unlock signal from key fob.

Active Test

Test Item	Description
FLASHER	This test is able to check right and left hazard reminder operation. The right hazard lamp turns on when "RH" on CONSULT-II screen is touched and the left hazard lamp turns on when "LH" on CONSULT-II screen is touched.
POWER WINDOW DOWN	This test is able to check power window down operation. The windows are lowered when "ON" on CONSULT-II screen is touched.
HORN	This test is able to check panic alarm and horn reminder operations. The alarm activate for 0.5 seconds after "ON" on CONSULT-II screen is touched.
DOOR LOCK	This test is able to check door lock operation. The doors lock and unlock based on the item on CONSULT-II screen touched.

Work Support

Test Item	Description
REMO CONT ID REGIST	Key fob ID code can be registered.
REMO CONT ID ERASUR	Key fob ID code can be erased.
REMO CONT ID CONFIR	It can be checked whether key fob ID code is registered or not in this mode.
HORN CHIRP SET	Horn chirp function mode can be changed in this mode. The function mode will be changed when "CHANG SETT" on CONSULT-II screen is touched.

REMOTE KEYLESS ENTRY SYSTEM

Test Item	Description
HAZARD LAMP SET	Hazard lamp function mode can be changed in this mode. The function mode will be changed when "CHANG SETT" on CONSULT-II screen is touched.
MULTI ANSWER BACK SET	Hazard and horn reminder mode can be changed in this mode. The reminder mode will be changed when "CHANG SETT" on CONSULT-II screen is touched.
AUTO LOCK SET	Auto locking function mode can be changed in this mode. The function mode will be changed when "CHANG SETT" on CONSULT-II screen is touched.
PANIC ALRM SET	Panic alarm operation mode can be changed in this mode. The operation mode will be changed when "CHANG SETT" on CONSULT-II screen is touched.
PW DOWN SET	Keyless power window down (open) operation mode can be changed in this mode. The operation mode will be changed when "CHANG SETT" on CONSULT-II screen is touched.

Hazard and horn reminder mode

	MODE 1 (C mode)		MODE 2 (S mode)		MODE 3		MODE 4		MODE 5		MODE 6	
	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock
Key fob operation												
Hazard warning lamp flash	Twice	Once	Twice	—	—	—	Twice	Once	Twice	—	—	Once
Horn sound	Once	—	—	—	—	—	—	—	Once	—	Once	—

Auto locking function mode

	MODE 1	MODE 2	MODE 3
Auto locking function	5 minutes	Nothing	1 minute

Panic alarm operation mode

	MODE 1	MODE 2	MODE 3
Key fob operation	0.5 seconds	Nothing	1.5 seconds

Keyless power window down operation mode

	MODE 1	MODE 2	MODE 3
Key fob operation	3 seconds	Nothing	5 seconds

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnosis Procedure

EIS002PB

1. Check the trouble symptom and customer's requests.
2. Understand outline of system. Refer to [BL-54, "System Description"](#) .
3. Confirm system operation.
 - Check that the power door lock system operates normally. Refer to [BL-16, "POWER DOOR LOCK SYSTEM"](#) .
4. Perform pre-diagnosis inspection. Refer to [BL-73, "Pre-Diagnosis Inspection"](#) .
5. Refer to trouble diagnosis chart by symptom, repair or replace any malfunctioning parts. Refer to [BL-74, "Trouble Diagnoses"](#) .
6. Inspection End.

Pre-Diagnosis Inspection

EIS002ZW

1. CHECK BCM CONFIGURATION

Confirm BCM Configuration for "KEYLESS ENTRY" is set to "WITH". Refer to [BCS-13, "READ CONFIGURATION PROCEDURE"](#) .

OK or NG

- OK >> Continue Trouble Diagnosis. Refer to [BL-73, "BCM Power Supply and Ground Circuit Check"](#) .
- NG >> Change BCM Configuration for "KEYLESS ENTRY" to "WITH". Refer to [BCS-16, "WRITE CONFIGURATION PROCEDURE"](#) .

BCM Power Supply and Ground Circuit Check

EIS002ZS

1. CHECK FUSE

Check the following BCM fuses and fusible link.

Component Parts	Terminal No. (SIGNAL)	Ampere	No.	Location
BCM	57 (BAT power supply)	15A	22	Fuse block (J/B)
	70 (BAT power supply)	50A	f	Fuse and fusible link box
	11 (ACC power supply)	10A	4	Fuse block (J/B)
	38 (IGN power supply)	10A	59	Fuse and relay box

NOTE:

Refer to [BL-16, "Component Parts and Harness Connector Location"](#) .

OK or NG


- OK >> GO TO 2.
- NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse, refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

REMOTE KEYLESS ENTRY SYSTEM

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM connectors M18, M20 terminals 11, 38, 57, 70 and ground.

Connector	Terminals (Wire color)		Signal name	Ignition switch	Voltage
	(+)	(-)			
M20	70 (W/B)	Ground	Battery power supply	OFF	Battery voltage
	57 (Y/R)		Battery power supply	OFF	Battery voltage
M18	11 (O)		ACC power supply	ACC	Battery voltage
	38 (W/L)		IGN power supply	ON	Battery voltage




OK or NG

- OK >> GO TO 3.
 NG >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M20 terminal 67 and ground.

Connector	Terminals (Wire color)		Continuity
	(+)	(-)	
M20	67 (B)	Ground	Yes



OK or NG

- OK >> Power supply and ground circuit is OK.
 NG >> Repair or replace harness.

Trouble Diagnoses SYMPTOM CHART

NOTE:

- Always check the "Trouble Diagnosis Procedure" before troubleshooting. Refer to [BL-73, "Trouble Diagnosis Procedure"](#).
- Always check key fob battery before replacing key fob. Refer to [BL-82, "Key Fob Battery and Function Check"](#).
- The panic alarm operation and trunk lid opener operation of remote keyless entry system do not activate with the ignition key inserted in the ignition key cylinder.
- Use Remote Keyless Entry Tester J-43241 (follow instructions on tester) to check operation of key fob before replacing key fob.

EIS002PD

REMOTE KEYLESS ENTRY SYSTEM

Symptom	Diagnoses/service procedure	Reference page	
All function of remote keyless entry system do not operate.	1. Key fob battery and function check (use Remote Keyless Entry Tester J-43241)	BL-82	A
	2. Replace key fob (use Remote Keyless Entry Tester J-43241). Refer to ID Code Entry Procedure. NOTE: If the result of key fob function check with CONSULT-II is OK, Key fob is not malfunctioning.	BL-88	B
	3. Check keyless receiver.	BL-83	C
	4. Replace BCM.	BCS-25	D
The new ID of key fob cannot be entered.	1. Key fob battery and function check (use Remote Keyless Entry Tester J-43241)	BL-82	
	2. Key switch (insert) check	BL-77 , BL-78	E
	3. Door switch check	BL-80 , BL-81	F
	4. ACC power check	BL-85	
	5. Replace key fob (use Remote Keyless Entry Tester J-43241). Refer to ID Code Entry Procedure. NOTE: If the result of key fob function check with CONSULT-II is OK, Key fob is not malfunctioning.	BL-88	G
	6. Replace BCM.	BCS-25	H
Door lock or unlock does not function. (If the power door lock system does not operate manually, check power door lock system. Refer to BL-16 . "POWER DOOR LOCK SYSTEM")	1. Key fob battery and function check (use Remote Keyless Entry Tester J-43241)	BL-82	BL
	2. Replace key fob (use Remote Keyless Entry Tester J-43241). Refer to ID Code Entry Procedure. NOTE: If the result of key fob function check with CONSULT-II is OK, Key fob is not malfunctioning.	BL-88	J
	3. Replace BCM.	BCS-25	K
Hazard and horn reminder does not activate properly when pressing lock or unlock button of key fob.	1. Check hazard and horn reminder mode with CONSULT-II NOTE: Hazard and horn reminder mode can be changed. First check the hazard and horn reminder mode setting.	BL-71	L
	2. Door switch check	BL-80 , BL-81	
	3. Replace BCM.	BCS-25	M
Hazard reminder does not activate properly when pressing lock or unlock button of key fob. (Horn reminder OK)	1. Check hazard reminder mode with CONSULT-II NOTE: Hazard reminder mode can be changed. First check the hazard reminder mode setting.	BL-71	
	2. Check hazard function with hazard switch	—	
	3. Replace BCM.	BCS-25	
Horn reminder does not activate properly when pressing lock or unlock button of key fob. (Hazard reminder OK)	1. Check horn reminder mode with CONSULT-II NOTE: Horn reminder mode can be changed. First check the horn reminder mode setting.	BL-71	
	2. Check horn function with horn switch	—	
	3. IPDM E/R operation check	BL-85	
	4. Replace BCM.	BCS-25	

REMOTE KEYLESS ENTRY SYSTEM

Symptom	Diagnoses/service procedure	Reference page
Room lamp, ignition key illumination and step lamp operation do not activate properly.	1. Room lamp operation check	BL-87
	2. Ignition key illumination operation check	BL-87
	3. Step lamp operation check	LT-131
	4. Door switch check	BL-80 , BL-81
	5. Replace BCM.	BCS-25
Panic alarm (horn and headlamp) does not activate when panic alarm button is continuously pressed.	1. Key fob battery and function check (use Remote Keyless Entry Tester J-43241)	BL-82
	2. Key switch (insert) check	BL-77 , BL-78
	3. Replace key fob (use Remote Keyless Entry Tester J-43241). Refer to ID Code Entry Procedure. NOTE: If the result of key fob function check with CONSULT-II is OK, key fob is not malfunctioning.	BL-88
	4. Replace BCM.	BCS-25
Auto door lock operation does not activate properly. (All other remote keyless entry functions OK.)	1. Check auto door lock operation mode with CONSULT-II NOTE: Auto door lock operation mode can be changed. First check the auto door lock operation mode setting.	BL-71
	2. Replace BCM.	BCS-25
Keyless power window down (open) operation does not activate properly. (All other remote keyless entry functions OK.)	1. Check power window down operation mode with CONSULT-II NOTE: Power window down operation mode can be changed. First check the power window down operation mode setting.	BL-71
	2. Check power window function with switch.	—
	3. Replace BCM.	BCS-25

REMOTE KEYLESS ENTRY SYSTEM

EIS002ZT


Key Switch (Insert) Check (Column Shift)

1. CHECK KEY SWITCH INPUT SIGNAL

 With CONSULT-II

Check key switch "KEY ON SW" in DATA MONITOR mode with CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).


- When key is inserted to ignition key cylinder:
KEY ON SW :ON
- When key is removed from ignition key cylinder:
KEY ON SW :OFF



 Without CONSULT-II

Check voltage between BCM connector M18 terminal 37 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V)
	(+)	(-)		
M18	37 (B/R)	Ground	Key is inserted.	Battery voltage
			Key is removed.	0



OK or NG

- OK >> System is OK.
- NG >> GO TO 2.


2. CHECK KEY SWITCH (INSERT)

- Turn ignition switch OFF.
- Disconnect key switch connector.
- Check continuity between key switch connector terminals 3 and 4.

Terminals	Condition	Continuity
3 - 4	Key is inserted.	Yes
	Key is removed.	No

OK or NG

- OK >> GO TO 3.
- NG >> Replace key switch.



REMOTE KEYLESS ENTRY SYSTEM

3. CHECK KEY SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between the BCM harness connector M18 terminal 37 (B/R) and key switch harness connector M80 terminal 4 (B/R).
3. Check continuity between BCM harness connector M18 terminal 37 (B/R) and ground.


37 (B/R) - 4 (B/R) : Continuity should exist
37 (B/R) - Ground : Continuity should not exist

OK or NG

OK >> Check the following.

- 10A fuse [No. 19, located in fuse block (J/B)]
- Harness for open or short between key switch and fuse

NG >> Repair or replace harness.



Key Switch (Insert) Check (Floor Shift)

EIS002ZU

1. CHECK KEY SWITCH AND KEY LOCK SOLENOID INPUT SIGNAL

With CONSULT-II


Check key switch "KEY ON SW" in DATA MONITOR mode with CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).

- When key is inserted to ignition key cylinder:

KEY ON SW :ON

- When key is removed from ignition key cylinder:

KEY ON SW :OFF



Without CONSULT-II


Check voltage between BCM connector M18 terminal 37 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V)
	(+)	(-)		
M18	37 (B/R)	Ground	Key is inserted.	Battery voltage
			Key is removed.	0

OK or NG

OK >> System is OK.

NG >> GO TO 2.



REMOTE KEYLESS ENTRY SYSTEM


2. CHECK KEY SWITCH (INSERT)

1. Turn ignition switch OFF.
2. Disconnect key switch and key lock solenoid connector.
3. Check continuity between key switch and key lock solenoid connector terminals 3 and 4.

Terminals	Condition	Continuity
3 - 4	Key is inserted.	Yes
	Key is removed.	No

OK or NG

- OK >> GO TO 3.
 NG >> Replace key switch and key lock solenoid.




3. CHECK KEY SWITCH AND KEY LOCK SOLENOID CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between the BCM harness connector M18 terminal 37 (B/R) and key switch and key lock solenoid harness connector M27 terminal 4 (B/R).
3. Check continuity between BCM harness connector M18 terminal 37 (B/R) and ground.

37 (B/R) - 4 (B/R) : Continuity should exist
37 (B/R) - Ground : Continuity should not exist

OK or NG

- OK >> Check the following.
- 10A fuse [No. 19, located in fuse block (J/B)]
 - Harness for open or short between key switch and key lock solenoid and fuse
- NG >> Repair or replace harness.



REMOTE KEYLESS ENTRY SYSTEM

EIS002Q5

Door Switch Check (King Cab)

1. CHECK DOOR SWITCHES INPUT SIGNAL

 With CONSULT-II

Check door switches ("DOOR SW-DR", "DOOR SW-AS") in DATA MONITOR mode with CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).

- When any doors are open:

DOOR SW-DR :ON

DOOR SW-AS :ON

- When any doors are closed:

DOOR SW-DR :OFF

DOOR SW-AS :OFF


DATA MONITOR	
MONITOR	
DOOR SW - DR	OFF
DOOR SW - AS	OFF
DOOR SW - RR	OFF
DOOR SW - RL	OFF

PIA6222E

 Without CONSULT-II

Check voltage between BCM connector M18 or M19 terminals 12, 47 and ground.

Connector	Item	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
		(+)	(-)		
M19	Door switches LH	47 (SB)	Ground	Open	0
M18	Door switches RH	12 (R/L)		Closed	Battery voltage



OK or NG

OK >> System is OK.

NG >> GO TO 2.

2. CHECK DOOR SWITCH CIRCUIT

- Turn ignition switch OFF.
- Disconnect door switch and BCM.
- Check continuity between door switch connector B8 (Front LH), B108 (Front RH) terminal 2, B73 (Rear upper LH), B156 (Rear upper RH), B74 (Rear lower LH), B157 (Rear lower RH) terminal 1 and BCM connector M18, M19 terminals 12, and 47.

2 (SB) - 47 (SB) :Continuity should exist

2 (R/L) - 12 (R/L) :Continuity should exist


1 (SB) - 47 (SB) :Continuity should exist

1 (R/L) - 12 (R/L) :Continuity should exist

- Check continuity between door switch connector B8 (Front LH), B108 (Front RH) terminal 2, B73 (Rear upper LH), B156 (Rear upper RH), B74 (Rear lower LH), B157 (Rear lower RH) terminal 1 and ground.

2 (SB or R/L) - Ground :Continuity should not exist

1 (SB or R/L) - Ground :Continuity should not exist



OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.

REMOTE KEYLESS ENTRY SYSTEM


3. CHECK DOOR SWITCHES

1. Disconnect door switch.
2. Check continuity between door switch terminals.

	Terminal	Condition	Continuity
Door switches (front)	2 - 3	Open	No
		Closed	Yes
Door switches (rear upper and lower)	1 - 2	Open	No
		Closed	Yes

OK or NG

- OK >> Repair or replace harness.
- NG >> Replace door switch.



Door Switch Check (Crew Cab)

1. CHECK DOOR SWITCHES INPUT SIGNAL

With CONSULT-II


Check door switches ("DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR") in DATA MONITOR mode with CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).

- When any doors are open:

DOOR SW-DR :ON
DOOR SW-AS :ON
DOOR SW-RL :ON
DOOR SW-RR :ON

- When any doors are closed:


DOOR SW-DR :OFF
DOOR SW-AS :OFF
DOOR SW-RL :OFF
DOOR SW-RR :OFF



Without CONSULT-II

Check voltage between BCM connector M18 or M19 terminals 12, 13, 47, 48 and ground.

Connector	Item	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
		(+)	(-)		
M19	Front door switch LH	47 (SB)	Ground	Open ↓ Closed	0 ↓ Battery voltage
	Rear door switch LH	48 (R/Y)			
M18	Front door switch RH	12 (GR/L)			
	Rear door switch RH	13 (O/B)			



OK or NG

- OK >> System is OK.
- NG >> GO TO 2.

REMOTE KEYLESS ENTRY SYSTEM


2. CHECK DOOR SWITCH CIRCUIT

- Turn ignition switch OFF.
- Disconnect door switch and BCM.
- Check continuity between door switch connector B8 (Front LH), B108 (Front RH), B18 (Rear LH), B116 (Rear RH) terminal 2 and BCM connector M18, M19 terminals 12, 13, 47 and 48.

2 (SB) - 47 (SB) :Continuity should exist
2 (R/L) - 12 (R/L) :Continuity should exist
2 (R/Y) - 48 (R/Y) :Continuity should exist
2 (R/B) - 13 (R/B) :Continuity should exist

- Check continuity between door switch connector B8 (Front LH), B108 (Front RH), B18 (Rear LH), B116 (Rear RH) terminal 2 and ground.

2 (SB, R/L, R/Y or R/W) - Ground :Continuity should not exist



OK or NG

- OK >> GO TO 3.
 NG >> Repair or replace harness.


3. CHECK DOOR SWITCHES

- Disconnect door switch.
- Check continuity between door switch terminals.

	Terminal	Condition	Continuity
Door switch (front and rear)	2 – Ground	Open	Yes
		Closed	No

OK or NG

- OK >> Check door switch case ground condition.
 NG >> Replace door switch.



Key Fob Battery and Function Check

1. CHECK KEY FOB BATTERY

Remove battery and measure voltage across battery positive and negative terminals, (+) and (-).


Voltage : 2.5V - 3.0V

NOTE:

Key fob does not function if battery is not set correctly.

OK or NG

- OK >> GO TO 2.
 NG >> Replace battery.



REMOTE KEYLESS ENTRY SYSTEM


2. CHECK KEY FOB FUNCTION

With CONSULT-II

Check key fob function in "DATA MONITOR" mode with CONSULT-II.

When pushing each button of key fob, the corresponding monitor item should be turned as follows.

Condition	Monitor item	
Pushing LOCK	KEYLESS LOCK	: ON
Pushing UNLOCK	KEYLESS UNLOCK	: ON
Keep pushing UNLOCK	RKE KEEP UNLK turns to ON 3 seconds after UNLOCK button is pushed.	: ON
Pushing PANIC	KEYLESS PANIC	: ON
Pushing LOCK and UNLOCK at the same time	RKE LCK-UNLCK	: ON



OK or NG


- OK >> Key fob is OK. Further inspection is necessary. Refer to [BL-74, "SYMPTOM CHART"](#).
- NG >> Replace key fob.

Remote Keyless Entry Receiver System Check

1. REMOTE KEYLESS ENTRY RECEIVER SIGNAL

Check signal voltage waveform between BCM connector terminal 20 and ground using an oscilloscope.

Connector	Terminal (Wire color)		Signal (Reference value.)
	(+)	(-)	
M18	20 (G/W)	Ground	



OK or NG

- OK >> Remote keyless entry receiver signal is OK.
- NG >> GO TO 2.


2. REMOTE KEYLESS ENTRY RECEIVER OUTPUT SIGNAL INSPECTION

Check voltage between remote keyless entry receiver connector M120 terminal 4 and ground.

Connector	Terminal (Wire color)		Voltage (V) (Approx.)
	(+)	(-)	
M120	4 (V/W)	Ground	5V

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 4.



REMOTE KEYLESS ENTRY SYSTEM


3. REMOTE KEYLESS ENTRY RECEIVER GROUND CIRCUIT

1. Disconnect remote keyless entry receiver connector.
2. Check continuity between remote keyless entry receiver connector M120 terminal 1 and ground.

1 (P) - Ground : Continuity should exist

OK or NG

- OK >> Replace remote keyless entry receiver.
NG >> GO TO 4.



4. HARNESS CONTINUITY INSPECTION

1. Disconnect remote keyless entry receiver and BCM connectors.
2. Check continuity between receiver connector M120 terminals 1, 2, 4 and BCM connector M18 terminals 18, 19, 20.

1 (P) - 18(P) : Continuity should exist

2 (G/W) - 20 (G/W) : Continuity should exist

4 (V/W) - 19 (V/W) : Continuity should exist

3. Check continuity between remote keyless entry receiver terminals 1, 2 and 4 and ground.


1 (P) - Ground : Continuity should not exist

2 (G/W) - Ground : Continuity should not exist

4 (V/W) - Ground : Continuity should not exist

OK or NG

- OK >> Check the condition of the harness and connectors.
NG >> Repair the harness between the remote keyless entry receiver and BCM.



REMOTE KEYLESS ENTRY SYSTEM

ACC Power Check


EIS002PI

1. CHECK ACC POWER

 With CONSULT-II

Check key switch "KEY ON SW" in DATA MONITOR mode with CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).


Monitor Item	Condition	
ACC ON SW	Ignition switch position is ACC	: ON
	Ignition switch position is OFF	: OFF



 Without CONSULT-II

Check voltage between BCM connector M18 terminal 11 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M18	11 (O)	Ground	ACC	Battery voltage
			OFF	0



OK or NG

OK >> ACC power circuit is OK.

NG >> Check the following.

- 10A fuse [No. 4, located in fuse block (J/B)]
- Harness for open or short.


IPDM E/R Operation Check

EIS002PJ

1. CHECK IPDM E/R INPUT VOLTAGE

Check voltage between IPDM E/R connector E122 terminal 45 and ground.

Connector	Terminal (Wire color)		Voltage (V) (Approx.)
	(+)	(-)	
E122	45 (G/W)	Ground	Battery voltage



OK or NG

OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).

NG >> GO TO 2.

REMOTE KEYLESS ENTRY SYSTEM

2. CHECK IPDM E/R INPUT VOLTAGE


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R and horn relay.
3. Check continuity between IPDM E/R connector E122 terminal 45 and horn relay connector H-1 terminal 1.

45 (G/W) - 1 (R/W) : Continuity should exist

OK or NG

OK >> Further inspection is necessary. Refer to [BL-74, "SYMP-TOM CHART"](#).

NG >> Repair or replace harness



REMOTE KEYLESS ENTRY SYSTEM

Check Hazard Function

EIS002PK

1. CHECK HAZARD WARNING LAMP

Does hazard indicator flash with hazard switch?

Yes or No

Yes >> Hazard warning lamp circuit is OK.

No >> Check "hazard indicator". Refer to [LT-79, "TURN SIGNAL AND HAZARD WARNING LAMPS"](#) .

Check Horn Function

EIS002PL

First, perform the "SELF-DIAG RESULTS" in "BCM" with CONSULT-II, then perform the trouble diagnosis of malfunction system indicated in "SELF-DIAG RESULTS" of "BCM".

1. CHECK HORN FUNCTION

Does horn sound with horn switch?

Yes or No

Yes >> Horn circuit is OK.

No >> Check horn circuit. Refer to [WW-38, "HORN"](#) .

Check Headlamp Function

EIS002PM

First, perform the "SELF-DIAG RESULTS" in "BCM" with CONSULT-II, then perform the trouble diagnosis of malfunction system indicated in "SELF-DIAG RESULTS" of "BCM".

1. CHECK HEADLAMP OPERATION

Does headlamp come on when turning lighting switch ON?

Yes or No

Yes >> Headlamp operation circuit is OK.

No >> Check headlamp circuit. Refer to [LT-6, "HEADLAMP \(FOR USA\)"](#) .

Check Front Room/Map Lamp Illumination Function

EIS002PN

1. CHECK MAP LAMP ILLUMINATION FUNCTION

When front room/map lamp switch is in DOOR position, open the front door LH or RH.

Front room/map lamp and ignition key illumination should illuminate.

OK or NG

OK >> System is OK.

NG >> Check front room/map lamp illumination circuit. Refer to [LT-154, "ILLUMINATION"](#) .

A
B
C
D
E
F
G
H
J
K
L
M

BL

REMOTE KEYLESS ENTRY SYSTEM

EIS002GD

ID Code Entry Procedure KEY FOB ID SET UP WITH CONSULT-II


NOTE:

- If a key fob is lost, the ID code of the lost key fob must be erased to prevent unauthorized use. A specific ID code can be erased with CONSULT-II. However, when the ID code of a lost key fob is not known, all controller ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new key fobs must be re-registered.
- When registering an additional key fob, the existing ID codes in memory may or may not be erased. If five ID codes are stored in memory when an additional code is registered, only the oldest code is erased. If less than five codes are stored in memory when an additional code is registered, the new ID code is added and no ID codes are erased.
- Entry of a maximum of five ID codes is allowed. When more than five codes are entered, the oldest ID code will be erased.
- Even if the same ID code that is already in memory is input, the same ID code can be entered. The code is counted as an additional code.


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.



3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".




5. Touch "BCM".
If "BCM" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




REMOTE KEYLESS ENTRY SYSTEM

6. Touch "MULTI REMOTE ENT".



A
B
C
D

7. Touch "WORK SUPPORT".



E
F
G


8. The items are shown on the figure at left can be set up.

- "REMO CONT ID REGIST"
Use this mode to register a key fob ID code.

NOTE:

Register the ID code when key fob or BCM is replaced, or when additional key fob is required.


- "REMO CONT ID ERASUR"
Use this mode to erase a key fob ID code.
- "REMO CONT ID CONFIR"
Use this mode to confirm if a key fob ID code is registered or not.



H
BL
J
K

REMOTE KEYLESS ENTRY SYSTEM

KEY FOB ID SET UP WITHOUT CONSULT-II



LIIA1546E

REMOTE KEYLESS ENTRY SYSTEM

NOTE:


- If a key fob is lost, the ID code of the lost key fob must be erased to prevent unauthorized use. A specific ID code can be erased with CONSULT-II. However, when the ID code of a lost key fob is not known, all controller ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new key fobs must be re-registered.
To erase all ID codes in memory, register one ID code (key fob) five times. After all ID codes are erased, the ID codes of all remaining and/or new key fobs must be re-registered.
- When registering an additional key fob, the existing ID codes in memory may or may not be erased. If five ID codes are stored in memory, when an additional code is registered, only the oldest code is erased. If less than five ID codes are stored in memory, when an additional ID code is registered, the new ID code is added and no ID codes are erased.
- If you need to activate more than two additional new key fobs, repeat the procedure "Additional ID code entry" for each new key fob.
- Entry of maximum five ID codes is allowed. When more than five ID codes are entered, the oldest ID code will be erased.
- Even if same ID code that is already in the memory is input, the same ID code can be entered. The code is counted as an additional code.

Key Fob Battery Replacement

EIS002GE

NOTE:

- Be careful not to touch the circuit board or battery terminal.
 - The key fob is water-resistant. However, if it does get wet, immediately wipe it dry.
1. Open the lid using a coin.
 2. Remove the battery.
 3. Install the new battery, positive side down.
 4. Close the lid securely. Push the key fob buttons two or three times to check operation.



LIJA0203E


VEHICLE SECURITY (THEFT WARNING) SYSTEM

VEHICLE SECURITY (THEFT WARNING) SYSTEM

PFV:28491

Component Parts and Harness Connector Location

EIS002GF



W11A0322E


VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS002GG

System Description

DESCRIPTION

Operation Flow



Setting the vehicle security system

Initial condition

- Ignition switch is in OFF position.

Disarmed phase

- When the vehicle is being driven or when doors are open, the vehicle security system is set in the disarmed phase on the assumption that the owner is inside or near the vehicle.

Pre-armed phase and armed phase

- The vehicle security system turns into the "pre-armed" phase when hood and all doors are closed and locked by electronic key. The security indicator lamp illuminates for 30 seconds. Then, the system automatically shifts into the "armed" phase.

Canceling the set vehicle security system

When one of the following operations is performed, the armed phase is canceled.

- Unlock the doors with the key or the key fob.

Activating the alarm operation of the vehicle security system

Make sure the system is in the armed phase.

When one of the following operations is performed, the system sounds the horns and flashes the headlamps for about 50 seconds.

1. Engine hood or any door is opened before unlocking door with key or key fob.
2. Door is unlocked without using key or key fob.

POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse [No.19, located in the fuse block (J/B)]
- to combination meter (security indicator lamp) terminal 8 and
- through 50A fusible link (letter f , located in the fuse and fusible link box)
- to BCM terminal 70
- through 15A fuse [No. 22, located in the fuse block (J/B)]
- to BCM terminal 57
- through 15A fuse (No. 25, located in the fuse and fusible link box)
- to horn relay terminal 2

VEHICLE SECURITY (THEFT WARNING) SYSTEM

- through 20A fuse (No. 52, located in the IPDM E/R) and
- through 20A fuse (No. 53, located in the IPDM E/R),
- to IPDM E/R internal CPU.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 4, located in the fuse box (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 67
- through body grounds M57, M61 and M79 and
- to IPDM E/R terminals 38 and 59
- through body ground E9, E15 and E24.

INITIAL CONDITION TO ACTIVATE THE SYSTEM

The operation of the vehicle security system is controlled by the doors and hood.

To activate the vehicle security system, BCM must receive signals indicating the doors and hood are closed and the doors are locked.

When a door is open, BCM terminal 12, 13, 47 or 48 receives a ground signal from each door switch.

When front door LH is unlocked, BCM terminal 22 receives a signal from terminal 12 (King Cab) or 14 (Crew Cab) of main power window and door lock/unlock switch.

When front door RH is unlocked, BCM terminal 22 receives a signal from terminal 16 of power window and door lock/unlock switch RH or the rear power window switch LH or RH.

VEHICLE SECURITY SYSTEM ALARM OPERATION

The vehicle security system is triggered by

- opening a door
- unlocking door without using the key or key fob.

The vehicle security system will be triggered once the system is in armed phase,

- when BCM receives a ground signal at terminals 12, 13, 47, 48 (door switch).

Power is supplied at all times

- to horn relay terminal 2
- through 15A fuse (No. 25, located in fuse and fusible link box).

When the vehicle security system is triggered, ground is supplied intermittently

- from IPDM E/R terminal 45
- to headlamp high relay and
- to horn relay terminal 1.

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 50 seconds, but will reactivate if the vehicle is tampered with again.

VEHICLE SECURITY SYSTEM DEACTIVATION

To deactivate the vehicle security system, a door must be unlocked with the key or key fob.

When the key is used to unlock a door, BCM terminal 22 receives signal

- from terminal 12 (King Cab) or 14 (Crew Cab) of the main power window and door lock/unlock switch.

When the BCM receives either one of these signals or unlock signal from key fob or key cylinder switch, the vehicle security system is deactivated. (Disarmed phase)

PANIC ALARM OPERATION

Remote keyless entry system may or may not operate vehicle security system (horn and headlamps) as required.

When the remote keyless entry system is triggered, ground is supplied intermittently

- from IPDM E/R terminal 45
- to headlamp high relay and
- to horn relay terminal 1.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off after 30 seconds or when BCM receives any signal from key fob.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

CAN Communication System Description

EIS002GH

Refer to [LAN-8, "CAN COMMUNICATION"](#) .

A

B

C

D

E

F

G

H

BL

J

K


L

M

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Schematic (King Cab)

EIS002GI




* THIS RELAY IS BUILT INTO THE IPDM/E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

WIWA0287E

VEHICLE SECURITY (THEFT WARNING) SYSTEM

BL-VEHSEC-02



41	42	43	44	45	46	47	48	49
50	51	52	53	54	55			

(M19) W



1
2
3

(B8) W

1 2

(B73) B

(B74) B

REFER TO THE FOLLOWING.


(M40) - SUPER MULTIPLE JUNCTION (SMJ)

WIWA0289E


VEHICLE SECURITY (THEFT WARNING) SYSTEM

BL-VEHSEC-03

A
B
C
D
E
F
G
H
BL
J
K
L
M



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40





REFER TO THE FOLLOWING.
M36 - SUPER MULTIPLE JUNCTION (SMJ)

W1WA0290E

VEHICLE SECURITY (THEFT WARNING) SYSTEM

BL-VEHSEC-04



— : DATA LINE



WIIWA0291E

VEHICLE SECURITY (THEFT WARNING) SYSTEM



BL-VEHSEC-05



WIWA0292E

VEHICLE SECURITY (THEFT WARNING) SYSTEM

BL-VEHSEC-06




LIWA0315E

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Schematic (Crew Cab)

EIS002QS



* THIS RELAY IS BUILT INTO THE IPDM/ER (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

A
B
C
D
E
F
G
H
I
J
K
L
M



BL

W1WA0293E

VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS002QT

Wiring Diagram -VEHSEC- (Crew Cab)



REFER TO THE FOLLOWING.


M31 - SUPER MULTIPLE JUNCTION (SMJ)

WIWA0294E


VEHICLE SECURITY (THEFT WARNING) SYSTEM

BL-VEHSEC-08

A
B
C
D
E
F
G
H
J
K
L
M





BL



REFER TO THE FOLLOWING.
 (M36), (M40) - SUPER MULTIPLE
 JUNCTION (SMJ)

VEHICLE SECURITY (THEFT WARNING) SYSTEM

BL-VEHSEC-11



LIWA0320E

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Terminals and Reference Value for BCM

EIS002GK

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
11	O	Ignition switch (ACC)	Ignition switch in ACC	Battery voltage
12	R/L	Front door switch RH	Door close (OFF) → Open (ON)	Battery voltage → 0
		Rear door switch upper RH (King Cab)		
		Rear door switch lower RH (King Cab)		
13	GR	Rear door switch RH (Crew Cab)	Door close (OFF) → Open (ON)	Battery voltage → 0
22	G	Anti-pinch serial link	When ignition switch is ON or power window timer operates	
23	G/O	Security indicator lamp	Goes off → illuminates (Every 2.4 seconds)	Battery voltage → 0
39	W	CAN-H	—	—
40	R	CAN-L	—	—
48	R/Y	Rear door switch LH (Crew Cab)	Door close (OFF) → Open (ON)	Battery voltage → 0
47	SB	Front door switch LH	Door close (OFF) → Open (ON)	Battery voltage → 0
		Rear door switch upper LH (King Cab)		
		Rear door switch lower LH (King Cab)		
57	Y/R	Power source (BAT)	—	Battery voltage
67	B	Ground	—	0
70	W/B	Power source (BAT)	—	Battery voltage

Terminals and Reference Value for IPDM E/R

EIS002GL

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)	
38	B	Ground	—	0	
39	W	CAN-H	—	—	
40	R	CAN-L	—	—	
45	G/W	Horn relay	When doors locks are operated using key fob (OFF → ON) *1	Battery voltage → 0	
52	L	Headlamp low (LH)	Lighting switch 2ND position	OFF	0V
				ON	Battery voltage
54	R/Y	Headlamp low (RH)	Lighting switch 2ND position	OFF	0V
				ON	Battery voltage
55	G	Headlamp high (LH)	Lighting switch HIGH or PASS position	OFF	0V
				ON	Battery voltage
56	L/W *2 Y *3	Headlamp high (RH)	Lighting switch HIGH or PASS position	OFF	0V
				ON	Battery voltage
59	B	Ground	—	0	

VEHICLE SECURITY (THEFT WARNING) SYSTEM

*1: when horn reminder is ON.

*2: L/W is for USA.

*3: Y is for Canada.

CONSULT-II Function

EIS002PO

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

DIAGNOSTIC ITEMS DESCRIPTION


BCM diagnosis position	Diagnosis mode	Description
THEFT ALM	Data monitor	The input data to the BCM is displayed in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.
	Work support	Changes the setting for each function.

CONSULT-II INSPECTION PROCEDURE

CAUTION:


If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.

1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.




BBA0369E

3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".



NOTE: EXAMPLE SHOWN. ACTUAL DISPLAY MAY DIFFER. BCI A0029E


5. Touch "BCM".
If "BCM" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




NOTE: EXAMPLE SHOWN. ACTUAL DISPLAY MAY DIFFER. BCI A0030E

VEHICLE SECURITY (THEFT WARNING) SYSTEM

6. Touch "THEFT ALM" on the "SELECT TEST ITEM" screen.



7. Select diagnosis mode. "DATA MONITOR", "ACTIVE TEST" and "WORK SUPPORT" are available.



CONSULT-II APPLICATION ITEM

Data Monitor

Monitored Item	Description
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch LH.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
KEYLESS UNLOCK	Indicates [ON/OFF] condition of unlock signal from key fob.
KEYLESS LOCK	Indicates [ON/OFF] condition of lock signal from key fob.
KEY CYL LK-SW	Indicates [ON/OFF] condition of lock signal from door key cylinder switch.
KEY CYL UN-SW	Indicates [ON/OFF] condition of unlock signal from door key cylinder switch.
CDL UNLOCK SW	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch.
CDL LOCK SW	Indicates [ON/OFF] condition of lock signal from lock/unlock switch.

Active Test

Test Item	Description
THEFT IND	This test is able to check security indicator lamp operation. The lamp will be turned on when "ON" on CONSULT-II screen is touched.
HEADLAMP (HI)	This test is able to check vehicle security lamp operation. The highbeam headlamps will be activated for 0.5 seconds after "ON" on CONSULT-II screen is touched.
VEHICLE SECURITY HORN	This test is able to check vehicle security horn operation. The horns will be activated for 0.5 seconds after "ON" on CONSULT-II screen is touched.


VEHICLE SECURITY (THEFT WARNING) SYSTEM

Work Support

Test Item	Description
SECURITY ALARM SET	This mode can confirm and change security alarm ON-OFF setting.
THEFT ALM TRG	The switch which triggered vehicle security alarm is recorded. This mode is able to confirm and erase the record of vehicle security alarm. The trigger data can be erased by touching "CLEAR" on CONSULT-II screen.

Trouble Diagnosis WORK FLOW

EIS002PP



LIA0123E

- "POWER DOOR LOCK SYSTEM" Diagnosis refer to [BL-16, "POWER DOOR LOCK SYSTEM"](#) .
- "REMOTE CONTROL SYSTEM" Diagnosis refer to [BL-53, "REMOTE KEYLESS ENTRY SYSTEM"](#) .

VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS002PQ

Preliminary Check

1. CHECK BCM CONFIGURATION

Confirm BCM Configuration for "THEFT ALARM" is set to "WITH". Refer to [BCS-13, "READ CONFIGURATION PROCEDURE"](#) .


OK or NG

OK >> GO TO 2.

NG >> Change BCM Configuration for "THEFT ALARM" to "WITH". Refer to [BCS-16, "WRITE CONFIGURATION PROCEDURE"](#) .

2. CHECK SYSTEM OPERATION

The system operation is canceled by turning ignition switch to ACC at any step between START and ARMED in the following flow chart.



>> After performing preliminary check, go to symptom chart. Refer to [BL-114, "Symptom Chart"](#) .

VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS002PR

Symptom Chart

PROCEDURE		Diagnostic procedure
SYMPTOM		
1	Vehicle security system cannot be set by	Door switch
		Lock/unlock switch
	Door outside key	Security indicator does not turn "ON".
2	*1 Vehicle security system does not alarm when	Any door is opened.
3	Vehicle security alarm does not activate.	Horn alarm
		Head lamp alarm
4	Vehicle security system cannot be canceled by	Door outside key
		Key fob

*1 : Make sure the system is in the armed phase.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS00208

Door Switch Check (King Cab)

1. CHECK DOOR SWITCHES INPUT SIGNAL

 With CONSULT-II

Check door switches ("DOOR SW-DR", "DOOR SW-AS") in DATA MONITOR mode with CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).

- When any doors are open:

DOOR SW-DR :ON

DOOR SW-AS :ON

- When any doors are closed:

DOOR SW-DR :OFF

DOOR SW-AS :OFF


DATA MONITOR	
MONITOR	
DOOR SW - DR	OFF
DOOR SW - AS	OFF
DOOR SW - RR	OFF
DOOR SW - RL	OFF

PIIA6222E

 Without CONSULT-II

Check voltage between BCM connector M18 or M19 terminals 12, 47 and ground.

Connector	Item	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
		(+)	(-)		
M19	Door switches LH	47 (SB)	Ground	Open	0
M18	Door switches RH	12 (R/L)		Closed	Battery voltage



OK or NG

- OK >> System is OK.
- NG >> GO TO 2.

2. CHECK DOOR SWITCH CIRCUIT

- Turn ignition switch OFF.
- Disconnect door switch and BCM.
- Check continuity between door switch connector B8 (Front LH), B108 (Front RH) terminal 2, B73 (Rear upper LH), B156 (Rear upper RH), B74 (Rear lower LH), B157 (Rear lower RH) terminal 1 and BCM connector M18, M19 terminals 12, and 47.

2 (SB) - 47 (SB) :Continuity should exist

2 (R/L) - 12 (R/L) :Continuity should exist


1 (SB) - 47 (SB) :Continuity should exist

1 (R/L) - 12 (R/L) :Continuity should exist

- Check continuity between door switch connector B8 (Front LH), B108 (Front RH) terminal 2, B73 (Rear upper LH), B156 (Rear upper RH), B74 (Rear lower LH), B157 (Rear lower RH) terminal 1 and ground.

2 (SB or R/L) - Ground :Continuity should not exist

1 (SB or R/L) - Ground :Continuity should not exist



OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace harness.

VEHICLE SECURITY (THEFT WARNING) SYSTEM


3. CHECK DOOR SWITCHES

1. Disconnect door switch.
2. Check continuity between door switch terminals.

Item	Terminal	Condition	Continuity
Door switches (front)	2 - 3	Open	No
		Closed	Yes
Door switches (rear upper and lower)	1 - 2	Open	No
		Closed	Yes

OK or NG

- OK >> Repair or replace harness.
- NG >> Replace door switch.



LIA1176E

EIS002Q9

Door Switch Check (Crew Cab)

1. CHECK DOOR SWITCHES INPUT SIGNAL

With CONSULT-II


Check door switches ("DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR") in DATA MONITOR mode with CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).

- When any doors are open:

DOOR SW-DR :ON
DOOR SW-AS :ON
DOOR SW-RL :ON
DOOR SW-RR :ON

- When any doors are closed:

DOOR SW-DR :OFF
DOOR SW-AS :OFF
DOOR SW-RL :OFF
DOOR SW-RR :OFF




PIA6222E

Without CONSULT-II

Check voltage between BCM connector M18 or M19 terminals 12, 13, 47, 48 and ground.

Connector	Item	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
		(+)	(-)		
M19	Front door switch LH	47 (SB)	Ground	Open ↓ Closed	0 ↓ Battery voltage
	Rear door switch LH	48 (R/Y)			
M18	Front door switch RH	12 (R/L)			
	Rear door switch RH	13 (GR)			



LIA1177E

OK or NG

- OK >> System is OK.
- NG >> GO TO 2.

VEHICLE SECURITY (THEFT WARNING) SYSTEM


2. CHECK DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door switch and BCM.
3. Check continuity between door switch connector B8 (Front LH), B108 (Front RH), B18 (Rear LH), B116 (Rear RH) terminal 2 and BCM connector M18, M19 terminals 12, 13, 47 and 48.

- 2 (SB) - 47 (SB) :Continuity should exist**
- 2 (R/L) - 12 (R/L) :Continuity should exist**
- 2 (R/Y) - 48 (R/Y) :Continuity should exist**
- 2 (R/W) - 13 (GR) :Continuity should exist**

4. Check continuity between door switch connector B8 (Front LH), B108 (Front RH), B18 (Rear LH), B116 (Rear RH) terminal 2 and ground.

- 2 (SB, R/L, R/Y or GR) - Ground :Continuity should not exist**



OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace harness.


3. CHECK DOOR SWITCHES

1. Disconnect door switch harness.
2. Check continuity between door switch connector terminals.

Item	Terminal	Condition	Continuity
Door switch (front and rear)	2 – Ground	Open	Yes
		Closed	No

OK or NG

- OK >> Check door switch case ground condition.
- NG >> Replace door switch.




VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS002PT

Security Indicator Lamp Check

1. SECURITY INDICATOR LAMP ACTIVE TEST


Ⓟ With CONSULT-II
Check "THEFT IND" in "ACTIVE TEST" mode with CONSULT-II.



ⓧ Without CONSULT-II

1. Disconnect BCM.
2. Check voltage between BCM harness connector M18 terminal 23 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M18	23 (G/O)	Ground	ON	0
			OFF	Battery voltage



OK or NG

- OK >> Security indicator lamp is OK.
- NG >> GO TO 2.

2. SECURITY INDICATOR LAMP CHECK

Check indicator lamp condition.
Refer to [BL-97, "Wiring Diagram -VEHSEC- \(King Cab\)"](#) , [BL-104, "Wiring Diagram -VEHSEC- \(Crew Cab\)"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Replace indicator lamp.


3. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and combination meter (security indicator lamp) connector.
3. Check continuity between BCM connector M18 terminal 23 and combination meter (security indicator lamp) harness connector M24 terminal 28.

23 (G/O) - 28 (G/O) : Continuity should exist

OK or NG

- OK >> Check the following.
 - 10A fuse [No. 19, located in fuse block (J/B)]
 - Harness for open or short between combination meter (security indicator lamp) and fuse
- NG >> Repair or replace harness.



VEHICLE SECURITY (THEFT WARNING) SYSTEM

Front Door Lock Assembly LH (Key Cylinder Switch) Check (King Cab)


EIS002QA

1. CHECK DOOR KEY CYLINDER SWITCH LH

Ⓜ With CONSULT-II

Check front door lock assembly LH (key cylinder switch) ("KEY CYL LK-SW") and ("KEY CYL UN-SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).


- When key inserted in front key cylinder is turned to LOCK:
KEY CYL LK-SW : ON
- When key inserted in front key cylinder is turned to UNLOCK:
KEY CYL UN-SW : ON



ⓧ Without CONSULT-II

Check voltage between main power window and door lock/unlock switch connector D7 terminals 6, 7 and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	6 (L)	Ground	Neutral/Unlock	5
			Lock	0
	7 (R)		Neutral/Lock	5
			Unlock	0



OK or NG

- OK >> Front door lock assembly LH (key cylinder switch) signal is OK.
- NG >> GO TO 2.


2. CHECK DOOR KEY CYLINDER SWITCH LH

- Turn ignition switch off.
- Disconnect front door lock assembly LH (key cylinder switch).
- Check continuity between door key cylinder switch LH connector terminals 1, 5 and 6.

Terminals	Condition	Continuity
1 - 5	Key is turned to LOCK.	Yes
6 - 5	Key is turned to UNLOCK.	Yes

OK or NG

- OK >> Check the following.
 - Front door lock assembly LH (key cylinder switch) ground circuit.
 - Harness for open or short between main power window and door lock/unlock switch and front door lock actuator LH (key cylinder switch LH).
- NG >> Replace front door lock assembly LH (key cylinder switch). Refer to [BL-128, "Removal and Installation"](#).



VEHICLE SECURITY (THEFT WARNING) SYSTEM

Front Door Lock Assembly LH (Key Cylinder Switch) Check (Crew Cab)

EIS0020B

1. CHECK DOOR KEY CYLINDER SWITCH LH

Ⓟ With CONSULT-II

Check front door lock assembly LH (key cylinder switch) ("KEY CYL LK-SW") and ("KEY CYL UN-SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-33, "DATA MONITOR"](#).

- When key inserted in front key cylinder is turned to LOCK:

KEY CYL LK-SW : ON

- When key inserted in front key cylinder is turned to UNLOCK:

KEY CYL UN-SW : ON


DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

LIIA0188E

ⓧ Without CONSULT-II

Check voltage between main power window and door lock/unlock switch connector D7 terminals 4, 6 and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	4 (L)	Ground	Neutral/Unlock	5
			Lock	0
	6 (R)	Ground	Neutral/Lock	5
			Unlock	0



OK or NG

- OK >> Front door lock assembly LH (key cylinder switch) signal is OK.
- NG >> GO TO 2.

2. CHECK DOOR KEY CYLINDER SWITCH LH

- Turn ignition switch off.
- Disconnect front door lock assembly LH (key cylinder switch).
- Check continuity between door key cylinder switch LH connector terminals 1, 5 and 6.


Terminals	Condition	Continuity
1 - 5	Key is turned to LOCK.	Yes
6 - 5	Key is turned to UNLOCK.	Yes

OK or NG

- OK >> Check the following.

- Front door lock assembly LH (key cylinder switch) ground circuit.
- Harness for open or short between main power window and door lock/unlock switch and front door lock actuator LH (key cylinder switch LH).

- NG >> Replace front door lock assembly LH (key cylinder switch). Refer to [BL-128, "Removal and Installation"](#).



VEHICLE SECURITY (THEFT WARNING) SYSTEM

Vehicle Security Horn Alarm Check

EIS002PV

1. CHECK HORN OPERATION

Check if horn sounds with horn switch.

Does horn operate?

- YES >> Check harness for open or short between IPDM E/R and horn relay.
- NO >> Check horn circuit. Refer to [WW-38, "HORN"](#) .

Vehicle Security Headlamp Alarm Check

EIS002PW

1. CHECK VEHICLE SECURITY HEADLAMP ALARM OPERATION

Check if headlamps operate with lighting switch.

Do headlamps come on when turning switch ON?

- YES >> Headlamp alarm is OK.
- NO >> Check headlamp system. Refer to [LT-6, "HEADLAMP \(FOR USA\)"](#) .

Door Lock/Unlock Switch Check

EIS002PX

1. CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

Check if power door lock operates with door lock/unlock switch.

Do doors lock/unlock when using each door lock/unlock switch?

- YES >> Door lock/unlock switch is OK.
- NO >> Refer to [BL-121, "Door Lock/Unlock Switch Check"](#) .

A
B
C
D
E
F
G
H
J
K
L
M

BL


DOOR

DOOR Fitting Adjustment

PF8:80100


EIS002GW

KING CAB



DOOR

CREW CAB



FRONT DOOR

Longitudinal clearance and surface height adjustment at front end

1. Remove the front fender. Refer to [EI-23, "Removal and Installation"](#).
2. Loosen the hinge mounting bolts. Raise the front door at rear end to adjust.

REAR DOOR

Longitudinal clearance and surface height adjustment at front end


1. Remove the center pillar upper garnish and center pillar lower garnish. Refer to [EI-36, "Removal and Installation"](#).
2. Accessing from inside the vehicle, loosen the mounting nuts. Open the rear door, and raise the rear door at rear end to adjust.

STRIKER ADJUSTMENT

1. Adjust the striker so that it becomes parallel with the lock insertion direction.

Striker Bolts

:16.6 N-m (1.7 kg-m, 12 ft-lb)



DOOR

EIS002GX


Removal and Installation

KING CAB


Front Door

CAUTION:

- When removing and installing the door assembly, support the door with a jack and shop cloth to protect the door and body.
 - When removing and installing door assembly, be sure to carry out the fitting adjustment.
 - Check the hinge rotating part for poor lubrication. If necessary, apply body grease.
1. Remove the door window and regulator assembly. Refer to [GW-76, "FRONT DOOR GLASS AND REGULATOR"](#) .
 2. Remove the door harness.
 3. Remove the check link cover.
 4. Remove the mounting bolts of the check link on the vehicle.



5. Remove the door-side hinge mounting nuts and bolts, and remove the door assembly.



Installation is in the reverse order of removal.

Rear Door

CAUTION:


- When removing and installing the door assembly, support the door with a jack and shop cloth to protect the door and body.
 - When removing and installing door assembly, be sure to carry out the fitting adjustment.
 - Check the hinge rotating part for poor lubrication. If necessary, apply body grease.
1. Remove the door glass. Refer to [GW-82, "SIDE WINDOW GLASS"](#) .
 2. Remove the speaker.
 3. Remove the door handles and latch assembly. Refer to [BL-131, "Component Structure"](#) .
 4. Remove the check link.
 5. Remove the wire harness.

DOOR

6. Remove the door assembly.

Installation is in the reverse order of removal.


- Door hinge nuts** : 24.5 N·m (2.5 kg-m, 18 ft-lb)
- Check link bolt** : 5.1 N·m (0.52 kg-m, 45 in-lb)



CREW CAB


CAUTION:

- When removing and installing the door assembly, support the door with a jack and shop cloth to protect the door and body.
 - When removing and installing door assembly, be sure to carry out the fitting adjustment.
 - Check the hinge rotating part for poor lubrication. If necessary, apply body grease.
1. Remove the door finisher. Refer to [EI-33, "Rear Door - Crew Cab"](#).
 2. Remove the inner seal.
 3. Remove the door window and regulator assembly. Refer to [GW-76, "FRONT DOOR GLASS AND REGULATOR"](#), [GW-80, "REAR DOOR GLASS AND REGULATOR"](#).
 4. Remove the door harness.
 5. Remove the check link cover.
 6. Remove the mounting bolts of the check link on the vehicle.



DOOR

7. Remove the door-side hinge mounting nuts and bolts, and remove the door assembly.




Installation is in the reverse order of removal.

Door Weatherstrip


EIS002GY

KING CAB



DOOR

CREW CAB



A
B
C
D
E
F
G
H
BL
J
K
L
M


FRONT DOOR LOCK

FRONT DOOR LOCK

PFP:80502

Component Structure

EIS002GZ



- | | | |
|----------------------------|--|--|
| 1. Grommet | 2. Outside handle bracket | 3. Key cylinder rod (Driver side only) |
| 4. Front gasket | 5. Lock knob cable | 6. Inside handle |
| 7. Door lock rocker switch | 8. Screw cap | 9. Inside handle cable |
| 10. Outside handle cable | 11. Door lock assembly | 12. Striker |
| 13. Outside handle | 14. Door key cylinder assembly (Driver side)
Outside handle escutcheon (Passenger side) | 15. Rear gasket |

Removal and Installation


REMOVAL

EIS002H0

1. Remove the front door window and front door regulator assembly. Refer to [GW-76, "Removal and Installation \(with Manual Windows\)"](#).
2. Remove door side grommet, and remove door key cylinder assembly (driver side) and outside handle escutcheon (passenger side) bolts (TORX T30) from grommet hole.

CAUTION:


Do not forcibly remove the TORX bolts (T30).




3. Reach to separate the key cylinder rod and outside handle rod connection (on the handle). If no door key cylinder is found, go to 6.

FRONT DOOR LOCK


4. While pulling the outside handle, remove door key cylinder assembly.




5. While pulling outside handle, slide toward rear of vehicle to remove outside handle.




6. Remove the front gasket and rear gasket.



7. Remove the TORX bolts (T30), remove the door lock assembly.




8. Remove the TORX bolt (T30) of the outside handle bracket.




A
B
C
D
E
F
G
H
BL
J
K
L
M

FRONT DOOR LOCK

9. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket and door lock assembly.



10. Disconnect the door lock actuator connector.
11. Reach to separate the key cylinder rod and outside handle rod connection.



INSTALLATION


Installation is in the reverse order of removal.

CAUTION:

To install each rod, be sure to rotate the rod holder until a click is felt.

Disassembly and Assembly DOOR KEY CYLINDER ASSEMBLY

EIS002H1



Remove the key cylinder escutcheon pawl and remove the door key cylinder.


REAR DOOR LOCK

PFP:82502

EIS002H2

REAR DOOR LOCK Component Structure

KING CAB




- | | | |
|---------------------------------|--------------------------|---------------------------------|
| 1. Rear upper door lock striker | 2. Rear door handle | 3. Rear lower door lock striker |
| 4. Lower latch cable | 5. Rear lower door latch | 6. Rear door lock assembly |
| 7. Rear inside door handle | 8. Upper latch cable | 9. Rear upper door latch |

W11A0335E

REAR DOOR LOCK

CREW CAB



1. Rear inside door handle

2. Rear door lock knob

3. Lock knob cable

4. Inside handle cable

5. Rear door lock/remote control assembly

6. Outside handle cable

Removal and Installation


REMOVAL

EIS002H3

1. Remove the rear door window and rear door module assembly. Refer to [GW-80, "Removal and Installation"](#).
2. Remove door grommets, and remove outside handle nuts from grommet hole.
3. Remove outside handle.
4. Disconnect the door lock actuator connector.

REAR DOOR LOCK

5. Reach to separate outside handle rod connection.



INSTALLATION

Installation is in the reverse order of removal.

- A
- B
- C
- D
- E
- F
- G
- H
- BL
- J
- K
- L
- M


TAIL GATE

PFP:93400

EIS002ZY

TAIL GATE

Removal and Installation



W1IA0337E

- | | | |
|--|--------------------------|--|
| 1. Rear gate liner cover (if equipped) | 2. Rear gate inner panel | 3. Rear gate rubber bumper |
| 4. Rear gate stay assembly | 5. Washer | 6. Rear gate cover |
| 7. Rear gate hinge assembly (RH), body side | 8. Rear gate ring (RH) | 9. Rear gate hinge assembly (RH), gate side |
| 10. Rear gate | 11. Rear gate handle | 12. Rear gate lock cylinder |
| 13. Rear gate hinge assembly (LH), gate side | 14. Rear gate ring (LH) | 15. Rear gate hinge assembly (LH), body side |
| 16. Rear gate control assembly | 17. Rubber bumper | 18. Rear gate latch assembly (RH & LH) |


NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

PFP:28591

Component Parts and Harness Connector Location

EIS002H4



A
B
C
D
E
F
G
H
BL
J
K
L
M

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS002H5

System Description

NVIS (Nissan Vehicle Immobilizer System-NATS) has the following immobilizer functions:

- Since only NVIS (NATS) ignition keys, whose IDs have been registered into the ECM and BCM, allow the engine to run, operation of a stolen vehicle without a NVIS (NATS) registered key is prevented by NVIS (NATS).
NVIS (NATS) will immobilize the engine if someone tries to start it without the registered key of NVIS (NATS).
- All of the originally supplied ignition key IDs have been NVIS (NATS) registered.
If requested by the vehicle owner, a maximum of five key IDs can be registered into the NVIS (NATS) components.
- The security indicator blinks when the ignition switch is in OFF or ACC position. NVIS (NATS) warns outsiders that the vehicle is equipped with the anti-theft system.
- When NVIS (NATS) detects trouble, the security indicator lamp lights up while ignition key is in the ON position.
- NVIS (NATS) trouble diagnoses, system initialization and additional registration of other NVIS (NATS) ignition key IDs must be carried out using CONSULT-II hardware and CONSULT-II NVIS (NATS) software. When NVIS (NATS) initialization has been completed, the ID of the inserted ignition key is automatically NVIS (NATS) registered. Then, if necessary, additional registration of other NVIS (NATS) ignition key IDs can be carried out.
Regarding the procedures of NVIS (NATS) initialization and NVIS (NATS) ignition key ID registration, refer to CONSULT-II Operation Manual NATS-IVIS/NVIS.
- **When servicing a malfunction of the NVIS (NATS) (indicated by lighting up of Security Indicator Lamp) or registering another NVIS (NATS) ignition key ID, it may be necessary to re-register original key identification. Therefore, be sure to receive ALL KEYS from vehicle owner.**

System Composition


EIS002H6

The immobilizer function of the NVIS (NATS) consists of the following:

- NATS ignition key
- NATS antenna amp. located in the ignition key cylinder
- Body control module (BCM)
- Engine control module (ECM)
- Security indicator

NOTE:

The communication between ECM and BCM uses the CAN communication system.



PIA1121E

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS002H7

ECM Re-communicating Function

The following procedure can automatically perform re-communication of ECM and BCM, but only when the ECM has been replaced with a new one (*1).

*1: New one means a virgin ECM which has never been energized on-board.

(In this step, initialization procedure by CONSULT-II is not necessary)

NOTE:

- **When registering new Key IDs or replacing the ECM other than brand new, refer to CONSULT-II Operation Manual NATS-IVIS/NVIS.**
 - **If multiple keys are attached to the key holder, separate them before work.**
 - **Distinguish keys with unregistered key ID from those with registered ID.**
1. Install ECM.
 2. Using a registered key (*2), turn ignition switch to ON.
*2: To perform this step, use the key (except for card plate key) that has been used before performing ECM replacement.
 3. Maintain ignition switch in ON position for at least 5 seconds.
 4. Turn ignition switch to OFF.
 5. Start engine.
If engine can be started, procedure is completed.
If engine cannot be started, refer to CONSULT-II Operation Manual NATS-IVIS/NVIS and initialize control unit.

A
B
C
D
E
F
G
H

BL



J
K
L
M

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

Wiring Diagram — NATS —

EIS002H8

BL-NATS-01



REFER TO THE FOLLOWING.
 (E16) -ELECTRICAL UNITS
 (M31), (M40) - SUPER
 MULTIPLE JUNCTION (SMJ)

WIWA0298E

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

Terminals and Reference Value for BCM

EIS002H9

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
21	G	NATS antenna amp.	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
23	G/O	Security indicator lamp	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0
25	BR	NATS antenna amp.	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
38	W/L	Ignition switch (ON or START)	Ignition switch (ON or START position)	Battery voltage
39	W	CAN-H	—	—
40	R	CAN-L	—	—
57	Y/R	Power source (Fuse)	—	Battery voltage
67	B	Ground	—	0
70	W/B	Power source (Fusible link)	—	Battery voltage

CONSULT-II

EIS002HA

CONSULT-II INSPECTION PROCEDURE


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. Turn ignition switch OFF.
2. Insert NVIS (NATS) program card into CONSULT-II.

Program card : NATS (AEN02C-1)

3. Connect CONSULT-II and CONSULT-II CONVERTER to data link connector.




4. Turn ignition switch ON.
5. Touch "START".




NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)


6. Touch "OTHER"



7. Select "NATS V.5.0".
If "NATS V5.0" is not indicated, go to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



8. Perform each diagnostic test mode according to each service procedure.
For further information, see the CONSULT-II Operation Manual NATS-IVIS/NVIS.



CONSULT-II DIAGNOSTIC TEST MODE FUNCTION

CONSULT-II DIAGNOSTIC TEST MODE	Description
C/U INITIALIZATION	When replacing any of the following components, C/U initialization and re-registration of all NATS ignition keys are necessary. [(NATS ignition key/ BCM/ ECM]
SELF-DIAG RESULTS	Detected items (screen terms) are as shown in the chart. Refer to BL-141, "NVIS (NATS) SELF-DIAGNOSTIC RESULTS ITEM CHART" .


NOTE:

- When any initialization is performed, all IDs previously registered will be erased and all NATS ignition keys must be registered again.
- The engine cannot be started with an unregistered key. In this case, the system will show "DIFFERENCE OF KEY" or "LOCK MODE" as a self-diagnostic result on the CONSULT-II screen.
- In rare case, "CHAIN OF ECM-IMMU" might be stored as a self-diagnostic result during key registration procedure, even if the system is not malfunctioning.

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS002HB

Work Flow



LIA1152E

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS002HC

Trouble Diagnoses SYMPTOM MATRIX CHART 1

Self-diagnosis related item

Symptom	Displayed "SELF-DIAG RESULTS" on CONSULT-II screen.	Diagnostic Procedure (Reference page)	System (Malfunctioning part or mode)	Reference Part No. Of Illustration On System Diagram
<ul style="list-style-type: none"> ● Security indicator lighting up* ● Engine cannot be started 	CHAIN OF ECM-IMMU [P1612]	PROCEDURE 1 (BL-145)	In rare case, "CHAIN OF ECM-IMMU" might be stored during key registration procedure, even if the system is not malfunctioning.	—
			Open circuit in battery voltage line of BCM circuit	C1
			Open circuit in ignition line of BCM circuit	C2
			Open circuit in ground line of BCM circuit	C3
			Open or short circuit between BCM and ECM communication line	C4
			ECM	B
			BCM	A
			DIFFERENCE OF KEY [P1615]	PROCEDURE 2 (BL-146)
	BCM	A		
	CHAIN OF IMMU-KEY [P1614]	PROCEDURE 5 (BL-149)	Malfunction of key ID chip	E5
			Communication line between ANT/ AMP and BCM: Open circuit or short circuit of battery voltage line or ground line	E1
				E2
			Open circuit in power source line of ANT/ AMP circuit	E3
			Open circuit in ground line of ANT/ AMP circuit	E4
			NATS antenna amp.	E6
			BCM	A
			ID DISCORD, IMM-ECM [P1611]	PROCEDURE 3 (BL-147)
	ECM	B		
LOCK MODE [P1610]	PROCEDURE 4 (BL-148)	LOCK MODE	D	
Security indicator lighting up*	DON'T ERASE BEFORE CHECKING ENG DIAG	WORK FLOW (BL-142)	Engine trouble data and NVIS (NATS) trouble data have been detected in ECM	—

*: When NVIS (NATS) detects trouble, the security indicator lights up while ignition key is in the "ON" position.

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)


SYMPTOM MATRIX CHART 2

Non self-diagnosis related item

Symptom	Diagnostic Procedure (Reference page)	System (Malfunctioning part or mode)	Reference Part No. Of Illustration On System Diagram
Security indicator does not light up*.	PROCEDURE 6 (BL-152)	Combination meter (security indicator lamp)	—
		Open circuit between Fuse and BCM	—
		BCM	A

*: CONSULT-II self-diagnostic results display screen "no malfunction is detected".

DIAGNOSTIC SYSTEM DIAGRAM



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS002HD

Diagnostic Procedure 1

Self-diagnostic results:

“CHAIN OF ECM-IMMU” displayed on CONSULT-II screen

First perform the “SELF-DIAG RESULTS” in “BCM” with CONSULT-II, then perform the trouble diagnosis of malfunction system indicated “SELF-DIAG RESULTS” of “BCM”. Refer to [BL-139, "CONSULT-II"](#)

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS “CHAIN OF ECM-IMMU” displayed on CONSULT-II screen.

NOTE:

In rare case, “CHAIN OF ECM-IMMU” might be stored during key registration procedure, even if the system is not malfunctioning.

Is CONSULT-II screen displayed as shown?

Yes >> GO TO 2.

No >> GO TO [BL-143, "SYMPTOM MATRIX CHART 1"](#).

SELF DIAGNOSIS	
DTC RESULTS	TIME
CHAIN OF ECM-IMMU [P1612]	0

PIIA1260E

2. CHECK POWER SUPPLY CIRCUIT FOR BCM

Check voltage between BCM connector M20 terminal 70 and ground.

70 (W/B) – Ground :Battery voltage


OK or NG

OK >> GO TO 3.

NG >> Check the following.

- 50A fusible link (letter f , located in fuse and fusible link box)
- Harness for open or short between fuse and BCM connector

Ref. Part No. C1



3. CHECK IGN SWITCH ON SIGNAL

1. Turn ignition switch ON.

2. Check voltage between BCM connector M18 terminal 38 and ground.

38 (W/L) – Ground :Battery voltage


OK or NG

OK >> GO TO 4.

NG >> Check the following.

- 10A fuse [No. 59, located in the fuse and relay box]
- Harness for open or short between fuse and BCM connector

Ref. part No. C2



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)


4. CHECK GROUND CIRCUIT FOR BCM

1. Turn ignition switch OFF.
2. Check continuity between BCM connector M18 terminal 67 and ground.

67 (B) – Ground :Continuity should exist

OK or NG

- OK >> GO TO 5.
NG >> Repair or replace harness. **Ref. part No. C3**



5. REPLACE BCM

1. Replace BCM. **Ref. part No. A**
2. Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

Does the engine start?

- Yes >> BCM is malfunctioning.
No >> ● ECM is malfunctioning.
- Replace ECM. **Ref. part No. B**
 - Perform initialization or re-communicating function.
 - For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".
 - For re-communicating function, refer to [BL-137, "ECM Re-communicating Function"](#).

Diagnostic Procedure 2

EIS002HE

Self-diagnostic results:

"DIFFERENCE OF KEY" displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS "DIFFERENCE OF KEY" displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as shown?

- Yes >> GO TO 2.
No >> GO TO [BL-143, "SYMPTOM MATRIX CHART 1"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
DIFFERENCE OF KEY [P1615]	0

PIA1261E

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

2. PERFORM INITIALIZATION WITH CONSULT-II


Perform initialization with CONSULT-II. Re-register all NATS ignition key IDs.
For initialization and registration of NATS ignition key IDs, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows message on the screen.

Can the system be initialized and can the engine be started with re-registered NATS ignition key?

- Yes >> ● Ignition key ID was unregistered. **Ref. part No. D**
- No >> ● BCM is malfunctioning.
 - Replace BCM. Refer to [BCS-25, "Removal and Installation of BCM"](#) . **Ref. part No. A**
 - Perform initialization with CONSULT-II.
 - For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



Diagnostic Procedure 3

EIS002HF

Self-diagnostic results:

"ID DISCORD, IMM-ECM" displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS "ID DISCORD, IMM-ECM" displayed on CONSULT-II screen.


NOTE:

"ID DISCORD IMM-ECM":

Registered ID of BCM is in discord with that of ECM.

Is CONSULT-II screen displayed as shown?

- Yes >> GO TO 2.
- No >> GO TO [BL-143, "SYMPTOM MATRIX CHART 1"](#) .



2. PERFORM INITIALIZATION WITH CONSULT-II


Perform initialization with CONSULT-II. Re-register all NATS ignition key IDs.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows message on the screen.

Can the system be initialized?

- Yes >> ● Start engine. (END)
 - (System initialization had not been completed. **Ref. part No. F**)
- No >> ● ECM is malfunctioning.
 - Replace ECM. **Ref. part No. B**
 - Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS002HG

Diagnostic Procedure 4

Self-diagnostic results:

“LOCK MODE” displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS “LOCK MODE” is displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as shown?

Yes >> GO TO 2.

No >> GO TO [BL-143, "SYMPTOM MATRIX CHART 1"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
LOCK MODE [P1610]	0

PIA1264E

2. ESCAPE FROM LOCK MODE

1. Turn ignition switch OFF.
2. Turn ignition switch ON with registered key. (Do not start engine.) Wait 5 seconds.
3. Return the key to OFF position. Wait 5 seconds.
4. Repeat steps 2 and 3 twice (total of three cycles).
5. Start the engine.

Does engine start?

Yes >> System is OK (Now system is escaped from “LOCK MODE”). Clear all codes.

No >> GO TO 3.

3. PERFORM INITIALIZATION WITH CONSULT-II

Perform initialization with CONSULT-II.

For initialization, refer to “CONSULT-II Operation Manual NATS-IVIS/NVIS”.

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows the message on the screen.

Can the system be initialized?

Yes >> System is OK.

No >> GO TO 4.

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL297W

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

4. PERFORM INITIALIZATION WITH CONSULT-II AGAIN


1. Replace BCM.
2. Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows the message on the screen.

Can the system be initialized?

- Yes >> System is OK. (BCM is malfunctioning. **Ref. part No. A**)
- No >> ● ECM is malfunctioning.
- Replace ECM. **Ref. part No. B**
 - Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



Diagnostic Procedure 5

EIS002HH

Self-diagnostic results:

"CHAIN OF IMMU-KEY" displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS "CHAIN OF IMMU-KEY" displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as shown?

- Yes >> GO TO 2.
- No >> GO TO [BL-143, "SYMPTOM MATRIX CHART 1"](#).

The screenshot shows a CONSULT-II screen with the following table:

SELF DIAGNOSIS	
DTC RESULTS	TIME
CHAIN OF IMMU-KEY [P1614]	0

PIIA1263E

2. CHECK NATS ANTENNA AMP. INSTALLATION

Check NATS antenna amp. installation. Refer to [BL-153, "How to Replace NATS Antenna Amp."](#).

OK or NG

- OK >> GO TO 3.
- NG >> Reinstall NATS antenna amp. correctly.

3. CHECK NVIS (NATS) IGNITION KEY ID CHIP

Start engine with another registered NATS ignition key.

Does the engine start?

- Yes >> ● Ignition key ID chip is malfunctioning.
- Replace the ignition key.
Ref. part No, E5
 - Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".
- No >> GO TO 4.

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)


4. CHECK POWER SUPPLY FOR NATS ANTENNA AMP.

Check voltage between NATS antenna amp. connector M21 terminal 1 and ground.

1 (W) – Ground :Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace harness.



5. CHECK NATS ANTENNA AMP. SIGNAL LINE- 1

Check voltage between NATS antenna amp. connector M21 terminal 2 and ground with analog tester.


2 (G) – Ground	Before turning ignition switch ON
	Voltage: 12V
	Just after turning ignition switch ON : Pointer of tester should move for less than one second

OK or NG

- OK >> GO TO 6.
- NG >> ● Repair or replace harness.

NOTE:

If harness is OK, replace BCM, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



6. CHECK NATS ANTENNA AMP. SIGNAL LINE- 2

Check voltage between NATS antenna amp. connector M21 terminal 4 and ground with analog tester.


4 (BR) – Ground	Before turning ignition switch ON
	Voltage: 12V
	Just after turning ignition switch ON : Pointer of tester should move for less than one second

OK or NG

- OK >> GO TO 7.
- NG >> ● Repair or replace harness.

NOTE:

If harness is OK, replace BCM, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

7. CHECK NATS ANTENNA AMP. GROUND LINE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect NATS antenna amp. connector.
3. Check continuity between NATS antenna amp. connector M21 terminal 3 and ground.

3 (B) – Ground :Continuity should exist.


OK or NG

OK >> ● NATS antenna amp. is malfunctioning.
Ref. part No. E6

NG >> ● Repair or replace harness.

NOTE:

If harness is OK, replace BCM, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



A
B
C
D
E
F
G
H
BL
J
K
L
M

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS002HI

Diagnostic Procedure 6

SECURITY INDICATOR LAMP DOES NOT LIGHT UP

1. CHECK FUSE

Check 10A fuse [No.19, located in the fuse block (J/B)]

NOTE:

Refer to [BL-135, "Component Parts and Harness Connector Location"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. CHECK SECURITY INDICATOR LAMP

1. Start engine and turn ignition switch OFF.
2. Check the combination meter (security indicator lamp) lights up.

Security indicator lamp should light up.

OK or NG

OK >> Inspection End.

NG >> GO TO 3.

3. CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT


1. Disconnect combination meter (security indicator lamp) connector.
2. Check voltage between combination meter (security indicator lamp) connector M24 terminal 8 and ground.

8 (Y/R) – Ground :Battery voltage

OK or NG

OK >> GO TO 4.

NG >> Repair or replace harness.



4. CHECK BCM (NATS CONTROL UNIT) FUNCTION

1. Connect combination meter (security indicator lamp) connector.
2. Disconnect BCM.
3. Check voltage between BCM connector M18 terminal 23 and ground.

23 (G/O) – Ground :Battery voltage

OK or NG

OK >> BCM is malfunctioning.


- Replace BCM. Refer to [BCS-25, "Removal and Installation of BCM"](#).

Ref. part No. A

- Perform initialization with CONSULT-II.
- For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NG >> Check the following.

- Harness for open or short between combination meter (security indicator lamp) and BCM (NATS control unit).
- Indicator lamp condition




NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

How to Replace NATS Antenna Amp.

EIS002HJ

NOTE:

- If NATS antenna amp. is not installed correctly, NVIS (NATS) system will not operate properly and SELF-DIAG RESULTS on CONSULT-II screen will show "LOCK MODE" or "CHAIN OF IMMU-KEY".
- Initialization is not necessary only when NATS antenna amp. is replaced with a new one.



A
B
C
D
E
F
G
H
J
K
L
M

BL

INTEGRATED HOMELINK TRANSMITTER



PFP:96401

INTEGRATED HOMELINK TRANSMITTER

Wiring Diagram —TRNSCV—

EIS002HK

BL-TRNSCV-01



WIWA0203E

INTEGRATED HOMELINK TRANSMITTER

EIS002HL

Trouble Diagnoses DIAGNOSTIC PROCEDURE

SYMPTOM: Transmitter does not activate receiver.


Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is at fault, not vehicle related.

1. ILLUMINATE CHECK

1. Turn ignition switch OFF.
2. Does red light (LED) of transmitter illuminate when any button is pressed?

YES or NO

- YES >> GO TO 2.
NO >> GO TO 3.



2. TRANSMITTER CHECK

Check transmitter with Tool*.

*:For details, refer to Technical Service Bulletin.

OK or NG

- OK >> Receiver or handheld transmitter malfunction, not vehicle related.
NG >> Replace transmitter.

3. CHECK BCM OUTPUT POWER SUPPLY

Does front room/map lamp assembly come on when driver side door is opened? Refer to [LT-130, "INTERIOR ROOM LAMP"](#).

Yes or No?

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning part.


4. POWER SUPPLY CHECK

1. Disconnect transmitter connector.
2. Check voltage between auto anti-dazzling inside mirror (integrated homelink transmitter) connector R7 terminal 10 and ground.

10 (Y/R) – Ground **:Battery voltage**

OK or NG

- OK >> GO TO 5.
NG >> Repair or replace harness.



INTEGRATED HOMELINK TRANSMITTER


5. GROUND CIRCUIT CHECK

Check continuity between auto anti-dazzling inside mirror (integrated homelink transmitter) connector R7 terminal 8 (B) and body ground.

8 (B) – Ground :Continuity should exist.

OK or NG

- OK >> Replace inside mirror assembly. Refer to [GW-85](#).
"[Removal and Installation](#)".
- NG >> Repair or replace harness.



CAB AND REAR BODY

CAB AND REAR BODY


PFP:93020

Body Mounting, King Cab

EIS003PG

When removing, be sure to replace bolts and nuts (sealant applied bolts or self-lock nuts are used for all mounting).

SEC. 950




A
B
C
D
E
F
G
H
BL
J
K
L
M

CAB AND REAR BODY

EIS003PH

Body Mounting, Crew Cab

When removing, be sure to replace bolts and nuts (sealant applied bolts or self-lock nuts are used for all mounting).



LIA1623E


BODY REPAIR

BODY REPAIR

PF:60100

Body Exterior Paint Color

EIS002HM



Component			Color code	A15	B18	C10	CY1	D13	G10	K11	K12	Q10	
			Description	Red Brawn	Deep Water	Copper	Sedona	Can-teen	Gal-axy	Smoke	Radiant Silver	Pearl White	
			Paint type	M	M	M	M	M	2P	M	M	2S	
			Clear coat	t	t	t	t	t	t	t	t	t	
1	Outside mirror	XE	Black	KH3	KH3	KH3	KH3	KH3	KH3	KH3	KH3	KH3	
		SE and LE	Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	
2	Front bumper	XE	Body color	A15	B18	C10	CY1	D13	G10	K11	K12	Q10	
		SE and LE	End caps	Body color	A15	B18	C10	CY1	D13	G10	K11	K12	Q10
			Center	Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
3	Outside handles	XE	Black	KH3	KH3	KH3	KH3	KH3	KH3	KH3	KH3	KH3	
		SE and LE	Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	
4	Radiator grille	XE	Center	Body color	A15	B18	C10	CY1	D13	G10	K11	K12	Q10
				Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		SE and LE	Grid	Black	KH3	KH3	KH3	KH3	KH3	KH3	KH3	KH3	KH3
5	Rear Bumper	XE	Body color	A15	B18	C10	CY1	D13	G10	K11	K12	Q10	
		SE and LE	Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	


M: Metallic; 2S: 2-Coat Solid, 2P: 2-Coat Pearl; 3P: 3-Coat Pearl; t: New Cross Linking Clear Coat

BODY REPAIR

EIS002HN

Body Component Parts UNDERBODY COMPONENT PARTS

-  : Indicates both-side anti-corrosive pre-coated steel portions
-  : Indicates high strength steel (HSS) portions
-  : Indicates both-side anti-corrosive pre-coated steel and (HSS) portions



LIIA1209E

BODY REPAIR

- | | |
|---|---|
| 1. Rear floor | A |
| 2. Rear seat crossmember | |
| 3. 4th crossmember | |
| 4. Rear floor reinforcement assembly | B |
| 5. Front seat mounting crossmember | |
| 6. Sill inner extension (RH, LH) | |
| 7. Front floor reinforcement | C |
| 8. Inner sill (RH, LH) | |
| 9. 2nd crossmember extension (RH, LH) | |
| 10. Front floor | D |
| 11. 2nd crossmember assembly | |
| 12. Dash side (RH, LH) | |
| 13. Hoodledge assembly (RH, LH) | E |
| 14. Harness bracket | |
| 15. Hoodledge front reinforcement (LH) | |
| 16. Battery mounting reinforcement (RH)
1st body mounting bracket (LH) | F |
| 17. Hoodledge reinforcement (RH, LH) | |
| 18. Rear hoodledge reinforcement (RH, LH) | G |
| 19. Cowl top | |
| 20. Cowl top extension | H |
| 21. Upper dash assembly | |

BL

J

K


L

M

BODY REPAIR

BODY COMPONENT PARTS KING CAB

-  : Indicates both-side anti-corrosive precoated steel portions
-  : Indicates high strength steel (HSS) portions
-  : Indicates both-side anti-corrosive precoated steel and (HSS) portions



W1IA0325E

BODY REPAIR

1. Side panel assembly (RH, LH)	A
2. Inner side panel assembly (RH, LH)	
3. Rear strut assembly (RH, LH)	
4. Inner rear strut assembly (RH, LH)	
5. Rear gate	B
6. Tail floor bolster assembly	
7. Rear body floor assembly	C
8. Front outer strut assembly (RH, LH)	
9. Rear roof rail	
10. Inner lock pillar (RH, LH)	D
11. Back panel assembly	
12. Outer lock pillar reinforcement (RH, LH)	
13. Body side outer (RH, LH)	E
14. Rear door assembly (RH, LH)	
15. Front door assembly (RH, LH)	F
16. Front fender (RH, LH)	
17. Hood	
18. Dash side (RH, LH)	G
19. Front pillar brace (RH, LH)	
20. Outer sill reinforcement (RH, LH)	
21. Inner upper front pillar (RH, LH)	H
22. Inner roof side rail (RH,LH)	
23. Roof	
24. Upper front pillar reinforcement (RH, LH)	BL
25. Front roof rail	
26. No. 1 roof bow	J
27. Header panel	

K


L

M

BODY REPAIR

CREW CAB

-  : Indicates both-side anti-corrosive precoated steel portions
-  : Indicates high strength steel (HSS) portions
-  : Indicates both-side anti-corrosive precoated steel and (HSS) portions



WIIA0326E

BODY REPAIR

1. Rear strut assembly (RH, LH)	A
2. Inner rear strut assembly (RH, LH)	
3. Rear gate	
4. Rear body floor assembly	B
5. Tail floor bolster assembly	
6. Inner side panel assembly (RH, LH)	
7. Side panel assembly (RH, LH)	C
8. Front outer strut assembly (RH, LH)	
9. Rear roof rail	
10. Inner lock pillar (RH, LH)	D
11. Back panel assembly	
12. Outer lock pillar reinforcement (RH, LH)	
13. Body side outer (RH, LH)	E
14. Rear door assembly (RH, LH)	
15. Front door assembly (RH, LH)	F
16. Front fender (RH, LH)	
17. Hood	
18. Hoodledge rear reinforcement (RH, LH)	G
19. Front pillar brace (RH, LH)	
20. Outer sill reinforcement (RH, LH)	
21. Inner upper front pillar (RH, LH)	H
22. Inner roof side rail (RH,LH)	
23. Inner center pillar (RH, LH)	
24. Upper front pillar reinforcement (RH, LH)	BL
25. Lower center pillar brace (RH, LH)	
26. Front roof rail	
27. Sunroof frame	J
28. No. 2 roof bow	
29. Standard roof	K
30. Roof with sunroof opening	
31. Header panel	L


M

BODY REPAIR

FRAME COMPONENT PARTS

King Cab

SEC. 500




LIA1624E

1. Front differential mounting bracket RH/LH
2. 1st cab mounting bracket RH/LH
3. Front side member extension assembly RH/LH
4. 1st crossmember assembly
5. Front upper link mounting bracket RH/LH
6. Panhard rod bracket reinforcement
7. Bound bumper bracket RH/LH
8. Front brake hose bracket RH/LH
9. Front shock absorber bracket RH/LH
10. Panhard rod reinforcement
11. 4th crossmember gusset RH/LH
12. 2nd cab mounting bracket RH/LH
13. 3rd cab mounting reinforcement
14. 3rd cab mounting bracket RH/LH
15. 1st rear body mounting bracket RH/LH
16. Rear spring front bracket assembly RH/LH
17. 2nd rear body mounting bracket RH/LH
18. Rear bound bumper bracket RH/LH
19. Rear bound bumper reinforcement RH/LH

BODY REPAIR

20. Rear spring rear bracket assembly RH/LH
21. 5th rear body mounting reinforcement bracket RH/LH
22. 9th crossmember assembly
23. Exhaust bracket assembly
24. 8th crossmember assembly
25. Rear shock absorber bracket assembly RH/LH
26. Canister bracket, RH
27. Canister bracket, LH
28. 7th crossmember assembly
29. 6th crossmember assembly
30. 5th crossmember assembly
31. 4th crossmember assembly
32. 3rd crossmember assembly
33. 2nd crossmember assembly
34. Frame assembly

Crew Cab



1. Front differential mounting bracket RH/LH
2. 1st cab mounting bracket RH/LH
3. Front side member extension assembly RH/LH
4. 1st crossmember assembly

BODY REPAIR

5. Front upper link mounting bracket RH/LH
6. Panhard rod bracket reinforcement
7. Bound bumper bracket RH/LH
8. Front brake hose bracket RH/LH
9. Front shock absorber bracket RH/LH
10. Panhard rod reinforcement
11. 4th crossmember gusset RH/LH
12. 2nd cab mounting bracket RH/LH
13. 3rd cab mounting bracket RH/LH
14. 4th cab mounting bracket RH/LH
15. Rear spring front bracket assembly RH/LH
16. 2nd rear body mounting bracket RH/LH
17. Rear bound bumper bracket RH/LH
18. Rear bound bumper reinforcement RH/LH
19. Rear spring rear bracket assembly RH/LH
20. 5th rear body mounting reinforcement bracket RH/LH
21. 9th crossmember assembly
22. Exhaust bracket assembly
23. 8th crossmember assembly
24. Rear shock absorber bracket assembly RH/LH
25. Canister bracket, RH
26. Canister bracket, LH
27. 7th crossmember assembly
28. 6th crossmember assembly
29. 5th crossmember assembly
30. 4th crossmember assembly
31. 3rd crossmember assembly
32. 2nd crossmember assembly
33. Frame assembly

BODY REPAIR

EIS002HO

Corrosion Protection


DESCRIPTION

To provide improved corrosion prevention, the following anti-corrosive measures have been implemented in NISSAN production plants. When repairing or replacing body panels, it is necessary to use the same anti-corrosive measures.

ANTI-CORROSIVE PRECOATED STEEL (GALVANNEALED STEEL)

To improve repairability and corrosion resistance, a new type of anti-corrosive precoated steel sheet has been adopted replacing conventional zinc-coated steel sheet.

Galvannealed steel is electroplated and heated to form Zinc-iron alloy, which provides excellent and long term corrosion resistance with cationic electrode position primer.




Nissan Genuine Service Parts are fabricated from galvannealed steel. Therefore, it is recommended that GENUINE NISSAN PARTS or equivalent be used for panel replacement to maintain the anti-corrosive performance built into the vehicle at the factory.

PHOSPHATE COATING TREATMENT AND CATIONIC ELECTRODEPOSITION PRIMER

A phosphate coating treatment and a cationic electrode position primer, which provide excellent corrosion protection, are employed on all body components.

CAUTION:

Confine paint removal during welding operations to an absolute minimum.




Nissan Genuine Service Parts are also treated in the same manner. Therefore, it is recommended that GENUINE NISSAN PARTS or equivalent be used for panel replacement to maintain anti-corrosive performance built into the vehicle at the factory.


BODY REPAIR

ANTI-CORROSIVE WAX

To improve corrosion resistance, anti-corrosive wax is applied inside the body sill and inside other closed sections. Accordingly, when replacing these parts, be sure to apply anti-corrosive wax to the appropriate areas of the new parts. Select an excellent anti-corrosive wax which will penetrate after application and has a long shelf life.



-  : Indicates outside body sealant
-  : Indicates anti-corrosive wax coated portions



LIA1210E


BODY REPAIR

UNDERCOATING

The underside of the floor and wheelhouse are undercoated to prevent rust, vibration, noise and stone chipping. Therefore, when such a panel is replaced or repaired, apply undercoating to that part. Use an undercoating which is rust preventive, soundproof, vibration-proof, shock-resistant, adhesive, and durable.

Precautions in undercoating

1. Do not apply undercoating to any place unless specified (such as the areas above the muffler and three way catalyst which are subjected to heat).
2. Do not undercoat the exhaust pipe or other parts which become hot.
3. Do not undercoat rotating parts.
4. Apply bitumen wax after applying undercoating.



A
B
C
D
E
F
G
H
BL
J
K
L
M

BODY REPAIR



Body Sealing DESCRIPTION

EIS002HP

The following figure shows the areas which are sealed at the factory. Sealant which has been applied to these areas should be smooth and free from cuts or gaps. Care should be taken not to apply an excess amount of


BODY REPAIR

sealant and not to allow other unaffected parts to come into contact with the sealant.




LIIA1303E

BODY REPAIR



LIA1315E

BODY REPAIR



A

B

C

D

E

F

G

H

BL

J

K

L

M


LIA1316E

BODY REPAIR

Body Construction BODY CONSTRUCTION

EIS002HQ


King Cab



Section A-A	Section B-B	Section C-C	Section D-D
Section E-E	Section F-F	Section G-G	Section H-H
Section J-J			

BODY REPAIR

Crew Cab



Section A-A	Section B-B	Section C-C	Section D-D
Section E-E	Section F-F	Section G-G	Section H-H
Section I-I	Section J-J	Section K-K	

A
B
C
D
E
F
G
H
BL
J
K
L
M

LIIA1318E



BODY REPAIR

Body Alignment **BODY CENTER MARKS**

EIS002HR

A mark has been placed on each part of the body to indicate the vehicle center. When repairing parts damaged by an accident which might affect the vehicle frame (members, pillars, etc.), more accurate and effective repair will be possible by using these marks together with body alignment specifications.

BODY REPAIR



Portion A	Portion B	Portion C

W11A0327E

A
B
C
D
E
F
G
H
BL
J
K
L
M


BODY REPAIR

PANEL PARTS MATCHING MARKS


A mark has been placed on each body panel to indicate the parts matching positions. When repairing parts damaged by an accident which might affect the vehicle structure (members, pillars, etc.), more accurate and

BODY REPAIR

effective repair will be possible by using these marks together with body alignment specifications.



Type V: ○-----
 Type W: ●-----




A
 B
 C
 D
 E
 F
 G
 H
BL
 J
 K
 L
 M

WIA0338E

BODY REPAIR

DESCRIPTION



- All dimensions indicated in the figures are actual.
- When using a tracking gauge, adjust both pointers to equal length. Then check the pointers and gauge itself to make sure there is no free play.
- When a measuring tape is used, check to be sure there is no elongation, twisting or bending.
- Measurements should be taken at the center of the mounting holes.
- An asterisk (*) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value.
- The coordinates of the measurement points are the distances measured from the standard line of "X", "Y" and "Z".



BODY REPAIR

ENGINE COMPARTMENT MEASUREMENT

Figures marked with a (*) indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.



Unit: mm


LIA1507E

A
B
C
D
E
F
G
H
BL
J
K
L
M


BODY REPAIR

MEASUREMENT POINTS


- ⓑ Fender mount
- ⓒ Fender mount
- ⓓ Front end module mount
- ⓔ 18mm x 16mm diameter
- ⓙ 16mm diameter



- ⓐ RH cowl
- ⓑ Fender mount
- ⓒ Fender mount
- ⓓ Front end module mount
- ⓔ 18mm x 16mm diameter
- ⓙ 16 mm diameter



- ⓕ, ⓕ, ⓖ, ⓖ, ⓗ, ⓗ Front side member extension front



W11A0279E


BODY REPAIR

UNDERBODY MEASUREMENT

Figures marked with a (*) indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.

As viewed from underside.

All dimensions indicated in this figure are actual.



Unit: mm


A
B
C
D
E
F
G
H
J
K
L
M

BL

LIIA1213E

BODY REPAIR

MEASUREMENT POINTS




Coordinates:

- (A, a) X: ± 447
Y: -745
Z: 255
- (B, b) X: ± 447
Y: -427
Z: 272
- (C, c) X: ± 353
Y: 35
Z: 303
- (D, d) X: ± 386
Y: 198
Z: 165
- (E, e) X: ± 454
Y: 504
Z: 115
- (F, f) X: ± 466
Y: 777
Z: 100
- (G, g) X: ± 495
Y: 1013
Z: 100
- (H, h) X: ± 564
Y: 2541
Z: 88
- (J, j) X: ± 558
Y: 4171
Z: 400
- (K, k) X: ± 559
Y: 4546
Z: 337

W11A0339E

BODY REPAIR



A
B
C
D
E
F
G
H
BL
J
K
L
M

Coordinates:	(A, a)	(B, b)	(C, c)	(D, d)	(E, e)	(F, f)	(G, g)	(H, h)	(J, j)	(K, k)
X :	± 447	± 447	± 353	± 386	± 454	± 466	± 495	± 564	± 558	± 559
Y :	-747	-427	35	198	504	777	1013	2541	4171	4546
Z :	255	272	303	165	115	100	100	88	400	337

Unit: mm


W1IA0340E

BODY REPAIR

PASSENGER COMPARTMENT MEASUREMENT

Windshield Opening

Figures marked with a (*) indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.




Unit: mm

LIA1289E

BODY REPAIR


King Cab Door Opening



A
B
C
D
E
F
G
H

BL

Crew Cab Door Opening




J
K
L
M

BODY REPAIR

Rear Window Opening

Figures marked with a (*) indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.









Unit: mm

LIIA1292E

BODY REPAIR







MEASUREMENT POINTS



A
B
C
D
E
F
G
H
BL
J
K
L
M


LIA1300E

BODY REPAIR



LIA1321E

BODY REPAIR





A
B
C
D
E
F
G
H
BL
J
K
L
M

LIA1322E

BODY REPAIR


REAR BODY MEASUREMENT



BODY REPAIR

King Cab Bed Opening

Figures marked with an (*) indicate symmetrically identical dimensions on both the right and left hand sides of the vehicle



Unit: mm


LIIA1293E

A
B
C
D
E
F
G
H

BL

Crew Cab Bed Opening

Figures marked with an (*) indicate symmetrically identical dimensions on both the right and left hand sides of the vehicle




Unit: mm

LIIA1294E

J
K
L
M

BODY REPAIR

Measurement Points



LIA1334E

BODY REPAIR

Handling Precautions for Plastics


EIS002HS

Abbreviation	Material name	Heatresisting temperature °C (°F)	Resistance to gasoline and solvents	Other cautions
PE	Polyethylene	60 (140)	Gasoline and most solvents are harmless if applied for a very short time (wipe up quickly).	Flammable
PVC	Polyvinyl Chloride	80 (176)	Same as above.	Poison gas is emitted when burned.
EPM/EPDM	Ethylene Propylene (Diene) rubber	80 (176)	Same as above.	Flammable
TPO/TPR	Thermoplastic Olefine/ Thermoplastic Rubber	80 (176)	Same as above.	Flammable
PP	Polypropylene	90 (194)	Same as above.	Flammable, avoid battery acid.
UP	Polyester thermoset	90 (194)	Same as above.	Flammable
PS	Polystyrene	80 (176)	Avoid solvents.	Flammable
ABS	Acrylonitrile Butadiene Styrene resin	80 (176)	Avoid gasoline and solvents.	
AES	Acrylonitrile Ethylene Styrene	80 (176)	Same as above.	
PMMA	Polymethyl Methacrylate	85 (185)	Same as above.	
AAS	Acrylonitrile Acrylic Styrene	85 (185)	Same as above.	
AS	Acrylonitrile Styrene	85 (185)	Same as above.	
EVA	Polyvinyl Ethyl Acetate	90 (194)	Same as above.	
ASA	Acrylonitrile Styrene Acrylate	100 (222)	Same as above.	Flammable
PPO/PPE	Polyphenylene Oxide/ Polyphenylene Ether	110 (230)	Same as above.	
PC	Polycarbonate	120 (248)	Same as above.	
PAR	Polyacrylate	180 (356)	Same as above.	
L-LDPE	Lenear Low Density PE	45 (100)	Gasoline and most solvents are harmless.	Flammable
PUR	Polyurethane	90 (194)	Same as above.	
TPU	Thermoplastic Urethane	110 (230)	Same as above.	
PPC	Polypropylene Composite	115 (239)	Same as above.	Flammable
POM	Polyacetal	120 (248)	Same as above.	Avoid battery acid.
PBT+PC	Polybutylene Terephthalate+Polycarbonate	120 (248)	Same as above.	Flammable
PA	Polyamide (Nylon)	140 (284)	Same as above.	Avoid immersing in water.
PBT	Polybutylene Terephthalate	140 (284)	Same as above.	
FRP	Fiber Reinforced Plastics	170 (338)	Same as above.	Avoid battery acid.
PET	Polyethylene Terephthalate	180 (356)	Same as above.	
PEI	Polyetherimide	200 (392)	Same as above.	

1. When repairing and painting a portion of the body adjacent to plastic parts, consider their characteristics (influence of heat and solvent) and remove them if necessary or take suitable measures to protect them.
2. Plastic parts should be repaired and painted using methods suiting the materials' characteristics.


BODY REPAIR

LOCATION OF PLASTIC PARTS



WIHA0350E

BODY REPAIR



A
B
C
D
E
F
G
H
BL
J
K
L
M

BODY REPAIR

EIS002HT

Precautions in Repairing High Strength Steel

High strength steel is used for body panels in order to reduce vehicle weight. Accordingly, precautions in repairing automotive bodies made of high strength steel are described below:

HIGH STRENGTH STEEL (HSS) USED IN NISSAN VEHICLES

Tensile strength	Nissan/Infiniti designation	Major applicable parts
373 N/mm ² (38kg/mm ² ,54klb/sq in)	SP130	<ul style="list-style-type: none"> ● Front inner pillar upper ● Front pillar hinge brace ● Outer front pillar reinforcement ● Other reinforcements
785-981 N/mm ² (80-100kg/mm ² 114-142klb/sq in)	SP150	<ul style="list-style-type: none"> ● Outer sill reinforcement ● Main back pillar


SP130 is the most commonly used HSS.

SP150 HSS is used only on parts that require much more strength.


Read the following precautions when repairing HSS:

1. Additional points to consider


- The repair of reinforcements (such as side members) by heating is not recommended since it may weaken the component. When heating is unavoidable, do not heat HSS parts above 550°C (1,022°F). Verify heating temperature with a thermometer. (Crayon-type and other similar type thermometer are appropriate.)



- When straightening body panels, use caution in pulling any HSS panel. Because HSS is very strong, pulling may cause deformation in adjacent portions of the body. In this case, increase the number of measuring points, and carefully pull the HSS panel.




- When cutting HSS panels, avoid gas (torch) cutting if possible. Instead, use a saw to avoid weakening surrounding areas due to heat. If gas (torch) cutting is unavoidable, allow a minimum margin of 50 mm (1.97in).




BODY REPAIR

- When welding HSS panels, use spot welding whenever possible in order to minimize weakening surrounding areas due to heat. If spot welding is impossible, use M.I.G. welding. Do not use gas (torch) welding because it is inferior in welding strength.




- The spot weld on HSS panels is harder than that of an ordinary steel panel. Therefore, when cutting spot welds on a HSS panel, use a low speed high torque drill (1,000 to 1,200 rpm) to increase drill bit durability and facilitate the operation.
- SP150 HSS panels with a tensile strength of 785 to 981 N/mm² (80 to 100 kg/mm², 114 to 142 klb/sq in), used as reinforcement in the door guard beams, is too strong to repair. When these HSS parts are damaged, the outer panels also sustain substantial damage; therefore, the assembly parts must be replaced.




2. Precautions in spot welding HSS

This work should be performed under standard working conditions. Always note the following when spot welding HSS:

- The electrode tip diameter must be sized properly according to the metal thickness.



- The panel surfaces must fit flush to each other, leaving no gaps.




A
B
C
D
E
F
G
H
BL
J
K
L
M

BODY REPAIR

- Follow the specifications for the proper welding pitch.

Thickness (t)	Minimum pitch (ℓ)
0.6 (0.024)	10 (0.39) or over
0.8 (0.031)	12 (0.47) or over
1.0 (0.039)	18 (0.71) or over
1.2 (0.047)	20 (0.79) or over
1.6 (0.063)	27 (1.06) or over
1.8 (0.071)	31 (1.22) or over

Unit:mm



EIS002HU

Foam Repair


During factory body assembly, foam insulators are installed in certain body panels and locations around the vehicle. Use the following procedure(s) to replace any factory-installed foam insulators.

URETHANE FOAM APPLICATIONS

Use commercially available spray foam for sealant (foam material) repair of material used on vehicle. Read instructions on product for fill procedures.

FILL PROCEDURES

1. Fill procedures after installation of service part.
 - Remove foam material remaining on vehicle side.
 - Clean area in which foam was removed.
 - Install service part.
 - Insert nozzle into hole near fill area and fill foam material or fill in enough to close gap with the service part.



2. Fill procedures before installation of service part.
 - Remove foam material remaining on vehicle side.
 - Clean area in which foam was removed.
 - Fill foam material on wheelhouse outer side.


NOTE:

Fill in enough to close gap with service part while avoiding flange area.

- Install service part.

NOTE:

Refer to label for information on working times.



BODY REPAIR

Replacement Operations

EIS002HV

DESCRIPTION

This section is prepared for technicians who have attained a high level of skill and experience in repairing collision-damaged vehicles and also use modern service tools and equipment. Persons unfamiliar with body repair techniques should not attempt to repair collision-damaged vehicles by using this section.

Technicians are also encouraged to read Body Repair Manual (Fundamentals) in order to ensure that the original functions and quality of the vehicle can be maintained. The Body Repair Manual (Fundamentals) contains additional information, including cautions and warnings, that are not including in this manual. Technicians should refer to both manuals to ensure proper repairs.

Please note that this information is prepared for worldwide usage, and as such, certain procedures may not apply in some regions or countries.

A

B

C

D

E

F

G

H

BL

J











K

L

M


BODY REPAIR

The symbols used in this section for cutting and welding / brazing operations are shown below.


 Saw cut or air chisel cut		
<p>Spot weld</p> <p>●●●●● 2-spot welds</p> <p>●●●●● 3-spot welds</p>  	<p>2-spot welds (2-panel overlapping portions)</p>  <p>3-spot welds (3-panel overlapping portions)</p> 	
<p>■ ■ ■ ■</p> <p>MIG plug weld</p>  		
<p>~~~~~</p> <p>MIG seam weld/ Point weld</p>  		
<p>▨ ▨ ▨ ▨</p> <p>Brazing</p>  		
<p>▩ ▩ ▩ ▩</p> <p>Soldering</p>  		
<p>—————</p> <p>Sealing</p>		

BODY REPAIR


- Front pillar butt joint can be determined anywhere within shaded area as shown in the figure. The best location for the butt joint is at position A due to the construction of the vehicle. Refer to the front pillar section.



- Determine cutting position and record distance from the locating indent. Use this distance when cutting the service part. Cut outer front pillar over 60 mm above inner front pillar cut position.




- Prepare a cutting jig to make outer pillar easier to cut. Also, this will permit service part to be accurately cut at joint position.



- An example of cutting operation using a cutting jig is as follows.

1. Mark cutting lines.
A: Cut position of outer pillar
B: Cut position of inner pillar
2. Align cutting line with notch on jig. Clamp jig to pillar.
3. Cut outer pillar along groove of jig. (At position A)
4. Remove jig and cut remaining portions.
5. Cut inner pillar at position B in same manner.




BODY REPAIR


HOODLEDGE

- Work after radiator core support has been removed.


Service Joint





2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




WIIA0341E

BODY REPAIR

FRONT PILLAR

- Work after rear hoodedge reinforcement has been removed.

Service Joint




Unit: mm


2-spot welds




3-spot welds



MIG Plug weld



(For 3 panels plug weld method)




MIG seam weld/
Point weld



WIIA0342E


BODY REPAIR

Service Joint




Unit : mm


2-spot welds



3-spot welds



MIG Plug weld



For 3 panels plug weld method




MIG seam weld/
Point weld



LIA1156E


BODY REPAIR

Service Joint




A
B
C
D
E
F
G
H
BL
J
K
L
M


2-spot welds




3-spot welds



MIG Plug weld



For 3 panels plug weld method



MIG seam weld/
Point weld




W11A0343E

BODY REPAIR

CENTER PILLAR

Service Joint

* Reinforcement is retained with the same welds as the b-pillar outer sheet metal.



Unit : mm

2-spot welds

3-spot welds

MIG Plug weld

(For 3 panels plug weld method)


MIG seam weld/
Point weld



LIIA1159E

BODY REPAIR


Service Joint




A
B
C
D
E
F
G
H
BL
J
K
L
M

Unit : mm


2-spot welds



3-spot welds



MIG Plug weld



For 3 panels plug weld method



MIG seam weld/
Point weld




LIIA1112E


BODY REPAIR

OUTER SILL KING CAB


Service Joint




2-spot welds



3-spot welds



MIG Plug weld



For 3 panels plug weld method




MIG seam weld/
Point weld



WIIA0344E


BODY REPAIR

Service Joint




A
B
C
D
E
F
G
H
BL
J
K
L
M


2-spot welds



3-spot welds



MIG Plug weld



For 3 panels plug weld method




MIG seam weld/
Point weld




LIIA1195E

BODY REPAIR


Service Joint





2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




LIA1196E

BODY REPAIR


CREW CAB

Service Joint


A
B
C
D
E
F
G
H
BL
J
K
L
M





2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




LIIA1197E

BODY REPAIR


REAR CAB PILLAR KING CAB

Service Joint




Unit: mm



2-spot welds



3-spot welds



MIG Plug weld




MIG seam weld/
Point weld



WIHA0345E


BODY REPAIR

Service Joint




A
B
C
D
E
F
G
H
BL
J
K
L
M



2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




LIIA1201E

BODY REPAIR


CREW CAB

Service Joint




Unit: mm



2-spot welds



3-spot welds



MIG Plug weld




MIG seam weld/
Point weld



W11A0346E


BODY REPAIR

Service Joint




A
B
C
D
E
F
G
H
BL
J
K
L
M



2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




WIA0347E


BODY REPAIR

REAR PANEL


Service Joint




2-spot welds



3-spot welds



MIG Plug weld



For 3 panels plug weld method



MIG seam weld/
Point weld




LIIA1205E

BODY REPAIR


REAR FLOOR REAR KING CAB

Service Joint




A
B
C
D
E
F
G
H
BL
J
K
L
M



2-spot welds




3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




LIIA1203E


BODY REPAIR

CREW CAB


Service Joint




2-spot welds



3-spot welds



MIG Plug weld



(For 3 panels plug weld method)



MIG seam weld/
Point weld




W11A0348E


BODY REPAIR

PICKUP BED
KING CAB

Service Joint




A
B
C
D
E
F
G
H
BL
J
K
L
M




W11A0349E

BODY REPAIR


Service Joint





2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




LIA1223E

BODY REPAIR

CREW CAB


Service Joint

A
B
C
D
E
F
G
H
BL
J
K
L
M




←
Front


2-spot welds



3-spot welds



MIG Plug weld



(For 3 panels plug weld method)




MIG seam weld/
Point weld




LIIA1224E

BODY REPAIR


Service Joint





2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld





LIA1225E

BODY REPAIR

Service Joint


A
B
C
D
E
F
G
H
BL
J
K
L
M




LIA1215E

BODY REPAIR


Service Joint





2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




LIA1216E


BODY REPAIR

Service Joint


A
B
C
D
E
F
G
H
BL
J
K
L
M





2-spot welds




3-spot welds



MIG Plug weld




MIG seam weld/
Point weld




LIIA1217E

BODY REPAIR


Service Joint





2-spot welds



3-spot welds



MIG Plug weld




MIG seam weld/
Point weld



LIA1218E


BODY REPAIR

Service Joint




A
B
C
D
E
F
G
H
BL
J
K
L
M



2-spot welds



3-spot welds



MIG Plug weld




MIG seam weld/
Point weld




LIIA1219E

BODY REPAIR


Service Joint





2-spot welds



3-spot welds



MIG Plug weld





MIG seam weld/
Point weld



LIA1220E


BODY REPAIR

Service Joint




A
B
C
D
E
F
G
H
BL
J
K
L
M


2-spot welds



3-spot welds



MIG Plug weld



(For 3 panels plug weld method)



MIG seam weld/
Point weld




LIIA1221E

BODY REPAIR

CRUSH HORN

- Work after 1st crossmember has been removed.



LIA1083E


Portions to be welded:

- A. Inner side rail crush horn, inner side rail crush horn and outer side rail crush horn.
- B. Outer side rail crush horn, outer side rail crush horn and inner side rail crush horn.


BODY REPAIR

Removal Notes

- Scribe a straight line on the outer side rail crush horn and inner side rail crush horn along the hole center as shown in the figure.




- Cut off outer side rail crush horn and inner side rail crush horn along scribed line A. Do not cut on the hole.



- Cut inner side rail crush horn at 45 mm backward cut position of cut line A. (along line B)


BODY REPAIR




- After removing outer panel, dress area on the inner panel surface with a sander or equivalent.

BODY REPAIR

Installation Notes



- Scribe a straight line on the inner side rail crush horn along the hole center as shown in the figure. Cut off inner side rail crush horn along scribed line.
- G



- Scribe a straight line on the outer side rail crush horn along the hole center as shown in the figure. Cut off outer side rail crush horn along scribed line.

BODY REPAIR

- Weld part to be butt-welded and seam-welded corner to corner as shown in the figure.

