

SECTION **LAN**  
LAN SYSTEM

A  
B  
C

CONTENTS

D  
E

**CAN**

<b>PRECAUTIONS</b> .....	<b>5</b>	IPDM E/R Circuit Check .....	49	F
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	5	CAN Communication Circuit Check .....	50	
Precautions When Using CONSULT-II .....	5	IPDM E/R Ignition Relay Circuit Check .....	50	
CHECK POINTS FOR USING CONSULT-II .....	5	Component Inspection .....	51	G
Precautions For Trouble Diagnosis .....	5	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	51	
CAN SYSTEM .....	5	<b>CAN SYSTEM (TYPE 2)</b> .....	<b>52</b>	H
Precautions For Harness Repair .....	6	System Description .....	52	
CAN SYSTEM .....	6	Component Parts and Harness Connector Location..	52	
<b>CAN COMMUNICATION</b> .....	<b>7</b>	Schematic .....	53	
System Description .....	7	Wiring Diagram - CAN - .....	54	I
CAN Communication Unit .....	7	Work Flow .....	57	
TYPE 1 .....	9	CHECK SHEET .....	58	
TYPE 2/TYPE 3/TYPE 4 .....	11	CHECK SHEET RESULTS (EXAMPLE) .....	60	J
TYPE 5/TYPE 6 .....	14	Circuit Check Between TCM and Data Link Connector .....	71	
TYPE 7/TYPE 8/TYPE 9/TYPE 10/TYPE 11/		Circuit Check Between Data Link Connector and IPDM E/R .....	72	
TYPE 12 .....	17	ECM Circuit Check .....	73	
TYPE 13 .....	21	TCM Circuit Check .....	74	
<b>CAN SYSTEM (TYPE 1)</b> .....	<b>24</b>	Combination Meter Circuit Check .....	74	L
System Description .....	24	BCM Circuit Check .....	75	
Component Parts and Harness Connector Location..	24	Data Link Connector Circuit Check .....	75	
Schematic .....	25	Front Air Control Circuit Check .....	76	M
Wiring Diagram - CAN - .....	26	ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	76	
Work Flow .....	29	IPDM E/R Circuit Check .....	77	
CHECK SHEET .....	30	CAN Communication Circuit Check .....	78	
CHECK SHEET RESULTS (EXAMPLE) .....	32	IPDM E/R Ignition Relay Circuit Check .....	78	
Circuit Check Between TCM and Data Link Connector .....	43	Component Inspection .....	79	
Circuit Check Between Data Link Connector and IPDM E/R .....	44	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	79	
ECM Circuit Check .....	45	<b>CAN SYSTEM (TYPE 3)</b> .....	<b>80</b>	
TCM Circuit Check .....	46	System Description .....	80	
Combination Meter Circuit Check .....	46	Component Parts and Harness Connector Location..	80	
BCM Circuit Check .....	47	Schematic .....	81	
Data Link Connector Circuit Check .....	47	Wiring Diagram - CAN - .....	82	
Front Air Control Circuit Check .....	48	Work Flow .....	85	
ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	48	CHECK SHEET .....	86	
		CHECK SHEET RESULTS (EXAMPLE) .....	88	

LAN

L

M

Circuit Check Between TCM and Driver Seat Control Unit .....	101	Circuit Check Between TCM and Data Link Connector .....	163
Circuit Check Between Driver Seat Control Unit and Data Link Connector .....	102	Circuit Check Between Data Link Connector and IPDM E/R .....	164
Circuit Check Between Data Link Connector and IPDM E/R .....	103	ECM Circuit Check .....	165
ECM Circuit Check .....	104	TCM Circuit Check .....	166
TCM Circuit Check .....	104	Combination Meter Circuit Check .....	166
Driver Seat Control Unit Circuit Check .....	105	BCM Circuit Check .....	167
Combination Meter Circuit Check .....	105	Data Link Connector Circuit Check .....	167
BCM Circuit Check .....	106	Steering Angle Sensor Circuit Check .....	168
Data Link Connector Circuit Check .....	106	Front Air Control Circuit Check .....	168
Front Air Control Circuit Check .....	107	ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	169
ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	107	IPDM E/R Circuit Check .....	169
IPDM E/R Circuit Check .....	108	CAN Communication Circuit Check .....	170
CAN Communication Circuit Check .....	108	IPDM E/R Ignition Relay Circuit Check .....	171
IPDM E/R Ignition Relay Circuit Check .....	109	Component Inspection .....	171
Component Inspection .....	109	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	171
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	109	<b>CAN SYSTEM (TYPE 6) .....</b>	<b>172</b>
<b>CAN SYSTEM (TYPE 4) .....</b>	<b>110</b>	System Description .....	172
System Description .....	110	Component Parts and Harness Connector Location .....	172
Component Parts and Harness Connector Location .....	110	Schematic .....	173
Schematic .....	111	Wiring Diagram - CAN - .....	174
Wiring Diagram - CAN - .....	112	Work Flow .....	177
Work Flow .....	115	CHECK SHEET .....	179
CHECK SHEET .....	117	CHECK SHEET RESULTS (EXAMPLE) .....	181
CHECK SHEET RESULTS (EXAMPLE) .....	119	Circuit Check Between TCM and Driver Seat Control Unit .....	196
Circuit Check Between TCM and Driver Seat Control Unit .....	133	Circuit Check Between Driver Seat Control Unit and Data Link Connector .....	197
Circuit Check Between Driver Seat Control Unit and Data Link Connector .....	134	Circuit Check Between Data Link Connector and IPDM E/R .....	198
Circuit Check Between Data Link Connector and IPDM E/R .....	135	ECM Circuit Check .....	199
ECM Circuit Check .....	136	TCM Circuit Check .....	199
TCM Circuit Check .....	136	Driver Seat Control Unit Circuit Check .....	200
Driver Seat Control Unit Circuit Check .....	137	Combination Meter Circuit Check .....	200
Combination Meter Circuit Check .....	137	Display Control Unit Circuit Check .....	201
Display Control Unit Circuit Check .....	138	BCM Circuit Check .....	201
BCM Circuit Check .....	138	Data Link Connector Circuit Check .....	202
Data Link Connector Circuit Check .....	139	Steering Angle Sensor Circuit Check .....	202
Front Air Control Circuit Check .....	139	Front Air Control Circuit Check .....	203
ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	140	ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	203
IPDM E/R Circuit Check .....	140	IPDM E/R Circuit Check .....	204
CAN Communication Circuit Check .....	141	CAN Communication Circuit Check .....	204
IPDM E/R Ignition Relay Circuit Check .....	141	IPDM E/R Ignition Relay Circuit Check .....	205
Component Inspection .....	142	Component Inspection .....	205
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	142	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	205
<b>CAN SYSTEM (TYPE 5) .....</b>	<b>143</b>	<b>CAN SYSTEM (TYPE 7) .....</b>	<b>206</b>
System Description .....	143	System Description .....	206
Component Parts and Harness Connector Location .....	143	Component Parts and Harness Connector Location .....	206
Schematic .....	144	Schematic .....	207
Wiring Diagram - CAN - .....	145	Wiring Diagram - CAN - .....	208
Work Flow .....	148	Work Flow .....	211
CHECK SHEET .....	149	CHECK SHEET .....	212
CHECK SHEET RESULTS (EXAMPLE) .....	151	CHECK SHEET RESULTS (EXAMPLE) .....	214
		Circuit Check Between TCM and Data Link Con-	

connector .....	226	Data Link Connector .....	292	
Circuit Check Between Data Link Connector and IPDM E/R .....	227	Circuit Check Between Data Link Connector and IPDM E/R .....	293	A
ECM Circuit Check .....	228	ECM Circuit Check .....	294	
TCM Circuit Check .....	229	TCM Circuit Check .....	294	B
Combination Meter Circuit Check .....	229	Driver Seat Control Unit Circuit Check .....	295	
BCM Circuit Check .....	230	Combination Meter Circuit Check .....	295	
Data Link Connector Circuit Check .....	230	Display Control Unit Circuit Check .....	296	C
Front Air Control Circuit Check .....	231	BCM Circuit Check .....	296	
Transfer Control Unit Circuit Check .....	231	Data Link Connector Circuit Check .....	297	
ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	232	Front Air Control Circuit Check .....	297	D
IPDM E/R Circuit Check .....	232	Transfer Control Unit Circuit Check .....	298	
CAN Communication Circuit Check .....	233	ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	298	
IPDM E/R Ignition Relay Circuit Check .....	234	IPDM E/R Circuit Check .....	299	E
Component Inspection .....	234	CAN Communication Circuit Check .....	299	
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	234	IPDM E/R Ignition Relay Circuit Check .....	300	
<b>CAN SYSTEM (TYPE 8) .....</b>	<b>235</b>	Component Inspection .....	300	F
System Description .....	235	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	300	
Component Parts and Harness Connector Location .....	235	<b>CAN SYSTEM (TYPE 10) .....</b>	<b>301</b>	G
Schematic .....	236	System Description .....	301	
Wiring Diagram - CAN - .....	237	Component Parts and Harness Connector Location .....	301	
Work Flow .....	240	Schematic .....	302	
CHECK SHEET .....	241	Wiring Diagram - CAN - .....	303	H
CHECK SHEET RESULTS (EXAMPLE) .....	243	Work Flow .....	306	
Circuit Check Between TCM and Driver Seat Control Unit .....	257	CHECK SHEET .....	307	
Circuit Check Between Driver Seat Control Unit and Data Link Connector .....	258	CHECK SHEET RESULTS (EXAMPLE) .....	309	I
Circuit Check Between Data Link Connector and IPDM E/R .....	259	Circuit Check Between TCM and Differential Lock Control Unit .....	323	
ECM Circuit Check .....	260	Circuit Check Between Differential Lock Control Unit and Data Link Connector .....	324	J
TCM Circuit Check .....	260	Circuit Check Between Data Link Connector and IPDM E/R .....	325	
Driver Seat Control Unit Circuit Check .....	261	ECM Circuit Check .....	326	LAN
Combination Meter Circuit Check .....	261	TCM Circuit Check .....	326	
BCM Circuit Check .....	262	Differential Lock Control Unit Circuit Check .....	327	
Data Link Connector Circuit Check .....	262	Combination Meter Circuit Check .....	327	L
Front Air Control Circuit Check .....	263	BCM Circuit Check .....	328	
Transfer Control Unit Circuit Check .....	263	Data Link Connector Circuit Check .....	328	
ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	264	Front Air Control Circuit Check .....	329	M
IPDM E/R Circuit Check .....	264	Transfer Control Unit Circuit Check .....	329	
CAN Communication Circuit Check .....	265	ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	330	
IPDM E/R Ignition Relay Circuit Check .....	265	IPDM E/R Circuit Check .....	330	
Component Inspection .....	266	CAN Communication Circuit Check .....	331	
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	266	IPDM E/R Ignition Relay Circuit Check .....	331	
<b>CAN SYSTEM (TYPE 9) .....</b>	<b>267</b>	Component Inspection .....	332	
System Description .....	267	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	332	
Component Parts and Harness Connector Location .....	267	<b>CAN SYSTEM (TYPE 11) .....</b>	<b>333</b>	
Schematic .....	268	System Description .....	333	
Wiring Diagram - CAN - .....	269	Component Parts and Harness Connector Location .....	333	
Work Flow .....	272	Schematic .....	334	
CHECK SHEET .....	274	Wiring Diagram - CAN - .....	335	
CHECK SHEET RESULTS (EXAMPLE) .....	276	Work Flow .....	338	
Circuit Check Between TCM and Driver Seat Control Unit .....	291	CHECK SHEET .....	339	
Circuit Check Between Driver Seat Control Unit and Data Link Connector .....	292	CHECK SHEET RESULTS (EXAMPLE) .....	342	
Circuit Check Between Data Link Connector and IPDM E/R .....	293	Circuit Check Between TCM and Differential Lock Control Unit .....	342	
ECM Circuit Check .....	294			
TCM Circuit Check .....	294			
Driver Seat Control Unit Circuit Check .....	295			
Combination Meter Circuit Check .....	295			
Display Control Unit Circuit Check .....	296			
BCM Circuit Check .....	296			
Data Link Connector Circuit Check .....	297			
Front Air Control Circuit Check .....	297			
Transfer Control Unit Circuit Check .....	298			
ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	298			
IPDM E/R Circuit Check .....	299			
CAN Communication Circuit Check .....	299			
IPDM E/R Ignition Relay Circuit Check .....	300			
Component Inspection .....	300			
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	300			

Control Unit .....	358	Display Control Unit Circuit Check .....	402
Circuit Check Between Differential Lock Control Unit and Driver Seat Control Unit .....	359	BCM Circuit Check .....	402
Circuit Check Between Driver Seat Control Unit and Data Link Connector .....	360	Data Link Connector Circuit Check .....	403
Circuit Check Between Data Link Connector and IPDM E/R .....	360	Front Air Control Circuit Check .....	403
ECM Circuit Check .....	361	Transfer Control Unit Circuit Check .....	404
TCM Circuit Check .....	362	ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	404
Differential Lock Control Unit Circuit Check .....	362	IPDM E/R Circuit Check .....	405
Driver Seat Control Unit Circuit Check .....	363	CAN Communication Circuit Check .....	406
Combination Meter Circuit Check .....	363	IPDM E/R Ignition Relay Circuit Check .....	406
BCM Circuit Check .....	364	Component Inspection .....	407
Data Link Connector Circuit Check .....	364	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	407
Front Air Control Circuit Check .....	365	<b>CAN SYSTEM (TYPE 13) .....</b>	<b>408</b>
Transfer Control Unit Circuit Check .....	365	System Description .....	408
ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	366	Component Parts and Harness Connector Location .....	408
IPDM E/R Circuit Check .....	366	Schematic .....	409
CAN Communication Circuit Check .....	367	Wiring Diagram - CAN - .....	410
IPDM E/R Ignition Relay Circuit Check .....	368	Work Flow .....	413
Component Inspection .....	368	CHECK SHEET .....	414
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	368	CHECK SHEET RESULTS (EXAMPLE) .....	416
<b>CAN SYSTEM (TYPE 12) .....</b>	<b>369</b>	Circuit Check Between TCM and Driver Seat Control Unit .....	431
System Description .....	369	Circuit Check Between Driver Seat Control Unit and Data Link Connector .....	432
Component Parts and Harness Connector Location .....	369	Circuit Check Between Data Link Connector and IPDM E/R .....	433
Schematic .....	370	ECM Circuit Check .....	434
Wiring Diagram - CAN - .....	371	TCM Circuit Check .....	434
Work Flow .....	374	Driver Seat Control Unit Circuit Check .....	435
CHECK SHEET .....	376	Combination Meter Circuit Check .....	435
CHECK SHEET RESULTS (EXAMPLE) .....	379	BCM Circuit Check .....	436
Circuit Check Between TCM and Differential Lock Control Unit .....	396	Data Link Connector Circuit Check .....	436
Circuit Check Between Differential Lock Control Unit and Driver Seat Control Unit .....	397	Steering Angle Sensor Circuit Check .....	437
Circuit Check Between Driver Seat Control Unit and Data Link Connector .....	398	Front Air Control Circuit Check .....	437
Circuit Check Between Data Link Connector and IPDM E/R .....	398	Transfer Control Unit Circuit Check .....	438
ECM Circuit Check .....	399	ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	438
TCM Circuit Check .....	400	IPDM E/R Circuit Check .....	439
Differential Lock Control Unit Circuit Check .....	400	CAN Communication Circuit Check .....	439
Driver Seat Control Unit Circuit Check .....	401	IPDM E/R Ignition Relay Circuit Check .....	440
Combination Meter Circuit Check .....	401	Component Inspection .....	440
		ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION .....	440

**PRECAUTIONS**

PF0:00001

**Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”**

UKS001AE

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

**Precautions When Using CONSULT-II**

UKS001AF

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

**CHECK POINTS FOR USING CONSULT-II**

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
  - If YES, GO TO 2.
  - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
  - If YES, GO TO 3.
  - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-7, "CAN Communication Unit"](#) .

**Precautions For Trouble Diagnosis CAN SYSTEM**

UKS001AG

- Do not apply voltage of 7.0V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN


# PRECAUTIONS

[CAN]


UKS001AH

## Precautions For Harness Repair CAN SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



## CAN COMMUNICATION

### System Description

UKS001AI

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### CAN Communication Unit

UKS001AJ

Go to CAN system, when selecting your CAN system type from the following table.


Body type	Truck												
Axle	2WD						4WD						
Engine	VK56DE												
Transmission	A/T												
Brake control	ABS	ABLS			VDC		ABLS					VDC	
Electronic locking rear differential										×	×	×	
Automatic drive positioner			×	×		×		×	×		×	×	×
Navigation system				×		×			×			×	
CAN system type	1	2	3	4	5	6	7	8	9	10	11	12	13
CAN system trouble diagnosis	<a href="#">LAN-24</a>	<a href="#">LAN-52</a>	<a href="#">LAN-80</a>	<a href="#">LAN-110</a>	<a href="#">LAN-143</a>	<a href="#">LAN-172</a>	<a href="#">LAN-206</a>	<a href="#">LAN-235</a>	<a href="#">LAN-267</a>	<a href="#">LAN-301</a>	<a href="#">LAN-333</a>	<a href="#">LAN-369</a>	<a href="#">LAN-408</a>

×: Applicable


#### NOTE:

Confirming the presence of the following items helps to identify CAN system type.

- Models with 4WD




- Models with ABLS




# CAN COMMUNICATION

[CAN]


- Models with VDC




- Models with electronic locking rear differential



- Models with automatic drive positioner



- Models with navigation system




# CAN COMMUNICATION

[CAN]

## TYPE 1

### System diagram

- Type 1



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Combina- tion meter	BCM	Front air control	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Engine speed signal	T	R	R		R		
Engine status signal	T			R	R		
Engine coolant temperature signal	T	R	R		R		
A/T self-diagnosis signal	R	T					
Accelerator pedal position signal	T	R					
Closed throttle position signal	T	R					
Wide open throttle position signal	T	R					
Battery voltage signal	T	R					
Ignition switch signal				T			R
Stop lamp switch signal		R	T				
Fuel consumption monitor signal	T		R				
			T				
Turbine revolution signal	R	T					
Output shaft revolution signal	R	T					
A/C switch signal	R			T	R		
A/C compressor request signal	T						R
Blower fan motor switch signal	R			T	R		
Cooling fan speed request signal	T				R		R
Position light request signal			R	T			R
Low beam request signal				T			R
Low beam status signal	R						T
High beam request signal			R	T			R
High beam status signal	R						T
Front fog light request signal				T			R

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Combina- tion meter	BCM	Front air control	ABS actu- ator and electric unit (con- trol unit)	IPDM E/R
Day time running light request signal				T			R
Rear window defogger request signal				T	R		R
Rear window defogger status signal				R			T
Vehicle speed signal			R		R	T	
	R	R	T	R	R		
Sleep wake up signal			R	T			R
Door switch signal			R	T			R
Turn indicator signal			R	T			
Buzzer output signal			R	T			
Fuel level sensor signal	R		T				
ASCD SET lamp signal	T		R				
ASCD CRUISE lamp signal	T		R				
Malfunction indicator lamp signal	T		R				
Front wiper request signal				T			R
Front wiper stop position signal				R			T
Theft warning horn request signal				T			R
Horn chirp signal				T			R
ABS warning lamp signal			R			T	
Brake warning lamp signal			R			T	
ASCD operation signal	T	R					
ASCD OD cancel request	T	R					
A/T CHECK indicator lamp signal		T	R				
A/T position indicator lamp signal		T	R				
Tire pressure signal			R	T			
1st position switch signal <sup>*1</sup>		R	T				
4th position switch signal <sup>*1</sup>		R	T				
Manual mode switch signal <sup>*2</sup>		R	T				
Not manual mode switch signal <sup>*2</sup>		R	T				
Manual mode shift up signal <sup>*2</sup>		R	T				
Manual mode shift down signal <sup>*2</sup>		R	T				
Tow mode switch signal		R	T				
A/T fluid temperature sensor signal		T	R				
Seat belt buckle switch signal			T	R			

\*1: Floor shift model only.

\*2: Column shift model only.


# CAN COMMUNICATION

[CAN]


## TYPE 2/TYPE 3/TYPE 4

### System diagram


- Type 2



- Type 3



- Type 4



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN COMMUNICATION

[CAN]

## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R		R	R	
Engine status signal	T					R	R		
Engine coolant temperature signal	T	R		R			R		
A/T self-diagnosis signal	R	T							
Accelerator pedal position signal	T	R						R	
Closed throttle position signal	T	R							
Wide open throttle position signal	T	R							
Battery voltage signal	T	R							
Key switch signal			R			T			
Ignition switch signal			R			T			R
P range signal		T	R					R	
Stop lamp switch signal		R		T					
Fuel consumption monitor signal	T			R					
				T	R				
Turbine revolution signal	R	T							
Output shaft revolution signal	R	T							
A/C switch signal	R					T			
A/C compressor request signal	T								R
Blower fan motor switch signal	R					T	R		
A/C switch/indicator signal					T		R		
					R		T		
Cooling fan speed request signal	T						R		R
Position light request signal				R		T			R
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal				R		T			R
High beam status signal	R								T
Front fog light request signal						T			R
Day time running light request signal						T			R
Rear window defogger request signal						T	R		R
Rear window defogger status signal						R			T
Vehicle speed signal				R			R	T	
	R	R	R	T	R	R	R		
Sleep wake up signal			R	R		T			R
Door switch signal			R	R	R	T			R
Turn indicator signal				R		T			
Key fob ID signal			R			T			
Key fob door unlock signal			R			T			
Buzzer output signal				R		T			

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Fuel level sensor signal	R			T					
Fuel level low warning signal				T	R				
ASCD SET lamp signal	T			R					
ASCD CRUISE lamp signal	T			R					
Malfunction indicator lamp signal	T			R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Theft warning horn request signal						T			R
Horn chirp signal						T			R
ABS warning lamp signal				R				T	
Brake warning lamp signal				R				T	
SLIP indicator lamp signal				R				T	
System setting signal			R		T				
			T		R				
Distance to empty signal				T	R				
ASCD operation signal	T	R							
ASCD OD cancel request	T	R							
A/T CHECK indicator lamp signal		T		R					
A/T position indicator lamp signal		T		R					
Tire pressure signal				R		T			
Tire pressure data signal					R	T			
1st position switch signal* <sup>1</sup>		R		T					
4th position switch signal* <sup>1</sup>		R		T					
Manual mode switch signal* <sup>2</sup>		R		T					
Not manual mode switch signal* <sup>2</sup>		R		T					
Manual mode shift up signal* <sup>2</sup>		R		T					
Manual mode shift down signal* <sup>2</sup>		R		T					
Tow mode switch signal		R		T					
A/T fluid temperature sensor signal		T		R					
Seat belt buckle switch signal				T		R			


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

\*1: Floor shift model only.


\*2: Column shift model only.

**TYPE 5/TYPE 6**  
**System diagram**

- Type 5



- Type 6



**Input/output signal chart**

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combina-tion meter	Dis-play control unit	BCM	Steer-ing angle sensor	Front air control	ABS actua-tor and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			R	R	
Engine status signal	T					R		R		
Engine coolant temperature signal	T			R				R		
A/T self-diagnosis signal	R	T								
Accelerator pedal position signal	T	R							R	
Closed throttle position signal	T	R								
Wide open throttle position signal	T	R								

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combina-tion meter	Dis-play control unit	BCM	Steer-ing angle sensor	Front air control	ABS actua-tor and elec-tric unit (con-trol unit)	IPDM E/R
Battery voltage signal	T	R								
Key switch signal			R			T				
Ignition switch signal			R			T				R
P range signal		T	R						R	
Stop lamp switch signal		R		T						
Fuel consumption monitor signal	T			R						
				T	R					
Turbine revolution signal	R	T								
Output shaft revolution signal	R	T								
A/C switch signal	R					T				
A/C compressor request signal	T									R
Blower fan motor switch signal	R					T		R		
A/C switch/indicator signal					T			R		
					R			T		
Cooling fan speed request signal	T							R		R
Position light request signal				R		T				R
Low beam request signal						T				R
Low beam status signal	R									T
High beam request signal				R		T				R
High beam status signal	R									T
Front fog light request signal						T				R
Day time running light request signal						T				R
Rear window defogger request signal						T		R		R
Rear window defogger status signal						R				T
Vehicle speed signal				R				R	T	
	R	R	R	T	R	R		R		
Sleep wake up signal			R	R		T				R
Door switch signal			R	R	R	T				R
Turn indicator signal				R		T				
Key fob ID signal			R			T				
Key fob door unlock signal			R			T				
Buzzer output signal				R		T				
Fuel level sensor signal	R			T						
Fuel level low warning signal				T	R					
ASCD SET lamp signal	T			R						
ASCD CRUISE lamp signal	T			R						
Malfunction indicator lamp signal	T			R						
Front wiper request signal						T				R
Front wiper stop position signal						R				T
Theft warning horn request signal						T				R

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Horn chirp signal						T				R
Steering angle sensor signal							T		R	
ABS warning lamp signal				R					T	
VDC OFF indicator lamp signal				R					T	
SLIP indicator lamp signal				R					T	
Brake warning lamp signal				R					T	
System setting signal			R		T					
			T		R					
Distance to empty signal				T	R					
ASCD operation signal	T	R								
ASCD OD cancel request	T	R								
A/T CHECK indicator lamp signal		T		R						
A/T position indicator lamp signal		T		R						
Tire pressure signal				R		T				
Tire pressure data signal					R	T				
1st position switch signal <sup>*1</sup>		R		T						
4th position switch signal <sup>*1</sup>		R		T						
Manual mode switch signal <sup>*2</sup>		R		T						
Not manual mode switch signal <sup>*2</sup>		R		T						
Manual mode shift up signal <sup>*2</sup>		R		T						
Manual mode shift down signal <sup>*2</sup>		R		T						
Tow mode switch signal		R		T						
A/T fluid temperature sensor signal		T		R						
Seat belt buckle switch signal				T		R				

\*1: Floor shift model only.

\*2: Column shift model only.


# CAN COMMUNICATION

[CAN]


TYPE 7/TYPE 8/TYPE 9/TYPE 10/TYPE 11/TYPE 12

## System diagram


- Type 7



- Type 8



- Type 9




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN


# CAN COMMUNICATION

[CAN]


- Type 10



- Type 11



- Type 12



# CAN COMMUNICATION

[CAN]

## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Differential lock control unit	Driver seat control unit	Combination meter	Display control unit	BCM	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
A/T self-diagnosis signal	R	T									
Stop lamp switch signal		R			T						
									R	T	
Battery voltage signal	T	R									
Key switch signal				R			T				
Ignition switch signal				R			T				R
P range signal		T		R						R	
Closed throttle position signal	T	R									
Wide open throttle position signal	T	R									
Engine speed signal	T	R			R	R		R	R	R	
Engine status signal	T						R	R			
Engine coolant temperature signal	T				R			R			
Accelerator pedal position signal	T	R								R	
Fuel consumption monitor signal	T				R						
					T	R					
Turbine revolution signal	R	T									
Output shaft revolution signal	R	T									
A/C switch signal	R						T				
A/C compressor request signal	T										R
Blower fan motor switch signal	R						T	R			
A/C switch/indicator signal						T		R			
						R		T			
Cooling fan speed request signal	T							R			R
Position light request signal					R		T				R
Low beam request signal							T				R
Low beam status signal	R										T
High beam request signal					R		T				R
High beam status signal	R										T
Front fog light request signal							T				R
Day time running light request signal							T				R
Rear window defogger request signal							T	R			R
Rear window defogger status signal							R				T
Vehicle speed signal			R		R			R	R	T	
	R	R		R	T	R	R	R			
Sleep wake up signal				R	R		T				R
Door switch signal				R	R	R	T				R
Key fob ID signal				R			T				

A

B

C

D

E

F

G

H

I

J

LAN

L

M

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Differential lock control unit	Driver seat control unit	Combination meter	Display control unit	BCM	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Key fob door unlock signal				R			T				
Buzzer output signal					R		T				
Fuel level sensor signal	R				T						
ASCD SET lamp signal	T				R						
ASCD CRUISE lamp signal	T				R						
Malfunction indicator lamp signal	T				R						
Fuel level low warning signal					T	R					
Front wiper request signal							T				R
Front wiper stop position signal							R				T
Theft warning horn request signal							T				R
Horn chirp signal							T				R
ABS warning lamp signal					R					T	
SLIP indicator lamp signal					R					T	
Brake warning lamp signal					R					T	
System setting signal				R		T					
				T		R					
Distance to empty signal					T	R					
ASCD operation signal	T	R									
ASCD OD cancel request	T	R									
A/T CHECK indicator lamp signal		T			R						
A/T position indicator lamp signal		T			R				R		
Tire pressure signal					R		T				
Tire pressure data signal						R	T				
1st position switch signal <sup>*1</sup>		R			T						
4th position switch signal <sup>*1</sup>		R			T						
Manual mode switch signal <sup>*2</sup>		R			T						
Not manual mode switch signal <sup>*2</sup>		R			T						
Manual mode shift up signal <sup>*2</sup>		R			T						
Manual mode shift down signal <sup>*2</sup>		R			T						
Tow mode switch signal		R			T						
A/T fluid temperature sensor signal		T			R						
4WD shift switch signal	R		R						T		
Seat belt buckle switch signal					T		R				
Differential lock switch signal			T							R	
Differential lock indicator signal			T							R	

\*1: Floor shift model only.

\*2: Column shift model only.


# CAN COMMUNICATION

[CAN]

## TYPE 13

### System diagram

- Type 13



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combination meter	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
A/T self-diagnosis signal	R	T								
Stop lamp switch signal		R		T				R	T	
Battery voltage signal	T	R								
Key switch signal			R		T					
Ignition switch signal			R		T					R
P range signal		T	R						R	
Closed throttle position signal	T	R								
Wide open throttle position signal	T	R								
Engine speed signal	T	R		R			R	R	R	
Engine status signal	T				R		R			
Engine coolant temperature signal	T			R			R			
Accelerator pedal position signal	T	R							R	
Fuel consumption monitor signal	T			R						
Turbine revolution signal	R	T								
Output shaft revolution signal	R	T								
A/C switch signal	R				T		R			
A/C compressor request signal	T									R
Blower fan motor switch signal	R				T		R			
Cooling fan speed request signal	T						R			R
Position light request signal				R	T					R

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Low beam request signal					T					R
Low beam status signal	R									T
High beam request signal				R	T					R
High beam status signal	R									T
Front fog light request signal					T					R
Day time running light request signal					T					R
Rear window defogger request signal					T		R			R
Rear window defogger status signal					R					T
Vehicle speed signal				R			R	R	T	
	R	R	R	T	R		R			
Sleep wake up signal			R	R	T					R
Door switch signal			R	R	T					R
Key fob ID signal			R		T					
Key fob door unlock signal			R		T					
Buzzer output signal				R	T					
Fuel level sensor signal	R			T						
ASCD SET lamp signal	T			R						
ASCD CRUISE lamp signal	T			R						
Malfunction indicator lamp signal	T			R						
Fuel level low warning signal				T						
Front wiper request signal					T					R
Front wiper stop position signal					R					T
Theft warning horn request signal					T					R
Horn chirp signal					T					R
Steering angle sensor signal						T			R	
ABS warning lamp signal				R					T	
VDC OFF indicator lamp signal				R					T	
SLIP indicator lamp signal				R					T	
Brake warning lamp signal				R					T	
ASCD operation signal	T	R								
ASCD OD cancel request	T	R								
A/T CHECK indicator lamp signal		T		R						
A/T position indicator lamp signal		T		R				R		
Tire pressure signal				R	T					
1st position switch signal <sup>*1</sup>		R		T						
4th position switch signal <sup>*1</sup>		R		T						
Manual mode switch signal <sup>*2</sup>		R		T						
Not manual mode switch signal <sup>*2</sup>		R		T						

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combina-tion meter	BCM	Steer-ing angle sensor	Front air control	Trans-fer control unit	ABS actua-tor and elec-tric unit (con-trol unit)	IPDM E/R
Manual mode shift up signal* <sup>2</sup>		R		T						
Manual mode shift down signal* <sup>2</sup>		R		T						
Tow mode switch signal		R		T						
A/T fluid temperature sensor signal		T		R						
4WD shift switch signal	R							T		
Seat belt buckle switch signal				T	R					

\*1: Floor shift model only.

\*2: Column shift model only.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CAN SYSTEM (TYPE 1)


### System Description

UKS001AK

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS001AL




# CAN SYSTEM (TYPE 1)

[CAN]

## Schematic

UKS001AM



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

BKWA0130E

# CAN SYSTEM (TYPE 1)


[CAN]

## Wiring Diagram - CAN -



UKS001AN

### LAN-CAN-01

▬ : DATA LINE



NEXT PAGE



REFER TO THE FOLLOWING.


(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0425E


# CAN SYSTEM (TYPE 1)

[CAN]

LAN-CAN-02




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



BKWA0426E

LAN-CAN-03

— : DATA LINE



37	38	39	40	41	42
43	44	45	46	47	48

(E122) W

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	
47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32

(E125) B

REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0427E

## Work Flow

- When there are no indications of "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

NISSAN  CONSULT-II  ENGINE START (NISSAN BASED VHCL) START (RENAULT BASED VHCL) SUB MODE LIGHT COPY		SELECT SYSTEM ENGINE A/T ABS AIR BAG BCM METER A/C AMP  BACK LIGHT COPY
---	--	---

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST  Scroll Down BACK LIGHT COPY		SELF-DIAG RESULTS DTC RESULTS    TIME <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 80%;">CAN COMM CIRCUIT (U1000)</td> <td style="width: 20%; text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table> F.F.DATA ERASE    PRINT MODE BACK LIGHT COPY	CAN COMM CIRCUIT (U1000)	0				
CAN COMM CIRCUIT (U1000)	0							

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST  Scroll Down BACK LIGHT COPY		CAN DIAG SUPPORT MNTR ENGINE <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2">ENGINE</th> </tr> <tr> <th> </th> <th>PRNT</th> </tr> <tr> <td>INITIAL DIAG</td> <td>OK</td> </tr> <tr> <td>TRANSMIT DIAG</td> <td>OK</td> </tr> <tr> <td>TCM</td> <td>OK</td> </tr> <tr> <td>VDC/TCS/ABS</td> <td>OK</td> </tr> <tr> <td>METER/M&amp;A</td> <td>OK</td> </tr> <tr> <td>ICC</td> <td>UNKWN</td> </tr> <tr> <td>BCM/SEC</td> <td>OK</td> </tr> <tr> <td>IPDM E/R</td> <td>OK</td> </tr> <tr> <td>AWD/4WD/e4WD</td> <td>UNKWN</td> </tr> </table> PRINT    Scroll Down MODE BACK LIGHT COPY	ENGINE			PRNT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN
ENGINE																								
	PRNT																							
INITIAL DIAG	OK																							
TRANSMIT DIAG	OK																							
TCM	OK																							
VDC/TCS/ABS	OK																							
METER/M&A	OK																							
ICC	UNKWN																							
BCM/SEC	OK																							
IPDM E/R	OK																							
AWD/4WD/e4WD	UNKWN																							

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-30, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-30, "CHECK SHEET"](#) .

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-32, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

# CAN SYSTEM (TYPE 1)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIB6627E

# CAN SYSTEM (TYPE 1)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
HVAC  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
HVAC  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

LAN

PKIB6628E

# CAN SYSTEM (TYPE 1)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-43, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—

PKIB6629E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 2

Check harness between data link connector and IPDM E/R. Refer to [LAN-44, "Circuit Check Between Data Link Connector and IPDM E/R"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6630E




## Case 3

Check ECM circuit. Refer to [LAN-45, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—

PKIB6631E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-46, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6632E




## Case 5

Check combination meter circuit. Refer to [LAN-46, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6633E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 6

Check BCM circuit. Refer to [LAN-47, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6634E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 7

Check data link connector circuit. Refer to [LAN-47, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6635E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 8

Check front air control circuit. Refer to [LAN-48, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6636E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-48, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6637E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 10

Check IPDM E/R circuit. Refer to [LAN-49, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6638E



# CAN SYSTEM (TYPE 1)

[CAN]

## Case 11

Check CAN communication circuit. Refer to [LAN-50, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6639E

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-50, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6640E

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-50, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS/ ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	-	UNKWN
A/T	-	NG	UNKWN	✓	-	✓	-	-	-
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
HVAC	No indication	-	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-
ABS	-	NG	UNKWN	✓	-	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-

PKIB6641E

## Circuit Check Between TCM and Data Link Connector

UKS001AP

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E34
  - Harness connector B40
  - Harness connector B69
  - Harness connector M40

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

**3 (L) - 12 (L) : Continuity should exist.**  
**8 (P) - 11 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E34 terminals 24 (L), 23 (P).

**12 (L) - 24 (L) : Continuity should exist.**  
**11 (P) - 23 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness.




### 4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B69.
2. Check continuity between harness connector B40 terminals 24 (L), 23 (P) and harness connector B69 terminals 51J (L), 52J (P).

**24 (L) - 51J (L) : Continuity should exist.**  
**23 (P) - 52J (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 5.  
 NG >> Repair harness.




### 5. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**  
**52J (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-29, "Work Flow"](#).  
 NG >> Repair harness.



## Circuit Check Between Data Link Connector and IPDM E/R

UKS001AQ

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).


**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



## 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).


**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-29, "Work Flow"](#).

NG >> Repair harness.



## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.



UKS001AS

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



UKS001AT

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66 Ω**

### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and data link connector.



UKS001AU

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66 Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.



UKS001AV

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Diagnose again. Refer to [LAN-29, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and combination meter.



## Front Air Control Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



UKS001AY

## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 108 - 132  $\Omega$**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.



PKIA8141E

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Combination meter
  - BCM
  - Front air control
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



### 3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

#### OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-51, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .  
 NG >> Repair harness.



## IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .


UKS001B1

## Component Inspection

### ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## CAN SYSTEM (TYPE 2)

PFP:23710


### System Description

UKS003A0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS003AP




# CAN SYSTEM (TYPE 2)

[CAN]

## Schematic

UKS003AQ



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN


BKWA0130E




# CAN SYSTEM (TYPE 2)

[CAN]

## LAN-CAN-05




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



BKWA0536E

LAN-CAN-06

▬ : DATA LINE



37	38	39	40	41	42
43	44	45	46	47	48

E122  
W

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	
47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32

E125  
B

REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0537E

## Work Flow

- When there are no indications of "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

NISSAN  CONSULT-II  ENGINE START (NISSAN BASED VHCL) START (RENAULT BASED VHCL) SUB MODE LIGHT COPY		SELECT SYSTEM ENGINE A/T ABS AIR BAG BCM METER A/C AMP  BACK LIGHT COPY
---	--	---

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST  Scroll Down BACK LIGHT COPY		SELF-DIAG RESULTS DTC RESULTS    TIME <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 80%;">CAN COMM CIRCUIT (U1000)</td> <td style="width: 20%; text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table> F.F.DATA ERASE    PRINT MODE BACK LIGHT COPY	CAN COMM CIRCUIT (U1000)	0				
CAN COMM CIRCUIT (U1000)	0							

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST  Scroll Down BACK LIGHT COPY		CAN DIAG SUPPORT MNTR ENGINE <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;">INITIAL DIAG</td> <td style="width: 40%;">OK</td> </tr> <tr> <td>TRANSMIT DIAG</td> <td>OK</td> </tr> <tr> <td>TCM</td> <td>OK</td> </tr> <tr> <td>VDC/TCS/ABS</td> <td>OK</td> </tr> <tr> <td>METER/M&amp;A</td> <td>OK</td> </tr> <tr> <td>ICC</td> <td>UNKWN</td> </tr> <tr> <td>BCM/SEC</td> <td>OK</td> </tr> <tr> <td>IPDM E/R</td> <td>OK</td> </tr> <tr> <td>AWD/4WD/e4WD</td> <td>UNKWN</td> </tr> </table> PRINT    Scroll Down MODE BACK LIGHT COPY	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN
INITIAL DIAG	OK																			
TRANSMIT DIAG	OK																			
TCM	OK																			
VDC/TCS/ABS	OK																			
METER/M&A	OK																			
ICC	UNKWN																			
BCM/SEC	OK																			
IPDM E/R	OK																			
AWD/4WD/e4WD	UNKWN																			

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-58, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-58, "CHECK SHEET"](#) .

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-60, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 2)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

# CAN SYSTEM (TYPE 2)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
HVAC  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
HVAC  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

LAN

PKIB6628E

# CAN SYSTEM (TYPE 2)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-71, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—

SKIB2704E



PKIA9478E

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 2

Check harness between data link connector and IPDM E/R. Refer to [LAN-72, "Circuit Check Between Data Link Connector and IPDM E/R"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2705E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 3

Check ECM circuit. Refer to [LAN-73, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>				
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>
HVAC	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—

SKIB2706E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-74, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2707E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 5

Check combination meter circuit. Refer to [LAN-74, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2708E



PKIA9482E

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 6

Check BCM circuit. Refer to [LAN-75, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—

SKIB2709E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 7

Check data link connector circuit. Refer to [LAN-75, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2710E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 8

Check front air control circuit. Refer to [LAN-76, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6774E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-76, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	✓	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2711E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 10

Check IPDM E/R circuit. Refer to [LAN-77, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2712E



PKIA9486E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 2)

[CAN]

## Case 11

Check CAN communication circuit. Refer to [LAN-78, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>				
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
BCM	No indication ✓	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>
HVAC	No indication ✓	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
ABS	—	NG ✓	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—
IPDM E/R	No indication ✓	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—

SKIB2713E

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-78, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>				
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>
HVAC	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—

SKIB2714E

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-78, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2715E

## Circuit Check Between TCM and Data Link Connector

UKS003AT

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E34
  - Harness connector B40
  - Harness connector B69
  - Harness connector M40

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

**3 (L) - 12 (L) : Continuity should exist.**  
**8 (P) - 11 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E34 terminals 24 (L), 23 (P).

**12 (L) - 24 (L) : Continuity should exist.**  
**11 (P) - 23 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness.




### 4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B69.
2. Check continuity between harness connector B40 terminals 24 (L), 23 (P) and harness connector B69 terminals 51J (L), 52J (P).

**24 (L) - 51J (L) : Continuity should exist.**  
**23 (P) - 52J (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 5.  
 NG >> Repair harness.




### 5. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**  
**52J (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-57, "Work Flow"](#).  
 NG >> Repair harness.



## Circuit Check Between Data Link Connector and IPDM E/R

UKS003AU

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).


**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



## 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).


**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-57, "Work Flow"](#).

NG >> Repair harness.



## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132  $\Omega$**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.



UKS003AW

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



UKS003AX

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66 Ω**

### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and data link connector.



UKS003AY

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66 Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.



UKS003AZ

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Diagnose again. Refer to [LAN-57, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and combination meter.



## Front Air Control Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P)**

**: Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



UKS003B1

## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P)**

**: Approx. 108 - 132  $\Omega$**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.



PKIA8141E

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Combination meter
  - BCM
  - Front air control
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



### 3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

#### OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-79, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).  
 NG >> Repair harness.



## IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).


UKS003B4

## Component Inspection

### ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CAN SYSTEM (TYPE 3)

PF2:23710


### System Description

UKS003A5

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS003A6




# CAN SYSTEM (TYPE 3)

[CAN]

## Schematic

UKS003A7



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

BKWA0132E

# CAN SYSTEM (TYPE 3)


[CAN]

## Wiring Diagram - CAN -


UKS003A8

### LAN-CAN-07

▬ : DATA LINE



NEXT PAGE



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

REFER TO THE FOLLOWING.






(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0428E

# CAN SYSTEM (TYPE 3)

[CAN]




## LAN-CAN-08



BKWA0429E

LAN-CAN-09

▬ : DATA LINE



REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0430E


# CAN SYSTEM (TYPE 3)

[CAN]


UKS003A9

## Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-86, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-86, "CHECK SHEET"](#).

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-88, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 3)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

# CAN SYSTEM (TYPE 3)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
AUTO DRIVE POS.  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
HVAC  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AUTO DRIVE POS.  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
HVAC  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

LAN

PKIB6658E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-101, "Circuit Check Between TCM and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—

SKIB2717E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-102, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—

SKIB2718E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-103, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2719E



PKIA9489E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 4

Check ECM circuit. Refer to [LAN-104, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—

SKIB2720E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 5

Check TCM circuit. Refer to [LAN-104, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2721E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 6

Check driver seat control unit circuit. Refer to [LAN-105, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2722E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 7

Check combination meter circuit. Refer to [LAN-105, "Combination Meter Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2723E



PKIA9493E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 8

Check BCM circuit. Refer to [LAN-106, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2724E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 9

Check data link connector circuit. Refer to [LAN-106, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2725E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 10

Check front air control circuit. Refer to [LAN-107, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB6775E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-107, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2726E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 12

Check IPDM E/R circuit. Refer to [LAN-108, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2727E



PKIA9497E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 3)

[CAN]

## Case 13

Check CAN communication circuit. Refer to [LAN-108, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>				
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
AUTO DRIVE POS.	No indication ✓	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—
BCM	No indication ✓	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>
HVAC	No indication ✓	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
ABS	—	NG ✓	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—
IPDM E/R	No indication ✓	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—

SKIB2728E

## Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-109, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>				
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>
HVAC	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—

SKIB2729E

**Case 15**

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-109, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	TCM	METER /M&A	BCM/SEC	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—

SKIB2730E

**Circuit Check Between TCM and Driver Seat Control Unit**

UKS003AA

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E50
  - Harness connector B75

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

**3 (L) - 12 (L) : Continuity should exist.**  
**8 (P) - 11 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E50.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E50 terminals 2 (L), 1 (P).

**12 (L) - 2 (L) : Continuity should exist.**  
**11 (P) - 1 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness.




### 4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B37.
2. Check continuity between harness connector B75 terminals 2 (L), 1 (P) and harness connector B37 terminals 15 (L), 14 (P).

**2 (L) - 15 (L) : Continuity should exist.**  
**1 (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-85, "Work Flow"](#).  
 NG >> Repair harness.



## Circuit Check Between Driver Seat Control Unit and Data Link Connector

UKS003AB

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector B69
  - Harness connector M40

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B37 and harness connector B69.
2. Check continuity between harness connector B37 terminals 15 (L), 14 (P) and harness connector B69 terminals 51J (L), 52J (P).

**15 (L) - 51J (L) : Continuity should exist.**  
**14 (P) - 52J (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



**3. CHECK HARNESS FOR OPEN CIRCUIT**


Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**

**52J (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-85, "Work Flow"](#).
- NG >> Repair harness.



**Circuit Check Between Data Link Connector and IPDM E/R**

UKS003AC

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



**3. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-85, "Work Flow"](#).
- NG >> Repair harness.



**ECM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.



PKIA0816E

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



SKIA6866E

**Driver Seat Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector P1
  - Harness connector B37

OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

**3 (L) - 19 (P) : Approx. 54 - 66 Ω**

OK or NG

OK &gt;&gt; Replace driver seat control unit.

NG &gt;&gt; Repair harness between driver seat control unit and harness connector B69.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66 Ω**

OK or NG

OK &gt;&gt; Replace combination meter.

NG &gt;&gt; Repair harness between combination meter and data link connector.



**BCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.

**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Diagnose again. Refer to [LAN-85, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and combination meter.



**Front Air Control Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E125.



**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 108 - 132  $\Omega$**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Driver seat control unit
  - Combination meter
  - BCM
  - Front air control
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR SHORT CIRCUIT**

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



**3. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-109, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).
- NG >> Repair harness.



**IPDM E/R Ignition Relay Circuit Check**

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

**Component Inspection**

**ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LAN

L  
M

## CAN SYSTEM (TYPE 4)


### System Description

UKS0039K

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS0039L




# CAN SYSTEM (TYPE 4)

[CAN]

## Schematic

UKS0039M



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

BKWA0134E

# CAN SYSTEM (TYPE 4)



[CAN]

## Wiring Diagram - CAN -

UKS0039N

### LAN-CAN-10

▬ : DATA LINE



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

REFER TO THE FOLLOWING.


(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0431E


# CAN SYSTEM (TYPE 4)

[CAN]

## LAN-CAN-11




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



BKWA0432E

LAN-CAN-12

— : DATA LINE



37	38	39	40	41	42
43	44	45	46	47	48

(E122) W

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	
47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32

(E125) B

REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0433E


# CAN SYSTEM (TYPE 4)

[CAN]


UKS00390

## Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-117, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-117, "CHECK SHEET"](#) .

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-148, "CAN Communication Line Check"](#) .
- Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-117, "CHECK SHEET"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CAN SYSTEM (TYPE 4)

[CAN]

- 
8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-117, "CHECK SHEET"](#) .

**NOTE:**

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-148, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-119, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

# CAN SYSTEM (TYPE 4)

[CAN]

## CHECK SHEET

### NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR check sheet

SKIB2731E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
AUTO DRIVE POS.  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
HVAC  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AUTO DRIVE POS.  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
HVAC  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB6658E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-133, "Circuit Check Between TCM and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	—	UNKWN	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3 ✓	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—	—

SKIB2732E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-134, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN ✓	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3 ✓	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—	—	

SKIB2733E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-135, "Circuit Check Between Data Link Connector and IPDM E/R"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—

SKIB2734E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 4

Check ECM circuit. Refer to [LAN-136, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—

SKIB2735E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 5

Check TCM circuit. Refer to [LAN-136, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

SKIB2736E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 6

Check driver seat control unit circuit. Refer to [LAN-137, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

SKIB2737E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 7

Check combination meter circuit. Refer to [LAN-137, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5 ✓	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

SKIB2738E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 8

Check display control unit circuit. Refer to [LAN-138, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	
Display control unit	—	CAN COMM	CAN CRC 1 ✓	CAN CRC 3 ✓	—	CAN CRC 5 ✓	—	CAN CRC 2 ✓	CAN CRC 4 ✓	—	CAN CRC 7 ✓	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

SKIB2739E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 9

Check BCM circuit. Refer to [LAN-138, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2 ✓	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN ✓	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN ✓	—	—	—	

SKIB2740E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 10

Check data link connector circuit. Refer to [LAN-139, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

SKIB2742E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 11

Check front air control circuit. Refer to [LAN-139, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

SKIB2743E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 12

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-140, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—

SKIB2744E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 13

Check IPDM E/R circuit. Refer to [LAN-140, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

SKIB2745E



# CAN SYSTEM (TYPE 4)

[CAN]

## Case 14

Check CAN communication circuit. Refer to [LAN-141, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UN <del>K</del> WN	—	UN <del>K</del> WN	UN <del>K</del> WN	—	UN <del>K</del> WN	—	UN <del>K</del> WN	UN <del>K</del> WN
A/T	—	NG	UN <del>K</del> WN	UN <del>K</del> WN	—	UN <del>K</del> WN	—	—	—	UN <del>K</del> WN	—
AUTO DRIVE POS.	No indication	NG	UN <del>K</del> WN	—	UN <del>K</del> WN	UN <del>K</del> WN	—	UN <del>K</del> WN	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UN <del>K</del> WN	UN <del>K</del> WN	—	UN <del>K</del> WN	—	—	—	—	UN <del>K</del> WN
HVAC	No indication	—	UN <del>K</del> WN	UN <del>K</del> WN	—	—	UN <del>K</del> WN	UN <del>K</del> WN	—	UN <del>K</del> WN	—
ABS	—	<del>NG</del>	UN <del>K</del> WN	UN <del>K</del> WN	UN <del>K</del> WN	—	—	—	—	—	—
IPDM E/R	No indication	—	UN <del>K</del> WN	UN <del>K</del> WN	—	—	—	UN <del>K</del> WN	—	—	—

SKIB2746E

## Case 15

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-141, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UN <del>K</del> WN	—	UN <del>K</del> WN	UN <del>K</del> WN	—	UN <del>K</del> WN	—	UN <del>K</del> WN	UN <del>K</del> WN
A/T	—	NG	UN <del>K</del> WN	UN <del>K</del> WN	—	UN <del>K</del> WN	—	—	—	UN <del>K</del> WN	—
AUTO DRIVE POS.	No indication	NG	UN <del>K</del> WN	—	UN <del>K</del> WN	UN <del>K</del> WN	—	UN <del>K</del> WN	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UN <del>K</del> WN	UN <del>K</del> WN	—	UN <del>K</del> WN	—	—	—	—	UN <del>K</del> WN
HVAC	No indication	—	UN <del>K</del> WN	UN <del>K</del> WN	—	—	UN <del>K</del> WN	UN <del>K</del> WN	—	UN <del>K</del> WN	—
ABS	—	NG	UN <del>K</del> WN	UN <del>K</del> WN	UN <del>K</del> WN	—	—	—	—	—	—
IPDM E/R	No indication	—	UN <del>K</del> WN	UN <del>K</del> WN	—	—	—	UN <del>K</del> WN	—	—	—

SKIB2747E

## Case 16

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-141, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

SKIB2748E

## Circuit Check Between TCM and Driver Seat Control Unit

UKS0039P

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E50
  - Harness connector B75

**OK or NG**

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).


**3 (L) - 12 (L) : Continuity should exist.**

**8 (P) - 11 (P) : Continuity should exist.**

**OK or NG**

OK >> GO TO 3.

NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E50.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E50 terminals 2 (L), 1 (P).

**12 (L) - 2 (L) : Continuity should exist.**  
**11 (P) - 1 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness.




### 4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B37.
2. Check continuity between harness connector B75 terminals 2 (L), 1 (P) and harness connector B37 terminals 15 (L), 14 (P).

**2 (L) - 15 (L) : Continuity should exist.**  
**1 (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-115, "Work Flow"](#).  
 NG >> Repair harness.



## Circuit Check Between Driver Seat Control Unit and Data Link Connector

UKS0039Q

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector B69
  - Harness connector M40

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B37 and harness connector B69.
2. Check continuity between harness connector B37 terminals 15 (L), 14 (P) and harness connector B69 terminals 51J (L), 52J (P).

**15 (L) - 51J (L) : Continuity should exist.**  
**14 (P) - 52J (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



### 3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**

**52J (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-115, "Work Flow"](#).
- NG >> Repair harness.



### Circuit Check Between Data Link Connector and IPDM E/R

UKS0039R

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

#### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



LAN

#### 3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-115, "Work Flow"](#).
- NG >> Repair harness.



**ECM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



**Driver Seat Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector P1
  - Harness connector B37

OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

**3 (L) - 19 (P) : Approx. 54 - 66 Ω**

OK or NG

OK &gt;&gt; Replace driver seat control unit.

NG &gt;&gt; Repair harness between driver seat control unit and harness connector B69.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66 Ω**

OK or NG

OK &gt;&gt; Replace combination meter.

NG &gt;&gt; Repair harness between combination meter and data link connector.



## Display Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

**25 (L) - 26 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace display control unit.  
 NG >> Repair harness between display control unit and data link connector.



UKS0039X

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.



**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Diagnose again. Refer to [LAN-115, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and combination meter.

**Front Air Control Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.



**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Driver seat control unit
  - Combination meter
  - Display control unit
  - BCM
  - Front air control
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR SHORT CIRCUIT**

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

**OK or NG**

- OK >> GO TO 3.  
 NG >> Repair harness.

**3. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

**OK or NG**

- OK >> Check ECM and IPDM E/R. Refer to [LAN-142, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .  
 NG >> Repair harness.

**IPDM E/R Ignition Relay Circuit Check**


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

**Component Inspection****ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



## CAN SYSTEM (TYPE 5)

PF2:23710


### System Description

UKS00392

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS00393




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 5)

[CAN]

## Schematic

UKS00394



BKWA0136E

# CAN SYSTEM (TYPE 5)


[CAN]

## Wiring Diagram - CAN -



UKS00395

### LAN-CAN-13

— : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



REFER TO THE FOLLOWING.






(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0434E

# CAN SYSTEM (TYPE 5)

[CAN]


## LAN-CAN-14





BKWA0435E

## LAN-CAN-15

▬ : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M




REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0436E

## Work Flow


- When there are no indications of "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-149, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-149, "CHECK SHEET"](#) .

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-151, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

# CAN SYSTEM (TYPE 5)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 5)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
AUTO DRIVE POS.  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
HVAC  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AUTO DRIVE POS.  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
HVAC  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB6658E

## CHECK SHEET RESULTS (EXAMPLE)

**NOTE:**


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

**Case 1**

Check harness between TCM and data link connector. Refer to [LAN-163, "Circuit Check Between TCM and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—

PKIB6643E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 2

Check harness between data link connector and IPDM E/R. Refer to [LAN-164, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6644E



PKIA9252E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 3

Check ECM circuit. Refer to [LAN-165, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>
A/T	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—
BCM	No indication	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	—	UNKW <sup>N</sup>
HVAC	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—
ABS	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	—
IPDM E/R	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	—	—

PKIB6645E



PKIA9253E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-166, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6646E



PKIA9254E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 5

Check combination meter circuit. Refer to [LAN-166, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6647E



PKIA9255E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 6

Check BCM circuit. Refer to [LAN-167, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—

PKIB6648E



PKIA9256E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 7

Check data link connector circuit. Refer to [LAN-167, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6649E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 8

Check steering angle sensor circuit. Refer to [LAN-168, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6650E




PKIA9258E

## Case 9

Check front air control circuit. Refer to [LAN-168, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN ✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6651E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-169, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6652E



PKIA9259E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 11

Check IPDM E/R circuit. Refer to [LAN-169, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6653E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 5)

[CAN]

## Case 12

Check CAN communication circuit. Refer to [LAN-170, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>
HVAC	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—

PKIB6654E

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-171, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>
HVAC	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—

PKIB6655E

## Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-171, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6656E

## Circuit Check Between TCM and Data Link Connector

UKS00397

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E50
  - Harness connector B75
  - Harness connector B69
  - Harness connector M40

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

**3 (L) - 12 (L) : Continuity should exist.**  
**8 (P) - 11 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E50.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E50 terminals 2 (L), 1 (P).

**12 (L) - 2 (L) : Continuity should exist.**  
**11 (P) - 1 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness.




### 4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B69.
2. Check continuity between harness connector B75 terminals 2 (L), 1 (P) and harness connector B69 terminals 51J (L), 52J (P).

**2 (L) - 51J (L) : Continuity should exist.**  
**1 (P) - 52J (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 5.  
 NG >> Repair harness.




### 5. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**  
**52J (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-148, "Work Flow"](#).  
 NG >> Repair harness.



## Circuit Check Between Data Link Connector and IPDM E/R

UKS00398

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).


**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



## 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).


**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-148, "Work Flow"](#).

NG >> Repair harness.



## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.



UKS0039A

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



UKS0039B

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and data link connector.



UKS0039C

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.



UKS0039D

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Diagnose again. Refer to [LAN-148, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and combination meter.



UKS0039E

## Steering Angle Sensor Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (L) and 4 (P).

**3 (L) - 4 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace steering angle sensor.  
 NG >> Repair harness between steering angle sensor and data link connector.



UKS003KP

## Front Air Control Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

UKS0039F

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 108 - 132 Ω**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.



UKS0039H

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Combination meter
  - BCM
  - Steering angle sensor
  - Front air control
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


## 2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



PKIA2077E

### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-171, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

NG >> Repair harness.



### IPDM E/R Ignition Relay Circuit Check

UKS0039I

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).


### Component Inspection

UKS0039J

#### ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CAN SYSTEM (TYPE 6)

PFP:23710


### System Description

UKS001F1

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS001F2




# CAN SYSTEM (TYPE 6)

[CAN]

## Schematic

UKS001F3



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

BKWA0140E

# CAN SYSTEM (TYPE 6)



[CAN]

## Wiring Diagram - CAN -

UKS001F4

### LAN-CAN-16

— — — : DATA LINE



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

REFER TO THE FOLLOWING.

(M40) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0440E

# CAN SYSTEM (TYPE 6)


[CAN]

## LAN-CAN-17

— : DATA LINE






A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



BKWA0441E

LAN-CAN-18

▬ : DATA LINE



REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0442E

## Work Flow

- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

NISSAN  CONSULT-II	➔	SELECT SYSTEM
ENGINE		ENGINE
START (NISSAN BASED VHCL)		A/T
START (RENAULT BASED VHCL)		ABS
SUB MODE		AIR BAG
LIGHT COPY		BCM
		METER A/C AMP
		BACK LIGHT COPY

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	➔	SELF-DIAG RESULTS
WORK SUPPORT		DTC RESULTS TIME
SELF-DIAG RESULTS		CAN COMM CIRCUIT (U1000) 0
DATA MONITOR		
DATA MONITOR (SPEC)		
CAN DIAG SUPPORT MNTR		F.F.DATA
ACTIVE TEST		ERASE PRINT
Scroll Down		MODE BACK LIGHT COPY
BACK LIGHT COPY		

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	➔	CAN DIAG SUPPORT MNTR
WORK SUPPORT		ENGINE
SELF-DIAG RESULTS		PRSRNT
DATA MONITOR		INITIAL DIAG OK
DATA MONITOR (SPEC)		TRANSMIT DIAG OK
CAN DIAG SUPPORT MNTR		TCM OK
ACTIVE TEST		VDC/TCS/ABS OK
Scroll Down		METER/M&A OK
BACK LIGHT COPY		ICC UNKWN
		BCM/SEC OK
		IPDM E/R OK
		AWD/4WD/e4WD UNKWN
		PRINT Scroll Down
		MODE BACK LIGHT COPY

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-179, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-179, "CHECK SHEET"](#).

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-148, "CAN Communication Line Check"](#).
- Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-179, "CHECK SHEET"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CAN SYSTEM (TYPE 6)

[CAN]

- 
8. Mark the “NG” or “UNKWN” item of the check sheet table with “v” from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-179, "CHECK SHEET"](#) .

**NOTE:**

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MONITOR” for the diagnosed control unit, replace the control unit. Refer to [AV-148, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-181, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

# CAN SYSTEM (TYPE 6)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 4	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	-	-	UNKWN
HVAC	No indication	-	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR check sheet

LAN

# CAN SYSTEM (TYPE 6)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
AUTO DRIVE POS.  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AUTO DRIVE POS.  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA9139E

# CAN SYSTEM (TYPE 6)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-196, "Circuit Check Between TCM and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6659E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-197, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	✓	—	✓	—	—	—	✓	✓
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	—	—	—	✓	—
AUTO DRIVE POS.	✓ No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	✓ CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	—
BCM	✓ No indication	NG	UNKWN	✓	—	UNKWN	—	—	—	—	—	UNKWN	—
HVAC	✓ No indication	—	UNKWN	✓	—	—	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	✓	✓	—	—	—	UNKWN	—	—	—	—
IPDM E/R	✓ No indication	—	UNKWN	✓	—	—	—	UNKWN	—	—	—	—	—

PKIB660E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-198, "Circuit Check Between Data Link Connector and IPDM E/R"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6661E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 4

Check ECM circuit. Refer to [LAN-199, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	—	—	UNKW <sup>✓</sup> N	—	
AUTO DRIVE POS.	No indication	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	—	—	—	UNKW <sup>✓</sup> N	
HVAC	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	UNKW <sup>✓</sup> N	—	—	—	
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	—	—	—	

PKIB6662E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 5

Check TCM circuit. Refer to [LAN-199, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UN <del>KN</del> W <del>N</del>	UN <del>KN</del> W <del>N</del>	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UN <del>KN</del> W <del>N</del>	—	UN <del>KN</del> W <del>N</del>	—	—	—	—	UN <del>KN</del> W <del>N</del>	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UN <del>KN</del> W <del>N</del>	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UN <del>KN</del> W <del>N</del>	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6663E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 6

Check driver seat control unit circuit. Refer to [LAN-200, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6664E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 7

Check combination meter circuit. Refer to [LAN-200, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	✓	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	✓	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	✓	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	✓	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6665E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 8

Check display control unit circuit. Refer to [LAN-201, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1 ✓	CAN CIRC 3 ✓	—	CAN CIRC 5 ✓	—	CAN CIRC 2 ✓	—	CAN CIRC 4 ✓	—	CAN CIRC 7 ✓	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIB666E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 9

Check BCM circuit. Refer to [LAN-201, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6667E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 10

Check data link connector circuit. Refer to [LAN-202, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIB668E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 11

Check steering angle sensor circuit. Refer to [LAN-202. "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6669E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 12

Check front air control circuit. Refer to [LAN-203, "Front Air Control Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIB6670E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 13

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-203, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6671E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 14

Check IPDM E/R circuit. Refer to [LAN-204, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN ✓	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7 ✓	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN ✓	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIB6672E



# CAN SYSTEM (TYPE 6)

[CAN]

## Case 15

Check CAN communication circuit. Refer to [LAN-204, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	—	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	
A/T	—	NG	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	—	—	—	—	UNKW <del>N</del> ✓	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1 ✓	CAN CIRC 3 ✓	—	CAN CIRC 5 ✓	—	CAN CIRC 2 ✓	—	CAN CIRC 4 ✓	—	CAN CIRC 7 ✓	
BCM	No indication ✓	NG	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	—	—	—	—	—	UNKW <del>N</del> ✓	
HVAC	No indication ✓	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	—	UNKW <del>N</del> ✓	—	
ABS	—	NG ✓	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	—	—	UNKW <del>N</del> ✓	—	—	—	
IPDM E/R	No indication ✓	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	—	—	UNKW <del>N</del> ✓	—	—	—	—	

PKIB6673E

## Case 16

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-205, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	—	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	
A/T	—	NG	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	—	—	—	—	UNKW <del>N</del> ✓	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1 ✓	CAN CIRC 3 ✓	—	CAN CIRC 5 ✓	—	CAN CIRC 2 ✓	—	CAN CIRC 4 ✓	—	CAN CIRC 7 ✓	
BCM	No indication ✓	NG	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	—	—	—	—	—	UNKW <del>N</del> ✓	
HVAC	No indication ✓	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	—	UNKW <del>N</del> ✓	—	
ABS	—	NG	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	—	—	UNKW <del>N</del> ✓	—	—	—	
IPDM E/R	No indication ✓	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	—	—	UNKW <del>N</del> ✓	—	—	—	—	

PKIB6674E

## Case 17

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-205, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	UNKW	—	UNKW	—	—	UNKW	UNKW
A/T	—	NG	UNKW	UNKW	—	UNKW	—	—	—	—	UNKW	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	UNKW	—	UNKW	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	—	—	—	—	UNKW
HVAC	No indication	—	UNKW	UNKW	—	—	UNKW	UNKW	—	—	UNKW	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	—	UNKW	—	—	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—

PKIB6675E

## Circuit Check Between TCM and Driver Seat Control Unit

UKS0023H

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E50
  - Harness connector B75

OK or NG

- OK    >> GO TO 2.  
 NG    >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

**3 (L) - 12 (L)                    : Continuity should exist.**  
**8 (P) - 11 (P)                     : Continuity should exist.**

OK or NG

- OK    >> GO TO 3.  
 NG    >> Repair harness.




**3. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector E50.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E50 terminals 2 (L), 1 (P).

**12 (L) - 2 (L) : Continuity should exist.**  
**11 (P) - 1 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness.




**4. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector B37.
2. Check continuity between harness connector B75 terminals 2 (L), 1 (P) and harness connector B37 terminals 15 (L), 14 (P).

**2 (L) - 15 (L) : Continuity should exist.**  
**1 (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-177, "Work Flow"](#).
- NG >> Repair harness.



**Circuit Check Between Driver Seat Control Unit and Data Link Connector**

UKS0023I

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector B69
  - Harness connector M40

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector B37 and harness connector B69.
2. Check continuity between harness connector B37 terminals 15 (L), 14 (P) and harness connector B69 terminals 51J (L), 52J (P).

**15 (L) - 51J (L) : Continuity should exist.**  
**14 (P) - 52J (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

**3. CHECK HARNESS FOR OPEN CIRCUIT**


Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**

**52J (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-177, "Work Flow"](#).
- NG >> Repair harness.



**Circuit Check Between Data Link Connector and IPDM E/R**

UKS0023J

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



**3. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-177, "Work Flow"](#).
- NG >> Repair harness.



**ECM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

**OK or NG**

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

**OK or NG**

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



## Driver Seat Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector P1
  - Harness connector B37

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

**3 (L) - 19 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace driver seat control unit.  
 NG >> Repair harness between driver seat control unit and harness connector B69.



## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and data link connector.



**Display Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

**25 (L) - 26 (P) : Approx. 54 - 66 Ω**

**OK or NG**

- OK >> Replace display control unit.  
 NG >> Repair harness between display control unit and data link connector.

**BCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66 Ω**

**OK or NG**

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.



## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Diagnose again. Refer to [LAN-177, "Work Flow"](#).  
 NG >> Repair harness between data link connector and combination meter.



## Steering Angle Sensor Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (L) and 4 (P).

**3 (L) - 4 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace steering angle sensor.  
 NG >> Repair harness between steering angle sensor and data link connector.



**Front Air Control Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Driver seat control unit
  - Combination meter
  - Display control unit
  - BCM
  - Steering angle sensor
  - Front air control
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR SHORT CIRCUIT**

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



**3. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-205, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).
- NG >> Repair harness.



**IPDM E/R Ignition Relay Circuit Check**


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

**Component Inspection  
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CAN SYSTEM (TYPE 7)


### System Description

UKS001FN

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS001FO




# CAN SYSTEM (TYPE 7)

[CAN]

## Schematic

UKS001FP



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

BKWA0142E

# CAN SYSTEM (TYPE 7)


[CAN]

## Wiring Diagram - CAN -



UKS001FQ

### LAN-CAN-19

▬ : DATA LINE



NEXT PAGE



REFER TO THE FOLLOWING.


(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0443E

# CAN SYSTEM (TYPE 7)


[CAN]

## LAN-CAN-20



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



LAN



BKWA0444E

LAN-CAN-21

▬ : DATA LINE



REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0445E


# CAN SYSTEM (TYPE 7)

[CAN]


UKS001FR

## Work Flow


- When there are no indications of "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-212, "CHECK SHEET"](#).

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-212, "CHECK SHEET"](#).

### NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-214, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

# CAN SYSTEM (TYPE 7)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

# CAN SYSTEM (TYPE 7)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
HVAC  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
HVAC  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB6772E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-226, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—

SKIB2750E



# CAN SYSTEM (TYPE 7)


[CAN]

## Case 2

Check harness between data link connector and IPDM E/R. Refer to [LAN-227, "Circuit Check Between Data Link Connector and IPDM E/R"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB2751E



PKIA9512E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 3

Check ECM circuit. Refer to [LAN-228, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N						
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	
HVAC	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	
ALL MODE AWD/4WD	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	—	

SKIB2752E



# CAN SYSTEM (TYPE 7)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-229, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	

SKIB2753E



PKIA9514E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 5

Check combination meter circuit. Refer to [LAN-229, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	

SKIB2754E



PKIA9515E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 6

Check BCM circuit. Refer to [LAN-230, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	

SKIB2755E



# CAN SYSTEM (TYPE 7)


[CAN]

## Case 7

Check data link connector circuit. Refer to [LAN-230, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	

SKIB2756E



PKIA9517E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 8

Check front air control circuit. Refer to [LAN-231, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6776E



PKIB6776E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 9

Check transfer control unit circuit. Refer to [LAN-231, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	

SKIB2757E



# CAN SYSTEM (TYPE 7)


[CAN]

## Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-232, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB2758E



# CAN SYSTEM (TYPE 7)


[CAN]

## Case 11

Check IPDM E/R circuit. Refer to [LAN-232, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB2759E



PKIA9520E

# CAN SYSTEM (TYPE 7)

[CAN]

## Case 12

Check CAN communication circuit. Refer to [LAN-233, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB2760E

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-234, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	—	UNKWN ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB2761E

## Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-234, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	✓	—	✓	—	✓	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	✓	UNKWN	—	—	✓	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	

SKIB2762E

## Circuit Check Between TCM and Data Link Connector

UKS001FS

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E50
  - Harness connector B75
  - Harness connector B69
  - Harness connector M40

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

**3 (L) - 12 (L) : Continuity should exist.**  
**8 (P) - 11 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.




**3. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector E50.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E50 terminals 2 (L), 1 (P).

**12 (L) - 2 (L) : Continuity should exist.**  
**11 (P) - 1 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness.




**4. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector B69.
2. Check continuity between harness connector B75 terminals 2 (L), 1 (P) and harness connector B69 terminals 51J (L), 52J (P).

**2 (L) - 51J (L) : Continuity should exist.**  
**1 (P) - 52J (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 5.
- NG >> Repair harness.




**5. CHECK HARNESS FOR OPEN CIRCUIT**

Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**  
**52J (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-211, "Work Flow"](#).
- NG >> Repair harness.



**Circuit Check Between Data Link Connector and IPDM E/R**

UKS001FT

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).


**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



## 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).


**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-211, "Work Flow"](#).

NG >> Repair harness.



## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.



UKS001FV

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



UKS001FW

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and data link connector.



UKS001FX

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.



UKS001FY

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Diagnose again. Refer to [LAN-211, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and combination meter.



## Front Air Control Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.



## Transfer Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 1 (L) and 2 (P).

**1 (L) - 2 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace transfer control unit.  
 NG >> Repair harness between transfer control unit and harness connector E152.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

UKS001G1

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



## IPDM E/R Circuit Check

UKS001G2

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.



UKS001G3

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Combination meter
  - BCM
  - Front air control
  - Transfer control unit
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



PKIA2077E

### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-234, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

NG >> Repair harness.



UKS001G4

### IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).


### Component Inspection

#### ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

UKS001G5

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



## CAN SYSTEM (TYPE 8)


### System Description

UKS001G6

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS001G7




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 8)

[CAN]

## Schematic

UKS001G8



BKWA0144E

# CAN SYSTEM (TYPE 8)


[CAN]

## Wiring Diagram - CAN -




UKS001G9

### LAN-CAN-22

— : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

REFER TO THE FOLLOWING.



(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0446E

# CAN SYSTEM (TYPE 8)

[CAN]


## LAN-CAN-23




BKWA0447E

## LAN-CAN-24

▬ : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M




REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0448E

## Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-241, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-241, "CHECK SHEET"](#) .

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-243, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

# CAN SYSTEM (TYPE 8)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

LAN

# CAN SYSTEM (TYPE 8)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
AUTO DRIVE POS.  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
HVAC  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AUTO DRIVE POS.  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
HVAC  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB6773E

## CHECK SHEET RESULTS (EXAMPLE)

**NOTE:**


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

**Case 1**

Check harness between TCM and driver seat control unit. Refer to [LAN-257, "Circuit Check Between TCM and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—

SKIB2766E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-258, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	

SKIB2767E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-259, "Circuit Check Between Data Link Connector and IPDM E/R"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB2768E



PKIA9523E

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 4

Check ECM circuit. Refer to [LAN-260, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N						
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	
AUTO DRIVE POS.	No indication	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	
HVAC	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	
ALL MODE AWD/4WD	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	—	

SKIB2769E



PKIA9524E

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 5

Check TCM circuit. Refer to [LAN-260, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	

SKIB2770E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 6

Check driver seat control unit circuit. Refer to [LAN-261, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB2771E




## Case 7

Check combination meter circuit. Refer to [LAN-261, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	✓	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	✓	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	✓	UNKWN	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	✓	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	

SKIB2773E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 8

Check BCM circuit. Refer to [LAN-262. "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	

SKIB2774E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 9

Check data link connector circuit. Refer to [LAN-262, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB2775E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 10

Check front air control circuit. Refer to [LAN-263, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6777E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 11

Check transfer control unit circuit. Refer to [LAN-263, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB2776E



PKIA9530E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 12

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-264, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	

SKIB2777E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 13

Check IPDM E/R circuit. Refer to [LAN-264, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB2778E



# CAN SYSTEM (TYPE 8)

[CAN]

## Case 14

Check CAN communication circuit. Refer to [LAN-265, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>					
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	—
AUTO DRIVE POS.	No indication <del>✓</del>	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—
BCM	No indication <del>✓</del>	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>
HVAC	No indication <del>✓</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
ALL MODE AWD/4WD	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—
IPDM E/R	No indication <del>✓</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—

SKIB2779E

## Case 15

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-265, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>					
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	—
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>
HVAC	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—
ALL MODE AWD/4WD	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—

SKIB2780E

## Case 16

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-265, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	✓	—	✓	—	✓	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	✓	UNKWN	—	—	✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB2781E

## Circuit Check Between TCM and Driver Seat Control Unit

UKS001GB

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E50
  - Harness connector B75

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).


**3 (L) - 12 (L) : Continuity should exist.**

**8 (P) - 11 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E50.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E50 terminals 2 (L), 1 (P).

**12 (L) - 2 (L) : Continuity should exist.**  
**11 (P) - 1 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness.




### 4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B37.
2. Check continuity between harness connector B75 terminals 2 (L), 1 (P) and harness connector B37 terminals 15 (L), 14 (P).

**2 (L) - 15 (L) : Continuity should exist.**  
**1 (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-240, "Work Flow"](#).  
 NG >> Repair harness.



## Circuit Check Between Driver Seat Control Unit and Data Link Connector

UKS001GC

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector B69
  - Harness connector M40

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B37 and harness connector B69.
2. Check continuity between harness connector B37 terminals 15 (L), 14 (P) and harness connector B69 terminals 51J (L), 52J (P).

**15 (L) - 51J (L) : Continuity should exist.**  
**14 (P) - 52J (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



**3. CHECK HARNESS FOR OPEN CIRCUIT**


Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**

**52J (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-240, "Work Flow"](#).
- NG >> Repair harness.



**Circuit Check Between Data Link Connector and IPDM E/R**

UKS001GD

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



LAN

**3. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-240, "Work Flow"](#).
- NG >> Repair harness.



**ECM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



**Driver Seat Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector P1
  - Harness connector B37

OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

**3 (L) - 19 (P) : Approx. 54 - 66 Ω**

OK or NG

OK &gt;&gt; Replace driver seat control unit.

NG &gt;&gt; Repair harness between driver seat control unit and harness connector B69.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66 Ω**

OK or NG

OK &gt;&gt; Replace combination meter.

NG &gt;&gt; Repair harness between combination meter and data link connector.



**BCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.

**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Diagnose again. Refer to [LAN-240, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and combination meter.



**Front Air Control Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.

**Transfer Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 1 (L) and 2 (P).

**1 (L) - 2 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace transfer control unit.  
 NG >> Repair harness between transfer control unit and harness connector E152.



**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.

**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 108 - 132  $\Omega$**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.



**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Driver seat control unit
  - Combination meter
  - BCM
  - Front air control
  - Transfer control unit
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

**OK or NG**

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair or replace as necessary.

**2. CHECK HARNESS FOR SHORT CIRCUIT**


With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

**OK or NG**

OK &gt;&gt; GO TO 3.

NG &gt;&gt; Repair harness.

**3. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

**OK or NG**

OK >> Check ECM and IPDM E/R. Refer to [LAN-266. "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

NG >> Repair harness.

**IPDM E/R Ignition Relay Circuit Check**


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26. "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13. "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

**Component Inspection****ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



## CAN SYSTEM (TYPE 9)


### System Description

UKS001GR

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS001GS




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 9)

[CAN]

## Schematic

UKS001GT



BKWA0146E

# CAN SYSTEM (TYPE 9)


[CAN]

## Wiring Diagram - CAN -




UKS001GU

LAN-CAN-25

— : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M





\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

REFER TO THE FOLLOWING.

(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0449E

## LAN-CAN-26




BKWA0450E

# CAN SYSTEM (TYPE 9)


[CAN]

## LAN-CAN-27

▬ : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M




REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0451E

## Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-274, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-274, "CHECK SHEET"](#) .

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
  - The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.
- Check CAN communication line of the navigation system. Refer to [AV-148, "CAN Communication Line Check"](#) .
  - Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-274, "CHECK SHEET"](#) .

## CAN SYSTEM (TYPE 9)

[CAN]

8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-274, "CHECK SHEET"](#) .

**NOTE:**

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-148, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-276, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 9)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table													
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR check sheet

SKIB2782E

# CAN SYSTEM (TYPE 9)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of HVAC SELF-DIAG RESULTS	Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
Attach copy of HVAC CAN DIAG SUPPORT MNTR	Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

PKIB6773E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-291, "Circuit Check Between TCM and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	✓	—	✓	—	✓	✓	✓	
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	—	✓	✓	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	UNKWN	—	UNKWN	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	✓	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	✓	—	UNKWN	—	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	✓	—	—	UNKWN	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	✓	✓	—	—	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	✓	—	—	—	UNKWN	—	—	—	—	

SKIB2783E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-292, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	✓	—	✓	—	—	✓	✓	✓
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	—	—	✓	✓	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7	—
BCM	No indication	NG	UNKWN	✓	—	UNKWN	—	—	—	—	—	UNKWN	—
HVAC	No indication	—	UNKWN	✓	—	—	UNKWN	UNKWN	—	—	UNKWN	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	✓	✓	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	—	UNKWN	—	—	—	—	—

SKIB2784E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-293, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN	—
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—

SKIB2785E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 4

Check ECM circuit. Refer to [LAN-294, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

SKIB2786E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 5

Check TCM circuit. Refer to [LAN-294, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

SKIB2787E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 6

Check driver seat control unit circuit. Refer to [LAN-295, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

SKIB2788E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 9)


[CAN]

## Case 7

Check combination meter circuit. Refer to [LAN-295, "Combination Meter Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

SKIB2789E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 8

Check display control unit circuit. Refer to [LAN-296, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CRC 1 ✓	CAN CRC 3 ✓	—	CAN CRC 5 ✓	—	CAN CRC 2 ✓	CAN CRC 4 ✓	—	—	CAN CRC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

SKIB2790E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 9)


[CAN]

## Case 9

Check BCM circuit. Refer to [LAN-296, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

SKIB2791E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 10

Check data link connector circuit. Refer to [LAN-297, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

SKIB2792E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 9)


[CAN]

## Case 11

Check front air control circuit. Refer to [LAN-297, "Front Air Control Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4 ✓	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

SKIB2794E




## Case 12

Check transfer control unit circuit. Refer to [LAN-298, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

SKIB2795E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 13

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-298, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

SKIB2796E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 14

Check IPDM E/R circuit. Refer to [LAN-299, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	—
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

SKIB2797E



# CAN SYSTEM (TYPE 9)

[CAN]

## Case 15

Check CAN communication circuit. Refer to [LAN-299, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—	
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	
HVAC	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	
ALL MODE AWD/4WD	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	—	
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	—	—	—	

SKIB2798E

## Case 16

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-300, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—	
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	
HVAC	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	
ALL MODE AWD/4WD	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	—	
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	—	—	—	

SKIB2799E

## Case 17

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-300, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

SKIB2800E

## Circuit Check Between TCM and Driver Seat Control Unit

UKS001GW

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E50
  - Harness connector B75

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).


**3 (L) - 12 (L) : Continuity should exist.**

**8 (P) - 11 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E50.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E50 terminals 2 (L), 1 (P).

**12 (L) - 2 (L) : Continuity should exist.**  
**11 (P) - 1 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness.




### 4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B37.
2. Check continuity between harness connector B75 terminals 2 (L), 1 (P) and harness connector B37 terminals 15 (L), 14 (P).

**2 (L) - 15 (L) : Continuity should exist.**  
**1 (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-272, "Work Flow"](#).  
 NG >> Repair harness.



## Circuit Check Between Driver Seat Control Unit and Data Link Connector

UKS001GX

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector B69
  - Harness connector M40

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B37 and harness connector B69.
2. Check continuity between harness connector B37 terminals 15 (L), 14 (P) and harness connector B69 terminals 51J (L), 52J (P).

**15 (L) - 51J (L) : Continuity should exist.**  
**14 (P) - 52J (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



### 3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**

**52J (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-272, "Work Flow"](#).
- NG >> Repair harness.



### Circuit Check Between Data Link Connector and IPDM E/R

UKS001GY

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

#### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



LAN

#### 3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-272, "Work Flow"](#).
- NG >> Repair harness.



**ECM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



**Driver Seat Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector P1
  - Harness connector B37

OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

**3 (L) - 19 (P) : Approx. 54 - 66 Ω**

OK or NG

OK &gt;&gt; Replace driver seat control unit.

NG &gt;&gt; Repair harness between driver seat control unit and harness connector B69.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66 Ω**

OK or NG

OK &gt;&gt; Replace combination meter.

NG &gt;&gt; Repair harness between combination meter and data link connector.



## Display Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

**25 (L) - 26 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace display control unit.  
 NG >> Repair harness between display control unit and data link connector.



## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.



**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Diagnose again. Refer to [LAN-272, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and combination meter.

**Front Air Control Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.



**Transfer Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 1 (L) and 2 (P).

**1 (L) - 2 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace transfer control unit.  
 NG >> Repair harness between transfer control unit and harness connector E152.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Driver seat control unit
  - Combination meter
  - Display control unit
  - BCM
  - Front air control
  - Transfer control unit
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


## 2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



## 3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-300, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).
- NG >> Repair harness.



## IPDM E/R Ignition Relay Circuit Check


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

## Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



## CAN SYSTEM (TYPE 10)

PF2:23710


### System Description

UKS001HE

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS001HF



BKIA0137E


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 10)

[CAN]

## Schematic

UKS001HG



BKWA0148E

# CAN SYSTEM (TYPE 10)




[CAN]

## Wiring Diagram - CAN -

UKS001HH

LAN-CAN-28

— — — : DATA LINE



REFER TO THE FOLLOWING.






(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0452E

# CAN SYSTEM (TYPE 10)

[CAN]

## LAN-CAN-29




BKWA0453E

# CAN SYSTEM (TYPE 10)


[CAN]

## LAN-CAN-30

— : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M




REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0454E

## Work Flow


- When there are no indications of "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "DIFF LOCK", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "DIFF LOCK", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-307, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-307, "CHECK SHEET"](#) .

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-309, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

# CAN SYSTEM (TYPE 10)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	UNKWN	UNKWN	-
DIFF LOCK	-	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	UNKWN	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	UNKWN	UNKWN
HVAC	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	UNKWN	UNKWN	-
ALL MODE AWD/4WD	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	UNKWN	-

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

LAN

# CAN SYSTEM (TYPE 10)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of DIFF LOCK SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of HVAC SELF-DIAG RESULTS	Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of DIFF LOCK CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
Attach copy of HVAC CAN DIAG SUPPORT MNTR	Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

PKIB6677E

## CHECK SHEET RESULTS (EXAMPLE)

**NOTE:**


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

**Case 1**

Check harness between TCM and differential lock control unit. Refer to [LAN-323, "Circuit Check Between TCM and Differential Lock Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—
DIFF LOCK	—	NG	UNKWN	UNKWN ✓	—	—	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—	—

PKIB6678E



# CAN SYSTEM (TYPE 10)


[CAN]

## Case 2

Check harness between differential lock control unit and data link connector. Refer to [LAN-324, "Circuit Check Between Differential Lock Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6679E



PKIA9548E

# CAN SYSTEM (TYPE 10)


[CAN]

## Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-325, "Circuit Check Between Data Link Connector and IPDM E/R"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6680E




## Case 4

Check ECM circuit. Refer to [LAN-326, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N					
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	
DIFF LOCK	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	
HVAC	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	
ALL MODE AWD/4WD	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	UNKW <sup>✓</sup> N	—	
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	—	—	

PKIB6681E




## Case 5

Check TCM circuit. Refer to [LAN-326, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6682E




## Case 6

Check differential lock control unit circuit. Refer to [LAN-327, "Differential Lock Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN ✓	UNKWN ✓	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6683E




## Case 7

Check combination meter circuit. Refer to [LAN-327, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6684E



# CAN SYSTEM (TYPE 10)


[CAN]

## Case 8

Check BCM circuit. Refer to [LAN-328, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6685E




## Case 9

Check data link connector circuit. Refer to [LAN-328, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6686E




## Case 10

Check front air control circuit. Refer to [LAN-329, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6687E




## Case 11

Check transfer control unit circuit. Refer to [LAN-329, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6688E



# CAN SYSTEM (TYPE 10)


[CAN]

## Case 12

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-330, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6689E



# CAN SYSTEM (TYPE 10)


[CAN]

## Case 13

Check IPDM E/R circuit. Refer to [LAN-330, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—

PKIB6690E



# CAN SYSTEM (TYPE 10)

[CAN]

## Case 14

Check CAN communication circuit. Refer to [LAN-331, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS		
ENGINE	—	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>					
A/T	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—
DIFF LOCK	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—
BCM	No indication <sup>✓</sup>	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>
HVAC	No indication <sup>✓</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—
ALL MODE AWD/4WD	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—
ABS	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—
IPDM E/R	No indication <sup>✓</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—

PKIB6691E

## Case 15

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-331, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS		
ENGINE	—	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>					
A/T	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—
DIFF LOCK	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—
BCM	No indication	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>
HVAC	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—
ALL MODE AWD/4WD	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—
ABS	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—
IPDM E/R	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—

PKIB6692E

## Case 16

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-331, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	UNKWN ✓	—	—	UNKWN ✓	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6693E

## Circuit Check Between TCM and Differential Lock Control Unit

UKS0020I

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E50
  - Harness connector B75

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).


**3 (L) - 12 (L) : Continuity should exist.**

**8 (P) - 11 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E50.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E50 terminals 2 (L), 1 (P).

**12 (L) - 2 (L) : Continuity should exist.**  
**11 (P) - 1 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness.




### 4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector.
2. Check continuity between harness connector B75 terminals 2 (L), 1 (P) and differential lock control unit harness connector B77 terminals 5 (L), 4 (P).

**2 (L) - 5 (L) : Continuity should exist.**  
**1 (P) - 4 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-306, "Work Flow"](#).  
 NG >> Repair harness.



## Circuit Check Between Differential Lock Control Unit and Data Link Connector

UKS001HJ

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector B69
  - Harness connector M40

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector and harness connector B69.
2. Check continuity between differential lock control unit harness connector B77 terminals 5 (L), 4 (P) and harness connector B69 terminals 51J (L), 52J (P).

**5 (L) - 51J (L) : Continuity should exist.**  
**4 (P) - 52J (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



**3. CHECK HARNESS FOR OPEN CIRCUIT**


Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**

**52J (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-306, "Work Flow"](#).
- NG >> Repair harness.



**Circuit Check Between Data Link Connector and IPDM E/R**

UKS001HK

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



**3. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-306, "Work Flow"](#).
- NG >> Repair harness.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

**ECM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.



PKIA0816E

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



SKIA6866E

**Differential Lock Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of differential lock control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect differential lock control unit connector.
2. Check resistance between differential lock control unit harness connector B77 terminals 5 (L) and 4 (P).

**5 (L) - 4 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace differential lock control unit.  
 NG >> Repair harness between differential lock control unit and harness connector B75.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and data link connector.



**BCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.

**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Diagnose again. Refer to [LAN-306, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and combination meter.



**Front Air Control Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.

**Transfer Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 1 (L) and 2 (P).

**1 (L) - 2 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace transfer control unit.  
 NG >> Repair harness between transfer control unit and harness connector E152.



**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.

**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 108 - 132  $\Omega$**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.



**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Differential lock control unit
  - Combination meter
  - BCM
  - Front air control
  - Transfer control unit
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR SHORT CIRCUIT**

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

**OK or NG**

- OK >> GO TO 3.  
 NG >> Repair harness.


**3. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**  
**14 (P) - Ground : Continuity should not exist.**

**OK or NG**

- OK >> Check ECM and IPDM E/R. Refer to [LAN-332, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).  
 NG >> Repair harness.

**IPDM E/R Ignition Relay Circuit Check**


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

**Component Inspection****ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



## CAN SYSTEM (TYPE 11)

PFP:23710


### System Description

UKS001HX

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS001HY




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 11)

[CAN]

## Schematic

UKS001HZ



BKWA0152E

# CAN SYSTEM (TYPE 11)


[CAN]

UKS00110

## Wiring Diagram - CAN -



### LAN-CAN-31

— : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN




\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

REFER TO THE FOLLOWING.

(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0455E

## LAN-CAN-32



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M18)  
W



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

(M22)  
W

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M24)  
W

27	28	29	30	31	32	33	34	35
36	37	38	39	40	41	42	43	44


(M50)  
W

# CAN SYSTEM (TYPE 11)


[CAN]

## LAN-CAN-33

▬ : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M




REFER TO THE FOLLOWING.  
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0457E

## Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "DIFF LOCK", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "DIFF LOCK", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-339, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-339, "CHECK SHEET"](#) .

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-342, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .



# CAN SYSTEM (TYPE 11)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
DIFF LOCK  
SELF-DIAG RESULTS

Attach copy of  
AUTO DRIVE POS.  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
HVAC  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

PKIB6695E

# CAN SYSTEM (TYPE 11)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
DIFF LOCK  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AUTO DRIVE POS.  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
HVAC  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB6696E

## CHECK SHEET RESULTS (EXAMPLE)

**NOTE:**


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

**Case 1**

Check harness between TCM and differential lock control unit. Refer to [LAN-358, "Circuit Check Between TCM and Differential Lock Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6697E



# CAN SYSTEM (TYPE 11)


[CAN]

## Case 2

Check harness between differential lock control unit and driver seat control unit. Refer to [LAN-359, "Circuit Check Between Differential Lock Control Unit and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN ✓	UNKWN ✓	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—	—	

PKIB6698E




## Case 3

Check harness between driver seat control unit and data link connector. Refer to [LAN-360, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN ✓	UNKWN ✓	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—	—

PKIB6699E



# CAN SYSTEM (TYPE 11)


[CAN]

## Case 4

Check harness between data link connector and IPDM E/R. Refer to [LAN-360, "Circuit Check Between Data Link Connector and IPDM E/R"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6700E



# CAN SYSTEM (TYPE 11)


[CAN]

## Case 5

Check ECM circuit. Refer to [LAN-361, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N					
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	
DIFF LOCK	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	
AUTO DRIVE POS.	No indication	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	
HVAC	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	
ALL MODE AWD/4WD	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	UNKW <sup>✓</sup> N	—	
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	—	—	

PKIB6701E




## Case 6

Check TCM circuit. Refer to [LAN-362, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6702E




## Case 7

Check differential lock control unit circuit. Refer to [LAN-362, "Differential Lock Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN ✓	UNKWN ✓	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6703E




## Case 8

Check driver seat control unit circuit. Refer to [LAN-363, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6704E



# CAN SYSTEM (TYPE 11)


[CAN]

## Case 9

Check combination meter circuit. Refer to [LAN-363, "Combination Meter Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6705E



# CAN SYSTEM (TYPE 11)


[CAN]

## Case 10

Check BCM circuit. Refer to [LAN-364, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6706E



# CAN SYSTEM (TYPE 11)


[CAN]

## Case 11

Check data link connector circuit. Refer to [LAN-364, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	

PKIB6707E




## Case 12

Check front air control circuit. Refer to [LAN-365, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6708E




## Case 13

Check transfer control unit circuit. Refer to [LAN-365, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—

PKIB6709E



# CAN SYSTEM (TYPE 11)


[CAN]

## Case 14

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-366, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—

PKIB6710E



PKIA9571E



# CAN SYSTEM (TYPE 11)

[CAN]

## Case 16

Check CAN communication circuit. Refer to [LAN-367, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>					
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—
DIFF LOCK	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—
AUTO DRIVE POS.	No indication ✓	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—
BCM	No indication ✓	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—
HVAC	No indication ✓	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—
ALL MODE AWD/4WD	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—
IPDM E/R	No indication ✓	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	—	—	—

PKIB6712E

## Case 17

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-368, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>					
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—
DIFF LOCK	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—
HVAC	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	—
ALL MODE AWD/4WD	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—	—	—	—

PKIB6713E

## Case 18

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-368, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	DIFF LOCK	METER/M&A	BCM/SEC	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6714E

## Circuit Check Between TCM and Differential Lock Control Unit

UKS0020K

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E50
  - Harness connector B75

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

**3 (L) - 12 (L) : Continuity should exist.**  
**8 (P) - 11 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.




**3. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector E50.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E50 terminals 2 (L), 1 (P).

**12 (L) - 2 (L) : Continuity should exist.**  
**11 (P) - 1 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness.




**4. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect differential lock control unit connector.
2. Check continuity between harness connector B75 terminals 2 (L), 1 (P) and differential lock control unit harness connector B77 terminals 5 (L), 4 (P).

**2 (L) - 5 (L) : Continuity should exist.**  
**1 (P) - 4 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-338, "Work Flow"](#).  
 NG >> Repair harness.



**Circuit Check Between Differential Lock Control Unit and Driver Seat Control Unit**

UKS0012


**1. CHECK HARNESS FOR OPEN CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect differential lock control unit connector and harness connector B37.
4. Check continuity between differential lock control unit harness connector B77 terminals 5 (L), 4 (P) and harness connector B37 terminals 15 (L), 14 (P).

**5 (L) - 15 (L) : Continuity should exist.**  
**4 (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-338, "Work Flow"](#).  
 NG >> Repair harness.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LAN

L  
M

**Circuit Check Between Driver Seat Control Unit and Data Link Connector****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector B69
  - Harness connector M40

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector B37 and harness connector B69.
2. Check continuity between harness connector B37 terminals 15 (L), 14 (P) and harness connector B69 terminals 51J (L), 52J (P).

**15 (L) - 51J (L) : Continuity should exist.**  
**14 (P) - 52J (P) : Continuity should exist.**

**OK or NG**

- OK >> GO TO 3.  
 NG >> Repair harness.


**3. CHECK HARNESS FOR OPEN CIRCUIT**

Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**  
**52J (P) - 14 (P) : Continuity should exist.**

**OK or NG**

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-338, "Work Flow"](#).  
 NG >> Repair harness.

**Circuit Check Between Data Link Connector and IPDM E/R****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

**6 (L) - 31G (L) : Continuity should exist.**  
**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




**3. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

**31G (L) - 39 (L) : Continuity should exist.**  
**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-338, "Work Flow"](#).
- NG >> Repair harness.



UKS00115

**ECM Circuit Check**

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LAN


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.



UKS00116

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



UKS0020L

## Differential Lock Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of differential lock control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector.
2. Check resistance between differential lock control unit harness connector B77 terminals 5 (L) and 4 (P).

**5 (L) - 4 (P) : Approx. 54 - 66 Ω**

### OK or NG

- OK >> Replace differential lock control unit.  
 NG >> Repair harness between differential lock control unit and harness connector B75.



UKS0017

## Driver Seat Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector P1
  - Harness connector B37

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

**3 (L) - 19 (P) : Approx. 54 - 66 Ω**

### OK or NG

- OK >> Replace driver seat control unit.  
 NG >> Repair harness between driver seat control unit and harness connector B69.



UKS0018

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and data link connector.



UKS00119

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).  
 NG >> Repair harness between BCM and data link connector.



UKS0011A

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Diagnose again. Refer to [LAN-338, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and combination meter.



PKIA2077E

## Front Air Control Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.



PKIA8136E

## Transfer Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

UKS001C


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 1 (L) and 2 (P).

**1 (L) - 2 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace transfer control unit.  
 NG >> Repair harness between transfer control unit and harness connector E152.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

UKS0011D

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



## IPDM E/R Circuit Check

UKS0011E

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.



UKS001F

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Differential lock control unit
  - Driver seat control unit
  - Combination meter
  - BCM
  - Front air control
  - Transfer control unit
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



PKIA2077E

### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-368, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .

NG >> Repair harness.



UKS001G

### IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .


### Component Inspection

#### ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

UKS001H

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



## CAN SYSTEM (TYPE 12)

PF2:23710


### System Description

UKS00111

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS0011J




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 12)

[CAN]

## Schematic

UKS001K



BKWA0156E

# CAN SYSTEM (TYPE 12)


[CAN]

## Wiring Diagram - CAN -




UKS001L

### LAN-CAN-34

— : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M









\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

REFER TO THE FOLLOWING.

M40 - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0458E

## LAN-CAN-35






BKWA0459E

# CAN SYSTEM (TYPE 12)

[CAN]

## LAN-CAN-36

— : DATA LINE




REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0460E

## Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "DIFF LOCK", "AUTO DRIVE POS.", "BCM", "HAVC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "DIFF LOCK", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-376, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-376, "CHECK SHEET"](#) .

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-148, "CAN Communication Line Check"](#) .
- Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-376, "CHECK SHEET"](#) .

## CAN SYSTEM (TYPE 12)

[CAN]

8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-376, "CHECK SHEET"](#) .

**NOTE:**

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-148, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-379, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 12)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR check sheet

# CAN SYSTEM (TYPE 12)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
DIFF LOCK  
SELF-DIAG RESULTS

Attach copy of  
AUTO DRIVE POS.  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
HVAC  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

PKIB6695E

# CAN SYSTEM (TYPE 12)

[CAN]

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
DIFF LOCK  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
AUTO DRIVE POS.  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
HVAC  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIB6696E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and differential lock control unit. Refer to [LAN-396, "Circuit Check Between TCM and Differential Lock Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	—	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	—	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—	—	—

PKIB6726E



# CAN SYSTEM (TYPE 12)


[CAN]

## Case 2

Check harness between differential lock control unit and driver seat control unit. Refer to [LAN-397, "Circuit Check Between Differential Lock Control Unit and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R	
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN	—	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—

PKIB672E





# CAN SYSTEM (TYPE 12)


[CAN]

## Case 4

Check harness between data link connector and IPDM E/R. Refer to [LAN-398, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR														
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R			
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—	—

PKIB6729E



# CAN SYSTEM (TYPE 12)


[CAN]

## Case 5

Check ECM circuit. Refer to [LAN-399, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3 ✓	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	—	—	UNKWN	—	—	—	—

PKIB6730E



PKIA9577E

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 6

Check TCM circuit. Refer to [LAN-400, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIB6731E



# CAN SYSTEM (TYPE 12)


[CAN]

## Case 7

Check differential lock control unit circuit. Refer to [LAN-400, "Differential Lock Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	—	—	UNKWN ✓	UNKWN ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIB6732E



PKIA9579E

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 8

Check driver seat control unit circuit. Refer to [LAN-401, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIB6733E



PKIA9580E

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 9

Check combination meter circuit. Refer to [LAN-401, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIB6734E



PKIA9581E

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 10

Check display control unit circuit. Refer to [LAN-402, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CINC 1	CAN CINC 3	—	—	CAN CINC 5	—	CAN CINC 2	CAN CINC 4	—	—	CAN CINC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIB6735E



# CAN SYSTEM (TYPE 12)


[CAN]

## Case 11

Check BCM circuit. Refer to [LAN-402. "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIB6736E



PKIA9583E

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 12

Check data link connector circuit. Refer to [LAN-403, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	—	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	—	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—	—	—

PKIB6737E



# CAN SYSTEM (TYPE 12)


[CAN]

## Case 13

Check front air control circuit. Refer to [LAN-403. "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—	UNKWN	—	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	UNKWN	—	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	—	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	UNKWN	—	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	—	—	—	—	—	—

PKIB6738E



PKIA9585E

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 14

Check transfer control unit circuit. Refer to [LAN-404, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR															
		Initial diagnosis	Transmit diagnosis	Receive diagnosis													
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	—	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	—	—	UNKWN	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—	—	—

PKIB6739E



# CAN SYSTEM (TYPE 12)


[CAN]

## Case 15

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-404, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIB6740E



PKIA9587E

# CAN SYSTEM (TYPE 12)


[CAN]

## Case 16

Check IPDM E/R circuit. Refer to [LAN-405, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR													
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—	—	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 7	✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	UNKWN	✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	—	—

PKIB6741E



# CAN SYSTEM (TYPE 12)

[CAN]

## Case 17

Check CAN communication circuit. Refer to [LAN-406, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
DIFF LOCK	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	—	—	—	UNKW <del>N</del>
HVAC	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—
ALL MODE AWD/4WD	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	—	—	—	—

PKIB6742E

## Case 18

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-406, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
DIFF LOCK	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—
AUTO DRIVE POS.	No indication	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	—	—	—	—	—	UNKW <del>N</del>
HVAC	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	UNKW <del>N</del>	—
ALL MODE AWD/4WD	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	—	—	UNKW <del>N</del>	—
ABS	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	—	UNKW <del>N</del>	—	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	—	—	—	—	UNKW <del>N</del>	—	—	—	—	—

PKIB6743E

## Case 19

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-406, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	DIFF LOCK	METER /M&A	DISPLAY	BCM /SEC	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 5	—	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	UNKWN ✓	—	—	—	—	UNKWN ✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—

PKIB6744E

## Circuit Check Between TCM and Differential Lock Control Unit

UKS0020F

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E50
  - Harness connector B75

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

3 (L) - 12 (L) : Continuity should exist.  
8 (P) - 11 (P) : Continuity should exist.

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.




**3. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector E50.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E50 terminals 2 (L), 1 (P).

**12 (L) - 2 (L) : Continuity should exist.**  
**11 (P) - 1 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness.




**4. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect differential lock control unit connector.
2. Check continuity between harness connector B75 terminals 2 (L), 1 (P) and differential lock control unit harness connector B77 terminals 5 (L), 4 (P).

**2 (L) - 5 (L) : Continuity should exist.**  
**1 (P) - 4 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-374, "Work Flow"](#) .  
 NG >> Repair harness.



**Circuit Check Between Differential Lock Control Unit and Driver Seat Control Unit**

UKS001IN


**1. CHECK HARNESS FOR OPEN CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect differential lock control unit connector and harness connector B37.
4. Check continuity between differential lock control unit harness connector B77 terminals 5 (L), 4 (P) and harness connector B37 terminals 15 (L), 14 (P).

**5 (L) - 15 (L) : Continuity should exist.**  
**4 (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-374, "Work Flow"](#) .  
 NG >> Repair harness.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LAN

L  
M

**Circuit Check Between Driver Seat Control Unit and Data Link Connector****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector B69
  - Harness connector M40

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect harness connector B37 and harness connector B69.
2. Check continuity between harness connector B37 terminals 15 (L), 14 (P) and harness connector B69 terminals 51J (L), 52J (P).

**15 (L) - 51J (L) : Continuity should exist.**  
**14 (P) - 52J (P) : Continuity should exist.**

**OK or NG**

- OK >> GO TO 3.  
 NG >> Repair harness.


**3. CHECK HARNESS FOR OPEN CIRCUIT**

Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**  
**52J (P) - 14 (P) : Continuity should exist.**

**OK or NG**

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-374, "Work Flow"](#).  
 NG >> Repair harness.

**Circuit Check Between Data Link Connector and IPDM E/R****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).


**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



## 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).


**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-374, "Work Flow"](#).

NG >> Repair harness.



## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.



UKS0011R

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



UKS0020G

## Differential Lock Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of differential lock control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector.
2. Check resistance between differential lock control unit harness connector B77 terminals 5 (L) and 4 (P).

**5 (L) - 4 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace differential lock control unit.  
 NG >> Repair harness between differential lock control unit and harness connector B75.



UKS001S

## Driver Seat Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector P1
  - Harness connector B37

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

**3 (L) - 19 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace driver seat control unit.  
 NG >> Repair harness between driver seat control unit and harness connector B69.



UKS001T

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and data link connector.



UKS0011U

## Display Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

**25 (L) - 26 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace display control unit.  
 NG >> Repair harness between display control unit and data link connector.



UKS0011V

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS001IW

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Diagnose again. Refer to [LAN-374, "Work Flow"](#).
- NG >> Repair harness between data link connector and combination meter.



UKS0020H

## Front Air Control Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.



UKS001Z

## Transfer Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 1 (L) and 2 (P).

**1 (L) - 2 (P) : Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace transfer control unit.  
 NG >> Repair harness between transfer control unit and harness connector E152.



UKS001J0

## ABS Actuator and Electric Unit (Control Unit) Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P)**

**: Approx. 54 - 66  $\Omega$**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



UKS001J1

## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P)**

**: Approx. 108 - 132  $\Omega$**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.



PKIA8141E

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Differential lock control unit
  - Driver seat control unit
  - Combination meter
  - Display control unit
  - BCM
  - Front air control
  - Transfer control unit
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



### 3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

#### OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-407, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).  
 NG >> Repair harness.



## IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).


UKS001J4

## Component Inspection

### ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

**LAN**

## CAN SYSTEM (TYPE 13)

PFP:23710


### System Description

UKS0038H

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS0038I




# CAN SYSTEM (TYPE 13)

[CAN]

## Schematic

UKS0038J



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

BKWA0164E

# CAN SYSTEM (TYPE 13)





[CAN]

## Wiring Diagram - CAN -

UKS0038K

### LAN-CAN-37

▬ : DATA LINE



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

REFER TO THE FOLLOWING.


(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0464E

# CAN SYSTEM (TYPE 13)


[CAN]

## LAN-CAN-38



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



LAN



BKWA0465E

LAN-CAN-39

▬ : DATA LINE




REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0466E

## Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-414, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-414, "CHECK SHEET"](#) .

**NOTE:**

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-416, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 13)

[CAN]

## CHECK SHEET

**NOTE:**

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

# CAN SYSTEM (TYPE 13)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of HVAC SELF-DIAG RESULTS	Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
Attach copy of HVAC CAN DIAG SUPPORT MNTR	Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

LAN

PKIB6773E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-431, "Circuit Check Between TCM and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UN <del>KN</del> ✓W <del>N</del>	UN <del>KN</del> ✓W <del>N</del>	—	UN <del>KN</del> ✓W <del>N</del>	UN <del>KN</del> ✓W <del>N</del>	UN <del>KN</del> ✓W <del>N</del>	
A/T	—	NG	UNKWN	UNKWN	—	UN <del>KN</del> ✓W <del>N</del>	—	—	UN <del>KN</del> ✓W <del>N</del>	UN <del>KN</del> ✓W <del>N</del>	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UN <del>KN</del> ✓W <del>N</del>	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UN <del>KN</del> ✓W <del>N</del>	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UN <del>KN</del> ✓W <del>N</del>	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UN <del>KN</del> ✓W <del>N</del>	UN <del>KN</del> ✓W <del>N</del>	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UN <del>KN</del> ✓W <del>N</del>	UN <del>KN</del> ✓W <del>N</del>	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UN <del>KN</del> ✓W <del>N</del>	—	—	UNKWN	—	—	—	—	

PKIB6746E




## Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-432, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	

PKIB6747E



# CAN SYSTEM (TYPE 13)


[CAN]

## Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-433, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIB6748E




## Case 4

Check ECM circuit. Refer to [LAN-434, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	
A/T	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	
AUTO DRIVE POS.	No indication	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	—	—	UNKW <sup>✓</sup> N	
HVAC	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	
ALL MODE AWD/4WD	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	—	—	UNKW <sup>✓</sup> N	—	
ABS	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	—	—	—	—	

PKIB6749E



# CAN SYSTEM (TYPE 13)


[CAN]

## Case 5

Check TCM circuit. Refer to [LAN-434, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIB6750E



# CAN SYSTEM (TYPE 13)


[CAN]

## Case 6

Check driver seat control unit circuit. Refer to [LAN-435, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIB6751E



# CAN SYSTEM (TYPE 13)


[CAN]

## Case 7

Check combination meter circuit. Refer to [LAN-435, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIB6752E



# CAN SYSTEM (TYPE 13)


[CAN]

## Case 8

Check BCM circuit. Refer to [LAN-436, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIB6753E



# CAN SYSTEM (TYPE 13)


[CAN]

## Case 9

Check data link connector circuit. Refer to [LAN-436, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIB6754E



# CAN SYSTEM (TYPE 13)


[CAN]

## Case 10

Check steering angle sensor circuit. Refer to [LAN-437, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIB6756E




## Case 11

Check front air control circuit. Refer to [LAN-437, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIB6755E



# CAN SYSTEM (TYPE 13)


[CAN]

## Case 12

Check transfer control unit circuit. Refer to [LAN-438, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIB6757E




LAN

## Case 13

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-438, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIB6758E



# CAN SYSTEM (TYPE 13)


[CAN]

## Case 14

Check IPDM E/R circuit. Refer to [LAN-439, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIB6759E



# CAN SYSTEM (TYPE 13)

[CAN]

## Case 15

Check CAN communication circuit. Refer to [LAN-439, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	
A/T	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	
AUTO DRIVE POS.	No indication	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	
BCM	No indication	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	—	—	UNKW <sup>N</sup>	
HVAC	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	
ALL MODE AWD/4WD	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	UNKW <sup>N</sup>	—	
ABS	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	
IPDM E/R	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	—	—	—	

PKIB6760E

## Case 16

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-440, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	
A/T	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	
AUTO DRIVE POS.	No indication	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	
BCM	No indication	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—	—	—	UNKW <sup>N</sup>	
HVAC	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	
ALL MODE AWD/4WD	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	UNKW <sup>N</sup>	—	
ABS	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	
IPDM E/R	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	UNKW <sup>N</sup>	—	—	—	—	

PKIB6761E

## Case 17

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-440, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN ✓	UNKWN ✓	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIB6762E

## Circuit Check Between TCM and Driver Seat Control Unit

UKS0038M

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F33
  - Harness connector E19
  - Harness connector E50
  - Harness connector B75

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).


**3 (L) - 12 (L) : Continuity should exist.**

**8 (P) - 11 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E50.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E50 terminals 2 (L), 1 (P).

**12 (L) - 2 (L) : Continuity should exist.**  
**11 (P) - 1 (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness.




### 4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B37.
2. Check continuity between harness connector B75 terminals 2 (L), 1 (P) and harness connector B37 terminals 15 (L), 14 (P).

**2 (L) - 15 (L) : Continuity should exist.**  
**1 (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-413, "Work Flow"](#).  
 NG >> Repair harness.



## Circuit Check Between Driver Seat Control Unit and Data Link Connector

UKS0038N

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector B69
  - Harness connector M40

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B37 and harness connector B69.
2. Check continuity between harness connector B37 terminals 15 (L), 14 (P) and harness connector B69 terminals 51J (L), 52J (P).

**15 (L) - 51J (L) : Continuity should exist.**  
**14 (P) - 52J (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



### 3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

**51J (L) - 6 (L) : Continuity should exist.**

**52J (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-413, "Work Flow"](#).
- NG >> Repair harness.



### Circuit Check Between Data Link Connector and IPDM E/R

UKS00380

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M31
  - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

#### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

**6 (L) - 31G (L) : Continuity should exist.**

**14 (P) - 42G (P) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



#### 3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

**31G (L) - 39 (L) : Continuity should exist.**

**42G (P) - 40 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-413, "Work Flow"](#).
- NG >> Repair harness.



**ECM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector E19
  - Harness connector F33

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

**3 (L) - 8 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace A/T assembly.  
 NG >> Repair harness between A/T assembly and harness connector F33.



**Driver Seat Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side and harness side).
  - Driver seat control unit connector
  - Harness connector P1
  - Harness connector B37

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

**3 (L) - 19 (P) : Approx. 54 - 66 Ω**

**OK or NG**

- OK >> Replace driver seat control unit.  
 NG >> Repair harness between driver seat control unit and harness connector B69.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

**11 (L) - 12 (P) : Approx. 54 - 66 Ω**

**OK or NG**

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and data link connector.



**BCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between BCM and data link connector.

**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Diagnose again. Refer to [LAN-413, "Work Flow"](#) .  
 NG >> Repair harness between data link connector and combination meter.



**Steering Angle Sensor Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (L) and 4 (P).

**3 (L) - 4 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace steering angle sensor.  
 NG >> Repair harness between steering angle sensor and data link connector.

**Front Air Control Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control and data link connector.



**Transfer Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 1 (L) and 2 (P).

**1 (L) - 2 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace transfer control unit.  
 NG >> Repair harness between transfer control unit and harness connector E152.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

**11 (L) - 15 (P) : Approx. 54 - 66 Ω**

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and harness connector E152.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - A/T assembly
  - Driver seat control unit
  - Combination meter
  - BCM
  - Steering angle sensor
  - Front air control
  - Transfer control unit
  - ABS actuator and electric unit (control unit)
  - IPDM E/R

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


## 2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



## 3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-440, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).
- NG >> Repair harness.



## IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

UKS00390

## Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

UKS00391

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	

