

A
EC
C
D
E
F
G
H
I
J
K
L
M

SECTION EC

ENGINE CONTROL SYSTEM

CONTENTS

KA24DE	
INDEX FOR DTC	17
Alphabetical Index	17
DTC No. Index	19
PRECAUTIONS	22
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	22
Precautions for On Board Diagnostic (OBD) System of Engine	22
Engine Fuel & Emission Control System	23
Precautions	24
Wiring Diagrams and Trouble Diagnosis	25
PREPARATION	26
Special Service Tools	26
Commercial Service Tools	26
ENGINE CONTROL SYSTEM	28
System Diagram	28
Vacuum Hose Drawing	29
System Chart	30
Multiport Fuel Injection (MFI) System	30
Distributor Ignition (DI) System	32
Air Conditioning Cut Control	33
Fuel Cut Control (at No Load and High Engine Speed)	33
Fast Idle Cam (FIC)	34
BASIC SERVICE PROCEDURE	35
Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment	35
Fuel Pressure Check	45
Fuel Pressure Regulator Check	47
ON BOARD DIAGNOSTIC (OBD) SYSTEM	48
Introduction	48
Two Trip Detection Logic	48
Emission-related Diagnostic Information	49
Malfunction Indicator Lamp (MIL)	61
OBD System Operation Chart	62
TROUBLE DIAGNOSIS	67
Trouble Diagnosis Introduction	67
DTC Inspection Priority Chart	71
Fail-safe Chart	72
Basic Inspection	73
Symptom Matrix Chart	83
Engine Control Component Parts Location	88
Circuit Diagram	90
ECM Harness Connector Terminal Layout	91
ECM Terminals and Reference Value	91
CONSULT-II Function	99
Generic Scan Tool (GST)	110
CONSULT-II Reference Value in Data Monitor Mode	112
Major Sensor Reference Graph in Data Monitor Mode	113
TROUBLE DIAGNOSIS - SPECIFICATION VALUE	116
Description	116
Testing Condition	116
Inspection Procedure	116
Diagnostic Procedure	117
TROUBLE DIAGNOSIS FOR INTERMITTENT INCI- DENT	120
Description	120
Diagnostic Procedure	120
POWER SUPPLY CIRCUIT FOR ECM	121
Wiring Diagram	121
Diagnostic Procedure	122
DTC P0031, P0032 HO2S1 HEATER	126
Description	126
CONSULT-II Reference Value in Data Monitor Mode	126
On Board Diagnosis Logic	126
DTC Confirmation Procedure	127
Wiring Diagram	128
Diagnostic Procedure	129
Removal and Installation	130
DTC P0037, P0038 HO2S2 HEATER	131
Description	131
CONSULT-II Reference Value in Data Monitor Mode	131
On Board Diagnosis Logic	131
DTC Confirmation Procedure	132
Wiring Diagram	133

Diagnostic Procedure	134	DTC P0127 IAT SENSOR	179
Removal and Installation	135	Component Description	179
DTC P0101 MAF SENSOR	136	On Board Diagnosis Logic	179
Component Description	136	DTC Confirmation Procedure	180
CONSULT-II Reference Value in Data Monitor Mode	136	Wiring Diagram	181
On Board Diagnosis Logic	136	Diagnostic Procedure	182
DTC Confirmation Procedure	137	Component Inspection	183
Overall Function Check	138	DTC P0128 THERMOSTAT FUNCTION	184
Wiring Diagram	139	On Board Diagnosis Logic	184
Diagnostic Procedure	140	DTC Confirmation Procedure	184
DTC P0102, P0103 MAF SENSOR	143	Diagnostic Procedure	185
Component Description	143	DTC P0132 HO2S1	186
CONSULT-II Reference Value in Data Monitor Mode	143	Component Description	186
On Board Diagnosis Logic	143	CONSULT-II Reference Value in Data Monitor Mode	186
DTC Confirmation Procedure	144	On Board Diagnosis Logic	186
Wiring Diagram	145	DTC Confirmation Procedure	187
Diagnostic Procedure	146	Wiring Diagram	188
DTC P0112, P0113 IAT SENSOR	149	Diagnostic Procedure	189
Component Description	149	Component Inspection	190
On Board Diagnosis Logic	149	Removal and Installation	191
DTC Confirmation Procedure	150	DTC P0133 HO2S1	192
Wiring Diagram	151	Component Description	192
Diagnostic Procedure	152	CONSULT-II Reference Value in Data Monitor Mode	192
DTC P0117, P0118 ECT SENSOR	154	On Board Diagnosis Logic	192
Component Description	154	DTC Confirmation Procedure	193
CONSULT-II Reference Value in Data Monitor Mode	154	Overall Function Check	194
On Board Diagnosis Logic	154	Wiring Diagram	195
DTC Confirmation Procedure	155	Diagnostic Procedure	196
Wiring Diagram	156	Component Inspection	199
Diagnostic Procedure	157	Removal and Installation	201
Component Inspection	158	DTC P0134 HO2S1	202
DTC P0121 TP SENSOR	159	Component Description	202
Component Description	159	CONSULT-II Reference Value in Data Monitor Mode	202
CONSULT-II Reference Value in Data Monitor Mode	159	On Board Diagnosis Logic	202
On Board Diagnosis Logic	160	DTC Confirmation Procedure	203
DTC Confirmation Procedure	160	Overall Function Check	203
Wiring Diagram	162	Wiring Diagram	205
Diagnostic Procedure	163	Diagnostic Procedure	206
Component Inspection	166	Component Inspection	207
DTC P0122, P0123 TP SENSOR	168	Removal and Installation	208
Component Description	168	DTC P0138 HO2S2	209
CONSULT-II Reference Value in Data Monitor Mode	168	Component Description	209
On Board Diagnosis Logic	168	CONSULT-II Reference Value in Data Monitor Mode	209
DTC Confirmation Procedure	169	On Board Diagnosis Logic	209
Wiring Diagram	170	DTC Confirmation Procedure	210
Diagnostic Procedure	171	Wiring Diagram	211
Component Inspection	172	Diagnostic Procedure	212
DTC P0125 ECT SENSOR	174	Component Inspection	213
Component Description	174	Removal and Installation	215
On Board Diagnosis Logic	174	DTC P0139 HO2S2	216
DTC Confirmation Procedure	175	Component Description	216
Wiring Diagram	176	CONSULT-II Reference Value in Data Monitor Mode	216
Diagnostic Procedure	177	On Board Diagnosis Logic	216
Component Inspection	178	DTC Confirmation Procedure	217

Overall Function Check	217	Wiring Diagram	264	
Wiring Diagram	219	Diagnostic Procedure	265	A
Diagnostic Procedure	220	Component Inspection	267	
Component Inspection	222	DTC P0340 CMP SENSOR	268	
Removal and Installation	224	Component Description	268	EC
DTC P0171 FUEL INJECTION SYSTEM FUNCTION 225		On Board Diagnosis Logic	268	
On Board Diagnosis Logic	225	DTC Confirmation Procedure	269	
DTC Confirmation Procedure	225	Wiring Diagram	270	C
Wiring Diagram	227	Diagnostic Procedure	272	
Diagnostic Procedure	228	Component Inspection	273	
Component Inspection	231	Removal and Installation	274	
DTC P0172 FUEL INJECTION SYSTEM FUNCTION 232		DTC P0400 EGR FUNCTION	275	D
On Board Diagnosis Logic	232	Description	275	
DTC Confirmation Procedure	232	On Board Diagnosis Logic	276	
Wiring Diagram	234	DTC Confirmation Procedure	276	E
Diagnostic Procedure	235	Overall Function Check	277	
Component Inspection	237	Wiring Diagram	279	
DTC P0181 FTT SENSOR	238	Diagnostic Procedure	280	F
Component Description	238	Component Inspection	283	
On Board Diagnosis Logic	238	Removal and Installation	284	
DTC Confirmation Procedure	238	DTC P0402 EGRC-BPT VALVE FUNCTION	285	G
Wiring Diagram	240	Description	285	
Diagnostic Procedure	241	On Board Diagnosis Logic	285	
Component Inspection	242	DTC Confirmation Procedure	286	
Removal and Installation	242	Overall Function Check	287	H
DTC P0182, P0183 FTT SENSOR	243	Diagnostic Procedure	288	
Component Description	243	Component Inspection	289	
On Board Diagnosis Logic	243	DTC P0405, P0406 EGRT SENSOR	291	I
DTC Confirmation Procedure	243	Component Description	291	
Wiring Diagram	244	On Board Diagnosis Logic	291	
Diagnostic Procedure	245	DTC Confirmation Procedure	292	J
Component inspection	246	Overall Function Check	293	
Removal and Installation	246	Wiring Diagram	294	
DTC P0217 COOLANT OVERTEMPERATURE		Diagnostic Procedure	295	
ENRICHMENT PROTECTION	247	Component Inspection	296	K
On Board Diagnosis Logic	247	Removal and Installation	296	
Overall Function Check	247	DTC P0420 THREE WAY CATALYST FUNCTION. 297		L
Diagnostic Procedure	248	On Board Diagnosis Logic	297	
Main 11 Causes of Overheating	249	DTC Confirmation Procedure	297	
Component Inspection	250	Overall Function Check	298	
DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE,		Diagnostic Procedure	299	
MULTIPLE CYLINDER MISFIRE	251	DTC P0441 EVAP CONTROL SYSTEM	302	M
On Board Diagnosis Logic	251	System Description	302	
DTC Confirmation Procedure	252	On Board Diagnosis Logic	302	
Diagnostic Procedure	252	DTC Confirmation Procedure	303	
Component Inspection	257	Overall Function Check	303	
Removal and Installation	258	Diagnostic Procedure	304	
DTC P0327, P0328 KS	259	DTC P0442 EVAP CONTROL SYSTEM	311	
Component Description	259	On Board Diagnosis Logic	311	
On Board Diagnosis Logic	259	DTC Confirmation Procedure	312	
DTC Confirmation Procedure	259	Diagnostic Procedure	314	
Wiring Diagram	260	DTC P0444, P0445 EVAP CANISTER PURGE VOL-		
Diagnostic Procedure	261	UME CONTROL SOLENOID VALVE	325	
Component Inspection	262	Description	325	
Removal and Installation	262	CONSULT-II Reference Value in Data Monitor Mode		
DTC P0335 CKP SENSOR (OBD)	263		325	
Component Description	263	On Board Diagnosis Logic	326	
On Board Diagnosis Logic	263	DTC Confirmation Procedure	326	
DTC Confirmation Procedure	263			

Wiring Diagram	327	DTC Confirmation Procedure	388
Diagnostic Procedure	329	Overall Function Check	389
DTC P0447 EVAP CANISTER VENT CONTROL		Wiring Diagram	390
VALVE	331	Diagnostic Procedure	391
Component Description	331	DTC P0505 ISC SYSTEM	393
CONSULT-II Reference Value in Data Monitor Mode		Description	393
. 331		CONSULT-II Reference Value in Data Monitor Mode	
On Board Diagnosis Logic	331	. 393	
DTC Confirmation Procedure	331	On Board Diagnosis Logic	394
Wiring Diagram	332	DTC Confirmation Procedure	394
Diagnostic Procedure	333	Wiring Diagram	395
DTC P0452 EVAP CONTROL SYSTEM PRESSURE		Diagnostic Procedure	396
SENSOR	337	DTC P0506 ISC SYSTEM	398
Component Description	337	Description	398
CONSULT-II Reference Value in Data Monitor Mode		CONSULT-II Reference Value in Data Monitor Mode	
. 337		. 398	
On Board Diagnosis Logic	337	On Board Diagnosis Logic	398
DTC Confirmation Procedure	338	DTC Confirmation Procedure	399
Wiring Diagram	339	Wiring Diagram	400
Diagnostic Procedure	340	Diagnostic Procedure	401
DTC P0453 EVAP CONTROL SYSTEM PRESSURE		DTC P0507 ISC SYSTEM	403
SENSOR	344	Description	403
Component Description	344	CONSULT-II Reference Value in Data Monitor Mode	
CONSULT-II Reference Value in Data Monitor Mode		. 403	
. 344		On Board Diagnosis Logic	403
On Board Diagnosis Logic	344	DTC Confirmation Procedure	404
DTC Confirmation Procedure	345	Wiring Diagram	405
Wiring Diagram	346	Diagnostic Procedure	406
Diagnostic Procedure	347	DTC P0510 CTP SWITCH	408
DTC P0455 EVAP CONTROL SYSTEM	354	Component Description	408
On Board Diagnosis Logic	354	On Board Diagnosis Logic	408
DTC Confirmation Procedure	355	DTC Confirmation Procedure	408
Diagnostic Procedure	356	Overall Function Check	409
DTC P0456 EVAP CONTROL SYSTEM	366	Wiring Diagram	410
On Board Diagnosis Logic	366	Diagnostic Procedure	411
DTC Confirmation Procedure	367	DTC P0605 ECM	415
Overall Function Check	368	Component Description	415
Diagnostic Procedure	369	On Board Diagnosis Logic	415
DTC P0460 FUEL LEVEL SENSOR	378	DTC Confirmation Procedure	415
Component Description	378	Diagnostic Procedure	416
On Board Diagnostic Logic	378	DTC P1143 HO2S1	417
DTC Confirmation Procedure	378	Component Description	417
Wiring Diagram	379	CONSULT-II Reference Value in Data Monitor Mode	
Diagnostic Procedure	380	. 417	
Removal and Installation	381	On Board Diagnosis Logic	417
DTC P0461 FUEL LEVEL SENSOR	382	DTC Confirmation Procedure	418
Component Description	382	Overall Function Check	418
On Board Diagnostic Logic	382	Diagnostic Procedure	419
Overall Function Check	382	Removal and Installation	421
DTC P0462, P0463 FUEL LEVEL SENSOR	384	DTC P1144 HO2S1	422
Component Description	384	Component Description	422
On Board Diagnostic Logic	384	CONSULT-II Reference Value in Data Monitor Mode	
DTC Confirmation Procedure	384	. 422	
Wiring Diagram	385	On Board Diagnosis Logic	422
Diagnostic Procedure	386	DTC Confirmation Procedure	423
Removal and Installation	387	Overall Function Check	423
DTC P0500 VSS	388	Diagnostic Procedure	424
Component Description	388	Removal and Installation	426
On Board Diagnosis Logic	388		

DTC P1146 HO2S2	427	469	
Component Description	427	470	A
CONSULT-II Reference Value in Data Monitor Mode		470	
On Board Diagnosis Logic	427	472	
DTC Confirmation Procedure	428	474	
Overall Function Check	428		
Wiring Diagram	430		
Diagnostic Procedure	431		
Removal and Installation	433		
DTC P1147 HO2S2	434		
Component Description	434		
CONSULT-II Reference Value in Data Monitor Mode		479	
On Board Diagnosis Logic	434	479	
DTC Confirmation Procedure	435	479	D
Overall Function Check	435	480	
Wiring Diagram	437		
Diagnostic Procedure	438		
Removal and Installation	440		
DTC P1148 CLOSED LOOP CONTROL	441		
On Board Diagnosis Logic	441		
DTC Confirmation Procedure	441		
Overall Function Check	441		
Diagnostic Procedure	442		
DTC P1217 ENGINE OVER TEMPERATURE	443		
On Board Diagnosis Logic	443		
Overall Function Check	443		
Diagnostic Procedure	444		
Main 11 Causes of Overheating	445		
DTC P1336 CKP SENSOR (OBD)	447		
Component Description	447		
On Board Diagnosis Logic	447		
DTC Confirmation Procedure	447		
Wiring Diagram	448		
Diagnostic Procedure	449		
DTC P1400 EGRC-SOLENOID VALVE	452		
Component Description	452		
CONSULT-II Reference Value in Data Monitor Mode		504	
On Board Diagnosis Logic	452	504	L
DTC Confirmation Procedure	452	505	
Overall Function Check	453	506	
Wiring Diagram	454	507	M
Diagnostic Procedure	455		
DTC P1402 EGR FUNCTION	458		
Description	458		
On Board Diagnosis Logic	459		
DTC Confirmation Procedure	459		
Wiring Diagram	462		
Diagnostic Procedure	463		
DTC P1442 EVAP CONTROL SYSTEM	467		
On Board Diagnosis Logic	467		
DTC Confirmation Procedure	468		
Diagnostic Procedure	468		
DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE	469		
Description	469		
CONSULT-II Reference Value in Data Monitor Mode		520	
On Board Diagnosis Logic	469	520	
DTC Confirmation Procedure	469	521	
Overall Function Check	468	521	
DTC P1146 HO2S2		469	
On Board Diagnosis Logic		470	
DTC Confirmation Procedure		470	
Wiring Diagram		472	
Diagnostic Procedure		474	
DTC P1446 EVAP CANISTER VENT CONTROL VALVE	479		
Component Description	479		
CONSULT-II Reference Value in Data Monitor Mode		479	C
On Board Diagnosis Logic	479	479	
DTC Confirmation Procedure	479	479	D
Diagnostic Procedure	480	480	
DTC P1448 EVAP CANISTER VENT CONTROL VALVE	483		
Component Description	483		
CONSULT-II Reference Value in Data Monitor Mode		483	
On Board Diagnosis Logic	483	483	F
DTC Confirmation Procedure	484	484	
Overall Function Check	485	485	
Diagnostic Procedure	485	485	G
DTC P1456 EVAP CONTROL SYSTEM	489		
On Board Diagnosis Logic	489		
DTC Confirmation Procedure	490		
Overall Function Check	491		
Diagnostic Procedure	492		
DTC P1464 FUEL LEVEL SENSOR	501		
Component Description	501		
On Board Diagnostic Logic	501		
DTC Confirmation Procedure	501		
Wiring Diagram	502		
Diagnostic Procedure	503		
Removal and Installation	503		
DTC P1490 VACUUM CUT VALVE BYPASS VALVE	504		
Description	504		
CONSULT-II Reference Value in Data Monitor Mode		504	
On Board Diagnosis Logic	504	504	L
DTC Confirmation Procedure	505	505	
Wiring Diagram	506	506	
Diagnostic Procedure	507	507	M
DTC P1491 VACUUM CUT VALVE BYPASS VALVE	510		
Description	510		
CONSULT-II Reference Value in Data Monitor Mode		510	
On Board Diagnosis Logic	511	511	
DTC Confirmation Procedure	511	511	
Overall Function Check	512	512	
Wiring Diagram	513	513	
Diagnostic Procedure	514	514	
DTC P1706 PNP SWITCH	520		
Component Description	520		
CONSULT-II Reference Value in Data Monitor Mode		520	
On Board Diagnosis Logic	520	520	
DTC Confirmation Procedure	521	521	
Overall Function Check	521	521	

Wiring Diagram	522	IACV-AAC Valve	574
Diagnostic Procedure For M/T Models	523	Injector	574
IGNITION SIGNAL	525	Resistor	575
Component Description	525	Throttle Position Sensor	575
CONSULT-II Reference Value in Data Monitor Mode	525	Heated Oxygen Sensor 1 Heater	575
Wiring Diagram	526	Calculated Load Value	575
Diagnostic Procedure	527	Intake Air Temperature Sensor	575
Removal and Installation	531	Heated Oxygen Sensor 2 Heater	575
INJECTOR CIRCUIT	532	Crankshaft Position Sensor (OBD)	575
Component Description	532	Fuel Tank Temperature Sensor	575
CONSULT-II Reference Value in Data Monitor Mode	532		
Wiring Diagram	533		
Diagnostic Procedure	534		
Removal and Installation	536		
START SIGNAL	537		
CONSULT-II Reference Value in Data Monitor Mode	537		
Wiring Diagram	538		
Diagnostic Procedure	539		
FUEL PUMP CIRCUIT	541		
Description	541		
CONSULT-II Reference Value in Data Monitor Mode	541		
Wiring Diagram	542		
Diagnostic Procedure	543		
Removal and Installation	545		
POWER STEERING OIL PRESSURE SWITCH	546		
Component Description	546		
CONSULT-II Reference Value in Data Monitor Mode	546		
Wiring Diagram	547		
Diagnostic Procedure	548		
IACV-FICD SOLENOID VALVE	550		
Component Description	550		
Wiring Diagram	551		
Diagnostic Procedure	552		
DATA LINK CONNECTOR	555		
Wiring Diagram	555		
EVAPORATIVE EMISSION SYSTEM	556		
Description	556		
Component Inspection	559		
How To Detect Fuel Vapor Leakage	560		
ON BOARD REFUELING VAPOR RECOVERY (ORVR)	562		
System Description	562		
Diagnostic Procedure	563		
POSITIVE CRANKCASE VENTILATION	572		
Description	572		
Inspection	572		
SERVICE DATA AND SPECIFICATIONS (SDS)	574		
Fuel Pressure Regulator	574		
Idle Speed and Ignition Timing	574		
Ignition Coil	574		
Mass Air Flow Sensor	574		
Engine Coolant Temperature Sensor	574		
EGR Temperature Sensor	574		
Fuel Pump	574		

VG33E	
INDEX FOR DTC	576
Alphabetical Index	576
DTC No. Index	579
PRECAUTIONS	582
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	582
On Board Diagnostic (OBD) System of Engine and A/T	582
Precautions	583
Wiring Diagrams and Trouble Diagnosis	586
PREPARATION	587
Special Service Tools	587
Commercial Service Tools	587
ENGINE CONTROL SYSTEM	589
System Diagram	589
Vacuum Hose Drawing	590
System Chart	591
Multiport Fuel Injection (MFI) System	591
Distributor Ignition (DI) System	593
Air Conditioner Cut Control	594
Fuel Cut Control (at No Load and High Engine Load)	594
BASIC SERVICE PROCEDURE	596
Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment	596
Fast Idle Cam (FIC) Inspection and Adjustment	606
Fuel Pressure Check	608
Fuel Pressure Regulator Check	609
ON BOARD DIAGNOSTIC (OBD) SYSTEM	610
Introduction	610
Two Trip Detection Logic	610
Emission-related Diagnostic Information	611
Malfunction Indicator Lamp (MIL)	625
OBD System Operation Chart	625
TROUBLE DIAGNOSIS	631
Trouble Diagnosis Introduction	631
DTC Inspection Priority Chart	636
Fail-safe Chart	637
Basic Inspection	637
Symptom Matrix Chart	650
Engine Control Component Parts Location	654
Circuit Diagram	657
ECM Harness Connector Terminal Layout	658
ECM Terminals and Reference Value	658
CONSULT-II Function	666
Generic Scan Tool (GST) Function	677

CONSULT-II Reference Value in Data Monitor Mode	Wiring Diagram	727	
Major Sensor Reference Graph in Data Monitor Mode	Diagnostic Procedure	728	A
TROUBLE DIAGNOSIS - SPECIFICATION VALUE 684	Component Inspection	729	
Description	DTC P0117, P0118 ECT SENSOR 730		EC
Testing Condition	Component Description	730	
Inspection Procedure	On Board Diagnosis Logic	730	
Diagnostic Procedure	DTC Confirmation Procedure	731	
TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT 688	Wiring Diagram	732	C
Description	Diagnostic Procedure	733	
Diagnostic Procedure	Component Inspection	734	
POWER SUPPLY CIRCUIT FOR ECM 689	Removal and Installation	734	
Wiring Diagram	DTC P0121 TP SENSOR 735		D
Diagnostic Procedure	Component Description	735	
DTC P0031, P0032, P0051, P0052 HO2S1 HEATER 695	CONSULT-II Reference Value in Data Monitor Mode		
Description		735	E
CONSULT-II Reference Value in Data Monitor Mode	On Board Diagnosis Logic	736	
On Board Diagnosis Logic	DTC Confirmation Procedure	736	
DTC Confirmation Procedure	Wiring Diagram	738	F
Wiring Diagram	Diagnostic Procedure	739	
Diagnostic Procedure	Component Inspection	743	
Component Inspection	DTC P0122, P0123 TP SENSOR 744		G
Removal and Installation	Component Description	744	
DTC P0037, P0038, P0057, P0058 HO2S2 HEATER 703	CONSULT-II Reference Value in Data Monitor Mode		
Description		744	H
CONSULT-II Reference Value in Data Monitor Mode	On Board Diagnosis Logic	744	
On Board Diagnosis Logic	DTC Confirmation Procedure	745	
DTC Confirmation Procedure	Wiring Diagram	746	
Wiring Diagram	Diagnostic Procedure	747	I
Diagnostic Procedure	DTC P0125 ECT SENSOR 751		
Component Inspection	Component Description	751	
Removal and Installation	On Board Diagnosis Logic	751	J
DTC P0101 MAF SENSOR 712	DTC Confirmation Procedure	751	
Component Description	Diagnostic Procedure	752	
CONSULT-II Reference Value in Data Monitor Mode	Component Inspection	752	
On Board Diagnosis Logic	Removal and Installation	753	K
DTC Confirmation Procedure	DTC P0127 IAT SENSOR 754		
Overall Function Check	Component Description	754	
Wiring Diagram	On Board Diagnosis Logic	754	L
Diagnostic Procedure	DTC Confirmation Procedure	754	
Component Inspection	Diagnostic Procedure	755	
DTC P0102, P0103 MAF SENSOR 719	Component Inspection	755	
Component Description	DTC P0128 THERMOSTAT FUNCTION 756		M
CONSULT-II Reference Value in Data Monitor Mode	On Board Diagnosis Logic	756	
On Board Diagnosis Logic	DTC Confirmation Procedure	756	
DTC Confirmation Procedure	Diagnostic Procedure	756	
Wiring Diagram	Component Inspection	757	
Diagnostic Procedure	Removal and Installation	757	
Component Inspection	DTC P0132, P0152 HO2S1 758		
DTC P0112, P0113 IAT SENSOR 725	Component Description	758	
Component Description	CONSULT-II Reference Value in Data Monitor Mode		
On Board Diagnosis Logic		758	
DTC Confirmation Procedure	On Board Diagnosis Logic	758	
Wiring Diagram	DTC Confirmation Procedure	759	
Diagnostic Procedure	Wiring Diagram	760	
Component Inspection	Diagnostic Procedure	763	
DTC P0112, P0113 IAT SENSOR 725	Component Inspection	766	
Component Description	Removal and Installation	766	
On Board Diagnosis Logic	DTC P0133, P0153 HO2S1 767		
DTC Confirmation Procedure	Component Description	767	
	CONSULT-II Reference Value in Data Monitor Mode		
		767	

	.767	Wiring Diagram	832
On Board Diagnosis Logic	767	Diagnostic Procedure	833
DTC Confirmation Procedure	768	Removal and Installation	834
Overall Function Check	769		
Wiring Diagram	770	DTC P0217 COOLANT OVERTEMPERATURE	
Diagnostic Procedure	773	ENRICHMENT PROTECTION	835
Removal and Installation	779	On Board Diagnosis Logic	835
DTC P0134, P0154 HO2S1	780	Overall Function Check	835
Component Description	780	Diagnostic Procedure	837
CONSULT-II Reference Value in Data Monitor Mode	780	Main 12 Causes of Overheating	839
On Board Diagnosis Logic	780		
DTC Confirmation Procedure	781	DTC P0300 - P0306 MULTIPLE CYLINDER MIS-	
Overall Function Check	781	FIRE, NO. 1 - 6 CYLINDER MISFIRE	840
Wiring Diagram	783	On Board Diagnosis Logic	840
Diagnostic Procedure	787	DTC Confirmation Procedure	840
Removal and Installation	790	Diagnostic Procedure	841
DTC P0138, P0158 HO2S2	791	DTC P0327, P0328 KS	849
Component Description	791	Component Description	849
CONSULT-II Reference Value in Data Monitor Mode	791	On Board Diagnosis Logic	849
On Board Diagnosis Logic	791	DTC Confirmation Procedure	849
DTC Confirmation Procedure	791	Wiring Diagram	850
Wiring Diagram	793	Diagnostic Procedure	851
Diagnostic Procedure	796	DTC P0335 CKP SENSOR (OBD)	853
Removal and Installation	799	Component Description	853
DTC P0139, P0159 HO2S2	800	CONSULT-II Reference Value in Data Monitor Mode	853
Component Description	800	On Board Diagnosis Logic	853
CONSULT-II Reference Value in Data Monitor Mode	800	DTC Confirmation Procedure	853
On Board Diagnosis Logic	800	Wiring Diagram	855
DTC Confirmation Procedure	800	Diagnostic Procedure	856
Overall Function Check	801	DTC P0340 CMP SENSOR	859
Wiring Diagram	802	Component Description	859
Diagnostic Procedure	805	On Board Diagnosis Logic	859
Removal and Installation	809	DTC Confirmation Procedure	859
DTC P0171, P0174 FUEL INJECTION SYSTEM		Wiring Diagram	861
FUNCTION	810	Diagnostic Procedure	863
On Board Diagnosis Logic	810	Removal and Installation	865
DTC Confirmation Procedure	810	DTC P0400 EGR FUNCTION	866
Wiring Diagram	812	Description	866
Diagnostic Procedure	814	On Board Diagnosis Logic	867
DTC P0172, P0175 FUEL INJECTION SYSTEM		DTC Confirmation Procedure	867
FUNCTION	818	Overall Function Check	868
On Board Diagnosis Logic	818	Wiring Diagram	870
DTC Confirmation Procedure	818	Diagnostic Procedure	871
Wiring Diagram	820	Component Inspection	874
Diagnostic Procedure	822	Removal and Installation	874
DTC P0181 FTT SENSOR	826	DTC P0402 EGRC-BPT VALVE FUNCTION	875
Component Description	826	Description	875
On Board Diagnosis Logic	826	On Board Diagnosis Logic	875
DTC Confirmation Procedure	826	DTC Confirmation Procedure	875
Wiring Diagram	828	Overall Function Check	877
Diagnostic Procedure	829	Diagnostic Procedure	878
Removal and Installation	830	Component Inspection	880
DTC P0182, P0183 FTT SENSOR	831	DTC P0405, P0406 EGRT SENSOR	881
Component Description	831	Component Description	881
On Board Diagnosis Logic	831	On Board Diagnosis Logic	881
DTC Confirmation Procedure	831	DTC Confirmation Procedure	881
		Overall Function Check	882
		Wiring Diagram	884
		Diagnostic Procedure	885

Component Inspection	886	DTC P0456 EVAP CONTROL SYSTEM	950	
Removal and Installation	886	On Board Diagnosis Logic	950	A
DTC P0420, P0430 THREE WAY CATALYST FUNCTION	887	DTC Confirmation Procedure	951	
On Board Diagnosis Logic	887	Overall Function Check	952	
DTC Confirmation Procedure	887	Diagnostic Procedure	953	EC
Overall Function Check	888	DTC P0460 FUEL LEVEL SENSOR	961	
Diagnostic Procedure	890	Component Description	961	
DTC P0441 EVAP CONTROL SYSTEM	893	On Board Diagnosis Logic	961	C
System Description	893	DTC Confirmation Procedure	961	
On Board Diagnosis Logic	893	Wiring Diagram	962	
DTC Confirmation Procedure	893	Diagnostic Procedure	963	
Overall Function Check	894	Removal and Installation	964	D
Diagnostic Procedure	895	DTC P0461 FUEL LEVEL SENSOR	965	
DTC P0442 EVAP CONTROL SYSTEM	901	Component Description	965	
On Board Diagnosis Logic	901	On Board Diagnosis Logic	965	E
DTC Confirmation Procedure	902	Overall Function Check	965	
Diagnostic Procedure	904	DTC P0462, P0463 FUEL LEVEL SENSOR	967	
DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE	913	Component Description	967	F
Description	913	On Board Diagnosis Logic	967	
CONSULT-II Reference Value in Data Monitor Mode	913	DTC Confirmation Procedure	967	
On Board Diagnosis Logic	914	Wiring Diagram	968	G
DTC Confirmation Procedure	914	Diagnostic Procedure	969	
Wiring Diagram	915	Removal and Installation	970	
Diagnostic Procedure	917	DTC P0500 VSS	971	
DTC P0447 EVAP CANISTER VENT CONTROL VALVE	920	Component Description	971	H
Component Description	920	On Board Diagnosis Logic	971	
CONSULT-II Reference Value in Data Monitor Mode	920	DTC Confirmation Procedure	971	
On Board Diagnosis Logic	920	Overall Function Check	972	I
DTC Confirmation Procedure	920	Wiring Diagram	973	
Wiring Diagram	922	Diagnostic Procedure	974	
Diagnostic Procedure	923	DTC P0505 ISC SYSTEM	976	J
DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR	926	Description	976	
Component Description	926	CONSULT-II Reference Value in Data Monitor Mode	976	
CONSULT-II Reference Value in Data Monitor Mode	926	On Board Diagnosis Logic	977	K
On Board Diagnosis Logic	926	DTC Confirmation Procedure	977	
DTC Confirmation Procedure	926	Wiring Diagram	979	
Wiring Diagram	928	Diagnostic Procedure	980	L
Diagnostic Procedure	929	Removal and Installation	982	
DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR	932	DTC P0510 CLOSED TP SWITCH	983	
Component Description	932	Component Description	983	M
CONSULT-II Reference Value in Data Monitor Mode	932	CONSULT-II Reference Value in Data Monitor Mode	983	
On Board Diagnosis Logic	932	On Board Diagnosis Logic	983	
DTC Confirmation Procedure	932	DTC Confirmation Procedure	983	
Wiring Diagram	934	Overall Function Check	984	
Diagnostic Procedure	935	Wiring Diagram	985	
DTC P0455 EVAP CONTROL SYSTEM	941	Diagnostic Procedure	986	
On Board Diagnosis Logic	941	DTC P0600 A/T COMMUNICATION LINE	990	
DTC Confirmation Procedure	942	System Description	990	
Diagnostic Procedure	943	On Board Diagnosis Logic	990	
		DTC Confirmation Procedure	990	
		Wiring Diagram	991	
		Diagnostic Procedure	994	
		DTC P0605 ECM	996	
		Component Description	996	
		On Board Diagnosis Logic	996	
		DTC Confirmation Procedure	996	
		Diagnostic Procedure	997	

DTC P1143, P1163 HO2S1	998	On Board Diagnosis Logic	1045
Component Description	998	DTC Confirmation Procedure	1045
CONSULT-II Reference Value in Data Monitor Mode	998	Overall Function Check	1045
On Board Diagnosis Logic	998	Wiring Diagram	1047
DTC Confirmation Procedure	999	Diagnostic Procedure	1048
Overall Function Check	1000	DTC P1402 EGR FUNCTION	1051
Diagnostic Procedure	1000	Description	1051
Removal and Installation	1004	On Board Diagnosis Logic	1052
DTC P1144, P1164 HO2S1	1005	DTC Confirmation Procedure	1052
Component Description	1005	Wiring Diagram	1055
CONSULT-II Reference Value in Data Monitor Mode	1005	Diagnostic Procedure	1056
On Board Diagnosis Logic	1005	Component Inspection	1058
DTC Confirmation Procedure	1006	DTC P1442 EVAP CONTROL SYSTEM	1059
Overall Function Check	1006	On Board Diagnosis Logic	1059
Diagnostic Procedure	1007	DTC Confirmation Procedure	1060
Removal and Installation	1011	Diagnostic Procedure	1060
DTC P1146, P1166 HO2S2	1012	DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE	1061
Component Description	1012	Description	1061
CONSULT-II Reference Value in Data Monitor Mode	1012	CONSULT-II Reference Value in Data Monitor Mode	1061
On Board Diagnosis Logic	1012	On Board Diagnosis Logic	1062
DTC Confirmation Procedure	1012	DTC Confirmation Procedure	1062
Overall Function Check	1014	Wiring Diagram	1063
Wiring Diagram	1015	Diagnostic Procedure	1065
Diagnostic Procedure	1018	DTC P1446 EVAP CANISTER VENT CONTROL VALVE	1070
Removal and Installation	1022	Component Description	1070
DTC P1147, P1167 HO2S2	1023	CONSULT-II Reference Value in Data Monitor Mode	1070
Component Description	1023	On Board Diagnosis Logic	1070
CONSULT-II Reference Value in Data Monitor Mode	1023	DTC Confirmation Procedure	1070
On Board Diagnosis Logic	1023	Wiring Diagram	1072
DTC Confirmation Procedure	1023	Diagnostic Procedure	1073
Overall Function Check	1025	DTC P1448 EVAP CANISTER VENT CONTROL VALVE	1076
Wiring Diagram	1026	Component Description	1076
Diagnostic Procedure	1029	CONSULT-II Reference Value in Data Monitor Mode	1076
Removal and Installation	1033	On Board Diagnosis Logic	1076
DTC P1148, P1168 CLOSED LOOP CONTROL	1034	DTC Confirmation Procedure	1076
On Board Diagnosis Logic	1034	Overall Function Check	1077
DTC Confirmation Procedure	1034	Wiring Diagram	1079
Overall Function Check	1034	Diagnostic Procedure	1080
Diagnostic Procedure	1035	DTC P1456 EVAP CONTROL SYSTEM	1084
DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)	1036	On Board Diagnosis Logic	1084
On Board Diagnosis Logic	1036	DTC Confirmation Procedure	1085
Overall Function Check	1036	Overall Function Check	1086
Diagnostic Procedure	1037	Diagnostic Procedure	1086
Main 12 Causes of Overheating	1038	DTC P1464 FUEL LEVEL SENSOR	1094
DTC P1336 CKP SENSOR (OBD)	1040	Component Description	1094
Component Description	1040	On Board Diagnosis Logic	1094
On Board Diagnosis Logic	1040	DTC Confirmation Procedure	1094
DTC Confirmation Procedure	1040	Wiring Diagram	1095
Wiring Diagram	1041	Diagnostic Procedure	1096
Diagnostic Procedure	1042	Removal and Installation	1096
DTC P1400 EGRC-SOLENOID VALVE	1045	DTC P1490 VACUUM CUT VALVE BYPASS VALVE	1097
Component Description	1045	Description	1097
CONSULT-II Reference Value in Data Monitor Mode	1045	CONSULT-II Reference Value in Data Monitor Mode	1097

Air Conditioner Cut Control	1194	Wiring Diagram	1304
Fuel Cut Control (at No Load and High Engine Load)	1194	Diagnostic Procedure	1305
BASIC SERVICE PROCEDURE	1196	Component Inspection	1306
Idle Speed/Ignition Timing/Idle Mixture Ratio		DTC P0037, P0038, P0057, P0058 HO2S2 HEATER	1308
Adjustment	1196	Description	1308
Fast Idle Cam (FIC) Inspection and Adjustment	1206	CONSULT-II Reference Value in Data Monitor Mode	1308
Fuel Pressure Check	1207	On Board Diagnosis Logic	1308
Fuel Pressure Regulator Check	1209	DTC Confirmation Procedure	1308
ON BOARD DIAGNOSTIC (OBD) SYSTEM	1210	Wiring Diagram	1310
Introduction	1210	Diagnostic Procedure	1314
Two Trip Detection Logic	1210	Component Inspection	1315
Emission-related Diagnostic Information	1211	Removal and Installation	1316
Malfunction Indicator Lamp (MIL)	1225	DTC P0101 MAF SENSOR	1317
OBD System Operation Chart	1225	Component Description	1317
TROUBLE DIAGNOSIS	1231	CONSULT-II Reference Value in Data Monitor Mode	1317
Trouble Diagnosis Introduction	1231	On Board Diagnosis Logic	1317
DTC Inspection Priority Chart	1236	DTC Confirmation Procedure	1317
Fail-safe Chart	1237	Overall Function Check	1319
Basic Inspection	1237	Wiring Diagram	1320
Symptom Matrix Chart	1250	Diagnostic Procedure	1321
Engine Control Component Parts Location	1254	Component Inspection	1323
Circuit Diagram	1257	DTC P0102, P0103 MAF SENSOR	1324
ECM Harness Connector Terminal Layout	1258	Component Description	1324
ECM Terminals and Reference Value	1258	CONSULT-II Reference Value in Data Monitor Mode	1324
CONSULT-II Function	1266	On Board Diagnosis Logic	1324
Generic Scan Tool (GST) Function	1276	DTC Confirmation Procedure	1324
CONSULT-II Reference Value in Data Monitor Mode	1278	Wiring Diagram	1326
Major Sensor Reference Graph in Data Monitor		Diagnostic Procedure	1327
Mode	1280	DTC P0112, P0113 IAT SENSOR	1330
TROUBLE DIAGNOSIS - SPECIFICATION VALUE	283	Component Description	1330
Description	1283	On Board Diagnosis Logic	1330
Testing Condition	1283	DTC Confirmation Procedure	1330
Inspection Procedure	1283	Wiring Diagram	1332
Diagnostic Procedure	1284	Diagnostic Procedure	1333
TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT	1287	Component Inspection	1334
Description	1287	DTC P0117, P0118 ECT SENSOR	1335
Diagnostic Procedure	1287	Component Description	1335
POWER SUPPLY CIRCUIT FOR ECM	1288	On Board Diagnosis Logic	1335
Wiring Diagram	1288	DTC Confirmation Procedure	1336
Diagnostic Procedure	1289	Wiring Diagram	1337
DTC P0031, P0032, P0051, P0052 HO2S1 HEATER	294	Diagnostic Procedure	1338
Description	1294	Component Inspection	1339
CONSULT-II Reference Value in Data Monitor Mode	1294	Removal and Installation	1339
On Board Diagnosis Logic	1294	DTC P0121 TP SENSOR	1340
DTC Confirmation Procedure	1294	Component Description	1340
Wiring Diagram	1296	CONSULT-II Reference Value in Data Monitor Mode	1340
Diagnostic Procedure	1299	On Board Diagnosis Logic	1341
Component Inspection	1300	DTC Confirmation Procedure	1341
Removal and Installation	1301	Wiring Diagram	1343
DTC P0034 SCB VALVE CONTROL SOLENOID VALVE	1302	Diagnostic Procedure	1344
Description	1302	Component Inspection	1348
CONSULT-II Reference Value in Data Monitor Mode	1302	DTC P0122, P0123 TP SENSOR	1349
On Board Diagnosis Logic	1303	Component Description	1349
DTC Confirmation Procedure	1303	CONSULT-II Reference Value in Data Monitor Mode	1349

On Board Diagnosis Logic	1349	Diagnostic Procedure	1401	
DTC Confirmation Procedure	1350	Removal and Installation	1404	A
Wiring Diagram	1351	DTC P0139, P0159 HO2S2	1405	
Diagnostic Procedure	1352	Component Description	1405	
DTC P0125 ECT SENSOR	1356	CONSULT-II Reference Value in Data Monitor Mode	1405	EC
Component Description	1356	On Board Diagnosis Logic	1405	
On Board Diagnosis Logic	1356	DTC Confirmation Procedure	1405	C
DTC Confirmation Procedure	1356	Overall Function Check	1406	
Diagnostic Procedure	1357	Wiring Diagram	1407	
Component Inspection	1357	Diagnostic Procedure	1410	
Removal and Installation	1358	Removal and Installation	1414	D
DTC P0127 IAT SENSOR	1359	DTC P0171, P0174 FUEL INJECTION SYSTEM		
Component Description	1359	FUNCTION	1415	
On Board Diagnosis Logic	1359	On Board Diagnosis Logic	1415	E
DTC Confirmation Procedure	1359	DTC Confirmation Procedure	1415	
Diagnostic Procedure	1360	Wiring Diagram	1417	
Component Inspection	1360	Diagnostic Procedure	1419	F
DTC P0128 THERMOSTAT FUNCTION	1361	DTC P0172, P0175 FUEL INJECTION SYSTEM		
On Board Diagnosis Logic	1361	FUNCTION	1423	
DTC Confirmation Procedure	1361	On Board Diagnosis Logic	1423	G
Diagnostic Procedure	1361	DTC Confirmation Procedure	1423	
Component Inspection	1362	Wiring Diagram	1425	
Removal and Installation	1362	Diagnostic Procedure	1427	
DTC P0132, P0152 HO2S1	1363	DTC P0181 FTT SENSOR	1431	H
Component Description	1363	Component Description	1431	
CONSULT-II Reference Value in Data Monitor Mode	1363	On Board Diagnosis Logic	1431	
On Board Diagnosis Logic	1363	DTC Confirmation Procedure	1431	I
DTC Confirmation Procedure	1364	Wiring Diagram	1433	
Wiring Diagram	1365	Diagnostic Procedure	1434	
Diagnostic Procedure	1368	Removal and Installation	1435	J
Removal and Installation	1371	DTC P0182, P0183 FTT SENSOR	1436	
DTC P0133, P0153 HO2S1	1372	Component Description	1436	
Component Description	1372	On Board Diagnosis Logic	1436	
CONSULT-II Reference Value in Data Monitor Mode	1372	DTC Confirmation Procedure	1436	K
On Board Diagnosis Logic	1372	Wiring Diagram	1437	
DTC Confirmation Procedure	1373	Diagnostic Procedure	1438	
Overall Function Check	1374	Removal and Installation	1439	L
Wiring Diagram	1375	DTC P0217 COOLANT OVERTEMPERATURE		
Diagnostic Procedure	1378	ENRICHMENT PROTECTION	1440	
Removal and Installation	1384	On Board Diagnosis Logic	1440	
DTC P0134, P0154 HO2S1	1385	Overall Function Check	1440	M
Component Description	1385	Diagnostic Procedure	1442	
CONSULT-II Reference Value in Data Monitor Mode	1385	Main 12 Causes of Overheating	1444	
On Board Diagnosis Logic	1385	DTC P0299 SUPERCHARGER FUNCTION	1445	
DTC Confirmation Procedure	1386	On Board Diagnosis Logic	1445	
Overall Function Check	1386	DTC Confirmation Procedure	1445	
Wiring Diagram	1388	Diagnostic Procedure	1446	
Diagnostic Procedure	1392	DTC P0300 - P0306 MULTIPLE CYLINDER MIS-		
Removal and Installation	1395	FIRE, NO. 1 - 6 CYLINDER MISFIRE	1448	
DTC P0138, P0158 HO2S2	1396	On Board Diagnosis Logic	1448	
Component Description	1396	DTC Confirmation Procedure	1448	
CONSULT-II Reference Value in Data Monitor Mode	1396	Diagnostic Procedure	1449	
On Board Diagnosis Logic	1396	DTC P0327, P0328 KS	1457	
DTC Confirmation Procedure	1396	Component Description	1457	
Wiring Diagram	1398	On Board Diagnosis Logic	1457	
		DTC Confirmation Procedure	1457	
		Wiring Diagram	1458	
		Diagnostic Procedure	1459	

DTC P0335 CKP SENSOR (OBD)	1461	SENSOR	1519
Component Description	1461	Component Description	1519
CONSULT-II Reference Value in Data Monitor Mode	1461	CONSULT-II Reference Value in Data Monitor Mode	1519
On Board Diagnosis Logic	1461	On Board Diagnosis Logic	1519
DTC Confirmation Procedure	1461	DTC Confirmation Procedure	1519
Wiring Diagram	1463	Wiring Diagram	1521
Diagnostic Procedure	1464	Diagnostic Procedure	1522
DTC P0340 CMP SENSOR	1467	DTC P0455 EVAP CONTROL SYSTEM	1528
Component Description	1467	On Board Diagnosis Logic	1528
On Board Diagnosis Logic	1467	DTC Confirmation Procedure	1529
DTC Confirmation Procedure	1467	Diagnostic Procedure	1530
Wiring Diagram	1469	DTC P0456 EVAP CONTROL SYSTEM	1538
Diagnostic Procedure	1471	On Board Diagnosis Logic	1538
Removal and Installation	1473	DTC Confirmation Procedure	1539
DTC P0420, P0430 THREE WAY CATALYST FUNCTION	1474	Overall Function Check	1540
On Board Diagnosis Logic	1474	Diagnostic Procedure	1541
DTC Confirmation Procedure	1474	DTC P0460 FUEL LEVEL SENSOR	1549
Overall Function Check	1475	Component Description	1549
Diagnostic Procedure	1477	On Board Diagnosis Logic	1549
DTC P0441 EVAP CONTROL SYSTEM	1480	DTC Confirmation Procedure	1549
System Description	1480	Wiring Diagram	1550
On Board Diagnosis Logic	1480	Diagnostic Procedure	1551
DTC Confirmation Procedure	1480	Removal and Installation	1552
Overall Function Check	1481	DTC P0461 FUEL LEVEL SENSOR	1553
Diagnostic Procedure	1482	Component Description	1553
DTC P0442 EVAP CONTROL SYSTEM	1488	On Board Diagnosis Logic	1553
On Board Diagnosis Logic	1488	Overall Function Check	1553
DTC Confirmation Procedure	1489	DTC P0462, P0463 FUEL LEVEL SENSOR	1555
Diagnostic Procedure	1491	Component Description	1555
DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE	1500	On Board Diagnosis Logic	1555
Description	1500	DTC Confirmation Procedure	1555
CONSULT-II Reference Value in Data Monitor Mode	1500	Wiring Diagram	1556
On Board Diagnosis Logic	1501	Diagnostic Procedure	1557
DTC Confirmation Procedure	1501	Removal and Installation	1558
Wiring Diagram	1502	DTC P0500 VSS	1559
Diagnostic Procedure	1504	Component Description	1559
DTC P0447 EVAP CANISTER VENT CONTROL VALVE	1507	On Board Diagnosis Logic	1559
Component Description	1507	DTC Confirmation Procedure	1559
CONSULT-II Reference Value in Data Monitor Mode	1507	Overall Function Check	1559
On Board Diagnosis Logic	1507	Wiring Diagram	1561
DTC Confirmation Procedure	1507	Diagnostic Procedure	1562
Wiring Diagram	1509	DTC P0505 ISC SYSTEM	1564
Diagnostic Procedure	1510	Description	1564
DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR	1513	CONSULT-II Reference Value in Data Monitor Mode	1564
Component Description	1513	On Board Diagnosis Logic	1565
CONSULT-II Reference Value in Data Monitor Mode	1513	DTC Confirmation Procedure	1565
On Board Diagnosis Logic	1513	Wiring Diagram	1567
DTC Confirmation Procedure	1513	Diagnostic Procedure	1568
Wiring Diagram	1515	Removal and Installation	1570
Diagnostic Procedure	1516	DTC P0510 CLOSED TP SWITCH	1571
DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR	1519	Component Description	1571
Component Description	1519	CONSULT-II Reference Value in Data Monitor Mode	1571
CONSULT-II Reference Value in Data Monitor Mode	1519	On Board Diagnosis Logic	1571
On Board Diagnosis Logic	1519	DTC Confirmation Procedure	1571
DTC Confirmation Procedure	1519	Overall Function Check	1572
Wiring Diagram	1521		
Diagnostic Procedure	1522		
On Board Diagnosis Logic	1528		
DTC Confirmation Procedure	1529		
Diagnostic Procedure	1530		
On Board Diagnosis Logic	1538		
DTC Confirmation Procedure	1539		
Overall Function Check	1540		
Diagnostic Procedure	1541		
Component Description	1549		
On Board Diagnosis Logic	1549		
DTC Confirmation Procedure	1549		
Wiring Diagram	1550		
Diagnostic Procedure	1551		
Removal and Installation	1552		
Component Description	1553		
On Board Diagnosis Logic	1553		
Overall Function Check	1553		
Component Description	1555		
On Board Diagnosis Logic	1555		
DTC Confirmation Procedure	1555		
Wiring Diagram	1556		
Diagnostic Procedure	1557		
Removal and Installation	1558		
Component Description	1559		
On Board Diagnosis Logic	1559		
DTC Confirmation Procedure	1559		
Overall Function Check	1559		
Wiring Diagram	1561		
Diagnostic Procedure	1562		
Description	1564		
CONSULT-II Reference Value in Data Monitor Mode	1564		
On Board Diagnosis Logic	1565		
DTC Confirmation Procedure	1565		
Wiring Diagram	1567		
Diagnostic Procedure	1568		
Removal and Installation	1570		
Component Description	1571		
CONSULT-II Reference Value in Data Monitor Mode	1571		
On Board Diagnosis Logic	1571		
DTC Confirmation Procedure	1571		
Overall Function Check	1572		

Wiring Diagram	1573	Overall Function Check	1624	
Diagnostic Procedure	1574	Diagnostic Procedure	1625	A
DTC P0600 A/T COMMUNICATION LINE	1578	Main 12 Causes of Overheating	1626	
System Description	1578	DTC P1336 CKP SENSOR (OBD)	1628	EC
On Board Diagnosis Logic	1578	Component Description	1628	
DTC Confirmation Procedure	1578	On Board Diagnosis Logic	1628	
Wiring Diagram	1579	DTC Confirmation Procedure	1628	
Diagnostic Procedure	1582	Wiring Diagram	1629	
DTC P0605 ECM	1584	Diagnostic Procedure	1630	C
Component Description	1584	DTC P1442 EVAP CONTROL SYSTEM	1633	
On Board Diagnosis Logic	1584	On Board Diagnosis Logic	1633	
DTC Confirmation Procedure	1584	DTC Confirmation Procedure	1634	D
Diagnostic Procedure	1585	Diagnostic Procedure	1634	
DTC P1143, P1163 HO2S1	1586	DTC P1444 EVAP CANISTER PURGE VOLUME		
Component Description	1586	CONTROL SOLENOID VALVE	1635	E
CONSULT-II Reference Value in Data Monitor Mode	1586	Description	1635	
On Board Diagnosis Logic	1586	CONSULT-II Reference Value in Data Monitor Mode	1635	
DTC Confirmation Procedure	1587	On Board Diagnosis Logic	1636	F
Overall Function Check	1588	DTC Confirmation Procedure	1636	
Diagnostic Procedure	1588	Wiring Diagram	1637	
Removal and Installation	1592	Diagnostic Procedure	1639	G
DTC P1144, P1164 HO2S1	1593	DTC P1446 EVAP CANISTER VENT CONTROL		
Component Description	1593	VALVE	1644	
CONSULT-II Reference Value in Data Monitor Mode	1593	Component Description	1644	H
On Board Diagnosis Logic	1593	CONSULT-II Reference Value in Data Monitor Mode	1644	
DTC Confirmation Procedure	1594	On Board Diagnosis Logic	1644	I
Overall Function Check	1594	DTC Confirmation Procedure	1644	
Diagnostic Procedure	1595	Wiring Diagram	1646	
Removal and Installation	1599	Diagnostic Procedure	1647	J
DTC P1146, P1166 HO2S2	1600	DTC P1448 EVAP CANISTER VENT CONTROL		
Component Description	1600	VALVE	1650	
CONSULT-II Reference Value in Data Monitor Mode	1600	Component Description	1650	K
On Board Diagnosis Logic	1600	CONSULT-II Reference Value in Data Monitor Mode	1650	
DTC Confirmation Procedure	1600	On Board Diagnosis Logic	1650	L
Overall Function Check	1602	DTC Confirmation Procedure	1650	
Wiring Diagram	1603	Overall Function Check	1651	
Diagnostic Procedure	1606	Wiring Diagram	1653	
Removal and Installation	1610	Diagnostic Procedure	1654	M
DTC P1147, P1167 HO2S2	1611	DTC P1456 EVAP CONTROL SYSTEM	1658	
Component Description	1611	On Board Diagnosis Logic	1658	
CONSULT-II Reference Value in Data Monitor Mode	1611	DTC Confirmation Procedure	1659	
On Board Diagnosis Logic	1611	Overall Function Check	1660	
DTC Confirmation Procedure	1611	Diagnostic Procedure	1660	
Overall Function Check	1613	DTC P1464 FUEL LEVEL SENSOR	1668	
Wiring Diagram	1614	Component Description	1668	
Diagnostic Procedure	1617	On Board Diagnosis Logic	1668	
Removal and Installation	1621	DTC Confirmation Procedure	1668	
DTC P1148, P1168 CLOSED LOOP CONTROL	1622	Wiring Diagram	1669	
On Board Diagnosis Logic	1622	Diagnostic Procedure	1670	
DTC Confirmation Procedure	1622	Removal and Installation	1670	
Overall Function Check	1622	DTC P1490 VACUUM CUT VALVE BYPASS VALVE	671	
Diagnostic Procedure	1623	Description	1671	
DTC P1217 ENGINE OVER TEMPERATURE		CONSULT-II Reference Value in Data Monitor Mode	1671	
(OVERHEAT)	1624	On Board Diagnosis Logic	1671	
On Board Diagnosis Logic	1624	DTC Confirmation Procedure	1671	

Wiring Diagram	1673	CONSULT-II Reference Value in Data Monitor Mode	1716
Diagnostic Procedure	1674	Wiring Diagram	1717
DTC P1491 VACUUM CUT VALVE BYPASS VALVE	1677	Diagnostic Procedure	1718
Description	1677	Removal and Installation	1720
CONSULT-II Reference Value in Data Monitor Mode	1677	POWER STEERING OIL PRESSURE SWITCH	1721
On Board Diagnosis Logic	1678	Component Description	1721
DTC Confirmation Procedure	1678	CONSULT-II Reference Value in Data Monitor Mode	1721
Overall Function Check	1679	Wiring Diagram	1722
Wiring Diagram	1680	Diagnostic Procedure	1723
Diagnostic Procedure	1681	IACV-FICD SOLENOID VALVE	1725
DTC P1605 A/T DIAGNOSIS COMMUNICATION	1689	Component Description	1725
LINE	1689	Wiring Diagram	1726
Component Description	1689	Diagnostic Procedure	1727
On Board Diagnosis Logic	1689	MIL AND DATA LINK CONNECTOR	1730
DTC Confirmation Procedure	1689	Wiring Diagram	1730
Wiring Diagram	1690	EVAPORATIVE EMISSION SYSTEM	1731
Diagnostic Procedure	1693	Description	1731
DTC P1706 PNP SWITCH	1694	Component Inspection	1734
Component Description	1694	How to Detect Fuel Vapor Leakage	1735
CONSULT-II Reference Value in Data Monitor Mode	1694	ON BOARD REFUELING VAPOR RECOVERY	1737
On Board Diagnosis Logic	1694	(ORVR)	1737
DTC Confirmation Procedure	1694	System Description	1737
Overall Function Check	1695	Diagnostic Procedure	1738
Wiring Diagram	1696	POSITIVE CRANKCASE VENTILATION	1747
Diagnostic Procedure	1697	Description	1747
IGNITION SIGNAL	1701	Component Inspection	1747
Component Description	1701	SERVICE DATA AND SPECIFICATIONS (SDS)	1748
Wiring Diagram	1702	Fuel Pressure Regulator	1748
Diagnostic Procedure	1703	Idle Speed and Ignition Timing	1748
Removal and Installation	1706	Ignition Coil	1748
INJECTOR CIRCUIT	1707	Mass Air Flow Sensor	1748
Component Description	1707	Engine Coolant Temperature Sensor	1748
CONSULT-II Reference Value in Data Monitor Mode	1707	Heated Oxygen Sensor 1 Heater	1748
Wiring Diagram	1708	Fuel Pump	1748
Diagnostic Procedure	1709	IACV-AAC Valve	1748
Removal and Installation	1711	Injector	1748
START SIGNAL	1712	Throttle Position Sensor	1749
CONSULT-II Reference Value in Data Monitor Mode	1712	Calculated Load Value	1749
Wiring Diagram	1713	Intake Air Temperature Sensor	1749
Diagnostic Procedure	1714	Heated Oxygen Sensor 2 Heater	1749
FUEL PUMP CIRCUIT	1716	Crankshaft Position Sensor (OBD)	1749
Description	1716	Fuel Tank Temperature Sensor	1749

INDEX FOR DTC

[KA24DE]

PFP:00024

UBS008LO

INDEX FOR DTC Alphabetical Index

Items (CONSULT-II screen terms)	DTC*1 *2	Trip	MIL lighting up	Reference page
	CONSULT-II GST			
Unable to access ECM	—	—	—	EC-72
CKP SEN/CIRCUIT	P0335	2	×	EC-263
CKP SENSOR (COG)	P1336	2	×	EC-447
CLOSED LOOP-B1	P1148	1	×	EC-441
CLOSED TP SW/CIRC	P0510	2	×	EC-408
CMP SEN/CIRCUIT	P0340	2	×	EC-268
CYL1 MISFIRE	P0301	2	×	EC-251
CYL2 MISFIRE	P0302	2	×	EC-251
CYL3 MISFIRE	P0303	2	×	EC-251
CYL4 MISFIRE	P0304	2	×	EC-251
ECM	P0605	2	×	EC-415
ECT SEN/CIRCUIT	P0117*3	1	×	EC-154
ECT SEN/CIRCUIT	P0118*3	1	×	EC-154
ECT SENSOR	P0125	2	×	EC-174
EGR SYSTEM	P0400	2	×	EC-275
EGR SYSTEM	P1402	2	×	EC-458
EGR TEMP SEN/CIRC	P0405	2	×	EC-291
EGR TEMP SEN/CIRC	P0406	2	×	EC-291
EGRC-BPT VALVE	P0402	2	×	EC-285
EGRC SOLENOID/V	P1400	2	×	EC-452
ENG OVER TEMP	P0217	1	×	EC-247
ENG OVER TEMP	P1217	1	×	EC-443
EVAP GROSS LEAK	P0455	2	×	EC-354
EVAP PURG FLOW/MON	P0441	2	×	EC-302
EVAP SMALL LEAK	P0442	2	×	EC-311
EVAP SMALL LEAK	P1442	2	×	EC-467
EVAP SYS PRES SEN	P0452	2	×	EC-337
EVAP SYS PRES SEN	P0453	2	×	EC-344
EVAP VERY SML LEAK	P0456	2	×	EC-366
EVAP VERY SML LEAK	P1456	2	×	EC-489
FTT SEN/CIRCUIT	P0182	2	×	EC-243
FTT SEN/CIRCUIT	P0183	2	×	EC-243
FTT SENSOR	P0181	2	×	EC-238
FUEL LEV SEN SLOSH	P0460	2	×	EC-378
FUEL LEVEL SEN/CIRC	P1464	2	×	EC-501
FUEL LEVEL SENSOR	P0461	2	×	EC-382
FUEL LEVL SEN/CIRC	P0462	2	×	EC-384
FUEL LEVL SEN/CIRC	P0463	2	×	EC-384
FUEL SYS-LEAN-B1	P0171	2	×	EC-225
FUEL SYS-RICH-B1	P0172	2	×	EC-232

INDEX FOR DTC

[KA24DE]

Items (CONSULT-II screen terms)	DTC*1 *2	Trip	MIL lighting up	Reference page
	CONSULT-II GST			
HO2S1 (B1)	P0132	2	×	EC-186
HO2S1 (B1)	P0133	2	×	EC-192
HO2S1 (B1)	P0134	2	×	EC-202
HO2S1 (B1)	P1143	2	×	EC-417
HO2S1 (B1)	P1144	2	×	EC-422
HO2S1 HTR (B1)	P0031	2	×	EC-126
HO2S1 HTR (B1)	P0032	2	×	EC-126
HO2S2 HTR (B1)	P0037	2	×	EC-131
HO2S2 HTR (B1)	P0038	2	×	EC-131
HO2S2 (B1)	P0138	2	×	EC-209
HO2S2 (B1)	P0139	2	×	EC-216
HO2S2 (B1)	P1146	2	×	EC-427
HO2S2 (B1)	P1147	2	×	EC-434
IAT SEN/CIRCUIT	P0112*3	1	×	EC-149
IAT SEN/CIRCUIT	P0113*3	1	×	EC-149
IAT SENSOR	P0127	2	×	EC-179
ISC SYSTEM/CIRC	P0505	2	×	EC-393
ISC SYSTEM	P0506	2	×	EC-398
ISC SYSTEM	P0507	2	×	EC-403
KNOCK SEN/CIRC-B1	P0327	1	—	EC-259
KNOCK SEN/CIRC-B1	P0328	1	—	EC-259
MAF SEN/CIRCUIT	P0101	2	×	EC-136
MAF SEN/CIRCUIT	P0102*3	1	×	EC-143
MAF SEN/CIRCUIT	P0103*3	1	×	EC-143
MULTI CYL MISFIRE	P0300	2	×	EC-251
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	2	—	—
P-N POS SW/CIRCUIT	P1706	2	×	EC-520
PURG VOLUME CONT/V	P0444	2	×	EC-325
PURG VOLUME CONT/V	P0445	2	×	EC-325
PURG VOLUME CONT/V	P1444	2	×	EC-469
THERMSTAT FNCTN	P0128	2	×	EC-184
TP SEN/CIRCUIT	P0121	2	×	EC-159
TP SEN/CIRCUIT	P0122*3	1	×	EC-168
TP SEN/CIRCUIT	P0123*3	1	×	EC-168
TW CATALYST SYS-B1	P0420	2	×	EC-297
VC CUT/V BYPASS/V	P1491	2	×	EC-510
VC/V BYPASS/V	P1490	2	×	EC-504
VEH SPEED SEN/CIRC	P0500	2	×	EC-388
VENT CONTROL VALVE	P0447	2	×	EC-331

INDEX FOR DTC

[KA24DE]

Items (CONSULT-II screen terms)	DTC*1 *2	Trip	MIL lighting up	Reference page
	CONSULT-II GST			
VENT CONTROL VALVE	P1446	2	×	EC-479
VENT CONTROL VALVE	P1448	2	×	EC-483

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by SAE J2012.

*3: When the fail-safe operation occurs, the MIL illuminates.

DTC No. Index

UBS008LP

×: Applicable —: Not applicable

DTC*1 *2	Items (CONSULT-II screen terms)	Trip	MIL lighting up	Reference page
CONSULT-II GST				
—	Unable to access ECM	—	—	EC-72
P0000	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—
P0031	HO2S1 HTR (B1)	2	×	EC-126
P0032	HO2S1 HTR (B1)	2	×	EC-126
P0037	HO2S2 HTR (B1)	2	×	EC-131
P0038	HO2S2 HTR (B1)	2	×	EC-131
P0101	MAF SEN/CIRCUIT	2	×	EC-136
P0102*3	MAF SEN/CIRCUIT	1	×	EC-143
P0103*3	MAF SEN/CIRCUIT	1	×	EC-143
P0112*3	IAT SEN/CIRCUIT	1	×	EC-149
P0113*3	IAT SEN/CIRCUIT	1	×	EC-149
P0117*3	ECT SEN/CIRCUIT	1	×	EC-154
P0118*3	ECT SEN/CIRCUIT	1	×	EC-154
P0121	TP SEN/CIRCUIT	2	×	EC-159
P0122*3	TP SEN/CIRCUIT	1	×	EC-168
P0123*3	TP SEN/CIRCUIT	1	×	EC-168
P0125	ECT SENSOR	2	×	EC-174
P0127	IAT SENSOR	2	×	EC-179
P0128	THERMSTAT FNCTN	2	×	EC-184
P0132	HO2S1 (B1)	2	×	EC-186
P0133	HO2S1 (B1)	2	×	EC-192
P0134	HO2S1 (B1)	2	×	EC-202
P0138	HO2S2 (B1)	2	×	EC-209
P0139	HO2S2 (B1)	2	×	EC-216
P0171	FUEL SYS-LEAN-B1	2	×	EC-225
P0172	FUEL SYS-RICH-B1	2	×	EC-232
P0181	FTT SENSOR	2	×	EC-238
P0182	FTT SEN/CIRCUIT	2	×	EC-243
P0183	FTT SEN/CIRCUIT	2	×	EC-243
P0217	ENG OVER TEMP	1	×	EC-247
P0300	MULTI CYL MISFIRE	2	×	EC-251

INDEX FOR DTC

[KA24DE]

DTC*1 *2	Items (CONSULT-II screen terms)	Trip	MIL lighting up	Reference page
P0301	CYL1 MISFIRE	2	×	EC-251
P0302	CYL2 MISFIRE	2	×	EC-251
P0303	CYL3 MISFIRE	2	×	EC-251
P0304	CYL4 MISFIRE	2	×	EC-251
P0327	KNOCK SEN/CIRC-B1	1	—	EC-259
P0328	KNOCK SEN/CIRC-B1	1	—	EC-259
P0335	CKP SEN/CIRCUIT	2	×	EC-263
P0340	CMP SEN/CIRCUIT	2	×	EC-268
P0400	EGR SYSTEM	2	×	EC-275
P0402	EGRC-BPT VALVE	2	×	EC-285
P0405	EGR TEMP SEN/CIRC	2	×	EC-291
P0406	EGR TEMP SEN/CIRC	2	×	EC-291
P0420	TW CATALYST SYS-B1	2	×	EC-297
P0441	EVAP PURG FLOW/MON	2	×	EC-302
P0442	EVAP SMALL LEAK	2	×	EC-311
P0444	PURG VOLUME CONT/V	2	×	EC-325
P0445	PURG VOLUME CONT/V	2	×	EC-325
P0447	VENT CONTROL VALVE	2	×	EC-331
P0452	EVAP SYS PRES SEN	2	×	EC-337
P0453	EVAP SYS PRES SEN	2	×	EC-344
P0455	EVAP GROSS LEAK	2	×	EC-354
P0456	EVAP VERY SML LEAK	2	×	EC-366
P0460	FUEL LEV SEN SLOSH	2	×	EC-378
P0461	FUEL LEVEL SENSOR	2	×	EC-382
P0462	FUEL LEVL SEN/CIRC	2	×	EC-384
P0463	FUEL LEVL SEN/CIRC	2	×	EC-384
P0500	VEH SPEED SEN/CIRC	2	×	EC-388
P0505	ISC SYSTEM/CIRC	2	×	EC-393
P0506	ISC SYSTEM	2	×	EC-398
P0507	ISC SYSTEM	2	×	EC-403
P0510	CLOSED TP SW/CIRC	2	×	EC-408
P0605	ECM	2	×	EC-415
P1143	HO2S1 (B1)	2	×	EC-417
P1144	HO2S1 (B1)	2	×	EC-422
P1146	HO2S2 (B1)	2	×	EC-427
P1147	HO2S2 (B1)	2	×	EC-434
P1148	CLOSED LOOP-B1	1	×	EC-441
P1217	ENG OVER TEMP	1	×	EC-443
P1336	CKP SENSOR (COG)	2	×	EC-447
P1400	EGRC SOLENOID/V	2	×	EC-452
P1402	EGR SYSTEM	2	×	EC-458
P1442	EVAP SMALL LEAK	2	×	EC-467

INDEX FOR DTC

[KA24DE]

DTC*1 *2	Items (CONSULT-II screen terms)	Trip	MIL lighting up	Reference page
CONSULT-II GST				
P1444	PURG VOLUME CONT/V	2	×	EC-469
P1446	VENT CONTROL VALVE	2	×	EC-479
P1448	VENT CONTROL VALVE	2	×	EC-483
P1456	EVAP VERY SML LEAK	2	×	EC-489
P1464	FUEL LEVL SEN/CIRC	2	×	EC-501
P1490	VC/V BYPASS/V	2	×	EC-504
P1491	VC CUT/V BYPASS/V	2	×	EC-510
P1706	P-N POS SW/CIRCUIT	2	×	EC-520

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by SAE J2012.

*3: When the fail-safe operation occurs, the MIL illuminates.

A
EC
C
D
E
F
G
H
I
J
K
L
M

PRECAUTIONS

PFP:00001

Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

UBS008LQ

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER” used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and in the instrument panel on the passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness, and spiral cable.

The vehicle (except Crew Cab model) is equipped with a passenger air bag deactivation switch. Because no rear seat exists where a rear-facing child restraint can be placed, the switch is designed to turn off the passenger air bag so that a rear-facing child restraint can be used in the front passenger seat. The switch is located in the center of the instrument panel, near the ashtray. When the switch is turned to the ON position, the passenger air bag is enabled and could inflate in a frontal collision. When the switch is turned to the OFF position, the passenger air bag is disabled and will not inflate in a frontal collision. A passenger air bag OFF indicator on the instrument panel lights up when the passenger air bag is switched OFF. The driver air bag always remains enabled and is not affected by the passenger air bag deactivation switch.

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow harness connectors.
- The vehicle (except Crew Cab model) is equipped with a passenger air bag deactivation switch which can be operated by the customer. When the passenger air bag is switched OFF, the passenger air bag is disabled and will not inflate in a frontal collision. When the passenger air bag is switched ON, the passenger air bag is enabled and could inflate in a frontal collision. After SRS maintenance or repair, make sure the passenger air bag deactivation switch is in the same position (ON or OFF) as when the vehicle arrived for service.

Precautions for On Board Diagnostic (OBD) System of Engine

UBS008LR

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-4, "HARNES CONNECTOR"](#).
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM before returning the vehicle to the customer.

Engine Fuel & Emission Control System

A

EC

C

D

E

F

G

H

I

J

K

L

M

ECM


- Do not disassemble ECM.
- If a battery terminal is disconnected, the memory will return to the ECM value.
The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

BATTERY

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.

WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



ECM PARTS HANDLING

- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor or crankshaft position sensor (OBD).



WIRELESS EQUIPMENT

- When installing CB ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
 - 1) Keep the antenna as far away as possible from the electronic control units.
 - 2) Keep the antenna feeder line more than 20 cm (7.9 in.) away from the harness of electronic controls.
Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.

FUEL PUMP


- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque. (Refer to MA section.)

ECM HARNESS HANDLING

- Securely connect ECM harness connectors.
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep engine control system harness at least 10 cm (3.9 in.) away from adjacent harnesses to prevent an engine control system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep engine control system parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

Precautions

- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.




SEF289H

- When connecting ECM harness connector, tighten securing bolt until the gap between orange indicators disappears.




: 3 - 5 N·m (0.3 - 0.5 kg·m, 26 - 43 in·lb)




SEF308Q

- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
Make sure that there are not any bends or breaks on ECM pin terminals when connecting pin connectors.



SEF291H

- Before replacing ECM, perform Terminals and Reference Value inspection and make sure ECM functions properly. Refer to [EC-91, "ECM Terminals and Reference Value"](#).




MEF040D


PRECAUTIONS

[KA24DE]

- After performing each TROUBLE DIAGNOSIS, perform “Overall Function Check” or “DTC Confirmation Procedure”.
The DTC should not be displayed in the “DTC Confirmation Procedure” if the repair is completed. The “Overall Function Check” should be a good result if the repair is completed.



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.



Wiring Diagrams and Trouble Diagnosis

When you read Wiring diagrams, refer to the following:

- [GI-13, "How to Read Wiring Diagrams"](#).
- [PG-8, "POWER SUPPLY ROUTING"](#).

When you perform trouble diagnosis, refer to the following:

- [GI-9, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#).
- [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).

PREPARATION

[KA24DE]

PFP:00002




UBS008LV

PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.




Tool number (Kent-Moore No.) Tool name	Description
KV10117100 (J36471-A) Heated oxygen sensor wrench	Loosening or tightening heated oxygen sensor 1 with 22 mm (0.87 in) hexagon nut
KV10114400 (J-38365) Heated oxygen sensor wrench	Loosening or tightening heated oxygen sensor 2 a: 22 mm (0.87 in)
(J-45178) TPS test connector	Used to test the throttle position sensor



Commercial Service Tools




UBS008LW

Tool name	Description
Fuel filler cap adapter	Checking fuel tank vacuum relief valve opening pressure
Leak detector i.e.: (J41416)	Locating the EVAP leak
EVAP service port adapter i.e.: (J41413-OBDD)	Applying positive pressure through EVAP service port



PREPARATION

[KA24DE]

Tool name	Description
<p>Socket wrench</p>  <p>19 mm (0.75 in)</p> <p>More than 32 mm (1.26 in)</p> <p>NT705</p>	<p>Removing and installing engine coolant temperature sensor</p>
<p>Oxygen sensor thread cleaner i.e.: (J-43897-18) i.e.: (J-43897-12)</p>  <p>a</p> <p>b</p> <p>Mating surface shave cylinder</p> <p>Flutes</p> <p>AEM488</p>	<p>Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown in "Commercial Service tools". a: J-43897-18 18 mm diameter, for Zirconia Oxygen Sensor b: J-43897-12 12 mm diameter, for Titania Oxygen Sensor</p>
<p>Anti-seize lubricant i.e.: (Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907)</p>  <p>AEM489</p>	<p>Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.</p>


A
EC
C
D
E
F
G
H
I
J
K
L
M

ENGINE CONTROL SYSTEM

PF:P:23710


System Diagram

UBS008LX



Vacuum Hose Drawing

Refer to [EC-28, "System Diagram"](#) for vacuum control system.



NOTE: Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.

View Y

System Chart

Input (Sensor)	ECM Function	Output (Actuator)
<ul style="list-style-type: none"> ● Camshaft position sensor ● Mass air flow sensor ● Engine coolant temperature sensor ● Heated oxygen sensor 1 ● Ignition switch ● Throttle position sensor ● PNP switch ● Air conditioner switch ● Knock sensor ● EGR temperature sensor*1 ● Crankshaft position sensor (OBD) ● EVAP control system pressure sensor*1 ● Fuel tank temperature sensor ● Battery voltage ● Power steering oil pressure switch ● Vehicle speed sensor ● Intake air temperature sensor ● Heated oxygen sensor 2*2 ● Closed throttle position switch*3 	Fuel injection & mixture ratio control	Injectors
	Distributor ignition system	Power transistor
	Idle air control system	IACV-AAC valve and IACV-FICD solenoid valve
	Fuel pump control	Fuel pump relay
	Heated oxygen sensor 1 monitor & on board diagnostic system	Malfunction indicator lamp (On the instrument panel)
	EGR control	EGRC-solenoid valve
	Heated oxygen sensors 1, 2 heater control	Heated oxygen sensor heater
	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
	Air conditioning cut control	Air conditioner relay
	ON BOARD DIAGNOSIS for EVAP system	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● Vacuum cut valve bypass valve

*1: These sensors are not used to control the engine system. They are used only for the on board diagnosis.

*2: Under normal conditions, this sensor is not for engine control operation.

*3: This switch will operate in place of the throttle position sensor to control EVAP parts if the sensor malfunctions.

Multipoint Fuel Injection (MFI) System INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed and piston position	Fuel injection & mixture ratio control	Injector
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Heated oxygen sensor 1	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position Throttle valve idle position		
PNP switch	Gear position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Air conditioner switch	Air conditioner operation		
Knock sensor	Engine knocking condition		
Battery	Battery voltage		
Power steering oil pressure switch	Power steering operation		
Heated oxygen sensor 2*	Density of oxygen in exhaust gas		

* Under normal conditions, this sensor is not for engine control operation.

SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the camshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.


<Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (manifold) can then better reduce CO, HC and NOx emissions. This system uses a heated oxygen sensor 1 in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about the heated oxygen sensor 1, refer to [EC-192](#). This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of the heated oxygen sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from the heated oxygen sensor 2.

Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of heated oxygen sensor 1 or its circuit
- Insufficient activation of heated oxygen sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the heated oxygen sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot film) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.


Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

“Fuel trim” refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

“Short term fuel trim” is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the heated oxygen sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

“Long term fuel trim” is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

FUEL INJECTION TIMING



Two types of systems are used.

Sequential Multiport Fuel Injection System

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous Multiport Fuel Injection System

Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The four injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

Distributor Ignition (DI) System INPUT/OUTPUT SIGNAL CHART

UBS008M1

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed and piston position	Ignition timing control	Power transistor
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position Throttle valve idle position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Knock sensor	Engine knocking		
PNP switch	Gear position		
Battery	Battery voltage		

SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown above.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.


e.g., N: 1,800 rpm, Tp: 1.50 msec
A°BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions.

If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.



Air Conditioning Cut Control INPUT/OUTPUT SIGNAL CHART

UBS008M2

Sensor	Input Signal to ECM	ECM function	Actuator
Air conditioner switch	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
Throttle position sensor	Throttle valve opening angle		
Camshaft position sensor	Engine speed		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Vehicle speed sensor	Vehicle speed		
Power steering oil pressure switch	Power steering operation		

SYSTEM DESCRIPTION

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- When the engine coolant temperature becomes excessively high.
- When operating power steering and air conditioner during low engine speed or when fully releasing accelerator pedal.
- When engine speed is excessively low.

Fuel Cut Control (at No Load and High Engine Speed) INPUT/OUTPUT SIGNAL CHART

UBS008M3

Sensor	Input Signal to ECM	ECM function	Actuator
Vehicle speed sensor	Vehicle speed	Fuel cut control	Injectors
PNP switch	Neutral position		
Throttle position sensor	Throttle position		
Camshaft position sensor	Engine speed		

SYSTEM DESCRIPTION

If the engine speed is above 3,000 rpm with no load, (for example, in Neutral and engine speed over 3,000 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.

NOTE:


This function is different from deceleration control listed under [EC-30, "Multiport Fuel Injection \(MFI\) System"](#) .

Fast Idle Cam (FIC)**COMPONENT DESCRIPTION**

The FIC is installed on the throttle body to maintain adequate engine speed while the engine is cold. It is operated by a volumetric change in wax located inside the thermo-element. The thermo-element is operated by engine coolant temperature.

For inspection refer to [EC-73, "Basic Inspection"](#) .

UBS008M4



BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment PREPARATION

- Make sure that the following parts are in good order.
 - Battery
 - Ignition system
 - Engine oil and coolant levels
 - Fuses
 - ECM harness connector
 - Vacuum hoses
 - Air intake system
(Oil filler cap, oil level gauge, etc.)
 - Fuel pressure
 - Engine compression
 - EGR valve operation
 - Throttle valve
 - EVAP system
- On models equipped with air conditioner, checks should be carried out while the air conditioner is "OFF".
- When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
- Turn off headlamps, heater blower.
- Keep front wheels pointed straight ahead.

EC

C

D

E

F

G

H

I

J

K

L

M


INSPECTION PROCEDURE

1. INSPECTION START

1. Visually check the following:
 - Air cleaner clogging
 - Hoses and duct for leaks
 - EGR valve operation
 - Electrical connectors
 - Gasket (intake manifold, cylinder head, exhaust system)
 - Throttle valve and throttle position sensor operation
2. Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge. Ensure engine speed stays below 1,000 rpm.
3. Open engine hood and run engine at about 2,000 rpm for about 2 minutes under no-load.
4. Make sure that no DTC is displayed with CONSULT-II or GST.

OK or NG

- OK >> ● GO TO 2 (With CONSULT-II).
 ● GO TO 3 (Without CONSULT-II).
- NG >> 1. Repair or replace components as necessary.
 2. GO TO 2 (With CONSULT-II).
 3. GO TO 3 (Without CONSULT-II).




A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M


2. CHECK IGNITION TIMING

 **With CONSULT-II**

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine two or three times under no-load, then run engine at idle speed for about 1 minute.
3. Select "IGNITION TIMING ADJ" in WORK SUPPORT mode.



4. Touch "START".
5. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.




6. Check ignition timing with a timing light.

M/T : 20°±2° BTDC

A/T : 20°±2° BTDC (in "P" or "N" position)

OK or NG


- OK >> GO TO 5.
 NG >> GO TO 4.




3. CHECK IGNITION TIMING

⊗ Without CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine two or three times under no-load, then run engine at idle speed for about 1 minute.



3. Turn off engine and disconnect throttle position sensor harness connector.
4. Start engine and rev it (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.




5. Check ignition timing with a timing light.

M/T : 20°±2° BTDC

A/T : 20°±2° BTDC (in "P" or "N" position)

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.



A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M

4. ADJUST IGNITION TIMING


With CONSULT-II

1. Adjust ignition timing to the specified value by turning distributor after loosening bolts which secure distributor.

Without CONSULT-II

1. Adjust ignition timing to the specified value by turning distributor after loosening bolts which secure distributor.
2. Turn off engine and connect throttle position sensor harness connector to throttle position sensor.

Models with CONSULT-II>>GO TO 2.
Models without CONSULT-II>>GO TO 3.



5. CHECK BASE IDLE SPEED

With CONSULT-II

1. Read idle speed in "IGNITION TIMING ADJ" in "WORK SUPPORT" mode.

M/T : 750±50 rpm
A/T : 750±50 rpm (in "P" or "N" position)

Without CONSULT-II

1. Check idle speed.

M/T : 750±50 rpm
A/T : 750±50 rpm (in "P" or "N" position)

IGNITION TIMING ADJ	
CONDITION SETTING	
IGN/T FEEDBACK	HOLD
MONITOR	
ENG SPEED	XXX rpm
IGN TIMING	XXX BTDC
CLSD THL POS	ON

OK or NG


OK (With CONSULT-II)>>GO TO 7.
OK (Without CONSULT-II)>>GO TO 8.
NG >> GO TO 6.

6. ADJUST BASE IDLE SPEED

1. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.
2. Adjust idle speed by turning idle speed adjusting screw.

M/T : 750±50 rpm
A/T : 750±50 rpm (in "P" or "N" position)


Models with CONSULT-II>>GO TO 7.
Models without CONSULT-II>>GO TO 8.



7. CHECK TARGET IDLE SPEED

With CONSULT-II

1. Touch "BACK" on CONSULT-II.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.




3. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T : 800±50 rpm

A/T : 800±50 rpm (in "P" or "N" position)

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.



8. CHECK TARGET IDLE SPEED

Without CONSULT-II


1. Turn off engine and connect throttle position sensor harness connector.
2. Start engine.
3. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.
4. Check target idle speed.

M/T : 800±50 rpm

A/T : 800±50 rpm (in "P" or "N" position)

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.



9. DETECT MALFUNCTIONING PART

Check the following.

1. Check IACV-AAC valve and replace if necessary. Refer to [EC-398](#) , [EC-403](#) .
2. Check IACV-AAC valve harness and repair if necessary. Refer to [EC-393](#) .
3. Check ECM function by substituting another known good ECM. (ECM may be the cause of an incident, but this is rarely the case.)

>> GO TO 10.

10. CHECK HEATED OXYGEN SENSOR 1 SIGNAL

With CONSULT-II

1. See "HO2S1 MNTR (B1)" in "DATA MONITOR" mode.
2. Run engine at about 2,000 rpm for about 2 minutes under no-load.
3. Maintain engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature) and check that the monitor fluctuates between "LEAN" and "RICH" more than five times during 10 seconds.

1 cycle: RICH → LEAN → RICH

2 cycles: RICH → LEAN → RICH → LEAN → RICH

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
HO2S1 MNTR (B1)	RICH

SEF820Y

Without CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Set voltmeter probe between ECM terminal 50 and ground.
3. Make sure that the voltage fluctuates between 0 - 0.3V and 0.6 - 1.0V more than 5 times during 10 seconds at 2,000 rpm.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V


2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 11.

11. CHECK HEATED OXYGEN SENSOR 1 HARNESS

1. Turn off engine and disconnect battery ground cable.
2. Disconnect ECM harness connector.
3. Disconnect heated oxygen sensor 1 harness connector.
4. Then connect harness connector terminal for heated oxygen sensor 1 to ground with a jumper wire.




5. Check for continuity between terminal 50 of ECM harness connector and body ground.

Continuity exists...OK
Continuity does not exist...NG

OK or NG


- OK >> 1. Connect ECM harness connector to ECM.
 2. Connect battery ground cable.
 3. GO TO 13.
- NG >> 1. Repair or replace harness.
 2. GO TO 12.



12. PREPARATION FOR IDLE SPEED ADJUSTING

 With CONSULT-II


1. Select "IGNITION TIMING ADJ" in "WORK SUPPORT" mode.
2. Touch "START".



 Without CONSULT-II

1. Stop engine and disconnect throttle position sensor harness connector.
2. Start engine.


>> GO TO 6.



13. PREPARATION FOR "CO" % CHECK


 With CONSULT-II

1. Select "ENGINE COOLANT TEMP" in "ACTIVE TEST" mode.
2. Set "COOLANT TEMP" to 5°C (41°F) by touching "Qu" and "Qd" and "UP", "DOWN".
1. Connect ECM harness connector to ECM.
2. Disconnect engine coolant temperature sensor harness connector.



3. Connect a resistor (4.4 kΩ) between terminals of engine coolant temperature sensor harness connector.
4. Connect battery ground cable.


>> GO TO 14.



14. CHECK "CO" %

⊗ Without CONSULT-II

1. Start engine and warm it up until engine coolant temperature indicator points to middle of gauge.
(Be sure to start engine after setting "COOLANT TEMP" or installing a 4.4 kΩ resistor.)




2. Rev engine two or three times under no-load, then run engine at idle speed.
3. Check "CO"%.

Idle CO : 2.9 - 10.8% and engine runs smoothly.

4. ⓘ With CONSULT-II
After checking CO%, touch "BACK".

5. ⊗ Without CONSULT-II
After checking CO%,

- Disconnect the resistor from terminals of engine coolant temperature sensor harness connector.
- Connect engine coolant temperature sensor harness connector to engine coolant temperature sensor.



OK or NG

- OK >> GO TO 15.
- NG >> GO TO 16.

15. CHECK HEATED OXYGEN SENSOR 1 SIGNAL

With CONSULT-II

1. Replace heated oxygen sensor 1.
2. See "HO2S1 MNTR (B1)" in "DATA MONITOR" mode.
3. Maintain engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.). Check that the monitor fluctuates between "LEAN" and "RICH" more than five times during 10 seconds.

1 cycle: RICH → LEAN → RICH

2 cycles: RICH → LEAN → RICH → LEAN → RICH

Without CONSULT-II

1. Stop engine.
2. Replace heated oxygen sensor 1.
3. Start engine and warm it up to normal operating temperature.
4. Run engine at approx. 2,000 rpm for approx. 2 minutes under no-load.
5. Set voltmeter probe between ECM terminal 50 and ground.
6. Make sure that voltage fluctuates between 0 - 0.3V and 0.6 - 1.0V more than 5 times during 10 seconds at 2,000 rpm.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 16.

16. DETECT MALFUNCTIONING PART

1. Connect heated oxygen sensor 1 harness connector to heated oxygen sensor 1.
2. Check fuel pressure regulator. Refer to [EC-47](#).
3. Check mass air flow sensor and its circuit.
Refer to [EC-136](#), [EC-143](#).
4. Check injector and its circuit.
Refer to [EC-532](#).
Clean or replace if necessary.
5. Check engine coolant temperature sensor and its circuit. Refer to [EC-154](#), [EC-174](#).
6. Check ECM function by substituting another known-good ECM.
(ECM may be the cause of an incident, but this is rarely the case.)

>> GO TO 12.

- If a vehicle contains a part which is operating outside of design specifications with no MIL illumination, the part shall not be replaced prior to emission testing unless it is determined that the part has been tampered with or abused in such a way that the diagnostic system cannot reasonably be expected to detect the resulting malfunction.



**Fuel Pressure Check
FUEL PRESSURE RELEASE**

UBS008M6

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.


Ⓟ With CONSULT-II

1. Start engine.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF.




⊗ Without CONSULT-II

1. Remove fuse for fuel pump.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF and reconnect fuel pump fuse.



FUEL PRESSURE CHECK

- When reconnecting fuel line, always use new clamps.
 - Make sure that clamp screw does not contact adjacent parts.
 - Use a torque driver to tighten clamps.
 - Use Pressure Gauge to check fuel pressure.
 - Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
1. Release fuel pressure to zero.
 2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
 3. Install pressure gauge between fuel filter and fuel tube.




4. Start engine and check for fuel leakage.
5. Read the indication of fuel pressure gauge.

At idle speed:

With vacuum hose connected **Approximately 235 kPa**
(2.4 kg/cm² , 34 psi)

With vacuum hose disconnected **Approximately 294 kPa**
(3.0 kg/cm² , 43 psi)

If results are unsatisfactory, perform [EC-47, "Fuel Pressure Regulator Check"](#).




UBS008M7

Fuel Pressure Regulator Check

1. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
2. Plug intake manifold with a rubber cap.
3. Connect variable vacuum source to fuel pressure regulator.
4. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.



ON BOARD DIAGNOSTIC (OBD) SYSTEM

PFP:00028

Introduction

UBS008M8

The ECM has an on board diagnostic system which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Diagnostic Trouble Code (DTC)	Mode 3 of SAE J1979
Freeze Frame data	Mode 2 of SAE J1979
System Readiness Test (SRT) code	Mode 1 of SAE J1979
1st Trip Diagnostic Trouble Code (1st Trip DTC)	Mode 7 of SAE J1979
1st Trip Freeze Frame data	
Test values and Test limits	Mode 6 of SAE J1979
Calibration ID	Mode 9 of SAE J1979

The above information can be checked using procedures listed in the table below.

X: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data	SRT code	Test value
CONSULT-II	X	X	X	X	X	—
GST	X	X*1	X	—	X	X

*1: 1st trip DTCs for self-diagnoses concerning SRT items cannot be shown on the GST display.

The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to [EC-72](#).)

Two Trip Detection Logic

UBS008M9

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MIL will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MIL lights up. The MIL lights up at the same time when the DTC is stored. <2nd trip> The “trip” in the “Two Trip Detection Logic” means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MIL, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

X: Applicable —: Not applicable

Items	MIL				DTC		1st trip DTC	
	1st trip		2nd trip		1st trip displaying	2nd trip displaying	1st trip displaying	2nd trip displaying
	Blinking	Lighting up	Blinking	Lighting up				
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 is being detected	X	—	—	—	—	—	X	—
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 is being detected	—	—	X	—	—	X	—	—
One trip detection diagnoses (Refer to EC-17 .)	—	X	—	—	X	—	—	—
Fail-safe items (Refer to EC-72 .)	—	X	—	—	X*1	—	—	—
Except above	—	—	—	X	—	X	X	—

*1: Except “ECM”

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[KA24DE]

UBS008MA

Emission-related Diagnostic Information EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

X: Applicable —: Not applicable

Items (CONSULT-II screen terms)	DTC*1*2	SRT code	Test value/ Test limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST				
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	—	—	—	—
HO2S1 HTR (B1)	P0031	X	X	X*5	EC-126
HO2S1 HTR (B1)	P0032	X	X	X*5	EC-126
HO2S2 HTR (B1)	P0037	X	X	X*5	EC-131
HO2S2 HTR (B1)	P0038	X	X	X*5	EC-131
MAF SEN/CIRCUIT	P0101	—	—	X	EC-136
MAF SEN/CIRCUIT	P0102*3	—	—	—	EC-143
MAF SEN/CIRCUIT	P0103*3	—	—	—	EC-143
IAT SEN/CIRCUIT	P0112*3	—	—	—	EC-149
IAT SEN/CIRCUIT	P0113*3	—	—	—	EC-149
ECT SEN/CIRCUIT	P0117*3	—	—	—	EC-154
ECT SEN/CIRCUIT	P0118*3	—	—	—	EC-154
TP SEN/CIRCUIT	P0121	—	—	X	EC-159
TP SEN/CIRCUIT	P0122*3	—	—	—	EC-168
TP SEN/CIRCUIT	P0123*3	—	—	—	EC-168
ECT SENSOR	P0125	—	—	X	EC-174
IAT SENSOR	P0127	—	—	X	EC-179
THERMSTAT FNCTN	P0128	—	—	X	EC-184
HO2S1 (B1)	P0132	X	X	X*5	EC-186
HO2S1 (B1)	P0133	X	X	X*5	EC-192
HO2S1 (B1)	P0134	X	X	X*5	EC-202
HO2S2 (B1)	P0138	X	X	X*5	EC-209
HO2S2 (B1)	P0139	X	X	X*5	EC-216
FUEL SYS-LEAN-B1	P0171	—	—	X	EC-225
FUEL SYS-RICH-B1	P0172	—	—	X	EC-232
FTT SENSOR	P0181	—	—	X	EC-238
FTT SEN/CIRCUIT	P0182	—	—	X	EC-243
FTT SEN/CIRCUIT	P0183	—	—	X	EC-243
ENG OVER TEMP	P0217	—	—	X	EC-247
MULTI CYL MISFIRE	P0300	—	—	X	EC-251
CYL1 MISFIRE	P0301	—	—	X	EC-251
CYL2 MISFIRE	P0302	—	—	X	EC-251
CYL3 MISFIRE	P0303	—	—	X	EC-251
CYL4 MISFIRE	P0304	—	—	X	EC-251
KNOCK SEN/CIRC-B1	P0327	—	—	—	EC-259
KNOCK SEN/CIRC-B1	P0328	—	—	—	EC-259
CKP SEN/CIRCUIT	P0335	—	—	X	EC-263
CMP SEN/CIRCUIT	P0340	—	—	X	EC-268
EGR SYSTEM	P0400	X	X	X*5	EC-275

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[KA24DE]

Items (CONSULT-II screen terms)	DTC*1*2	SRT code	Test value/ Test limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST				
EGRC-BPT VALVE	P0402	X	X	X*5	EC-285
EGR TEMP SEN/CIRC	P0405	—	—	X	EC-291
EGR TEMP SEN/CIRC	P0406	—	—	X	EC-291
TW CATALYST SYS-B1	P0420	X	X	X*5	EC-297
EVAP PURG FLOW/MON	P0441	X	X	X*5	EC-302
EVAP SMALL LEAK	P0442	X	X	X*5	EC-311
PURG VOLUME CONT/V	P0444	—	—	X	EC-325
PURG VOLUME CONT/V	P0445	—	—	X	EC-325
VENT CONTROL VALVE	P0447	—	—	X	EC-331
EVAP SYS PRES SEN	P0452	—	—	X	EC-337
EVAP SYS PRES SEN	P0453	—	—	X	EC-344
EVAP GROSS LEAK	P0455	X	X	X*5	EC-354
EVAP VERY SML LEAK	P0456	X*4	X	X*5	EC-366
FUEL LEV SEN SLOSH	P0460	—	—	X	EC-378
FUEL LEVEL SENSOR	P0461	—	—	X	EC-382
FUEL LEVL SEN/CIRC	P0462	—	—	X	EC-384
FUEL LEVL SEN/CIRC	P0463	—	—	X	EC-384
VEH SPEED SEN/CIRC	P0500	—	—	X	EC-388
ISC SYSTEM/CIRC	P0505	—	—	X	EC-393
ISC SYSTEM	P0506	—	—	X	EC-398
ISC SYSTEM	P0507	—	—	X	EC-403
CLOSED TP SW/CIRC	P0510	—	—	X	EC-408
ECM	P0605	—	—	X	EC-415
HO2S1 (B1)	P1143	X	X	X*5	EC-417
HO2S1 (B1)	P1144	X	X	X*5	EC-422
HO2S2 (B1)	P1146	X	X	X*5	EC-427
HO2S2 (B1)	P1147	X	X	X*5	EC-434
CLOSED LOOP-B1	P1148	—	—	X	EC-441
ENG OVER TEMP	P1217	—	—	X	EC-443
CKP SENSOR (COG)	P1336	—	—	X	EC-447
EGRC SOLENOID/V	P1400	—	—	X	EC-452
EGR SYSTEM	P1402	X	X	X*5	EC-458
EVAP SMALL LEAK	P1442	X	X	X*5	EC-467
PURG VOLUME CONT/V	P1444	—	—	X	EC-469
VENT CONTROL VALVE	P1446	—	—	X	EC-479
VENT CONTROL VALVE	P1448	—	—	X	EC-483
EVAP VERY SML LEAK	P1456	X*4	X	X*5	EC-489
FUEL LEVEL SEN/CIRC	P1464	—	—	X	EC-501
VC/V BYPASS/V	P1490	—	—	X	EC-504
VC CUT/V BYPASS/V	P1491	—	—	X	EC-510
P-N POS SW/CIRCUIT	P1706	—	—	X	EC-520

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by SAE J2012.

- *3: When the fail-safe operation occurs, the MIL illuminates.
- *4: SRT code will not be set if the self-diagnostic result is NG.
- *5: These are not displayed with GST.

DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed. If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MIL will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MIL during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in [EC-60, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

For malfunctions in which 1st trip DTCs are displayed, refer to [EC-49](#). These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT-II.

1st trip DTC is specified in Mode 7 of SAE J1979. 1st trip DTC detection occurs without lighting up the MIL and therefore does not warn the driver of a malfunction. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in "Work Flow" procedure Step II, refer to [EC-68](#). Then perform "DTC Confirmation Procedure" or "Overall Function Check" to try to duplicate the malfunction. If the malfunction is duplicated, the item requires repair.

How to read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

 **With CONSULT-II**

 **With GST**

CONSULT-II or GST (Generic Scan Tool) Examples: P0340, P1148, P1775, etc.
These DTCs are prescribed by SAE J2012.

(CONSULT-II also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, GST does not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".
If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

DTC display	SELF DIAG RESULTS		1st trip DTC display	SELF DIAG RESULTS	
	DTC RESULTS			DTC RESULTS	
	CKP SEN/CIRCUIT [P0335]	0		CKP SEN/CIRCUIT [P0335]	1t

PBIB0911E

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, throttle valve opening, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For details, see [EC-103, "Freeze Frame Data and 1st Trip Freeze Frame Data"](#).

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0304 Fuel Injection System Function — DTC: P0171, P0172
2		Except the above items
3	1st trip freeze frame data	

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in [EC-60, "HOW TO ERASE EMIS-SION-RELATED DIAGNOSTIC INFORMATION"](#).

SYSTEM READINESS TEST (SRT) CODE

System Readiness Test (SRT) code is specified in Mode 1 of SAE J1979.

As part of enhanced emissions test for Inspection and Maintenance (I/M), certain states require that the status of SRT be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "incomplete", use the information in this service manual to set the SRT to "complete".

In most cases, the ECM will automatically complete its self-diagnosis cycle during normal usage and the SRT status will indicate "complete" for each application system. Once set as "complete", the SRT status remains "complete" until the self-diagnosis memory is erased.

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern and the SRT will indicate "incomplete" for these items.

NOTE:

The SRT will also indicate "incomplete" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.

If, during the state emissions inspection, the SRT indicates "complete" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "incomplete" for one or more of the SRT items, the vehicle is returned to the customer untested.

NOTE:

If MIL is "ON" during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "complete" for all test items. Therefore, it is important to check SRT ("complete") and DTC (No DTCs) before the inspection.

This service manual contains the service procedure and support information to perform a comprehensive road test that enables the ECM to complete the SRT.

SRT Item

The following table shows required self-diagnostic items to set the SRT to "CMPLT".

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[KA24DE]

SRT item (CONSULT-II indication)	Performance Priority *	Required self-diagnostic items to set the SRT to "CMPLT"	Corresponding DTC No.	
CATALYST	2	Three way catalyst function	P0420	A
EVAP SYSTEM	1	EVAP control system	P0442, P1442	EC
	2	EVAP control system	P0456, P1456	
	2	EVAP control system purge flow monitoring	P0441	C
HO2S	2	Heated oxygen sensor 1	P0134	
		Heated oxygen sensor 1	P1143	
		Heated oxygen sensor 1	P1144	D
		Heated oxygen sensor 1	P0133	
		Heated oxygen sensor 1	P0132	
		Heated oxygen sensor 2	P1146	E
		Heated oxygen sensor 2	P1147	
		Heated oxygen sensor 2	P0139	F
		Heated oxygen sensor 2	P0138	
HO2S HTR	2	Heated oxygen sensor 1 heater	P0031, P0032	
		Heated oxygen sensor 2 heater	P0037, P0038	G
EGR SYSTEM	3	EGR function	P0400	
		EGRC-BPT valve function	P0402	H
	1	EGR function	P1402	

*: If completion of several SRTs is required, perform driving patterns (DTC confirmation procedure) one by one based on the priority for models with CONSULT-II.

SRT Set Timing

SRT is set as “complete” after self-diagnosis has been performed one or more times. Completion of SRT will occur if the result is OK or NG. The set timing is different between them and is shown in the following table.

Self-diagnosis result		Example				
		Diagnosis	Ignition OFF – ON – OFF	Ignition OFF – ON – OFF	Ignition OFF – ON – OFF	Ignition OFF – ON – OFF
All OK	Case 1	P0400	OK (1)	– (1)	OK (2)	– (2)
		P0402	OK (1)	– (1)	– (1)	OK (2)
		P1402	OK (1)	OK (2)	– (2)	– (2)
		SRT of EGR	“complete”	“complete”	“complete”	“complete”
	Case 2	P0400	OK (1)	– (1)	– (1)	– (1)
		P0402	– (0)	– (0)	OK (1)	– (1)
		P1402	OK (1)	OK (2)	– (2)	– (2)
		SRT of EGR	“incomplete”	“incomplete”	“complete”	“complete”
NG exists	Case 3	P0400	OK	OK	–	–
		P0402	–	–	–	–
		P1402	NG	–	NG	NG (Consecutive NG)
		(1st trip) DTC	1st trip DTC	–	1st trip DTC	DTC (=MIL “ON”)
		SRT of EGR	“incomplete”	“incomplete”	“incomplete”	“complete”

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is OK.

– : Self-diagnosis is not carried out.

When all SRT related self-diagnoses showed OK results in a same cycle (Ignition OFF – ON – OFF), the SRT will indicate “complete”.

→ Case 1 above

When all SRT related self-diagnoses show OK results through several different cycles, the SRT will indicate “complete” at the time the respective self-diagnoses have at least one OK result.

→ Case 2 above

If one or more SRT related self-diagnoses showed NG results in 2 consecutive cycles, the SRT will also indicate “complete”.

→ Case 3 above

The previous table shows that the minimum number of cycles for setting SRT as “incomplete” is one (1) for each self-diagnosis (Case 1 and 2) or two (2) for one self-diagnosis (Case 3). However, in preparation for the State emissions inspection, it is unnecessary of each self-diagnosis to be executed twice (Case 3) because of the following reasons;


- The SRT will indicate “complete” at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires “complete” of the SRT only with OK self-diagnosis result.
- When, during SRT driving pattern, 1st trip DTC (NG) is detected prior to “complete” of SRT, the self-diagnosis memory must be erased from ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate “incomplete”.

NOTE:

SRT can be set as “complete” together with the DTC(s). Therefore, DTC check must always be carried out prior to the State emission inspection even though the SRT indicates “complete”.

SRT Service Procedure

If a vehicle has been rejected for the State emissions inspection due to one or more SRT items indicating "incomplete", review the following flowchart diagnostic sequence.



*1 [EC-51](#)

*2 [EC-55](#)

*3 [EC-56](#)

How to Display SRT Code

1. **With CONSULT-II**
 Selecting "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT-II.
 For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT-II screen; for items whose SRT codes are not set, "INCMP" is displayed.
2. **With GST**
 Selecting Mode 1 with GST (Generic Scan Tool)

A sample of CONSULT-II display for SRT code is shown below.

“INCMP” means the self-diagnosis is incomplete and SRT is not set.
“CMPLT” means the self-diagnosis is complete and SRT is set.

SRT STATUS	
CATALYST	CMPLT
EVAP SYSTEM	INCMP
HO2S HTR	CMPLT
HO2S	CMPLT
EGR SYSTEM	INCMP

SEF713Y

How to Set SRT Code

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions.

With CONSULT-II

Perform corresponding DTC confirmation procedure one by one based on “Performance Priority” in the table on [EC-52, "SRT Item"](#).


Without CONSULT-II

The most efficient driving pattern in which SRT codes can be properly set is explained on [EC-57, "Driving Pattern"](#). The driving pattern should be performed one or more times to set all SRT codes.

Driving Pattern

Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws. Refer to next page for more information and explanation of chart.

Driving pattern



PBIB1400E

A
EC
C
D
E
F
G
H
I
J
K
L
M

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[KA24DE]

- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.
Zone A refers to the range where the time required, for the diagnosis under normal conditions*, is the shortest.
Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

*: Normal conditions refer to the following:

- Sea level
- Flat road
- Ambient air temperature: 20 - 30°C (68 - 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.
Under different conditions [For example: ambient air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1:

- The engine is started at the engine coolant temperature of -10 to 35°C (14 to 95°F) (where the voltage between the ECM terminal 59 and ground is 3.0 - 4.3V).**
- The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminal 59 and ground is lower than 1.4V).**
- The engine is started at the tank fuel temperature of warmer than 0°C (32°F) (where the voltage between the ECM terminal 60 and ground is less than 4.1V).**

Pattern 2:

- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

Pattern 3:

- The driving pattern outlined in *2 must be repeated at least 3 times.

Pattern 4:

- Tests are performed after the engine has been operated for at least 17 minutes.
- The accelerator pedal must be held very steady during steady-state driving.
- If the accelerator pedal is moved, the test must be conducted all over again.

*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.


*2: Operate the vehicle in the following driving pattern.

- Decelerate vehicle to 0 km/h (0 MPH) and let engine idle.
- Repeat driving pattern shown below at least 10 times.
- **During acceleration, hold the accelerator pedal as steady as possible.**
- Repeat steps 1 and 2 until the EGR system SRT is set.

*3: Checking the vehicle speed with GST is advised.

Suggested upshift speeds for M/T models

Shown below are suggested vehicle speeds for shifting into a higher gear. These suggestions relate to fuel economy and vehicle performance. Actual upshift speeds will vary according to road conditions, the weather and individual driving habits.



	For normal acceleration in low altitude areas [less than 1,219 m (4,000 ft)]:		For quick acceleration in low altitude areas and high altitude areas [over 1,219 m (4,000 ft)]:
Gear change	ACCEL shift point km/h (MPH)	CRUISE shift point km/h (MPH)	km/h (MPH)
1st to 2nd	24 (15)	24 (15)	24 (15)

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[KA24DE]

2nd to 3rd	40 (25)	29 (18)	40 (25)
3rd to 4th	58 (36)	48 (30)	64 (40)
4th to 5th	64 (40)	63 (39)	72 (45)

Suggested Maximum Speed in Each Gear

Downshift to a lower gear if the engine is not running smoothly, or if you need to accelerate.

Do not exceed the maximum suggested speed (shown below) in any gear. For level road driving, use the highest gear suggested for that speed. Always observe posted speed limits and drive according to the road conditions to ensure safe operation. Do not over-rev the engine when shifting to a lower gear as it may cause engine damage or loss of vehicle control.

Gear	km/h (MPH) 2WD (AUTO mode)
1st	50 (30)
2nd	95 (60)

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

The following is the information specified in Mode 6 of SAE J1979.

The test value is a parameter used to determine whether a system/circuit diagnostic test is “OK” or “NG” while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items (9 test items).

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

X: Applicable —: Not applicable

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
CATALYST	Three way catalyst function	01H	01H	Max.	X
		02H	81H	Min.	X
EVAP SYSTEM	EVAP control system (Small leak)	05H	03H	Max.	X
	EVAP control system purge flow monitoring	06H	83H	Min.	X
HO2S	Heated oxygen sensor 1	09H	04H	Max.	X
		0AH	84H	Min.	X
		0BH	04H	Max.	X
		0CH	04H	Max.	X
	Heated oxygen sensor 2	0DH	04H	Max.	X
		19H	86H	Min.	X
		1AH	86H	Min.	X
		1BH	06H	Max.	X
HO2S HTR	Heated oxygen sensor 1 heater	1CH	06H	Max.	X
		29H	08H	Max.	X
	Heated oxygen sensor 2 heater	2AH	88H	Min.	X
		2DH	0AH	Max.	X
		2EH	8AH	Min.	X

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[KA24DE]

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
EGR SYSTEM	EGR function	31H	8CH	Min.	X
		32H	8CH	Min.	X
		33H	8CH	Min.	X
		34H	8CH	Min.	X
		35H	0CH	Max.	X
	EGRC-BPT valve function	36H	0CH	Max.	X
		37H	8CH	Min.	X

HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

How to Erase DTC (With CONSULT-II)

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it ON (engine stopped) again.
2. Turn CONSULT-II "ON" and touch "ENGINE".
3. Touch "SELF-DIAG RESULTS".
4. Touch "ERASE". (The DTC in the ECM will be erased.)

How to erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.

SELECT SYSTEM

ENGINE

SELECT DIAG MODE

WORK SUPPORT

SELF-DIAG RESULTS

DATA MONITOR

DATA MONITOR (SPEC)

ACTIVE TEST

DTC & SRT CONFIRMATION

ECM PART NUMBER

SELF DIAG RESULTS

DTC RESULTS	TIME
MAF SEN/CIRCUIT [P0101]	0

2. Turn CONSULT-II "ON" and touch "ENGINE".
3. Touch "SELF-DIAG RESULTS".
4. Touch "ERASE". (The DTC in the ECM will be erased.)

LEC030A

The emission-related diagnostic information can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

How to Erase DTC (With GST)

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it ON (engine stopped) again.
2. Select Mode 4 with GST (Generic Scan Tool).

The emission-related diagnostic information in the ECM can be erased by selecting Mode 4 with GST (Generic Scan Tool).

NOTE:

- If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.
- The following data are cleared when the ECM memory is erased.
 1. Diagnostic trouble codes
 2. 1st trip diagnostic trouble codes
 3. Freeze frame data
 4. 1st trip freeze frame data
 5. System readiness test (SRT) codes
 6. Test values
 7. Others

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.


Malfunction Indicator Lamp (MIL)

DESCRIPTION

UBS008MB




The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MIL does not light up, refer to [DI-22, "WARNING LAMPS"](#) or see [EC-555, "DATA LINK CONNECTOR"](#).
2. When the engine is started, the MIL should go off. If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.



ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following two functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in "ON" position 	BULB CHECK	This function checks the MIL bulb for damage (blown, open circuit, etc.). If the MIL does not come on, check MIL circuit.
	Engine stopped 		
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MIL will light up to inform the driver that a malfunction has been detected. The following malfunctions will light up or blink the MIL in the 1st trip. <ul style="list-style-type: none"> ● "Misfire (Possible three way catalyst damage)" ● "One trip detection diagnoses"

DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MIL on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to [DI-22, "WARNING LAMPS"](#) or see [EC-555, "DATA LINK CONNECTOR"](#).

DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MIL	Condition
ON	When the malfunction is detected or the ECM's CPU is malfunctioning.
OFF	No malfunction.

OBD System Operation Chart

UBS008MC

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DETECTABLE ITEMS

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MIL will come on. For details, refer to [EC-48, "Two Trip Detection Logic"](#).
- The MIL will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The "TIME" in "SELF-DIAGNOSTIC RESULTS" mode of CONSULT-II will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in "OK" for the 2nd trip.

SUMMARY CHART

Items	Fuel Injection System	Misfire	Other
MIL (goes off)	3 (pattern B)	3 (pattern B)	3 (pattern B)
DTC, Freeze Frame Data (no display)	80 (pattern C)	80 (pattern C)	40 (pattern A)
1st Trip DTC (clear)	1 (pattern C), *1	1 (pattern C), *1	1 (pattern B)
1st Trip Freeze Frame Data (clear)	*1, *2	*1, *2	1 (pattern B)


For details about patterns "B" and "C" under "Fuel Injection System" and "Misfire", see [EC-64](#).

For details about patterns "A" and "B" under "Other", see [EC-66](#).

*1: Clear timing is at the moment OK is detected.

*2: Clear timing is when the same malfunction is detected in the 2nd trip.

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS FOR “MIS-FIRE” <EXHAUST QUALITY DETERIORATION>, “FUEL INJECTION SYSTEM”



*1: When the same malfunction is detected in two consecutive trips, MIL will light up.

*2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)

*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.

*6: The 1st trip DTC and the 1st trip freeze frame data will be cleared at the moment OK is detected.

*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

*8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

EXPLANATION FOR DRIVING PATTERNS FOR “MISFIRE <EXHAUST QUALITY DETERIORATION>”, “FUEL INJECTION SYSTEM”

Driving Pattern B

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MIL will go off when the B counter reaches 3. (*2 in “OBD SYSTEM OPERATION CHART”)

Driving Pattern C

Driving pattern C means the vehicle operation as follows:

1. The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

Calculated load value: (Calculated load value in the freeze frame data) $\times (1 \pm 0.1)$ [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), “T” should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), “T” should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:


Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)

- The C counter will be cleared when the malfunction is detected regardless of (1).
- The C counter will be counted up when (1) is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"



*1: When the same malfunction is detected in two consecutive trips, MIL will light up.

*2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)


*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.

*6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.

*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

Driving Pattern A



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

Driving Pattern B

Driving pattern B means the vehicle operation as follows:


All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MIL will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").


TROUBLE DIAGNOSIS

Trouble Diagnosis Introduction INTRODUCTION

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no incidents such as vacuum leaks, fouled spark plugs, or other incidents with the engine.




It is much more difficult to diagnose an incident that occurs intermittently rather than continuously. Most intermittent incidents are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.



A visual check only may not find the cause of the incidents. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on [EC-68](#).


Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such incidents, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on next page should be used.

Start your diagnosis by looking for "conventional" malfunctions first. This will help troubleshoot driveability malfunctions on an electronically controlled engine vehicle.



WORK FLOW

Flow Chart



SEF510ZG

*1: [EC-72, "Fail-safe Chart"](#)

*2: If time data of "SELF-DIAG RESULTS" is other than "0" or "1" refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#)

*3: If the incident cannot be duplicated, refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) 5.

*4: If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to [EC-121, "POWER SUPPLY CIRCUIT FOR ECM"](#).

*5: If the malfunctioning part cannot be found, refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

*6: [EC-57, "Driving Pattern"](#)

*7: [EC-116, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#)

TROUBLE DIAGNOSIS

[KA24DE]

Description for Work Flow

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the EC-70. "DIAGNOSTIC WORKSHEET" .
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II or GST) the (1st trip) DTC and the (1st trip) freeze frame data, then erase the code and the data. (Refer to EC-60. "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION" .) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV. Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-83. "Symptom Matrix Chart" .) Also check related service bulletins for information.
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform "INCIDENT SIMULATION TESTS" in GI-25. "How to Perform Efficient Diagnosis for an Electrical Incident" . If the malfunction code is detected, skip STEP IV and perform STEP V.
STEP IV	Try to detect the (1st trip) DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT-II or GST. During the (1st trip) DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform "INCIDENT SIMULATION TESTS" in refer to GI-25. "How to Perform Efficient Diagnosis for an Electrical Incident" . In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the (1st trip) DTC detection.
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to Trouble Diagnosis for DTC PXXXX. If the normal code is indicated, proceed to EC-73. "Basic Inspection" . If CONSULT-II is available, perform "DATA MONITOR (SPEC)" mode with CONSULT-II and proceed to EC-116. "TROUBLE DIAGNOSIS - SPECIFICATION VALUE" . (If malfunction is detected, proceed to "Repair/replace".) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-83 .)
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-91. "ECM Terminals and Reference Value" , EC-112. "CONSULT-II Reference Value in Data Monitor Mode" . The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to "CIRCUIT INSPECTION" in GI-25. "How to Perform Efficient Diagnosis for an Electrical Incident" . Repair or replace the malfunction parts.
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code [DTC No. P0000] is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM. (Refer to EC-60. "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION" .)

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[KA24DE]

DIAGNOSTIC WORKSHEET

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on [EC-70](#) in order to organize all the information for troubleshooting.

Some conditions may cause the malfunction indicator lamp to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere.

KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE Road conditions
HOW Operating conditions,
 Weather conditions,
 Symptoms

SEF907L

Worksheet Sample

Customer name MR/MS		Model & Year	VIN
Engine #		Trans.	Mileage
Incident Date		Manuf. Date	In Service Date
Fuel and fuel filler cap		<input type="checkbox"/> Vehicle ran out of fuel causing misfire <input type="checkbox"/> Fuel filler cap was left off or incorrectly screwed on.	
Symptoms	<input type="checkbox"/> Startability	<input type="checkbox"/> Impossible to start <input type="checkbox"/> No combustion <input type="checkbox"/> Partial combustion <input type="checkbox"/> Partial combustion affected by throttle position <input type="checkbox"/> Partial combustion NOT affected by throttle position <input type="checkbox"/> Possible but hard to start <input type="checkbox"/> Others []	
	<input type="checkbox"/> Idling	<input type="checkbox"/> No fast idle <input type="checkbox"/> Unstable <input type="checkbox"/> High idle <input type="checkbox"/> Low idle <input type="checkbox"/> Others []	
	<input type="checkbox"/> Driveability	<input type="checkbox"/> Stumble <input type="checkbox"/> Surge <input type="checkbox"/> Knock <input type="checkbox"/> Lack of power <input type="checkbox"/> Intake backfire <input type="checkbox"/> Exhaust backfire <input type="checkbox"/> Others []	
	<input type="checkbox"/> Engine stall	<input type="checkbox"/> At the time of start <input type="checkbox"/> While idling <input type="checkbox"/> While accelerating <input type="checkbox"/> While decelerating <input type="checkbox"/> Just after stopping <input type="checkbox"/> While loading	
Incident occurrence		<input type="checkbox"/> Just after delivery <input type="checkbox"/> Recently <input type="checkbox"/> In the morning <input type="checkbox"/> At night <input type="checkbox"/> In the daytime	
Frequency		<input type="checkbox"/> All the time <input type="checkbox"/> Under certain conditions <input type="checkbox"/> Sometimes	
Weather conditions		<input type="checkbox"/> Not affected	
Weather		<input type="checkbox"/> Fine <input type="checkbox"/> Raining <input type="checkbox"/> Snowing <input type="checkbox"/> Others []	
Temperature		<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold <input type="checkbox"/> Humid °F	
Engine conditions		<input type="checkbox"/> Cold <input type="checkbox"/> During warm-up <input type="checkbox"/> After warm-up Engine speed <div style="text-align: center;"> </div>	
Road conditions		<input type="checkbox"/> In town <input type="checkbox"/> In suburbs <input type="checkbox"/> Highway <input type="checkbox"/> Off road (up/down)	
Driving conditions		<input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While idling <input type="checkbox"/> At racing <input type="checkbox"/> While accelerating <input type="checkbox"/> While cruising <input type="checkbox"/> While decelerating <input type="checkbox"/> While turning (RH/LH) Vehicle speed <div style="text-align: center;"> </div>	
Malfunction indicator lamp		<input type="checkbox"/> Turned on <input type="checkbox"/> Not turned on	

LEC031A

TROUBLE DIAGNOSIS

[KA24DE]

UBS008ME

DTC Inspection Priority Chart

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)	
1	● P0101, P0102, P0103 MAF sensor	EC
	● P0112, P0113, P0127 IAT sensor	
	● P0117, P0118, P0125 ECT sensor	
	● P0121, P0122, P0123 TP sensor	
	● P0128 Thermostat function	
	● P0181, P0182, P0183 FTT sensor	
	● P0327, P0328 KS	
	● P0340 CMP sensor	
	● P0460, P0461, P0462, P0463, P1464 Fuel level sensor	
	● P0500 VSS	
	● P0605 ECM	
	● P1400 EGRC-solenoid valve	
	● P1706 PNP switch	
2	● P0031, P0032 HO2S1 heater	C
	● P0037, P0038 HO2S2 heater	
	● P0132, P0133, P0134, P1143, P1144 HO2S1	
	● P0138, P0139, P1146, P1147 HO2S2	
	● P0335, P1336 CKP sensor	
	● P0405, P0406 EGRT sensor	
	● P0441 EVAP control system purge flow monitoring	
	● P0444, P0445, P1444 EVAP canister purge volume control solenoid valve	
	● P0447, P1446, P1448 EVAP canister vent control valve	
	● P0452, P0453 EVAP control system pressure sensor	
	● P0510 CTP switch	
	● P1442 EVAP control system	
	● P1490, P1491 Vacuum cut valve bypass valve	
● P1775, P1776 TCC solenoid valve		
3	● P0171, P0172 Fuel injection system function	D
	● P0300 - P0304 Misfire	
	● P0400, P1402 EGR function	
	● P0402 EGRC-BPT valve	
	● P0420 Three way catalyst function	
	● P0442, P0455, P0456, P1456 EVAP control system	
	● P0505, P0506, P507 ISC system	
	● P1148 Closed loop control	
		E
		F
		G
		H
		I
		J
		K
		L
		M

TROUBLE DIAGNOSIS

[KA24DE]

UBS008MF

Fail-safe Chart

The ECM enters fail-safe mode if any of the following malfunctions is detected due to the open or short circuit. When the ECM enters the fail-safe mode, the MIL illuminates.

DTC No.	Detected items	Engine operating condition in fail-safe mode	
CONSULT-II GST			
P0102 P0103	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.	
P0112 P0113	Intake air temperature sensor	The ECM functions on the assumption that the intake air temperature is 25°C (77°F).	
P0117 P0118	Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch to ON or START. CONSULT-II displays the engine coolant temperature decided by ECM.	
		Condition	Engine coolant temperature decided (CONSULT-II display)
		Just as ignition switch is turned to ON or Start	40°C (104°F)
		More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
		Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
P0122 P0123	Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
		Condition	Driving condition
		When engine is idling	Normal
		When accelerating	Poor acceleration
Unable to access ECM	ECM	ECM fail-safe activating condition The computing function of the ECM was judged to be malfunctioning. When the fail-safe system activates (i.e., if the ECM detects a malfunction condition in the CPU of ECM), the MIL on the instrument panel lights to warn the driver. However it is not possible to access ECM and DTC cannot be confirmed.	
		Engine control with fail-safe When ECM fail-safe is operating, fuel injection, ignition timing, fuel pump operation and IACV-AAC valve operation are controlled under certain limitations.	
			ECM fail-safe operation
		Engine speed	Engine speed will not rise more than 3,000 rpm
		Fuel injection	Simultaneous multiport fuel injection system
		Ignition timing	Ignition timing is fixed at the preset valve
		Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls
		IACV-AAC valve	Full open
		Replace ECM, if ECM fail-safe condition is confirmed.	

Basic Inspection

Precaution:


Perform Basic Inspection without electrical or mechanical loads applied;

- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear window defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.

1. INSPECTION START

1. Check service records for any recent repairs that may indicate a related malfunction, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Vacuum hoses for splits, kinks, or improper connections
 - Wiring for improper connections, pinches, or cuts


With CONSULT-II>>GO TO 2.
With GST>>GO TO 4.



2. CONNECT CONSULT-II TO THE VEHICLE

Connect "CONSULT-II" and CONSULT-II CONVERTER to the data link connector and select "ENGINE" from the menu. Refer to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).

>> GO TO 3.



3. CHECK FI CAM FUNCTION


With CONSULT-II

1. Adjust accelerator wire. Refer to [ACC-2, "Adjusting Accelerator Wire"](#) .
2. Warm up engine to 75°C (167°F).
3. Stop engine and wait at least 5 seconds, then turn ignition switch ON.
4. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
5. When the engine coolant temp is 75 to 85°C (167 to 185°F), confirm the clearance is less than 0.05 mm (0.0020 in), between stopper and throttle drum as shown in the figure.

OK or NG

OK >> GO TO 5.

- NG >> 1. Replace throttle body assembly. Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .
2. GO TO 5.



4. CHECK FI CAM FUNCTION


With GST

1. Adjust accelerator wire. Refer to [ACC-2, "Adjusting Accelerator Wire"](#) .
2. Warm up engine to 75°C (167°F).
3. Stop engine and wait at least 10 seconds, then turn ignition switch ON.
4. Select "MODE 1" with GST.
5. When the engine coolant temp is 75 to 85°C (167 to 185°F), confirm the clearance is less than 0.05 mm (0.0020 in), between stopper and throttle drum as shown in the figure.

OK or NG

OK >> GO TO 12.


- NG >> 1. Replace throttle body assembly. Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .
2. GO TO 12.



5. CHECK IGNITION TIMING

With CONSULT-II

1. Warm up engine to normal operating temperature.
2. Select "IGNITION TIMING ADJ" in "WORK SUPPORT" mode.
3. Touch "START".



4. Check ignition timing at idle using timing light.


Ignition timing 20°±2° BTDC (in "P" or "N" position)

OK or NG

OK >> GO TO 6.

NG >> 1. Adjust ignition timing by turning distributor. Refer to [EC-35, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#) .

2. GO TO 6.



6. CHECK BASE IDLE SPEED

With CONSULT-II

1. Select "IGNITION TIMING ADJ" in "WORK SUPPORT" mode and touch "START".
2. Check idle speed.

750±50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 7.

NG >> 1. Adjust base idle speed by turning idle speed adjusting screw. Refer to [EC-35, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#) .

2. GO TO 7.

IACV-AAC/V ADJ	
ADJ MONITOR	
ENG SPEED	700 rpm
CONDITION SETTING	
IACV-ACC/V	FIXED
MONITOR	
COOLAN TEMP/S	XXX°C
CLSD THL POS	XXX N

SEF714Z

7. CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION (CHECK THROTTLE POSITION SENSOR IDLE POSITION)

 With CONSULT-II

NOTE:

Always check ignition timing and base idle speed before performing the following.

1. Warm up engine to normal operating temperature.
2. Check FI cam. Refer to procedure 3.
3. Stop engine.
4. Turn ignition switch ON.
5. Select "DATA MONITOR" mode with CONSULT-II.
6. Select "CLSD THL/P SW" from the menu.
7. Read "CLSD THL/P SW" signal under the following conditions.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
CLSD THL/P SW	ON

SEF197Y

- Insert a 0.1 mm (0.004 in) and 0.3 mm (0.012 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure and check the signal.
"CLSD THL/P SW" signal should remain "ON" while inserting 0.1 mm (0.004 in) feeler gauge.
"CLSD THL/P SW" signal should remain "OFF" while inserting 0.3 mm (0.012 in) feeler gauge.

OK or NG

- OK >> GO TO 11.
- NG >> GO TO 8.




8. ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-1

With CONSULT-II

NOTE:

- Never adjust throttle adjust screw (TAS).
 - Do not touch throttle drum when checking "CLSD THL/P SW" signal. Doing so may cause an incorrect adjustment.
1. Warm engine up to normal operating temperature.
 2. Check FI cam. Refer to procedure 3.
 3. Stop engine.
 4. Loosen throttle position sensor fixing bolts.
 5. Turn ignition switch ON.
 6. Select "CLSD THL/P SW" in "DATA MONITOR" mode.
 7. Insert a 0.1 mm (0.004 in) feeler gauge between throttle adjust screw and throttle drum as shown in the figure.
 8. Open throttle valve and then close.



9. Check "CLSD THL/P SW" signal. "CLSD THL/P SW" signal should remain "OFF" when the throttle valve is closed. If it is impossible to adjust closed throttle position switch, replace throttle position sensor.

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
CLSD THL/P SW	ON


SEF197Y

9. ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-2

With CONSULT-II

Turn throttle position sensor body counterclockwise until "CLSD THL/P SW" signal switches to "OFF".


>> GO TO 10.



10. ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-3

With CONSULT-II

1. Temporarily tighten sensor body fixing bolts as follows.
 - **Gradually move the sensor body clockwise and stop it when "CLSD THL/P SW" signal switches from "OFF" to "ON" when tightening sensor body fixing bolts.**
2. Make sure two or three times that the signal is "ON" when the throttle valve is closed and "OFF" when it is opened.
3. Remove 0.1 mm (0.004 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge.
4. Make sure two or three times that the signal remains "OFF" when the throttle valve is closed.
5. Tighten throttle position sensor.
6. Check "CLSD THL/P SW" signal again.
 - The signal remains "OFF" while closing throttle valve.**



OK or NG

- OK >> 1. Remove 0.3 mm (0.012 in) feeler gauge.
 2. GO TO 11.
- NG >> GO TO 8.

11. CHECK TARGET IDLE SPEED

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "ENG SPEED" in "DATA MONITOR" mode.
3. Check idle speed.

800±50 rpm (in "P" or "N" position)


OK or NG

- OK >> **INSPECTION END**
- NG >> Adjust idle speed. Refer to [EC-35, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#) .
 Inspection end after adjust idle speed.

12. CHECK IGNITION TIMING

⊗ Without CONSULT-II

1. Warm up engine to normal operating temperature.
2. Stop engine and disconnect throttle position sensor harness connector.
3. Start engine.
4. Rev engine (2,000 to 3,000 rpm) two or three times under no-load and then run engine at idle speed.



5. Check ignition timing at idle using timing light.


Ignition timing : $20^{\circ} \pm 2^{\circ}$ BTDC (in "P" or "N" position)

OK or NG

OK >> GO TO 13.

NG >> 1. Adjust ignition timing by turning distributor. Refer to [EC-35, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#).

2. GO TO 13.



13. CHECK BASE IDLE SPEED

⊗ Without CONSULT-II

Make sure that engine speed falls to the following speed.

750 ± 50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 14.

NG >> 1. Adjust base idle speed by turning idle speed adjusting screw. Refer to [EC-35, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#).

2. GO TO 14.


14. CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION (CHECK THROTTLE POSITION SENSOR IDLE POSITION)

⊗ Without CONSULT-II

NOTE:

Always check ignition timing and base idle speed before performing the following.


1. Warm up engine to normal operating temperature.
2. Check FI cam. Refer to procedure 4.
3. Stop engine.
4. Disconnect closed throttle position switch harness connector.
5. Connect the tester probe to closed throttle position switch terminals 5 and 6.
6. Check harness continuity under the following conditions.



- Insert the 0.1 mm (0.004 in) and 0.3 mm (0.012 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure.
“Continuity should exist” while inserting 0.1 mm (0.004 in) feeler gauge.
“Continuity should not exist” while inserting 0.3 mm (0.012 in) feeler gauge.

OK or NG

- OK >> GO TO 18.
 NG >> GO TO 15.




15. ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-1

⊗ Without CONSULT-II

NOTE:


- Never adjust throttle adjust screw (TAS).
 - Do not touch throttle drum when checking "continuity". Doing so may cause an incorrect adjustment.
1. Warm engine up to normal operating temperature.
 2. Check FI cam. Refer to procedure 4.
 3. Stop engine.
 4. Loosen throttle position sensor fixing bolts.
 5. Disconnect closed throttle position sensor harness connector.
 6. Insert 0.1 mm (0.004 in) feeler gauge between the throttle adjust screw and throttle drum as shown in the figure.
 7. Open throttle valve then close.



8. Check continuity between closed throttle position switch terminal 5 and 6.
The continuity should not exist while closing the throttle position sensor body.
 If it is impossible to adjust closed throttle position switch, replace throttle position sensor.

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 16.




16. ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-2

⊗ Without CONSULT-II

Turn throttle position sensor body counterclockwise until continuity does not exist.


>> GO TO 17.



17. ADJUSTMENT THROTTLE POSITION SENSOR IDLE POSITION-3

⊗ Without CONSULT-II

- Temporarily tighten sensor body fixing bolts as follows.
 - Gradually move the sensor body clockwise and stop it when the continuity comes to exist, then tighten sensor body fixing bolts.
- Make sure two or three times that the continuity exists when the throttle valve is closed and continuity does not exist when it is opened.
- Remove 0.1 mm (0.004 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge.
- Make sure two or three times that continuity does not exist when the throttle valve is closed.
- Tighten throttle position sensor.
- Check the continuity again.
 - Continuity does not exist while closing the throttle valve.



OK or NG

- OK >> GO TO 18.
 NG >> GO TO 15.

18. REINSTALLATION

⊗ Without CONSULT-II

- Remove 0.3 mm (0.012 in) feeler gauge.
- Reconnect throttle position sensor harness connector and closed throttle position switch harness connector.
- Rev engine (2,000 to 3,000 rpm) two or three times under no-load and then run engine at idle speed.

>> GO TO 19.

19. RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY


⊗ Without CONSULT-II

NOTE:

Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.

- Start engine.
- Warm up engine to normal operating temperature.
- Stop engine. (Turn ignition switch "OFF".)
- Turn ignition switch "ON" and wait at least 5 seconds.
- Turn ignition switch "OFF" and wait at least 5 seconds.
- Repeat steps 4 and 5, 20 times.

>> GO TO 20.



20. CHECK TARGET IDLE SPEED

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.

800±50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 21.

NG >> 1. Adjust target idle speed. Refer to [EC-35, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#).

2. GO TO 21.

21. ERASE UNNECESSARY DTC

After this inspection, unnecessary DTC No. might be displayed.

Erase the stored memory in ECM and TCM.

Refer to [EC-60, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

>> INSPECTION END

**Symptom Matrix Chart
SYSTEM — ENGINE CONTROL SYSTEM**

UBS008MH

		SYMPTOM											Reference page		
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION		EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	EC-541
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			EC-47
	Injector circuit	1	1	2	3	2		2	2			2			EC-532
	Evaporative emission system	3	3	4	4	4	4	4	4	4	4	4			EC-556
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		EC-572
	Incorrect idle speed adjustment	3	3				1	1	1	1		1			EC-73
	IACV-AAC valve circuit	1	1	2	3	3	2	2	2	2		2		2	EC-393 , EC-398 , EC-403
	IACV-FICD solenoid valve circuit	2	2	3	3	3	3	3	3	3		3			EC-550
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			EC-73
	Ignition circuit	1	1	2	2	2		2	2			2			EC-525

TROUBLE DIAGNOSIS

[KA24DE]

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
EGR	EGRC-solenoid valve circuit		2	2	3	3						3			EC-452
	EGR system	2	1	2	3	3	3	2	2	3		3			EC-275 , EC-285 , EC-458
Main power supply and ground circuit		2	2	3	3	3		3	3		2	3		2	EC-121
Air conditioner circuit		2	2	3	3	3	3	3	3	3		3		2	MTC-25

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Camshaft position sensor circuit		2	2	3	3	3		3	3			3			EC-268
Mass air flow sensor circuit		1	1	2	2	2		2	2			2			EC-136 , EC-149
Heated oxygen sensor 1 circuit			1	2	3	2		2	2			2			EC-186 , EC-192 , EC-202 , EC-417 , EC-422
Engine coolant temperature sensor circuit		1	1	2	3	2	3	2	2	3		2			EC-154 , EC-174
Throttle position sensor circuit			1	2		2	2	2	2	2		2			EC-159 , EC-168

TROUBLE DIAGNOSIS

[KA24DE]

	SYMPTOM													Reference page
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Incorrect throttle position sensor adjustment		3	1		1	1	1	1	1		1			EC-73
Vehicle speed sensor circuit		2	3		3						3			EC-388
Knock sensor circuit			2								3			EC-259
ECM	2	2	3	3	3	3	3	3	3	3	3			EC-72 , EC-415
Start signal circuit	2													EC-537
PNP switch circuit			3		3		3	3			3			EC-520
Power steering oil pressure switch circuit		2					3	3						EC-546

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[KA24DE]

SYSTEM — ENGINE MECHANICAL & OTHER

		SYMPTOM												Reference page		
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA		
Fuel	Fuel tank	5	5												FL-3	
	Fuel piping			5	5	5		5	5			5				
	Vapor lock															
	Valve deposit															
	Poor fuel (Heavy weight gaso- line, Low octane)	5		5	5	5		5	5			5			—	
Air	Air duct		5													
	Air cleaner															
	Air leakage from air duct (Mass air flow sensor — throttle body)			5	5		5		5	5			5			
	Throttle body, Throttle wire	5			5		5				5					ACC-2
	Air leakage from intake manifold/ Collector/Gasket														—	
Crank- ing	Battery	1	1	1		1		1	1			1		1	SC-4	
	Generator circuit														SC-24	
	Starter circuit	3													SC-9	
	Flywheel	6													EM-46	
	PNP switch	4													—	

1 - 6: The numbers refer to the order of inspection.
(continued on next page)






TROUBLE DIAGNOSIS

[KA24DE]

		SYMPTOM												Reference page
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATSWATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA
Engine	Cylinder head	5	5	5	5	5		5	5			5	3	EM-30, EM-46
	Cylinder head gasket										4			
	Cylinder block												4	
	Piston													
	Piston ring	6	6	6	6	6		6	6			6		
	Connecting rod													
	Bearing													
	Crankshaft													
Valve mechanism	Timing chain	5	5	5	5	5		5	5			5	3	EM-19, EM-30
	Camshaft													
	Intake valve													
	Exhaust valve													
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	5	5	5	5	5		5	5			5		EX-3
	Three way catalyst													
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	5	5	5	5	5		5	5			5		EM-16, LU-7
	Oil level (Low)/Filthy oil													
Cooling	Radiator/Hose/Radiator filler cap													CO-7 MA-16
	Thermostat									5				
	Water pump	5	5	5	5	5		5	5		4	5		
	Water gallery													
	Coolant level (low)/Contaminated coolant													



1 - 6: The numbers refer to the order of inspection.

Engine Control Component Parts Location




TROUBLE DIAGNOSIS

[KA24DE]




A
EC
C
D
E
F
G
H
I
J
K
L
M

Circuit Diagram



ECM Harness Connector Terminal Layout

UBS008MK




ECM Terminals and Reference Value


PREPARATION

UBS008ML


1. ECM is located behind the instrument lower cover. For this inspection:
 - Remove instrument lower cover.



2. Remove ECM harness protector.



3. Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.
 - Open harness securing clip to make testing easier.
 - Use extreme care not to touch 2 pins at one time.
 - Data is for comparison and may not be exact.



ECM INSPECTION TABLE







Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



TROUBLE DIAGNOSIS

[KA24DE]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	PU/W	Ignition signal	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 0.5V★  <small>SEF186T</small>
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	0.2 - 1.0V★  <small>SEF187T</small>
2	B	Ignition check	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	12 - 14V★  <small>SEF188T</small>
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	12 - 13V★  <small>SEF189T</small>
3	P/L	Tachometer	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 1V★  <small>SEF190T</small>
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	0.5 - 2V★  <small>SEF191T</small>


TROUBLE DIAGNOSIS

[KA24DE]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	LG/R	ECM relay (Self shut-off)	[Engine is running] [Ignition switch OFF] ● For a few seconds after turning ignition switch OFF	0 - 1V
			[Ignition switch OFF] ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
5	R/Y	EVAP canister purge volume control solenoid valve	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)★ 
			[Engine is running] ● Engine speed is 2,000 rpm (More than 200 seconds after starting engine)	12 - 13V★ 
10	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
11	W/R	Fuel pump relay	[Ignition switch ON] ● For 5 seconds after turning ignition switch ON.	0 - 1V
			[Engine is running] [Ignition switch ON] ● More than 5 seconds after turning ignition switch ON	BATTERY VOLTAGE (11 - 14V)
12	P	Air conditioner relay	[Engine is running] ● Both A/C switch and blower switch are ON* *: Any mode except "OFF", ambient air temperature above 10°C (50°F).	Approximately 0V
			[Engine is running] ● A/C switch is OFF	BATTERY VOLTAGE (11 - 14V)
18	R/W	Malfunction indicator lamp	[Ignition switch ON]	0 - 1V
			[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)
19	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
20	L/OR	Start signal	[Ignition switch ON]	Approximately 0V
			[Ignition switch START]	BATTERY VOLTAGE (11 - 14V)
21	G/R	Air conditioner dual-pressure switch	[Engine is running] ● Both air conditioner switch and blower switch are ON (Compressor operates)	Approximately 0V
			[Engine is running] ● Air conditioner switch is OFF	BATTERY VOLTAGE (11 - 14V)







TROUBLE DIAGNOSIS

[KA24DE]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22	L/B	Park/neutral position (PNP) switch	[Ignition switch ON] ● Gear position is neutral	Approximately 0V
			[Ignition switch ON] ● Except the above gear position	Approximately 5V
23	L	Throttle position sensor	[Ignition switch ON] ● Warm-up condition ● Accelerator pedal fully released	0.2 - 0.8V
			[Ignition switch ON] ● Engine stopped ● Accelerator pedal fully depressed	3.5 - 4.5V
24	W/G	Ignition switch	[Ignition switch OFF]	0V
			[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
25	B/Y	ECM ground	[Engine is running] ● Idle speed	Engine ground
28	BR/W	Throttle position switch (Closed position)	[Ignition switch ON] ● Warm-up condition ● Accelerator pedal released	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch ON] ● Engine stopped ● Accelerator pedal depressed	Approximately 0V
29	G/B	Vehicle speed sensor	[Engine is running] ● Lift up the vehicle ● In 2nd gear position ● 40 km/h (25 MPH)	1 - 4V★ 
32	B/Y	ECM ground	[Engine is running] ● Idle speed	Engine ground
39	GY/R	Power steering oil pressure switch	[Engine is running] ● Steering wheel is fully turned	Approximately 0V
			[Engine is running] ● Steering wheel is not turned	Approximately 5V
42	BR	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	B/W	Sensors' ground	[Engine is running] ● Idle speed	Approximately 0V

TROUBLE DIAGNOSIS

[KA24DE]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
44 48	PU PU	Camshaft position sensor (Reference signal)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>0.2 - 0.5V★ (V)</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>0 - 0.5V★ (V)</p> 
46	OR/B	Fuel level sensor	[Ignition switch ON]	<p>Approximately 0 - 4.8V Output voltage varies with fuel level.</p>
47	L	Crankshaft position sensor (OBD)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 0V★ (V)</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 0V★ (V)</p> 
49	LG	Camshaft position sensor (Position signal)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 2.6V★ (V)</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 2.5 - 2.6V★ (V)</p> 
50	B	Heated oxygen sensor 1	[Engine is running]	<p>0 - Approximately 1.0V (Periodically change)</p>

A
EC
C
D
E
F
G
H
I
J
K
L
M





TROUBLE DIAGNOSIS

[KA24DE]

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
54	R	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	0.9 - 1.8V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm	1.9 - 2.3V
55	G	Mass air flow sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
56	OR	Heated oxygen sensor 2	[Engine is running] ● Warm-up condition ● Revving engine from idle up to 3,000 rpm quickly after the following conditions are met. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load.	0 - Approximately 1.0V
59	LG/R	Engine coolant temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature
60	Y/B	Fuel tank temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with fuel temperature
61	PU/R	Intake air temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with intake air temperature
62	Y	EVAP control system pressure sensor	[Ignition switch ON]	1.8 - 4.8V
63	G/OR	EGR temperature sensor	[Engine is running] ● Warm-up condition ● Idle speed	Less than 4.5V
			[Engine is running] ● Warm-up condition ● EGR system is operating	0 - 1.5V
64	W	Knock sensor	[Engine is running] ● Idle speed	Approximately 2.4V
66	B	Fuel level sensor ground	[Engine is running] ● Idle speed	Approximately 0V
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P			
69	LG/R	Data link connector	[Ignition switch ON] ● CONSULT-II or GST is disconnected.	Approximately 2V
80	SB	Power supply (Back-up)	[Ignition switch OFF]	BATTERY VOLTAGE (11 - 14V)

TROUBLE DIAGNOSIS

[KA24DE]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	OR/L	IACV-AAC valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>10.5 - 11.5V★ (V)</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>1 - 13V★ (V)</p> 
102 104 109 111	W/B W/R W/L W/PU	Injector No. 1 Injector No. 3 Injector No. 2 Injector No. 4	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★ (V)</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>BATTERY VOLTAGE (11 - 14V)★ (V)</p> 
103	G/W	EGRC-solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 1V
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Revving engine from idle to 3,000 rpm quickly 	BATTERY VOLTAGE (11 - 14V)
108	R/G	EVAP canister vent control valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
116	B/R	ECM ground	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	Engine ground
117	B/P	Current return	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	BATTERY VOLTAGE (11 - 14V)
119	BR/Y	Heated oxygen sensor heater 1	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm. 	Approximately 0.4V
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	BATTERY VOLTAGE (11 - 14V)
120	P/B	Vacuum cut valve bypass valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[KA24DE]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
122	R/B	Heated oxygen sensor heater 2	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 4,000 rpm after the following conditions are met. ● Engine: after warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	Approximately 0.4V
			[Ignition switch ON] <ul style="list-style-type: none"> ● Engine is not running 	BATTERY VOLTAGE (11 - 14V)
124	B/R	ECM ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Engine ground

★ : Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

TROUBLE DIAGNOSIS

[KA24DE]

UBS008MM

CONSULT-II Function FUNCTION

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly. *1
Data monitor	Input/Output data in the ECM can be read.
Data monitor (SPEC)	Input/Output of the specification for the basic fuel schedule, AFM, A/F, feedback control valve and the other data monitor items can be read.
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
DTC confirmation	The status of system monitoring tests and the self-diagnosis status/result can be confirmed.
Function test	This mode is used to inform customers when their vehicle condition requires periodic maintenance.
ECM part number	ECM part numbers can be read.

*1 The following emission-related diagnostic information is cleared when the ECM memory is erased.

1. Diagnostic trouble codes
2. 1st trip diagnostic trouble codes
3. Freeze frame data
4. 1st trip freeze frame data
5. System readiness test (SRT) codes
6. Test values
7. Others

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[KA24DE]

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

Item		DIAGNOSTIC TEST MODE							
		WORK SUP-PORT	SELF-DIAGNOSTIC RESULTS		DATA MONITOR	DATA MONITOR (SPEC)	ACTIVE TEST	DTC & SRT CONFIRMATION	
			DTC*1	FREEZE FRAME DATA*2				SRT STATUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS INPUT	Camshaft position sensor		X	X	X	X			
	Mass air flow sensor		X		X	X			
	Engine coolant temperature sensor		X	X	X	X	X		
	Heated oxygen sensor 1		X		X	X		X	X
	Heated oxygen sensor 2		X		X	X		X	X
	Vehicle speed sensor		X	X	X	X			
	Throttle position sensor	X	X		X	X			
	Fuel tank temperature sensor		X		X	X	X		
	EVAP control system pressure sensor		X		X	X			
	EGR temperature sensor		X		X	X			
	Intake air temperature sensor		X		X	X			
	Crankshaft position sensor (OBD)		X						
	Knock sensor		X						
	Fuel level sensor		X		X	X			
	Ignition switch (start signal)				X				
	Closed throttle position switch		X		X				
	Closed throttle position switch (throttle position sensor signal)				X				
	Air conditioner switch				X				
	Park/Neutral position (PNP) switch		X		X				
	Power steering oil pressure switch				X				
Air conditioner pressure switch				X					
Battery voltage				X					
Ambient air temperature switch				X	X				

TROUBLE DIAGNOSIS

[KA24DE]

Item		DIAGNOSTIC TEST MODE							
		WORK SUP-PORT	SELF-DIAGNOSTIC RESULTS		DATA MONITOR	DATA MONITOR (SPEC)	ACTIVE TEST	DTC & SRT CONFIRMATION	
			DTC*1	FREEZE FRAME DATA*2				SRT STATUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS OUTPUT	Injectors				X	X	X		
	Power transistor (Ignition timing)	X			X	X	X		
	IACV-AAC valve	X	X		X	X	X		
	EVAP canister purge volume control solenoid valve		X		X	X	X		X
	Air conditioner relay				X	X			
	Fuel pump relay	X			X	X	X		
	EGRC-solenoid valve		X		X	X	X		
	Heated oxygen sensor 1 heater		X		X	X		X	
	Heated oxygen sensor 2 heater		X		X	X		X	
	EVAP canister vent control valve		X		X	X	X		
	Vacuum cut valve bypass valve		X		X	X	X		X
	Calculated load value			X	X	X			


X: Applicable

*1: This item includes 1st trip DTCs.


*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to [EC-51](#).

CONSULT-II INSPECTION PROCEDURE

1. Turn ignition switch OFF.
2. Connect "CONSULT-II" and CONSULT-II CONVERTER to data link connector which is located behind the fuse box cover.




3. Turn ignition switch ON.
4. Touch "START(NISSAN BASED VHCL)".
If ENGINE is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



TROUBLE DIAGNOSIS


[KA24DE]

5. Touch "ENGINE".



6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual.



WORK SUPPORT MODE

Work Item

WORK ITEM	CONDITION	USAGE
TP SW/TP SEN IDLE POSI ADJ	<ul style="list-style-type: none"> FOLLOW THE BASIC INSPECTION IN THE SERVICE MANUAL 	When adjusting the idle throttle position
IGNITION TIMING ADJ	<ul style="list-style-type: none"> IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CRANKSHAFT POSITION SENSOR. 	When adjusting initial ignition timing
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line
SELF-LEARNING CONT	<ul style="list-style-type: none"> THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT. 	When clearing the coefficient of self-learning value

TROUBLE DIAGNOSIS

[KA24DE]

WORK ITEM	CONDITION	USAGE
EVAP SYSTEM CLOSE	<p>OPEN THE VACUUM CUT VALVE BYPASS VALVE AND CLOSE THE EVAP CANISTER VENT CONTROL VALVE IN ORDER TO MAKE EVAP SYSTEM CLOSE UNDER THE FOLLOWING CONDITIONS.</p> <ul style="list-style-type: none"> ● BATTERY VOLTAGE IS SUFFICIENT. ● IGN SW "ON" ● ENGINE NOT RUNNING ● AMBIENT TEMPERATURE IS ABOVE 0°C (32°F). ● NO VACUUM AND NO HIGH PRESSURE IN EVAP SYSTEM ● TANK FUEL TEMP. IS MORE THAN 0°C (32°F). ● WITHIN 10 MINUTES AFTER STARTING "EVAP SYSTEM CLOSE" <p>WHEN TRYING TO EXECUTE "EVAP SYSTEM CLOSE" UNDER THE CONDITIONS ABOVE, CONSULT-II WILL DISCONTINUE AND DISPLAY INSTRUCTIONS.</p> <p>NOTE: WHEN STARTING ENGINE, CONSULT-II MAY DISPLAY "BATTERY VOLTAGE IS LOW. CHARGE BATTERY", EVEN WHEN USING A CHARGED BATTERY.</p>	When detecting EVAP vapor leak point of EVAP system
TARGET IDLE RPM ADJ*	● IDLE CONDITION	When setting target idle speed

*: This function is not necessary in the usual service procedure.

SELF-DIAG RESULTS MODE

Self Diagnostic Item

Regarding items of "DTC and 1st trip DTC", refer to [EC-17, "INDEX FOR DTC"](#).

Freeze Frame Data and 1st Trip Freeze Frame Data

Freeze frame data item*	Description
DIAG TROUBLE CODE [PXXXX]	● Engine Control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to EC-17, "INDEX FOR DTC" .)
FUEL SYS-B1	<ul style="list-style-type: none"> ● "Fuel injection system status" at the moment a malfunction is detected is displayed. ● One mode in the following is displayed. "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	● The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	● The engine coolant temperature at the moment a malfunction is detected is displayed.
S-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Short-term fuel trim" at the moment a malfunction is detected is displayed. ● The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
L-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Long-term fuel trim" at the moment a malfunction is detected is displayed. ● The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
ENGINE SPEED [rpm]	● The engine speed at the moment a malfunction is detected is displayed.
VEHICLE SPEED [km/h] or [mph]	● The vehicle speed at the moment a malfunction is detected is displayed.
ABSOL TH-P/S [%]	● The throttle valve opening angle at the moment a malfunction is detected is displayed.

TROUBLE DIAGNOSIS

[KA24DE]

Freeze frame data item*	Description
B/FUEL SCHDL [msec]	<ul style="list-style-type: none"> The base fuel schedule at the moment a malfunction is detected is displayed.
INT/A TEMP SE [°C] or [°F]	<ul style="list-style-type: none"> The intake air temperature at the moment a malfunction is detected is displayed.

*: The items are the same as those of 1st trip freeze frame data.

DATA MONITOR MODE

Monitored Item

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks
ENG SPEED [rpm]	×	×	<ul style="list-style-type: none"> Indicates the engine speed computed from the REF signal (180° signal) of the camshaft position sensor. 	<ul style="list-style-type: none"> Accuracy becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated.
MAS A/F SE-B1 [V]	×	×	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
B/FUEL SCHDL [msec]		×	<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	
A/F ALPHA-B1 [%]		×	<ul style="list-style-type: none"> Indicates the mean value of the air-fuel ratio feedback correction factor per cycle. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control.
COOLAN TEMP/S [°C] or [°F]	×	×	<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
HO2S1 (B1) [V]	×	×	<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 1 is displayed. 	
HO2S2 (B1) [V]	×	×	<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 2 is displayed. 	
HO2S1 MNTR (B1) [RICH/LEAN]	×		<ul style="list-style-type: none"> Display of heated oxygen sensor 1 signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. 	<ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously.
HO2S2 MNTR (B1) [RICH/LEAN]	×		<ul style="list-style-type: none"> Display of heated oxygen sensor 2 signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
VHCL SPEED SE [km/h] or [mph]	×	×	<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed sensor signal is displayed. 	
BATTERY VOLT [V]	×	×	<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 	

TROUBLE DIAGNOSIS

[KA24DE]

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks	
THRTL POS SEN [V]	×	×	● The throttle position sensor signal voltage is displayed.		A EC
FUEL T/TMP SE [°C] or [°F]	×		● The fuel temperature judged from the fuel tank temperature sensor signal voltage is displayed.		C
INT/A TEMP SE [°C] or [°F]	×	×	● The intake air temperature determined by the signal voltage of the intake air temperature sensor is indicated.		D
EGR TEMP SEN [V]	×	×	● The signal voltage of the EGR temperature sensor is displayed.		E
EVAP SYS PRES [V]	×		● The signal voltage of EVAP control system pressure sensor is displayed.		F
FUEL LEVEL SE [V]	×		● The signal voltage of the fuel level sensor is displayed.		F
START SIGNAL [ON/OFF]	×	×	● Indicates [ON/OFF] condition from the starter signal.	● After starting the engine, [OFF] is displayed regardless of the starter signal.	G
CLSD THL POS [ON/OFF]	×	×	● Indicates idle position [ON/OFF] computed by ECM according to the throttle position sensor signal.		H
CLSD THL/P SW [ON/OFF]	×		● Indicates mechanical contact [ON/OFF] condition of the closed throttle position switch.		H
AIR COND SIG [ON/OFF]	×	×	● Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioning signal.		I
P/N POSI SW [ON/OFF]	×	×	● Indicates [ON/OFF] condition from the PNP switch signal.		J
PW/ST SIGNAL [ON/OFF]	×	×	● Indicates [ON/OFF] condition of the power steering oil pressure switch determined by the power steering oil pressure switch signal.		K
IGNITION SW [ON/OFF]	×		● Indicates [ON/OFF] condition from ignition switch.		L
INJ PULSE-B1 [msec]		×	● Indicates the actual fuel injection pulse width compensated by ECM according to the input signals.	● When the engine is stopped, a certain computed value is indicated.	M
IGN TIMING [BTDC]		×	● Indicates the ignition timing computed by ECM according to the input signals.		
CAL/LD VALUE [%]			● "Calculated load value" indicates the value of the current airflow divided by peak airflow.		
ABSOL TH·P/S [%]			● "Absolute throttle position sensor" indicates the throttle opening computed by ECM according to the signal voltage of the throttle position sensor.		
MASS AIRFLOW [g·m/s]			● Indicates the mass airflow computed by ECM according to the signal voltage of the mass air flow sensor.		
IACV-AAC/V [%]		×	● Indicates the IACV-AAC valve control value computed by ECM according to the input signals.		

TROUBLE DIAGNOSIS

[KA24DE]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	Description	Remarks
PURG VOL C/V [%]			<ul style="list-style-type: none"> ● Indicates the EVAP canister purge volume control value computed by the ECM according to the input signals. ● The opening becomes larger as the value increases. 	
AIR COND RLY [ON/OFF]		×	<ul style="list-style-type: none"> ● Indicates the air conditioner relay control condition determined by ECM according to the input signals. 	
EGRC SOL/V [ON/OFF] (FLOW/CUT)		×	<ul style="list-style-type: none"> ● Indicates the control condition of the EGRC-solenoid valve determined by ECM according to the input signals. ● ON ... EGR valve is operational ● OFF ... EGR valve operation is cut-off 	
FUEL PUMP RLY [ON/OFF]		×	<ul style="list-style-type: none"> ● Indicates the fuel pump relay control condition determined by ECM according to the input signals. 	
VC/V BYPASS/V [ON/OFF]			<ul style="list-style-type: none"> ● The control condition of the vacuum cut valve bypass valve (determined by ECM according to the input signal) is indicated. ● ON ... Open ● OFF ... Closed 	
VENT CONT/V [ON/OFF]			<ul style="list-style-type: none"> ● The control condition of the EVAP canister vent control valve (determined by ECM according to the input signal) is indicated. ● ON ... Closed ● OFF ... Open 	
HO2S1 HTR (B1) [ON/OFF]			<ul style="list-style-type: none"> ● Indicates [ON/OFF] condition of heated oxygen sensor 1 heater determined by ECM according to the input signals. 	
HO2S2 HTR (B1) [ON/OFF]			<ul style="list-style-type: none"> ● Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to the input signals. 	
VOLTAGE [V]			<ul style="list-style-type: none"> ● Voltage measured by the voltage probe. 	
Frequency [msec] or [Hz] or [%]			<ul style="list-style-type: none"> ● Pulse width, frequency or duty cycle measured by the pulse probe. 	<ul style="list-style-type: none"> ● Only “#” is displayed if item is unable to be measured. ● Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

TROUBLE DIAGNOSIS

[KA24DE]

DATA MONITOR (SPEC) MODE

Monitored Item

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks
ENG SPEED [rpm]	×	×	<ul style="list-style-type: none"> Indicates the engine speed computed from the REF signal (180° signal) of the camshaft position sensor. 	
MAS A/F SE-B1 [V]	×	×	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor specification is displayed. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.
B/FUEL SCHDL [msec]			<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.
A/F ALPHA-B1 [%]		×	<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When engine is running specification range is indicated. This data also includes the data for the air-fuel ratio learning control.

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

ACTIVE TEST MODE

Test Item

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Fuel injectors Heated oxygen sensor 1
IGNITION TIMING	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Adjust initial ignition timing
IACV-AAC/V OPENING	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. Change the IACV-AAC valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> Harness and connector IACV-AAC valve
POWER BALANCE	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. Air conditioner switch "OFF" Shift lever "N" Cut off each injector signal one at a time using CONSULT-II. 	Engine runs rough or dies.	<ul style="list-style-type: none"> Harness and connector Compression Injectors Power transistor Spark plugs Ignition coils
ENG COOLANT TEMP	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the engine coolant temperature indication using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Engine coolant temperature sensor Fuel injectors
FUEL PUMP RELAY	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the fuel pump relay "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> Harness and connector Fuel pump relay

TROUBLE DIAGNOSIS

[KA24DE]

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
EGRC SOLENOID VALVE	<ul style="list-style-type: none"> ● Ignition switch: ON ● Turn EGRC-solenoid valve "ON" and "OFF" using CONSULT-II and listen to operating sound. 	EGRC-solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● EGRC-solenoid valve
PURG VOL CONT/V	<ul style="list-style-type: none"> ● Engine: After warming up, run engine at 1,500 rpm. ● Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> ● Harness and connector ● EVAP canister purge volume control solenoid valve
FUEL T/TEMP SEN	<ul style="list-style-type: none"> ● Change the fuel tank temperature using CONSULT-II. 		
VENT CONTROL/V	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn solenoid valve "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve
VC/V BYPASS/V	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn solenoid valve "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve

DTC & SRT CONFIRMATION MODE

SRT STATUS Mode

For details, refer to [EC-52. "SYSTEM READINESS TEST \(SRT\) CODE"](#).

SRT Work Support Mode

This mode enables a technician to drive a vehicle to set the SRT while monitoring the SRT status.

DTC Work Support Mode

TEST MODE	TEST ITEM	CONDITION	REFERENCE PAGE
EVAP SYSTEM	PURG FLOW P0441	Refer to corresponding trouble diagnosis for DTC.	EC-302
	EVAP SML LEAK P0442/P1442		EC-311 , EC-467
	EVAP V/S LEAK P0456/P1456		EC-366 , EC-489
	PURG VOL CN/V P1444		EC-469
	VC CUT/V BP/V P1491		EC-510
HO2S1	HO2S1 (B1) P0133		EC-192
	HO2S1 (B1) P0134		EC-202
	HO2S1 (B1) P1143		EC-417
	HO2S1 (B1) P1144		EC-422
HO2S2	HO2S2 (B1) P0139		EC-216
	HO2S2 (B1) P1146	EC-427	
	HO2S2 (B1) P1147	EC-434	
EGR SYSTEM	EGR SYSTEM P0400	EC-275	
	EGRC-BPT/LV P0402	EC-285	
	EGR SYSTEM P1402	EC-458	

REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

Description

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

1. "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT-II screen in real time. In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM.

At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at left, and the data after the malfunction detection is recorded. Then the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.

The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "RECORDING Speed". Refer to CONSULT-II OPERATION MANUAL.

2. "MANU TRIG" (Manual trigger):

- DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM. DATA MONITOR can be performed continuously even though a malfunction is detected.

Use these triggers as follows:

Operation

1. "AUTO TRIG"

- While trying to detect the DTC/1st trip DTC by performing the "DTC Confirmation Procedure", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent. When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC Confirmation Procedure", the moment a malfunction is found the DTC/1st trip


TROUBLE DIAGNOSIS

[KA24DE]

DTC will be displayed. (Refer to "INCIDENT SIMULATION TESTS" in [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .

2. "MANU TRIG"

- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.




Generic Scan Tool (GST) DESCRIPTION

UBS008MN

Generic Scan Tool (OBDII scan tool) complying with SAE J1978 has 8 different functions explained on the next page.

ISO9141 is used as the protocol.

The name "GST" or "Generic Scan Tool" is used in this service manual.




FUNCTION

Diagnostic test mode		Function
MODE 1	READINESS TESTS	This mode gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.
MODE 2	(FREEZE DATA)	This mode gains access to emission-related data value which were stored by ECM during the freeze frame. For details, refer to EC-52, "FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA" .
MODE 3	DTCs	This mode gains access to emission-related power train trouble codes which were stored by ECM.

Diagnostic test mode		Function
MODE 4	CLEAR DIAG INFO	This mode can clear all emission-related diagnostic information. This includes: <ul style="list-style-type: none"> ● Clear number of diagnostic trouble codes (MODE 1) ● Clear diagnostic trouble codes (MODE 3) ● Clear trouble code for freeze frame data (MODE 1) ● Clear freeze frame data (MODE 2) ● Reset status of system monitoring test (MODE 1) ● Clear on board monitoring test results (MODE 6 and 7)
MODE 6	(ON BOARD TESTS)	This mode accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored.
MODE 7	(ON BOARD TESTS)	This mode enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions.
MODE 8	—	—
MODE 9	(CALIBRATION ID)	This mode is to enable the off-board to request vehicle specific information such as Vehicle Identification Number (VIN) and Calibration ID.


GST INSPECTION PROCEDURE

1. Turn ignition switch OFF.
2. Connect "GST" to data link connector which is located under LH dash panel near the fuse box cover.




3. Turn ignition switch ON.
4. Enter the program according to instruction on the screen or in the operation manual.

(*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.

For further information, see the GST Operation Manual of the tool maker.



TROUBLE DIAGNOSIS

[KA24DE]

UBS008MO

CONSULT-II Reference Value in Data Monitor Mode

Remarks:

● Specification data are reference values.

● Specification data are output/input values which are detected or supplied by the ECM at the connector.

* Specification data may not be directly related to their components signals/values/operations.

(i.e., Adjust ignition timing with a timing light before monitoring IGN TIMING. Specification data might be displayed even when ignition timing is not adjusted to specification. This IGN TIMING monitors the data calculated by the ECM according to the input signals from the camshaft position sensor and other ignition timing related sensors.)

MONITOR ITEM	CONDITION		SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare the CONSULT-II value with tachometer indication. 		Almost the same speed as the value tachometer indication
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	0.9 - 1.8V
		2,500 rpm	1.9 - 2.3V
COOLAN TEMP/S	<ul style="list-style-type: none"> ● Engine: After warming up 		More than 70°C (158°F)
HO2S1 (B1)	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)			LEAN ↔ RICH Changes more than 5 times during 10 seconds.
HO2S2 (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle up to 3,000 rpm quickly	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)			
VHCL SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare the CONSULT-II value with speedometer indication 		Almost the same speed as the speedometer indication
BATTERY VOLT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 		11 - 14V
THRTL POS SEN	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) 	Throttle valve fully closed	0.2 - 0.8V
		Throttle valve fully opened	3.5 - 4.5V
EGR TEMP SEN	<ul style="list-style-type: none"> ● Engine: After warming up 		Less than 4.5V
START SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON → START → ON 		OFF → ON → OFF
CLSD THL/P SW	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) 	Throttle valve: Idle position	ON
		Throttle valve: Slightly open	OFF
CLSD THL POS	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) 	Throttle valve: Idle position	ON
		Throttle valve: Slightly open	OFF
AIR COND SIG	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	A/C switch: OFF	OFF
		A/C switch: ON (Compressor operates.)	ON
P/N POSI SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Shift lever: "P" or "N"	ON
		Except above	OFF
PW/ST SIGNAL	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Steering wheel in neutral position (forward direction)	OFF
		The steering wheel is turned	ON
IGNITION SW	<ul style="list-style-type: none"> ● Ignition switch: ON → OFF → ON 		ON → OFF → ON
INJ PULSE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	2.5 - 3.3 msec
		2,000 rpm	2.4 - 3.2 msec

TROUBLE DIAGNOSIS

[KA24DE]

MONITOR ITEM	CONDITION	SPECIFICATION
B/FUEL SCHDL	● Engine: After warming up ● Air conditioner switch: OFF	Idle 0.8 - 1.2 msec
	● Shift lever: "N" ● No-load	2,000 rpm 0.8 - 1.2 msec
IGN TIMING	● Engine: After warming up ● Air conditioner switch: OFF	Idle Approx. 20° BTDC
	● Shift lever: "N" ● No-load	2,000 rpm More than 25° BTDC
IACV-AAC/V	● Engine: After warming up ● Air conditioner switch: OFF	Idle Approx. 30%
	● Shift lever: "N" ● No-load	2,000 rpm —
PURG VOL C/V	● Engine: After warming up ● Air conditioner switch: OFF	Idle 0%
	● No-load	2,000 rpm (More than 200 seconds after starting engine) —
A/F ALPHA-B1	● Engine: After warming up	Maintaining engine speed at 2,000 rpm 50 - 159%
EVAP SYS PRES	● Ignition switch: ON	Approx. 3.4V
AIR COND RLY	● Air conditioner switch: OFF → ON	OFF → ON
FUEL PUMP RLY	● Ignition switch is turned to ON (Operates for 5 seconds) ● Engine running and cranking	ON
	● Except as shown above	OFF
EGRC SOL/V	● Engine: After warming up ● Air conditioner switch: OFF	Idle ON (Cut)
	● Shift lever: "N" ● No-load	Engine speed: Revving engine from idle to 3,000 rpm quickly. OFF (Flow)
VENT CONT/V	● Ignition switch: ON	OFF
HO2S1 HTR (B1)	● Engine speed: Below 3,600 rpm	ON
	● Engine speed: Above 3,600 rpm	OFF
HO2S2 HTR (B1)	● Engine speed: Below 4,000 rpm after the following conditions are met. ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under on load	ON
	● Ignition switch: ON (Engine stopped)	OFF
VC/V BYPASS/V	● Ignition switch: ON	OFF
CAL/LD VALUE	● Engine: After warming up ● Air conditioner switch: OFF	Idle 9.5 - 34.0%
	● Shift lever: "N" ● No-load	2,500 rpm 13.9 - 24.9%
ABSOL TH-P/S	● Engine: After warming up, engine stopped	Throttle valve: fully closed 0.0%
	● Ignition switch: ON	Throttle valve: fully opened Approx. 80%
MASS AIRFLOW	● Engine: After warming up ● Air conditioner switch: OFF	Idle 0.9 - 5.8 g-m/s
	● Shift lever: "N" ● No-load	2,500 rpm 7.5 - 13.2 g-m/s

Major Sensor Reference Graph in Data Monitor Mode

UBS008MP

The following are the major sensor reference graphs in "DATA MONITOR" mode.

TROUBLE DIAGNOSIS


[KA24DE]

(Select "MANU TRIG" in "DATA MONITOR" with CONSULT-II. "Trigger Point" is set to 100%, "Recording Speed" is set to MAX.)

THRTL POS SEN, ABSOL TH·P/S, CLSD THL POS

Below is the data for "THRTL POS SEN", "ABSOL TH·P/S" and "CLSD THL POS" when depressing the accelerator pedal with the ignition switch ON.


The signal of "THRTL POS SEN" and "ABSOL TH·P/S" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".




ENG SPEED, MAS A/F SE-B1, THRTL POS SEN, HO2S2 (B1), HO2S1 (B1), INJ PULSE-B1

Below is the data for "ENG SPEED", "MAS A/F SE-B1", "THRTL POS SEN", "HO2S2 (B1)", "HO2S1 (B1)" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine to normal operating temperature.


Each value is for reference, the exact value may vary.




A
EC
C
D
E
F
G
H
I
J
K
L
M




- "THRTL POS SEN" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "HO2S1 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

PFP:00031

Description

UBS008MQ

The specification (SP) value indicates the tolerance of the value that is displayed in "DATA MONITOR (SPEC)" mode of CONSULT-II during normal operation of the Engine Control System. When the value in "DATA MONITOR (SPEC)" mode is within the SP value, the Engine Control System is confirmed OK. When the value in "DATA MONITOR (SPEC)" mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MIL.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1/B2 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Testing Condition

UBS008MR

- Vehicle driven distance: More than 5,000 km (3,107 miles)
- Barometric pressure: 101.3 kPa (760.0 mmHg, 29.92 inHg)±3 kPa (22.5 mmHg, 0.89 inHg)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Transmission: Warmed-up*1
- Electrical load: Not applied*2
- Engine speed: Idle

*1: Drive vehicle for 5 minutes after the engine is warmed up to normal operating temperature.

*2: Rear window defogger switch, air conditioner switch, lighting switch are "OFF". Steering wheel is straight ahead.


Inspection Procedure

UBS008MS


NOTE:

Perform "DATA MONITOR (SPEC)" mode in maximum scale display.

1. Perform [EC-73, "Basic Inspection"](#) .
2. Confirm that the testing conditions indicated above are met.
3. Select "B/FUEL SCHDL", "A/F ALPHA-B1" and "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode with CONSULT-II.
4. Make sure that monitor items are within the SP value.
5. If NG, go to [EC-117, "Diagnostic Procedure"](#) .




Diagnostic Procedure




(Go to next page.)

A
EC
C
D
E
F
G
H
I
J
K
L
M



SEF768Z



A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT**Description**

Intermittent incidents (I/I) may occur. In many cases, the malfunction resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on DTC (1st trip) visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific malfunctioning area.

Common I/ Report Situations

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "1t".
III	The symptom described by the customer does not recur.
IV	(1st trip) DTC data does not appear during the DTC Confirmation Procedure.
VI	The TROUBLE DIAGNOSIS for PXXXX does not indicate the malfunctioning area.

Diagnostic Procedure**1. INSPECTION START**

Erase (1st trip) DTCs. Refer to [EC-60, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

>> GO TO 2.

2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection. Refer to "CIRCUIT INSPECTION", "Ground Inspection" in [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

3. SEARCH FOR ELECTRICAL INCIDENT

Perform "INCIDENT SIMULATION TESTS" in [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).

OK or NG

OK >> GO TO 4.

NG >> Repair or replace.

4. CHECK CONNECTOR TERMINALS

Refer to "HOW TO PROBE CONNECTORS", "How to Check Enlarged Contact Spring of Terminal" in [GI-22, "How to Check Terminal"](#).

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace connector.

POWER SUPPLY CIRCUIT FOR ECM

[KA24DE]

POWER SUPPLY CIRCUIT FOR ECM


PF-P:24110

Wiring Diagram


UBS008MW

EC-MAIN-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- EP : 9
- LP : 2



POWER SUPPLY CIRCUIT FOR ECM

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
4	LG/R	ECM relay (Self shut-off)	[Engine is running] [Ignition switch OFF] ● For a few seconds after turning ignition switch OFF	0 - 1V
			[Ignition switch OFF] ● A few seconds passed after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
10	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
19	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
24	W/G	Ignition switch	[Ignition switch OFF]	0V
			[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
25	B/Y	ECM ground	[Engine is running] ● Idle speed	Engine ground
32	B/Y	ECM ground	[Engine is running] ● Idle speed	Engine ground
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P			
80	SB	Power supply (Back-up)	[Ignition switch OFF]	BATTERY VOLTAGE (11 - 14V)
116	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
117	B/P	Current return	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)
124	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground

Diagnostic Procedure

UBS008MX

1. INSPECTION START

Start engine.

Is engine running?

Yes or No

Yes >> GO TO 4.

No >> GO TO 2.


2. CHECK POWER SUPPLY-I

1. Turn ignition switch OFF and then ON.
2. Check voltage between ECM terminal 24 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M65, E43
- Harness connectors M59, F27
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair harness or connectors.


4. CHECK POWER SUPPLY-II

1. Stop engine.
2. Check voltage between ECM terminal 80 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Fuse block (J/B) connector M27
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair harness or connectors.

6. CHECK POWER SUPPLY-III

1. Turn ignition switch ON and then OFF.
2. Check voltage between ECM terminals 67, 72, 117 and ground with CONSULT-II or tester.


Voltage : After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop to approximately 0V.

OK or NG

OK >> GO TO 12.

NG (Battery voltage does not exist.)>>GO TO 7.

NG (Battery voltage exists for more than a few seconds.)>>GO TO 11.



7. CHECK HARNESS CONTINUITY BETWEEN ECM RELAY AND ECM

1. Disconnect ECM harness connector.
2. Disconnect ECM relay.
3. Check harness continuity between ECM terminals 67, 72, 117 and ECM relay terminal 3. Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



8. CHECK VOLTAGE BETWEEN ECM RELAY AND GROUND


Check voltage between ECM relay terminals 2, 5 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

OK >> GO TO 10.

NG >> GO TO 9.



9. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and harness connector F36

>> Repair harness or connectors.

10. CHECK OUTPUT SIGNAL CIRCUIT

1. Check harness continuity between ECM terminal 4 and ECM relay terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 11.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

11. CHECK ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between ECM relay terminals 3 and 5.


12V (1 - 2) applied : Continuity exists.

No voltage applied : No continuity

OK or NG

OK >> GO TO 12.

NG >> Replace ECM relay.

**12. CHECK GROUND CIRCUIT**

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 10, 19, 25, 32, 116, 124 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 13.

NG >> Repair open circuit or short to power in harness or connectors.

13. CHECK INTERMITTENT INCIDENT

Perform [EC-120. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0031, P0032 HO2S1 HEATER

[KA24DE]

DTC P0031, P0032 HO2S1 HEATER

PF:22690

Description SYSTEM DESCRIPTION

UBS008MY

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
Engine coolant temperature sensor	Engine coolant temperature		

The ECM performs ON/OFF duty control of the heated oxygen sensor 1 heater corresponding to the engine speed and engine coolant temperature. The duty percent varies with engine coolant temperature when engine is started.

OPERATION

Engine speed	Heated oxygen sensor 1 heater
Above 3,600 rpm	OFF
Below 3,600 rpm after warming up	ON

CONSULT-II Reference Value in Data Monitor Mode

UBS008MZ

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Engine speed: Below 3,600 rpm 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,600 rpm 	OFF

On Board Diagnosis Logic

UBS008N0

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0031	Heated oxygen sensor 1 heater control circuit low	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 1 heater circuit is open or shorted.) ● Heater oxygen sensor 1 heater
P0032	Heated oxygen sensor 1 heater control circuit high	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 1 heater circuit is shorted.) ● Heater oxygen sensor 1 heater

DTC Confirmation Procedure**NOTE:**

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 10 seconds.
3. Turn ignition switch “ON” and select “DATA MONITOR” mode with CONSULT-II.
4. Start engine and run it for at least 6 seconds at idle speed.
5. If 1st trip DTC is detected, go to [EC-129, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

1. Turn ignition switch “OFF” and wait at least 10 seconds.
 2. Start engine and warm it up to normal operating temperature.
 3. Start engine and run it for at least 6 seconds at idle speed.
 4. Turn ignition switch OFF and wait least 5 seconds.
 5. Start engine and run it for at least 6 seconds at idle speed.
 6. Select “MODE 3” with GST.
 7. If DTC is detected, go to [EC-129, "Diagnostic Procedure"](#) .
- **When using GST, “DTC Confirmation Procedure” should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**





DTC P0031, P0032 HO2S1 HEATER

[KA24DE]

UBS008N2

Wiring Diagram

EC-HO2S1H-01



BBWA0436E

DTC P0031, P0032 HO2S1 HEATER

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
119	BR/Y	Heated oxygen sensor 1 heater	[Engine is running] ● Engine speed is below 3,000 rpm.	Approximately 0.4V
			[Engine is running] ● Engine speed is above 3,000 rpm.	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS008N3

1. CHECK POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 1 harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- 15A fuse
- Fuse block (J/B) connector M26
- Harness for open or short between heated oxygen sensor 1 and 15A fuse

>> Repair harness or connectors.

3. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between heated oxygen sensor 1 terminal 3 and ECM terminal 119.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground or short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

Check resistance between terminals 3 and 1.

Resistance : 2.3 - 4.3 Ω at 25°C (77°F)

Check continuity between terminals 2 and 1, 3 and 2.

Continuity should not exist.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 5.

NG >> Replace heated oxygen sensor 1.


5. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .



DTC P0037, P0038 HO2S2 HEATER

[KA24DE]

DTC P0037, P0038 HO2S2 HEATER

PF2:226A0

Description SYSTEM DESCRIPTION

UBS008N5

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
Engine coolant temperature sensor	Engine coolant temperature sensor		
Mass air flow sensor	Amount of intake air		

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater corresponding to the engine speed, amount of intake air and engine coolant temperature.

OPERATION

Engine speed rpm	Heated oxygen sensor 2 heater
Above 4,000	OFF
<ul style="list-style-type: none"> Below 3,600 rpm after the following conditions are met. Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	ON

CONSULT-II Reference Value in Data Monitor Mode

UBS008N6

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1)	<ul style="list-style-type: none"> Engine speed: Below 4,000 rpm after the following conditions are met. Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	ON
	<ul style="list-style-type: none"> Engine speed: Above 4,000 rpm 	OFF

On Board Diagnosis Logic

UBS008N7

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0037	Heated oxygen sensor 2 heater control circuit low	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> Harness or connectors (The heated oxygen sensor 2 heater circuit is open or shorted.) Heater oxygen sensor 2 heater
P0038	Heated oxygen sensor 2 heater control circuit high	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> Harness or connectors (The heated oxygen sensor 2 heater circuit is shorted.) Heater oxygen sensor 2 heater

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is in between 10.5V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minute.
6. If 1st trip DTC is detected, go to [EC-134, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANT TEMP/S	XXX °C

SEF174Y

WITH GST

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Turn ignition switch "OFF" and wait at least 10 seconds.
6. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
7. Let engine idle for one minute.
8. Select "MODE 3" with GST.
9. If DTC is detected, go to [EC-134, "Diagnostic Procedure"](#).

When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.


DTC P0037, P0038 HO2S2 HEATER

[KA24DE]




UBS008N9

Wiring Diagram

EC-HO2S2H-01



- : Detectable line for DTC
 - : Non-detectable line for DTC
 - : EARLY PRODUCTION
 - : LATE PRODUCTION
 - : 10
 - : 3
- *1



WBWA0009E

DTC P0037, P0038 HO2S2 HEATER

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
122	R/B	Heated oxygen sensor 2 heater	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed: Below 3,600 rpm after the following conditions are met. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS008NA


1. CHECK POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 2 harness connector.
3. Turn ignition switch ON.
4. Check voltage between terminal 2 and ground.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector M26
- 15A fuse
- Harness for open or short between heated oxygen sensor 2 and 15A fuse

>> Repair harness or connectors.

3. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between heated oxygen sensor 2 terminal 3 and ECM terminal 122. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground or short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Harness for open or short between heated oxygen sensor 2 and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2 HEATER

Check the following.

1. Check resistance between terminals 2 and 3.

Resistance : 2.3 - 4.3Ω at 25°C (77°F)

2. Check continuity.


Terminal No.	Continuity
1 and 2, 3, 4	No
4 and 1, 2, 3	

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 6.
- NG >> Replace heated oxygen sensor 2.



6. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 2


Refer to [EX-3, "EXHAUST SYSTEM"](#) .

DTC P0101 MAF SENSOR

Component Description

UBS008NC

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

UBS008ND

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	0.9 - 1.8V
		2,500 rpm	1.9 - 2.3V
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	9.5 - 34.0%
		2,500 rpm	13.9 - 24.9%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	0.9 - 5.8 g-m/s
		2,500 rpm	7.5 - 13.2 g-m/s

On Board Diagnosis Logic

UBS008NE

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0101 0101	Mass air flow sensor circuit range/performance problem	A)	A high voltage from the sensor is sent to ECM under light load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor
		B)	A low voltage from the sensor is sent to ECM under heavy load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor

DTC Confirmation Procedure

Perform "PROCEDURE FOR MALFUNCTION A" first. If the DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

NOTE:

If engine will not start or stops soon, wait at least 10 seconds with engine stopped (Ignition switch "ON") instead of running engine at idle speed.

With CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and warm it up to normal operating temperature.
4. Run engine for at least 10 seconds at idle speed.
5. If DTC is detected, go to [EC-140, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y


With GST

Follow the procedure "With CONSULT-II".

PROCEDURE FOR MALFUNCTION B

With CONSULT-II

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
If engine cannot be started, go to [EC-140, "Diagnostic Procedure"](#).
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Check the voltage of "MAS A/F SE-B1" with "DATA MONITOR".
5. Increases engine speed to about 4,000 rpm.
6. Monitor the linear voltage rise in response to engine speed increases.
If NG, go to [EC-140, "Diagnostic Procedure"](#).
If OK, go to following step.



DTC P0101 MAF SENSOR

[KA24DE]

7. Maintain the following conditions for at least 10 consecutive seconds.

ENG SPEED	More than 2,000 rpm
THRTL POS SEN	More than 3V
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V

SEF175Y

8. If DTC is detected, go to [EC-140, "Diagnostic Procedure"](#) .

Overall Function Check

UBS008NG

Use this procedure to check the overall function of the mass air flow sensor circuit. During this check, a DTC might not be confirmed.

PROCEDURE FOR MALFUNCTION B

With GST

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
3. Select "MODE 1" with GST.
4. Check the mass air flow sensor signal with "MODE 1".
5. Check for linear mass air flow rise in response to increases to about 4,000 rpm in engine speed.
6. If NG, go to [EC-140, "Diagnostic Procedure"](#) .

CALC LOAD	20%
COOLANT TEMP	95°C
SHORT FT #1	2%
LONG FT #1	0%
SHORT FT #2	4%
LONG FT #2	0%
ENGINE SPD	2637RPM
VEHICLE SPD	0MPH
IGN ADVANCE	41.0°
INTAKE AIR	41°C
MAF	14.1gm/sec
THROTTLE POS	3%

SEF534P





DTC P0101 MAF SENSOR

[KA24DE]

UBS008NH

Wiring Diagram

EC-MAFS-01



WBWA0010E

DTC P0101 MAF SENSOR

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
54	R	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	0.9 - 1.8V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm	1.9 - 2.3V
55	G	Mass air flow sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS008NI

1. INSPECTION START

Which malfunction (A or B) is duplicated?

A or B

- A >> GO TO 3.
- B >> GO TO 2.

2. CHECK INTAKE SYSTEM

Check the followings for connection.

- Air duct
- Air cleaner
- Vacuum hoses
- Intake air passage between air duct to collector


OK or NG

- OK >> GO TO 3.
- NG >> Reconnect the parts.

3. RETIGHTEN GROUND SCREWS


1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 4.



4. CHECK POWER SUPPLY

1. Disconnect mass air flow sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and mass air flow sensor
- Harness for open or short between mass air flow sensor and ECM

>> Repair harness or connectors.

6. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between mass air flow sensor terminal 3 and ECM terminal 55. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground or short to power.

OK or NG

- OK >> GO TO 7.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK INPUT SIGNAL CIRCUIT

1. Check harness continuity between terminal 4 and ECM terminal 54. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK MASS AIR FLOW SENSOR

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Start engine and warm it up to normal operating temperature.
4. Check voltage between ECM terminal 54 (mass air flow sensor signal) and ground.



Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 1.0
Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.85
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.9 - 2.3
Idle to about 4,000 rpm*	1.3 - 1.7 to Approx. 3.0

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

5. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Repeat above check.
6. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.

OK or NG

- OK >> GO TO 9.
- NG >> Replace mass air flow sensor.



9. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


DTC P0102, P0103 MAF SENSOR

PF2:22680

Component Description

UBS008NK

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

UBS008NL

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	0.9 - 1.8V
		2,500 rpm	1.9 - 2.3V
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	9.5 - 34.0%
		2,500 rpm	13.9 - 24.9%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	0.9 - 5.8 g-m/s
		2,500 rpm	7.5 - 13.2 g-m/s

On Board Diagnosis Logic

UBS008NM

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor
P0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR DTC P0102

With CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait 5 seconds at most.
4. If DTC is detected, go to [EC-146, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II".

PROCEDURE FOR DTC P0103

With CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 6 seconds.
4. If DTC is detected, go to [EC-146, "Diagnostic Procedure"](#) .
If DTC is not detected, go to next step.
5. Start engine and let it idle for at least 6 seconds.
6. If DTC is detected, go to [EC-146, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II".





DTC P0102, P0103 MAF SENSOR

[KA24DE]

UBS008NO

Wiring Diagram

EC-MAFS-01



WBWA0010E

DTC P0102, P0103 MAF SENSOR

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
54	R	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	0.9 - 1.8V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm	1.9 - 2.3V
55	G	Mass air flow sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS008NP

1. INSPECTION START

Which malfunction (P0102 or P0103) is duplicated?

P0102 or P0103

P0102 >> GO TO 2.

P0103 >> GO TO 3.

2. CHECK INTAKE SYSTEM

Check the followings for connection.

- Air duct
- Air cleaner
- Vacuum hoses
- Intake air passage between air duct to collector

OK or NG


OK >> GO TO 3.

NG >> Reconnect the parts.

3. RETIGHTEN GROUND SCREWS


1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 4.



4. CHECK POWER SUPPLY

1. Disconnect mass air flow sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and mass air flow sensor
- Harness for open or short between mass air flow sensor and ECM

>> Repair harness or connectors.

6. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between mass air flow sensor terminal 3 and ECM terminal 55. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground or short to power.

OK or NG

- OK >> GO TO 7.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK INPUT SIGNAL CIRCUIT

1. Check harness continuity between terminal 4 and ECM terminal 54. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK MASS AIR FLOW SENSOR

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Start engine and warm it up to normal operating temperature.
4. Check voltage between ECM terminal 54 (mass air flow sensor signal) and ground.



Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 1.0
Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 185
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.9 - 2.3
Idle to about 4,000 rpm*	1.3 - 1.7 to Approx. 3.0

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

5. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Repeat above check.
6. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.

OK or NG

- OK >> GO TO 9.
- NG >> Replace mass air flow sensor.



9. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**


DTC P0112, P0113 IAT SENSOR

PF2:22630

Component Description

UBS008NR

The intake air temperature sensor is mounted to the air duct housing. The sensor detects intake air temperature and transmits a signal to the ECM.




The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.

<Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
20 (68)	3.5	2.1 - 2.9
80 (176)	1.23	0.27 - 0.38

*: These data are reference values and are measured between ECM terminal 61 (Intake air temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

On Board Diagnosis Logic

UBS008NS

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0112	Intake air temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air temperature sensor
P0113	Intake air temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode
Intake air temperature sensor circuit	The ECM functions on the assumption that the intake air temperature is 25°C (77°F).

DTC Confirmation Procedure**NOTE:**

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-152. "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

④ WITH GST

Follow the procedure "WITH CONSULT-II".

DTC P0112, P0113 IAT SENSOR


[KA24DE]

UBS008NU


Wiring Diagram

EC-IATS-01


A
EC
C
D
E
F
G
H
I
J
K
L
M



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 19
- LP : 22
- *2 EP : 1
- LP : 4




Refer to the following.
E43 - SUPER MULTIPLE JUNCTION (SMJ)



WBWA0011E

Diagnostic Procedure**1. CHECK POWER SUPPLY**

1. Turn ignition switch OFF.
2. Disconnect intake air temperature sensor harness connector.
3. Turn ignition switch ON.




4. Check voltage between intake air temperature sensor terminal 1 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.

**2. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between ECM and intake air temperature sensor

>> Repair harness or connectors.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check harness continuity between intake air temperature sensor terminal 2 and engine ground. Refer to the Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART


Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between ECM and intake air temperature sensor

>> Repair open circuit or short to power in harness or connectors.

5. CHECK INTAKE AIR TEMPERATURE SENSOR

Check resistance as shown in the figure.



OK or NG

OK >> GO TO 6.

NG >> Replace intake air temperature sensor.

6. CHECK INTERMITTENT INCIDENT

Perform [EC-120. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


DTC P0117, P0118 ECT SENSOR

PFP:22630

Component Description

UBS008NX


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 59 (Engine coolant temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

CONSULT-II Reference Value in Data Monitor Mode

UBS008NY

MONITOR ITEM	CONDITION	SPECIFICATION
COOLAN TEMP/S	● Engine: After warming up	More than 70°C (158°F)

On Board Diagnosis Logic

UBS008NZ

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Engine coolant temperature sensor
P0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch to ON or START. CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned to ON or Start	40°C (104°F)
	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-157, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II".

A
EC
C
D
E
F
G
H
I
J
K
L
M




DTC P0117, P0118 ECT SENSOR

[KA24DE]

UBS00801

Wiring Diagram


EC-ECTS-01



AEC984A

Diagnostic Procedure**1. CHECK POWER SUPPLY**

1. Turn ignition switch "OFF".
2. Disconnect engine coolant temperature sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between engine coolant temperature sensor terminal 1 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.

**2. DETECT MALFUNCTIONING PART**

Check the harness for open or short between ECM and engine coolant temperature sensor.

>> Repair harness or connectors.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check harness continuity between engine coolant temperature sensor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the harness for open or short between ECM and engine coolant temperature sensor.

>> Repair open circuit or short to power in harness or connectors.

5. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-158, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace engine coolant temperature sensor.

6. CHECK INTERMITTENT INCIDENT


Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component Inspection
ENGINE COOLANT TEMPERATURE SENSOR**

UBS00803


1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.



<Reference data>

Engine coolant temperature °C (°F)	Voltage V	Resistance kΩ
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

2. If NG, replace engine coolant temperature sensor.



DTC P0121 TP SENSOR


Component Description

NOTE:

If DTC P0121 is displayed with DTC P0510, first perform trouble diagnosis for DTC P0510, [EC-408](#).

The throttle position sensor responds to the accelerator pedal movement. This sensor is a type of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit, is not used for engine control.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL POS SEN	● Ignition switch: ON (Engine stopped) ● Engine: After warming up	Throttle valve: fully closed 0.2 - 0.8V
		Throttle valve: fully opened 3.5 - 4.5V
ABSOL TH-P/S	● Ignition switch: ON (Engine stopped) ● Engine: After warming up	Throttle valve: fully closed 0.0%
		Throttle valve: fully opened Approx. 80%

On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0121	Throttle position sensor circuit range/performance problem	A) A high voltage from the sensor is sent to ECM under light load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The throttle position sensor circuit is open or shorted.) ● Throttle position sensor ● Fuel injector ● Camshaft position sensor ● Mass air flow sensor
		B) A low voltage from the sensor is sent to ECM under heavy load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The throttle position sensor circuit is open or shorted.) ● throttle position sensor ● Intake air leaks

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	
Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
	Condition	Driving condition
	When engine is idling	Normal
	When accelerating	Poor acceleration

DTC Confirmation Procedure

Perform “PROCEDURE FOR MALFUNCTION A” first. If the DTC cannot be confirmed, perform “PROCEDURE FOR MALFUNCTION B”.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

With CONSULT-II

1. Turn ignition switch ON.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for at least 10 seconds.
If idle speed is over 1,100 rpm, maintain the following conditions for at least 10 seconds to keep engine speed below 1,100 rpm.

Selector lever	Suitable position except “N” (Higher gear position such as 3rd or 4th is better to keep low engine rpm.)
Accelerator pedal	Released
Vehicle speed	As slow as possible

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

4. If DTC is detected, go to [EC-163, "Diagnostic Procedure"](#) .

With GST

Follow the procedure “With CONSULT-II”.

PROCEDURE FOR MALFUNCTION B

CAUTION:


Always drive vehicle at a safe speed.

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch OFF and wait at least 5 seconds.
 3. Turn ignition switch ON.
 4. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II.
 5. Select "THRTL POS SEN" and "ABSOL TH·P/S" in "DATA MONITOR" mode with CONSULT-II.
 6. Press RECORD on CONSULT-II screen at the same time accelerator pedal is depressed.
 7. Print out the recorded graph and check the following:
 - The voltage rise is linear in response to accelerator pedal depression.
 - The voltage when accelerator pedal is fully depressed is approximately 4V.
- If NG, go to [EC-163, "Diagnostic Procedure"](#) .
 If OK, go to following step.

DATA MONITOR	
MONITOR	NO DTC
THRTL POS SEN	XXX V
ABSOL TH·P/S	XXX %

SEF177Y



8. Select "AUTO TRIG" in "DATA MONITOR" mode with CONSULT-II.
9. Maintain the following conditions for at least 10 consecutive seconds.

ENG SPEED	More than 2,000 rpm
MAS A/F SE-B1	More than 3V
COOLAN TEMP/S	More than 70°C (158°F)
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C

SEF178Y

10. If DTC is detected, go to [EC-163, "Diagnostic Procedure"](#) .

With GST

Follow the procedure "With CONSULT-II".




DTC P0121 TP SENSOR

[KA24DE]

Wiring Diagram

UBS00809

EC-TPS-01



BBWA0547E

DTC P0121 TP SENSOR

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
23	L	Throttle position sensor	[Ignition switch ON] ● Warm-up condition ● Accelerator pedal fully released	0.2 - 0.8V
			[Ignition switch ON] ● Accelerator pedal fully depressed	3.5 - 4.5V
42	BR	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	B/W	Sensors' ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS0080A

1. INSPECTION START

Which malfunction A or B is duplicated?

MALFUNCTION	Type
A	A
B	B

Type A or B

Type A >> GO TO 4.

Type B >> GO TO 2.

2. ADJUST THROTTLE POSITION SENSOR

1. Check the following items. Refer to [EC-73, "Basic Inspection"](#) .

Items	Specifications
Ignition timing	20° ± 2° BTDC
Base idle speed	750 ± 50 rpm
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF
Target idle speed	800 ± 50 rpm

>> GO TO 3.

3. CHECK INTAKE SYSTEM

Check the following for connection.

- Air duct
- Air cleaner
- Vacuum hoses
- Intake air passage between air duct to intake manifold collector

OK or NG


OK >> GO TO 4.

NG >> Reconnect the parts.

4. RETIGHTEN GROUND SCREWS


1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 5.



5. CHECK POWER SUPPLY

1. Disconnect throttle position sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 6.
 NG >> Repair harness or connectors.



6. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check harness continuity between throttle position sensor terminal 3 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 8.
 NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check harness for open or short between ECM and throttle position sensor.

>> Repair open circuit or short to power in harness or connectors.

8. CHECK INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 23 and terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK THROTTLE POSITION SENSOR

Refer to [EC-166, "Component Inspection"](#) .

OK or NG

OK >> GO TO 10.

NG >> Replace throttle position sensor. To adjust it, perform [EC-73, "Basic Inspection"](#) .

10. CHECK MASS AIR FLOW SENSOR

Refer to [EC-166, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace mass air flow sensor.

11. CHECK CAMSHAFT POSITION SENSOR

Refer to [EC-273, "Component Inspection"](#)

OK or NG

OK >> GO TO 12.

NG >> Replace distributor assembly with camshaft position sensor.

12. CHECK FUEL INJECTOR

Refer to [EC-166, "Component Inspection"](#) .

OK or NG

OK >> GO TO 13.

NG >> Replace fuel injector.

13. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L

M

Component Inspection
THROTTLE POSITION SENSOR


With CONSULT-II

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Stop engine and turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Check voltage of "THRTL POS SEN" under the following conditions.

NOTE:

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	Voltage [V]
Completely closed	0.2 - 0.8 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.5 (b)



If NG, adjust closed throttle position switch. Refer to [EC-73](#), "Basic Inspection".


Without CONSULT-II

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Stop engine and turn ignition switch ON.
4. Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground under the following conditions.

NOTE:

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	Voltage [V]
Completely closed	0.2 - 0.8 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.5 (b)




If NG, adjust closed throttle position switch. Refer to [EC-73](#), "Basic Inspection".

MASS AIR FLOW SENSOR

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (mass air flow sensor signal) and ground.

Conditions	Voltage [V]
Ignition switch ON (Engine stopped)	Less than 1.0
Idle (Engine is warmed-up to normal operating temperature)	0.9 - 1.8
2,500 rpm (Engine is warmed-up to normal operating temperature)	1.9 - 2.3
Idle to about 4,000 rpm*	1.3 - 1.7 to Approx. 3.0




*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Repeat above check.

DTC P0121 TP SENSOR

[KA24DE]


5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.



FUEL INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance : 7.3 - 9.9Ω [at 25°C (77°F)]



A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0122, P0123 TP SENSOR

PF16119

Component Description


UBS0080D

NOTE:

If DTC, P0122 or P0123 is displayed with DTC P0510, first perform trouble diagnosis for DTC P0510, [EC-408](#).

The throttle position sensor responds to the accelerator pedal movement. This sensor is a type of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit, is not used for engine control.



SEF105S

CONSULT-II Reference Value in Data Monitor Mode

UBS0080E

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL POS SEN	● Ignition switch: ON (Engine stopped)	Throttle valve: fully closed 0.2 - 0.8V
	● Engine: After warming up	Throttle valve: fully opened 3.5 - 4.5V
ABSOL TH-P/S	● Ignition switch: ON (Engine stopped)	Throttle valve: fully closed 0.0%
	● Engine: After warming up	Throttle valve: fully opened Approx. 80%

On Board Diagnosis Logic

UBS0080F

DTC No.	Trouble diagnosis name	DTC Detecting Condition	Check Items (Possible Cause)
P0122	Throttle position sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	● Harness or connectors (The sensor circuit is open or shorted.) ● Throttle position sensor
P0123	Throttle position sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	
Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
	Condition	Driving condition
	When engine is idling	Normal
	When accelerating	Poor acceleration

DTC Confirmation Procedure

UBS0080G

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 10V at idle.
 - This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.
1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
 2. Start engine and maintain the following conditions for at least 5 consecutive seconds.

VHCL SPEED SE	More than 4 km/h (2 MPH)
Selector lever	Suitable position except "P" or "N" position

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF

SEF065Y

3. If DTC is detected, go to [EC-171, "Diagnostic Procedure"](#).

WITH GST

Follow the procedure "WITH CONSULT-II".




DTC P0122, P0123 TP SENSOR

[KA24DE]

Wiring Diagram

UBS0080H

EC-TPS-01



BBWA0547E

DTC P0122, P0123 TP SENSOR

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
23	L	Throttle position sensor	[Ignition switch ON] ● Warm-up condition ● Accelerator pedal fully released	0.2 - 0.8V
			[Ignition switch ON] ● Accelerator pedal fully depressed	3.5 - 4.5V
42	BR	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	B/W	Sensors' ground	[Engine is running] ● Idle speed	Approximately 0V


Diagnostic Procedure

UBS0080I

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK POWER SUPPLY

1. Disconnect throttle position sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between throttle position sensor terminal 1 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness or connectors.



3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check harness continuity between throttle position sensor terminal 3 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check harness for open or short between ECM and throttle position sensor.

>> Repair open circuit or short to power in harness or connectors.

5. CHECK INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 23 and throttle position sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK THROTTLE POSITION SENSOR

Refer to [EC-172, "Component Inspection"](#)

OK or NG

- OK >> GO TO 7.
NG >> Replace throttle position sensor. To adjust it, perform [EC-73, "Basic Inspection"](#) .

7. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

Component Inspection THROTTLE POSITION SENSOR

UBS0080J

With CONSULT-II

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Stop engine and turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.

DTC P0122, P0123 TP SENSOR

[KA24DE]

5. Check voltage of "THRTL POS SEN" under the following conditions.

NOTE:

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	Voltage [V]
Completely closed	0.2 - 0.8 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.5 (b)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
THRTL POS SEN	XXX V

SEF179Y

If NG, adjust closed throttle position switch. Refer to [EC-73](#), "[Basic Inspection](#)".


⊗ **Without CONSULT-II**

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Stop engine and turn ignition switch ON.
4. Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground under the following conditions.

NOTE:

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	Voltage [V]
Completely closed	0.2 - 0.8 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.5 (b)



If NG, adjust closed throttle position switch. Refer to [EC-73](#), "[Basic Inspection](#)".


DTC P0125 ECT SENSOR

Component Description

NOTE:

If DTC P0125 is displayed with P0117 or P0118, first perform trouble diagnosis for DTC P0117 or P0118, [EC-154](#).


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 59 (Engine coolant temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0125	Insufficient engine coolant temperature for closed loop fuel control	<ul style="list-style-type: none"> ● Voltage sent to ECM from the sensor is not practical, even when some time has passed after starting the engine. ● Engine coolant temperature is insufficient for closed loop fuel control. 	<ul style="list-style-type: none"> ● Harness or connectors (High resistance in the circuit) ● Engine coolant temperature sensor ● Thermostat

DTC Confirmation Procedure

CAUTION:

Be careful not to overheat engine.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Check that “COOLAN TEMP/S” is above 10°C (50°F).
If it is above 10°C (50°F), the test result will be OK.
If it is below 10°C (50°F), go to the following step.
4. Start engine and run it for 65 minutes at idle speed.
If “COOLAN TEMP/S” increases to more than 10°C (50°F) within 65 minutes, stop engine because the test result will be OK.
5. If DTC is detected, go to [EC-177, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

WITH GST

Follow the procedure “WITH CONSULT-II”.

A
EC
C
D
E
F
G
H
I
J
K
L
M




DTC P0125 ECT SENSOR

[KA24DE]

Wiring Diagram

UBS00800


EC-ECTS-01



AEC984A

Diagnostic Procedure**1. CHECK POWER SUPPLY**

1. Turn ignition switch "OFF".
2. Disconnect engine coolant temperature sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between engine coolant temperature sensor terminal 1 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.

**2. DETECT MALFUNCTIONING PART**

Check the harness for open or short between ECM and engine coolant temperature sensor.

>> Repair harness or connectors.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check harness continuity between engine coolant temperature sensor terminal 2 and engine ground. Refer to the Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the harness for open or short between ECM and engine coolant temperature sensor.

>> Repair open circuit or short to power in harness or connectors.

5. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-178, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace engine coolant temperature sensor.

6. CHECK THERMOSTAT OPERATION

When the engine is cooled [lower than 76.5°C (170°F)], condition grasp lower radiator hose and confirm the engine coolant does not flow.

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace thermostat. Refer to [CO-13, "THERMOSTAT"](#) .

7. CHECK INTERMITTENT INCIDENT


Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component Inspection
ENGINE COOLANT TEMPERATURE SENSOR**

UBS0080Q

1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.




PBIB0081E

<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 93 (Engine coolant temperature sensor) and ground.

2. If NG, replace engine coolant temperature sensor.




SEF012P

DTC P0127 IAT SENSOR

Component Description

The intake air temperature sensor is mounted to the air duct housing. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.




<Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
20 (68)	3.5	2.1 - 2.9
80 (176)	1.23	0.27 - 0.38

*: These data are reference values and are measured between ECM terminal 61 (Intake air temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0127	Intake air temperature too high	Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Intake air temperature sensor

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

The ECM functions on the assumption that the intake air temperature is 25°C (77°F).

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

Ⓟ WITH CONSULT-II

1. Wait until engine coolant temperature is less than 90°C (194°F).
 - Turn ignition switch ON.
 - Select “DATA MONITOR” mode with CONSULT-II.
 - Check the engine coolant temperature.
 - If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch “OFF” and cool down engine.
 - Perform the following steps before engine coolant temperature is above 90°C (194°F).
2. Turn ignition switch ON.
3. Select “DATA MONITOR” mode with CONSULT-II.
4. Start engine.
5. Hold vehicle speed more than 70 km/h (43 MPH) for 100 consecutive seconds.
6. If 1st trip DTC is detected, go to [EC-182, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

SEF176Y

Ⓟ WITH GST

Follow the procedure “WITH CONSULT-II”.

DTC P0127 IAT SENSOR


[KA24DE]

UBS0080V


Wiring Diagram

EC-IATS-01


A
EC
C
D
E
F
G
H
I
J
K
L
M



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 19
- *1 LP : 22
- *2 EP : 1
- *2 LP : 4



Refer to the following.
E43 - SUPER MULTIPLE JUNCTION (SMJ)




WBWA0011E

Diagnostic Procedure

1. CHECK POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect intake air temperature sensor harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between ECM and intake air temperature sensor

>> Repair harness or connectors.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check harness continuity between intake air temperature sensor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between ECM and intake air temperature sensor

>> Repair open circuit or short to power in harness or connectors.

5. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-183, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace intake air temperature sensor.


6. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component Inspection
INTAKE AIR TEMPERATURE SENSOR**


1. Check resistance between intake air temperature sensor terminals 1 and 2 as shown in the figure.



<Reference data>

Temperature °C (°F)	Resistance kΩ
80 (176)	0.27 - 0.38

2. If NG, replace intake air temperature sensor.



DTC P0128 THERMOSTAT FUNCTION

PF2:21200

On Board Diagnosis Logic

UBS0080Z

Engine coolant temperature has not risen enough to open the thermostat even though the engine has run long enough.

This is due to a leak in the seal or the thermostat stuck open.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0128	Thermostat function	The engine coolant temperature does not reach to specified temperature even though the engine has run long enough.	<ul style="list-style-type: none"> ● Thermostat ● Leakage from sealing portion of thermostat ● Engine coolant temperature sensor

DTC Confirmation Procedure

UBS008P0

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- For best results, perform at ambient temperature of **-10°C (14°F) or higher.**
- For best results, perform at engine coolant temperature of **-10°C (14°F) to 60°C (140°F).**

 **WITH CONSULT-II**

1. Replace thermostat with new one. Refer to [CO-13, "THERMOSTAT"](#) . Use only a genuine NISSAN thermostat as a replacement. If an incorrect thermostat is used, the MIL may come on.
2. Turn ignition switch “ON”.
3. Select “COOLAN TEMP/S” in “DATA MONITOR” mode with CONSULT-II.
4. Check that the “COOLAN TEMP/S” is above 60°C (140°F).
If it is below 60°C (140°F), go to following step.
If it is above 60°C (140°F), stop engine and cool down the engine to less than 60°C (140°F), then retry from step 1.
5. Drive vehicle for 10 consecutive minutes under the following conditions.

VHCL SPEED SE	80 - 120 km/h (50 - 75 MPH)
----------------------	------------------------------------

If 1st trip DTC is detected, go to [EC-185, "Diagnostic Procedure"](#) .


 **WITH GST**

1. Follow the procedure “WITH CONSULT-II” above.

Diagnostic Procedure


1. CHECK ENGINE COOLANT TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Remove engine coolant temperature sensor.
3. Check resistance between engine coolant temperature sensor terminals under the following conditions.



<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260



SEP304X

OK or NG

- OK >> **INSPECTION END.**
- NG >> Replace engine coolant temperature sensor.

A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P0132 HO2S1

PFP:22690

Component Description

UBS008P2

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS008P3


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS008P4

To judge the malfunction, the diagnosis checks that the heated oxygen sensor 1 output is not inordinately high.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0132	Heated oxygen sensor 1 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Heated oxygen sensor 1

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.
4. Select “DATA MONITOR” mode with CONSULT-II.
5. Restart engine and let it idle for 35 seconds.
6. If 1st trip DTC is detected, go to [EC-189, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C




SEF174Y

WITH GST

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch OFF and wait at least 5 seconds.
 3. Restart engine and let it idle for 35 seconds.
 4. Turn ignition switch OFF and wait at least 5 seconds.
 5. Restart engine and let it idle for 35 seconds.
 6. Select “MODE 3” with GST.
 7. If DTC is detected, go to [EC-189, "Diagnostic Procedure"](#) .
- **When using GST, “DTC Confirmation Procedure” should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

Wiring Diagram

EC-HO2S1-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Heated oxygen sensor 1	<p>[Engine is running]</p> <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm 	0 - Approximately 1.0V (Periodically change)

Diagnostic Procedure


UBS008P7

1. RETIGHTEN HEATED OXYGEN SENSOR 1

1. Turn ignition switch OFF.
2. Loosen and retighten heated oxygen sensor 1.


**Tightening torque : 40 - 60 N·m
(4.1 - 6.1 kg-m, 30 - 44 ft-lb)**

>> GO TO 2.



2. CHECK INPUT SIGNAL CIRCUIT

1. Disconnect heated oxygen sensor 1 harness connector and ECM harness connector.



2. Check harness continuity between ECM terminal 50 and HO2S1 terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Check harness continuity between ECM terminal 50 or HO2S1 terminal 2 and ground. Refer to Wiring Diagram.

Continuity should not exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HARNESS CONNECTOR

Check heated oxygen sensor 1 harness connector for water.
Water should not exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness connector.

4. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-190, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Replace heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection HEATED OXYGEN SENSOR 1

UBS008P8

Ⓟ With CONSULT-II

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Select "MANU TRIG" in "DATA MONITOR" mode, and the trigger point is adjusted to 100%.
4. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)" in item selection.
5. Hold engine speed at 2,000 rpm under no load during the following steps.
6. Touch "START" on CONSULT-II screen.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLANT TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

7. Check the following.
 - "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown below:
 - "HO2S1 (B1)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)" voltage never exceeds 1.0V.

cycle	1 2 3 4 5
HO2S1 MNTR (B1)	R-L-R-L-R-L-R-L-R
R means HO2S1 MNTR (B1) indicates RICH L means HO2S1 MNTR (B1) indicates LEAN	

SEF217YA




CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Set voltmeter probes between ECM terminal 50 [Heated oxygen sensor 1 signal] and engine ground.
4. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than five times within 10 seconds.
 - 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 - 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

**Removal and Installation
HEATED OXYGEN SENSOR 1**

UBS008P9

Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .



DTC P0133 HO2S1

PFP:22690

Component Description

UBS008PA

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS008PB


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	<ul style="list-style-type: none"> Engine: After warming up 	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS008PC

To judge the malfunction of heated oxygen sensor 1, this diagnosis measures response time of heated oxygen sensor 1 signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and heated oxygen sensor 1 temperature index. Judgment is based on whether the compensated time [heated oxygen sensor 1 cycling time index] is inordinately long or not.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0133	Heated oxygen sensor 1 circuit slow response	The response of the voltage signal from the sensor takes more than the specified time.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks ● Exhaust gas leaks ● PCV valve ● Mass air flow sensor

DTC Confirmation Procedure

UBS008PD

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch ON and select “HO2S1 (B1) P0133” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.
5. Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 5.

HO2S1 (B1) P0133	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

SEF338Z

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 40 to 50 seconds.)


ENG SPEED	1,750 - 3,750 rpm
Vehicle speed	More than 80 km/h (50 MPH)
B/FUEL SCHDL	3.5 - 15.5 msec
Selector lever	Suitable position

HO2S1 (B1) P0133	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

SEF339Z

If “TESTING” is not displayed after 5 minutes, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-196, "Diagnostic Procedure"](#).




Overall Function Check

UBS008PE

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.

 **WITH GST**





1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 (Heated oxygen sensor 1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than five times within 10 seconds.
 - 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V**
 - 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V**
4. If NG, go to [EC-196, "Diagnostic Procedure"](#).



Wiring Diagram

EC-HO2S1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Heated oxygen sensor 1	<p>[Engine is running]</p> <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm 	0 - Approximately 1.0V (Periodically change)


Diagnostic Procedure

UBS008PG

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.




2. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten corresponding heated oxygen sensor 1.


**Tightening torque : 40 - 60 N·m
(4.1 - 6.1 kg-m, 30 - 44 ft-lb)**

>> GO TO 3.



3. CHECK FOR EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst.



OK or NG

- OK >> GO TO 4.
 NG >> Repair or replace.

4. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 5.
 NG >> Repair or replace.


5. CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 or P0172 detected?
 Is it difficult to start engine?**

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-60. "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 or P0172 detected?
 Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171 or P0172. Refer to [EC-225](#) or [EC-232](#).
 No >> GO TO 6.

6. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 50 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

5. Check harness continuity between ECM terminal 50 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.


Continuity should not exist.

6. Also check harness for short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



7. CHECK HEATED OXYGEN SENSOR 1 HEATER

Check resistance between HO2S1 terminals 3 and 1.

Resistance : 2.3 - 4.3Ω at 25°C (77°F)

Check continuity between HO2S1 terminals 2 and 1, 3 and 2.

Continuity should not exist.


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 8.

NG >> Replace heated oxygen sensor 1.



8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-199, "Component Inspection"](#).

OK or NG

OK >> GO TO 9.

NG >> Replace mass air flow sensor.

9. CHECK PCV VALVE

Refer to [EC-199, "Component Inspection"](#).

OK or NG

OK >> GO TO 10.

NG >> Replace PCV valve.

10. CHECK FRONT HEATED OXYGEN SENSOR

Refer to [EC-199, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 11.
- NG >> Replace heated oxygen sensor 1.

11. CHECK INTERMITTENT INCIDENT

Refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection HEATED OXYGEN SENSOR 1

UBS008PH



Ⓟ With CONSULT-II

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Select "MANU TRIG" in "DATA MONITOR" mode, and the trigger point is adjusted to 100%.
4. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)" in item selection.
5. Hold engine speed at 2,000 rpm under no load during the following steps.
6. Touch "START" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLANT TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

7. Check the following.
 - "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown below:
 - "HO2S1 (B1)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)" voltage never exceeds 1.0V.




CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Set voltmeter probes between ECM terminal 50 [Heated oxygen sensor 1 signal] and engine ground.
4. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than five times within 10 seconds.
 - 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V**
 - 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V**
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



MASS AIR FLOW SENSOR

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.

Conditions	Voltage [V]
Ignition switch ON (Engine stopped.)	Less than 1.0
Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.8
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.9 - 2.3
Idle to about 4,000 rpm*	1.3 - 1.7 to Approx. 3.0

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.


4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Repeat above check.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.



PCV VALVE

1. With engine running at idle, remove PCV valve from breather separator.

2. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over the valve inlet.



**Removal and Installation
HEATED OXYGEN SENSOR 1**

Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .

A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P0134 HO2S1

PFP:22690

Component Description

UBS008PJ

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS008PK


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)			LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS008PL

Under the condition in which the heated oxygen sensor 1 signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0134	Heated oxygen sensor 1 circuit no activity detected	The voltage from the sensor is constantly approx. 0.3V.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Heated oxygen sensor 1

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select “HO2S1 (B1) P0134” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
3. Touch “START”.
4. Let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 4.

HO2S1 (B1) P0134	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
THRTL POS SEN	XXX V

LEC032A

5. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 10 to 60 seconds.)

ENG SPEED	1,400 - 4,000 rpm
Vehicle speed	64 - 130 km/h (40 - 81 MPH)
B/FUEL SCHDL	3.5 - 17 msec
Selector lever	Suitable position

HO2S1 (B1) P0134	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
THRTL POS SEN	XXX V

LEC033A

If “TESTING” is not displayed after 5 minutes, retry from step 2.

6. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to [EC-206. "Diagnostic Procedure"](#).

During this test, P1148 may be displayed on CONSULT-II screen.

HO2S1 (B1) P0134	
COMPLETED	

LEC034A

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.


WITH GST

1. Start engine and warm it up to normal operating temperature.

DTC P0134 HO2S1

[KA24DE]





2. Set voltmeter probes between ECM terminal 50 (Heated oxygen sensor 1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 - 0.4V.
4. If NG, go to [EC-206, "Diagnostic Procedure"](#).



Wiring Diagram

EC-HO2S1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Heated oxygen sensor 1	<p>[Engine is running]</p> <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm 	0 - Approximately 1.0V (Periodically change)

Diagnostic Procedure

UBS008PP


1. INSPECTION START

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.



3. Disconnect heated oxygen sensor 1 harness connector.

>> GO TO 2.



2. CHECK INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 50 and HO2S1 terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Check harness continuity between ECM terminal 50 or HO2S1 terminal 2 and ground. Refer to Wiring Diagram.

Continuity should not exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-207, "Component Inspection"](#) .

With CONSULT-II

OK or NG

- OK >> GO TO 4.
- NG >> Replace heated oxygen sensor 1.

4. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection HEATED OXYGEN SENSOR 1

UBS008PQ

With CONSULT-II

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Select "MANU TRIG" in "DATA MONITOR" mode, and the trigger point is adjusted to 100%.
4. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)" in Item Selection.
5. Hold engine speed at 2,000 rpm under no load during the following steps.
6. Touch "START" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN


SEF646Y

7. Check the following.
 - "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown below:
 - "HO2S1 (B1)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)" voltage never exceeds 1.0V.

cycle | 1 | 2 | 3 | 4 | 5 |
 HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R

R means HO2S1 MNTR (B1) indicates RICH
L means HO2S1 MNTR (B1) indicates LEAN

SEF217YA




CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Set voltmeter probes between ECM terminal 50 (Heated oxygen sensor 1 signal) and engine ground.
4. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than five times within 10 seconds.
1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation

HEATED OXYGEN SENSOR 1

Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .

UBS008PR

DTC P0138 HO2S2

PF2:226A0

Component Description


UBS008PS

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

UBS008PT


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle up to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle up to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

UBS008PU

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether or not the voltage is too high during various driving conditions such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0138	Heated oxygen sensor 2 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Heated oxygen sensor 2

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for two minutes.
6. If 1st trip DTC is detected, go to [EC-212, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y


WITH GST

1. Start engine and warm it up to the normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 10 seconds.
 3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
 4. Let engine idle for two minutes.
 5. Turn ignition switch "OFF" and wait at least 10 seconds.
 6. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
 7. Let engine idle for two minutes.
 8. Select "Mode 3" with GST.
 9. If NG, go to [EC-212, "Diagnostic Procedure"](#).
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**


Wiring Diagram

EC-HO2S2-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 10
- LP : 3



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Revving engine from idle up to 3,000 rpm quickly after the following conditions are met. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - Approximately 1.0V


Diagnostic Procedure

UBS008PY

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.

**2. CHECK INPUT SIGNAL CIRCUIT**

1. Disconnect heated oxygen sensor 2 harness connector and ECM harness connector.
2. Check harness continuity between ECM terminal 56 and HO2S2 terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Check harness continuity between ECM terminal 56 or HO2S2 terminal 1 and ground. Refer to Wiring Diagram.

Continuity should not exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between heated oxygen sensor 2 and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK GROUND CIRCUIT

1. Check harness continuity between heated oxygen sensor 2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between heated oxygen sensor 2 and engine ground

>> Repair open circuit or short to power in harness or connectors.

6. CHECK HARNESS CONNECTOR

Check heated oxygen sensor 2 harness connector for water.

Water should not exist.

OK or NG

- OK >> GO TO 7.
NG >> Repair or replace harness connector.

7. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-213, "Component Inspection"](#)

OK or NG

- OK >> GO TO 8.
NG >> Replace heated oxygen sensor 2.

8. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

**Component Inspection
HEATED OXYGEN SENSOR 2**

UBS008PZ

Ⓟ With CONSULT-II


1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 5 seconds.
4. Start engine and keep engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minute.

- Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

- Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "HO2S2 (B1)" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

- Reconnect all harness connectors disconnected.
- Start engine and warm it up to the normal operating temperature.
- Turn ignition switch "OFF" and wait at least 5 seconds.
- Start engine and keep engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
- Let engine idle for one minute.

- Set voltmeter probes between ECM terminals 56 (Heated oxygen sensor 2 signal) and engine ground.
- Check the voltage when revving up to 4,000 rpm under no load at least 10 times.


(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.56V at least once.
If the voltage is above 0.56V at step 4, step 5 is not necessary.

- Check the voltage when revving up to 5,000 rpm under no load. Or keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.

The voltage should be below 0.54V at least once.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation
HATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L


M

DTC P0139 HO2S2

Component Description

UBS008Q1

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

UBS008Q2


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle up to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle up to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

UBS008Q3

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the switching response of the sensor's voltage is faster than specified during various driving conditions such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0139	Heated oxygen sensor 2 circuit slow response	It takes more time for the sensor to respond between rich and lean than the specified time.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors ● Intake air leaks

DTC Confirmation Procedure

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Open engine hood before conducting following procedure

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 5 seconds.
3. Start engine and keep engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Select "HO2S2 (B1) P0139" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II and follow the instruction of CONSULT-II.



6. Make sure the "OK" is displayed after touching "SELF-DIAG RESULTS".
If NG is displayed, refer to [EC-220, "Diagnostic Procedure"](#).
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - Turn ignition switch "ON" and leave the vehicle in a cool place (soak the vehicle).
 - Turn ignition switch "ON" and select "COOLANT TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
 - Start engine and warm it up while monitoring "COOLANT TEMP/S" indication on CONSULT-II.
 - When "COOLANT TEMP/S" indication reach to 70°C (158°F), go to step 3.

Overall Function Check


Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 5 seconds.
3. Start engine and keep engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeter probes between ECM terminals 56 (Heated oxygen sensor 2 signal) and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should change at more than 0.06V for 1 second during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.




The voltage should change at more than 0.06V for 1 second during this procedure.

8. If NG, go to [EC-220, "Diagnostic Procedure"](#) .



Wiring Diagram

EC-HO2S2-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



: Detectable line for DTC
 : Non-detectable line for DTC
EP : EARLY PRODUCTION
LP : LATE PRODUCTION
 *1 EP : 10
LP : 3



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Revving engine from idle up to 3,000 rpm quickly after the following conditions are met. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - Approximately 1.0V


Diagnostic Procedure

UBS008Q7

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 or P0172 detected?
Is it difficult to start engine?**



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-60. "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 or P0172 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171 or P0172. Refer to [EC-225](#) or [EC-232](#).
No >> GO TO 3.

3. CHECK INPUT SIGNAL CIRCUIT

1. Disconnect heated oxygen sensor 2 harness connector and ECM harness connector.
2. Check harness continuity between ECM terminal 56 and HO2S2 terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

3. Check harness continuity between ECM terminal 56 or HO2S2 terminal 1 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between heated oxygen sensor 2 and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK GROUND CIRCUIT

1. Check harness continuity between heated oxygen sensor 2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

OK >> GO TO 7.

NG >> GO TO 6

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between heated oxygen sensor 2 and engine ground

>> Repair open circuit or short to power in harness or connectors.

7. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-220, "Diagnostic Procedure"](#) .

K or NG

OK >> GO TO 8.

NG >> Replace heated oxygen sensor 2.

8. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

Component Inspection HEATED OXYGEN SENSOR 2

UBS008Q8

With CONSULT-II


1. Reconnect all harness connectors disconnected.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 5 seconds.
4. Start engine and keep engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minute.

- Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

- Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.




"HO2S2 (B1)" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "HO2S2 (B1)" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

- Reconnect all harness connectors disconnected.
- Start engine and warm it up to the normal operating temperature.
- Turn ignition switch "OFF" and wait at least 5 seconds.
- Start engine and keep engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
- Let engine idle for one minute.
- Set voltmeter probes between ECM terminals 56 (Heated oxygen sensor 2 signal) and engine ground.
- Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.56V at least once.
If the voltage is above 0.56V at step 4, step 5 is not necessary.
- Check the voltage when revving up to 5,000 rpm under no load. Or keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.
The voltage should be below 0.54V at least once.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation
HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

DTC P0171 FUEL INJECTION SYSTEM FUNCTION

PFP:16600

On Board Diagnosis Logic

UBS008QA

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensor 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and lights up the MIL (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensor 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection & mixture ratio control	Injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0171	Fuel injection system too lean	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	<ul style="list-style-type: none"> ● Intake air leaks ● Heated oxygen sensor 1 ● Injectors ● Exhaust gas leaks ● Incorrect fuel pressure ● Lack of fuel ● Mass air flow sensor ● Incorrect PCV hose connection

DTC Confirmation Procedure


UBS008QB

NOTE:


If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON and select “SELF-LEARNING CONT” in “WORK SUPPORT” mode with CONSULT-II.
4. Clear the self-learning control coefficient by touching “CLEAR”.
5. Select “DATA MONITOR” mode with CONSULT-II.




6. Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0171 should be detected at this stage, if a malfunction exists. If so, go to [EC-228, "Diagnostic Procedure"](#).
7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction.
8. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-228, "Diagnostic Procedure"](#). If engine does not start, visually check for exhaust and intake air leak.



 **WITH GST**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 7" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and run it for at least 10 minutes at idle speed.
8. Select "MODE 7" with GST. The 1st trip DTC P0171 should be detected at this stage, if a malfunction exists. If so, go to [EC-228, "Diagnostic Procedure"](#).
9. If it is difficult to start engine at step 8, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-228, "Diagnostic Procedure"](#). If engine does not start, visually check for exhaust and intake air leak.



DTC P0171 FUEL INJECTION SYSTEM FUNCTION




[KA24DE]

UBS008QC

Wiring Diagram

EC-FUEL-01

A
EC
C
D
E
F
G
H
I
J
K
L
M




BBWA0441E

Diagnostic Procedure

1. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

2. CHECK FOR INTAKE AIR LEAK AND PCV HOSE

1. Listen for an intake air leak between the mass air flow sensor and the intake manifold.
2. Check PCV hose connection.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.

3. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 1 harness connector and ECM harness connector.
3. Check harness continuity between ECM terminal 50 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.


4. Check harness continuity between ECM terminal 50 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero.
Refer to [EC-45, "FUEL PRESSURE RELEASE"](#) .
2. Install fuel pressure gauge and check fuel pressure.

At idling

When fuel pressure regulator valve vacuum hose is connected. **235 kPa (2.4 kg/cm² , 34 psi)**

When fuel pressure regulator valve vacuum hose is disconnected. **294 kPa (3.0 kg/cm² , 43 psi)**

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-541](#) .)
- Fuel pressure regulator (Refer to [EC-47](#) .)
- Fuel lines (Refer to [MA-18, "Checking Fuel Lines"](#) .)
- Fuel filter for clogging

>> Repair or replace.

6. CHECK MASS AIR FLOW SENSOR

Refer to [EC-231, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-143, "DTC P0102, P0103 MAF SENSOR"](#) .

A
EC
C
D
E
F
G
H
I
J
K
L
M

7. CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Install all parts removed.
2. Start engine.
3. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
4. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
IACV-AAC/V	XXX %

SEF981Z


Without CONSULT-II

1. Install all parts removed.
2. Start engine.
3. Listen to each injector operating sound.
Clicking noise should be heard.

OK or NG

OK >> GO TO 8.

NG >> Perform trouble diagnosis for injector, refer to [EC-532](#), "[INJECTOR CIRCUIT](#)".



8. REMOVE INJECTOR

1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
2. Turn ignition switch OFF.
3. Remove injector with fuel tube assembly.
Keep fuel hose and all injectors connected to injector gallery. The injector harness connectors should remain connected.

>> GO TO 9.

9. CHECK INJECTOR

Refer to [EC-231](#), "[Component Inspection](#)".

OK or NG

OK >> GO TO 10.

NG >> Replace injectors from which fuel does not spray out. Always replace O-ring with new one.

10. CHECK INTERMITTENT INCIDENT

Perform [EC-120](#), "[TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT](#)".

>> INSPECTION END.

Component Inspection

MASS AIR FLOW SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

at idling : 0.9 - 5.8 g-m/sec

at 2,500 rpm : 7.5 - 13.2 g-m/sec

With GST

1. Start engine and warm it up to normal operating temperature.
2. Check mass air flow sensor signal in MODE 1 with GST.


at idling : 0.9 - 5.8 g-m/sec

at 2,500 rpm : 7.5 - 13.2 g-m/sec

INJECTOR

1. Disconnect all ignition coil harness connectors.
2. Place pans or saucers under each injector.
3. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors.

Fuel should be sprayed evenly for each cylinder.



A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P0172 FUEL INJECTION SYSTEM FUNCTION

PFP:16600

On Board Diagnosis Logic

UBS008QG

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensor 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and lights up the MIL (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensor 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection & mixture ratio control	Injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0172	Fuel injection system too rich	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Injectors ● Exhaust gas leaks ● Incorrect fuel pressure ● Mass air flow sensor

DTC Confirmation Procedure


UBS008QH

NOTE:


If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

④ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON and select “SELF-LEARNING CONT” in “WORK SUPPORT” mode with CONSULT-II.
4. Clear the self-learning control coefficient by touching “CLEAR”.
5. Select “DATA MONITOR” mode with CONSULT-II.



6. Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists. If so, go to [EC-235, "Diagnostic Procedure"](#).
7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction.
8. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-235, "Diagnostic Procedure"](#). If engine does not start, remove ignition plugs and check for fouling, etc.




④ WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.

DTC P0172 FUEL INJECTION SYSTEM FUNCTION

[KA24DE]

3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 7" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and run it for at least 10 minutes at idle speed.
8. Select "MODE 7" with GST. The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists. If so, go to [EC-235, "Diagnostic Procedure"](#).
9. If it is difficult to start engine at step 8, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-235, "Diagnostic Procedure"](#). If engine does not start, remove ignition plugs and check for fouling, etc.



A

EC

C

D

E

F

G

H

I

J

K

L

M






DTC P0172 FUEL INJECTION SYSTEM FUNCTION

[KA24DE]

UBS008Q1

Wiring Diagram

EC-FUEL-01




BBWA0441E

Diagnostic Procedure

1. CHECK FOR EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

2. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 1 harness connector and ECM harness connector.
3. Check harness continuity between ECM terminal 50 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.


4. Check harness continuity between ECM terminal 50 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK FUEL PRESSURE

1. Release fuel pressure to zero.
Refer to [EC-45, "FUEL PRESSURE RELEASE"](#) .
2. Install fuel pressure gauge and check fuel pressure.

At idling

When fuel pressure regulator valve vacuum hose is connected. Approximately 235 kPa (2.4 kg/cm² , 34 psi)

When fuel pressure regulator valve vacuum hose is disconnected. Approximately 294 kPa (3.0 kg/cm² , 43 psi)

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-541](#) .)
- Fuel pressure regulator (Refer to [EC-47](#) .)

>> Repair or replace.

5. CHECK MASS AIR FLOW SENSOR

Refer to [EC-237, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-143, "DTC P0102, P0103 MAF SENSOR"](#) .

6. CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Install all parts removed.
2. Start engine.
3. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
4. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
IACV-AAC/V	XXX %

SEF981Z


Without CONSULT-II

1. Install all parts removed.
2. Start engine.
3. Listen to each injector operating sound.
Clicking noise should be heard.

OK or NG

OK >> GO TO 7.

NG >> Perform trouble diagnosis for injectors, [EC-532, "INJECTOR CIRCUIT"](#) .



7. REMOVE INJECTOR

1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
2. Turn ignition switch OFF.
3. Remove injector assembly.
Keep fuel hose and all injectors connected to injector gallery.

>> GO TO 8.

8. CHECK INJECTOR

Refer to [EC-237, "Component Inspection"](#) .

OK or NG

OK (Does not drip)>>GO TO 9.

NG (Drips)>>Replace the injectors from which fuel is dripping. Always replace O-ring with new one.

9. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component Inspection
MASS AIR FLOW SENSOR**

UBS008QK

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

at idling	: 0.9 - 5.8 g-m/sec
at 2,500 rpm	: 7.5 - 13.2 g-m/sec

With GST

1. Start engine and warm it up to normal operating temperature.
2. Check mass air flow sensor signal in MODE 1 with GST.

at idling	: 0.9 - 5.8 g-m/sec
at 2,500 rpm	: 7.5 - 13.2 g-m/sec

INJECTOR

1. Disconnect all injector harness connectors.
2. Disconnect all ignition coil harness connectors.
3. Prepare pans or saucers under each injectors.
4. Crank engine for about 3 seconds.
Make sure fuel does not drip from injector.


DTC P0181 FTT SENSOR

PFP:22630

Component Description

UBS008QM

The fuel tank temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.




<Reference data>

Fluid temperature °C (°F)	Voltage* V	Resistance kΩ
20 (68)	3.5	2.3 - 2.7
50 (122)	2.2	0.79 - 0.90

*: These data are reference values and are measured between ECM terminal 60 (Fuel tank temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



On Board Diagnosis Logic

UBS008QN

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0181 0181	Fuel tank temperature sensor circuit range/performance	Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signals from engine coolant temperature sensor and intake air temperature sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Fuel tank temperature sensor

DTC Confirmation Procedure

UBS008QO

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 10 seconds.
If 1st trip DTC is detected, go to [EC-241, "Diagnostic Procedure"](#)
If 1st trip DTC is not detected, go to following step.
4. Check "COOLAN TEMP/S" indication.
If the indication is less than 60°C (140°F), the result will be OK.
If the indication is above 60°C (140°F), go to the following step.
5. Cool engine down until "COOLAN TEMP/S" indication decreases to less than 60°C (140°F).
6. Wait at least 10 seconds.
7. If 1st trip DTC is detected, go to [EC-241, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y



WITH GST

Follow the procedure "WITH CONSULT-II".

A

EC

C

D

E

F

G

H

I

J

K

L

M





DTC P0181 FTT SENSOR

[KA24DE]

UBS008QP

Wiring Diagram


EC-FTTS-01



WBWA0013E

Diagnostic Procedure**1. CHECK POWER SUPPLY**

1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.

**2. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors B103, M91
- Harness connectors M81, F36
- Harness for open or short between ECM and fuel tank temperature sensor

>> Repair harness or connector.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check harness continuity between terminal 4 and body ground. Refer to wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
 NG >> Repair open circuit or short to power in harness or connectors.

4. CHECK FUEL TANK TEMPERATURE SENSOR

Refer to [EC-242. "Component Inspection"](#)

OK or NG

- OK >> GO TO 5.
 NG >> Replace fuel tank temperature sensor.

5. CHECK INTERMITTENT INCIDENT


Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component Inspection
FUEL TANK TEMPERATURE SENSOR**


UBS008QR

1. Remove fuel level sensor unit.



2. Check resistance by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90



**Removal and Installation
FUEL TANK TEMPERATURE SENSOR**

UBS008QS

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .


DTC P0182, P0183 FTT SENSOR

PFP:22630

Component Description

UBS008QT

The fuel tank temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.




<Reference data>

Fluid temperature °C (°F)	Voltage* V	Resistance kΩ
20 (68)	3.5	2.3 - 2.7
50 (122)	2.2	0.79 - 0.90

*: These data are reference values and are measured between ECM terminal 60 (Fuel tank temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



On Board Diagnosis Logic

UBS008QU

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0182	Fuel tank temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Fuel tank temperature sensor
P0183	Fuel tank temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

UBS008QV

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 10 seconds.
4. If 1st trip DTC is detected, go to [EC-245, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

WITH GST

Follow the procedure "WITH CONSULT-II".


DTC P0182, P0183 FTT SENSOR

[KA24DE]


UBS008QW

Wiring Diagram

EC-FTTS-01




- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- EP : 6
- LP : 7



WBWA0013E

Diagnostic Procedure**1. CHECK POWER SUPPLY**

1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.

**2. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors B103, M91
- Harness connectors M81, F36
- Harness for open or short between ECM and fuel tank temperature sensor

>> Repair harness or connector.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check harness continuity between terminal 4 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to power in harness or connectors.

4. CHECK FUEL TANK TEMPERATURE SENSOR

Refer to [EC-246, "Component inspection"](#) .

OK or NG

- OK >> GO TO 5.
NG >> Replace fuel tank temperature sensor.

5. CHECK INTERMITTENT INCIDENT


Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component inspection
FUEL TANK TEMPERATURE SENSOR**


UBS008QY

1. Remove fuel level sensor unit.



2. Check resistance by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90



**Removal and Installation
FUEL TANK TEMPERATURE SENSOR**

UBS008QZ

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

[KA24DE]

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

PFP:00019

On Board Diagnosis Logic

UBS008R0

This diagnosis checks whether the engine coolant temperature is extraordinary high, even when the load is not heavy.

When malfunction is detected, the malfunction indicator lamp (MIL) will light up even in the first trip.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0217 0217	Engine coolant over temperature condition	Engine coolant temperature is excessively high under normal engine speed.	<ul style="list-style-type: none">● Cooling fan● Thermostat● Improper ignition timing● Engine coolant temperature sensor● Blocked radiator● Blocked front end (Improper fitting of nose mask)● Crushed vehicle frontal area (Vehicle frontal is collided but not repaired)● Blocked air passage by improper installation of front fog lamp or fog lamps● Improper mixture ratio of coolant● Damaged bumper For more information, refer to EC-249, "Main 11 Causes of Overheating" .

CAUTION:

When a malfunction is indicated, be sure to replace the coolant. Refer to [MA-16, "Changing Engine Coolant"](#). Also, replace the engine oil. Refer to [MA-20, "Changing Engine Oil"](#).

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-14, "ANTI-FREEZE COOLANT MIXTURE RATIO"](#).
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Overall Function Check

UBS008R1

Use this procedure to check the overall function of the coolant overtemperature enrichment protection check, a DTC might not be confirmed.

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high-pressure fluid escaping from the radiator.

Wrap a thick cloth around the cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

1. Check the coolant level and mixture ratio (using coolant tester) in the reservoir tank and radiator.
Allow engine to cool before checking coolant level and mixture ratio.
 - If the coolant level in the reservoir and/or radiator is below the proper range, go to [EC-248, "Diagnostic Procedure"](#).
 - If the coolant mixture ratio is out of the range of 45 to 55%, replace the coolant in the following procedure [MA-16, "Changing Engine Coolant"](#).
- a. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant from a kettle. Be sure to use coolant with the proper mixture ratio. Refer to [MA-14, "ANTI-FREEZE COOLANT MIXTURE RATIO"](#).
- b. After refilling coolant, run engine to ensure that no water-flow noise is emitted.
- c. After checking or replacing coolant, go to step 3 below.
2. Ask the customer if engine coolant has been added. If it has been added, go to [EC-248, "Diagnostic Procedure"](#). After repair, go to the next step.
3. Start engine and let it idle.
4. Make sure that A/C switch is "OFF" and air conditioner is not operating. If NG, check air conditioner circuit. Refer to [MTC-25, "TROUBLE DIAGNOSES"](#). After repair, go to the next step.

5. Start engine and make sure that cooling fan operates.
Be careful not to overheat engine.
 If NG, check cooling fan. Refer to [CO-16, "COOLING FAN \(CRANKSHAFT DRIVEN\)"](#) . After repair, go to the next step.
6. Check for blocked coolant passage.
 - a. Warm up engine to normal operating temperature, then grasp radiator upper hose and lower hose and make sure that coolant flows.
 If NG, go to [EC-248, "Diagnostic Procedure"](#) . After repair, go to the next step.
Be extremely careful not to touch any moving or adjacent parts.
7. Check for blocked radiator air passage.
 - a. When aftermarket fog lamps have been installed, check for damaged fans and clogging in the condenser and radiator.
 - b. Check the front end for clogging caused by insects or debris.
 - c. Check for improper fitting of front-end cover, damaged radiator grille or bumper, damaged vehicle front.
 If NG, take appropriate action and then go to the next step.
8. Check function of ECT sensor.
 Refer to step 6 of [EC-248, "Diagnostic Procedure"](#) .
 If NG, replace ECT sensor and go to the next step.
9. Check ignition timing. Refer to [EC-73, "Basic Inspection"](#) .
 Make sure that ignition timing is $20^{\circ} \pm 2^{\circ}$ at idle.
 If NG, adjust ignition timing and then recheck.

Diagnostic Procedure

UBS008R2

1. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.


Testing pressure : 157 kPa (1.6 kg/cm² , 23 psi)

CAUTION:

Higher than the specified pressure may cause radiator damage.
 Pressure should not drop.

OK or NG

- OK >> GO TO 2.
 NG >> Check the following for leak.
- Hose
 - Radiator
 - Water pump
 Refer to [CO-10, "WATER PUMP"](#) .



2. CHECK RADIATOR CAP

Refer to [EC-250, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 3.
 NG >> Replace radiator cap.

3. CHECK THERMOSTAT

Refer to [EC-250, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 4.
 NG >> Replace thermostat.

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION [KA24DE]

4. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-250, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace engine coolant temperature sensor.

5. CHECK MAIN 11 CAUSES

If the cause cannot be isolated, go to [EC-249, "Main 11 Causes of Overheating"](#) .

>> INSPECTION END

Perform FINAL CHECK by the following procedure after repair is completed.

1. Warm up engine. Run the vehicle for at least 20 minutes. Pay attention to engine coolant temperature gauge on the instrument panel. If the reading shows an abnormally high temperature, another part may be malfunctioning.
2. Stop vehicle and let engine idle. Check the intake and exhaust systems for leaks by listening for noise or visually inspecting the components.
3. Allow engine to cool and visually check for oil and coolant leaks. Then, perform "OVERALL FUNCTION CHECK".

Main 11 Causes of Overheating

UBS008R3

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> ● Blocked radiator ● Blocked condenser ● Blocked radiator grille ● Blocked bumper 	● Visual	No blocking	—
	2	● Coolant mixture	● Coolant tester	50 - 50% coolant mixture	See MA-12, "RECOMMENDED FLUIDS AND LUBRICANTS" .
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See MA-16, "Changing Engine Coolant" .
	4	● Radiator cap	● Pressure tester	78 - 98 kPa (0.8 - 1.0 kg/cm ² , 11 - 14 psi) 59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See CO-8, "System Check" .
ON*2	5	● Coolant leaks	● Visual	No leaks	See CO-8, "System Check" .
ON*2	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot	See CO-13, "THERMOSTAT" and CO-14, "RADIATOR" .
OFF	7	● Combustion gas leak	● Color checker chemical tester 4 Gas analyzer	Negative	—
ON*3	8	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See MA-16, "Changing Engine Coolant" .
OFF*4	9	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See CO-8, "System Check" .
OFF	10	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-30, "CYLINDER HEAD" .
	11	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See EM-46, "CYLINDER BLOCK" .

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

[KA24DE]

- *1: Turn the ignition switch ON.
- *2: Engine running at 3,000 rpm for 10 minutes.
- *3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.
- *4: After 60 minutes of cool down time.


For more information, refer to [CO-6, "OVERHEATING CAUSE ANALYSIS"](#)

Component Inspection RADIATOR CAP

UBS008R4

Apply pressure to cap with a tester.

Radiator cap relief pressure : 78 - 98 kPa (0.8 - 1.0 kg/cm² , 11 - 14 psi)



THERMOSTAT


1. Check valve seating condition at normal room temperatures.
It should seat tightly.
2. Check valve opening temperature and valve lift.

Valve opening temperature : 76.5°C (170°F) [standard]

Valve lift : More than 8 mm/90°C (0.31 in/194°F)


3. Check if valve is closed at 5°C (9°F) below valve opening temperature.

For details, refer to [CO-13, "THERMOSTAT"](#) .




ENGINE COOLANT TEMPERATURE SENSOR

Check resistance as shown in the figure.



<Reference data>

Temperature C (F)	Resistance k
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260



DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

[KA24DE]

DTC P0300 - P0304 NO. 4 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

PF0:00020

On Board Diagnosis Logic

UBS008R6

When a misfire occurs, engine speed will fluctuate. If the engine speed fluctuates enough to cause the CKP sensor signal to vary, the ECM can determine that a misfire is occurring.

Sensor	Input Signal to ECM	ECM function
Crankshaft position sensor (OBD)	Engine speed	On board diagnosis of misfire

The misfire detection logic consists of the following two conditions.

- One Trip Detection Logic (Three Way Catalyst Damage)**
 On the first trip that a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MIL will blink.
 When a misfire condition occurs, the ECM monitors the CKP sensor signal every 200 engine revolutions for a change.
 When the misfire condition decreases to a level that will not damage the TWC, the MIL will turn off.
 If another misfire condition occurs that can damage the TWC on a second trip, the MIL will blink.
 When the misfire condition decreases to a level that will not damage the TWC, the MIL will remain on.
 If another misfire condition occurs that can damage the TWC, the MIL will begin to blink again.
- Two Trip Detection Logic (Exhaust quality deterioration)**
 For misfire conditions that will not damage the TWC (but will affect vehicle emissions), the MIL will only light when the misfire is detected on a second trip. During this condition, the ECM monitors the CKP sensor signal every 1,000 engine revolutions.
 A misfire malfunction can be detected on any one cylinder or on multiple cylinders.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0300 0300	Multiple cylinder misfire detected	Multiple cylinder misfire.	<ul style="list-style-type: none"> ● Improper spark plug ● Insufficient compression
P0301 0301	No.1 cylinder misfire detected	No. 1 cylinder misfires.	<ul style="list-style-type: none"> ● Incorrect fuel pressure ● The injector circuit is open or shorted
P0302 0302	No. 2 cylinder misfire detected	No. 2 cylinder misfires.	<ul style="list-style-type: none"> ● Fuel injectors ● Intake air leak
P0303 0303	No. 3 cylinder misfire detected	No. 3 cylinder misfires.	<ul style="list-style-type: none"> ● The ignition secondary circuit is open or shorted
P0304 0304	No. 4 cylinder misfire detected	No. 4 cylinder misfires.	<ul style="list-style-type: none"> ● Lack of fuel ● Drive plate/Fly wheel ● Heated oxygen sensor 1 ● Incorrect distributor rotor ● EGR valve

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON, and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF and wait at least 5 seconds.
4. Start engine again and drive at 1,500 to 3,000 rpm for at least 3 minutes.
Hold the accelerator pedal as steady as possible.

NOTE:

Refer to the freeze frame data for the test driving conditions.

5. If 1st trip DTC is detected, go to [EC-252, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANT TEMP/S	XXX °C

SEF174Y

WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

1. CHECK FOR INTAKE AIR LEAK

1. Start engine and run it at idle speed.
2. Listen for the sound of the intake air leak.

OK or NG

- OK >> GO TO 2.
NG >> Discover air leak location and repair.

2. CHECK FOR EXHAUST SYSTEM CLOGGING

Stop engine and visually check exhaust tube, three way catalyst (manifold) and muffler for dents.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace it.

3. CHECK EGR FUNCTION

Perform DTC Confirmation Procedure for DTC P1402 EGR FUNCTION (OPEN).

Refer to [EC-459](#) .

OK or NG

- OK >> GO TO 4.
NG >> Repair EGR system.

4. PERFORM POWER BALANCE TEST

 **With CONSULT-II**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
IACV-AAC/V	XXX %


SEF981Z

 **Without CONSULT-II**

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes or No

- Yes >> GO TO 5.
 No >> GO TO 8.




5. CHECK INJECTOR

Does each injector make an operating sound at idle?

Yes or No

- Yes >> GO TO 6.
 No >> Check injector(s) and circuit(s). Refer to [EC-532](#).
"INJECTOR CIRCUIT".




A
EC
C
D
E
F
G
H
I
J
K
L
M

6. CHECK IGNITION SPARK

1. Turn ignition switch OFF.
2. Disconnect ignition wire from spark plug.
3. Connect a known good spark plug to the ignition wire.
4. Place end of spark plug against a suitable ground and crank engine.
5. Check for spark.

OK or NG

- OK >> GO TO 8.
NG >> GO TO 7.



7. CHECK IGNITION WIRES

Refer to [EC-257, "Component Inspection"](#) .

OK or NG


- OK >> Check distributor rotor head for incorrect parts. Check ignition coil, power transistor and their circuits. Refer to [EC-525, "IGNITION SIGNAL"](#) .
NG >> Replace.

8. CHECK SPARK PLUGS

Remove the spark plugs and check for fouling, etc.

OK or NG

- OK >> GO TO 9.
NG >> Repair or replace spark plug(s) with standard type one(s). For spark plug type, refer to [MA-22, "Changing Spark Plugs"](#) .



9. CHECK COMPRESSION PRESSURE

Check compression pressure.

Refer to [EM-30, "CHECKING COMPRESSION PRESSURE"](#) .

Standard	: 1,226 kPa (12.5 kg/cm² , 178 psi)/300 rpm
Minimum	: 1,030 kPa (10.5 kg/cm² , 149 psi)/300 rpm
Difference between each cylinder	: 98 kPa (1.0 kg/cm² , 14 psi)/300 rpm

OK or NG

- OK >> GO TO 10.
NG >> Check pistons, piston rings, valves, valve seats and cylinder head gaskets.


10. CHECK FUEL PRESSURE

1. Install any parts removed.
2. Release fuel pressure to zero. Refer to [EC-45, "FUEL PRESSURE RELEASE"](#).
3. Install fuel pressure gauge and check fuel pressure. Refer to [EC-46, "FUEL PRESSURE CHECK"](#).

At idle : Approx. 235 kPa (2.4 kg/cm² , 34 psi)

OK or NG

- OK >> GO TO 12.
 NG >> GO TO 11.



11. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-541, "FUEL PUMP CIRCUIT"](#) .)
- Fuel pressure regulator (Refer to [EC-47, "Fuel Pressure Regulator Check"](#) .)
- Fuel lines (Refer to [MA-18, "Checking Fuel Lines"](#)).
- Fuel filter for clogging

>> Repair or replace.

12. CHECK IGNITION TIMING

1. Check the following items. Refer to [EC-73, "Basic Inspection"](#) .

Items	Specifications
Ignition timing	20° ± 2° BTDC
Base idle speed	750 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF
Target idle speed	800 ± 50 rpm (in P or N position)

OK or NG

- OK >> GO TO 13.
 NG >> Adjust ignition timing.

13. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-257, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 14.
 NG >> Replace heated oxygen sensor 1.

14. CHECK MASS AIR FLOW SENSOR

 **With CONSULT-II**

Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

at idling : 0.9 - 5.8 g-m/sec
at 2,500 rpm : 7.5 - 13.2 g-m/sec

 **With GST**

Check mass air flow sensor signal in MODE 1 with GST.

at idling : 0.9 - 5.8 g-m/sec
at 2,500 rpm : 7.5 - 13.2 g-m/sec

OK or NG

OK >> GO TO 16.
NG >> GO TO 15.

15. CHECK CONNECTORS

Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds.

Refer to [EC-143, "DTC P0102, P0103 MAF SENSOR"](#) .

OK or NG

NG >> Repair or replace it.

16. CHECK SYMPTOM MATRIX CHART

Check items on the rough idle symptom in [EC-83, "Symptom Matrix Chart"](#) .

OK or NG

OK >> GO TO 17.
NG >> Repair or replace.

17. ERASE THE 1ST TRIP DTC

Some tests may cause a 1st trip DTC to be set.

Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to [EC-60, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .

>> GO TO 18.

18. CHECK INTERMITTENT INCIDENT


Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection

INJECTOR

Does each injector make an operating sound at idle?




MEC703B

IGNITION WIRES

1. Inspect wires for cracks, damage, burned terminals and for improper fit.
2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks.

Resistance : 13.6 - 18.4 kΩ/m (4.15 - 5.61 kΩ/ft) at 25°C (77°F)


If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.



SEF174P

SPARK PLUGS

Remove the spark plugs and check for fouling, etc.



SEF156I

HEATED OXYGEN SENSOR 1

Ⓟ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode, and the trigger point is adjusted to 100%.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)" in item selection.
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "START" on CONSULT-II screen.
6. Check the following.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y


DTC P0327, P0328 KS

PF0:22060

Component Description

UBS008RB

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.



On Board Diagnosis Logic

UBS008RC

The MIL will not light up for these diagnoses.

DTC No.	Trouble diagnosis name	DTC detected condition	Possible cause
P0327	Knock sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Knock sensor
P0328	Knock sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

UBS008RD

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 5 seconds at idle speed.
3. If 1st trip DTC is detected, go to [EC-261, "Diagnostic Procedure"](#)






WITH GST

Follow the procedure "WITH CONSULT-II".

Wiring Diagram

UBS008RE

EC-KS-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
64	W	Knock sensor	[Engine is running] ● Idle speed	Approximately 2.4V


Diagnostic Procedure

UBS008RF

1. RETIGHTEN GROUND SCREWS

Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK INPUT SIGNAL CIRCUIT-1

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 64 and ground.


Resistance : Approximately 500 - 620 kΩ [at 25°C (77°F)]

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F2, F101
- Harness for open or short between knock sensor and ECM.

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK KNOCK SENSOR

Refer to [EC-262, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Replace knock sensor.

5. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection KNOCK SENSOR

UBS008RG


Use an ohmmeter which can measure more than 10 M Ω .

1. Disconnect knock sensor harness connector.
2. Check resistance between terminal 1 and ground.

Resistance : 500 - 620 k Ω [at 25°C (77°F)]

CAUTION:

Discard any knock sensors that have been dropped or physically damaged. Use only new ones.



UBS008RH

Removal and Installation KNOCK SENSOR

Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .

DTC P0335 CKP SENSOR (OBD)

PF2:23731

UBS008RI

Component Description

The crankshaft position sensor (OBD) is located on the transaxle housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.



When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not directly used to control the engine system. It is used only for the on board diagnosis.



On Board Diagnosis Logic

UBS008RJ

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335	Crankshaft position sensor (POS) circuit	<ul style="list-style-type: none"> The crankshaft position sensor (POS) signal is not detected by the ECM during the first few seconds of engine cranking. The proper pulse signal from the crankshaft position sensor (POS) is not sent to ECM while the engine is running. The crankshaft position sensor (POS) signal is not in the normal pattern during engine running. 	<ul style="list-style-type: none"> Harness or connectors (The crankshaft position sensor (OBD) circuit is open) Crankshaft position sensor (OBD) Dead battery

DTC Confirmation Procedure

UBS008RK

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

- Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- Start engine and run it for at least 15 seconds at idle speed.
- If 1st trip DTC is detected, go to [EC-265, "Diagnostic Procedure"](#)

WITH GST

Follow the procedure "WITH CONSULT-II".





DTC P0335 CKP SENSOR (OBD)

[KA24DE]

UBS008RL

Wiring Diagram

EC-CKPS-01



BBWA0548E



DTC P0335 CKP SENSOR (OBD)

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (AC Voltage)
47	L	Crankshaft position sensor (OBD)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 0V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 0V★</p> 

★ : Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

UBS008RM

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK INPUT SIGNAL CIRCUIT


1. Disconnect crankshaft position sensor (OBD) and ECM harness connectors.
2. Disconnect ECM harness connector.
3. Check continuity between ECM terminal 47 and crankshaft position sensor (OBD) terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E202, E32
- Harness connectors E41, F25
- Harness for open or short between crankshaft position sensor (OBD) and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK GROUND CIRCUIT

1. Reconnect ECM harness connector.
2. Check harness continuity between crankshaft position sensor (OBD) terminal 1 and engine ground. Refer to wiring diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E202, E32
- Harness connectors E41, F25
- Harness for open or short between crankshaft position sensor (OBD) and ECM

>> Repair open circuit or short to power in harness or connectors.

6. CHECK SHIELD CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect harness connectors E202, E32.
3. Check harness continuity between harness connector E32 terminal 2 and ground. Refer to wiring diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E41, F25
- Harness for open or short between harness connector E32 and engine ground

>> Repair open circuit or short to power in harness or connectors.

8. CHECK CRANKSHAFT POSITION SENSOR (OBD)

Refer to [EC-267, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace crankshaft position sensor (OBD).

9. CHECK INTERMITTENT INCIDENT


Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection
CRANKSHAFT POSITION SENSOR


UBS008RN

1. Disconnect crankshaft position sensor (OBD) harness connector.
2. Loosen the fixing bolt of the sensor.
3. Remove the sensor.
4. Visually check the sensor for chipping.



5. Check resistance as shown in the figure.

Resistance : Approximately 512 - 632Ω
[at 20°C (68°F)]



DTC P0340 CMP SENSOR



Component Description

The camshaft position sensor is a basic component of the engine control system. It monitors engine speed and piston position. These input signals to the engine control system are used to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for a 1° (POS) signal and 4 slits for a 180° (REF) signal. The wave-forming circuit consists of Light Emitting Diodes (LED) and photo diodes.

The rotor plate is positioned between the LED and the photo diode. The LED transmits light to the photo diode. As the rotor plate turns, the slits cut the light to generate rough-shaped pulses. These pulses are converted into on-off signals by the wave-forming circuit and sent to the ECM.

The distributor is not repairable and must be replaced as an assembly except distributor cap and rotor head.



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0340	Camshaft position sensor circuit	A) Either 1° or 180° signal is not sent to ECM for the first few seconds during engine cranking.	<ul style="list-style-type: none"> ● Harness or connectors (The camshaft position sensor circuit is open or shorted.) ● Camshaft position sensor ● Starter motor (Refer to SC-9.) ● Starting system circuit (Refer to SC-9.) ● Dead (Weak) battery
		B) Either 1° or 180° signal is not sent to ECM often enough while the engine speed is higher than the specified engine speed.	
		C) The relation between 1° and 180° signal is not in the normal range during the specified engine speed.	

DTC Confirmation Procedure

Perform "Procedure for malfunction A" first. If DTC cannot be confirmed, perform "Procedure for malfunction B and C".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V.

PROCEDURE FOR MALFUNCTION A

 **With CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Crank engine for at least 2 seconds.
4. If 1st trip DTC is detected, go to [EC-272, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **With GST**

Follow the procedure "With CONSULT-II".

PROCEDURE FOR MALFUNCTION B AND C

 **With CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and run it for at least 2 seconds at idle speed.
4. If 1st trip DTC is detected, go to [EC-272, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **With GST**

Follow the procedure "With CONSULT-II".

A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P0340 CMP SENSOR

[KA24DE]

UBS008RS

Wiring Diagram

EC-CMPS-01



WBWA0014E





DTC P0340 CMP SENSOR

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	LG/R	ECM relay (Self shutoff)	[Engine is running] [Ignition switch OFF] ● For a few seconds after turning ignition switch OFF	0 - 1V
			[Ignition switch OFF] ● More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
44 48	PU PU	Camshaft position sensor (Reference signal)	[Engine is running] (Warm-up condition) ● Idle speed	0.2 - 0.5V★ (V) 
			[Engine is running] ● Engine speed is 2,000 rpm	0 - 0.5V★ (V) 
49	LG	Camshaft position sensor (Position signal)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.6V★ (V) 
			[Engine is running] ● Engine speed is 2,000 rpm	Approximately 2.5 - 2.6V★ (V) 
67 72	B/P B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
117	B/P	Current return	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)

A

EC

C

D

E

F

G

H

I

J

K

L

M

Diagnostic Procedure

1. CHECK STARTING SYSTEM

Does the engine turn over?
(Does the starter motor operate?)

Yes or No


Yes >> GO TO 2.

No >> Check starting system. Refer to [SC-9, "STARTING SYSTEM"](#) .

2. RETIGHTEN GROUND SCREWS


1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 3.



3. CHECK POWER SUPPLY

1. Disconnect camshaft position (CMP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between terminal 5 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between camshaft position sensor and ECM relay
- Harness for open or short between camshaft position sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between CMP sensor terminal 4 and ECM terminal 49, CMP sensor terminal 3 and ECM terminals 44, 48.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK GROUND CIRCUIT

1. Check harness continuity between CMP sensor terminal 6 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to power in harness or connectors.

7. CHECK CAMSHAFT POSITION SENSOR

Refer to [EC-273, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace camshaft position sensor.

8. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component Inspection
CAMSHAFT POSITION SENSOR**

UBS008RU

1. Reconnect all harness connector disconnected.
2. Start engine and warm it up to normal operating temperature.

DTC P0340 CMP SENSOR

[KA24DE]

3. Check voltage between ECM terminal 49 and engine ground, ECM terminals 44, 48 and engine ground.

Terminals 44, 48 and engine ground		
Condition	Idle	2,000 rpm
Voltage	0.2 - 0.5V	0 - 0.5V
Pulse signal		

Terminal 49 and engine ground		
Condition	Idle	2,000 rpm
Voltage	Approximately 2.6V	Approximately 2.5 - 2.6V
Pulse signal		

LEC035A

Removal and Installation CAMSHAFT POSITION SENSOR

Refer to [EM-13, "OUTER COMPONENT PARTS"](#).

UBS008RV


DTC P0400 EGR FUNCTION

**Description
SYSTEM DESCRIPTION**

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EGR control	EGRC-solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Intake air temperature sensor	Intake air temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Vehicle speed sensor	Vehicle speed		

This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current flows through the solenoid valve is cut. This causes the vacuum to be discharged into the atmosphere. The EGR valve remains closed.


- Low engine coolant temperature
- Engine starting
- High-speed engine operation
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction
- Low intake air temperature



COMPONENT DESCRIPTION


Exhaust Gas Recirculation (EGR) Valve

The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.




EGRC-Solenoid Valve

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an OFF signal, the vacuum signal passes through the solenoid valve. The signal then reaches the EGR valve. When the ECM sends an ON signal, a plunger will then move to cut the vacuum signal from the intake manifold collector to the EGR valve.



On Board Diagnosis Logic

If the absence of EGR flow is detected by EGR temperature sensor under the condition that calls for EGR, a low-flow malfunction is diagnosed.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0400	EGR system closed stuck	<ul style="list-style-type: none"> No EGR flow is detected under conditions that call for EGR. 	<ul style="list-style-type: none"> EGR valve stuck closed EGRC-BPT valve Vacuum hose EGRC-solenoid valve EGR passage EGR temperature sensor Exhaust gas leaks

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.
- P0400 will not be displayed at "SELF-DIAG RESULTS" mode with CONSULT-II even though DTC work support test result is "NG".

WITH CONSULT-II


- Turn ignition switch "ON".
- Check "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II and confirm it is within the range listed below.

COOLAN TEMP/S : Less than 40°C (104°F)


If the value is out of range, park the vehicle in a cool place and allow the engine temperature to stabilize. Do not attempt to lower the coolant temperature with a fan or means other than ambient air. Doing so may produce an inaccurate diagnostic result.

- Start engine and let it idle monitoring "COOLAN TEMP/S" value. When the "COOLAN TEMP/S" value reaches 70°C (158°F), immediately go to the next step.
- Select "EGR SYSTEM P0400" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.

5. Touch "START".




6. Accelerate vehicle to a speed of 40 km/h (25 MPH) once and then stop vehicle with engine running.
If "COMPLETED" appears on CONSULT-II screen, go to step 9.
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.



7. Check the output voltage of "THRTL POS SEN" (at closed throttle position) and note it.

8. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions until "TESTING" changes to "COMPLETED". (It will take approximately 30 seconds or more.)

ENG SPEED	2,000 - 2,800 rpm
Vehicle speed	10 km/h (6 MPH) or more
B/FUEL SCHDL	7.0 - 10.0 msec
THRTL POS SEN	$(X + 0.23) - (X + 0.74) V$ X = Voltage value measured at step 7
Selector lever	Suitable position



If "TESTING" is not displayed after 5 minutes, retry from step 2.

9. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-280, "Diagnostic Procedure"](#).


Overall Function Check

UBS008RZ


Use this procedure to check the overall EGR function. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Disconnect EGRC solenoid valve harness connector. (The 1st trip DTC for EGRC solenoid valve will be displayed, however, ignore it.)



- Check the EGR valve lifting when revving engine from 2,000 rpm to 4,000 rpm quickly under no load using the following methods.



EGR valve should lift up and down without sticking.

If NG, go to [EC-280, "Diagnostic Procedure"](#).


If OK, go to the next step.

- Check voltage between ECM terminal 63 (EGR temperature sensor signal) and ground at idle speed.

Less than 4.5V should exist.

If NG, go to next step.


- Turn ignition switch "OFF".



- Check harness continuity between EGR temperature sensor harness connector terminal 2 and ECM terminal 43 (ECM ground).

Continuity should exist.

- Check "EGR TEMPERATURE SENSOR". Refer to [EC-283, "Component Inspection"](#).



DTC P0400 EGR FUNCTION



[KA24DE]

UBS008S0


Wiring Diagram

EC-EGRC1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



Refer to the following.
 (E43) - SUPER MULTIPLE JUNCTION (SMJ)



BBWA0453E


Diagnostic Procedure

1. CHECK EXHAUST SYSTEM

1. Start engine.
2. Check exhaust pipes and muffler for leaks.

OK or NG


- OK (With CONSULT-II)>>GO TO 2.
- OK (Without CONSULT-II)>>GO TO 3.
- NG >> Repair or replace exhaust system.



2. CHECK VACUUM SOURCE TO EGR VALVE

With CONSULT-II

1. Warm engine up to normal operating temperature.
2. Disconnect vacuum hose to EGR valve.
3. Check for vacuum existence at idle.
Vacuum should not exist at idle.



4. Select "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode with CONSULT-II and turn the solenoid valve OFF.
5. Check for vacuum existence when revving engine from 2,000 rpm up to 4,000 rpm.
Vacuum should exist when revving engine.

OK or NG


- OK >> GO TO 4.
- NG >> GO TO 5.

ACTIVE TEST	
EGRC SOL/V	ON
(EGR)	CUT
MONITOR	
ENG SPEED	XXX rpm

3. CHECK VACUUM SOURCE TO EGR VALVE

⊗ **Without CONSULT-II**

1. Warm engine up to normal operating temperature.
2. Disconnect vacuum hose to EGR valve.
3. Check for vacuum existence at idle.
Vacuum should not exist at idle.
4. Disconnect EGRC solenoid valve harness connector. (The 1st trip DTC for EGRC solenoid valve will be displayed, but ignore it.)
5. Check for vacuum existence when revving engine from 2,000 rpm up to 4,000 rpm.
Vacuum should exist when revving engine.



OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.

4. CHECK EGR VALVE

Refer to [EC-283, "Component Inspection"](#).

OK or NG


- OK >> GO TO 11.
- NG >> Repair or replace EGR valve.

5. CHECK VACUUM HOSE

1. Turn ignition switch OFF.
2. Check vacuum hose for clogging, cracks or improper connection.

OK or NG

- OK (With CONSULT-II)>>GO TO 6.
- OK (Without CONSULT-II)>>GO TO 7.
- NG >> Repair or replace vacuum hose.



6. CHECK EGRC SOLENOID VALVE OPERATION

⊕ **With CONSULT-II**

1. Turn ignition switch ON.
2. Turn EGRC solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.
Clicking noise should be heard.

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 8.

ACTIVE TEST	
EGRC SOL/V	ON
(EGR)	CUT
MONITOR	
ENG SPEED	XXX rpm

SEF716Z

7. CHECK EGRC SOLENOID VALVE OPERATION

⊗ Without CONSULT-II

Check operating sound of the solenoid valve when disconnecting and reconnecting EGRC solenoid valve harness connector. (The DTC or the 1st trip DTC for the EGRC solenoid valve will be displayed, however, ignore it.)

Clicking noise should be heard.

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.

8. CHECK EGRC SOLENOID VALVE CIRCUIT

1. Turn ignition switch "OFF".
2. Check the following.
 - Harness connectors E43, M65
 - Harness connectors M59, F27
 - 10A fuse
 - Harness for open or short between fuse block and EGRC solenoid valve
 - Harness for open or short between ECM and EGRC solenoid valve

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK EGRC SOLENOID VALVE

Refer to [EC-283, "Component Inspection"](#) .

OK or NG

OK >> GO TO 10.

NG >> Replace EGRC solenoid valve.

10. CHECK EGRC-BPT VALVE

Refer to [EC-283, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace EGRC-BPT valve.

11. CHECK EGR TEMPERATURE SENSOR

Refer to [EC-283, "Component Inspection"](#) .

OK or NG

OK >> GO TO 12.

NG >> Replace EGR temperature sensor.


12. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection EGR VALVE

- Apply vacuum to EGR vacuum port with a hand vacuum pump.
EGR valve spring should lift.
- Check for sticking.



EGRC-SOLENOID VALVE

Ⓟ With CONSULT-II

Check air passage continuity.
Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.

ACTIVE TEST	
EGRC SOL/V	ON
(EGR)	CUT
MONITOR	
ENG SPEED	XXX rpm

Condition	Air passage continuity between A and B	Air passage continuity between A and C
EGRC SOLENOID VALVE		
ON	Yes	No
OFF	No	Yes

Operation takes less than 1 second.

LEC036A

⊗ Without CONSULT-II

Check air passage continuity shown in the figure.


Condition	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

Operation takes less than 1 second.

LEC037A


EGRC-BPT VALVE

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂ O, 3.94 inH₂ O) from under EGRC-BPT valve.
3. If a leakage is noted, replace the valve.




EGR TEMPERATURE SENSOR

Check resistance change and resistance value.



<Reference data>

EGR temperature °C (°F)	Voltage [V]	Resistance MΩ
0 (32)	4.56	0.62 - 1.05
50 (122)	2.25	0.065 - 0.094
100 (212)	0.59	0.011 - 0.015



Removal and Installation EGR VALVE

Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .


UBS008S3

DTC P0402 EGRC-BPT VALVE FUNCTION

PF0:14741

Description

UBS008S4



SYSTEM DESCRIPTION

The EGRC-BPT valve monitors exhaust pressure to activate the diaphragm, controlling throttle body vacuum applied to the EGR valve. In other words, recirculated exhaust gas is controlled in response to positioning of the EGR valve or to engine operation.

On Board Diagnosis Logic

UBS008S5

If too much EGR flow exists due to an EGRC-BPT valve malfunction, off idle engine roughness will increase. If the roughness is large, then the vacuum to the EGR valve is interrupted through the EGRC-solenoid valve. If the engine roughness is reduced at that time, the EGRC-BPT valve malfunction is indicated.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0402	EGRC-BPT valve function	<ul style="list-style-type: none"> The EGRC-BPT valve does not operate properly. 	<ul style="list-style-type: none"> EGRC-BPT valve EGR valve Loose or disconnected rubber tube Blocked rubber tube Camshaft position sensor Blocked exhaust system Orifice Mass air flow sensor EGRC-solenoid valve

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:


If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Install vacuum gauge between EGRC-BPT valve and EGR valve as shown in the illustration.
2. Start engine and warm it up to normal operating temperature.
3. Stop engine and wait at least 5 seconds.
4. Turn ignition switch ON and select “EGRC-BPT VLV P0402” of “EGR SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II.
5. Start engine and let it idle.




6. Touch “START”.
7. Check the output voltage of “THRTL POS SEN” (at closed throttle position) and note it.




8. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen and the bar chart may increase. Maintain the conditions many times until “COMPLETED” appears.

Selector lever	Suitable position
ENG SPEED	1,400 - 2,000 rpm
Vehicle speed	30 - 100 km/h (19 - 62 MPH)
B/FUEL SCHDL	5 - 7.5 msec
THRTL POS SEN	(X - (X + 0.88)) V X = Voltage value measured at step 7




NOTE:


- The bar chart on CONSULT-II screen indicates the status of this test. However, the test may be finished before the bar chart becomes full scale.
 - If the bar chart indication does not continue to progress, completely release accelerator pedal once and try to meet the conditions again.
 - If “TESTING” does not appear on CONSULT-II screen, retry from step 2.
9. If CONSULT-II instructs to carry out “Overall Function Check”, go to next step. If “NG” is displayed, refer to [EC-288, "Diagnostic Procedure"](#).



10. Open engine hood.
11. Raise engine speed to 2,400 to 3,200 rpm under no-load and hold it. Then touch "NEXT" on CONSULT-II screen.



12. Check vacuum gauge while keeping engine speed at 2,400 to 3,200 rpm.
Vacuum should be 0 to -20 kPa (0 to -150 mmHg, 0 to -5.91 inHg).
If NG, go to [EC-288, "Diagnostic Procedure"](#) .
If OK, touch "YES" on the CONSULT-II screen.



13. Check the EGR valve lifting when revving from 2,000 rpm to 4,000 rpm quickly under no load.
EGR valve should lift up, and go down without sticking when the engine is returned to idle.
If NG, check EGR valve.
If OK, touch "YES" or the CONSULT-II screen.
14. Check the rubber tube between intake manifold collector, EGRC solenoid valve, EGR valve and EGRC-BPT valve for cracks, blockages or twisting.
If NG, repair or replace.
If OK, touch "YES" on the CONSULT-II screen.


Overall Function Check

UBS008S7

Use this procedure to check the overall function of the EGRC-BPT valve. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Install vacuum gauge between EGRC-BPT valve and EGR valve as shown in the illustration.
2. Lift up vehicle.
3. Start engine and shift to 1st gear position.
4. Check vacuum gauge while keeping engine speed at 2,400 to 3,200 rpm.
Vacuum should be 0 to -20 kPa (0 to -150 mmHg, 0 to -5.91 inHg).
If NG, go to [EC-288, "Diagnostic Procedure"](#) .
If OK, go to next step.



5. Check the EGR valve lifting when revving from 2,000 rpm to 4,000 rpm quickly under no load.
EGR valve should lift up, and go down without sticking when the engine is returned to idle.
6. Check rubber tube between intake manifold collector, EGRC solenoid valve, EGR valve and EGRC-BPT valve for misconnection, cracks or blockages.
7. If NG, go to [EC-288, "Diagnostic Procedure"](#) .

Diagnostic Procedure

1. CHECK HOSE

Check vacuum hose for clogging and improper connection.

OK or NG

OK >> GO TO 2.

NG >> Repair or replace vacuum hose.

2. CHECK EXHAUST SYSTEM

Check exhaust system for collapse.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace exhaust system.

3. CHECK ORIFICE

Check if orifice is installed in vacuum hose between EGRC-BPT valve and EGRC solenoid valve.

OK or NG

OK >> GO TO 4.

NG >> Replace vacuum hose.

4. CHECK EGRC-BPT VALVE

Refer to [EC-289, "Component Inspection"](#).

OK or NG

OK >> GO TO 5.

NG >> Replace EGRC-BPT valve.

5. CHECK CAMSHAFT POSITION SENSOR

Refer to [EC-273, "Component Inspection"](#).

OK or NG

OK >> GO TO 6.

NG >> Replace camshaft position sensor.

6. CHECK MASS AIR FLOW SENSOR

Refer to [EC-289, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> Replace mass air flow sensor.

7. CHECK EGRC SOLENOID VALVE

Refer to [EC-289, "Component Inspection"](#).

OK or NG

OK >> GO TO 8.

NG >> Replace EGRC solenoid valve.

8. CHECK EGR VALVE

Refer to [EC-289, "Component Inspection"](#).

OK or NG

OK >> GO TO 9.

NG >> Replace EGR valve.

9. CHECK INTERMITTENT INCIDENT


Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection
EGRC-BPT VALVE

UBS008S9

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check leakage without applying any pressure from under EGR-BPT valve.
Leakage should exist.





MASS AIR FLOW SENSOR

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (mass air flow sensor signal) and ground.

Conditions	Voltage [V]
Ignition switch ON (Engine stopped.)	Less than 1.0
Idle (Engine is warmed-up to normal operating temperature.)	0.9 - 1.8
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.9 - 2.3
Idle to about 4,000 rpm*	1.3 - 1.7 to Approx. 3.0

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Repeat above check.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.



EGRC-SOLENOID VALVE


Ⓟ With CONSULT-II

Check air passage continuity.

DTC P0402 EGRC-BPT VALVE FUNCTION

[KA24DE]

Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.



ACTIVE TEST	
EGRC SOL/V	ON
(EGR)	CUT
MONITOR	
ENG SPEED	XXX rpm


Condition EGRC SOLENOID VALVE	Air passage continuity between A and B	Air passage continuity between A and C
ON	Yes	No
OFF	No	Yes

Operation takes less than 1 second.

LEC036A

⊗ Without CONSULT-II

Check air passage continuity shown in the figure.




Condition	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

Operation takes less than 1 second.

LEC037A

EGR VALVE

- Apply vacuum to EGR vacuum port with a hand vacuum pump.
EGR valve spring should lift.
- Check for sticking.



DTC P0405, P0406 EGRT SENSOR


PFP:14710

Component Description

UBS008SB

The EGR temperature sensor detects temperature changes in the EGR passageway. When the EGR valve opens, hot exhaust gases flow, and the temperature in the passageway changes. The EGR temperature sensor is a thermistor that modifies a voltage signal sent from the ECM. This modified signal then returns to the ECM as an input signal. As the temperature increases, EGR temperature sensor resistance decreases. This sensor is not used to control the engine system.

It is used only for the on board diagnosis.




<Reference data>

EGR temperature °C (°F)	Voltage* V	Resistance MΩ
0 (32)	4.56	0.62 - 1.05
50 (122)	2.25	0.065 - 0.094
100 (212)	0.59	0.011 - 0.015

*: These data are reference values and are measured between ECM terminal 63 (EGR temperature sensor) and ground.

When EGR system is operating.

Voltage: 0 - 1.5V



On Board Diagnosis Logic

UBS008SC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0405	EGR temperature sensor circuit low input	A) An excessively low voltage from the EGR temperature sensor is sent to ECM even when engine coolant temperature is low.	<ul style="list-style-type: none"> ● Harness or connectors (The EGR temperature sensor circuit is shorted.) ● EGR temperature sensor ● Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve
P0406	EGR temperature sensor circuit high input	B) An excessively high voltage from the EGR temperature sensor is sent to ECM even when engine coolant temperature is high.	<ul style="list-style-type: none"> ● Harness or connectors (The EGR temperature sensor circuit is open.) ● EGR temperature sensor ● Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve

DTC Confirmation Procedure

Perform "PROCEDURE FOR MALFUNCTION A" first. If 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

 **With CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Verify that engine coolant temperature is less than 50°C (122°F).
If the engine coolant temperature is above the range, cool the engine down.
4. Start engine and let it idle for at least 8 seconds.
5. If 1st trip DTC is detected, go to [EC-295, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANT TEMP/S	XXX °C

SEF174Y

 **With GST**

- Follow the procedure "With CONSULT-II".

PROCEDURE FOR MALFUNCTION B

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

Always perform the test at a temperature above 5°C (41°F).

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Run engine at idle for at least 2 minutes.
3. Confirm that EGR valve is not lifting.
If the result is NG, perform trouble diagnosis for DTC P1402. Refer to [EC-458](#).
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Read "EGR TEMP SEN" at about 1,500 rpm while holding the EGR valve in full open position by hand.
Voltage should decrease to less than 1.0V.
If the result is NG, go to [EC-295, "Diagnostic Procedure"](#).
If the result is OK, go to following step.
6. Turn ignition switch OFF and wait at least 5 seconds.
7. Turn ignition switch ON.
8. Check the output voltage of "THRTL POS SEN" (at closed throttle position) and note it.
9. Start engine.
10. Maintain the following conditions for at least 5 consecutive seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANT TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V
B/FUEL SCHDL	XXX msec

SEF201Y

ENG SPEED	2,000 - 2,800 rpm
VHCL SPEED SE	10 km/h (6 MPH) or more
B/FUEL SCHDL	7 - 10.5 msec
THRTL POS SEN	(X + 0.23) – (X + 0.74) V X = Voltage value measured at step 7
Selector lever	Suitable position

11. If 1st trip DTC is detected, go to [EC-295, "Diagnostic Procedure"](#).


Overall Function Check

Use this procedure to check the overall function of the EGR temperature sensor. During this check, a 1st trip DTC might not be confirmed.


PROCEDURE FOR MALFUNCTION B

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Run engine at idle for at least 2 minutes.
3. Confirm that EGR valve is not lifting.
If NG, perform trouble diagnosis for DTC P1402.
Refer to [EC-458](#) .



4. Check voltage between ECM terminal 63 (EGR temperature sensor signal) and ground at about 1,500 rpm with EGR valve lifted up to the full position by hand.
Voltage should decrease to less than 1.0V.
5. If NG, go to [EC-295. "Diagnostic Procedure"](#) .
If OK, perform trouble diagnoses for DTC P0400 and P1400.
Refer to [EC-275](#) , [EC-452](#) .



A
EC
C
D
E
F
G
H
I
J
K
L
M




DTC P0405, P0406 EGRT SENSOR

[KA24DE]

UBS008SF

Wiring Diagram


EC-EGR/TS-01



AEC006B

Diagnostic Procedure**1. CHECK POWER SUPPLY**

1. Turn ignition switch "OFF".
2. Disconnect EGR temperature sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 2.
 NG >> Repair harness or connectors.

**2. CHECK GROUND CIRCUIT**

1. Turn ignition switch "OFF".
2. Check harness continuity between EGR temperature sensor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the harness for open or short between EGR temperature sensor and ECM.

>> Repair open circuit or short to ground or short to power in harness or connector.

4. CHECK EGR TEMPERATURE SENSOR

Refer to [EC-296, "Component Inspection"](#).

OK or NG

- OK >> GO TO 5.
 NG >> Replace EGR temperature sensor.

5. CHECK INTERMITTENT INCIDENT


Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection EGR TEMPERATURE SENSOR


Check resistance change and resistance value.

UBS008SH



<Reference data>

EGR temperature °C (°F)	Voltage [V]	Resistance MΩ
0 (32)	4.56	0.62 - 1.05
50 (122)	2.25	0.065 - 0.094
100 (212)	0.59	0.011 - 0.015



Removal and Installation EGR TEMPERATURE SENSOR

Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .

UBS008SI

DTC P0420 THREE WAY CATALYST FUNCTION

PFP:20905


On Board Diagnosis Logic

UBS008SJ

The ECM monitors the switching frequency ratio of heated oxygen sensor 1 and 2.

A three way catalyst (manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2. As oxygen storage capacity decreases, the heated oxygen sensor 2 switching frequency will increase.

When the frequency ratio of heated oxygen sensors 1 and 2 approaches a specified limit value, the three way catalyst malfunction is diagnosed.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0420	Catalyst system efficiency below threshold	<ul style="list-style-type: none"> Three way catalyst (manifold) does not operate properly. Three way catalyst (manifold) does not have enough oxygen storage capacity. 	<ul style="list-style-type: none"> Three way catalyst (manifold) Exhaust tube Intake air leaks Injectors Injector leaks Spark plug Improper ignition timing

DTC Confirmation Procedure

UBS008SK

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Open engine hood before conducting following procedure.
- Do not hold engine speed more than specified minutes below.

Ⓜ WITH CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 5 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Select "DTC & SRT CONFIRMATION" then "SRT WORK SUPPORT" mode with CONSULT-II.
6. Rev engine up to 2,000 to 3,000 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely. If "INCMP" of "CATALYST" changed to "COMPLT", go to step 9
7. Wait 5 seconds at idle.

SRT WORK SUPPORT	
CATALYST	INCMP
EVAP SYSTEM	INCMP
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0822E

DTC P0420 THREE WAY CATALYST FUNCTION

[KA24DE]

8. Rev engine up to 2,000 to 3,000 rpm and maintain it until "INCMP" of "CATALYST" changes to "CMPLT" (It will take approximately 5 minutes).
If not "CMPLT", perform the following.

- a. Turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle).

SRT WORK SUPPORT	
CATALYST	CMPLT
EVAP SYSTEM	INCMP
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0823E

- b. Turn ignition switch "ON" and select "COOLANTEMP/S" in "DATA MONITOR" mode with CONSULT-II.
- c. Start engine and warm it up while monitoring "COOLANTEMP/S" indication on CONSULT-II.
- d. When "COOLANTEMP/S" indication reaches to 70°C (158°F), go to step 3.

DATA MONITOR	
MONITOR	NO DTC
COOLANTEMP/S	XXX °C

SEF013Y

9. Select "SELF-DIAG RESULTS" mode with CONSULT-II.
10. Confirm that the 1st trip DTC is not detected.
If the 1st trip DTC is detected, go to [EC-299, "Diagnostic Procedure"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	

SEF535Z

Overall Function Check

UBS008SL

Use this procedure to check the overall function of the three way catalyst. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 5 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeters probes between ECM terminals 50 (Heated oxygen sensor 1 signal), 56 (Heated oxygen sensor 2 signal) and engine ground.
6. Keep engine speed at 2,000 rpm constant under no load.
7. Make sure that the voltage switching frequency (high & low) between ECM terminal 56 and engine ground is much less than that of ECM terminal 50 and engine ground.

Switching frequency ratio = A/B


A: Heated oxygen sensor 2 voltage switching frequency

B: Heated oxygen sensor 1 voltage switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, it means three way catalyst (manifold) does not operate properly.

Go to [EC-299, "Diagnostic Procedure"](#).



NOTE:

If the voltage at terminal 50 does not switch periodically more than 5 times within 10 seconds at step 4, perform trouble diagnosis for DTC P0133 first. (See [EC-192](#).)

Diagnostic Procedure

UBS008SM

1. CHECK EXHAUST SYSTEM


Visually check exhaust tubes and muffler for dent.

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

2. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.

3. CHECK INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.

4. CHECK IGNITION TIMING

1. Check the following items. Refer to [EC-73. "Basic Inspection"](#) .

Items	Specifications
Ignition timing	20° ± 2° BTDC
Base idle speed	750 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF
Target idle speed	800 ± 50 rpm (in P or N position)

OK or NG


- OK >> GO TO 5.
- NG >> Adjust ignition timing.

5. CHECK INJECTORS

1. Refer to Wiring Diagram for Injectors, [EC-533](#) .
2. Stop engine and then turn ignition switch ON.
3. Check voltage between ECM terminals 102, 104, 109 and 111 and ground with CONSULT-II or tester.
Battery voltage should exist.

OK or NG

- OK >> GO TO 6.
NG >> Perform [EC-534, "Diagnostic Procedure"](#) .




6. CHECK IGNITION SPARK

1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

OK or NG

- OK >> GO TO 8.
NG >> GO TO 7.



7. CHECK IGNITION WIRES


1. Inspect wires for cracks, damage, burned terminals and for improper fit.
2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks.

Resistance : 13.6 - 18.4 kΩ/m (4.15 - 5.61 kΩ/ft) at 25°C (77°F)

If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.

OK or NG

- OK >> Check ignition coil, power transistor and their circuits. Refer to [EC-525, "IGNITION SIGNAL"](#) .
NG >> Replace.



8. CHECK INJECTOR

1. Turn ignition switch OFF.
2. Remove injector assembly.
Keep fuel hose and all injectors connected to injector gallery.
3. Disconnect camshaft position sensor harness connector.
4. Turn ignition switch "ON".
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip.)>>GO TO 9.

NG (Drips.)>>Replace the injector(s) from which fuel is dripping.

9. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

Trouble is fixed.>>**INSPECTION END.**

Trouble is not fixed.>>Replace three way catalyst.

A

EC

C

D

E

F

G

H

I

J

K

L


M

DTC P0441 EVAP CONTROL SYSTEM

System Description

NOTE:

If DTC P0441 is displayed with DTC P0510, perform trouble diagnosis for “DTC P0510” first. (See [EC-408](#) .)



In this evaporative emission (EVAP) control system, purge flow occurs during non-closed throttle conditions. Purge volume is related to air intake volume. Under normal purge conditions (non-closed throttle), the EVAP canister purge volume control solenoid valve is open. Purge flow exposes the EVAP control system pressure sensor to intake manifold vacuum.

On Board Diagnosis Logic

Under normal conditions (non-closed throttle), sensor output voltage indicates if pressure drop and purge flow are adequate. If not, a fault is determined.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0441	EVAP control system incorrect purge flow	EVAP control system does not operate properly, EVAP control system has a leak between intake manifold and EVAP control system pressure sensor.	<ul style="list-style-type: none"> ● EVAP canister purge volume control solenoid valve stuck closed ● EVAP control system pressure sensor and the circuit ● Loose, disconnected or improper connection of rubber tube ● Blocked rubber tube ● Cracked EVAP canister ● Closed throttle position switch ● Blocked purge port ● EVAP canister vent control valve

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


- For best results perform test at a temperature of 5°C (41°F) or more.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Start engine and let it idle for at least 60 seconds.
4. Select “PURG FLOW P0441” of “EVAP SYSTEM” in “DTC CONFIRMATION” mode with CONSULT-II.
5. Touch “START”.
If “COMPLETED” is displayed, go to step 7.
6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take at least 30 seconds.)

Selector lever	Suitable position
Vehicle speed	32 - 120 km/h (20 - 75 MPH)
ENG SPEED	500 - 3,750 rpm
Engine coolant temperature	More than 70°C (158°F)

If “TESTING” is not changed for a long time, retry from step 2.



7. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to [EC-304, "Diagnostic Procedure"](#).

Overall Function Check


Use this procedure to check the overall monitoring function of the EVAP control system purge flow monitoring. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Lift up drive wheels.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF, wait at least 5 seconds.
4. Start engine and wait at least 60 seconds.

5. Set voltmeter probes to ECM terminals 62 (EVAP control system pressure sensor signal) and ground.
6. Check EVAP control system pressure sensor value at idle speed and note it.
7. Establish and maintain the following conditions for at least 1 minute.

- Air conditioner switch** : ON
- Headlamp switch** : ON
- Rear window defogger switch** : ON
- Engine speed** : Approx. 3,000 rpm
- Gear position** : Any position other than "Neutral" or "Reverse"



8. Verify that EVAP control system pressure sensor value stays 0.1V less than the value at idle speed (measured at step 6) for at least 1 second.
9. If NG, go to [EC-304, "Diagnostic Procedure"](#).

Diagnostic Procedure

UBS008SR

1. CHECK EVAP CANISTER

1. Turn ignition switch OFF.
2. Check EVAP canister for cracks.


OK or NG

- OK (With CONSULT-II)>>GO TO 2.
- OK (Without CONSULT-II)>>GO TO 3.
- NG >> Replace EVAP canister.

2. CHECK PURGE FLOW

With CONSULT-II

1. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port and install vacuum gauge.
2. Start engine and let it idle.



3. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II.
4. Rev engine up to 2,000 rpm.
5. Touch "Qd" and "Qu" on CONSULT-II screen to adjust "PURG VOL CONT/V" opening.

PURG VOL CONT/V	Vacuum
100.0%	Should exist.
0.0%	Should not exist.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 4.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN
THRTL POS SEN	XXX V

SEF801Y

3. CHECK PURGE FLOW

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port and install vacuum gauge.
4. Start engine and let it idle for at least 60 seconds.
5. Check vacuum gauge indication when revving engine up to 2,000 rpm.


Vacuum should exist.

6. Release the accelerator pedal fully and let idle.

Vacuum should not exist.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 4.



4. CHECK EVAP PURGE LINE


Check EVAP purge line for improper connection or disconnection. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 5.
- NG >> Repair it.

5. CHECK EVAP PURGE HOSE AND PURGE PORT


1. Disconnect purge hoses connected to EVAP service port **A** and EVAP canister purge volume control solenoid valve **B**.
2. Blow air into each hose and EVAP purge port **C**.



3. Check that air flows freely.

OK or NG

- OK (With CONSULT-II)>>GO TO 6.
- OK (Without CONSULT-II)>>GO TO 7.
- NG >> Repair or clean hoses and/or purge port.



6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 8.
 NG >> GO TO 7.


ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN
THRTL POS SEN	XXX V

SEF801Y

7. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

SEF334X

Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

SEF335X

OK or NG

- OK >> GO TO 8.
 NG >> Replace EVAP canister purge volume control solenoid valve.

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

1. Turn ignition switch OFF.
2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG


- OK >> GO TO 9.
- NG >> Repair it.

9. CHECK CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.
Water should not exist.

OK or NG

- OK >> GO TO 10.
- NG >> Replace EVAP control system pressure sensor.



10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR AND CIRCUIT

Refer to "DTC Confirmation Procedure" for DTC P0452, [EC-337](#) and DTC P0453, [EC-344](#) .

OK or NG


- OK (With CONSULT-II)>>GO TO 11.
- OK (Without CONSULT-II)>>GO TO 12.
- NG >> Replace EVAP control system pressure sensor.

11. CHECK EVAP CANISTER VENT CONTROL VALVE-I

1. Remove EVAP canister vent control valve from EVAP canister.
2. Check portion **B** of EVAP canister vent control valve for being rusted.

OK or NG


- OK >> GO TO 12.
- NG >> Replace EVAP canister vent control valve.



12. CHECK EVAP CANISTER VENT CONTROL VALVE-II

With CONSULT-II

1. Reconnect harness connectors disconnected.
2. Turn ignition switch "ON".
3. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
4. Check air passage continuity and operation delay time.



ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 (B1)	XXX V
THRTL POS SEN	XXX V

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.

SEF803Y

Without CONSULT-II


1. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

OK or NG

- OK >> GO TO 14.
- NG >> GO TO 13.



13. CHECK EVAP CANISTER VENT CONTROL VALVE-III

1. Clean the air passage (Portion A to B) of EVAP canister vent control valve using an air blower.
2. Perform Test No. 12 again.

OK or NG

- OK (With Consult-II)>>GO TO 14.
- OK (Without Consult-II)>>GO TO 15.
- NG >> Replace EVAP canister vent control valve.

14. CHECK THROTTLE POSITION SWITCH

 With CONSULT-II

1. Install all removed parts.
2. Start engine and warm it up to normal operation temperature.
3. Turn ignition switch "OFF".
4. Turn ignition switch "ON".
5. Select "DATA MONITOR" mode with CONSULT-II.
6. Check indication of "CLSD THL/P SW" under the following conditions.
Measurement must be made with throttle position switch installed in vehicle.


Throttle valve conditions	CLSD THL/P SW
Completely closed	ON
Partially open or completely open	OFF


OK or NG

- OK >> GO TO 17.
- NG >> GO TO 16.

15. CHECK THROTTLE POSITION SWITCH

1. Install all removed parts.
2. Start engine and warm it up to normal operation temperature.
3. Turn ignition switch "OFF".
4. Disconnect closed throttle position switch harness connector.
5. Check continuity between closed throttle position switch terminals 5 and 6 under the following conditions.
Resistance measurement must be made with throttle position switch installed in vehicle.





Throttle valve conditions	Continuity
Completely closed	Yes
Partially open or completely open	No

OK or NG

LEC094A

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 16.

16. ADJUST THROTTLE POSITION SWITCH

Check the following items. Refer to [EC-73, "Basic Inspection"](#) .

Items	Specifications
Ignition timing	20° ± 2° BTDC
Base idle speed	750 ± 50 rpm
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF
Target idle speed	800 ± 50 rpm

Is it possible to adjust closed throttle position switch?

YES or NO

YES >> GO TO 17.

NO >> Replace throttle position switch.

17. CHECK EVAP PURGE LINE

Inspect EVAP purge line (pipe and rubber tube). Check for evidence of leaks.
Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#) .

OK or NG

OK >> GO TO 18.

NG >> Replace it.

18. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 19.

19. CHECK INTERMITTENT INCIDENT

Refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

DTC P0442 EVAP CONTROL SYSTEM

On Board Diagnosis Logic


NOTE:

If DTC P0442 is displayed with DTC P1448, first perform trouble diagnosis for DTC P1448. (See EC-483 .)

This diagnosis detects leaks in the EVAP purge line using engine intake manifold vacuum.

If pressure does not increase, the ECM will check for leaks in the line between the fuel tank and EVAP canister purge volume control solenoid valve under the following "Vacuum test" conditions.

The vacuum cut valve bypass valve is opened to clear the line between the fuel tank and the EVAP canister purge volume control solenoid valve. The EVAP canister vent control valve will then be closed to shut the EVAP purge line off. The EVAP canister purge volume control solenoid valve is opened to depressurize the EVAP purge line using intake manifold vacuum. After this occurs, the EVAP canister purge volume control solenoid valve will be closed.



PBIB1402E

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0442	EVAP control system small leak detected (negative pressure)	EVAP control system has a leak, EVAP control system does not operate properly.	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged ● Water separator ● EVAP canister is saturated with water ● EVAP control system pressure sensor ● Fuel level sensor and the circuit ● Refueling control valve ● ORVR system leaks

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS008ST

NOTE:

- If DTC P0442 is displayed with DTC P1448, first perform trouble diagnosis for DTC P1448. Refer to [EC-483](#).
- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II TESTING CONDITION:


- Perform “DTC WORK SUPPORT” when the fuel level is between 1/4 to 3/4 full and vehicle is placed on flat level surface.
 - Always perform test at a temperature of 0 to 30°C (32 to 86°F).
1. Turn ignition switch ON.
 2. Turn ignition switch OFF and wait at least 5 seconds.
 3. Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
 4. Check that the following conditions are met.

COOLAN TEMP/S	0 - 70°C (32 - 158°F)
INT/A TEMP SE	0 - 60°C (32 - 140°F)

DTC P0442 EVAP CONTROL SYSTEM


[KA24DE]

5. Select "EVAP SML LEAK P0442/P1442" of "EVAP SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II. Follow the instruction displayed.



NOTE:

- If the engine cannot be maintained within the range on CONSULT-II screen, go to [EC-73, "Basic Inspection"](#).
6. Make sure that "OK" is displayed.
If "NG" is displayed, refer to [EC-314, "Diagnostic Procedure"](#).



WITH GST

1. Start engine.
2. Drive vehicle according to [EC-57, "Driving Pattern"](#).

NOTE:

Be sure to read the explanation of "Driving pattern" on [EC-57](#) before driving vehicle.

3. Stop vehicle.
4. Select "MODE 1" with GST.
 - If SRT of EVAP system is not set yet, go to the following step.
 - If SRT of EVAP system is set, the result will be OK.
5. Turn ignition switch OFF and wait at least 5 seconds.
6. Start engine.
It is not necessary to cool engine down before driving.
7. Drive vehicle again according to the "Driving pattern", [EC-57](#).
8. Stop vehicle.
9. Select "MODE 3" with GST.
 - If P0441 is displayed on the screen, go to [EC-304, "Diagnostic Procedure"](#).
 - If P0442 is displayed on the screen, go to [EC-314, "Diagnostic Procedure"](#).
 - If P0441 and P0442 are not displayed on the screen, go to the following step.
10. Select "MODE 1" with GST.
 - If SRT of EVAP system is set, the result will be OK.
 - If SRT of EVAP system is not set, go to step 5.


Diagnostic Procedure

1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch OFF.
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

- OK >> GO TO 2.
 NG >> Replace with genuine NISSAN fuel filler cap.



2. CHECK FUEL FILLER CAP INSTALLATION

Check that the cap is tightened properly rotating the cap clockwise.

OK or NG

- OK >> GO TO 3.
 NG >> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.
 ● Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION


Check for air releasing sound while opening the fuel filler cap.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP)

1. Wipe clean valve housing.



2. Check valve opening pressure and vacuum.


Pressure : 16.0 - 20.0 kPa
(0.163 - 0.204 kg/cm² , 2.32 - 2.90 psi)
Vacuum : -6.0 to -3.5 kPa
(-0.061 to -0.036 kg/cm² , -0.87 to -0.51 psi)

CAUTION:

Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.


OK or NG

- OK >> GO TO 5.
 NG >> Replace fuel filler cap with a genuine one.



5. INSTALL PRESSURE PUMP


1. Install the EVAP service port adapter and the pressure pump securely to EVAP service port.



NOTE:

- Improper installation of service port may cause leaking.

Models with CONSULT-II>>GO TO 6.
 Models without CONSULT-II>>GO TO 7.




A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M

6. CHECK FOR EVAP LEAK

With CONSULT-II


1. Turn ignition switch ON.
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.



3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



4. Using EVAP leak detector, locate the leak portion. For the leak detector, refer to instruction manual for more details. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#)

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.



7. CHECK FOR EVAP LEAK

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12 volts until the end of test.) Shown in the above figure.
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg).



NOTE:

- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.

5. Using EVAP leak detector, locate the leak. For the leak detector, refer to instruction manual for more details. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#) .

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.




8. CHECK WATER SEPARATOR

1. Check visually for insect nests in the water separator air inlet.
 2. Check visually for cracks or flaws in the appearance.
 3. Check visually for cracks or flaws in the hose.
 4. Check that **A** and **C** are not clogged by blowing air into **B** with **A** , and then **C** plugged.
 5. In case of NG in items 2 - 4, replace the parts.
- Do not disassemble water separator.

OK or NG

- OK >> GO TO 9.
 NG >> Replace water separator.



9. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

Refer to [EC-484, "DTC Confirmation Procedure"](#) .

OK or NG


- OK >> GO TO 10.
 NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connectors.

10. CHECK IF EVAP CANISTER IS SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

- Yes >> GO TO 11.
- No (With CONSULT-II)>>GO TO 13.
- No (Without CONSULT-II)>>GO TO 14.



11. CHECK EVAP CANISTER

Weigh the EVAP canister with EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK (With CONSULT-II)>>GO TO 13.
- OK (Without CONSULT-II)>>GO TO 14.
- NG >> GO TO 12

12. DETECT MALFUNCTIONING PART

Check the following.

1. Visually check the EVAP canister for damage.
2. Check hose connection between EVAP canister and water separator for clogging and poor connection.

>> Repair hose or replace EVAP canister.

13. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform “PURG VOL CONT/V” in “ACTIVE TEST” mode.
4. Touch “Qu” on CONSULT-II screen to increase “PURG VOL CONT/V” opening to 100.0%.
5. Check vacuum hose for vacuum.

ACTIVE TEST		Vacuum should exist.
PURG VOL CONT/V	XXX %	
MONITOR		
ENG SPEED	XXX rpm	
A/F ALPHA-B1	XXX %	
HO2S1 MNTR (B1)	LEAN	
THRTL POS SEN	XXX V	

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 15.

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 60 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.
Vacuum should exist.

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 15.

15. CHECK VACUUM HOSE

Check vacuum hoses for clogging or disconnection. Refer to [EC-29, "Vacuum Hose Drawing"](#) .

OK or NG

- OK (With CONSULT-II)>>GO TO 16.
- OK (Without CONSULT-II)>>GO TO 17.
- NG >> Repair or reconnect the hose.

16. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 18.
- NG >> GO TO 17.


ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN
THRTL POS SEN	XXX V

SEF801Y

17. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

SEF334X

Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No


SEF335X

OK or NG

- OK >> GO TO 18.
- NG >> Replace EVAP canister purge volume control solenoid valve.

18. CHECK FUEL TANK TEMPERATURE SENSOR


Check resistance by heating with hot water or heat gun as shown in the figure.



Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

OK or NG


- OK >> GO TO 19.
- NG >> Replace fuel tank temperature sensor.




A
EC
C
D
E
F
G
H
I
J
K
L
M

19. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.



CAUTION:
Never apply force to the air hole protector of the sensor, if equipped.



2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.


CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg , -27.56 inHg) or over 101.3 kPa (760 mmHg , 29.56 inHg) of pressure.

4. Check output voltage between ECM terminal 62 and engine ground.

Applied vacuum kPa (mmHg, inHg)	Voltage [V]
Not applied	1.8 - 4.8
-26.7 (-200 , -7.87)	2.1 to 2.5V lower than above value

CAUTION:
Discard any EVAP control system pressure sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



OK or NG

- OK >> GO TO 20.
- NG >> Replace EVAP control system pressure sensor.

20. CHECK EVAP PURGE LINE

Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 21.
- NG >> Repair or reconnect the hose.

21. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 22.

22. CHECK REFUELING EVAP VAPOR LINE

Check refueling EVAP vapor line between EVAP canister and fuel tank for clogging, kink, looseness and improper connection. For location, refer to [EC-562, "ON BOARD REFUELING VAPOR RECOVERY \(ORVR\)"](#).

OK or NG

OK >> GO TO 23.

NG >> Repair or replace hoses and tubes.

23. CHECK SIGNAL LINE AND RECIRCULATION LINE

Check signal line and recirculation line between filler neck tube and fuel tank for clogging, kink, cracks, looseness and improper connection.


OK or NG

OK >> GO TO 24.

NG >> Repair or replace hoses, tubes or filler neck tube.

24. CHECK REFUELING CONTROL VALVE

1. Remove fuel filler cap.
2. Check air continuity between hose ends A and B.
Blow air into the hose end B. Air should flow freely into the fuel tank.
3. Blow air into hose end A and check there is no leakage.
4. Apply pressure to both hose ends A and B [20 kPa (150 mmHg, 5.91 inHg)] using a pressure pump and a suitable 3-way connector. Check that there is no leakage.



OK or NG

OK >> GO TO 25.

NG >> Replace refueling control valve with fuel tank.

25. CHECK FUEL LEVEL SENSOR

1. Remove fuel level sensor assembly. Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .
2. Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

OK >> GO TO 26.

NG >> Replace fuel level sensor.

26. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[KA24DE]

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PF1:14920

Description SYSTEM DESCRIPTION


UBS008SV

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Throttle position switch	Closed throttle position		
Heated oxygen sensor 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Fuel tank temperature sensor	Fuel temperature in fuel tank		
Vehicle speed sensor	Vehicle speed		

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



CONSULT-II Reference Value in Data Monitor Mode

UBS008SW

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PURG VOL C/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch "OFF" ● Shift lever: "N" ● No-load 	Idle (Vehicle stopped)	0%
		2,000 rpm	—

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[KA24DE]

On Board Diagnosis Logic

UBS008SX

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0444	EVAP canister purge volume control solenoid valve circuit open	An excessively low voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● EVAP canister purge volume control solenoid valve
P0445	EVAP canister purge volume control solenoid valve circuit shorted	An excessively high voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is shorted.) ● EVAP canister purge volume control solenoid valve

DTC Confirmation Procedure

UBS008SY

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for at least 30 seconds.
4. If 1st trip DTC is detected, go to [EC-329. "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure “WITH CONSULT-II”.


DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[KA24DE]


UBS008SZ

Wiring Diagram

EC-PGC/V-01



— : Detectable line for DTC
— : Non-detectable line for DTC
 EP : EARLY PRODUCTION
 LP : LATE PRODUCTION
 *1 : EP : 9
 LP : 2



WBWA0015E



DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	LG/R	ECM relay (Self-shutoff)	[Engine is running] [Ignition switch OFF] <ul style="list-style-type: none"> For a few seconds after turning ignition switch OFF 	0 - 1V
			[Ignition switch OFF] <ul style="list-style-type: none"> A few seconds passed after turning ignition switch OFF 	BATTERY VOLTAGE (11 - 14V)
5	R/Y	EVAP canister purge volume control solenoid valve	[Engine is running] <ul style="list-style-type: none"> Idle speed 	BATTERY VOLTAGE (11 - 14V)★ 
			[Engine is running] <ul style="list-style-type: none"> Engine speed is 2,000 rpm (More than 200 seconds after starting engine) 	BATTERY VOLTAGE (11 - 14V)★ 
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P			
117	B/P	Current return	[Engine is running] <ul style="list-style-type: none"> Idle speed 	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

1. CHECK POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between EVAP canister purge volume control solenoid valve terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair harness or connectors.

3. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 5 and EVAP canister purge volume control solenoid valve terminal 1.
Refer to Wiring Diagram.
Continuity should exist.
4. Also, check harness for short to ground and short to power.

OK or NG

- OK (With CONSULT-II)>>GO TO 5.
 OK (Without CONSULT-II)>>GO TO 6.
 NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the harness for open or short between EVAP canister purge volume control solenoid valve and ECM.

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 6.


ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN
THRTL POS SEN	XXX V

SEF801Y

6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

SEF334X

Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

SEF335X

OK or NG

- OK >> GO TO 7.
 NG >> Replace EVAP canister purge volume control solenoid valve.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0447 EVAP CANISTER VENT CONTROL VALVE

PFP:14935

Component Description

UBS008T2

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.


This solenoid (the EVAP canister vent control valve) responds to signals from the ECM.

When the ECM sends an ON signal, the coil in the solenoid valve is energized.

A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS008T3

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

UBS008T4

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0447	EVAP canister vent control valve circuit open	An improper voltage signal is sent to ECM through EVAP canister vent control valve.	<ul style="list-style-type: none"> ● Harness or connectors (The valve circuit is open or shorted.) ● EVAP canister vent control valve

DTC Confirmation Procedure

UBS008T5

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-333, "Diagnostic Procedure"](#)

WITH GST

Follow the procedure "WITH CONSULT-II".

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y



DTC P0447 EVAP CANISTER VENT CONTROL VALVE

[KA24DE]

UBS008T6

Wiring Diagram

EC-VENT/V-01



WBWA0016E

DTC P0447 EVAP CANISTER VENT CONTROL VALVE

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
108	R/G	EVAP canister vent control valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS00877

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK CIRCUIT

1. Turn ignition switch ON.
2. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
3. Make sure that ratcheting sound is heard from the vent control valve.

OK or NG


- OK >> GO TO 7.
- NG >> GO TO 3.

ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 (B1)	XXX V
THRTL POS SEN	XXX V

SEF802Y

3. CHECK POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect EVAP canister vent control valve harness connector.
3. Turn ignition switch ON.




4. Check voltage between EVAP canister vent control valve terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M67, B101
- Harness connectors B101, C2
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between EVAP canister vent control valve and fuse

>> Repair harness or connectors.

5. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 108 and terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C2, B112
- Harness connectors B101, M67
- Harness connectors M81, F36
- Harness for open or short between EVAP canister vent control valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.


7. CHECK EVAP CANISTER VENT CONTROL VALVE-I

1. Remove EVAP canister vent control valve from EVAP canister.
2. Check portion **B** of EVAP canister vent control valve for being rusted.

OK or NG

OK >> GO TO 8.

NG >> Replace EVAP canister vent control valve.




A
EC
C
D
E
F
G
H
I
J
K
L
M

8. CHECK EVAP CANISTER VENT CONTROL VALVE-II

With CONSULT-II

1. Reconnect harness connectors disconnected.
2. Turn ignition switch "ON".
3. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
4. Check air passage continuity and operation delay time.



ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 (B1)	XXX V
THRTL POS SEN	XXX V

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.

SEF803Y

Without CONSULT-II


1. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

OK or NG

- OK >> GO TO 10.
 NG >> GO TO 9.



9. CHECK EVAP CANISTER VENT CONTROL VALVE-III

1. Clean the air passage (Portion A to B) of EVAP canister vent control valve using an air blower.
2. Perform Test No. 8 again.

OK or NG

- OK >> GO TO 10.
 NG >> Replace EVAP canister vent control valve.

10. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

[KA24DE]



DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

PF2:25085

Component Description

UBS008T9

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases. The EVAP control system pressure sensor is not used to control the engine system. It is used only for on board diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS008TA

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EVAP SYS PRES	● Ignition switch: ON	1.8 - 4.8V

On Board Diagnosis Logic

UBS008TB

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0452	EVAP control system pressure sensor low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● EVAP control system pressure sensor

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform test at a temperature above 5°C (41°F).
- Before performing the following procedure, confirm battery voltage is more than 11V at idle.

WITH CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Make sure that "FUEL T/TMP SE" is more than 0°C (32°F).
6. Start engine and wait at least 20 seconds.
7. If 1st trip DTC is detected, go to [EC-340, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
FUEL T/TMP SE	XXX °C

SEF194Y

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Check that voltage between ECM terminal 60 (Fuel tank temperature sensor signal) and ground is less than 4.2V.
3. Turn ignition switch OFF and wait at least 5 seconds.
4. Start engine and wait at least 20 seconds.
5. Select "MODE 7" with GST.
6. If 1st trip DTC is detected, go to [EC-340, "Diagnostic Procedure"](#)





DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

[KA24DE]

Wiring Diagram

UBS008TD

EC-PRE/SE-01



WBWA0076E

DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
42	BR	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	B/W	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
62	Y	EVAP control system pres-sure sensor	[Ignition switch ON]	1.8 - 4.8V

Diagnostic Procedure

UBS008TE

1. CHECK RUBBER TUBE CONNECTED TO THE SENSOR

Check rubber tube connected to the sensor for clogging, vent, kink, disconnection or improper connection.


OK or NG

- OK >> GO TO 2.
- NG >> Reconnect, repair or replace.

2. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 3.




3. CHECK HARNESS CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check sensor harness connector for water.
Water should not exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness connector.




4. CHECK POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between terminal 3 and engine ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair harness or connectors.

6. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check harness continuity between EVAP control system pressure sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M81, F36
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair open circuit or short to power in harness or connectors.

8. CHECK INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 62 and EVAP control system pressure sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

1. Turn ignition switch "OFF".
2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.


OK or NG

OK >> GO TO 11.

NG >> Repair it.


11. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.



CAUTION:

Never apply force to the air hole protector of the sensor, if equipped.



2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.

CAUTION:


- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg , -27.56 inHg) or over 101.3 kPa (760 mmHg , 29.56 inHg) of pressure.

4. Check output voltage between ECM terminal 62 and engine ground.

Applied vacuum kPa (mmHg, inHg)	Voltage [V]
Not applied	1.8 - 4.8
-26.7 (-200, -7.87)	2.1 to 2.5V lower than above value

CAUTION:

Discard any EVAP control system pressure sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



OK or NG

- OK >> GO TO 12.
- NG >> Replace EVAP control system pressure sensor.

12. CHECK INTERMITTENT INCIDENT

Perform [EC-120. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[KA24DE]



DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

PF2:25085

Component Description

UBS008TF

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases. The EVAP control system pressure sensor is not used to control the engine system. It is used only for on board diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS008TG

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EVAP SYS PRES	● Ignition switch: ON	1.8 - 4.8V

On Board Diagnosis Logic

UBS008TH

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0453	EVAP control system pressure sensor high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● EVAP control system pressure sensor ● Rubber hose to EVAP control system pressure is clogged, vent, kinked, disconnected or improper connection. ● EVAP canister vent control valve ● EVAP canister purge volume control solenoid valve ● EVAP canister ● Water separator

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform test at a temperature above 5°C (41°F).
- Before performing the following procedure, confirm battery voltage is more than 11V at idle.

WITH CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Make sure that "FUEL T/TMP SE" is more than 0°C (32°F).
6. Start engine and wait at least 20 seconds.
7. If 1st trip DTC is detected, go to [EC-347, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
FUEL T/TMP SE	XXX °C

SEF194Y

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Check that voltage between ECM terminal 60 (Fuel tank temperature sensor signal) and ground is less than 4.2V.
3. Turn ignition switch OFF and wait at least 5 seconds.
4. Start engine and wait at least 20 seconds.
5. Select "MODE 7" with GST.
6. If 1st trip DTC is detected, go to [EC-347, "Diagnostic Procedure"](#)









DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[KA24DE]

UBS008TJ

Wiring Diagram

EC-PRE/SE-01



BBWA0521E

DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
42	BR	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	B/W	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
62	Y	EVAP control system pres-sure sensor	[Ignition switch ON]	1.8 - 4.8V

Diagnostic Procedure

UBS008TK

1. CHECK RUBBER TUBE CONNECTED TO THE SENSOR

Check rubber tube connected to the sensor for clogging, vent, kink, disconnection or improper connection.


OK or NG

- OK >> GO TO 2.
- NG >> Reconnect, repair or replace.

2. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 3.




3. CHECK HARNESS CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check sensor harness connector for water.
Water should not exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness connector.




4. CHECK POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between EVAP control system pressure sensor terminal 3 and engine ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair harness or connectors.

6. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check harness continuity between EVAP control system pressure sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M81, F36
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair open circuit or short to power in harness or connectors.

8. CHECK INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 62 and EVAP control system pressure sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 10.

OK (Without CONSULT-II)>>GO TO 11.

NG >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

 **With CONSULT-II**

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

OK >> GO TO 12.

NG >> GO TO 11.


ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN
THRTL POS SEN	XXX V

SEF801Y

11. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

SEF334X

Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

SEF335X

OK or NG

- OK >> GO TO 12.
- NG >> Replace EVAP canister purge volume control solenoid valve.

12. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

1. Turn ignition switch "OFF".
2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG


- OK >> GO TO 13.
- NG >> Repair it.

13. CHECK EVAP CANISTER VENT CONTROL VALVE-I

1. Remove EVAP canister vent control valve from EVAP canister.
2. Check portion **B** of EVAP canister vent control valve for being rusted.

OK or NG


- OK >> GO TO 14.
- NG >> Replace EVAP canister vent control valve.



14. CHECK EVAP CANISTER VENT CONTROL VALVE-II

 With CONSULT-II

1. Reconnect harness connectors disconnected.
2. Turn ignition switch "ON".
3. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
4. Check air passage continuity and operation delay time.



ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 (B1)	XXX V
THRTL POS SEN	XXX V

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.

SEF803Y

 Without CONSULT-II


1. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

OK or NG

- OK >> GO TO 16.
- NG >> GO TO 15.



15. CHECK EVAP CANISTER VENT CONTROL VALVE-III


1. Clean the air passage (Portion A to B) of EVAP canister vent control valve using an air blower.
2. Perform Test No. 13 again.

OK or NG

- OK >> GO TO 16.
- NG >> Replace EVAP canister vent control valve.


16. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.



CAUTION:

Never apply force to the air hole protector of the sensor, if equipped.



2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.

CAUTION:


- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg , -27.56 inHg) or over 101.3 kPa (760 mmHg , 29.56 inHg) of pressure.

4. Check output voltage between ECM terminal 62 and engine ground.

Applied vacuum kPa (mmHg, inHg)	Voltage [V]
Not applied	1.8 - 4.8
-26.7 (-200 , -7.87)	2.1 to 2.5V lower than above value

CAUTION:

Discard any EVAP control system pressure sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



OK or NG

- OK >> GO TO 17.
 NG >> Replace EVAP control system pressure sensor.

17. CHECK RUBBER TUBE FOR CLOGGING

Check obstructed water separator and rubber tube to EVAP canister vent control valve and clean the rubber tube using air blower.

Check water separator.


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

- **Do not disassemble water separator.**

OK or NG

OK >> GO TO 18.

NG >> Clean, repair or replace rubber tube and/or water separator.




18. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

Yes >> GO TO 19.

No >> GO TO 21.



19. CHECK EVAP CANISTER

Weigh the EVAP canister with EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

OK >> GO TO 21.

NG >> GO TO 20.

20. DETECT MALFUNCTIONING PART

Check the following.

1. Visually check the EVAP canister for damage.
2. Check hose connection between EVAP canister and water separator for clogging and poor connection.

>> Repair hose or replace EVAP canister or water separator.

21. CHECK INTERMITTENT INCIDENT

Perform [EC-120. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END.


DTC P0455 EVAP CONTROL SYSTEM

On Board Diagnosis Logic

NOTE:

If DTC P0455 is displayed with DTC P1448, first perform trouble diagnosis for DTC P1448. (See EC-483.)

This diagnosis detects a very large leak (fuel filler cap fell off etc.) in the EVAP system between the fuel tank and the EVAP canister purge volume control solenoid valve.



PBIB1402E

DTC No.	Trouble diagnosis name	DTC detecting condition	Check Items (Possible Cause)
P0442	EVAP control system gross leak detected.	<ul style="list-style-type: none"> ● EVAP control system has a leak. ● EVAP control system does not operate properly. 	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent. ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged. ● Water separator ● EVAP canister is saturated with water. ● EVAP control system pressure sensor ● Fuel level sensor and the circuit ● Refueling control valve ● ORVR system leaks

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS008TM

CAUTION:

Never remove fuel filter cap during the DTC confirmation procedure.

NOTE:


- If DTC P0455 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See [EC-483](#).)
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.
- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

TESTING CONDITION:

- Perform "DTC WORK SUPPORT" when the fuel level is between 1/4 to 3/4 full and vehicle is placed on flat level surface.
- Open engine hood before conducting the following procedure.

WITH CONSULT-II


1. Tighten fuel filter cap securely until ratcheting sound is heard.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 5 seconds.
4. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
5. Make sure that the following conditions are met.
COOLAN TEMP/S: 0 - 70°C (32 - 158°F)
INT/A TEMP SE: 0 - 60°C (32 - 140°F)
6. Select "EVAP SML LEAK P0442/P1442" of "EVAP SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
 Follow the instruction displayed.



NOTE:

If the engine speed cannot be maintained within the range displayed on the CONSULT-II screen, go to [EC-73, "Basic Inspection"](#).

7. Make sure that "OK" is displayed.
 If "NG" is displayed, select "SELF-DIAG RESULTS" mode with CONSULT-II and make sure that "EVAP GROSS LEAK [P0455]" is displayed. If it is displayed, refer to [EC-356, "Diagnostic Procedure"](#).
 If P0442 is displayed, perform [EC-314, "Diagnostic Procedure"](#).



WITH GST

NOTE:

- Be sure to read the explanation of "Driving Pattern" on [EC-57](#) before driving vehicle.
 - It is better that the fuel level is low.
1. Start engine.
 2. Drive vehicle according to [EC-57, "Driving Pattern"](#).
 3. Stop vehicle.
 4. Select "MODE 1" with GST.
 - If SRT of EVAP system is not set yet, go to the following step.
 - If SRT of EVAP system is set, the result will be OK.
 5. Turn ignition switch "OFF" and wait at least 5 seconds.
 6. Start engine.
It is not necessary to cool engine down before driving.
 7. Drive vehicle again according to the [EC-57, "Driving Pattern"](#).
 8. Stop vehicle.
 9. Select "MODE 3" with GST.
 - If P0455 is displayed on the screen, go to [EC-356, "Diagnostic Procedure"](#).
 - If P0442 is displayed on the screen, go to [EC-314, "Diagnostic Procedure"](#).
 - If P0441 is displayed on the screen, go to [EC-304, "Diagnostic Procedure"](#).
 - If P0441, P0442 and P0455 are not displayed on the screen, go to the following step.
 10. Select "MODE 1" with GST.
 - If SRT of EVAP system is set, the result will be OK.
 - If SRT of EVAP system is not set, go to step 6.

Diagnostic Procedure


UBS0087N

1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch OFF.
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

- OK >> GO TO 2.
- NG >> Replace with genuine NISSAN fuel filler cap.



2. CHECK FUEL FILLER CAP INSTALLATION

Check that the cap is tightened properly by rotating the cap clockwise.

OK or NG

OK >> GO TO 3.

NG >> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.
● Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION

Check for air releasing sound while opening the fuel filler cap.


OK or NG

OK >> GO TO 6.

NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP)

1. Wipe clean valve housing.




2. Check valve opening pressure and vacuum.

Pressure : 16.0 - 20.0 kPa
(0.163 - 0.204 kg/cm², 2.32 - 2.90 psi)

Vacuum : -6.0 to -3.5 kPa
(-0.061 to -0.036 kg/cm², -0.87 to -0.51 psi)

CAUTION:

Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.



OK or NG

OK >> GO TO 5.

NG >> Replace fuel filler cap with a genuine one.

5. CHECK EVAP PURGE LINE

Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection or disconnection.

Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

OK >> GO TO 6.

NG >> Repair or reconnect the hose.

6. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 7.

7. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

Refer to [EC-484, "DTC Confirmation Procedure"](#) .


OK or NG

OK >> GO TO 8.

NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connector.

8. INSTALL THE PRESSURE PUMP

To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely.




NOTE:

Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking.

Models with CONSULT-II>>GO TO 9.


Models without CONSULT-II>>GO TO 10.



9. CHECK FOR EVAP LEAK

With CONSULT-II


1. Turn ignition switch ON.
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.



3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#)

OK or NG

- OK >> GO TO 11.
 NG >> Repair or replace.




10. CHECK FOR EVAP LEAK

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> Repair or replace.



11. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

📖 With CONSULT-II

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode.
4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN
THRTL POS SEN	XXX V

Vacuum should exist.

OK or NG

- OK >> GO TO 14.
- NG >> GO TO 13.

12. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.
Vacuum should exist.

OK or NG

- OK >> GO TO 14.
- NG >> GO TO 13.

13. CHECK VACUUM HOSE

Check vacuum hoses for clogging or disconnection. Refer to [EC-29, "Vacuum Hose Drawing"](#) .

OK or NG

- OK (With CONSULT-II)>>GO TO 14.
- OK (Without CONSULT-II)>>GO TO 15.
- NG >> Repair or reconnect the hose.

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 16.
- NG >> GO TO 15.


ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN
THRTL POS SEN	XXX V

SEF801Y

15. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

SEF334X

Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

SEF335X


OK or NG

OK >> GO TO 16.

NG >> Replace EVAP canister purge volume control solenoid valve.

16. CHECK FUEL TANK TEMPERATURE SENSOR

Check resistance by heating with hot water or heat gun as shown in the figure.




Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

OK or NG

OK >> GO TO 17.


NG >> Replace fuel tank temperature sensor, refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#).



A
EC
C
D
E
F
G
H
I
J
K
L
M


17. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.



CAUTION:

Never apply force to the air hole protector of the sensor, if equipped.



2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.

CAUTION:


- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg , -27.56 inHg) or over 101.3 kPa (760 mmHg , 29.56 inHg) of pressure.

4. Check output voltage between ECM terminal 62 and engine ground.

Applied vacuum kPa (mmHg, inHg)	Voltage [V]
Not applied	1.8 - 4.8
-26.7 (-200 , -7.87)	2.1 to 2.5V lower than above value

CAUTION:

Discard any EVAP control system pressure sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



OK or NG

- OK >> GO TO 18.
- NG >> Replace EVAP control system pressure sensor.

18. CHECK FUEL LEVEL SENSOR

1. Remove fuel level sensor assembly.
Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#).
2. Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#).

OK or NG

- OK >> GO TO 19.
- NG >> Replace fuel level sensor.

19. CHECK INTERMITTENT INCIDENT

Refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0456 EVAP CONTROL SYSTEM


PFP:14950

On Board Diagnosis Logic

UBS00870

This diagnosis detects very small leaks in the EVAP line between the fuel tank and the EVAP canister purge volume control solenoid valve using intake manifold vacuum in the same way as conventional EVAP small leak diagnosis.

If the ECM judges a leak equivalent to a very small leak, the very small leak DTC P0456 or P1456 will be detected. If the ECM judges a leak equivalent to a small leak, the EVAP small leak DTC P0442 will be detected. Correspondingly, if the ECM judges there is no leak, the diagnosis result is OK.



DTC P0456 EVAP CONTROL SYSTEM

[KA24DE]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0456	Evaporative emission control system very small leak (negative pressure check)	<ul style="list-style-type: none"> ● EVAP system has a very small leak. ● EVAP system does not operate properly. 	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged ● Water separator ● EVAP canister is saturated with water ● EVAP control system pressure sensor ● Refueling control valve ● ORVR system leaks ● Fuel level sensor and the circuit ● Foreign matter caught in EVAP canister purge volume control solenoid valve

A
EC
C
D
E
F
G
H
I
J

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS008TP

NOTE:

- If DTC P0456 or P1456 is displayed with DTC P0442, first perform trouble diagnosis for DTC P0456 or P1456.
- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.
- After repair, make sure that the hoses and clips are installed properly.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

Ⓜ WITH CONSULT-II TESTING CONDITION:


- Open engine hood before conducting following procedure.
- If any of following condition is met just before the DTC confirmation procedure, leave the vehicle for more than 1 hour.
 - Fuel filler cap is removed.
 - Refilled or drained the fuel.
 - EVAP component parts is/are removed.

K
L
M

DTC P0456 EVAP CONTROL SYSTEM

[KA24DE]

- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.
1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
 2. Make sure the following conditions are met.
FUEL LEVEL SE: 1.16 - 0.25V
COOLAN TEMP/S: 0 - 32°C (32 - 90°F)
FUEL T/TMP SE: 0 - 32°C (32 - 90°F)
INT A/TEMP SE: More than 0°C (32°F)
If NG, turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle) or refilling/draining fuel until the output voltage condition of the "FUEL LEVEL SE" meets within the range above and leave the vehicle for more than 1 hour. Then start from step 1.
 3. Turn ignition switch "OFF" and wait at least 5 seconds.
 4. Turn ignition switch "ON".
 5. Select "EVAP V/S LEAK P0456/P1456" of "EVAP SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
Follow the instruction displayed.



6. Make sure that "OK" is displayed.
If "NG" is displayed, refer to [EC-369, "Diagnostic Procedure"](#).

NOTE:

- If the engine speed cannot be maintained within the range displayed on CONSULT-II screen, go to [EC-72, "Fail-safe Chart"](#).

Overall Function Check

UBS008TQ

WITH GST

Use this procedure to check the overall function of the EVAP very small leak function. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

- Never use compressed air, doing so may damage the EVAP system.
- Do not start engine.
- Do not exceeded 4.12 kPa (0.042 kg/cm², 0.6 psi).


1. Attach the EVAP service port adapter securely to the EVAP service port.
2. Set the pressure pump and a hose.
3. Also set a vacuum gauge via 3-way connector and a hose.
4. Turn ignition switch "ON".
5. Connect GST and select mode 8.
6. Using mode 8 control the EVAP canister vent control valve (close) and vacuum cut valve bypass valve (open).
7. Apply pressure and make sure the following conditions are satisfied.

Pressure to be applied: 2.7 kPa (20 mmHg, 0.79 inHg)

Time to be waited after the pressure drawn in to the EVAP system and the pressure to be dropped: 60 seconds and the pressure should not be dropped more than 0.4 kPa (3 mmHg, 0.12 inHg)

If NG, go to [EC-369, "Diagnostic Procedure"](#).

If OK, go to next step.



NOTE:

For more information, refer to GST instruction manual.

8. Disconnect GST.
9. Start engine and warm it up to normal operating temperature.
10. Turn ignition switch "OFF" and wait at least 10 seconds.
11. Restart engine and let it idle for 90 seconds.
12. Keep engine speed at 2,000 rpm for 30 seconds.
13. Turn ignition switch "OFF".

Diagnostic Procedure


UBS008TR

1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch "OFF".
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

- OK >> GO TO 2.
 NG >> Replace with genuine NISSAN fuel filler cap.

**2. CHECK FUEL FILLER CAP INSTALLATION**

- Check that the cap is tightened properly by rotating the cap clockwise.

OK or NG

- OK >> GO TO 3.
 NG >> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.
 ● Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION


- Check for air releasing sound while opening the fuel filler cap.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE

1. Wipe clean valve housing.




2. Check valve opening pressure and vacuum.

Pressure : 15.3 - 20.0 kPa
(0.156 - 0.204 kg/cm² , 2.22 - 2.90 psi)

Vacuum : -6.0 to -3.3 kPa
(-0.061 to -0.034 kg/cm² , -0.87 to -0.48 psi)

CAUTION:

Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.




OK or NG

OK >> GO TO 5.

NG >> Replace fuel filler cap with a genuine one.

5. INSTALL THE PRESSURE PUMP

To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely.




NOTE:

Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking.

Models with CONSULT-II>>GO TO 6.

Models without CONSULT-II>>GO TO 7.




6. CHECK FOR EVAP LEAK

 With CONSULT-II

1. Turn ignition switch "ON".
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.
3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#)

OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace.




7. CHECK FOR EVAP LEAK

 Without CONSULT-II

1. Turn ignition switch "OFF".
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace.



8. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 9.
 NG >> Replace water separator.



9. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

- Refer to [EC-484, "DTC Confirmation Procedure"](#) .

OK or NG


- OK >> GO TO 10.
 NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connector.

10. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Does water drain from the EVAP canister?

Yes or No

- Yes >> GO TO 11.
 No (With CONSULT-II)>>GO TO 13.
 No (Without CONSULT-II)>>GO TO 14.



11. CHECK EVAP CANISTER

- Weigh the EVAP canister with the EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK (With CONSULT-II)>>GO TO 13.
 OK (Without CONSULT-II)>>GO TO 14.
 NG >> GO TO 12.

12. DETECT MALFUNCTIONING PART

- Check the following.
 - EVAP canister for damage
 - EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

13. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

With CONSULT-II

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode.
4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 16.
- NG >> GO TO 15.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
HO2S1 MNTR (B1)	LEAN

PBIB0828E

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 15.

15. CHECK VACUUM HOSE

- Check vacuum hoses for clogging or disconnection. Refer to [EC-29, "Vacuum Hose Drawing"](#) .

OK or NG

- OK (With CONSULT-II)>>GO TO 16.
- OK (Without CONSULT-II)>>GO TO 17.
- NG >> Repair or reconnect the hose.

16. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 18.
- NG >> GO TO 17.


ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V


SEF985Y

17. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.







Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

SEF334X

Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.





Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

SEF335X

OK or NG

OK >> GO TO 18.

NG >> Replace EVAP canister purge volume control solenoid valve.


18. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance between fuel level sensor unit and fuel pump terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

OK or NG


- OK >> GO TO 19.
 NG >> Replace fuel level sensor unit.




A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M

19. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.



CAUTION:
Never apply force to the air hole protector of the sensor, if equipped.



2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.


CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg , -27.56 inHg) or over 101.3 kPa (760 mmHg , 29.56 inHg) of pressure.

4. Check output voltage between ECM terminal 62 and engine ground.

Applied vacuum kPa (mmHg, inHg)	Voltage [V]
Not applied	1.8 - 4.8
-26.7 (-200, -7.87)	2.1 to 2.5V lower than above value

CAUTION:
Discard any EVAP control system pressure sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



OK or NG

- OK >> GO TO 20.
- NG >> Replace EVAP control system pressure sensor.

20. CHECK EVAP PURGE LINE

- Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection.
Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 21.
- NG >> Repair or reconnect the hose.

21. CLEAN EVAP PURGE LINE

- Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 22.

22. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

OK >> GO TO 23.

NG >> Replace fuel level sensor unit.

23. CHECK INTERMITTENT INCIDENT

- Refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P0460 FUEL LEVEL SENSOR


PFP:25060

Component Description

UBS008TS

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



On Board Diagnostic Logic

UBS008TT

When the vehicle is parked, naturally the fuel level in the fuel tank is stable. It means that output signal of the fuel level sensor does not change. If ECM senses sloshing signal from the sensor, fuel level sensor malfunction is detected.

Malfunction is detected when even though the vehicle is parked, a signal being varied is sent from the fuel level sensor to ECM.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0460	Fuel level sensor circuit noise	Even though the vehicle is parked, a signal being varied is sent from the fuel level sensor to ECM.	<ul style="list-style-type: none"> ● Fuel level sensor circuit (The sensor circuit is open or shorted) ● Fuel level sensor

DTC Confirmation Procedure

UBS008TU

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait maximum of 2 consecutive minutes.
4. If 1st trip DTC is detected, go to [EC-380, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
FUEL T/TMP SE	XXX °C
FUEL LEVEL SE	XXX V

SEF195Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P0460 FUEL LEVEL SENSOR

[KA24DE]


UBS008TV

Wiring Diagram

EC-FLS1-01



Refer to the following.
F29 - ELECTRICAL UNITS



WBWA0017E

Diagnostic Procedure


1. CHECK FUEL LEVEL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Turn ignition switch "ON".
4. Check voltage between fuel level sensor unit and fuel pump terminal 2 and ground with CONSULT-II or a tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, B103
- Harness for open or short between combination meter and fuel level sensor until and fuel pump

>> Repair or replace harness or connectors.

3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between fuel level sensor unit terminal 4 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to power in harness or connectors.

4. CHECK FUEL LEVEL SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 46 and fuel level sensor unit terminal 2, ECM terminal 66 and fuel level sensor unit terminal 4. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Harness connectors M91, B103
- Harness connectors M67, B101
- Harness for open or short between ECM and fuel level sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace fuel level sensor unit.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Removal and Installation
FUEL LEVEL SENSOR**

UBS008TX

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0461 FUEL LEVEL SENSOR


PFP:25060

Component Description

UBS008TY

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



On Board Diagnostic Logic

UBS008TZ

Driving long distances naturally affects fuel gauge level.

This diagnosis detects the fuel gauge malfunction of the gauge not moving even after a long distance has been driven.

Malfunction is detected when the output signal of the fuel level sensor does not change within the specified range even though the vehicle has been driven a long distance.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0461	Fuel level sensor circuit range/performance	The output signal of the fuel level sensor does not change within the specified range even though the vehicle has been driven a long distance.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Fuel level sensor

Overall Function Check

UBS008U0

Use this procedure to check the overall function of the fuel level sensor function. During this check, a 1st trip DTC might not be confirmed.

WARNING:

When performing following procedure, be sure to observe the handling of the fuel. Refer to [FL-3, "FUEL TANK"](#).

TESTING CONDITION:

Before starting overall function check, preparation of draining fuel and refilling fuel is required.

WITH CONSULT-II

NOTE:

Start from step 11, if it is possible to confirm that the fuel cannot be drained by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) in advance.

1. Prepare a fuel container and a spare hose.
2. Release fuel pressure from fuel line, refer to [EC-45, "FUEL PRESSURE RELEASE"](#).
3. Remove the fuel feed hose on the fuel level sensor unit.
4. Connect a spare fuel hose where the fuel feed hose was removed.
5. Turn ignition switch "OFF" and wait at least 10 seconds then turn "ON".
6. Select "FUEL LEVEL SE" in "DATA MONITOR" mode with CONSULT-II.
7. Check "FUEL LEVEL SE" output voltage and note it.
8. Select "FUEL PUMP" in "ACTIVE TEST" mode with CONSULT-II.
9. Touch "ON" and drain fuel approximately 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) and stop it.
10. Fill fuel into the fuel tank for 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal).
11. Check "FUEL LEVEL SE" output voltage and note it.

DATA MONITOR	
MONITOR	NO DTC
FUEL T/TMP SE	XXX °C
FUEL LEVEL SE	XXX V

SEF195Y

DTC P0461 FUEL LEVEL SENSOR

[KA24DE]


12. Check "FUEL LEVEL SE" output voltage and confirm whether the voltage changes more than 0.03V during step 7 to 11.
If NG, check the fuel level sensor, refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#).

WITH GST

NOTE:

Start from step 11, if it is possible to confirm that the fuel cannot be drained by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) in advance.

1. Prepare a fuel container and a spare hose.
2. Release fuel pressure from fuel line, refer to [EC-45, "FUEL PRESSURE RELEASE"](#).
3. Remove the fuel feed hose on the fuel level sensor unit.
4. Connect a spare fuel hose where the fuel feed hose was removed.
5. Turn ignition switch "OFF".
6. Set voltmeters probe between ECM terminal 46 (fuel level sensor signal) and ground.
7. Turn ignition switch "ON".
8. Check voltage between ECM terminal 46 and ground and note it.
9. Drain fuel by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) from the fuel tank using proper equipment.
10. Fill fuel into the fuel tank for 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal).
11. Confirm that the voltage between ECM terminal 46 and ground changes more than 0.03V during step 8 - 10.
If NG, check component of fuel level sensor, refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#).




DTC P0462, P0463 FUEL LEVEL SENSOR

Component Description

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



On Board Diagnostic Logic

ECM receives two signals from the fuel level sensor circuit.

One is fuel level sensor power supply circuit, and the other is fuel level sensor ground circuit.

This diagnosis indicates the former, to detect open or short circuit malfunction.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0462	Fuel level sensor circuit low input	An excessively low voltage is sent from the sensor is sent to ECM.	<ul style="list-style-type: none"> Fuel level sensor circuit (The sensor circuit is open or shorted) Fuel level sensor
P0463	Fuel level sensor circuit high input	An excessively high voltage is sent from the sensor is sent to ECM.	

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at ignition switch "ON".

WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Wait at least 5 seconds.
- If 1st trip DTC is detected, go to [EC-386, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
FUEL T/TMP SE	XXX °C
FUEL LEVEL SE	XXX V

WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P0462, P0463 FUEL LEVEL SENSOR

[KA24DE]



UBS008U4

Wiring Diagram

EC-FLS2-01



Refer to the following.
 (F29) - ELECTRICAL UNITS



WBWA0018E

Diagnostic Procedure


1. CHECK FUEL LEVEL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit and fuel pump harness connector, ECM harness connector.
3. Turn ignition switch "ON".
4. Check voltage between fuel level sensor unit terminal 2 and ground, ECM terminal 46 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, B103
- Harness connectors M81, F36
- Harness for open or short between combination meter and fuel level sensor unit
- Harness for open or short between combination meter and ECM

>> Repair or replace harness or connectors.

3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between fuel level sensor unit terminal 4 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to power in harness or connectors.

4. CHECK FUEL LEVEL SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 46 and fuel level sensor unit terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Harness connectors M91, B103
- Harness for open or short between ECM and fuel level sensor

>> Repair open circuit or short to power in harness on connectors.

6. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace fuel level sensor unit.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Removal and Installation
FUEL LEVEL SENSOR**

UBS008U6

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .


DTC P0500 VSS

PF3:32702

Component Description

UBS008U7

The vehicle speed sensor is installed in the transmission. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.



On Board Diagnosis Logic

UBS008U8

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0500	Vehicle speed sensor	The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven.	<ul style="list-style-type: none"> ● Harness or connectors (The vehicle speed sensor circuit is open or shorted) ● Vehicle speed sensor

DTC Confirmation Procedure

UBS008U9

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

Ⓜ With CONSULT-II

1. Start engine
2. Read vehicle speed sensor signal in "DATA MONITOR" mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
3. If NG, go to [EC-391, "Diagnostic Procedure"](#) . If OK, go to following step.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Warm engine up to normal operating temperature.
6. Maintain the following conditions for at least 1 minute.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
B/FUEL SCHDL	XXX msec
PW/ST SIGNAL	OFF
VHCL SPEED SE	XXX km/h

SEF196Y

ENG SPEED	1,800 - 6,000 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	7 - 15 msec
Selector lever	Suitable position
PW/ST SIGNAL	OFF

7. If 1st trip DTC is detected, go to [EC-391, "Diagnostic Procedure"](#) .

Overall Function Check

Use this procedure to check the overall function of the EVAP canister vent control valve circuit. During this check, a 1st trip DTC might not be confirmed.

 **WITH GST**

1. Lift up drive wheels.
2. Start engine.
3. Read vehicle speed sensor signal in "MODE 1" with GST.
The vehicle speed sensor on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
4. If NG, go to [EC-391, "Diagnostic Procedure"](#) .




FUEL SYS #1	CLOSED
FUEL SYS #2	CLOSED
CALC LOAD	19%
COOLANT TEMP	93°C
SHORT FT #1	1%
LONG FT #1	0%
SHORT FT #2	3%
LONG FT #2	0%
ENGINE SPD	2037RPM
VEHICLE SPD	12MPH
IGN ADVANCE	38.0°
INTAKE AIR	43°C

SEF568P

A
EC
C
D
E
F
G
H
I
J
K
L
M

Wiring Diagram

EC-VSS-01



Refer to the following.

E43 - SUPER MULTIPLE JUNCTION (SMJ)

F29 - ELECTRICAL UNITS

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
29	G/B	Vehicle speed sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Lift up the vehicle ● In 2nd gear position ● Vehicle speed is 40 km/h (25 MPH) 	<p>1 - 4V★</p>

Diagnostic Procedure

UBS008UC

1. CHECK INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and combination meter harness connector M38.
3. Check harness continuity between ECM terminal 29 and meter terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- Harness for open or short between ECM and combination meter

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK SPEEDOMETER FUNCTION

Make sure that speedometer functions properly.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors E32, E202
- Harness for open or short between combination meter and vehicle speed sensor

>> Repair harness or connectors. Check vehicle speed sensor and its circuit. Refer to [DI-17, "VEHICLE SPEED SENSOR SIGNAL CHECK"](#).

5. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0505 ISC SYSTEM


**Description
SYSTEM DESCRIPTION**

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Idle air control	IACV-AAC valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
PNP switch	Park/Neutral position		
Air conditioner switch	Air conditioner operation		
Power steering oil pressure switch	Power steering load signal		
Battery	Battery voltage		
Vehicle speed sensor	Vehicle speed		
Intake air temperature sensor	Intake air temperature		

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which bypasses the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner, power steering and cooling fan operation).

COMPONENT DESCRIPTION

The IAC valve-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.



CONSULT-II Reference Value in Data Monitor Mode

MONITOR ITEM	CONDITION	SPECIFICATION	
IACV-AAC/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	
		2,000 rpm	Approx. 30%
			—

On Board Diagnosis Logic

UBS008UF

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0505	IACV-AAC valve circuit	An improper voltage signal is sent to ECM through IACV-AAC valve.	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open or shorted.) ● IACV-AAC valve

DTC Confirmation Procedure

UBS008UG

NOTE:


If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch “ON”.

 **WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Wait at least 2 seconds.
4. If 1st trip DTC is detected, go to [EC-396, "Diagnostic Procedure"](#)



SEF058Y

 **WITH GST**

Follow the procedure “With CONSULT-II”.


DTC P0505 ISC SYSTEM

[KA24DE]

UBS008UH




Wiring Diagram

EC-AAC/V-01



— : Detectable line for DTC
— : Non-detectable line for DTC

A
EC
C
D
E
F
G
H
I
J
K
L
M





BBWA0449E

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	OR/L	IACV-AAC valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>10.5 - 11.5V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>1 - 13V★</p> 

Diagnostic Procedure

UBS008UI

1. CHECK POWER SUPPLY

1. Stop engine.
2. Disconnect IACV-AAC valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- Fuse block (J/B) connector M27
- 10A fuse
- Harness for open or short between IACV-AAC valve and fuse

>> Repair harness or connectors.

3. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 101 and terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK IACV-AAC VALVE

Disconnect IACV-AAC valve harness connector.

- Check IACV-AAC valve resistance.


Resistance : Approximately 10 Ω
[at 25°C (77°F)]

- Check plunger for seizing or sticking.
- Check for broken spring.

OK or NG

OK >> GO TO 5.

NG >> Replace IACV-AAC valve.



5. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0506 ISC SYSTEM


**Description
SYSTEM DESCRIPTION**

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Idle air control	IACV-AAC valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
PNP switch	Park/Neutral position		
Air conditioner switch	Air conditioner operation		
Power steering oil pressure switch	Power steering load signal		
Battery	Battery voltage		
Vehicle speed sensor	Vehicle speed		
Intake air temperature sensor	Intake air temperature		

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which bypasses the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner, power steering and cooling fan operation).

COMPONENT DESCRIPTION

The IAC valve-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.



CONSULT-II Reference Value in Data Monitor Mode

MONITOR ITEM	CONDITION		SPECIFICATION
IACV-AAC/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	Approx. 30%
		2,000 rpm	—

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0506	Idle speed control system RPM lower than expected	The idle speed is less than the target idle speed by 100 rpm or more.	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open or shorted) ● IACV-AAC valve

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON again and select “DATA MONITOR” mode with CONSULT-II.
4. Start engine and run it for at least 1 minute at idle speed.
5. If 1st trip DTC is detected, go to [EC-401, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

WITH GST

Follow the procedure “WITH CONSULT-II”.

A
EC
C
D
E
F
G
H
I
J
K
L
M




DTC P0506 ISC SYSTEM

[KA24DE]

UBS008UO

Wiring Diagram

EC-AAC/V-01





BBWA0449E

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	OR/L	IACV-AAC valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>10.5 - 11.5V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>1 - 13V★</p> 

Diagnostic Procedure

UBS008UP

1. CHECK POWER SUPPLY

1. Stop engine.
2. Disconnect IACV-AAC valve harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : **Battery voltage**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- Fuse block (J/B) connector M27
- 10A fuse
- Harness for open or short between IACV-AAC valve and 10A fuse

>> Repair harness or connectors.

3. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 101 and terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK IACV-AAC VALVE

Disconnect IACV-AAC valve harness connector.

- Check IACV-AAC valve resistance.


Resistance : Approximately 10 Ω [at 25°C (77°F)]

- Check plunger for seizing or sticking.
- Check for broken spring.

OK or NG

OK >> GO TO 5.

NG >> Replace IACV-AAC valve.



SEF249W

5. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0507 ISC SYSTEM


Description
SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Idle air control	IACV-AAC valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
PNP switch	Park/Neutral position		
Air conditioner switch	Air conditioner operation		
Power steering oil pressure switch	Power steering load signal		
Battery	Battery voltage		
Vehicle speed sensor	Vehicle speed		
Intake air temperature sensor	Intake air temperature		

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which bypasses the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner, power steering and cooling fan operation).

COMPONENT DESCRIPTION

The IAC valve-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.



CONSULT-II Reference Value in Data Monitor Mode

MONITOR ITEM	CONDITION	SPECIFICATION
IACV-AAC/V	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	Idle Approx. 30%
		2,000 rpm —

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0507	Idle speed control system RPM higher than expected	The idle speed is more than the target idle speed by 200 rpm or more.	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open or shorted) ● IACV-AAC valve ● Intake air leaks ● PCV system

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON again and select "DATA MONITOR" mode with CONSULT-II.
4. Start engine and run it for at least 1 minute at idle speed.
5. If 1st trip DTC is detected, go to [EC-406, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANTEMP/S	XXX °C

SEF174Y

WITH GST

Follow the procedure "WITH CONSULT-II".


DTC P0507 ISC SYSTEM

[KA24DE]

UBS008UV




Wiring Diagram

EC-AAC/V-01



Refer to PG-POWER .
— : Detectable line for DTC
— : Non-detectable line for DTC

A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M





BBWA0449E

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	OR/L	IACV-AAC valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>10.5 - 11.5V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>1 - 13V★</p> 

Diagnostic Procedure

UBS008UW

1. CHECK POWER SUPPLY

1. Stop engine.
2. Disconnect IACV-AAC valve harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- Fuse block (J/B) connector M27
- 10A fuse
- Harness for open or short between IACV-AAC valve and 10A fuse

>> Repair harness or connectors.

3. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 101 and terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK IACV-AAC VALVE

Disconnect IACV-AAC valve harness connector.

- Check IACV-AAC valve resistance.


Resistance : Approximately 10 Ω
[at 25°C (77°F)]

- Check plunger for seizing or sticking.
- Check for broken spring.

OK or NG

OK >> GO TO 5.

NG >> Replace IACV-AAC valve.



5. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


DTC P0510 CTP SWITCH

PFP:22620

Component Description

UBS008UY

A closed throttle position switch and wide open throttle position switch are built into the throttle position sensor unit. The wide open throttle position switch is used only for A/T control. When the throttle valve is in the closed position, the closed throttle position switch sends a voltage signal to the ECM. The ECM only uses this signal to open or close the EVAP canister purge control valve when the throttle position sensor is malfunctioning.



On Board Diagnosis Logic

UBS008UZ

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0510	Closed throttle position switch circuit	Battery voltage from the closed throttle position switch is sent to ECM with the throttle valve opened.	<ul style="list-style-type: none"> ● Harness or connectors (The closed throttle position switch circuit is shorted.) ● Closed throttle position switch ● Throttle position sensor

DTC Confirmation Procedure

UBS008V0

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "CLSD THL/P SW" in "DATA MONITOR" mode with CONSULT-II and check the indication under the following conditions.

Condition	Signal indication
Throttle valve: Idle position	ON
Throttle valve: Slightly open	OFF

If the result is NG, go to [EC-411, "Diagnostic Procedure"](#) .
If OK, go to following step.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
CLSD THL/P SW	ON

SEF197Y

3. Drive the vehicle for at least 5 consecutive seconds under the following condition.

THRTL POS SEN	More than 2.5V
VHCL SPEED SE	More than 4 km/h (2 MPH)
Selector lever	Suitable position
Driving pattern	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

4. If 1st trip DTC is detected, go to [EC-411, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V

SEF198Y

Overall Function Check


Use this procedure to check the overall function of the closed throttle position switch circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Check the voltage between ECM terminal 28 (Closed throttle position switch signal) and ground under the following conditions.

Condition	Voltage
At idle	Battery voltage
At 2,000 rpm	Approximately 0 - 1V

3. If NG, go to [EC-411, "Diagnostic Procedure"](#) .



A
EC
C
D
E
F
G
H
I
J
K
L
M






DTC P0510 CTP SWITCH

[KA24DE]

UBS008V2

Wiring Diagram

EC-TP/SW-01



BBWA0450E

DTC P0510 CTP SWITCH

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
28	BR/W	Throttle position switch (Closed position)	[Ignition switch ON] ● Warm-up condition ● Accelerator pedal released	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch ON] ● Accelerator pedal depressed	Approximately 0V

Diagnostic Procedure

UBS008V3

1. CHECK POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect throttle position switch harness connector.
3. Turn ignition switch "ON".




4. Check voltage between terminal 5 and engine ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- Fuse block (J/B) connector M27
- 10A fuse
- Harness for open or short between throttle position switch and fuse

>> Repair harness or connectors.

3. CHECK INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 28 and terminal 6.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the harness for open or short between throttle position switch and ECM.

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. ADJUST THROTTLE POSITION SWITCH IDLE POSITION

Check the following items. Refer to [EC-73, "Basic Inspection"](#) .

Items	Specifications
Ignition timing	20° ± 2° BTDC
Base idle speed	750 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.1 mm (0.004 in): ON 0.3 mm (0.012 in): OFF
Target idle speed	800 ± 50 rpm (in P or N position)

>> GO TO 6.

6. CHECK CLOSED THROTTLE POSITION SWITCH

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and turn ignition switch "ON".
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Check indication of "CLSD THL/P SW" under the following conditions.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
CLSD THL/P SW	ON

Throttle valve conditions	CLSD THL/P SW
Completely closed	ON
Partially open or completely open	OFF

SEF721Z

NOTE:

Measurement must be made with closed throttle position switch installed in vehicle.

If NG, adjust closed throttle position switch. Refer to [EC-73, "Basic Inspection"](#) .

5. If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.

 Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect throttle position switch harness connector.
4. Check continuity between terminals 5 and 6 under the following conditions.


Throttle valve conditions	Continuity
Completely closed	Yes
Partially open or completely open	No

NOTE:

Continuity measurement must be made with closed throttle position switch installed in vehicle.

If NG, adjust closed throttle position switch. Refer to [EC-73, "Basic Inspection"](#) .

5. If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.



OK or NG

- OK >> GO TO 7.
- NG >> Replace throttle position switch.

7. CHECK THROTTLE POSITION SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and turn ignition switch "ON".
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Check voltage of "THRTL POS SEN" under the following conditions.

NOTE:

Voltage measurement must be made with throttle position sensor installed in vehicle.

If NG, adjust closed throttle position switch. Refer to [EC-73, "Basic Inspection"](#).

5. If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace throttle position sensor.

DATA MONITOR	
MONITOR	NO DTC
COOLANT TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V

SEF198Y

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and turn ignition switch "ON".
3. Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground under the following conditions.


Throttle valve conditions	Voltage [V]
Completely closed	0.2 - 0.8 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.5 (b)

NOTE:

Voltage measurement must be made with throttle position sensor installed in vehicle.

If NG, adjust closed throttle position switch. Refer to [EC-73, "Basic Inspection"](#).

4. If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace throttle position sensor.



OK or NG

- OK >> GO TO 8.
- NG >> Replace throttle position sensor.

8. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END.


DTC P0605 ECM

PF2:23710

Component Description

UBS008V5

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



On Board Diagnosis Logic

UBS008V6

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0605	ECM	ECM calculation function is malfunctioning.	● ECM

DTC Confirmation Procedure

UBS008V7

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

 WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine.
4. Run engine for at least 30 seconds at idle speed.
5. If 1st trip DTC is detected, go to [EC-416, "Diagnostic Procedure"](#)

 WITH GST

Follow the procedure "WITH CONSULT-II".



Diagnostic Procedure**1. INSPECTION START**

 **With CONSULT-II**

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. Perform "DTC Confirmation Procedure".
See previous page.
5. Is the 1st trip DTC P0605 displayed again?

 **With GST**

1. Turn ignition switch ON.
2. Select MODE 4 with GST.
3. Touch "ERASE".
4. Perform "DTC Confirmation Procedure".
See previous page.
5. Is the 1st trip DTC P0605 displayed again?

Yes or No

- Yes >> Replace ECM.
No >> **INSPECTION END.**



DTC P1143 HO2S1

PFP:22690

UBS008V9

Component Description

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS008VA


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	<ul style="list-style-type: none"> Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)			LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS008VB

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the "rich" output is sufficiently high and whether the "lean" output is sufficiently low. When both the outputs are shifting to the lean side, the malfunction will be detected.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1143	Heated oxygen sensor 1 lean shift monitoring	The maximum and minimum voltage from the sensor are not reached to the specified voltages.	<ul style="list-style-type: none"> Heated oxygen sensor 1 Heated oxygen sensor 1 heater Fuel pressure Injectors Intake air leaks

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch ON and select “HO2S1 (B1) P1143” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.
5. Start engine and let it idle for at least 3.0 minutes.

NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 5.

HO2S1 (B1) P1143	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
THRTL POS SEN	XXX V

LEC054A

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)

ENG SPEED	1,200 - 3,150 rpm
Vehicle speed	Less than 100 km/h (Less than 62 MPH)
B/FUEL SCHDL	3.5 - 15 msec
Selector lever	Suitable position

HO2S1 (B1) P1143	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
THRTL POS SEN	XXX V

LEC053A

If “TESTING” is not displayed after 5 minutes, retry from step 2.

7. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to [EC-419. "Diagnostic Procedure"](#).

HO2S1 (B1) P1143	
COMPLETED	

LEC055A


Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.

2. Set voltmeter probes between ECM terminal 50 (Heated oxygen sensor 1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is over 0.1V at least one time.
4. If NG, go to [EC-419, "Diagnostic Procedure"](#) .



UBS008VE


Diagnostic Procedure

1. RETIGHTEN HEATED OXYGEN SENSOR 1

1. Turn ignition switch OFF.
2. Loosen and retighten heated oxygen sensor 1.

**Tightening torque :40 - 60 N·m
(4.1 - 6.1 kg-m, 30 - 44 ft-lb)**


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA.


With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-60, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171. Refer to [EC-225](#).
- No >> GO TO 3.

3. CHECK HEATED OXYGEN SENSOR 1 HEATER

Check resistance between terminals 3 and 1.

Resistance : 2.3 - 4.3 Ω at 25°C (77°F)

Check continuity between terminals 2 and 1, 3 and 2.


Continuity should not exist.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

OK or NG

- OK >> GO TO 4.
- NG >> Replace heated oxygen sensor 1.



4. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-199, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 1.

A

EC

5. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

Refer to [EC-195, "Wiring Diagram"](#) , for circuit.

C

D

>> INSPECTION END.

**Removal and Installation
HEATED OXYGEN SENSOR 1**

UBS008VF

E

Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .

F

G

H

I

J

K

L

M



DTC P1144 HO2S1

PF2:22690

Component Description

UBS008VG

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS008VH


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	<ul style="list-style-type: none"> Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)			LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS008VI

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the “rich” output is sufficiently high. The “lean” output is sufficiently low. When both the outputs are shifting to the rich side, the malfunction will be detected.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1144	Heated oxygen sensor 1 rich shift monitoring	The maximum and minimum voltages from the sensor are beyond the specified voltages.	<ul style="list-style-type: none"> Heated oxygen sensor 1 Heated oxygen sensor 1 heater Fuel pressure Injectors

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch ON and select “HO2S1 (B1) P1144” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.
5. Start engine and let it idle for at least 3.0 minutes.


NOTE:

Never raise engine speed above 3,000 rpm after this step. If the engine speed limit is exceeded, return to step 5.




6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)

ENG SPEED	1,200 - 3,150 rpm
Vehicle speed	Less than 100 km/h (Less than 62 MPH)
B/FUEL SCHDL	3.5 - 15 msec
Selector lever	Suitable position



If “TESTING” is not displayed after 5 minutes, retry from step 2.

7. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to [EC-424, "Diagnostic Procedure"](#).



Overall Function Check


Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a DTC might not be confirmed.

 **WITH GST**

1. Start engine and warm it up to normal operating temperature.

A
EC
C
D
E
F
G
H
I
J
K
L
M

2. Set voltmeter probes between ECM terminal 50 (Heated oxygen sensor 1 signal) and ECM ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is below 0.8V at least one time.
 - The minimum voltage is below 0.35V at least one time.
4. If NG, go to [EC-424, "Diagnostic Procedure"](#) .



UBS008VL


Diagnostic Procedure

1. RETIGHTEN HEATED OXYGEN SENSOR 1

1. Turn ignition switch OFF.
2. Loosen and retighten heated oxygen sensor 1.

**Tightening torque : 40 - 60 N·m
(4.1 - 6.1 kg-m, 30 - 44 ft-lb)**


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-60. "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172. Refer to [EC-232](#).
No >> GO TO 3.

3. CHECK HARNESS CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 1 harness connector.
3. Check harness connector for water.
Water should not exit.

OK or NG

- OK >> GO TO 4.
NG >> Repair or replace harness connector.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

Check resistance between terminals 3 and 1.

Resistance : 2.3 - 4.3 Ω at 25°C (77°F)

Check continuity between terminals 2 and 1, 3 and 2.

Continuity should not exist.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 5.

NG >> Replace heated oxygen sensor 1.

5. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-199, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT


Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

Refer to [EC-195, "Wiring Diagram"](#) , for circuit.

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .



SEF220W

UBS008VM

DTC P1146 HO2S2

PF2:226A0

Component Description


UBS008VN

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

UBS008VO


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revsing engine from idle up to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revsing engine from idle up to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

UBS008VP

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifole) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the minimum voltage of the sensor is sufficiently low during various driving conditions such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1146	Heated oxygen sensor 2 minimum voltage monitoring	<ul style="list-style-type: none"> ● The minimum voltage from the sensor is not reached to the specified voltage. 	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors

DTC Confirmation Procedure

NOTE:


If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Open engine hood before conducting following procedure

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 10 seconds.
3. Start engine and keep engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Select “HO2S2 (B1) P1146” of “HO2S2” in “DTC WORK SUPPORT” mode with CONSULT-II and follow the instruction of CONSULT-II.



6. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”.
 If “NG” is displayed, refer to [EC-431, "Diagnostic Procedure"](#).
 If “CAN NOT BE DIAGNOSED” is displayed, perform the following.
 - a. Turn ignition switch “OFF” and leave the vehicle in a cool place (soak the vehicle).
 - b. Turn ignition switch “ON” and select “COOLANTEMP/S” in “DATA MONITOR” mode with CONSULT-II.
 - c. Start engine and warm it up while monitoring “COOLANTEMP/S” indication on CONSULT-II.
 - d. When “COOLANTEMP/S” indication reaches to 70°C (158°F), go to step 3.

Overall Function Check


Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 5 seconds.
3. Start engine and keep engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeter probes between ECM terminals 56 (Heated oxygen sensor 2 signal) and engine ground.
6. Check the voltage when revving engine up to 4,000 rpm under no load at least 10 times.
 (Depress and release accelerator pedal as soon as possible.)
The voltage should be below 0.54V at least once during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.
The voltage should be below 0.54V at least once during this procedure.



8. If NG, go to [EC-431, "Diagnostic Procedure"](#) .

A

EC

C

D

E

F

G

H

I

J


K

L



M

Wiring Diagram

EC-HO2S2-01



: Detectable line for DTC
 : Non-detectable line for DTC
EP : EARLY PRODUCTION
LP : LATE PRODUCTION
*1 EP : 10
*1 LP : 3



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Revving engine from idle up to 3,000 rpm quickly after the following conditions are met. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - Approximately 1.0V


Diagnostic Procedure

UBS008VT

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.




2. CLEAR THE SELF-LEARNING DATA

④ With CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.

**Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch "OFF".
 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.
 4. Stop engine and reconnect mass air flow sensor harness connector.
 5. Make sure DTC P0102 is displayed.
 6. Erase the DTC memory. Refer to [EC-60, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
 7. Make sure DTC P0000 is displayed.
 8. Run engine for at least 10 minutes at idle speed.
- Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172. Refer to [EC-232](#) .
No >> GO TO 3.

3. CHECK INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 2 harness connector and ECM harness connector.
3. Check harness continuity between ECM terminal 56 and HO2S2 terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Check harness continuity between ECM terminal 56 or HO2S2 terminal 1 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between heated oxygen sensor 2 and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK GROUND CIRCUIT

1. Check harness continuity between heated oxygen sensor 2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between heated oxygen sensor 2 and engine ground

>> Repair open circuit or short to power in harness or connectors.

7. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-213, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace heated oxygen sensor 2.

8. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

**Removal and Installation
HEATED OXYGEN SENSOR 2**

Refer to [EX-3, "EXHAUST SYSTEM"](#) .


UBS008VU

DTC P1147 HO2S2

Component Description

UBS008VV

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

UBS008VV


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle up to 3,000 rpm quickly.	0 - 0.3V ←→ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	Revving engine from idle up to 3,000 rpm quickly.	LEAN ←→ RICH

On Board Diagnosis Logic

UBS008VX

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the maximum voltage of the sensor is sufficiently high during various driving conditions such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1147	Heated oxygen sensor 2 maximum voltage monitoring	<ul style="list-style-type: none"> ● The maximum voltage from the sensor is not reached to the specified voltage. 	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors ● Intake air leaks

DTC Confirmation Procedure

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Open engine hood before conducting following procedure

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Select "HO2S2 (B1) P1147" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II and follow the instruction of CONSULT-II.



6. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-438, "Diagnostic Procedure"](#).
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a. Turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle).
 - b. Turn ignition switch "ON" and select "COOLANTEMP/S" in "DATA MONITOR" mode with CONSULT-II.
 - c. Start engine and warm it up while monitoring "COOLANTEMP/S" indication on CONSULT-II.
 - d. When "COOLANTEMP/S" indication reaches to 70°C (158°F), go to step 3.

Overall Function Check


Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 5 seconds.
3. Start engine and keep engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeter probes between ECM terminals 56 (Heated oxygen sensor 2 signal) and engine ground.
6. Check the voltage when revving engine up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.56V at least once during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.
The voltage should be above 0.56V at least once during this procedure.




8. If NG, go to [EC-438, "Diagnostic Procedure"](#) .



Wiring Diagram

EC-HO2S2-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 10
- LP : 3



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Revving engine from idle up to 3,000 rpm quickly after the following conditions are met. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load 	0 - Approximately 1.0V


Diagnostic Procedure

UBS008W1

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-60. "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171. Refer [EC-225](#).
No >> GO TO 3.

3. CHECK INPUT SIGNAL CIRCUIT

1. Disconnect heated oxygen sensor 2 harness connector and ECM harness connector.
2. Check harness continuity between ECM terminal 56 and HO2S2 terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

3. Check harness continuity between ECM terminal 56 or HO2S2 terminal 1 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between ECM and heated oxygen sensor 2

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK GROUND CIRCUIT

1. Check harness continuity between heated oxygen sensor 2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between heated oxygen sensor 2 and engine ground

>> Repair open circuit or short to power in harness or connectors.

7. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-213, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace heated oxygen sensor 2.

8. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

UBS008W2

DTC P1148 CLOSED LOOP CONTROL

PFP:22690

On Board Diagnosis Logic

UBS008W3

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1148	Closed loop control function	The closed loop control function does not operate even when vehicle is driving in the specified condition.	<ul style="list-style-type: none"> ● The heated oxygen sensor 1 circuit is open or shorted. ● Heated oxygen sensor 1 ● Heated oxygen sensor heater

DTC Confirmation Procedure

UBS008W4

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Never raise engine speed above 3,000 rpm during the "DTC Confirmation Procedure". If the engine speed limit is exceeded, retry the procedure from step 4.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Hold engine speed at 2,000 rpm and check the following.
 - "HO2S1 (B1)" voltage should go above 0.70V at least once.
 - "HO2S1 (B1)" voltage should go below 0.21V at least once. If the result is NG, perform [EC-442, "Diagnostic Procedure"](#). If the result is OK, perform the following step.
4. Let engine idle at least 3 minutes.
5. Maintain the following condition at least 50 consecutive seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
VHCL SPEED SE	XXX km/h

SEF682Y

B/FUEL SCHDL	4.0 msec or more
ENG SPEED	1,800 - 3,000 rpm
Selector lever	Suitable position
VHCL SPEED SE	More than 70 km/h (43 MPH)

During this test, DTC P0134 may be displayed on CONSULT-II screen.

6. If DTC is detected, go to [EC-442, "Diagnostic Procedure"](#).

Overall Function Check

UBS008W5

Use this procedure to check the overall function of the closed loop control. During this check, a DTC might not be confirmed.


WITH GST

1. Start engine and warm it up to normal operating temperature.

DTC P1148 CLOSED LOOP CONTROL

[KA24DE]

2. Set voltmeter probes between ECM terminal 50 (Heated oxygen sensor 1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage should go above 0.70V at least once.
 - The voltage should go below 0.21V at least once.
4. If NG, go to [EC-442, "Diagnostic Procedure"](#) .



Diagnostic Procedure

Refer to [EC-196, "Diagnostic Procedure"](#) .

UBS008W6

DTC P1217 ENGINE OVER TEMPERATURE

PFP:00000

On Board Diagnosis Logic

UBS008W7

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1217	Engine over temperature (Overheat)	<ul style="list-style-type: none"> ● Cooling fan does not operate properly (Overheat). ● Cooling fan system does not operate properly (Overheat). ● Engine coolant was not added to the system using the proper filling method. 	<ul style="list-style-type: none"> ● Cooling fan (crankshaft driven) ● Radiator hose ● Radiator ● Radiator cap ● Water pump ● Thermostat ● Engine coolant temperature sensor <p>For more information, refer to EC-445, "Main 11 Causes of Overheating".</p>

CAUTION:

When a malfunction is indicated, be sure to replace the coolant. Refer to [MA-16, "Changing Engine Coolant"](#). Also, replace the engine oil.

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-14, "ANTI-FREEZE COOLANT MIXTURE RATIO"](#).
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Overall Function Check


UBS008W8

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
 If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-444, "Diagnostic Procedure"](#).
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-444, "Diagnostic Procedure"](#).



SEF621W

Diagnostic Procedure

1. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.

Testing pressure : 157 kPa (1.6 kg/cm² , 23 psi)

CAUTION:


Higher than the specified pressure may cause radiator damage. Pressure should not drop.

OK or NG

OK >> GO TO 2.

NG >> Check the following for leak.

- Hose
 - Radiator
 - Water pump
- Refer to [CO-10, "WATER PUMP"](#) .



2. CHECK RADIATOR CAP


Apply pressure to cap with a tester.

Radiator cap relief pressure : 78 - 98 kPa
(0.8 - 1.0 kg/cm² , 11 - 14 psi)

OK or NG

OK >> GO TO 3.

NG >> Replace radiator cap.



3. CHECK THERMOSTAT

1. Check valve seating condition at normal room temperatures. **It should seat tightly.**
2. Check valve opening temperature and valve lift.

Valve opening temperature : 76.5°C (170°F) [standard]

Valve lift : More than 8 mm/90°C
(0.31 in/194°F)


3. Check if valve is closed at 5°C (9°F) below valve opening temperature.

For details, refer to [CO-13, "THERMOSTAT"](#) .

OK or NG


OK >> GO TO 4.

NG >> Replace thermostat.



4. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Check resistance as shown in the figure.




<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

OK or NG

- OK >> GO TO 5.
- NG >> Replace engine coolant temperature sensor.



5. CHECK MAIN 11 CAUSES

If the cause cannot be isolated, go to [EC-445, "Main 11 Causes of Overheating"](#) .

>> **INSPECTION END**

Perform FINAL CHECK by the following procedure after repair is completed.

- Warm up engine. Run the vehicle for at least 20 minutes. Pay attention to engine coolant temperature gauge on the instrument panel. If the reading shows an abnormally high temperature, another part may be malfunctioning.
- Stop vehicle and let engine idle. Check the intake and exhaust systems for leaks by listening for noise or visually inspecting the components.
- Allow engine to cool and visually check for oil and coolant leaks. Then, perform "Overall Function Check".

Main 11 Causes of Overheating

UBS008WA

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> ● Blocked radiator ● Blocked condenser ● Blocked radiator grille ● Blocked bumper 	● Visual	No blocking	—
	2	● Coolant mixture	● Coolant tester	50 - 50% coolant mixture	See MA-12, "RECOMMENDED FLUIDS AND LUBRICANTS" .
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See MA-16, "Changing Engine Coolant" .
	4	● Radiator cap	● Pressure tester	78 - 98 kPa (0.8 - 1.0 kg/cm ² , 11 - 14 psi) 59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See CO-8, "System Check"

DTC P1217 ENGINE OVER TEMPERATURE

[KA24DE]

Engine	Step	Inspection item	Equipment	Standard	Reference page
ON*2	5	● Coolant leaks	● Visual	No leaks	See CO-8, "System Check" .
ON*2	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot	See CO-13, "THERMOSTAT" and CO-14, "RADIATOR" .
OFF	7	● Combustion gas leak	● Color checker chemical tester 4 Gas analyzer	Negative	—
ON*3	8	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See MA-16, "Changing Engine Coolant" .
OFF*4	9	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See CO-8, "System Check" .
OFF	10	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-30, "CYLINDER HEAD" .
	11	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See EM-46, "CYLINDER BLOCK" .

*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to [CO-6, "OVERHEATING CAUSE ANALYSIS"](#) .

DTC P1336 CKP SENSOR (OBD)

Component Description

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.



The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system.

It is used only for the on board diagnosis.



On Board Diagnosis Logic

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1336	Crankshaft position sensor (OBD) (COG)	<ul style="list-style-type: none"> A chipping of the flywheel or drive plate gear tooth (cog) is detected by the ECM. 	<ul style="list-style-type: none"> Harness or connectors Crankshaft position sensor (OBD) Drive plate/Flywheel


DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

- Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- Start engine and run it for at least 2 minutes at idle speed.
- If 1st trip DTC is detected, go to [EC-449, "Diagnostic Procedure"](#)



WITH GST

Follow the procedure "WITH CONSULT-II".



DTC P1336 CKP SENSOR (OBD)

[KA24DE]

UBS008WE

Wiring Diagram

EC-CKPS-01



BBWA0548E

DTC P1336 CKP SENSOR (OBD)

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (AC Voltage)
43	B/W	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
47	L	Crankshaft position sensor (OBD)	[Engine is running] ● Warm-up condition ● Idle speed	Approx. 0V★ (V) SEF112V
			[Engine is running] ● Engine speed is 2,000 rpm	Approx. 0V★ (V) SEF113V

Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK INPUT SIGNAL CIRCUIT


1. Disconnect crankshaft position sensor (OBD) and ECM harness connectors.
2. Check harness continuity between ECM terminal 47 and crankshaft position sensor (OBD) terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E202, E32
- Harness connectors E41, F25
- Harness for open or short between crankshaft position sensor (OBD) and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK GROUND CIRCUIT

1. Reconnect ECM harness connectors.
2. Check harness continuity between crankshaft position sensor (OBD) terminal 1 and engine ground. Refer to wiring diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E202, E32
- Harness connectors E41, F25
- Harness for open or short between crankshaft position sensor (OBD) and ECM

>> Repair open circuit or short to power in harness or connectors.

6. CHECK SHIELD CIRCUIT

1. Turn ignition switch OFF".
2. Disconnect harness connectors E202, E32.
3. Check harness continuity between harness connector E32 terminal 2 and ground. Refer to wiring diagram.

Continuity should exist

4. Also check harness for short to power.
5. Then reconnect harness connectors.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E41, F25
- Harness for open or short between harness connector E32 and engine ground

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK IMPROPER INSTALLATION

1. Loosen and retighten the fixing bolt of the crankshaft position sensor (OBD). Then retest.
2. Perform [EC-447, "DTC Confirmation Procedure"](#) again.

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 9.

9. CHECK CRANKSHAFT POSITION SENSOR (OBD)

Refer to [EC-267, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
NG >> Replace crankshaft position sensor (OBD).

10. CHECK GEAR TOOTH

Visually check for chipping flywheel or drive plate gear tooth (cog).

OK or NG

- OK >> GO TO 11.
NG >> Replace the flywheel or drive plate.

11. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L


M

DTC P1400 EGRC-SOLENOID VALVE

Component Description

UBS008WH

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an OFF signal, the vacuum signal passes through the solenoid valve. The signal then reaches the EGR valve. When the ECM sends an ON signal, a plunger will then move to cut the vacuum signal from the throttle body to the EGR valve.



SEF240PD

CONSULT-II Reference Value in Data Monitor Mode

UBS008WJ

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
EGRC SOL/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" (A/T models) ● No-load 	Idle	ON
		Rev engine up from idle to 3,000 rpm quickly.	OFF

On Board Diagnosis Logic

UBS008WJ

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1400	EGRC solenoid valve circuit	The improper voltage signal is sent to ECM through EGRC solenoid valve.	<ul style="list-style-type: none"> ● Harness or connectors (The EGRC solenoid valve circuit is open or shorted.) ● EGRC solenoid valve

DTC Confirmation Procedure

UBS008WK

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform at a temperature above -10°C (14°F).

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode with CONSULT-II.



SEF174Y

DTC P1400 EGRC-SOLENOID VALVE

[KA24DE]

3. Maintain the following conditions for at least 5 consecutive seconds.

ENG SPEED	Less than 3,000 rpm
B/FUEL SCHDL	Less than 12.6 msec
VHCL SPEED SE	Suitable speed

4. If 1st trip DTC is detected, go to [EC-455, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V
B/FUEL SCHDL	XXX msec

SEF201Y

Overall Function Check

UBS008WL


Use this procedure to check the overall function of the EGR temperature sensor. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Check the voltage between ECM terminal 103 and ground at idle.

Voltage : 0 - 1V

3. Check that the voltage changes to battery voltage and returns to 0 - 1V when revving the engine from idle to 3,000 rpm quickly.
4. If NG, go to [EC-455, "Diagnostic Procedure"](#) .






DTC P1400 EGRC-SOLENOID VALVE

[KA24DE]


UBS008WM

Wiring Diagram

EC-EGRC1-01



Refer to the following.
 E43 - SUPER MULTIPLE JUNCTION (SMJ)



BBWA0453E

DTC P1400 EGRC-SOLENOID VALVE

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
103	G/W	EGRC-solenoid valve	[Engine is running] ● Warm-up condition ● Idle speed	0 - 1V
			[Engine is running] ● Warm-up condition ● M/T models: Lift up drive wheels and shift to 1st gear position. ● Rev engine up from 2,000 to 4,000 rpm.	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS008WN

1. CHECK EGRC SOLENOID VALVE

 **With CONSULT-II**

- Turn ignition switch "ON".
- Turn EGRC solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.

ACTIVE TEST	
EGRC SOL/V	ON
MONITOR	
ENG SPEED	XXX rpm

SEF722Z

 **Without CONSULT-II**


- Start engine and rev engine up to 3,000 rpm quickly.
- When disconnecting and reconnecting the EGRC solenoid valve harness connector, make sure that the EGRC solenoid valve makes operating sound. (The DTC or the 1st trip DTC for the EGRC solenoid valve will be displayed, however, ignore it.)

OK or NG

- OK (With CONSULT-II)>>GO TO 6.
- OK (Without CONSULT-II)>>GO TO 7.
- NG >> GO TO 2

2. CHECK POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect EGRC solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M59, F27
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between EGRC solenoid valve and fuse

>> Repair harness or connectors.

4. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 103 and terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK (With CONSULT-II)>>GO TO 6.
- OK (Without CONSULT-II)>>GO TO 7.
- NG >> GO TO 5

5. DETECT MALFUNCTIONING PART


Check the harness for open or short between EGRC solenoid valve and ECM.

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK EGRC SOLENOID VALVE

With CONSULT-II

Check air passage continuity.
Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.



ACTIVE TEST	
EGRC SOL/V	ON
(EGR)	CUT
MONITOR	
ENG SPEED	XXX rpm

Condition	Air passage continuity between A and B	Air passage continuity between A and C
ON	Yes	No
OFF	No	Yes

Operation takes less than 1 second.

LEC036A


OK or NG

- OK >> GO TO 8.
- NG >> Replace EGRC solenoid valve.

7. CHECK EGRC SOLENOID VALVE

Without CONSULT-II

Check air passage continuity shown in the figure.



Condition	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

Operation takes less than 1 second.

LEC037A

OK or NG

- OK >> GO TO 8.
- NG >> Replace EGRC solenoid valve.

8. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1402 EGR FUNCTION

PFP:14710


Description SYSTEM DESCRIPTION

UBS008WP

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EGR control	EGRC-solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		

This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current through the solenoid valve is cut. This causes the vacuum to be cut. The EGR valve remains closed.


- Low engine coolant temperature
- Engine starting
- High-speed engine operation
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction



COMPONENT DESCRIPTION

Exhaust Gas Recirculation (EGR) Valve


The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.



EGRC-solenoid Valve

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an OFF signal, the vacuum signal passes through the solenoid valve. A plunger will then move to cut the vacuum signal (from the throttle body to the EGR valve).

When the ECM sends an ON signal, a plunger will then move to cut the vacuum signal from the throttle body to the EGR valve.



SEF240PD


UBS008WQ

On Board Diagnosis Logic

If EGR temperature sensor detects EGR flow under the condition that does not call for EGR, a high-flow malfunction is diagnosed.

NOTE:

Diagnosis for this DTC will occur when engine coolant temperature is approx. 50 to 60°C (122 to 140°F). Therefore, it will be better to turn ignition switch “ON” (Start engine) at the engine coolant temperature below 40°C (104°F) when starting DTC confirmation procedure.



SEF073P

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1402	EGR control system stuck open	EGR flow is detected under conditions that do not call for EGR.	<ul style="list-style-type: none"> ● EGRC solenoid valve ● EGR valve leaking or stuck open ● EGR temperature sensor ● EGRC-BPT valve

DTC Confirmation Procedure

UBS008WR

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


TESTING CONDITION:

- Engine coolant temperature and EGR temperature must be verified in “DATA MONITOR” mode with CONSULT-II before starting DTC WORK SUPPORT test. If it is out of range below, the test cannot be conducted.

COOLAN TEMP/S: -10 to 60°C (14 to 140°F)*

EGR TEMP SEN: Less than 3.7V

If the values are out of the ranges indicated above, park the vehicle in a cool place and allow the engine temperature to stabilize. Do not attempt to reduce the engine coolant or EGR temperature with a fan or means other than ambient air. Doing so may produce an inaccurate diagnostic result.



SEF202Y

*: Although CONSULT-II screen displays “-10 to 40°C (14 to 104°F)” as a range of engine coolant temperature, ignore it.


WITH CONSULT-II

1. Turn ignition switch OFF and wait at least 5 seconds, then turn ignition switch ON.


DTC P1402 EGR FUNCTION

[KA24DE]

2. Select "EGR SYSTEM P1402" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.




3. Touch "START". Follow instruction of CONSULT-II.




4. Start engine and let it idle until "TESTING" on CONSULT-II screen is turned to "COMPLETED". (It will take 60 seconds or more.)

If "TESTING" is not displayed after 5 minutes, turn ignition "OFF" and cool the engine coolant temperature to the range of -10 to 60°C (14 to 140°F). Retry from step 1.



5. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-463, "Diagnostic Procedure"](#).



WITH GST

1. Turn ignition switch ON and select "MODE 1" with GST.
2. Check that engine coolant temperature is within the range of -10 to 35°C (14 to 95°F).
3. Check that voltage between ECM terminal 63 (EGR temperature sensor signal) and ground is less than 4.8V.
4. Start engine and let it idle for at least 60 seconds.
5. Stop engine.
6. Perform from step 1 to 4.
7. Select "MODE 3" with GST.

DTC P1402 EGR FUNCTION

[KA24DE]

-
8. If DTC is detected, go to [EC-463, "Diagnostic Procedure"](#) .
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

A

EC

C

D

E

F

G

H

I

J


K

L

M




Wiring Diagram

EC-EGRC1-01



Refer to the following.

(E43) - SUPER MULTIPLE JUNCTION (SMJ)




Diagnostic Procedure

1. CHECK VACUUM HOSE

Check vacuum hose for clogging, cracks or improper connection.
Refer to [EC-29. "Vacuum Hose Drawing"](#) .

OK or NG

- OK (With CONSULT-II)>>GO TO 2.
- OK (Without CONSULT-II)>>GO TO 3.
- NG >> Repair or replace vacuum hose.



2. CHECK EGRC SOLENOID VALVE CIRCUIT

Ⓜ With CONSULT-II

1. Turn ignition switch ON.
2. Turn EGRC solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.
Clicking noise should be heard.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

ACTIVE TEST	
EGRC SOL/V	ON
(EGR)	CUT
MONITOR	
ENG SPEED	XXX rpm

The table is identified by the code SEF716Z.

3. CHECK EGRC SOLENOID VALVE CIRCUIT

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect EGRC solenoid valve harness connector.
3. Turn ignition switch ON.
4. Check operating sound of the solenoid valve when disconnecting and reconnecting EGRC solenoid valve harness connector. (The DTC or the 1st trip DTC for the EGRC solenoid valve will be displayed, however, ignore it.)

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M59, F27
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between fuse block and EGRC solenoid valve
- Harness for open or short between ECM and EGRC solenoid valve

OK or NG

OK >> GO TO 5.


NG >> Repair open circuit or short to power in harness or connector.

5. CHECK EGRC SOLENOID VALVE

Ⓜ With CONSULT-II

Check air passage continuity.

Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.



ACTIVE TEST	
EGRC SOL/V	ON
(EGR)	CUT
MONITOR	
ENG SPEED	XXX rpm

Condition	Air passage continuity between A and B	Air passage continuity between A and C
ON	Yes	No
OFF	No	Yes

Operation takes less than 1 second.

LEC036A

OK or NG


OK >> GO TO 7.

NG >> Replace EGRC solenoid valve.

6. CHECK EGRC SOLENOID VALVE

⊗ Without CONSULT-II

Check air passage continuity shown in the figure.



Condition	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

Operation takes less than 1 second.

LEC037A

OK or NG

OK >> GO TO 7.


NG >> Replace EGRC solenoid valve.

7. CHECK EGR VALVE

- Apply vacuum to EGR vacuum port with a hand vacuum pump. **EGR valve spring should lift.**
- Check for sticking.

OK or NG


- OK >> GO TO 8.
 NG >> Replace EGR valve.

**8. CHECK EGRC-BPT VALVE**

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂ O, 3.94 inH₂ O) from under EGRC-BPT valve.
3. If a leakage is noted, replace the valve.


OK or NG

- OK >> GO TO 9.
 NG >> Replace EGRC-BPT valve.



9. CHECK EGR TEMPERATURE SENSOR

Check resistance change and resistance value.




<Reference data>

EGR temperature C (F)	Voltage [V]	Resistance M
0 (32)	4.56	0.62 - 1.05
50 (122)	2.25	0.065 - 0.094
100 (212)	0.59	0.011 - 0.015

OK or NG

- OK >> GO TO 10.
- NG >> Replace EGR temperature sensor.



10. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1442 EVAP CONTROL SYSTEM

On Board Diagnosis Logic


NOTE:

If DTC P0442 is displayed with DTC P1448, first perform trouble diagnosis for DTC P1448. (See [EC-483](#) .)

This diagnosis detects leaks in the EVAP purge line using engine intake manifold vacuum.

If pressure does not increase, the ECM will check for leaks in the line between the fuel tank and EVAP canister purge volume control solenoid valve under the following "Vacuum test" conditions.

The vacuum cut valve bypass valve is opened to clear the line between the fuel tank and the EVAP canister purge volume control solenoid valve. The EVAP canister vent control valve will then be closed to shut the EVAP purge line off. The EVAP canister purge volume control solenoid valve is opened to depressurize the EVAP purge line using intake manifold vacuum. After this occurs, the EVAP canister purge volume control solenoid valve will be closed.



PBIB1402E

DTC P1442 EVAP CONTROL SYSTEM

[KA24DE]

DTC No.	Trouble diagnosis name	DTC detecting condition	Check Items (Possible Cause)
P1442	EVAP control system small leak detected (positive pressure)	<ul style="list-style-type: none"> ● EVAP control system has a leak. ● EVAP control system does not operate properly. 	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent. ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged. ● Water separator ● EVAP canister is saturated with water. ● EVAP control system pressure sensor ● Fuel level sensor and the circuit ● Refueling control valve ● ORVR system leaks

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS008WV

Refer to "DTC P0442 EVAP CONTROL SYSTEM", [EC-312, "DTC Confirmation Procedure"](#) .

Diagnostic Procedure

UBS008WV

Refer to "DTC P0442 EVAP CONTROL SYSTEM", [EC-314, "Diagnostic Procedure"](#) .

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [KA24DE]

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PFP:14920

UBS008WX


Description SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Throttle position switch	Closed throttle position		
Heated oxygen sensor 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Fuel tank temperature sensor	Fuel temperature in fuel tank		
Vehicle speed sensor	Vehicle speed		

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



CONSULT-II Reference Value in Data Monitor Mode

UBS008WY

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PURG VOL C/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch "OFF" ● Shift lever: "N" ● No-load 	Idle (Vehicle stopped)
	2,000 rpm (200 seconds after starting engine)	—

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [KA24DE]

UBS008WZ

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1444	EVAP canister purge volume control solenoid valve	The canister purge flow is detected during the specified driving conditions, even when EVAP canister purge volume control solenoid valve is completely closed.	<ul style="list-style-type: none"> ● EVAP control system pressure sensor ● EVAP canister purge volume control solenoid valve (The valve is stuck open.) ● EVAP canister vent control valve ● EVAP canister ● Hoses (Hoses are connected incorrectly or clogged.)

DTC Confirmation Procedure

UBS008X0

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.
4. Select “DATA MONITOR” mode with CONSULT-II.
5. Check that “FUEL T/TMP SE” is 0°C (32°F) or more.
6. Select “PURG VOL C/V P1444” of “EVAP SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II.
7. Touch “START”.

PURG VOL CN/V P1444	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
THRTL POS SEN	XXX V
B/FUEL SCHDL	XXX msec

SEF205Y


8. Start engine and let it idle until “TESTING” on CONSULT-II changes to “COMPLETED”. (It will take for at least 10 seconds.)
If “TESTING” is not displayed after 5 minutes, retry from step 2.

PURG VOL CN/V P1444	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
THRTL POS SEN	XXX V
B/FUEL SCHDL	XXX msec

SEF206Y

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [KA24DE]

9. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-474, "Diagnostic Procedure"](#).



WITH GST



Follow the procedure "WITH CONSULT-II".

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [KA24DE]

UBS008X1

Wiring Diagram

EC-PGC/V-01



WBWA0015E



DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	LG/R	ECM relay (Self-shutoff)	[Engine is running] [Ignition switch "OFF"] <ul style="list-style-type: none"> For a few seconds after turning ignition switch "OFF" 	0 - 1V
			[Ignition switch "OFF"] <ul style="list-style-type: none"> A few seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)
5	R/Y	EVAP canister purge volume control solenoid valve	[Engine is running] <ul style="list-style-type: none"> Idle speed 	BATTERY VOLTAGE (11 - 14V)★ (V)  <small>SEF109V</small>
			[Engine is running] <ul style="list-style-type: none"> Engine speed is 2,000 rpm 	BATTERY VOLTAGE (11 - 14V)★ (V)  <small>SEF110V</small>
67	B/P	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
72	B/P			
117	B/P	Current return	[Engine is running] <ul style="list-style-type: none"> Idle speed 	BATTERY VOLTAGE (11 - 14V)


DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [KA24DE]

UBS008X2

Diagnostic Procedure

1. CHECK POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between EVAP canister purge volume control solenoid valve terminal 2 and engine ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair harness or connectors.

3. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 5 and EVAP canister purge volume control solenoid valve terminal 1.
Refer to Wiring diagram.
Continuity should exist.
4. Also, check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART


Check the harness for open or short between EVAP canister purge volume control solenoid valve and ECM.

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [KA24DE]


5. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.



CAUTION:

Never apply force to the air hole protector of the sensor, if equipped.



2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.

CAUTION:


- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg , -27.56 inHg) or over 101.3 kPa (760 mmHg , 29.56 inHg) of pressure.

4. Check output voltage between ECM terminal 62 and engine ground.

Applied vacuum kPa (mmHg, inHg)	Voltage [V]
Not applied	1.8 - 4.8
-26.7 (-200 , -7.87)	2.1 to 2.5V lower than above value

CAUTION:

Discard any EVAP control system pressure sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



OK or NG

OK (With CONSULT-II)>>GO TO 6.

OK (Without CONSULT-II)>>GO TO 7.

NG >> Replace EVAP control system pressure sensor.

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [KA24DE]

6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 8.
 NG >> GO TO 7.


ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN
THRTL POS SEN	XXX V

SEF801Y

7. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

SEF334X

Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

SEF335X

OK or NG

- OK >> GO TO 8.
 NG >> Replace EVAP canister purge volume control solenoid valve.


DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [KA24DE]

8. CHECK EVAP CANISTER VENT CONTROL VALVE-I

1. Remove EVAP canister vent control valve from EVAP canister.
2. Check portion **B** of EVAP canister vent control valve for being rusted.

OK or NG

- OK >> GO TO 9.
NG >> Replace EVAP canister vent control valve.



9. CHECK EVAP CANISTER VENT CONTROL VALVE-II

With CONSULT-II

1. Reconnect harness connectors disconnected.
2. Turn ignition switch "ON".
3. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
4. Check air passage continuity and operation delay time.

ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 (B1)	XXX V
THRTL POS SEN	XXX V

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.

SEF803Y

Without CONSULT-II


1. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

OK or NG

- OK >> GO TO 11.
NG >> GO TO 10.



10. CHECK EVAP CANISTER VENT CONTROL VALVE-III

1. Clean the air passage (Portion **A** to **B**) of EVAP canister vent control valve using an air blower.
2. Perform Test No. 9 again.

OK or NG

- OK >> GO TO 11.
NG >> Replace EVAP canister vent control valve.

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [KA24DE]

11. CHECK RUBBER TUBE

Check for obstructed water separator and rubber tube connected to EVAP canister vent control valve and clean the rubber tube using air blower. Check water separator.


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

- **Do not disassemble water separator.**

OK or NG

OK >> GO TO 12.

NG >> Clean, repair or replace rubber tube and/or water separator.




12. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

Yes >> GO TO 13.

No >> GO TO 14.



13. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

OK >> GO TO 15.

NG >> GO TO 14.

14. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

15. CHECK INTERMITTENT INCIDENT

Refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

DTC P1446 EVAP CANISTER VENT CONTROL VALVE

PFP:14935

Component Description

UBS008X4

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.


This solenoid (the EVAP canister vent control valve) responds to signals from the ECM.

When the ECM sends an ON signal, the coil in the solenoid valve is energized.

A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS008X5

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

UBS008X6

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1446	EVAP canister vent control valve close	EVAP canister vent control valve remains closed under specified driving conditions.	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● EVAP control system pressure sensor and the circuit ● Blocked rubber tube to EVAP canister vent control valve ● Water separator ● EVAP canister is saturated with water

DTC Confirmation Procedure

UBS008X7

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform at a temperature above 0°C (32°F).

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Check that "FUEL T/TMP SE" is 0°C (32°F) or more.
6. Drive vehicle at a speed of approximately 80 km/h (50 MPH) for a maximum of 15 minutes.
7. If 1st trip DTC is detected, go to [EC-480, "Diagnostic Procedure"](#)

NOTE:

If a malfunction exists, NG result may be displayed quicker.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

SEF189Y



WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Check that voltage between ECM terminal 60 (fuel tank temperature sensor signal) and ground is less than 4.2V.
3. Drive vehicle at a speed of approximately 80 km/h (50 MPH) for 15 minutes.
4. Select "MODE 7" with GST.
5. If 1st trip DTC is detected, go to [EC-480, "Diagnostic Procedure"](#)



UBS008X8

Diagnostic Procedure

1. CHECK RUBBER TUBE FOR CLOGGING

Check obstructed water separator and rubber tube to EVAP canister vent control valve and clean the rubber tube using air blower.

Check water separator.


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

● **Do not disassemble water separator.**

OK or NG

OK >> GO TO 2.

NG >> Clean, repair or replace rubber tube and/or water separator.



PBIB1032E


2. CHECK EVAP CANISTER VENT CONTROL VALVE-I

1. Remove EVAP canister vent control valve from EVAP canister.
2. Check portion **B** of EVAP canister vent control valve for being rusted.

OK or NG

OK >> GO TO 3.

NG >> Replace EVAP canister vent control valve.




BBIA0308E

3. CHECK EVAP CANISTER VENT CONTROL VALVE-II

With CONSULT-II

1. Reconnect harness connectors disconnected.
2. Turn ignition switch "ON".
3. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
4. Check air passage continuity and operation delay time.



ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 (B1)	XXX V
HO2S1 (B2)	XXX V
THRTL POS SEN	XXX V

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.

SEF991Y

Without CONSULT-II


1. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. CHECK EVAP CANISTER VENT CONTROL VALVE-III

1. Clean the air passage (Portion A to B) of EVAP canister vent control valve using an air blower.
2. Perform Test No. 3 again.

OK or NG


- OK >> GO TO 5.
- NG >> Replace EVAP canister vent control valve.

5. CHECK IF EVAP CANISTER IS SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

- Yes >> GO TO 6.
- No >> GO TO 8.



6. CHECK EVAP CANISTER

Weigh the EVAP canister with EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Visually check the EVAP canister for damage.
- Check hose connection between EVAP canister and water separator for clogging and poor connection.

>> Repair hose or replace EVAP canister.

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG

- OK >> GO TO 9.
- NG >> Install hose properly or replace it.

9. CHECK HARNESS CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check harness connector for water.

Water should not exist.

OK or NG

- OK >> GO TO 10.
- NG >> Replace EVAP control system pressure sensor.

10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR AND CIRCUIT

Refer to "DTC Confirmation Procedure", for DTC P0452, [EC-337](#) and DTC P0453, [EC-344](#) .

OK or NG

- OK >> GO TO 11.
- NG >> Replace EVAP control system pressure sensor and repair or replace harness and connector.

11. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

DTC P1448 EVAP CANISTER VENT CONTROL VALVE

PFP:14935

UBS008X9

Component Description

NOTE:

If DTC P1448 is displayed with P0442, perform trouble diagnosis for DTC P1448 first.

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.



This solenoid (the EVAP canister vent control valve) responds to signals from the ECM.

When the ECM sends an ON signal, the coil in the solenoid valve is energized.

A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS008XA

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

UBS008XB

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1448	EVAP canister vent control valve open	EVAP canister vent control valve remains opened under specified driving conditions.	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● EVAP control system pressure sensor and the circuit ● Blocked rubber tube to EVAP canister vent control valve ● Water separator ● EVAP canister is saturated with water ● Vacuum cut valve

DTC Confirmation Procedure

NOTE:


- If DTC P1448 is displayed with P0442, perform trouble diagnosis for DTC P1448 first.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

**WITH CONSULT-II
TESTING CONDITION:**

- Perform “DTC WORK SUPPORT” when the fuel level is less than 3/4 full and vehicle is placed on flat level surface.
 - Always perform test at a temperature of 0 to 30°C (32 to 86°F).
 - It is better that the fuel level is low.
1. Turn ignition switch ON.
 2. Turn ignition switch OFF and wait at least 5 seconds.
 3. Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
 4. Check that the following conditions are met.

COOLAN TEMP/S	0 - 70°C (32 - 158°F)
INT/A TEMP SE	0 - 60°C (32 - 140°F)

5. Select “EVAP SML LEAK P0442/P1442” of “EVAP SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II.
Follow the instruction displayed.




NOTE:

- If “CAN NOT BE DIAGNOSED” is displayed on the CONSULT-II screen, stop the engine and stabilize the vehicle temperature at 25°C (77°F) or cooler. After “FUEL T/TMP SE” becomes less than 30°C (86°F), retest. (Use a fan to reduce the stabilization time.)
 - If the engine speed cannot be maintained within the range displayed on CONSULT-II screen, go to [EC-73, "Basic Inspection"](#).
 - The engine idle portion of this test (See illustration.) will take approximately 5 minutes.
6. Make sure that “OK” is displayed.
If “NG” is displayed, go to following step.

NOTE:

Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

7. Stop engine and wait at least 5 seconds, then turn “ON”.
8. Disconnect hose from water separator.
9. Select “VENT CONTROL/V” of “ACTIVE TEST” mode with CONSULT-II.
10. Touch “ON” and “OFF” alternately.




DTC P1448 EVAP CANISTER VENT CONTROL VALVE

[KA24DE]

11. Make sure of the following.

Condition	Air passage continuity between A and B
Touching "ON"	No
Touching "OFF"	Yes

If the result is NG, go to [EC-485, "Diagnostic Procedure"](#) .
 If the result is OK, go to "Diagnostic Procedure" for DTC P0442, [EC-311](#) .



Overall Function Check


Use this procedure to check the overall function of the EVAP canister vent control valve circuit. During this check, a DTC might not be confirmed.

WITH GST

1. Disconnect hose from water separator.
2. Disconnect EVAP canister vent control valve harness connector.
3. Verify the following.

Condition	Air passage continuity
12V direct current supply between terminals 1 and 2	No
No supply	Yes

If the result is NG, go to [EC-485, "Diagnostic Procedure"](#) .
 If the result is OK, perform trouble diagnosis for DTC P0442. Refer to [EC-311](#) .



Diagnostic Procedure

1. CHECK RUBBER TUBE

1. Turn ignition switch OFF.
2. Check disconnection or obstruction of rubber tube connected to EVAP canister vent control valve.

OK or NG


- OK >> GO TO 2.
 NG >> Repair or clean rubber tube.

2. CHECK EVAP CANISTER VENT CONTROL VALVE-I

1. Remove EVAP canister vent control valve from EVAP canister.
2. Check portion **B** of EVAP canister vent control valve for being rusted.

OK or NG

- OK >> GO TO 3.
 NG >> Replace EVAP canister vent control valve.



3. CHECK EVAP CANISTER VENT CONTROL VALVE-II

With CONSULT-II

1. Reconnect harness connectors disconnected.
2. Turn ignition switch "ON".
3. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
4. Check air passage continuity and operation delay time.

ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 (B1)	XXX V
HO2S1 (B2)	XXX V
THRTL POS SEN	XXX V

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.

SEF991Y

Without CONSULT-II


1. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. CHECK EVAP CANISTER VENT CONTROL VALVE-III

1. Clean the air passage (Portion A to B) of EVAP canister vent control valve using an air blower.
2. Perform Test No. 3 again.

OK or NG

- OK >> GO TO 5.
- NG >> Replace EVAP canister vent control valve.



5. CHECK VACUUM CUT VALVE

Check vacuum cut valve as follows:

1. Plug port **C** and **D** with fingers.
2. Apply vacuum to port **A** and check that there is no suction from port **B**.
3. Apply vacuum to port **B** and check that there is suction from port **A**.
4. Blow air in port **B** and check that there is a resistance to flow out of port **A**.
5. Open port **C** and **D**.
6. Blow air in port **A** check that air flows freely out of port **C**.
7. Blow air in port **B** check that air flows freely out of port **D**.

OK or NG

- OK >> GO TO 6.
- NG >> Replace vacuum cut valve.




6. CHECK IF EVAP CANISTER IS SATURATED WITH WATER

1. Remove EVAP canister with the vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

- Yes >> GO TO 9.
- No >> GO TO 7.



7. CHECK EVAP CANISTER

Weigh the EVAP canister with EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0lb).

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 8.


A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M

8. DETECT MALFUNCTIONING PART

Check the following.

1. Visually check the EVAP canister for damage.
2. Check hose connection between EVAP canister and water separator for clogging and poor connection.
3. Check water separator.
 - Check visually for insect nests in the water separator air inlet.
 - Check visually for cracks or flaws in the appearance.
 - Check visually for cracks or flaws in the hose.
 - Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
 - In case of NG in items 2 - 4, replace the parts.
 - **Do not disassemble water separator.**

>> Repair hose or replace EVAP canister or water separator.



9. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG

- OK >> GO TO 10.
 NG >> Install hose property or replace it.

10. CHECK HARNESS CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check harness connector for water.
Water should not exist.

OK or NG

- OK >> GO TO 11.
 NG >> Replace EVAP control system pressure sensor.

11. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

Perform "DTC Confirmation Procedure", for DTC P0452, [EC-337](#) and DTC P0453, [EC-344](#) .

OK or NG

- OK >> GO TO 12.
 NG >> Replace EVAP control system pressure sensor and repair or replace harness and connector.

12. CHECK INTERMITTENT INCIDENT

Perform [EC-120](#). "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" .

>> INSPECTION END

DTC P1456 EVAP CONTROL SYSTEM

PFP:14710

On Board Diagnosis Logic

UBS008XF


This diagnosis detects very small leaks in the EVAP line between fuel tank and EVAP canister purge volume control solenoid valve, using of vapor pressure in the fuel tank.

The EVAP canister vent control valve is closed to shut the EVAP purge line. The vacuum cut valve bypass valve will then be opened to clear the line between the fuel tank and the EVAP canister purge volume control solenoid valve. The EVAP control system pressure sensor can now monitor the pressure inside the fuel tank. If pressure increases, the ECM will check for leaks in the line between the vacuum cut valve and EVAP canister purge volume control solenoid valve.

If ECM judges a leak which corresponds to a very small leak, the very small leak P1456 will be detected.

If ECM judges a leak equivalent to a small leak, EVAP small leak P1442 will be detected.

If ECM judges there are no leaks, the diagnosis will be OK.



PBIB1402E

DTC P1456 EVAP CONTROL SYSTEM

[KA24DE]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1456	Evaporative emission control system very small leak (positive pressure check)	<ul style="list-style-type: none"> ● EVAP system has a very small leak. ● EVAP system does not operate properly. 	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged ● Water separator ● EVAP canister is saturated with water ● EVAP control system pressure sensor ● Refueling control valve ● ORVR system leaks ● Fuel level sensor and the circuit ● Foreign matter caught in EVAP canister purge volume control solenoid valve

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS008XG

NOTE:


- If DTC P0456 or P1456 is displayed with P0442, first perform trouble diagnosis for DTC P0456 or P1456.
- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.
- After repair, make sure that the hoses and clips are installed properly.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Open engine hood before conducting following procedure.
- If any of following condition is met just before the DTC confirmation procedure, leave the vehicle for more than 1 hour.
 - Fuel filler cap is removed.
 - Refilled or drained the fuel.
 - EVAP component parts is/are removed.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Make sure the following conditions are met.
FUEL LEVEL SE: 1.16 - 0.25V
COOLAN TEMP/S: 0 - 32°C (32 - 90°F)
FUEL T/TMP SE: 0 - 32°C (32 - 90°F)
INT A/TEMP SE: More than 0°C (32°F)
 If NG, turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle) or refilling/draining fuel until the output voltage condition of the "FUEL LEVEL SE" meets within the range above and leave the vehicle for more than 1 hour. Then start from step 1.
3. Turn ignition switch "OFF" and wait at least 5 seconds.
4. Turn ignition switch "ON".
5. Select "EVAP V/S LEAK P0456/P1456" of "EVAP SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
 Follow the instruction displayed.



6. Make sure that "OK" is displayed.
 If "NG" is displayed, refer to [EC-492, "Diagnostic Procedure"](#).

NOTE:

If the engine speed cannot be maintained within the range displayed on CONSULT-II screen, go to [EC-73, "Basic Inspection"](#).

Overall Function Check

UBS008XH

WITH GST

Use this procedure to check the overall function of the EVAP very small leak function. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

- Never use compressed air, doing so may damage the EVAP system.
- Do not start engine.
- Do not exceeded 4.12 kPa (0.042 kg/cm², 0.6 psi).


1. Attach the EVAP service port adapter securely to the EVAP service port.
2. Set the pressure pump and a hose.
3. Also set a vacuum gauge via 3-way connector and a hose.
4. Turn ignition switch "ON".
5. Connect GST and select mode 8.
6. Using mode 8 control the EVAP canister vent control valve (close) and vacuum cut valve bypass valve (open).
7. Apply pressure and make sure the following conditions are satisfied.

Pressure to be applied: 2.7 kPa (20 mmHg, 0.79 inHg)

Time to be waited after the pressure drawn in to the EVAP system and the pressure to be dropped: 60 seconds and the pressure should not be dropped more than 0.4 kPa (3 mmHg, 0.12 inHg)

If NG, go to [EC-492, "Diagnostic Procedure"](#).

If OK, go to next step.



NOTE:

For more information, refer to GST instruction manual.

8. Disconnect GST.
9. Start engine and warm it up to normal operating temperature.
10. Turn ignition switch "OFF" and wait at least 10 seconds.
11. Restart engine and let it idle for 90 seconds.
12. Keep engine speed at 2,000 rpm for 30 seconds.
13. Turn ignition switch "OFF".

Diagnostic Procedure


UBS008XI

1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch "OFF".
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

- OK >> GO TO 2.
NG >> Replace with genuine NISSAN fuel filler cap.



2. CHECK FUEL FILLER CAP INSTALLATION

- Check that the cap is tightened properly by rotating the cap clockwise.

OK or NG

- OK >> GO TO 3.
NG >> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.
● Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION


- Check for air releasing sound while opening the fuel filler cap.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE

1. Wipe clean valve housing.




2. Check valve opening pressure and vacuum.

Pressure : 15.3 - 20.0 kPa
(0.156 - 0.204 kg/cm² , 2.22 - 2.90 psi)

Vacuum : -6.0 to -3.3 kPa
(-0.061 to -0.034 kg/cm² , -0.87 to -0.48 psi)

CAUTION:

Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.




OK or NG

OK >> GO TO 5.

NG >> Replace fuel filler cap with a genuine one.

5. INSTALL THE PRESSURE PUMP

To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely.




NOTE:

Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking.

Models with CONSULT-II>>GO TO 6.

Models without CONSULT-II>>GO TO 7.




6. CHECK FOR EVAP LEAK

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.
3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#)

OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace.



7. CHECK FOR EVAP LEAK

Without CONSULT-II

1. Turn ignition switch "OFF".
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.



NOTE:

- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.

5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace.



8. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 9.
 NG >> Replace water separator.



9. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

- Refer to [EC-484, "DTC Confirmation Procedure"](#) .

OK or NG


- OK >> GO TO 10.
 NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connector.

10. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Does water drain from the EVAP canister?

Yes or No

- Yes >> GO TO 11.
 No (With CONSULT-II)>>GO TO 13.
 No (Without CONSULT-II)>>GO TO 14.



11. CHECK EVAP CANISTER

- Weigh the EVAP canister with the EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK (With CONSULT-II)>>GO TO 13.
 OK (Without CONSULT-II)>>GO TO 14.
 NG >> GO TO 12.

12. DETECT MALFUNCTIONING PART

- Check the following.
 - EVAP canister for damage
 - EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

13. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

With CONSULT-II

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode.
4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 16.
- NG >> GO TO 15.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
HO2S1 MNTR (B1)	LEAN

PBIB0828E

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 15.

15. CHECK VACUUM HOSE

- Check vacuum hoses for clogging or disconnection. Refer to [EC-29, "Vacuum Hose Drawing"](#) .

OK or NG

- OK (With CONSULT-II)>>GO TO 16.
- OK (Without CONSULT-II)>>GO TO 17.
- NG >> Repair or reconnect the hose.

16. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 18.
- NG >> GO TO 17.


ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V


SEF985Y

17. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

 With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.







Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

 Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.





Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

OK or NG

OK >> GO TO 18.

NG >> Replace EVAP canister purge volume control solenoid valve.


18. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance between fuel level sensor unit and fuel pump terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90


OK or NG

- OK >> GO TO 19.
 NG >> Replace fuel level sensor unit.




19. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.



CAUTION:

Never apply force to the air hole protector of the sensor, if equipped.



2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.

CAUTION:


- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg , -27.56 inHg) or over 101.3 kPa (760 mmHg , 29.56 inHg) of pressure.

4. Check output voltage between ECM terminal 62 and engine ground.

Applied vacuum kPa (mmHg, inHg)	Voltage [V]
Not applied	1.8 - 4.8
-26.7 (-200, -7.87)	2.1 to 2.5V lower than above value

CAUTION:

Discard any EVAP control system pressure sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



OK or NG

- OK >> GO TO 20.
- NG >> Replace EVAP control system pressure sensor.

20. CHECK EVAP PURGE LINE

- Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 21.
- NG >> Repair or reconnect the hose.

21. CLEAN EVAP PURGE LINE

- Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 22.

22. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

OK >> GO TO 23.

NG >> Replace fuel level sensor unit.

23. CHECK INTERMITTENT INCIDENT

Refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


DTC P1464 FUEL LEVEL SENSOR

Component Description

UBS008XJ

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



SEF800Z

UBS008XK

On Board Diagnostic Logic

ECM receives two signals from the fuel level sensor.

One is fuel level sensor power supply circuit, and the other is fuel level sensor ground circuit.

This diagnosis indicates the latter to detect open circuit malfunction.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1464	Fuel level sensor circuit ground signal	A high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted)

DTC Confirmation Procedure

UBS008XL

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Wait at least 5 seconds.
- If 1st trip DTC is detected, go to [EC-503, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
FUEL T/TMP SE	XXX °C
FUEL LEVEL SE	XXX V

SEF195Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P1464 FUEL LEVEL SENSOR

[KA24DE]


UBS008XM

Wiring Diagram

EC-FLS3-01



Refer to the following.
F29 - ELECTRICAL UNITS



WBWA0019E

Diagnostic Procedure

1. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and body ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F36, M81
- Harness connectors M67, C1
- Harness for open and short between ECM and body ground

>> Replace open circuit or short to power in harness or connectors.

3. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Replace fuel level sensor unit.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

>> **INSPECTION END.**

Removal and Installation FUEL LEVEL SENSOR UNIT

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1490 VACUUM CUT VALVE BYPASS VALVE

PFP:17372

Description

UBS008XP


COMPONENT DESCRIPTION

The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.


The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.



EVAPORATIVE EMISSION SYSTEM DIAGRAM



PBIB1402E

CONSULT-II Reference Value in Data Monitor Mode

UBS008XQ

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VC/V BYPASS/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

UBS008XR

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1490	Vacuum cut valve bypass valve circuit	An improper voltage signal is sent to ECM through vacuum cut valve bypass valve.	<ul style="list-style-type: none"> ● Harness or connectors (The vacuum cut valve bypass valve circuit is open or shorted) ● Vacuum cut valve bypass valve

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

 **WITH CONSULT-II**

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-507, "Diagnostic Procedure"](#)

 **WITH GST**

Follow the procedure "WITH CONSULT-II".

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M


DTC P1490 VACUUM CUT VALVE BYPASS VALVE

[KA24DE]


UBS008XT

Wiring Diagram


EC-BYPS/V-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- EP : 12
- LP : 15



Refer to the following.
 E43 - SUPER MULTIPLE JUNCTION (SMJ)



WBWA0020E

DTC P1490 VACUUM CUT VALVE BYPASS VALVE

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
120	P/B	Vacuum cut valve bypass valve	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS008XU

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK VACUUM CUT VALVE BYPASS VALVE CIRCUIT

1. Turn ignition switch ON.
2. Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.
3. Make sure that clicking sound is heard from the vacuum cut valve bypass valve.

OK or NG


- OK >> GO TO 7.
- NG >> GO TO 3.

ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	RICH
THRTL POS SEN	XXX V

SEF806Y

3. CHECK POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect vacuum cut valve bypass valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M67, B101
- Harness connectors B112, C2
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between vacuum cut valve bypass valve and fuse

>> Repair harness or connectors.

5. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 120 and vacuum cut valve bypass valve terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Harness connectors M67, B101
- Harness connectors B112, C2
- Harness for open or short between vacuum cut valve bypass valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK VACUUM CUT VALVE BYPASS VALVE

With CONSULT-II

Check air passage continuity.
Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.

ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	RICH
THRTL POS SEN	XXX V

Condition VC/V BYPASS/V	Air passage continuity between A and B
ON	Yes
OFF	No

Operation takes less than 1 second.

SEF807Y

Without CONSULT-II

Check air passage continuity shown in the figure.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

Operation takes less than 1 second.

SEF557Y

OK or NG

- OK >> GO TO 8.
- NG >> Replace vacuum cut valve bypass valve.

8. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

PF17372

Description

UBS008XV


COMPONENT DESCRIPTION

The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.


The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.



EVAPORATIVE EMISSION SYSTEM DIAGRAM



CONSULT-II Reference Value in Data Monitor Mode

UBS008XV

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VC/V BYPASS/V	● Ignition switch: ON	OFF

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

[KA24DE]

On Board Diagnosis Logic

UBS008XX

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1491	Vacuum cut valve bypass valve	Vacuum cut valve bypass valve does not operate properly.	<ul style="list-style-type: none"> ● Vacuum cut valve bypass valve ● Vacuum cut valve ● Bypass hoses for clogging ● EVAP control system pressure sensor and circuit ● EVAP canister vent control valve ● Hose between fuel tank and vacuum cut valve clogged ● Hose between vacuum cut valve and EVAP canister clogged ● EVAP canister ● EVAP purge port of fuel tank for clogging ● Refueling control valve ● Refueling EVAP vapor cut valve

DTC Confirmation Procedure

UBS008XY

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


- Always perform test at a temperature of 5 to 30°C (41 to 86°F).
- This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF and wait at least 5 seconds.
4. Start engine and let it idle for at least 60 seconds.
5. Select "VC CUT/V BP/V P1491" of "EVAP SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
6. Touch "START".
7. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 30 seconds.)

ENG SPEED	More than 1,000 rpm
Selector lever	Suitable position
Vehicle speed	36 - 120 km/h (22 - 75 MPH)
B/FUEL SCHDL	Less than 10 msec

If "TESTING" is not displayed after 5 minutes, retry from step 3.



8. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-514, "Diagnostic Procedure"](#)


Overall Function Check

UBS008XZ

Use this procedure to check the overall function of vacuum cut valve bypass valve. During this check, the 1st trip DTC might not be confirmed.

WITH GST

1. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
2. Apply vacuum to port **A** and check that there is no suction from port **B**.
3. Apply vacuum to port **B** and check that there is suction from port **A**.
4. Blow air in port **B** and check that there is a resistance to flow out of port **A**.
5. Supply battery voltage to the terminal.
6. Blow air in port **A** and check that air flows freely out of port **B**.
7. Blow air in port **B** and check that air flows freely out of port **A**.
8. If NG, go to [EC-514, "Diagnostic Procedure"](#).




DTC P1491 VACUUM CUT VALVE BYPASS VALVE

[KA24DE]


UBS008Y0

Wiring Diagram

EC-BYPS/V-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 12
- LP : 15



WBWA0020E

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
120	P/B	Vacuum cut valve bypass valve	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS008Y1

1. INSPECTION START

Do you have CONSULT-II?


Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK COMPONENT

 **With CONSULT-II**

1. Turn ignition switch OFF.
2. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
3. Apply vacuum to port A and check that there is no suction from port B.
4. Apply vacuum to port B and check that there is suction from port A.
5. Blow air in port B and check that there is a resistance to flow out of port A.
6. Turn ignition switch ON.
7. Select "VC/V BYPASS/V" in "ACTIVE TEST" mode with CONSULT-II and touch "ON".
8. Blow air in port A and check that air flows freely out of port B.
9. Blow air in port B and check that air flows freely out of port A.



ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	RICH
THRTL POS SEN	XXX V

SEF808Y


OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.

3. CHECK COMPONENT

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
3. Apply vacuum to port A and check that there is no suction from port B.
4. Apply vacuum to port B and check that there is suction from port A.
5. Blow air in port B and check that there is a resistance to flow out of port A.
6. Disconnect vacuum cut valve bypass valve harness connector.
7. Supply battery voltage to the terminal.
8. Blow air in port A and check that air flows freely out of port B.
9. Blow air in port B and check that air flows freely out of port A.



OK or NG

- OK >> GO TO 4.
 NG >> GO TO 5.

4. CHECK EVAP PURGE LINE

1. Check EVAP purge line between EVAP canister and fuel tank for clogging or disconnection.
2. Check EVAP purge port of fuel tank for clogging.
3. Check EVAP canister. Refer to [EC-559, "Component Inspection"](#).

OK or NG

- OK >> GO TO 8.
 NG (Step 1)>>Repair it.
 NG (Step 2)>>Clean EVAP purge port.
 NG (Step 3)>>Replace EVAP canister.

5. CHECK BYPASS HOSE

Check bypass hoses for clogging.

OK or NG


- OK >> GO TO 6.
 NG >> Repair or replace hoses.

6. CHECK VACUUM CUT VALVE BYPASS VALVE

With CONSULT-II

Check air passage continuity.

Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.



CONNECT

ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	RICH
THRTL POS SEN	XXX V


Condition VC/V BYPASS/V	Air passage continuity between A and B
ON	Yes
OFF	No

Operation takes less than 1 second.

SEF807Y

Without CONSULT-II

Check air passage continuity shown in the figure.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

Operation takes less than 1 second.

SEF557Y

OK or NG

OK >> GO TO 7.

NG >> Replace vacuum cut valve bypass valve.

7. CHECK VACUUM CUT VALVE



Check vacuum cut valve as follows:

1. Plug port **C** and **D** with fingers.
2. Apply vacuum to port **A** and check that there is no suction from port **B**.
3. Apply vacuum to port **B** and check that there is suction from port **A**.
4. Blow air in port **B** and check that there is a resistance to flow out of port **A**.
5. Open port **C** and **D**.
6. Blow air in port **A** check that air flows freely out of port **C**.
7. Blow air in port **B** check that air flows freely out of port **D**.

OK or NG

OK >> GO TO 8.

NG >> Replace vacuum cut valve.



8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

1. Turn ignition switch OFF.
2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG


- OK >> GO TO 9.
- NG >> Repair it

9. CHECK CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.
Water should not exist.

OK or NG

- OK >> GO TO 10.
- NG >> Replace EVAP control system pressure sensor.



10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

Perform "DTC Confirmation Procedure", for DTC P0452, [EC-337](#) and DTC P0453, [EC-344](#).

OK or NG


- OK >> GO TO 11.
- NG >> Replace EVAP control system pressure sensor.

11. CHECK EVAP CANISTER VENT CONTROL VALVE-I

1. Remove EVAP canister vent control valve from EVAP canister.
2. Check portion **B** of EVAP canister vent control valve for being rusted.

OK or NG


- OK >> GO TO 12.
- NG >> Replace EVAP canister vent control valve.



12. CHECK EVAP CANISTER VENT CONTROL VALVE-II

With CONSULT-II

1. Turn ignition switch ON.
2. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
3. Check air passage continuity and operation delay time.



ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 (B1)	XXX V
THRTL POS SEN	XXX V

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.

SEF803Y

Without CONSULT-II


1. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

OK or NG

- OK >> GO TO 14.
- NG >> GO TO 13.



13. CHECK EVAP CANISTER VENT CONTROL VALVE-III

1. Clean the air passage (Portion A to B) of EVAP canister vent control valve using an air blower.
2. Perform Test No. 12 again.

OK or NG

- OK >> GO TO 14.
- NG >> Replace EVAP canister vent control valve.

14. CHECK REFUELING CONTROL VALVE

Refer to [EC-562. "ON BOARD REFUELING VAPOR RECOVERY \(ORVR\)"](#).

OK or NG

- OK >> GO TO 15.
- NG >> Repair or replace hoses.

15. CHECK REFUELING EVAP VAPOR CUT VALVE

Refer to [EC-562. "ON BOARD REFUELING VAPOR RECOVERY \(ORVR\)"](#).

OK or NG

- OK >> GO TO 16.
- NG >> Repair or replace hoses.

16. CHECK INTERMITTENT INCIDENT

Refer to [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1706 PNP SWITCH

[KA24DE]

DTC P1706 PNP SWITCH


PF3:32006

Component Description

UBS008Y2

When the gear position is "N" or "P", park/neutral position (PNP) switch is "ON".

ECM detects the park/neutral position when continuity with ground exists.



CONSULT-II Reference Value in Data Monitor Mode

UBS008Y3

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: Neutral	ON
		Except above	OFF

On Board Diagnosis Logic

UBS008Y4

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1706	Park/neutral position switch	The signal of the park/neutral position (PNP) switch is not changed in the process of engine starting and driving.	<ul style="list-style-type: none">● Harness or connectors [The park/neutral position (PNP) switch circuit is open or shorted.]● Park/neutral position (PNP) switch

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

With CONSULT-II

1. Turn ignition switch ON.
2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II. Then check the "P/N POSI SW" signal under the following conditions.

Position (Selector lever)	Known-good signal
Neutral	ON
Except the above position	OFF

If NG, go to [EC-523, "Diagnostic Procedure For M/T Models"](#) .

If OK, go to following step.

3. Select "DATA MONITOR" mode with CONSULT-II.
4. Start engine and warm it up to normal operating temperature.
5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	1,400 - 4,000 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	3.5 - 17 msec
VHCL SPEED SE	More than 64 km/h (More than 40 MPH)
Selector lever	Suitable position

6. If 1st trip DTC is detected, go to [EC-523, "Diagnostic Procedure For M/T Models"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF
B/FUEL SCHDL	XXX msec

SEF213Y

Overall Function Check


Use this procedure to check the overall function of the park/neutral position switch circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Turn ignition switch ON.
2. Check voltage between ECM terminal 22 (PNP switch signal) and body ground under the following conditions.

Condition (Gear position)	Voltage (V) (Known-good data)
"N" or "P" position	Approx. 0
Except the above position	Approx. 5

3. If NG, go to [EC-523, "Diagnostic Procedure For M/T Models"](#) .





DTC P1706 PNP SWITCH

[KA24DE]


UBS008Y7

Wiring Diagram

EC-PNP/SW-01



Refer to the following.
E43 - SUPER MULTIPLE JUNCTION (SMJ)



WBWA0021E

DTC P1706 PNP SWITCH

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
22	L/B	PNP switch	[Ignition switch "ON"] ● Gear position is Neutral	Approximately 0V
			[Ignition switch "ON"] ● Except the above gear position	Approximately 5V

Diagnostic Procedure For M/T Models

UBS008Y8

1. CHECK GROUND CIRCUIT


- Turn ignition switch OFF.
- Disconnect park neutral position (PNP) switch harness connector.
- Check harness continuity between PNP switch terminal 2 and body ground.
Refer to Wiring Diagram.

Continuity should exist.

- Also check harness for short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E33, E201
- Harness for open or short between PNP switch and body ground

>> Repair open circuit or short to power in harness or connectors.

3. CHECK INPUT SIGNAL CIRCUIT

- Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 22 and PNP switch terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

- Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F36, M81
- Harness connectors M65, E43
- Harness connectors E33, E201
- Harness for open or short between ECM and PNP switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK PNP SWITCH

Refer to [MT-9, "Position Switch Check"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace PNP switch.

6. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

IGNITION SIGNAL

Component Description


IGNITION COIL & POWER TRANSISTOR


The ignition signal from the ECM is sent to the power transistor. The power transistor switches the ignition coil primary circuit on and off. As the primary circuit is turned on and off, the proper high voltage is induced in the coil secondary circuit.

The distributor is not repairable and must be replaced as an assembly except distributor cap and rotor head.

NOTE:

The rotor screw which secures the distributor rotor head to the distributor shaft must be tightened properly.

 : 3.3 - 3.9 N·m (0.34 - 0.40 kg·m, 29.5 - 34.7 in·lb)



CONSULT-II Reference Value in Data Monitor Mode

MONITOR ITEM	CONDITION		SPECIFICATION
IGN TIMING	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	Approx. 20° BTDC
		2,000 rpm	More than 25° BTDC


IGNITION SIGNAL

[KA24DE]

UBS008YP

Wiring Diagram





EC-IGN/SG-01



: Detectable line for DTC
 : Non-detectable line for DTC

Refer to PG-POWER .

Refer to the following.
 (E43) - SUPER MULTIPLE JUNCTION (SMJ)



BBWA0458E

IGNITION SIGNAL

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	PU/W	Ignition signal	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>0 - 0.5V★</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>0.2 - 1.0V★</p>
2	B	Ignition check	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>12 - 14V★</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>12 - 13V★</p>

Diagnostic Procedure

1. INSPECTION START

Turn ignition switch "OFF", and restart engine.

Is engine running?

Yes or No

- Yes (With CONSULT-II)>>GO TO 2.
- Yes (Without CONSULT-II)>>GO TO 3.
- No >> GO TO 4.

2. CHECK OVERALL FUNCTION

④ With CONSULT-II

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
2. Make sure that all circuits do not produce a momentary engine speed drop.

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 7.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
IACV-AAC/V	XXX %

SEF981Z

3. CHECK OVERALL FUNCTION

⊗ Without CONSULT-II

1. Let engine idle.
2. Read the voltage signal between ECM terminal 1 and ground with an oscilloscope.
3. Verify that the oscilloscope screen shows the signal wave as shown below.




OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 7.

4. CHECK POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect distributor harness connector F17.
3. Turn ignition switch "ON".




4. Check voltage between ignition coil terminal 7 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M59, F27
- Harness for open or short between ignition coil and ignition switch

>> Repair harness or connectors.

6. CHECK GROUND CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect distributor harness connector F13.
3. Check harness continuity between power transistor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to power in harness or connectors.

7. CHECK OUTPUT SIGNAL CIRCUIT


1. Stop engine.
2. Disconnect distributor harness connector F13.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 1 and power transistor terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.




8. CHECK IGNITION COIL

1. Remove distributor cap.
2. Check resistance as shown in the figure.

Terminal	Resistance [at 25°C (77°F)]
7 - 8	Less than 1Ω
7 - 9	7 - 13Ω

OK or NG

- OK >> GO TO 9.
 NG >> Replace distributor assembly as a unit.




9. CHECK POWER TRANSISTOR

1. Disconnect distributor harness connector F17.
2. Check power transistor resistance between terminals 2 and 8.

Terminals	Resistance	Result
2 and 8	Except 0Ω	OK
	0Ω	NG

OK or NG

- OK >> GO TO 10.
 NG >> Replace distributor assembly.



10. CHECK INPUT SIGNAL CIRCUIT

1. Strip tape covering resistor.
2. Disconnect resistor harness connector.
3. Check harness continuity between ignition coil terminal 8 and resistor terminal 1, resistor terminal 2 and ECM terminal 2.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 11.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



11. CHECK RESISTOR


Check resistance between resistor terminals 1 and 2.

Resistance : Approximately 2.2 kΩ [at 25°C (77°F)]

OK or NG

OK >> GO TO 12.

NG >> Replace resistor.



12. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Removal and Installation DISTRIBUTOR


Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .

UBS008YR

INJECTOR CIRCUIT

Component Description

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the ball valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
INJ PULSE-B1	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: Neutral ● No-load Idle	2.5 - 3.3 msec
	2,000 rpm	2.4 - 3.2 msec
B/FUEL SCHDL	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: Neutral ● No-load Idle	0.8 - 1.2 msec
	2,000 rpm	0.8 - 1.2 msec


INJECTOR CIRCUIT

[KA24DE]



UBS008YU

Wiring Diagram

EC-INJECT-01



— : Detectable line for DTC
 - - - : Non-detectable line for DTC



BBWA0459E

INJECTOR CIRCUIT

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
102 104 109 111	W/B W/R W/L W/PU	Injector No. 1 Injector No. 3 Injector No. 2 Injector No. 4	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p> <p>SEF011W</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>BATTERY VOLTAGE (11 - 14V)★</p> <p>SEF012W</p>

Diagnostic Procedure

1. CHECK OVERALL FUNCTION

UBS008YV

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
IACV-AAC/V	XXX %


SEF981Z

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.
Clicking noise should be heard.

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.




2. CHECK POWER SUPPLY

1. Stop engine.
2. Disconnect injector harness connector.
3. Turn ignition switch ON.
4. Check voltage between injector terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F27, M59
- Fuse block (J/B) connector M26
- 10A fuse
- Harness for open or short between injector and fuse

>> Repair harness or connectors.

4. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between injector terminal 2 and ECM terminals 102, 104, 109, 111. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the harness for open or short between ECM and injector.

>> Repair open circuit or short to ground or short to power in harness or connectors.


6. CHECK INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance : 7.3 - 9.9Ω [at 25°C (77°F)]

OK or NG

- OK >> GO TO 7.
NG >> Replace injector.



7. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation INJECTOR

Refer to [EM-13, "OUTER COMPONENT PARTS"](#) .

UBS008YW

START SIGNAL

[KA24DE]

PFP:48750

START SIGNAL

CONSULT-II Reference Value in Data Monitor Mode

UBS008YX

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
START SIGNAL	● Ignition switch: ON → START → ON	OFF → ON → OFF

A

EC

C

D

E

F

G

H

I

J

K

L

M




START SIGNAL

[KA24DE]

UBS008YY

Wiring Diagram

EC-S/SIG-01



WBWA0022E

START SIGNAL

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
20	L/OR	Start signal	[Ignition switch "ON"]	Approximately 0V
			[Ignition switch "START"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS008YZ

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

With CONSULT-II

- Turn ignition switch ON.
- Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.

DATA MONITOR	
MONITOR	NO DTC
START SIGNAL	OFF

Condition	"START SIGNAL"
Ignition switch "ON"	OFF
Ignition switch "START"	ON

SEF227Y

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 4.

3. CHECK OVERALL FUNCTION


Without CONSULT-II

- Turn ignition switch to START.
- Check voltage between ECM terminal 20 and ground under the following conditions.

Condition	Voltage
Ignition switch START	Battery voltage
Except above	Approx. 0V

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the 7.5A fuse.

OK or NG

- OK >> GO TO 5.
 NG >> Replace 7.5A fuse.

5. CHECK INPUT SIGNAL CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and 7.5A fuse.
3. Check harness continuity between ECM terminal 20 and fuse block.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 6.



6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Fuse block (J/B) connector M26
- Harness for open or short between ECM and fuse block

OK or NG

- OK >> GO TO 7.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

FUEL PUMP CIRCUIT

[KA24DE]

FUEL PUMP CIRCUIT

PF:17042

Description SYSTEM DESCRIPTION

UBS008Z0


Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Fuel pump control	Fuel pump relay
Ignition switch	Start signal		

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a 180° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to perform. If the 180° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds.
Engine running and cranking	Operates.
Except as shown above	Stops.

COMPONENT DESCRIPTION

The fuel pump with a fuel damper is an in-tank type (the pump and damper are located in the fuel tank).



CONSULT-II Reference Value in Data Monitor Mode

UBS008Z1

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> ● Ignition switch is turned to ON (Operates for 5 seconds) ● Engine running and cranking 	ON
	<ul style="list-style-type: none"> ● Except as shown above 	OFF



FUEL PUMP CIRCUIT

[KA24DE]

UBS008Z2

Wiring Diagram

EC-F/PUMP-01



WBWA0023E

FUEL PUMP CIRCUIT

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
11	W/R	Fuel pump relay	[Ignition switch "ON"] ● For 5 seconds after turning ignition switch "ON"	0 - 1V
			[Engine is running] [Ignition switch "ON"] ● More than 5 seconds after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


UBS008Z3

1. CHECK OVERALL FUNCTION

- Turn ignition switch ON.
- Pinch fuel feed hose with two fingers.
Fuel pressure pulsation should be felt on the fuel feed hose for 5 seconds after ignition switch is turned "ON".


OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.



2. CHECK POWER SUPPLY

- Turn ignition switch "OFF".
- Disconnect fuel pump relay.
- Turn ignition switch "ON".




- Check voltage between terminals 2, 5 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector M31
- 15A fuse
- Harness for open or short between fuse and fuel pump relay

>> Repair harness or connectors.

4. CHECK POWER GROUND CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Check harness continuity between fuel pump terminal 2 and body ground, fuel pump terminal 1 and fuel pump relay terminal 3.


Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B101, M67
- Harness for open or short between fuel pump and body ground
- Harness for open or short between fuel pump and fuel pump relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK OUTPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 11 and fuel pump relay terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F36, M81
- Harness for open or short between ECM and fuel pump relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK FUEL PUMP RELAY

With CONSULT-II

1. Reconnect fuel pump relay, fuel level sensor unit and fuel pump harness connector and ECM harness connector.
2. Turn ignition switch ON.
3. Turn fuel pump relay "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.


ACTIVE TEST	
FUEL PUMP RELAY	ON
MONITOR	
ENG SPEED	XXX rpm

SEF724Z

Without CONSULT-II

Check continuity between terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No



OK or NG

- OK >> GO TO 9.
- NG >> Replace fuel pump relay.


9. CHECK FUEL PUMP

1. Disconnect fuel level sensor and fuel pump harness connector.
2. Check resistance between terminals 1 and 2.

Resistance : 0.2 - 5.0Ω [at 25°C (77°F)]

OK or NG

- OK >> GO TO 10.
- NG >> Replace fuel pump.



10. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Removal and Installation FUEL PUMP

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

POWER STEERING OIL PRESSURE SWITCH

[KA24DE]


POWER STEERING OIL PRESSURE SWITCH

PF:49761

Component Description

UBS008Z5

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the IACV-AAC valve to increase the idle speed and adjust for the increased load.



CONSULT-II Reference Value in Data Monitor Mode

UBS008Z6

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel in neutral position (forward direction)	OFF
		The steering wheel is fully turned	ON



POWER STEERING OIL PRESSURE SWITCH

[KA24DE]

Wiring Diagram

UBS008Z7

EC-PST/SW-01



AEC012B

POWER STEERING OIL PRESSURE SWITCH

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
39	GY/R	Power steering oil pressure switch	[Engine is running] ● Steering wheel is fully turned	Approximately 0V
			[Engine is running] ● Steering wheel is not turned	Approximately 5V

Diagnostic Procedure

UBS008Z8

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

 **With CONSULT-II**

- Start engine.
- Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.

DATA MONITOR	
MONITOR	NO DTC
PW/ST SIGNAL	OFF

Conditions	PW/ST SIGNAL indication
Steering is in neutral position	OFF
Steering is turned	ON

LEC065A

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 4.

3. CHECK OVERALL FUNCTION


 **Without CONSULT-II**

- Start engine.
- Check voltage between ECM terminal 39 and ground under the following conditions.

Condition	Voltage [V]
When steering wheel is turned quickly	Approx. 0
Except above	Approx. 5

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 4.



4. CHECK INPUT SIGNAL CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 39 and terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.


5. CHECK POWER STEERING OIL PRESSURE SWITCH

1. Disconnect power steering oil pressure switch harness connector then start engine.
2. Check continuity between terminals 1 and ground.

Conditions	Continuity
Steering wheel is being turned	Yes
Steering wheel is not being turned	No

OK or NG

- OK >> GO TO 6.
- NG >> Replace power steering oil pressure switch.



6. CHECK INTERMITTENT INCIDENT


Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

IACV-FICD SOLENOID VALVE

Component Description

When the air conditioner is on, the IACV-FICD solenoid valve supplies additional air to adjust to the increased load.





IACV-FICD SOLENOID VALVE

[KA24DE]

UBS008ZA

Wiring Diagram

EC-FICD-01



* : This connector is not shown in HARNESS LAYOUT of PG section.

WBWA0024E

IACV-FICD SOLENOID VALVE

[KA24DE]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
12	P	Air conditioner relay	[Engine is running] ● Both A/C switch and blower switch are ON★	Approximately 0V
			[Engine is running] ● A/C switch is OFF	BATTERY VOLTAGE (11 - 14V)

★ : Ambient air temperature above 10°C (50°F) and in any mode except OFF.

Diagnostic Procedure

UBS008ZB


1. CHECK OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.
800±50 rpm
If NG, adjust idle speed.
3. Push air conditioner switch ON and turn fan switch to 4-speed.
4. Recheck idle speed.

875 rpm or more

OK or NG

- OK >> **INSPECTION END.**
 NG >> GO TO 2.



MEF634E

2. CHECK AIR CONDITIONER FUNCTION


Check if air conditioner compressor functions normally.

OK or NG

- OK >> GO TO 3.
 NG >> Refer to [MTC-25, "TROUBLE DIAGNOSIS"](#) .

3. CHECK POWER SUPPLY

1. Stop engine.
2. Disconnect IACV-FICD solenoid valve harness connector.
3. Start engine, then push A/C switch ON and turn fan switch to 4-speed.




4. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between IACV-FICD solenoid valve and harness connector F27
 >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check harness continuity between solenoid valve terminal 1 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART


Check the harness for open or short between IACV-FICD solenoid valve and body ground.

- >> Repair open circuit or short to power in harness or connectors.

7. CHECK IACV-FICD SOLENOID VALVE

Disconnect IACV-FICD solenoid valve harness connector.

- Check for clicking sound when applying 12V direct current to terminals.
- Check plunger for seizing or sticking.




SEF231V

- Check for broken spring.

OK or NG

OK >> GO TO 8.

NG >> Replace IACV-FICD solenoid valve.



SEF097K

8. CHECK INTERMITTENT INCIDENT

Perform [EC-120, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DATA LINK CONNECTOR


[KA24DE]

PF:24814

UBS008ZD

DATA LINK CONNECTOR

Wiring Diagram



EC-MIL/DL-01

— : Detectable line for DTC
 — : Non-detectable line for DTC

EP : EARLY PRODUCTION


LP : LATE PRODUCTION

*1 EP : 3
 LP : 6



*2 EP : 17
 LP : 20

*3 EP : 14
 LP : 17

A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M



Refer to the following.
 F29 - ELECTRICAL UNITS




EVAPORATIVE EMISSION SYSTEM

PFP:14950

Description SYSTEM DESCRIPTION

UBS008ZE



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister.

The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank.

The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating.

EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases.

EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.


EVAPORATIVE EMISSION SYSTEM

[KA24DE]

EVAPORATIVE EMISSION LINE DRAWING

NOTE:

Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.




A
EC
C
D
E
F
G
H
I
J
K
L
M

SEF712Z

EVAPORATIVE EMISSION SYSTEM

[KA24DE]




WEC555

Component Inspection
EVAP CANISTER

Check EVAP canister as follows:


1. Pinch the fresh air hose.
2. Blow air into port **A** and check that air flows freely through port **B**.



Tightening Torque


Tighten EVAP canister as shown in the figure.

Make sure new O-ring is installed properly between EVAP canister and EVAP canister vent control valve.



FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP)

1. Wipe clean valve housing.



2. Check valve opening pressure and vacuum.


Pressure : 16.0 - 20.0 kPa
(0.163 - 0.204 kg/cm², 2.32 - 2.90 psi)

Vacuum : -6.0 to -3.5 kPa
(-0.061 to -0.036 kg/cm², -0.87 to -0.51 psi)

3. If out of specification, replace fuel filler cap as an assembly.

CAUTION:

Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.



VACUUM CUT VALVE AND VACUUM CUT VALVE BYPASS VALVE

Refer to [EC-510](#).

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE


Refer to [EC-469](#).

FUEL TANK TEMPERATURE SENSOR

Refer to [EC-243](#) .

EVAP SERVICE PORT

Positive pressure is delivered to the EVAP system through the EVAP service port. If fuel vapor leakage in the EVAP system occurs, use a leak detector to locate the leak.



UBS008ZG

How To Detect Fuel Vapor Leakage

CAUTION:


- Never use compressed air or a high pressure pump.
- Do not start engine.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in EVAP system.

NOTE:

Improper installation of adapter to the service port may cause a leak.


WITH CONSULT-II

1. Attach the EVAP service port adapter securely to the EVAP service port.
2. Also attach the pressure pump and hose.
3. Turn ignition switch "ON".
4. Select the "EVAP SYSTEM CLOSE" of "WORK SUPPORT MODE" with CONSULT-II.
5. Touch "START". A bar graph (Pressure indicating display) will appear on the screen.



PEF658U

6. Apply positive pressure to the EVAP system until the pressure indicator reaches the middle of the bar graph.
7. Remove the EVAP service port adapter and hose with pressure pump.




PEF917U

EVAPORATIVE EMISSION SYSTEM


[KA24DE]

8. Locate the leak using a leak detector. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#).



⊗ WITHOUT CONSULT-II

1. Attach the EVAP service port adapter securely to the EVAP service port and pressure pump with pressure gauge to the EVAP service port.
2. Apply battery voltage to between the terminals of both EVAP canister vent control valve and vacuum cut valve bypass valve to make a closed EVAP system.
3. To locate the leak, deliver positive pressure to the EVAP system until pressure gauge points reach 1.38 to 2.76 kPa (0.014 to 0.028 kg/cm², 0.2 to 0.4 psi).
4. Remove the EVAP service port adapter and hose with pressure pump.
5. Locate the leak using a leak detector. Refer to [EC-557, "EVAPORATIVE EMISSION LINE DRAWING"](#).




ON BOARD REFUELING VAPOR RECOVERY (ORVR)

PFP:00032

System Description

UBS008ZH



From the beginning of refueling, the fuel tank pressure goes up. When the pressure reaches the setting value of the refueling control valve (RCV) opening pressure, the RCV is opened. After RCV opens, the air and vapor inside the fuel tank go through refueling EVAP vapor cut valve, RCV and refueling vapor line to the EVAP canister. The vapor is absorbed by the EVAP canister and the air is released to the atmosphere.

When the refueling has reached the full level of the fuel tank, the refueling EVAP vapor cut valve is closed and refueling is stopped because of auto shut-off. The vapor which was absorbed by the EVAP canister is purged during driving.

The RCV is always closed during driving and the evaporative emission control system is operated the same as conventional system.

WARNING:

When conducting inspections below, be sure to observe the following:

- Put a “CAUTION: INFLAMMABLE” sign in workshop.
- Do not smoke while servicing fuel system. Keep open flames and sparks away from work area.
- Be sure to furnish the workshop with a CO₂ fire extinguisher.

CAUTION:

- Before removing fuel line parts, carry out the following procedures:
 - Put drained fuel in an explosion-proof container and put lid on securely.
 - Release fuel pressure from fuel line. Refer to [EC-45. "FUEL PRESSURE RELEASE"](#) .
 - Disconnect battery ground cable.
- Always replace O-ring when the fuel gauge retainer is removed.
- Do not kink or twist hose and tube when they are installed.
- Do not tighten hose and clamps excessively to avoid damaging hoses.
- After installation, run engine and check for fuel leaks at connection.
- Do not attempt to top off the fuel tank after the fuel pump nozzle shuts off automatically. Continued refueling may cause fuel overflow, resulting in fuel spray and possibly a fire.

Diagnostic Procedure

SYMPTOM: FUEL ODOR FROM EVAP CANISTER IS STRONG.

1. CHECK EVAP CANISTER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Weigh the EVAP canister with EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG


- OK >> GO TO 2.
- NG >> GO TO 3.

2. CHECK IF EVAP CANISTER SATURATED WITH WATER

- Does water drain from the EVAP canister?

Yes or No

- Yes >> GO TO 3.
- No (With CONSULT-II)>>GO TO 6.
- No (Without CONSULT-II)>>GO TO 7.



3. REPLACE EVAP CANISTER

Replace EVAP canister with a new one.

>> GO TO 4.

4. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 5.
- NG >> Replace water separator.



5. DETECT MALFUNCTIONING PART


Check the EVAP hose between EVAP canister and water separator for clogging or poor connection.

>> Repair or replace EVAP hose.

6. CHECK REFUELING EVAP VAPOR CUT VALVE

With CONSULT-II

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel feed hose located on the fuel gauge retainer.
 - Connect a spare fuel hose, one side to fuel gauge retainer where the hose was removed and the other side to a fuel container.
 - Drain fuel using "FUEL PUMP RELAY" in "ACTIVE TEST" mode with CONSULT-II.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.
Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel gauge retainer with fuel gauge unit.
 - Always replace O-ring with new one.**
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel gauge retainer remaining open and check that the pressure is applicable.




OK or NG

- OK >> GO TO 8.
- NG >> Replace refueling EVAP vapor cut valve with fuel tank.

7. CHECK REFUELING EVAP VAPOR CUT VALVE

⊗ **Without CONSULT-II**

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel gauge retainer.
 - Drain fuel from the tank using a hand pump into a fuel container.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.
Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel gauge retainer with fuel gauge unit.
 - Always replace O-ring with new one.**
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel gauge retainer remaining open and check that the pressure is applicable.




OK or NG

- OK >> GO TO 8.
- NG >> Replace refueling EVAP vapor cut valve with fuel tank.

8. CHECK REFUELING CONTROL VALVE

1. Remove fuel filler cap.
2. Check air continuity between hose ends A and B.
Blow air into the hose end B. Air should flow freely into the fuel tank.
3. Blow air into hose end A and check there is no leakage.
4. Apply pressure to both hose ends A and B [20 kPa (150 mmHg, 5.91 inHg)] using a pressure pump and a suitable 3-way connector. Check that there is no leakage.



OK or NG

OK >> **INSPECTION END**

NG >> Replace refueling control valve with fuel tank.

SYMPTOM: CANNOT REFUEL/FUEL ODOR FROM THE FUEL FILLER OPENING IS STRONG WHILE REFUELING.

1. CHECK EVAP CANISTER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Weigh the EVAP canister with EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG

OK >> GO TO 2.

NG >> GO TO 3.


2. CHECK IF EVAP CANISTER SATURATED WITH WATER

- Does water drain from the EVAP canister?

Yes or No

Yes >> GO TO 3.

No >> GO TO 6.



3. REPLACE EVAP CANISTER

Replace EVAP canister with a new one.

>> GO TO 4.

4. CHECK WATER SEPARATOR

1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.


NOTE:

- Do not disassemble water separator.

OK or NG

OK >> GO TO 5.

NG >> Replace water separator.



5. DETECT MALFUNCTIONING PART

Check the EVAP hose between EVAP canister and water separator for clogging or poor connection.

>> Repair or replace EVAP hose.

6. CHECK VENT HOSES AND VENT TUBES

Check hoses and tubes between EVAP canister and refueling control valve for clogging, kink, looseness and improper connection.

OK or NG

OK >> GO TO 7.

NG >> Repair or replace hoses and tubes.

7. CHECK FILLER NECK TUBE

Check signal line and recirculation line for clogging, dents and cracks.


OK or NG

OK >> GO TO 8.

NG >> Replace filler neck tube.

8. CHECK REFUELING CONTROL VALVE

1. Remove fuel filler cap.
2. Check air continuity between hose ends A and B.
Blow air into the hose end B. Air should flow freely into the fuel tank.
3. Blow air into hose end A and check there is no leakage.
4. Apply pressure to both hose ends A and B [20 kPa (150 mmHg, 5.91 inHg)] using a pressure pump and a suitable 3-way connector. Check that there is no leakage.



OK or NG

OK (With CONSULT-II) >> GO TO 9.

OK (Without CONSULT-II) >> GO TO 10.


NG >> Replace refueling control valve with fuel tank.

9. CHECK REFUELING EVAP VAPOR CUT VALVE

With CONSULT-II

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel feed hose located on the fuel gauge retainer.
 - Connect a spare fuel hose, one side to fuel gauge retainer where the hose was removed and the other side to a fuel container.
 - Drain fuel using "FUEL PUMP RELAY" in "ACTIVE TEST" mode with CONSULT-II.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.

Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel gauge retainer with fuel gauge unit.
 - Always replace O-ring with new one.**
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel gauge retainer remaining open and check that the pressure is applicable.




OK or NG

- OK >> GO TO 11.
 NG >> Replace refueling EVAP vapor cut valve with fuel tank.

10. CHECK REFUELING EVAP VAPOR CUT VALVE

⊗ **Without CONSULT-II**

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel gauge retainer.
 - Drain fuel from the tank using a hand pump into a fuel container.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.
Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel gauge retainer with fuel gauge unit.
 - Always replace O-ring with new one.**
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel gauge retainer remaining open and check that the pressure is applicable.



OK or NG

- OK >> GO TO 11.
- NG >> Replace refueling EVAP vapor cut valve with fuel tank.

11. CHECK FUEL FILLER TUBE

Check filler neck tube and hose connected to the fuel tank for clogging, dents and cracks.

OK or NG

- OK >> GO TO 12.
- NG >> Replace fuel filler tube.

12. CHECK ONE-WAY FUEL VALVE-I

Check one-way valve for clogging.

OK or NG

- OK >> GO TO 13.
- NG >> Repair or replace one-way fuel valve with fuel tank.

13. CHECK ONE-WAY FUEL VALVE-II


1. Make sure that fuel is drained from the tank.
2. Remove fuel filler tube and hose.
3. Check one-way fuel valve for operation as follows.
When a stick is inserted, the valve should open, when removing stick it should close.

Do not drop any material into the tank.

OK or NG

OK >> **INSPECTION END**

NG >> Replace fuel filler tube or replace one-way fuel valve with fuel tank.




A
EC
C
D
E
F
G
H
I
J
K
L
M

POSITIVE CRANKCASE VENTILATION

PFP:11810

Description

UBS008ZJ



AEC042B

This system returns blow-by gas to the intake collector.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.

During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air duct into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve.

The flow goes through the hose connection in the reverse direction.


On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the intake collector under all conditions.

Inspection

PCV (POSITIVE CRANKCASE VENTILATION) VALVE

UBS008ZK

With engine running at idle, remove PCV valve from breather separator. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over the valve inlet.



SEC137A


VENTILATION HOSE

1. Check hoses and hose connections for leaks.

POSITIVE CRANKCASE VENTILATION

[KA24DE]

2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



A

EC

C

D

E

F

G

H

I

J

K

L

M

SERVICE DATA AND SPECIFICATIONS (SDS)

[KA24DE]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Fuel Pressure Regulator

UBS008ZL

Fuel pressure at idling kPa (kg/cm ² , psi)	Vacuum hose is connected	Approximately 235 (2.4, 34)
	Vacuum hose is disconnected	Approximately 294 (3.0, 43)

Idle Speed and Ignition Timing

UBS008ZM

Base idle speed*1 rpm	No-load*3 (in "P" or "N" position)	750±50
Target idle speed*2 rpm	No-load*3 (in "P" or "N" position)	800±50
Air conditioner: ON rpm	In "P" or "N" position	875 or more
Ignition timing*1	In "P" or "N" position	20°±2° BTDC

*1: Throttle position sensor harness connector disconnected or using CONSULT-II "WORK SUPPORT" mode

*2: Throttle position sensor harness connector connected

*3: Under the following conditions:

- Air conditioner switch: OFF
- Electrical load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Ignition Coil

UBS008ZN

Primary voltage V	Battery voltage 12
Primary resistance [at 20°C (68°F)] Ω	Approximately 1.0
Secondary resistance [at 20°C (68°F)] kΩ	Approximately 10

Mass Air Flow Sensor

UBS008ZO

Supply voltage V	Battery voltage (11 - 14)
Output voltage V	0.9 - 1.8*
Mass air flow (Using CONSULT-II or GST) g-m/sec	0.9 - 5.8 at idle* 7.5 - 13.2 at 2,500 rpm*

*: Engine is warmed up to normal operating temperature and idling under no-load.

Engine Coolant Temperature Sensor

UBS008ZP

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

EGR Temperature Sensor

UBS008ZQ

EGR temperature °C (°F)	Voltage (V)	Resistance (MΩ)
0 (32)	4.56	0.62 - 1.05
50 (122)	2.25	0.065 - 0.094
100 (212)	0.59	0.011 - 0.015

Fuel Pump

UBS008ZR

Resistance [at 25°C (77°F)] Ω	0.2 - 5.0
-------------------------------	-----------

IACV-AAC Valve

UBS008ZS

Resistance [at 25°C (77°F)] Ω	Approximately 10.0
-------------------------------	--------------------

Injector

UBS008ZT

Resistance [at 25°C (77°F)] Ω	7.3 - 9.9
-------------------------------	-----------

SERVICE DATA AND SPECIFICATIONS (SDS)

[KA24DE]

Resistor

UBS008ZU

Resistance [at 25°C (77°F)] Ω	Approximately 2.2
-------------------------------	-------------------

Throttle Position Sensor

UBS008ZV

Throttle valve conditions	Voltage (at normal operating temp., engine off, ignition switch on)
Completely closed (a)	0.2 - 0.8V
Partially open	Between (a) and (b)
Completely open (b)	3.5 - 4.5V

Heated Oxygen Sensor 1 Heater

UBS008ZW

Resistance [at 25°C (77°F)] Ω	2.3 - 4.3
-------------------------------	-----------

Calculated Load Value

UBS008ZX

	Calculated load value % (Using CONSULT-II or GST)
At idle	9.5 - 34.0%
At 2,500 rpm	13.9 - 24.9%

Intake Air Temperature Sensor

UBS008ZY

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38

Heated Oxygen Sensor 2 Heater

UBS008ZZ

Resistance [at 25°C (77°F)] Ω	2.3 - 4.3
-------------------------------	-----------

Crankshaft Position Sensor (OBD)

UBS00900

Resistance [at 20°C (68°F)] Ω	512 - 632
-------------------------------	-----------

Fuel Tank Temperature Sensor

UBS00901

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

INDEX FOR DTC

[VG33E]

INDEX FOR DTC

PFP:00024

Alphabetical Index

UBS007UJ

x: Applicable —: Not applicable

Item (CONSULT-II screen terms)	DTC*1*2	Trip	MIL Lighting up	Reference page
	CONSULT-II GST			
Unable to access ECM	—	—	—	EC-637
A/T 1ST GR FNCTN	P0731	2	x	AT-119
A/T 2ND GR FNCTN	P0732	2	x	AT-125
A/T 3RD GR FNCTN	P0733	2	x	AT-131
A/T 4TH GR FNCTN	P0734	2	x	AT-137
A/T COMM LINE	P0600*3	2	—	EC-990
A/T DIAG COMM LINE	P1605	2	x	EC-1115
A/T TCC S/V FNCTN	P0744	2	x	AT-149
ATF TEMP SEN/CIRC	P0710	2	x	AT-105
CKP SEN/CIRCUIT	P0335	2	x	EC-853
CKP SENSOR (COG)	P1336	2	x	EC-1040
CLOSED LOOP-B1	P1148	1	x	EC-1034
CLOSED LOOP-B2	P1168	1	x	EC-1034
CLOSED TP SW/CIRC	P0510	2	x	EC-983
CMP SEN/CIRCUIT	P0340	2	x	EC-859
CYL1 MISFIRE	P0301	2	x	EC-840
CYL2 MISFIRE	P0302	2	x	EC-840
CYL3 MISFIRE	P0303	2	x	EC-840
CYL4 MISFIRE	P0304	2	x	EC-840
CYL5 MISFIRE	P0305	2	x	EC-840
CYL6 MISFIRE	P0306	2	x	EC-840
ECM	P0605	2	x	EC-996
ECT SEN/CIRCUIT	P0117	1	x	EC-730
ECT SEN/CIRCUIT	P0118	1	x	EC-730
ECT SENSOR	P0125	2	x	EC-751
EGRC-BPT VALVE	P0402	2	x	EC-875
EGR SOLENOID/V	P1400	2	x	EC-1045
EGR SYSTEM	P0400	2	x	EC-866
EFR SYSTEM	P1402	2	x	EC-1051
EGR TEMP SEN/CIRC	P0405	2	x	EC-881
EGR TEMP SEN/CIRC	P0406	2	x	EC-881
ENG OVER TEMP	P0217	1	x	EC-835
ENG OVER TEMP	P1217	1	x	EC-1036
ENG SPEED SIG	P0725	2	x	AT-115
EVAP GROSS LEAK	P0455	2	x	EC-941
EVAP PURG FLOW/MON	P0441	2	x	EC-893
EVAP SMALL LEAK	P0442	2	x	EC-901
EVAP SMALL LEAK	P1442	2	x	EC-1059
EVAP SYS PRES SEN	P0452	2	x	EC-926

INDEX FOR DTC

[VG33E]

Item (CONSULT-II screen terms)	DTC*1*2	Trip	MIL Lighting up	Reference page	
	CONSULT-II GST				
EVAP SYS PRES SEN	P0453	2	×	EC-932	
EVAP VERY SML LEAK	P0456	2	×	EC-950	EC
EVAP VERY SML LEAK	P1456	2	×	EC-1084	
FTT SEN/CIRCUIT	P0182	2	×	EC-831	C
FTT SEN/CIRCUIT	P0183	2	×	EC-831	
FTT SENSOR	P0181	2	×	EC-826	
FUEL LEV SEN SLOSH	P0460	2	×	EC-961	D
FUEL LEVEL SEN/CIRC	P1464	2	×	EC-1094	
FUEL LEVEL SENSOR	P0461	2	×	EC-965	E
FUEL LEVL SEN/CIRC	P0462	2	×	EC-967	
FUEL LEVL SEN/CIRC	P0463	2	×	EC-967	
FUEL SYS-LEAN-B1	P0171	2	×	EC-810	F
FUEL SYS-LEAN-B2	P0174	2	×	EC-810	
FUEL SYS-RICH-B1	P0172	2	×	EC-818	
FUEL SYS-RICH-B2	P0175	2	×	EC-818	G
HO2S1 (B1)	P0132	2	×	EC-758	
HO2S1 (B1)	P0133	2	×	EC-767	H
HO2S1 (B1)	P0134	2	×	EC-780	
HO2S1 (B1)	P1143	2	×	EC-998	I
HO2S1 (B1)	P1144	2	×	EC-1005	
HO2S1 (B2)	P0152	2	×	EC-758	
HO2S1 (B2)	P0153	2	×	EC-767	J
HO2S1 (B2)	P0154	2	×	EC-780	
HO2S1 (B2)	P1163	2	×	EC-998	
HO2S1 (B2)	P1164	2	×	EC-1005	K
HO2S1 HTR (B1)	P0031	2	×	EC-695	
HO2S1 HTR (B1)	P0032	2	×	EC-695	L
HO2S1 HTR (B2)	P0051	2	×	EC-695	
HO2S1 HTR (B2)	P0052	2	×	EC-695	
HO2S2 HTR (B1)	P0037	2	×	EC-703	M
HO2S2 HTR (B1)	P0038	2	×	EC-703	
HO2S2 HTR (B2)	P0057	2	×	EC-703	
HO2S2 HTR (B2)	P0058	2	×	EC-703	
HO2S2 (B1)	P0138	2	×	EC-791	
HO2S2 (B1)	P0139	2	×	EC-800	
HO2S2 (B1)	P1146	2	×	EC-1012	
HO2S2 (B1)	P1147	2	×	EC-1023	
HO2S2 (B2)	P0158	2	×	EC-791	
HO2S2 (B2)	P0159	2	×	EC-800	
HO2S2 (B2)	P1166	2	×	EC-1012	
HO2S2 (B2)	P1167	2	×	EC-1023	
IAT SEN/CIRCUIT	P0112	2	×	EC-725	
IAT SEN/CIRCUIT	P0113	2	×	EC-725	

INDEX FOR DTC

[VG33E]

Item (CONSULT-II screen terms)	DTC*1*2	Trip	MIL Lighting up	Reference page
	CONSULT-II GST			
IAT SENSOR	P0127	2	×	EC-754
ISC SYSTEM/CIRC	P0505	2	×	EC-976
KNOCK SEN/CIRC-B1	P0327	2	—	EC-849
KNOCK SEN/CIRC-B1	P0328	2	—	EC-849
L/PRESS SOL/CIRC	P0745	2	×	AT-156
MAF SEN/CIRCUIT	P0101	2	×	EC-712
MAF SEN/CIRCUIT	P0102	1	×	EC-719
MAF SEN/CIRCUIT	P0103	2	×	EC-719
MULTI CYL MISFIRE	P0300	2	×	EC-840
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	—	—	—
P-N POS SW/CIRCUIT	P1706	2	×	EC-1120
PNP SW/CIRC	P0705	2	×	AT-99
PURG VOLUME CONT/V	P0444	2	×	EC-913
PURG VOLUME CONT/V	P0445	2	×	EC-913
PURG VOLUME CONT/V	P1444	2	×	EC-1061
SFT SOL A/CIRC	P0750	2	×	AT-161
SFT SOL B/CIRC	P0755	2	×	AT-166
TCC SOLENOID/CIRC	P0740	2	×	AT-144
THERMSTAT FNCTN	P0128	2	×	EC-756
TP SEN/CIRC A/T	P1705*4	1	×	AT-171
TP SEN/CIRCUIT	P0121	2	×	EC-735
TP SEN/CIRCUIT	P0122	1	×	EC-744
TP SEN/CIRCUIT	P0123	1	×	EC-744
TW CATALYST SYS-B1	P0420	2	×	EC-887
TW CATALYST SYS-B2	P0430	2	×	EC-887
VC CUT/V BYPASS/V	P1491	2	×	EC-1103
VC/V BYPASS/V	P1490	2	×	EC-1097
VEH SPEED SEN/CIRC AT	P0720	2	×	AT-110
VEH SPEED SEN/CIRC	P0500*4	2	×	EC-971
VENT CONTROL VALVE	P0447	2	×	EC-920
VENT CONTROL VALVE	P1446	2	×	EC-1070
VENT CONTROL VALVE	P1448	2	×	EC-1076

*1: 1st trip DTC No. 1 is the same as DTC No.

*2: These numbers are prescribed by SAE J2012.

*3: This DTC is displayed with CONSULT-II only.

*4: The MIL illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

NOTE:

Regarding WD22 models, "B1" indicates bank 1, "B2" indicates bank 2.

INDEX FOR DTC

[VG33E]

UBS007UK

DTC No. Index

×: Applicable —: Not applicable

DTC*1*2 CONSULT-II GST	Items (CONSULT-II screen terms)	Trip	MIL Lighting up	Reference page
—	Unable to access ECM	2	×	EC-637
P0000	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—
P0031	HO2S1 HTR (B1)	2	×	EC-695
P0032	HO2S1 HTR (B1)	2	×	EC-695
P0037	HO2S2 HTR (B1)	2	×	EC-703
P0038	HO2S2 HTR (B1)	2	×	EC-703
P0051	HO2S1 HTR (B2)	2	×	EC-695
P0052	HO2S1 HTR (B2)	2	×	EC-695
P0057	HO2S2 HTR (B2)	2	×	EC-703
P0058	HO2S2 HTR (B2)	2	×	EC-703
P0101	MAF SEN/CIRCUIT	2	×	EC-712
P0102	MAF SEN/CIRCUIT	1	×	EC-719
P0103	MAF SEN/CIRCUIT	2	×	EC-719
P0112	IAT SEN/CIRCUIT	2	×	EC-725
P0113	IAT SEN/CIRCUIT	2	×	EC-725
P0117	ECT SEN/CIRCUIT	1	×	EC-730
P0118	ECT SEN/CIRCUIT	1	×	EC-730
P0121	TP SEN/CIRCUIT	2	×	EC-735
P0122	TP SEN/CIRCUIT	1	×	EC-744
P0123	TP SEN/CIRCUIT	1	×	EC-744
P0125	ECT SENSOR	2	×	EC-751
P0127	IAT SENSOR	2	×	EC-754
P0128	THERMSTAT FNCTN	2	×	EC-756
P0132	HO2S1 (B1)	2	×	EC-758
P0133	HO2S1 (B1)	2	×	EC-767
P0134	HO2S1 (B1)	2	×	EC-780
P0138	HO2S2 (B1)	2	×	EC-791
P0139	HO2S2 (B1)	2	×	EC-800
P0152	HO2S1 (B2)	2	×	EC-758
P0153	HO2S1 (B2)	2	×	EC-767
P0154	HO2S1 (B2)	2	×	EC-780
P0158	HO2S2 (B2)	2	×	EC-791
P0159	HO2S2 (B2)	2	×	EC-800
P0171	FUEL SYS-LEAN-B1	2	×	EC-810
P0172	FUEL SYS-RICH-B1	2	×	EC-818
P0174	FUEL SYS-LEAN-B2	2	×	EC-810
P0175	FUEL SYS-RICH-B2	2	×	EC-818
P0181	FTT SENSOR	2	×	EC-826
P0182	FTT SEN/CIRCUIT	2	×	EC-831

A
EC
C
D
E
F
G
H
I
J
K
L
M

INDEX FOR DTC

[VG33E]

DTC*1*2	Items (CONSULT-II screen terms)	Trip	MIL Lighting up	Reference page
CONSULT-II GST				
P0183	FTT SEN/CIRCUIT	2	×	EC-831
P0217	ENG OVER TEMP	1	×	EC-835
P0300	MULTI CYL MISFIRE	2	×	EC-840
P0301	CYL1 MISFIRE	2	×	EC-840
P0302	CYL2 MISFIRE	2	×	EC-840
P0303	CYL3 MISFIRE	2	×	EC-840
P0304	CYL4 MISFIRE	2	×	EC-840
P0305	CYL5 MISFIRE	2	×	EC-840
P0306	CYL6 MISFIRE	2	×	EC-840
P0327	KNOCK SEN/CIRC-B1	2	—	EC-849
P0328	KNOCK SEN/CIRC-B1	2	—	EC-849
P0335	CKP SEN/CIRCUIT	2	×	EC-853
P0340	CMP SEN/CIRCUIT	2	×	EC-859
P0400	EGR SYSTEM	2	×	EC-866
P0402	EGRC-BPT VALVE	2	×	EC-875
P0405	EGR TEMP SEN/CIRC	2	×	EC-881
P0406	EGR TEMP SEN/CIRC	2	×	EC-881
P0420	TW CATALYST SYS-B1	2	×	EC-887
P0430	TW CATALYST SYS-B2	2	×	EC-887
P0441	EVAP PURG FLOW/MON	2	×	EC-893
P0442	EVAP SMALL LEAK	2	×	EC-901
P0444	PURG VOLUME CONT/V	2	×	EC-913
P0445	PURG VOLUME CONT/V	2	×	EC-913
P0447	VENT CONTROL VALVE	2	×	EC-920
P0452	EVAP SYS PRES SEN	2	×	EC-926
P0453	EVAP SYS PRES SEN	2	×	EC-932
P0455	EVAP GROSS LEAK	2	×	EC-941
P0456	EVAP VERY SML LEAK	2	×	EC-950
P0460	FUEL LEV SEN SLOSH	2	×	EC-961
P0461	FUEL LEVEL SENSOR	2	×	EC-965
P0462	FUEL LEVL SEN/CIRC	2	×	EC-967
P0463	FUEL LEVL SEN/CIRC	2	×	EC-967
P0500*4	VEH SPEED SEN/CIRC	2	×	EC-971
P0505	ISC SYSTEM/CIRC	2	×	EC-976
P0510	CLOSED TP SW/CIRC	2	×	EC-983
P0600*3	A/T COMM LINE	2	—	EC-990
P0605	ECM	2	×	EC-996
P0705	PNP SW/CIRC	2	×	AT-99
P0710	ATF TEMP SEN/CIRC	2	×	AT-105
P0720	VEH SPD SEN/CIR AT	2	×	AT-110
P0725	ENGINE SPEED SIG	2	×	AT-115
P0731	A/T 1ST GR FNCTN	2	×	AT-119

INDEX FOR DTC

[VG33E]

DTC*1*2	Items (CONSULT-II screen terms)	Trip	MIL Lighting up	Reference page	A
CONSULT-II GST					
P0732	A/T 2ND GR FNCTN	2	×	AT-125	
P0733	A/T 3RD GR FNCTN	2	×	AT-131	EC
P0734	A/T 4TH GR FNCTN	2	×	AT-137	
P0740	TCC SOLENOID/CIRC	2	×	AT-144	C
P0744	A/T TCC S/V FNCTN	2	×	AT-149	
P0745	L/PRESS SOL/CIRC	2	×	AT-156	D
P0750	SFT SOL A/CIRC	2	×	AT-161	
P0755	SFT SOL B/CIRC	2	×	AT-166	
P1143	HO2S1 (B1)	2	×	EC-998	E
P1144	HO2S1 (B1)	2	×	EC-1005	
P1146	HO2S2 (B1)	2	×	EC-1012	F
P1147	HO2S2 (B1)	2	×	EC-1023	
P1148	CLOSED LOOP-B1	1	×	EC-1034	
P1163	HO2S1 (B2)	2	×	EC-998	G
P1164	HO2S1 (B2)	2	×	EC-1005	
P1166	HO2S2 (B2)	2	×	EC-1012	H
P1167	HO2S2 (B2)	2	×	EC-1023	
P1168	CLOSED LOOP-B2	1	×	EC-1034	
P1217	ENG OVER TEMP	1	×	EC-1036	I
P1336	CKP SENSOR (COG)	2	×	EC-1040	
P1400	EGR SOLENOID/V	2	×	EC-1045	J
P1402	EGR SYSTEM	2	×	EC-1051	
P1442	EVAP SMALL LEAK	2	×	EC-1059	K
P1444	PURG VOLUME CONT/V	2	×	EC-1061	
P1446	VENT CONTROL VALVE	2	×	EC-1070	L
P1448	VENT CONTROL VALVE	2	×	EC-1076	
P1456	EVAP VERY SML LEAK	2	×	EC-1084	M
P1464	FUEL LEVL SEN/CIRC	2	×	EC-1094	
P1490	VC/V BYPASS/V	2	×	EC-1097	
P1491	VC CUT/V BYPASS/V	2	×	EC-1103	
P1605	A/T DIAG COMM LINE	2	×	EC-1115	
P1705*4	TP SEN/CIRC A/T	1	×	AT-171	
P1706	P-N POS SW/CIRCUIT	2	×	EC-1120	
P1760	O/R CLTCH SOL/CIRC	2	×	AT-178	

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by SAE J2012.

*3: This DTC is displayed with CONSULT-II only.

*4: The MIL illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

NOTE:

Regarding WD22 models, "B1" indicates bank 1, "B2" indicates bank 2.

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

UBS007UL

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

The vehicle may be equipped with a passenger air bag deactivation switch. Because no rear seat exists where a rear-facing child restraint can be placed, the switch is designed to turn off the passenger air bag so that a rear-facing child restraint can be used in the front passenger seat. The switch is located in the center of the instrument panel, near the ashtray. When the switch is turned to the ON position, the passenger air bag is enabled and could inflate for certain types of collision. When the switch is turned to the OFF position, the passenger air bag is disabled and will not inflate. A passenger air bag OFF indicator on the instrument panel lights up when the passenger air bag is switched OFF. The driver air bag always remains enabled and is not affected by the passenger air bag deactivation switch.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.
- The vehicle may be equipped with a passenger air bag deactivation switch which can be operated by the customer. When the passenger air bag is switched OFF, the passenger air bag is disabled and will not inflate. When the passenger air bag is switched ON, the passenger air bag is enabled and could inflate for certain types of collision. After SRS maintenance or repair, make sure the passenger air bag deactivation switch is in the same position (ON or OFF) as when the vehicle arrived for service.

On Board Diagnostic (OBD) System of Engine and A/T

UBS007UM

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the negative battery cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-4, "HARNESS CONNECTOR"](#).
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM and TCM (Transmission control module) before returning the vehicle to the customer.

Precautions


A
EC
C
D
E
F
G
H
I
J
K
L
M

ECM

- Do not disassemble ECM.
- Do not turn on board diagnostic test mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value.
The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

WIRELESS EQUIPMENT

- When installing CB ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
- 1) Keep the antenna as far away as possible from the electronic control units
 - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls.
Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.



BATTERY

Always use a 12 volt battery as power source.
Do not attempt to disconnect battery cables while engine is running.

BEFORE STARTING

Do not depress accelerator pedal when starting.
Immediately after starting, do not rev up engine unnecessarily.
Do not rev up engine just prior to shutdown.

ECM PARTS HANDLING

- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor or crankshaft position sensor (OBD).



FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque. (Refer to MA section.)


ECM HARNESS HANDLING

- Securely connect ECM harness connectors.
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (3.9 in.) away from adjacent harnesses to prevent an ECM system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.


PRECAUTIONS

[VG33E]

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- Before removing parts, turn ignition switch OFF and then disconnect battery ground cable.




- Do not disassemble ECM.
- If a battery terminal is disconnected, the memory will return to the ECM value. The ECM will not start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a malfunction. Do not replace parts because of a slight variation.




- When connecting ECM harness connector, tighten securing bolt until the gap between orange indicators disappears.



: 3 - 5 N·m (0.3 - 0.5 kg-m, 26 - 43 in-lb)





- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Securely connect ECM harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep engine control system harness at least 10 cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep engine control system parts and harness dry.




PRECAUTIONS

[VG33E]

- Before replacing ECM, perform “ECM Terminals and Reference Value” inspection and make sure ECM functions properly. Refer to [EC-658, "ECM Terminals and Reference Value"](#).
- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Even a slight leak in the air intake system can cause serious incidents.
- Do not shock or jar the camshaft position sensor, crankshaft position sensor (OBD).
- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure” or “Overall Function Check”.
The DTC should not be displayed in the “DTC Confirmation Procedure” if the repair is completed. The “Overall Function Check” should be a good result if the repair is completed.



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.




A
EC
C
D
E
F
G
H
I
J
K
L
M

PRECAUTIONS

[VG33E]

- Regarding model WD22, “B1” indicates the bank 1, “B2” indicates the bank 2 as shown in the figure.



Wiring Diagrams and Trouble Diagnosis

UBS007UO

When you read Wiring diagrams, refer to the following:

- [GI-13. "How to Read Wiring Diagrams"](#)
- [PG-8. "POWER SUPPLY ROUTING"](#)

When you perform trouble diagnosis, refer to the following:

- [GI-9. "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-25. "How to Perform Efficient Diagnosis for an Electrical Incident"](#)

PREPARATION

[VG33E]


PF0:00002

UBS007UP

PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
Hose clipper  Approx. 20 mm (0.79 in)	Clamping the EVAP purge hose between the fuel tank and EVAP canister applied to DTC P1442 [EVAP control system (small leak-positive pressure)]
KV10117100 (J36471-A) Heated oxygen sensor wrench	Loosening or tightening heated oxygen sensor 1 with 22 mm (0.87 in) hexagon nut
KV10114400 (J-38365) Heated oxygen sensor wrench	Loosening or tightening heated oxygen sensor 2 a: 22 mm (0.87 in)
(J-45178) TPS test connector	Used to test the throttle position sensor





Commercial Service Tools

UBS007UQ

Tool name (Kent-Moore No.)	Description
Leak detector i.e.: (J41416)	Locating the EVAP leak
EVAP service port adapter i.e.: (J41413-OB0)	Applying positive pressure through EVAP service port

PREPARATION

[VG33E]

Tool name (Kent-Moore No.)	Description
<p>Fuel filler cap adapter</p>  <p style="text-align: right;">NT653</p>	<p>Checking fuel tank vacuum relief valve opening pressure</p>
<p>Socket wrench</p>  <p style="text-align: right;">NT705</p>	<p>Removing and installing engine coolant temperature sensor</p>
<p>Oxygen sensor thread cleaner i.e.:(J-43897-18) (J-43897-12)</p>  <p style="text-align: right;">AEM488</p>	<p>Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown in "Commercial Service Tools". a: J-43897-18 (18 mm diameter with pitch 1.5 mm) for Zirconia Oxygen Sensor b: J-43897-12 (12 mm diameter with pitch 1.25 mm) for Titania Oxygen Sensor</p>
<p>Anti-seize lubricant i.e.:(Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907)</p>  <p style="text-align: right;">AEM489</p>	<p>Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.</p>

ENGINE CONTROL SYSTEM


System Diagram

PF0:23710

UBS007UR

A
C
D
E
F
G
H
I
J
K
L
M

EC




↗ : Intake air flow
 ↘ : Exhaust air flow

- ① Vacuum cut valve bypass valve
- ② Vacuum cut valve
- ③ EVAP canister purge volume control solenoid valve
- ④ EVAP control system pressure sensor
- ⑤ EVAP canister vent control valve

Vacuum Hose Drawing

UBS007US



NOTE:
Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.

BBIA0183E

System Chart

Input (Sensor)	ECM Function	Output (Actuator)	
<ul style="list-style-type: none"> ● Camshaft position sensor ● Mass air flow sensor ● Engine coolant temperature sensor ● Heated oxygen sensor 1 ● Ignition switch ● Throttle position sensor ● Closed throttle position switch *4 ● Park/neutral position (PNP) switch ● Air conditioner switch ● Knock sensor ● Intake air temperature sensor ● EVAP control system pressure sensor *1 ● Battery voltage ● Power steering oil pressure switch ● Vehicle speed sensor ● Fuel tank temperature sensor *1 ● Crankshaft position sensor (OBD) *1 ● Heated oxygen sensor 2 *3 ● TCM (Transmission control module) *2 ● Ambient air temperature switch 	Fuel injection & mixture ratio control	Injectors	
	Distributor ignition system	Power transistor	
	Idle air control system	IACV-AAC valve and IACV-FICD solenoid valve	
	Fuel pump control	Fuel pump relay	
	On board diagnostic system	MIL (On the instrument panel)	
	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater	
	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater	
	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve	
	Air conditioning cut control	Air conditioner relay	
		ON BOARD DIAGNOSIS for EVAP system	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● Vacuum cut valve bypass valve

*1: These sensors are not used to control the engine system. They are used only for the on board diagnosis.

*2: The DTC related to A/T will be sent to ECM.

*3: This sensor is not used to control the engine system under normal conditions.

*4: This switch will operate in place of the throttle position sensor to control EVAP parts if the sensor malfunctions.

Multiport Fuel Injection (MFI) System INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed and piston position	Fuel injection & mixture ratio control	Injectors
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Heated oxygen sensor 1	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position Throttle valve idle position		
Park/neutral position (PNP) switch	Gear position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Air conditioner switch	Air conditioner operation		
Knock sensor	Engine knocking condition		
Battery	Battery voltage		
Power steering oil pressure switch	Power steering operation		
Heated oxygen sensor 2*	Density of oxygen in exhaust gas		

* Under normal conditions, this sensor is not for engine control operation.

SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined

by input signals (for engine speed and intake air) from both the camshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.


<Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from “N” to “D”
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (manifold) can then better reduce CO, HC and NOx emissions. This system uses a heated oxygen sensor 1 in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about the heated oxygen sensor 1, refer to [EC-758](#). This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of the heated oxygen sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from the heated oxygen sensor 2.

Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of heated oxygen sensor 1 or its circuit
- Insufficient activation of heated oxygen sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the heated oxygen sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot wire) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.


Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the heated oxygen sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

FUEL INJECTION TIMING



Two types of systems are used.

Sequential Multiport Fuel Injection System

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous Multiport Fuel Injection System

Fuel is injected simultaneously into all six cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The six injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

Distributor Ignition (DI) System INPUT/OUTPUT SIGNAL CHART

UBS007UV

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed and piston position	Ignition timing control	Power transistor
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position Throttle valve idle position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Knock sensor	Engine knocking		
Park/neutral position (PNP) switch	Gear position		
Battery	Battery voltage		

SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown.


The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

e.g., N: 1,800 rpm, Tp: 1.50 msec
A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.



Air Conditioner Cut Control INPUT/OUTPUT SIGNAL CHART

UBS007UW

Sensor	Input Signal to ECM	ECM function	Actuator
Air conditioner switch	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
Throttle position sensor	Throttle valve opening angle		
Camshaft position sensor	Engine speed		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Vehicle speed sensor	Vehicle speed		
Power steering oil pressure switch	Power steering operation		

SYSTEM DESCRIPTION

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned OFF.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.

Fuel Cut Control (at No Load and High Engine Load) INPUT/OUTPUT SIGNAL CHART

UBS007UX

Sensor	Input Signal to ECM	ECM function	Actuator
Vehicle speed sensor	Vehicle speed	Fuel cut control	Injectors
Park/neutral position (PNP) switch	Neutral position		
Throttle position sensor	Throttle position		
Engine coolant temperature sensor	Engine coolant temperature		
Camshaft position sensor	Engine speed		

SYSTEM DESCRIPTION

If the engine speed is above 2,500 rpm with no load (for example, in neutral and engine speed over 2,500 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 2,000 rpm, then fuel cut is cancelled.

NOTE:

This function is different from deceleration control listed under [EC-591, "Multiport Fuel Injection \(MFI\) System"](#)

A

EC

C

D

E

F

G

H

I

J

K

L


M

BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment PREPARATION

1. Make sure that the following parts are in good order.
 - Battery
 - Ignition system
 - Engine oil and coolant levels
 - Fuses
 - ECM harness connector
 - Vacuum hoses
 - Air intake system
(Oil filler cap, oil level gauge, etc.)
 - Fuel pressure
 - Engine compression
 - Throttle valve
 - Evaporative emission system
2. On air conditioner equipped models, checks should be carried out while the air conditioner is OFF.
3. On automatic transmission equipped models, when checking idle rpm, ignition timing and mixture ratio, checks should be carried out while shift lever is in "N" position.
4. When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
5. Turn off headlamps, heater blower, rear defogger.
6. Keep front wheels pointed straight ahead.
7. Make the check after the cooling fan has stopped.

OVERALL INSPECTION SEQUENCE



SEF554YA

NOTE:



If a vehicle contains a part which is operating outside of design specifications with no MIL illumination, the part shall not be replaced prior to emission testing unless it is determined that the part has been tampered with or abused in such a way that the diagnostic system cannot reasonably be expected to detect the resulting malfunction.

A
EC
C
D
E
F
G
H
I
J
K
L
M

INSPECTION PROCEDURE

1. INSPECTION START


1. Check service records for any recent repairs that may indicate a related malfunction, or a current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Wiring harness for improper connections, pinches and cut
 - Vacuum hoses for splits, kinks and improper connections
 - Hoses and ducts for leaks
 - Air cleaner clogging
 - Gasket
3. Confirm that electrical or mechanical loads are not applied.
 - Headlamp switch is OFF.
 - Air conditioner switch is OFF.
 - Rear window defogger switch is OFF.
 - Steering wheel is in the straight-ahead position, etc.
4. Visually check the following:
 - Air cleaner clogging
 - Hoses and ducts for leaks
 - Electrical connectors
 - Gasket
 - Throttle valve and throttle position sensor operation
5. Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge. Ensure engine stays below 1,000 rpm.



6. Open engine hood and run engine at about 2,000 rpm for about 2 minutes under no-load.
7. Make sure that no DTC is displayed with CONSULT-II or GST.


OK or NG

- OK >> GO TO 2.
 NG >> 1. Repair or replace components as necessary.
 2. GO TO 2.




2. CHECK IGNITION TIMING

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.



3. Turn off engine and disconnect throttle position sensor harness connector.
4. Start and rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run at idle speed.




5. Check ignition timing with a timing light.

M/T : $10^{\circ} \pm 2^{\circ}$ BTDC
A/T : $10^{\circ} \pm 2^{\circ}$ BTDC (in "P" or "N" position)

OK or NG


- OK >> GO TO 4.
 NG >> GO TO 3.



3. ADJUST IGNITION TIMING

1. Adjust ignition timing by turning distributor after loosening securing bolts.
2. Turn off engine and connect throttle position sensor harness connector to throttle position sensor.

>> GO TO 2.



4. CHECK BASE IDLE SPEED

With CONSULT-II


1. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T : 700±50 rpm
A/T : 700±50 rpm (in "P" or "N" position)

Without CONSULT-II

1. Check idle speed.

M/T : 700±50 rpm
A/T : 700±50 rpm (in "P" or "N" position)



OK or NG


- OK >> GO TO 6.
 NG >> GO TO 5.

5. ADJUST BASE IDLE SPEED

1. Rev engine (2,000 to 3,000 rpm) 2 or 3 times under no-load then run engine at idle speed.
2. Adjust idle speed by turning idle speed adjusting screw.

M/T : 700±50 rpm
A/T : 700±50 rpm (in "P" or "N" position)

>> GO TO 6.



6. CHECK TARGET IDLE SPEED

With CONSULT-II

1. Turn off engine and connect throttle position sensor harness connector.
2. Start and rev engine (2,000 to 3,000 rpm) 2 or 3 times under no-load then run at idle speed.
3. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T : 750±50 rpm
A/T : 750±50 rpm (in "P" or "N" position)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

Without CONSULT-II

1. Turn off engine and connect throttle position sensor harness connector.
2. Start and rev engine (2,000 to 3,000 rpm) 2 or 3 times under no-load then run at idle speed.
3. Check idle speed.

M/T : 750±50 rpm
A/T : 750±50 rpm (in "P" or "N" position)

OK or NG

- OK (With CONSULT-II)>>GO TO 8.
- OK (Without CONSULT-II)>>GO TO 9.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

1. Check IACV-AAC valve and replace if necessary. Refer to [EC-976](#) .
2. Check IACV-AAC valve harness and repair if necessary. Refer to [EC-976](#) .
3. Check ECM function by substituting another known-good ECM. (ECM may be the cause of an incident, but this is rarely the case.)

- With CONSULT-II>>GO TO 8.
- Without CONSULT-II>>GO TO 9.

8. CHECK HEATED OXYGEN SENSOR 1 (BANK 2) SIGNAL

With CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. See "HO2S1 MNTR (B2)" in "DATA MONITOR" mode.
3. Running engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

1 time: RICH → LEAN → RICH
2 times: RICH → LEAN → RICH → LEAN → RICH

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	RICH

PBIB0120E

OK or NG

- OK >> GO TO 12.
- NG (Monitor does not fluctuate.)>>GO TO 17.
- NG (Monitor fluctuates less than 5 times.)>>GO TO 10.

9. CHECK HEATED OXYGEN SENSOR 1 (BANK 2) SIGNAL

⊗ Without CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Set voltmeter probe between ECM terminal 62 and ground.
3. Make sure that the voltage fluctuates between 0 - 0.3V and 0.6 - 1.0V more than 5 times during 10 seconds at 2,000 rpm.
1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG

- OK >> GO TO 12.
 NG (Voltage does not fluctuate.)>>GO TO 17.
 NG (Voltage fluctuates less than 5 times.)>>GO TO 10.

10. CHECK HEATED OXYGEN SENSOR 1 (BANK 2) SIGNAL

⊕ With CONSULT-II

1. Stop engine.
2. Replace heated oxygen sensor 1 (bank 2).
3. Start engine and warm it up to normal operating temperature.
4. Run engine at approx. 2,000 rpm for approx. 2 minutes under no-load.
5. See "HO2S1 MNTR (B2)" in "DATA MONITOR" mode.
6. Running engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.
1 time: RICH → LEAN → RICH
2 times: RICH → LEAN → RICH → LEAN → RICH

⊗ Without CONSULT-II

1. Stop engine.
2. Replace heated oxygen sensor 1 (bank 2).
3. Start engine and warm it up to normal operating temperature.
4. Run engine at approx. 2,000 rpm for approx. 2 minutes under no-load.
5. Set voltmeter probe between ECM terminal 62 and ground.
6. Make sure that the voltage fluctuates between 0 - 0.3V and 0.6 - 1.0V more than 5 times during 10 seconds at 2,000 rpm.
1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG

- OK (With CONSULT-II)>>GO TO 12.
 OK (Without CONSULT-II)>>GO TO 13.
 NG >> GO TO 11.

11. DETECT MALFUNCTIONING PART

Check the following.

1. Check fuel pressure regulator. Refer to [EC-609](#) .
2. Check mass air flow sensor and its circuit. Refer to [EC-712](#) .
3. Check injector and its circuit. Refer to [EC-1133](#) .
Clean or replace if necessary.
4. Check engine coolant temperature sensor and its circuit. Refer to [EC-730](#) .
5. Check ECM function by substituting another known good ECM.
(ECM may be the cause of an incident, but this is rarely the case.)

>> GO TO 2.

12. CHECK HEATED OXYGEN SENSOR 1 (BANK 1) SIGNAL

With CONSULT-II

1. See "HO2S1 (B1)" in "DATA MONITOR" mode.
2. Maintaining engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.
1 time: RICH → LEAN → RICH
2 times: RICH → LEAN → RICH → LEAN → RICH

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	RICH

PBIB0120E

OK or NG

- OK >> **INSPECTION END.**
 NG (Monitor does not fluctuate.)>>GO TO 16.
 NG (Monitor fluctuates less than 5 times.)>>GO TO 14.

13. CHECK HEATED OXYGEN SENSOR 1 (BANK 1) SIGNAL

Without CONSULT-II

1. Set voltmeter probe between ECM terminal 63 and ground.
2. Make sure that the voltage fluctuates between 0 - 0.3V and 0.6 - 1.0V more than 5 times during 10 seconds at 2,000 rpm.
1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG

- OK >> **INSPECTION END.**
 NG (Voltage does not fluctuate.)>>GO TO 16.
 NG (Voltage fluctuates less than 5 times.)>>GO TO 14.

14. CHECK HEATED OXYGEN SENSOR 1 (BANK 1) SIGNAL

With CONSULT-II

1. Stop engine.
2. Replace heated oxygen sensor 1 (bank 1).
3. Start engine and warm it up to normal operating temperature.
4. Run engine at approx. 2,000 rpm for approx. 2 minutes under no-load.
5. See "HO2S1 MNTR (B1)" in "DATA MONITOR" mode.
6. Maintaining engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.
1 time: RICH → LEAN → RICH
2 times: RICH → LEAN → RICH → LEAN → RICH

Without CONSULT-II

1. Stop engine.
2. Replace heated oxygen sensor 1 (bank 1).
3. Start engine and warm it up to normal operating temperature.
4. Run engine at approx. 2,000 rpm for approx. 2 minutes under no-load.
5. Set voltmeter probe between ECM terminal 63 and ground.
6. Make sure that the voltage fluctuates between 0 - 0.3V and 0.6 - 1.0V more than 5 times during 10 seconds at 2,000 rpm.
1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG

- OK >> **INSPECTION END.**
 NG >> GO TO 15.

15. DETECT MALFUNCTIONING PART

Check the following.

1. Check fuel pressure regulator. Refer to [EC-609](#) .
2. Check mass air flow sensor and its circuit. Refer to [EC-712](#) .
3. Check injector and its circuit. Refer to [EC-1133](#) .
Clean or replace if necessary.
4. Check engine coolant temperature sensor and its circuit. Refer to [EC-730](#) .
5. Check ECM function by substituting another known good ECM.
(ECM may be the cause of an incident, but this is rarely the case.)

>> GO TO 2.

16. CHECK HEATED OXYGEN SENSOR 1 (BANK 1) HARNESS

1. Turn off engine and disconnect battery ground cable.
2. Disconnect ECM harness connector.
3. Disconnect heated oxygen sensor 1 (bank 1) harness connector.
4. Check harness continuity between ECM terminal 50 and heated oxygen sensor 1 (bank 1) harness connector.

Continuity should exist.

OK or NG

- OK >> 1. Connect ECM harness connector.
2. GO TO 18.
- NG >> 1. Repair or replace harness.
2. GO TO 8 (With CONSULT-II).
GO TO 9 (Without CONSULT-II).

17. CHECK HEATED OXYGEN SENSOR 1 (BANK 2) HARNESS

1. Turn off engine and disconnect battery ground cable.
2. Disconnect ECM harness connector.
3. Disconnect heated oxygen sensor 1 (bank 2) harness connector.
4. Check harness continuity between ECM terminal 51 and heated oxygen sensor 1 (bank 2) harness connector.

Continuity should exist.

OK or NG

- OK >> 1. Connect ECM harness connector.
2. GO TO 18.
- NG >> 1. Repair or replace harness.
2. GO TO 8 (With CONSULT-II).
GO TO 9 (Without CONSULT-II).

18. PREPARATION FOR "CO" % CHECK

With CONSULT-II

1. Select "ENG COOLANT TEMP" in "ACTIVE TEST" mode.
2. Set "ENG COOLANT TEMP" to 5°C (41°F) by touching "DWN" and "Qd".


ACTIVE TEST	
ENG COOLANT TEMP	XXX °C
MONITOR	
ENG SPEED	XXX rpm
INJ PULSE-B1	XXX msec
IGN TIMING	XXX BTDC

SEF172Y

Without CONSULT-II

1. Disconnect engine coolant temperature sensor harness connector.
2. Connect a resistor (4.4 kΩ) between terminals of engine coolant temperature sensor harness connector.


>> GO TO 19.



A
EC
C
D
E
F
G
H
I
J
K
L
M

19. CHECK "CO" %


1. Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge.



2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.
3. Check "CO" %.

Idle CO : 1.5 - 9.5%

4. **Without CONSULT-II**
After checking CO%,
 - Disconnect the resistor from terminals of engine coolant temperature sensor.
 - Connect engine coolant temperature sensor harness connector to engine coolant temperature sensor.



OK or NG

- OK >> GO TO 10.
- NG >> GO TO 20.

20. DETECT MALFUNCTIONING PART

Check the following.

1. Connect heated oxygen sensor 1 harness connectors to heated oxygen sensors 1.
2. Check fuel pressure regulator. Refer to [EC-609](#).
3. Check mass air flow sensor and its circuit. Refer to [EC-712](#).
4. Check injector and its circuit. Refer to [EC-1133](#).
Clean or replace if necessary.
5. Check engine coolant temperature sensor and its circuit. Refer to [EC-730](#).
6. Check ECM function by substituting another known good ECM.
(ECM may be the cause of an incident, but this is rarely the case.)

>> GO TO 2.

Fast Idle Cam (FIC) Inspection and Adjustment OPERATION PROCEDURE

UBS007V0


With CONSULT-II

1. Turn ignition switch ON.

BASIC SERVICE PROCEDURE

[VG33E]

- See "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.



- When engine coolant temperature is 20 to 30°C (68 to 86°F), make sure that the center of mark **A** is aligned with mark **B** as shown in the figure.


- If NG, adjust by turning adjusting screw.

Lock nut




: 0.98 - 1.96 N·m (10 - 20 kg·cm, 8.7 - 17.4 in·lb)

- Start engine and warm it up.




- When engine coolant temperature is 75 to 85°C (167 to 185°F), check the following.

- The center of mark **A** is aligned with mark **C**.
- The cam follower lever's roller is not touching the fast idle cam.
- If NG, replace thermo-element and perform the above inspection and adjustment again.



With GST

- Turn ignition switch ON.
- Check voltage between ECM terminal 59 (Engine coolant temperature sensor signal) and ground.




3. When the voltage is between 3.12 to 3.52V, make sure that the center of mark **A** is aligned with mark **B** as shown in the figure.
 - If NG, adjust by turning adjusting screw.


Lock nut

 : 0.98 - 1.96 N·m (10 - 20 kg-cm, 8.7 - 17.4 in-lb)

4. Start engine and warm it up.



5. When the voltage is between 1.10 to 1.36V, check the following.
 - The center of mark **A** is aligned with mark **C**.
 - The cam follower lever's roller is not touching the fast idle cam.
 - If NG, replace thermo-element and perform the above inspection and adjustment again.




Fuel Pressure Check FUEL PRESSURE RELEASE

UBS007V1

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.


Ⓟ With CONSULT-II

1. Turn ignition switch ON.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch OFF.



ⓧ Without CONSULT-II

1. Remove fuel pump fuse located in fuse box.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF.
5. Reinstall fuel pump fuse after servicing fuel system.



FUEL PRESSURE CHECK

- When reconnecting fuel line, always use new clamps.
- Make sure that clamp screw does not contact adjacent pats.
- Use a torque driver to tighten clamps.

- Use Pressure Gauge to check fuel pressure.
 - Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
1. Release fuel pressure to zero.
 2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
 3. Install pressure gauge between fuel filter and fuel tube.
 4. Start engine and check for fuel leakage.
 5. Read the indication of fuel pressure gauge.


At idling

:With vacuum hose connected

**Approximately 235 kPa
(2.4 kg/cm² , 34 psi)**

With vacuum hose disconnected


**Approximately 294 kPa
(3.0 kg/cm² , 43 psi)**



If results are unsatisfactory, perform Fuel Pressure Regulator Check.


Fuel Pressure Regulator Check

1. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
2. Plug intake manifold with a blind cap.
3. Connect variable vacuum source to fuel pressure regulator.



4. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.



ON BOARD DIAGNOSTIC (OBD) SYSTEM

PFP:00028

Introduction

UBS007V3

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Emission-related diagnostic information	SAE Mode
Diagnostic Trouble Code (DTC)	Mode 3 of SAE J1979
Freeze Frame data	Mode 2 of SAE J1979
System Readiness Test (SRT) code	Mode 1 of SAE J1979
1st Trip Diagnostic Trouble Code (1st Trip DTC)	Mode 7 of SAE J1979
1st Trip Freeze Frame data	
Test values and Test limits	Mode 6 of SAE J1979
Calibration ID	Mode 9 of SAE J1979

The above information can be checked using procedures listed in the table below.

X: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data	SRT code	Test value
CONSULT-II	×	×	×	×	×	—
GST	×	×*1	×	—	×	×

*1: 1st trip DTCs for self-diagnoses concerning SRT items cannot be shown on the GST display.

The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to [EC-637](#), "Fail-safe Chart" .)

Two Trip Detection Logic

UBS007V4

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MIL will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MIL lights up. The MIL lights up at the same time when the DTC is stored. <2nd trip> The "trip" in the "Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MIL, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

X: Applicable —: Not applicable

Items	MIL				DTC		1st trip DTC	
	1st trip		2nd trip		1st trip displaying	2nd trip displaying	1st trip displaying	2nd trip displaying
	Blinking	Lighting up	Blinking	Lighting up				
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	×	—	—	—	—	—	×	—
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	—	—	×	—	—	×	—	—
One trip detection diagnosis (refer to EC-576)	—	×	—	—	×	—	—	—
Except above	—	—	—	×	—	×	×	—

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33E]

UBS007V5

Emission-related Diagnostic Information EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

X: Applicable —: Not applicable

Items (CONSULT-II screen terms)	DTC*1*2	SRT code	Test value/ Test limit (GST only)	1st trip DTC*1	Reference page
	CONSULT-II GST				
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	—	—	—	—
HO2S1 HTR (B1)	P0031	×	×	X*4	EC-695
HO2S1 HTR (B1)	P0032	×	×	X*4	EC-695
HO2S2 HTR (B1)	P0037	×	×	X*4	EC-703
HO2S2 HTR (B1)	P0038	×	×	X*4	EC-703
HO2S1 HTR (B2)	P0051	×	×	X*4	EC-695
HO2S1 HTR (B2)	P0052	×	×	X*4	EC-695
HO2S2 HTR (B2)	P0057	×	×	X*4	EC-703
HO2S2 HTR (B2)	P0058	×	×	X*4	EC-703
MAF SEN/CIRCUIT	P0101	—	—	×	EC-712
MAF SEN/CIRCUIT	P0102	—	—	—	EC-719
MAF SEN/CIRCUIT	P0103	—	—	×	EC-719
IAT SEN/CIRCUIT	P0112	—	—	×	EC-725
IAT SEN/CIRCUIT	P0113	—	—	×	EC-725
ECT SEN/CIRCUIT	P0117	—	—	—	EC-730
ECT SEN/CIRCUIT	P0118	—	—	—	EC-730
TP SEN/CIRCUIT	P0121	—	—	×	EC-735
TP SEN/CIRCUIT	P0122	—	—	—	EC-744
TP SEN/CIRCUIT	P0123	—	—	—	EC-744
ECT SENSOR	P0125	—	—	×	EC-751
IAT SENSOR	P0127	—	—	×	EC-754
THERMSTAT FNCTN	P0128	—	—	×	EC-756
HO2S1 (B1)	P0132	×	×	X*4	EC-758
HO2S1 (B1)	P0133	×	×	X*4	EC-767
HO2S1 (B1)	P0134	×	×	X*4	EC-780
HO2S2 (B1)	P0138	×	×	X*4	EC-791
HO2S2 (B1)	P0139	×	×	X*4	EC-800
HO2S1 (B2)	P0152	×	×	X*4	EC-758
HO2S1 (B2)	P0153	×	×	X*4	EC-767
HO2S1 (B2)	P0154	×	×	X*4	EC-780
HO2S2 (B2)	P0158	×	×	X*4	EC-791
HO2S2 (B2)	P0159	×	×	X*4	EC-800
FUEL SYS-LEAN-B1	P0171	—	—	×	EC-810
FUEL SYS-RICH-B1	P0172	—	—	×	EC-818
FUEL SYS-LEAN-B2	P0174	—	—	×	EC-810
FUEL SYS-RICH-B2	P0175	—	—	×	EC-818

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33E]

Items (CONSULT-II screen terms)	DTC*1*2	SRT code	Test value/ Test limit (GST only)	1st trip DTC*1	Reference page
	CONSULT-II GST				
FTT SENSOR	P0181	—	—	×	EC-826
FTT SEN/CIRCUIT	P0182	—	—	×	EC-831
FTT SEN/CIRCUIT	P0183	—	—	×	EC-831
ENG OVER TEMP	P0217	—	—	×	EC-835
MULTI CYL MISFIRE	P0300	—	—	×	EC-840
CYL1 MISFIRE	P0301	—	—	×	EC-840
CYL2 MISFIRE	P0302	—	—	×	EC-840
CYL3 MISFIRE	P0303	—	—	×	EC-840
CYL4 MISFIRE	P0304	—	—	×	EC-840
CYL5 MISFIRE	P0305	—	—	×	EC-840
CYL6 MISFIRE	P0306	—	—	×	EC-840
KNOCK SEN/CIRC-B1	P0327	—	—	×	EC-849
KNOCK SEN/CIRC-B1	P0328	—	—	×	EC-849
CKP SEN/CIRCUIT	P0335	—	—	×	EC-853
CMP SEN/CIRCUIT	P0340	—	—	×	EC-859
EGR SYSTEM	P0400	×	×	× ^{*4}	EC-866
EGRC-BPT VALVE	P0402	×	×	× ^{*4}	EC-875
EGR TEMP SEN/CIRC	P0405	—	—	×	EC-881
EGR TEMP SEN/CIRC	P0406	—	—	×	EC-881
TW CATALYST SYS-B1	P0420	×	×	× ^{*4}	EC-887
TW CATALYST SYS-B2	P0430	×	×	× ^{*4}	EC-887
EVAP PURG FLOW/MON	P0441	×	×	× ^{*4}	EC-893
EVAP SMALL LEAK	P0442	×	×	× ^{*4}	EC-901
PURG VOLUME CONT/V	P0444	—	—	×	EC-913
PURG VOLUME CONT/V	P0445	—	—	×	EC-913
VENT CONTROL VALVE	P0447	—	—	×	EC-920
EVAP SYS PRES SEN	P0452	—	—	×	EC-926
EVAP SYS PRES SEN	P0453	—	—	×	EC-932
EVAP GROSS LEAK	P0455	×	×	× ^{*4}	EC-941
EVAP VERY SML LEAK	P0456	× ^{*3}	×	× ^{*4}	EC-950
FUEL LEV SEN SLOSH	P0460	—	—	×	EC-961
FUEL LEVEL SENSOR	P0461	—	—	×	EC-965
FUEL LEVL SEN/CIRC	P0462	—	—	×	EC-967
FUEL LEVL SEN/CIRC	P0463	—	—	×	EC-967
VEH SPEED SEN/CIRC	P0500 ^{*4}	—	—	×	EC-971
ISC SYSTEM/CIRC	P0505	—	—	×	EC-976
CLOSED TP SW/CIRC	P0510	—	—	×	EC-983
A/T COMM LINE	P0600 ^{*3}	—	—	×	EC-990
ECM	P0605	—	—	×	EC-996
PNP SW/CIRC	P0705	—	—	×	AT-99
ATF TEMP SEN/CIRC	P0710	—	—	×	AT-105

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33E]

Items (CONSULT-II screen terms)	DTC*1*2	SRT code	Test value/ Test limit (GST only)	1st trip DTC*1	Reference page
	CONSULT-II GST				
VEH SPD SEN/CIR AT	P0720	—	—	×	AT-110
ENGINE SPEED SIG	P0725	—	—	×	AT-115
A/T 1ST GR FNCTN	P0731	—	—	×	AT-119
A/T 2ND GR FNCTN	P0732	—	—	×	AT-125
A/T 3RD GR FNCTN	P0733	—	—	×	AT-131
A/T 4TH GR FNCTN	P0734	—	—	×	AT-137
TCC SOLENOID/CIRC	P0740	—	—	×	AT-144
A/T TCC S/V FNCTN	P0744	—	—	×	AT-149
L/PRESS SOL/CIRC	P0745	—	—	×	AT-156
SFT SOL A/CIRC	P0750	—	—	—	AT-161
SFT SOL B/CIRC	P0755	—	—	—	AT-166
HO2S1 (B1)	P1143	×	×	× ^{*4}	EC-998
HO2S1 (B1)	P1144	×	×	× ^{*4}	EC-1005
HO2S2 (B1)	P1146	×	×	× ^{*4}	EC-1012
HO2S2 (B1)	P1147	×	×	× ^{*4}	EC-1023
CLOSED LOOP-B1	P1148	—	—	—	EC-1034
HO2S1 (B2)	P1163	×	×	× ^{*4}	EC-998
HO2S1 (B2)	P1164	×	×	× ^{*4}	EC-1005
HO2S2 (B2)	P1166	×	×	× ^{*4}	EC-1012
HO2S2 (B2)	P1167	×	×	× ^{*4}	EC-1023
CLOSED LOOP-B2	P1168	—	—	—	EC-1034
ENG OVER TEMP	P1217	—	—	—	EC-1036
CKP SENSOR (COG)	P1336	—	—	×	EC-1040
EGR SOLENOID/V	P1400	—	—	×	EC-1045
EGR SYSTEM	P1402	×	×	× ^{*4}	EC-1051
EVAP SMALL LEAK	P1442	×	×	× ^{*4}	EC-1059
PURG VOLUME CONT/V	P1444	—	—	×	EC-1061
VENT CONTROL VALVE	P1446	—	—	×	EC-1070
VENT CONTROL VALVE	P1448	—	—	×	EC-1076
EVAP VERY SML LEAK	P1456	× ^{*3}	×	× ^{*4}	EC-1084
FUEL LEVEL SEN/CIRC	P1464	—	—	×	EC-1094
VC/V BYPASS/V	P1490	—	—	×	EC-1097
VC CUT/V BYPASS/V	P1491	—	—	×	EC-1103
A/T DIAG COMM LINE	P1605	—	—	×	EC-1115
TP SEN/CIRC A/T	P1705 ^{*4}	—	—	—	AT-171
P-N POS SW/CIRCUIT	P1706	—	—	×	EC-1120
O/R CLTCH SOL/CIRC	P1760	—	—	×	AT-178

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by SAE J2012.

*3: SRT code will not be set if the self-diagnostic result is NG.

*4: These are not displayed with GST.

NOTE:

Regarding WD22 models, "B1" indicates bank 1, "B2" indicates bank 2.

DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MIL will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MIL during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in [EC-623, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .

For malfunctions in which 1st trip DTCs are displayed, refer to [EC-611, "EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS"](#) . These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT-II.

1st trip DTC is specified in Mode 7 of SAE J1979. 1st trip DTC detection occurs without lighting up the MIL and therefore does not warn the driver of a incident. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in "Work Flow" procedure Step II, refer to [EC-632, "WORK FLOW"](#) . Then perform "DTC Confirmation Procedure" or "Overall Function Check" to try to duplicate the incident. If the malfunction is duplicated, the item requires repair.

How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

 **With CONSULT-II**

 **With GST**

CONSULT-II or GST (Generic Scan Tool) Examples: P0340, P0705, P0750, etc.

These DTCs are prescribed by SAE J2012.

(CONSULT-II also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, GST do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".

If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

DTC display	SELF DIAG RESULTS		1st trip DTC display	SELF DIAG RESULTS	
	DTC RESULTS			DTC RESULTS	
	CKP SEN/CIRCUIT [P0335]	0		CKP SEN/CIRCUIT [P0335]	1t

PBIB0911E

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed and absolute pressure at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For details, see [EC-614, "FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA"](#).

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0306 Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175
2		Except the above items (Includes A/T related items)
3	1st trip freeze frame data	

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in [EC-623, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

SYSTEM READINESS TEST (SRT) CODE

System Readiness Test (SRT) code is specified in Mode 1 of SAE J1979.

As part of enhanced emissions test for Inspection and Maintenance (I/M), certain states require that the status of SRT be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "INCMP", use the information in this service manual to set the SRT to "CMPLT".

In most cases, the ECM will automatically complete its self-diagnosis cycle during normal usage and the SRT status will indicate "CMPLT" for each application system. Once set as "CMPLT", the SRT status remains "CMPLT" until the self-diagnosis memory is erased.

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern and the SRT will indicate "INCMP" for these items.

NOTE:

The SRT will also indicate "INCMP" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.

If, during the state emissions inspection, the SRT indicates "CMPLT" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "INCMP" for one or more of the SRT items, the vehicle is returned to the customer untested.

NOTE:

If MIL is "ON" during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "CMPLT" for all test items. Therefore, it is important to check SRT ("CMPLT") and DTC (No DTCs) before the inspection.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33E]

SRT Item

The following table shows required self-diagnostic items to set the SRT to “CMPLT”.

SRT item (CONSULT-II indication)	Performance Priority *	Required self-diagnostic items to set the SRT to “CMPLT”	Corresponding DTC No.
CATALYST	3	Three way catalyst function	P0420, P0430
EVAP SYSTEM	2	EVAP control system	P0442, P1442
	3	EVAP control system	P0456, P1456
	3	EVAP control system purge flow monitoring	P0441
HO2S	3	Heated oxygen sensor 1	P0132, P0152
		Heated oxygen sensor 1	P0133, P0153
		Heated oxygen sensor 1	P0134, P0154
		Heated oxygen sensor 1	P1143, P1163
		Heated oxygen sensor 1	P1144, P1164
		Heated oxygen sensor 2	P0138, P0158
		Heated oxygen sensor 2	P0139, P0157
		Heated oxygen sensor 2	P1146, P1166
		Heated oxygen sensor 2	P1147, P1167
HO2S HEATER	3	Heated oxygen sensor 1 heater	P0031, P0032, P0051, P0052
		Heated oxygen sensor 2 heater	P0037, P0038, P0057, P0058
EGR SYSTEM	3	EGR function	P0400
		EGRC-BPT valve function	P0402
	1	EGR function	P1402

*: If completion of several SRTs is required, perform driving patterns (DTC confirmation procedure) one by one based on the priority for models with CONSULT-II.

SRT Set Timing

SRT is set as “CMPLT” after self-diagnosis has been performed one or more times. Completion of SRT is done regardless of whether the result is OK or NG. The set timing is different between OK and NG results and is shown in the table below.

Self-diagnosis result		Example				
		Diagnosis	Ignition OFF – ON – OFF	Ignition OFF – ON – OFF	Ignition OFF – ON – OFF	Ignition OFF – ON – OFF
All OK	Case 1	P0400	OK (1)	– (1)	OK (2)	– (2)
		P0402	OK (1)	– (1)	– (1)	OK (2)
		P1402	OK (1)	OK (2)	– (2)	– (2)
		SRT of EGR	“CMPLT”	“CMPLT”	“CMPLT”	“CMPLT”
	Case 2	P0400	OK (1)	– (1)	– (1)	– (1)
		P0402	– (0)	– (0)	OK (1)	– (1)
		P1402	OK (1)	OK (2)	– (2)	– (2)
		SRT of EGR	“INCMP”	“INCMP”	“CMPLT”	“CMPLT”

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33E]

NG exists	Case 3	P0400	OK	OK	–	–
		P0402	–	–	–	–
		P1402	NG	–	NG	NG (Consecutive NG)
		(1st trip) DTC	1st trip DTC	–	1st trip DTC	DTC (=MIL “ON”)
		SRT of EGR	“INCMP”	“INCMP”	“INCMP”	“CMPLT”

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is OK.

–: Self-diagnosis is not carried out.

When all SRT related self-diagnoses showed OK results in a same cycle (Ignition OFF – ON – OFF), the SRT will indicate “CMPLT”. → Case 1 above

When all SRT related self-diagnoses show OK results through several different cycles, the SRT will indicate “CMPLT” at the time the respective self-diagnoses have at least one OK result. → Case 2 above

If one or more SRT related self-diagnoses showed NG results in 2 consecutive cycles, the SRT will also indicate “CMPLT”. → Case 3 above

The table above shows that the minimum number of cycles for setting SRT as “INCMP” is one (1) for each self-diagnosis (Case 1 and 2) or two (2) for one self-diagnosis (Case 3). However, in preparation for the State emissions inspection, it is unnecessary of each self-diagnosis to be executed twice (Case 3) for the following reasons;


- The SRT will indicate “CMPLT” at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires “CMPLT” of the SRT only with OK self-diagnosis result.
- When, during SRT driving pattern, 1st trip DTC (NG) is detected prior to “CMPLT” of SRT, the self-diagnosis memory must be erased from ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate “INCMP”.

NOTE:

SRT can be set as “CMPLT” together with the DTC(s). Therefore, DTC check must always be carried out prior to the State emission inspection even though the SRT indicates “CMPLT”.

SRT Service Procedure

If a vehicle has failed the State emissions inspection due to one or more SRT items indicating "INCMP", review the following flowchart diagnostic sequence on the next page.



SEF573XA

*1 [EC-614](#)

*2 [EC-619](#)

*3 [EC-619](#)

How to Display SRT Code

WITH CONSULT-II

Selecting "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT-II.

For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT-II screen; for items whose SRT codes are not set, "INCMP" is displayed.

A sample of CONSULT-II display for SRT code is shown below.

"INCMP" means the self-diagnosis is incomplete and SRT is not set.

"CMPLT" means the self-diagnosis is complete and SRT is set.

SRT STATUS	
CATALYST	CMPLT
EVAP SYSTEM	INCMP
HO2S HTR	CMPLT
HO2S	CMPLT

SEF935Z

WITH GST

Selecting Mode 1 with GST (Generic Scan Tool)

How to Set SRT Code

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions.

With CONSULT-II

Perform corresponding DTC confirmation procedure one by one based on "Performance Priority" in the table on [EC-616, "SRT Item"](#).

Without CONSULT-II


The most efficient driving pattern in which SRT codes can be properly set is explained on the next page. The driving pattern should be performed one or more times to set all SRT codes.

A
EC
C
D
E
F
G
H
I
J
K
L
M

Driving Pattern

Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws. Refer to next page for more information and explanation of chart.

Driving pattern



PBIB1400E

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33E]

- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.
Zone A refers to the range where the time required, for the diagnosis under normal conditions*, is the shortest.
Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

*: Normal conditions refer to the following:

- Sea level
- Flat road
- Ambient air temperature: 20 - 30°C (68 - 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.
Under different conditions [For example: ambient air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1:

- **The engine is started at the engine coolant temperature of -10 to 35°C (14 to 95°F) (where the voltage between the ECM terminal 59 and ground is 3.0 - 4.3V).**
- **The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminal 59 and ground is lower than 1.4V).**
- **The engine is started at the tank fuel temperature of warmer than 0°C (32°F) (where the voltage between the ECM terminal 60 and ground is less than 4.1V).**

Pattern 2:

- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

Pattern 3:

- The driving pattern outlined in *2 must be repeated at least 3 times.

Pattern 4:


- Tests are performed after the engine has been operated for at least 17 minutes.
- The accelerator pedal must be held very steady during steady-state driving.
- If the accelerator pedal is moved, the test must be conducted all over again.

*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

*2: Operate the vehicle in the following driving pattern.

1. Decelerate vehicle to 0 km/h (0 MPH) and let engine idle.
2. Repeat driving pattern shown below at least 10 times.
- **During acceleration, hold the accelerator pedal as steady as possible.**

*3: Checking the vehicle speed with CONSULT-II or GST is advised.



Suggested Transmission Gear Position for A/T Models

Set the selector lever in the "D" position with the overdrive switch turned ON.

Suggested upshift speeds for M/T models

Shown below are suggested vehicle speeds for shifting into a higher gear. These suggestions relate to fuel economy and vehicle performance. Actual upshift speeds will vary according to road conditions, the weather and individual driving habits.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33E]

	For normal acceleration in low altitude areas [less than 1,219 m (4,000 ft)]:	For quick acceleration in low altitude areas and high altitude areas [over 1,219 m (4,000 ft)]:
Gear change	ACCEL shift point km/h (MPH)	km/h (MPH)
1st to 2nd	24 (15)	24 (15)
2nd to 3rd	40 (25)	40 (25)
3rd to 4th	64 (40)	64 (40)
4th to 5th	72 (45)	72 (45)

Suggested Maximum Speed in Each Gear

Downshift to a lower gear if the engine is not running smoothly, or if you need to accelerate.

Do not exceed the maximum suggested speed (shown below) in any gear. For level road driving, use the highest gear suggested for that speed. Always observe posted speed limits and drive according to the road conditions to ensure safe operation. Do not over-rev the engine when shifting to a lower gear as it may cause engine damage or loss of vehicle control.

Gear	km/h (MPH) 2WD (AUTO mode)
1st	50 (30)
2nd	95 (60)

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

The following is the information specified in Mode 6 of SAE J1979.

The test value is a parameter used to determine whether a system/circuit diagnostic test is “OK” or “NG” while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items (30 test items).

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

X: Applicable —: Not applicable

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
CATALYST	Three way catalyst function (Bank 1)	01H	01H	Max.	X
	Three way catalyst function (Bank 2)	03H	02H	Max.	X
EVAP SYSTEM	EVAP control system (Small leak)	05H	03H	Max.	X
	EVAP control system purge flow monitoring	06H	83H	Min.	X

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33E]

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
HO2S	Heated oxygen sensor 1 (bank 1)	09H	04H	Max.	X
		0AH	84H	Min.	X
		0BH	04H	Max.	X
		0CH	04H	Max.	X
		0DH	04H	Max.	X
	Heated oxygen sensor 1 (bank 2)	11H	05H	Max.	X
		12H	85H	Min.	X
		13H	05H	Max.	X
		14H	05H	Max.	X
		15H	05H	Max.	X
	Heated oxygen sensor 2 (bank 1)	19H	86H	Min.	X
		1AH	86H	Min.	X
		1BH	06H	Max.	X
		1CH	06H	Max.	X
	Heated oxygen sensor 2 (bank 2)	21H	87H	Min.	X
		22H	87H	Min.	X
23H		07H	Max.	X	
24H		07H	Max.	X	
HO2S HEATER	Heated oxygen sensor 1 (bank 1)	29H	08H	Max.	X
		2AH	88H	Min.	X
	Heated oxygen sensor 1 (bank 2)	2BH	09H	Max.	X
		2CH	89H	Min.	X
	Heated oxygen sensor 2 (bank 1)	2DH	0AH	Max.	X
		2EH	8AH	Min.	X
	Heated oxygen sensor 2 (bank 2)	2FH	0BH	Max.	X
30H		8BH	Min.	X	
EGR SYSTEM	EGR function	31H	8CH	Min.	X
		32H	8CH	Min.	X
		33H	8CH	Min.	X
		34H	8CH	Min.	X
		35H	0CH	Max.	X
	EGRC-BPT valve function	36H	0CH	Max.	X
		37H	8CH	Min.	X

HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

How to Erase DTC (With CONSULT-II)

NOTE:

If the DTC is not for A/T related items (see [EC-576](#)), skip steps 2 through 4.

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it ON (engine stopped) again.
2. Turn CONSULT-II "ON" and touch "A/T".
3. Touch "SELF-DIAG RESULTS".
4. Touch "ERASE". [The DTC in the TCM (Transmission control module) will be erased.] Then touch "BACK" twice.
5. Touch "ENGINE".

6. Touch "SELF-DIAG RESULTS".
 7. Touch "ERASE". (The DTC in the ECM will be erased.)
- If DTCs are displayed for both ECM and TCM (Transmission control module), they need to be erased individually from the ECM and TCM (Transmission control module).

How to erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.

SELECT SYSTEM
ENGINE
A/T

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SELF-DIAG RESULTS	
DTC RESULTS	TIME
SHIFT SOLENOID/V A	

2. Turn **CONSULT-II** "ON", and touch "A/T".

3. Touch "SELF-DIAG RESULTS".

4. Touch "ERASE". (The DTC in the TCM will be erased.)

SELECT SYSTEM
ENGINE
A/T

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
DATA MONITOR (SPEC)
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SELF DIAG RESULTS	
DTC RESULTS	TIME
SFT SOL A/CIRC [P0750]	0

5. Touch "ENGINE".

6. Touch "SELF-DIAG RESULTS".

7. Touch "ERASE". (The DTC in the ECM will be erased.)

SEF823YD

The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

How to Erase DTC (With GST)

The emission related diagnostic information in the ECM can be erased by selecting Mode 4 with GST.

NOTE:

If the DTC is not for A/T related items (see [EC-576](#)), skip step 2.

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it ON (engine stopped) again.
 2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
 3. Select Mode 4 with GST (Generic Scan Tool).
- **If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.**
 - **Erasing the emission-related diagnostic information using CONSULT-II or GST is easier and quicker than switching the mode selector on the ECM.**
 - **The following data are cleared when the ECM memory is erased.**
 1. Diagnostic trouble codes
 2. 1st trip diagnostic trouble codes
 3. Freeze frame data

4. 1st trip freeze frame data
5. System readiness test (SRT) codes
6. Test values
7. Others


Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

Malfunction Indicator Lamp (MIL) DESCRIPTION

UBS007V6




The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
If the MIL does not light up, refer to [EC-1156](#) or see [DI-22, "WARNING LAMPS"](#).
2. When the engine is started, the MIL should go off.
If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.



ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following two functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in ON position 	BULB CHECK	This function checks the MIL bulb for damage (blown, open circuit, etc.). If the MIL does not come on, check MIL circuit. (See EC-1156, "MIL AND DATA LINK CONNECTOR" .)
	Engine stopped 		
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MIL will light up to inform the driver that a malfunction has been detected. The following malfunctions will light up or blink the MIL in the 1st trip. <ul style="list-style-type: none"> ● "Misfire (Possible three way catalyst damage)" ● "One trip detection diagnoses"

DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MIL on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to [EC-1156](#), or see [DI-22, "WARNING LAMPS"](#).

DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MIL	Condition
ON	When the malfunction is detected or the ECM's CPU is malfunctioning.
OFF	No malfunction.

OBD System Operation Chart

UBS007V7

RELATIONSHIP BETWEEN MIL, 1ST TRIP DTC, DTC, AND DETECTABLE ITEMS

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33E]

- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MIL will come on. For details, refer to “Two Trip Detection Logic” on [EC-610, "Two Trip Detection Logic"](#) .
- The MIL will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The “TIME” in “SELF-DIAGNOSTIC RESULTS” mode of CONSULT-II will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in “OK” for the 2nd trip.

SUMMARY CHART

Items	Fuel Injection System	Misfire	Other
MIL (goes off)	3 (pattern B)	3 (pattern B)	3 (pattern B)
DTC, Freeze Frame Data (no display)	80 (pattern C)	80 (pattern C)	40 (pattern A)
1st Trip DTC (clear)	1 (pattern C), *1	1 (pattern C), *1	1 (pattern B)
1st Trip Freeze Frame Data (clear)	*1, *2	*1, *2	1 (pattern B)


For details about patterns “B” and “C” under “Fuel Injection System” and “Misfire”, see [EC-628](#) .

For details about patterns “A” and “B” under “Other”, see [EC-630](#) .

*1: Clear timing is at the moment OK is detected.

*2: Clear timing is when the same malfunction is detected in the 2nd trip.

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS FOR "MIS-FIRE" <EXHAUST QUALITY DETERIORATION>, "FUEL INJECTION SYSTEM"



*1: When the same malfunction is detected in two consecutive trips, MIL will light up.

*2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)

*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.

*6: The 1st trip DTC and the 1st trip freeze frame data will be cleared at the moment OK is detected.

*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

*8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

EXPLANATION FOR DRIVING PATTERNS FOR “MISFIRE <EXHAUST QUALITY DETERIORATION>”, “FUEL INJECTION SYSTEM”

<Driving Pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MIL will go off when the B counter reaches 3. (*2 in “OBD SYSTEM OPERATION CHART”)

<Driving Pattern C>

Driving pattern C means the vehicle operation as follows:

The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

Calculated load value: (Calculated load value in the freeze frame data) $\times (1 \pm 0.1)$ [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), “T” should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), “T” should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:


Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)

- The C counter will be cleared when the malfunction is detected regardless of the vehicle conditions described above.
- The C counter will be counted up when the vehicle conditions described above is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"



*1: When the same malfunction is detected in two consecutive trips, MIL will light up.

*2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)


*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.

*6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.

*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

<Driving Pattern A>



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

<Driving Pattern B>

Driving pattern B means the vehicle operation as follows:


All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MIL will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").


TROUBLE DIAGNOSIS

Trouble Diagnosis Introduction
INTRODUCTION

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no malfunctions such as vacuum leaks, fouled spark plugs, or other malfunctions with the engine.




It is much more difficult to diagnose an incident that occurs intermittently rather than continuously. Most intermittent incidents are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.




A visual check only may not find the cause of the incidents. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on [EC-632, "WORK FLOW"](#). Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such incidents, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on next page should be used.

Start your diagnosis by looking for "conventional" malfunctions first. This will help troubleshoot driveability malfunctions on an electronically controlled engine vehicle.



WORK FLOW

Flow Chart



*1 If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

*4 If malfunctioning part cannot be detected, perform [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

*2 If the incident cannot be verified, perform [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

*5 [EC-620, "Driving Pattern"](#)

*3 If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to [EC-689, "POWER SUPPLY CIRCUIT FOR ECM"](#).

*6 [EC-684, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#)

SEF510ZF

TROUBLE DIAGNOSIS

[VG33E]

Description For Work Flow

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the EC-634. "DIAGNOSTIC WORKSHEET" .
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II or GST) the (1st trip) DTC and the (1st trip) freeze frame data, then erase the DTC and the data. (Refer to EC-623. "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION" .) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV. If the incident cannot be verified, perform EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. EC-650. "Symptom Matrix Chart" .) Also check related service bulletins for information.
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . If the malfunction code is detected, skip STEP IV and perform STEP V.
STEP IV	Try to detect the (1st trip) DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT-II or GST. During the (1st trip) DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the (1st trip) DTC detection.
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-637. "Basic Inspection" .) If CONSULT-II is available, perform "DATA MONITOR (SPEC)" mode with CONSULT-II and proceed to the EC-684. "TROUBLE DIAGNOSIS - SPECIFICATION VALUE" . (If malfunction is detected, proceed to "REPAIR/REPLACE".) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-650. "Symptom Matrix Chart" .)
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-658. "ECM Terminals and Reference Value" , EC-679. "CONSULT-II Reference Value in Data Monitor Mode" . The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to GI-25. "How to Perform Efficient Diagnosis for an Electrical Incident" , "Circuit Inspection". Repair or replace the malfunction parts. If malfunctioning part cannot be detected, perform EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" .
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code [DTC No. P0000 or 0505] is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM and TCM (Transmission control module). (Refer to EC-623 and AT-35 .)

A
EC
C
D
E
F
G
H
I
J
K
L
M

DIAGNOSTIC WORKSHEET**Description**

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, each customer feels differently about a incident. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

Some conditions may cause the MIL to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere [for the models with EVAP (SMALL LEAK) diagnosis].

KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

DTC Inspection Priority Chart

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> ● P0101, P0102, P0103 Mass air flow sensor ● P0112, P0113, P0127 Intake air temperature sensor ● P0117, P0118, P0125 Engine coolant temperature sensor ● P0121, P0122, P0123 Throttle position sensor ● P0181, P0182, P0183 Fuel tank temperature sensor ● P0327, P0328 Knock sensor ● P0335 P1336 CKP sensor (OBD) ● P0340 CMP sensor ● P0460 P0461 P1464 Fuel level sensor ● P0500 VSS ● P0600 A/T control ● P0605 ECM ● P1400 EGRC-solenoid valve ● P1605 A/T diagnosis communication line ● P1706 PNP switch
2	<ul style="list-style-type: none"> ● P0132-P0134, P1143, P1144/P0152-P0154, P1163, P1164 HO2S1 ● P0031, P0032/P0051, P0052 HO2S1 heater ● P0138, P0139, P1146, P1147/P0158, P0159, P1166, P1167 HO2S2 ● P0037, P0038/P0057, P0058 HO2S2 heater ● P0217 Engine coolant overtemperature enrichment protection ● P0405, P0406 EGR temperature sensor ● P0441 EVAP control system purge flow monitoring ● P0444, P0445, P1444 EVAP canister purge volume control solenoid valve ● P0447, P1446, P1448 EVAP canister vent control valve ● P0452, P0453 EVAP control system pressure sensor ● P0456, P1456 EVAP control system ● P0510 CTP switch ● P0705-P0755, P1705, P1760 A/T related sensors, solenoid valves and switches ● P1490 P1491 Vacuum cut valve bypass valve
3	<ul style="list-style-type: none"> ● P0171, P0172, P0174, P0175 Fuel injection system function ● P0306 - P0300 Misfire ● P0400, P1402 EGR function ● P0402 EGRC-BPT valve function ● P0420, P0430 Three way catalyst function ● P0442/P1442 EVAP control system ● P0455 EVAP control system ● P0505 ISC valve ● P0731-P0734 P0744 A/T function ● P1148, P1168 Closed loop control

TROUBLE DIAGNOSIS

[VG33E]

UBS007VA

Fail-safe Chart

When the DTC listed below is detected, the ECM enters the fail-safe mode and the MIL illuminates.

DTC No.	Detected items	Engine operating condition in fail-safe mode													
P0102 P0103	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.													
P0117 P0118	Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.													
		Condition	Engine coolant temperature decided (CONSULT-II display)												
		Just as ignition switch is turned ON or Start	40°C (104°F)												
		More than approx. 4 minutes after ignition ON or Start	80°C (176°F)												
		Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)												
P0122 P0123	Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.													
		Condition	Driving condition												
		When engine is idling	Normal												
		When accelerating	Poor acceleration												
Unable to access ECM	ECM	<p>ECM fail-safe activating condition The computing function of the ECM was judged to be malfunctioning. When the fail-safe system activates (i.e., if the ECM detects a malfunction condition in the CPU of ECM), the MIL on the instrument panel lights to warn the driver. However it is not possible to access ECM and DTC cannot be confirmed.</p> <p>Engine control with fail-safe When ECM fail-safe is operating, fuel injection, ignition timing, fuel pump operation, and IACV-AAC valve operation are controlled under certain limitations.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">ECM fail-safe operation</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Engine speed</td> <td style="text-align: center;">Engine speed will not rise more than 3,000 rpm</td> </tr> <tr> <td>Fuel injection</td> <td style="text-align: center;">Simultaneous multiport fuel injection system</td> </tr> <tr> <td>Ignition timing</td> <td style="text-align: center;">Ignition timing is fixed at the preset value</td> </tr> <tr> <td>Fuel pump</td> <td style="text-align: center;">Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls</td> </tr> <tr> <td>IACV-AAC valve</td> <td style="text-align: center;">Full open</td> </tr> </tbody> </table> <p>Replace ECM, if ECM fail-safe condition is confirmed.</p>		ECM fail-safe operation		Engine speed	Engine speed will not rise more than 3,000 rpm	Fuel injection	Simultaneous multiport fuel injection system	Ignition timing	Ignition timing is fixed at the preset value	Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls	IACV-AAC valve	Full open
ECM fail-safe operation															
Engine speed	Engine speed will not rise more than 3,000 rpm														
Fuel injection	Simultaneous multiport fuel injection system														
Ignition timing	Ignition timing is fixed at the preset value														
Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls														
IACV-AAC valve	Full open														

Basic Inspection

UBS007VB

Precaution:


Perform Basic Inspection without electrical or mechanical loads applied;

- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear window defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.

1. INSPECTION START

1. Check service records for any recent repairs that may indicate a related incident, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Vacuum hoses for splits, kinks, or improper connections
 - Wiring for improper connections, pinches, or cuts

Models with CONSULT-II>>GO TO 2.
Models with GST>>GO TO 2.
Models with No Tools>> GO TO 15.



2. CONNECT CONSULT-II OR GST TO THE VEHICLE

With CONSULT-II

Connect "CONSULT-II" to the data link connector for CONSULT-II and select "ENGINE" from the menu. Refer to [EC-668](#).

With GST


Connect "GST" to the data link connector for GST.
Refer to [EC-678](#).

Models with CONSULT-II>>GO TO 3.
Models with GST>>GO TO 14.

3. CHECK FI CAM FUNCTION

With CONSULT-II


1. Turn ignition switch ON.
2. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
3. Start engine and warm it up.



4. When engine coolant temperature is 75 to 85°C (167 to 185°F), check the following.
 - The center of mark **A** is aligned with mark **C**.
 - The cam follower lever's roller is not touching the fast idle cam.

OK or NG


- OK >> GO TO 4.
- NG >> 1. Check FI cam. Refer to [EC-606, "Fast Idle Cam \(FIC\) Inspection and Adjustment"](#).
- 2. GO TO 4.



4. CHECK IGNITION TIMING

With CONSULT-II

1. Warm up engine to normal operating temperature.
2. Select "IGNITION TIMING ADJ" in "WORK SUPPORT" mode and touch "START".




3. Check ignition timing at idle using a timing light.

Ignition timing : 10°±2° BTDC

OK or NG

- OK >> GO TO 5.
- NG >> 1. Adjust ignition timing by turning distributor. Refer to [EC-596, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#).
- 2. GO TO 5.



5. CHECK BASE IDLE SPEED


With CONSULT-II

1. Select "IGNITION TIMING ADJ" in "WORK SUPPORT" mode and touch "START".
2. Check idle speed.

700±50 rpm (in "P" or "N" position)

OK or NG

- OK >> GO TO 6.
 NG >> 1. Adjust engine speed by turning idle speed adjusting screw. Refer to [EC-596. "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#) .
 2. GO TO 6.



6. CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION-I

With CONSULT-II

NOTE:


Always check ignition timing and base idle speed before performing the following.

1. Warm up engine to normal operating temperature.
2. Check FI cam, refer to procedure 3.
3. Stop engine.

>> GO TO 7.

7. CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION-II

1. Turn ignition switch ON.
2. Select "TP SW/TP SEN IDLE POSI ADJ" in "WORK SUPPORT" mode.
3. Read "CLSD THL/P SW" signal under the following conditions.
 - Insert a 0.3 mm (0.012 in) and 0.4 mm (0.016 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure and check the signal.



DATA MONITOR	
MONITOR	NO DTC
CLSD THL/P SW	ON

"CLSD THL/P SW" signal should remain "ON" while inserting 0.3 mm (0.012 in) feeler gauge.
 "CLSD THL/P SW" signal should remain "OFF" while inserting 0.4 mm (0.016 in) feeler gauge.

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 8.

8. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION

Ⓜ With CONSULT-II


NOTE:

- Never adjust throttle adjust screw (TAS).
 - Do not touch throttle drum when checking "CLSD THL/P SW" signal, doing so may cause an incorrect adjustment.
1. Warm up engine to normal operating temperature.
 2. Check FI cam. Refer to procedure 3.
 3. Stop engine.
 4. Loosen throttle position sensor fixing bolts.

>> GO TO 9.

9. ADJUSTMENT CLOSED THROTTLE POSITION SWITCH IDLE POSITION-II

1. Turn ignition switch ON.
2. Select "TP SW/TP SEN IDLE POSI ADJ" in "WORK SUPPORT" mode.
3. Insert 0.35 mm (0.0138 in) feeler gauge between throttle adjust screw and throttle drum as shown in the figure.
4. Open throttle valve and then close.



5. Check "CLSD THL/P SW" signal.
"CLSD THL/P SW" signal should remain "OFF" when the throttle valve is closed.

OK or NG

- OK >> GO TO 11.
- NG >> GO TO 10.


DATA MONITOR	
MONITOR	NO DTC
CLSD THL/P SW	OFF

10. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-III

 **With CONSULT-II**

Turn throttle position sensor body counterclockwise until "CLSD THL/P SW" signal switches to "OFF".


>> GO TO 11.



11. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-IV

 With CONSULT-II

1. Remove 0.35 mm (0.0138 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge.
2. Temporarily tighten sensor body fixing bolts as follows.
 - **Gradually move the sensor body clockwise and stop it when “CLSD THL/P SW” signal switches from “OFF” to “ON”, then temporarily tighten sensor body fixing bolts.**
3. Make sure two or three times that the signal is “ON” when the throttle valve is closed and “OFF” when it is opened.
4. Remove 0.3 mm (0.012 in) feeler gauge then insert 0.4 mm (0.016 in) feeler gauge.
5. Make sure two or three times that the signal remains “OFF” when the throttle valve is closed.
6. Tighten throttle position sensor.
7. Check the “CLSD THL/P SW” signal again.
The signal remains “OFF” while closing throttle valve.



OK or NG

- OK >> GO TO 12.
- NG >> GO TO 8.


12. RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY

 With CONSULT-II

NOTE:

Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.

1. Remove feeler gauge.
2. Start engine.
3. Warm up engine to normal operating temperature.
4. Select “TP SW/TP SEN IDLE POSI ADJ” in “WORK SUPPORT” mode.
5. Stop engine. (Turn ignition switch OFF.)
6. Turn ignition switch ON and wait at least 5 seconds.
7. Turn ignition switch OFF and wait at least 5 seconds.



8. Repeat steps 5 and 6 until “CLSD THL POS” signal changes to “ON”.

>> GO TO 13.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
CLSD THL/P SW	ON

SEF197Y

13. CHECK TARGET IDLE SPEED

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "ENG SPEED" in "DATA MONITOR" mode.
3. Check idle speed.

750±50 rpm (in "P" or "N" position)

OK or NG

OK >> **INSPECTION END.**

NG >> 1. Adjust idle speed. Refer to [EC-596, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#) .
2. GO TO 27.

14. CHECK FI CAM FUNCTION


With GST

1. Turn ignition switch ON.
2. Select "MODE 1" with GST.
3. Start engine and warm it up.
4. When engine coolant temperature is 75 to 85°C (167 to 185°F), check the following.
 - The center of mark **A** is aligned with mark **C** .
 - The cam follower lever's roller is not touching the fast idle cam.

OK or NG

OK >> GO TO 16.


NG >> 1. Check FI cam. Refer to [EC-606, "Fast Idle Cam \(FIC\) Inspection and Adjustment"](#) .
2. GO TO 16.



15. CHECK FI CAM FUNCTION

 **No Tools**

1. Set the voltmeter between ECM terminal 59 (Engine coolant temperature sensor signal) and ground.
2. Start engine and warm it up.




3. When the voltage is between 1.10 to 1.36V, check the following.
 - The center of mark **A** is aligned with mark **C**.
 - The cam follower lever's roller is not touching the fast idle cam.

OK or NG

OK >> GO TO 16.

NG >> 1. Check FI cam. Refer to [EC-606, "Fast Idle Cam \(FIC\) Inspection and Adjustment"](#).


2. GO TO 16.



16. CHECK IGNITION TIMING

 **Without CONSULT-II**

1. Warm up engine to normal operating temperature.
2. Stop engine and disconnect throttle position sensor harness connector.
3. Start engine.



4. Check ignition timing at idle using a timing light.


Ignition timing : 10°±2° BTDC

OK or NG

OK >> GO TO 17.

NG >> 1. Adjust ignition timing by turning distributor. Refer to [EC-596, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#).

2. GO TO 17.



17. CHECK BASE IDLE SPEED

⊗ Without CONSULT-II

1. Make sure that throttle position sensor harness connector remain disconnected.
2. Does engine speed fall to the following speed?

700±50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 18.

NG >> 1. Adjust engine speed by turning idle speed adjusting screw. Refer to [EC-596, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#) .

2. GO TO 18.

18. CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION

⊗ Without CONSULT-II

NOTE:


Always check ignition timing and base idle speed before performing the following.

1. Warm up engine to normal operating temperature.
2. Check FI cam, refer to procedure 14 or 15.
3. Stop engine.

>> GO TO 19.

19. CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION-I

1. Disconnect closed throttle position switch harness connector.
2. Check continuity between closed throttle position switch terminals **5** and **6** under the following conditions.




- Insert the 0.3 mm (0.012 in) and 0.4 mm (0.016 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure.
"Continuity should exist" while inserting 0.3 mm (0.012 in) feeler gauge.
"Continuity should not exist" while inserting 0.4 mm (0.016 in) feeler gauge.

OK or NG

OK >> GO TO 24.

NG >> GO TO 20.



20. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION

⊗ Without CONSULT-II


NOTE:

- Never adjust throttle adjust screw (TAS).
 - Do not touch throttle drum when checking “continuity”, doing so may cause an incorrect adjustment.
1. Warm up engine to normal operating temperature.
 2. Check FI cam. Refer to procedure 12 or 13.
 3. Stop engine.
 4. Loosen throttle position sensor fixing bolts.

>> GO TO 21.

21. ADJUSTMENT CLOSED THROTTLE POSITION SWITCH IDLE POSITION-II

1. Disconnect closed throttle position switch harness connector.
2. Insert 0.35 mm (0.0138 in) feeler gauge between the throttle adjust screw and throttle drum as shown in the figure.
3. Open throttle valve then close.




4. Check continuity between closed throttle position switch terminals 5 and 6.

Continuity should not exist while closing the throttle position sensor.

OK or NG

- OK >> GO TO 23.
- NG >> GO TO 22.




22. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-III

⊗ Without CONSULT-II


Turn throttle position sensor body counterclockwise until continuity does not exist.

>> GO TO 23.



23. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-IV**⊗ Without CONSULT-II**

1. Remove 0.35 mm (0.0138 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge.
2. Temporarily tighten sensor body fixing bolts as follows.
 - **Gradually move the sensor body clockwise and stop it when the continuity comes to exist, then temporarily tighten sensor body fixing bolts.**
3. Make sure two or three times that the continuity exists when the throttle valve is closed and continuity does not exist when it is opened.
4. Remove 0.3 mm (0.012 in) feeler gauge then insert 0.4 mm (0.016 in) feeler gauge.
5. Make sure two or three times that the continuity does not exist when the throttle valve is closed.
6. Tighten throttle position sensor.
7. Check the continuity again.



Continuity does not exist while closing the throttle valve.

OK or NG

OK >> GO TO 24.


NG >> GO TO 20.

24. RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY**⊗ Without CONSULT-II****NOTE:**

Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.

1. Remove feeler gauge.
2. Start engine.
3. Warm up engine to normal operating temperature.
4. Stop engine. (Turn ignition switch OFF.)
5. Turn ignition switch ON and wait at least 5 seconds.
6. Turn ignition switch OFF and wait at least 5 seconds.
7. Repeat steps 4 and 5, 20 times.

>> GO TO 25.



25. REINSTALLATION**⊗ Without CONSULT-II**

1. Reconnect throttle position sensor harness connector and closed throttle position switch harness connector.
2. Start engine and rev it (2,000 to 3,000 rpm) two or three times under no-load and then run engine at idle speed.

>> GO TO 26.

26. CHECK TARGET IDLE SPEED**⊗ Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.

750±50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 27.

NG >> 1. Adjust idle speed. Refer to [EC-596, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#).
2. GO TO 27.

27. ERASE UNNECESSARY DTC

After this inspection, unnecessary DTC No. might be displayed.

Erase the stored memory in ECM and TCM (Transmission control module).

Refer to [EC-623, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) and [AT-35, "HOW TO ERASE DTC"](#).

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS

[VG33E]

UBS007VC

Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

		SYMPTOM											Reference page		
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION		EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		3	2			3		1	EC-1142
	Injector circuit							2							EC-1133
	Fuel pressure regulator system														EC-609
	Evaporative emission system	4	4	4	4	4	4	4	3	3		4			EC-1157
Air	Positive crankcase ventilation system												1		EC-1173
	Incorrect idle speed adjustment	3	3				1	1	1	1		1			EC-637
	IACV-AAC valve circuit		1				2	2						1	EC-976
	IACV-FICD solenoid valve circuit	2	2	3	3	3	3	3	2	2		3			EC-1151
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			EC-596
	Ignition circuit	1	1	2	2	2		2	2			2			EC-1127
EGR	EGRC-solenoid valve circuit		2	2	3	3						3			EC-1045
	EGR system	2	1	2	3	3	3	2	2	3		3			EC-866, EC-875, EC-1051
Main power supply and ground circuit		1									1				EC-689
Air conditioner circuit		2	2	3	3	3		3	2	2		3		1	MTC-25

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

TROUBLE DIAGNOSIS

[VG33E]

	SYMPTOM													Reference page
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATSWATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Camshaft position sensor circuit	1			2				2						EC-859
Mass air flow sensor circuit														
Heated oxygen sensor 1 circuit		1	2	3	2		2				2			EC-758, EC-767, EC-780, EC-998, EC-1005
Engine coolant temperature sensor circuit	1	2	3		3	3			2		3			EC-730, EC-751
Throttle position sensor circuit		1	2		2	2					2			EC-735, EC-744
Incorrect throttle position sensor adjustment		3	1		1	1	1	1	1		1			EC-637
Vehicle speed sensor circuit		2												EC-971
Knock sensor circuit			3		3						3			EC-849
ECM	2	2		3		3	3	2	2	1				EC-996, EC-637
Start signal circuit	1													EC-1138
Park/neutral position (PNP) switch circuit			3		3						3			EC-1120
Power steering oil pressure switch circuit		2					3	2						EC-1147

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[VG33E]

SYSTEM — ENGINE MECHANICAL & OTHER

		SYMPTOM												Reference section															
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)														
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA															
Fuel	Fuel tank	5	5												FL-2														
	Fuel piping			5	5	5		5	4			5																	
	Vapor lock																												
	Valve deposit																												
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5		5	4			5			—														
Air	Air duct	5	5	5	5	5	5	5	4	4	5	5	5	1															
	Air cleaner																												
	Air leakage from air duct (Mass air flow sensor — throttle body)																5												
	Throttle body, Throttle wire																	5											EM-78
	Air leakage from intake manifold/Collector/Gasket				5											—													
Crank- ing	Battery	1	1	1	1	1	1	1	1	1	1	1	1	1	SC-4														
	Generator circuit																											SC-24	
	Starter circuit																												SC-9
	Park/neutral position (PNP) switch																												MT-46, AT-99
	Drive plate/Flywheel														6														EM-78

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

TROUBLE DIAGNOSIS

[VG33E]


		SYMPTOM												Reference section	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATSWATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Engine	Cylinder head	5	5	5	5	5		5	5			5			EM-100
	Cylinder head gasket										2		2		
	Cylinder block														
	Piston												3		
	Piston ring														
	Connecting rod	6	6	6	6	6		6	6			6			
	Bearing														
	Crankshaft														
Valve mechanism	Timing chain														EM-130 , EM-89
	Camshaft	6													
	Intake valve		6	6	6	6		6	6			6	2		
	Exhaust valve														
	Hydraulic lash adjuster														
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	6	6	6	6	6		6	6			6			EX-3
	Three way catalyst														
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	6	6	6	6	6		6	6			6	2		LU-14 , LU-15 , LU-16 , EM-86 MA-30
	Oil level (Low/Filthy) oil														
Cooling	Radiator/Hose/Radiator filler cap														CO-22 , CO-23 , CO-25 , CO-28 , CO-30 , CO-32 MA-26
	Thermostat						5				5				
	Water pump	6	6	6	6	6		6	6		2	6			
	Water gallery														
	Cooling fan						5				5				
	Coolant level (low)/Contaminated coolant														

1 - 6: The numbers refer to the order of inspection.

A
EC
C
D
E
F
G
H
I
J
K
L
M

Engine Control Component Parts Location

UBS007VD



BBIA0179E

A





EC

C

D

E

F





G

H

I

J

K





L

M


TROUBLE DIAGNOSIS

[VG33E]




Circuit Diagram

A
EC
C
D
E
F
G
H
I
J
K
L
M



ECM Harness Connector Terminal Layout

UBS007VF



SEF533P


ECM Terminals and Reference Value

PREPARATION


UBS007VG

1. ECM is located behind the instrument lower cover. For this inspection:

- Remove instrument lower cover.




2. Remove ECM harness protector.



3. Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.

- Open harness securing clip to make testing easier.
- Use extreme care not to touch 2 pins at one time.
- Data is for comparison and may not be exact.



ECM INSPECTION TABLE





Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TROUBLE DIAGNOSIS



[VG33E]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	PU/W	Ignition signal	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>Approximately 0.7V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>1.1 - 1.5V★</p> 
3	P/L	Tachometer	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1 - 2V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>3 - 5V★</p> 
4	OR/B	ECM relay (Self shut-off)	<p>[Engine is running] [Ignition switch OFF]</p> <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch OFF 	0 - 1.5V
			<p>[Ignition switch OFF]</p> <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch OFF 	BATTERY VOLTAGE (11 - 14V)

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[VG33E]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
5	R/Y	EVAP canister purge volume control solenoid valve	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	BATTERY VOLTAGE (11 - 14V)★ 
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm (More than 100 seconds after starting engine) 	BATTERY VOLTAGE (11 - 14V)★ 
6	G/W	SCB valve control solenoid valve	[Ignition switch ON] <ul style="list-style-type: none"> ● Engine stopped 	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
7	Y/G	A/T check signal	[Ignition switch ON] [Engine is running]	0 - 3.0V
9	B/Y	Ambient air temperature switch	[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is above 25°C (77°F) ● Air conditioner is operating 	0V
			[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is below 19°C (66°F) ● Air conditioner is operating 	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is below 19°C (66°F) ● Air conditioner is not operating 	Approximately 5V
10	B/R	ECM ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Engine ground
11	W/R	Fuel pump relay	[Ignition switch ON] <ul style="list-style-type: none"> ● For 5 seconds after turning ignition switch ON 	0 - 1V
			[Engine is running] [Ignition switch ON] <ul style="list-style-type: none"> ● More than 5 seconds after turning ignition switch ON 	BATTERY VOLTAGE (11 - 14V)
12	P	Air conditioner relay	[Engine is running] <ul style="list-style-type: none"> ● Both A/C switch and blower switch are ON* 	0 - 1V
			[Engine is running] <ul style="list-style-type: none"> ● A/C switch is OFF 	BATTERY VOLTAGE (11 - 14V)




TROUBLE DIAGNOSIS

[VG33E]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	A
18	R/W	Malfunction indicator lamp	[Ignition switch ON]	0 - 1V	EC
			[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)	
19	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground	C
20	L/OR	Start signal	[Ignition switch ON]	Approximately 0V	D
			[Ignition switch START]	9 - 12V	
21	G/R	Air conditioner switch	[Engine is running] ● Both A/C switch and blower switch are ON (Compressor operates)*	Approximately 0V	E
			[Engine is running] ● A/C switch is OFF	BATTERY VOLTAGE (11 - 14V)	
22	L/B	Park/neutral position (PNP) switch	[Ignition switch ON] ● Gear position is "N" or "P"	Approximately 0V	F
			[Ignition switch ON] ● Except the above gear position	Approximately 5V	G
23	L	Throttle position sensor	[Engine is running] ● Warm-up condition ● More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. ● Accelerator pedal fully released	0.15 - 0.85V	H
			[Ignition switch ON] ● Engine stopped ● Accelerator pedal fully depressed	3.5 - 4.7V	I
24	W/L	Ignition switch	[Ignition switch OFF]	0V	J
			[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)	
25	B/Y	ECM ground	[Engine is running] ● Idle speed	Engine ground	L
26	PU/W	A/T signal No. 1	[Engine is running] ● Idle speed	Approximately 0 - 1.0V	M
27	P/B	A/T signal No. 2	[Engine is running] ● Idle speed	Approximately 0 - 1.0V	M
28	BR/W	Throttle position switch (Closed position)	[Engine is running] ● Warm-up condition ● More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. ● Accelerator pedal fully released	BATTERY VOLTAGE (11 - 14V)	
			[Ignition switch ON] ● Engine stopped ● Accelerator pedal depressed	Approximately 0V	







TROUBLE DIAGNOSIS

[VG33E]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
29	G/B	Vehicle speed sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Lift up the vehicle. ● In 2nd gear position ● Vehicle speed is 40 km/h (25 MPH) 	<p>2 - 3V★</p> 
32	B/Y	ECM ground	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	Engine ground
35	G/R	A/T signal No. 3	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	Approximately 0 - 1.0V
39	GY/R	Power steering oil pressure switch	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Steering wheel is being turned 	Approximately 0V
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Steering wheel is not being turned 	Approximately 5V
42	B/W	Sensors' power supply	<p>[Ignition switch ON]</p>	Approximately 5V
43	BR	Sensors' ground	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
44 48	PU PU	Camshaft position sensor (Reference signal)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>0.3 - 0.5V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>0.3 - 0.5V★</p> 
46	G	Fuel level sensor	<p>[Ignition switch ON]</p>	<p>Approximately 0 - 4.8V</p> <p>Output voltage varies with fuel level.</p>

TROUBLE DIAGNOSIS

[VG33E]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	L	Crankshaft position sensor (OBD)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1 - 2V★ (AC range)</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>3 - 4V★ (AC range)</p> 
49	LG	Camshaft position sensor (Position signal)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 2.5V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 2.5V★</p> 
50	B	Heated oxygen sensor 1 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p> 
51	G	Heated oxygen sensor 1 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p> 

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[VG33E]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
54	R	Mass air flow sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	1.0 - 1.7V
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,500 rpm 	1.7 - 2.3V
55	G	Mass air flow sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
56	OR	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Engine after warming up. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. ● Revving engine from idle to 3,000 rpm quickly. 	0 - Approximately 1.0V
57	Y	Heated oxygen sensor 2 (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Engine after warming up. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. ● Revving engine from idle to 3,000 rpm quickly. 	0 - Approximately 1.0V
59	LG/R	Engine coolant temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature
60	Y/B	Fuel tank temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with fuel temperature
61	PU/R	Intake air temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with intake air temperature.
62	Y	EVAP control system pressure sensor	[Ignition switch ON]	1.8 - 4.8V
63	G/OR	EGR temperature sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Less than 4.5V
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● EGR system is operating 	0 - 1.5V
64	W	Knock sensor	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 2.5V
66	B	Fuel level sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
68	W/G	A/T signal	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0 - 5.0V
69	LG/R	Data link connector	[Engine is running] <ul style="list-style-type: none"> ● Idle speed (CONSULT-II or GST is disconnected) 	6 - 10V

TROUBLE DIAGNOSIS

[VG33E]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
72	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
80	SB	Power supply (Back-up)	[Ignition switch OFF]	BATTERY VOLTAGE (11 - 14V)
101	OR/L	IACV-AAC valve	[Engine is running] ● Warm-up condition ● Idle speed	8 - 11V★ SEF005V
			[Engine is running] ● Warm-up condition ● Engine speed is 3,000 rpm	7 - 10V★ SEF692W
102 104 106 109 111 113	W/B W/R W/G W/L W/PU W	Injector No. 1 Injector No. 3 Injector No. 5 Injector No. 2 Injector No. 4 Injector No. 6	[Engine is running] ● Warm-up condition ● Idle speed	BATTERY VOLTAGE (11 - 14V)★ SEF007V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm	BATTERY VOLTAGE (11 - 14V)★ SEF008V
103	G/W	EGRC-solenoid valve	[Engine is running] ● Warm-up condition ● Idle speed	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Warm-up condition ● Revving engine from idle to 3,000 rpm quickly	0 - 1V
108	R/G	EVAP canister vent control valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
116	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
117	B/P	Current return	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[VG33E]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
119	BR/Y	Heated oxygen sensor 1 heater (bank 1)	[Engine is running] ● Engine speed is below 2,800 rpm	Approximately 0.4V
			[Engine is running] ● Engine speed is above 2,800 rpm	BATTERY VOLTAGE (11 - 14V)
120	P/B	Vacuum cut valve bypass valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
121	BR	Heated oxygen sensor 1 heater (bank 2)	[Engine is running] ● Engine speed is below 2,800 rpm	Approximately 0.4V
			[Engine is running] ● Engine speed is above 2,800 rpm	BATTERY VOLTAGE (11 - 14V)
122	R/B	Heated oxygen sensor 2 heater (bank 1)	[Engine is running] ● Engine speed is below 3,600 rpm after the following conditions are met. – Engine: After warming up – Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load.	0 - 1.0V
			[Ignition switch ON] ● Engine stopped [Engine is running] ● Engine speed is above 3,600 rpm	BATTERY VOLTAGE (11 - 14V)
123	R/Y	Heated oxygen sensor 2 heater (bank 2)	[Engine is running] ● Engine speed is below 3,600 rpm after the following conditions are met. – Engine: After warming up – Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load.	0 - 1.0V
			[Ignition switch ON] ● Engine stopped [Engine is running] ● Engine speed is above 3,600 rpm	BATTERY VOLTAGE (11 - 14V)
124	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground

*: Any mode except OFF, ambient air temperature is above 25°C (77°F).

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

CONSULT-II Function FUNCTION

UBS007VH

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*1
Data monitor	Input/Output data in the ECM can be read.
Data monitor (SPEC)	Input/Output specification of the basic fuel schedule, AFM, A/F feedback control value and the other data monitor items can be read.
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
DTC confirmation	The status of system monitoring tests and the self-diagnosis status/result can be confirmed.

TROUBLE DIAGNOSIS

[VG33E]

Diagnostic test mode	Function
Function test	This mode is used to inform customers when their vehicle condition requires periodic maintenance.
ECM part number	ECM part number can be read.

*1 The following emission-related diagnostic information is cleared when the ECM memory is erased.

1. Diagnostic trouble codes
2. 1st trip diagnostic trouble codes
3. Freeze frame data
4. 1st trip freeze frame data
5. System readiness test (SRT) codes
6. Test values
7. Others

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

Item		DIAGNOSTIC TEST MODE							
		WORK SUP-PORT	SELF-DIAGNOS-TIC RESULTS		DATA MONI-TOR	DATA MONI-TOR (SPEC)	ACTIVE TEST	DTC & SRT CON-FIRMATION	
			DTC*1	FREEZE FRAME DATA*2				SRT STA-TUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS INPUT	Camshaft position sensor		X	X	X	X			
	Mass air flow sensor		X		X	X			
	Engine coolant temperature sensor		X	X	X	X	X		
	Heated oxygen sensor 1		X		X	X		X	X
	Heated oxygen sensor 2		X		X	X		X	X
	Vehicle speed sensor		X	X	X	X			
	Throttle position sensor	X	X		X	X			
	Fuel tank temperature sensor		X		X	X	X		
	EVAP control system pressure sensor		X		X	X			
	EGR temperature sensor		X		X	X			
	Intake air temperature sensor		X		X	X			
	Crankshaft position sensor (OBD)		X						
	Knock sensor		X						
	Ignition switch (start signal)				X	X			
	Closed throttle position switch		X		X	X			
	Closed throttle position switch (throttle position sensor signal)				X	X			
	Air conditioner switch				X	X			
	Park/neutral position (PNP) switch		X		X	X			
	Power steering oil pressure switch				X	X			
Battery voltage				X	X				
Ambient air temperature switch				X	X				

TROUBLE DIAGNOSIS

[VG33E]

Item		DIAGNOSTIC TEST MODE							
		WORK SUP-PORT	SELF-DIAGNOS-TIC RESULTS		DATA MONI-TOR	DATA MONI-TOR (SPEC)	ACTIVE TEST	DTC & SRT CON-FIRMATION	
			DTC*1	FREEZE FRAME DATA*2				SRT STA-TUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS OUTPUT	Injectors				X	X	X		
	Power transistor (Ignition timing)				X	X	X		
	IACV-AAC valve	X	X		X	X	X		
	EVAP canister purge volume control solenoid valve		X		X	X	X		X
	Air conditioner relay				X	X			
	Fuel pump relay	X			X	X	X		
	EGRC-solenoid valve	X	X		X	X	X		
	Heated oxygen sensor 1 heater		X		X	X		X	
	Heated oxygen sensor 2 heater		X		X	X		X	
	EVAP canister vent control valve	x	X		X	X	X		
	Vacuum cut valve bypass valve	x	X		X	X	X		X
	Calculated load value			X	X	X			


X: Applicable

*1: This item includes 1st trip DTCs.


*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to [EC-670, "Freeze Frame Data and 1st Trip Freeze Frame Data"](#).

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to data link connector which is located under LH dash panel near the fuse box cover.



3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".




5. Touch "ENGINE".
 If "ENGINE" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .



6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual.



WORK SUPPORT MODE

Work Item

WORK ITEM	CONDITION	USAGE
TP SW/TP SEN IDLE POSI ADJ	<ul style="list-style-type: none"> FOLLOW THE BASIC INSPECTION INSTRUCTION IN THE SERVICE MANUAL. 	When adjusting the idle throttle position
IGNITION TIMING ADJ	<ul style="list-style-type: none"> IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR. 	When adjusting target ignition timing After adjustment, confirm target ignition timing with a timing light by turning the distributor.
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line
SELF-LEARNING CONT	<ul style="list-style-type: none"> THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT. 	When clean the coefficient of self-learning control valve

TROUBLE DIAGNOSIS

[VG33E]

WORK ITEM	CONDITION	USAGE
EVAP SYSTEM CLOSE	<p>OPEN THE VACUUM CUT VALVE BYPASS VALVE AND CLOSE THE EVAP CANISTER VENT CONTROL VALVE IN ORDER TO MAKE EVAP SYSTEM CLOSE UNDER THE FOLLOWING CONDITIONS.</p> <ul style="list-style-type: none"> ● IGN SW ON ● ENGINE NOT RUNNING ● AMBIENT TEMPERATURE IS ABOVE 0°C (32°F). ● NO VACUUM AND NO HIGH PRESSURE IN EVAP SYSTEM ● FUEL TANK TEMP. IS MORE THAN 0°C (32°F). ● WITHIN 10 MINUTES AFTER STARTING “EVAP SYSTEM CLOSE” ● WHEN TRYING TO EXECUTE “EVAP SYSTEM CLOSE” UNDER THE CONDITION EXCEPT ABOVE, CONSULT-II WILL DISCONTINUE IT AND DISPLAY APPROPRIATE INSTRUCTION. <p>NOTE: WHEN STARTING ENGINE, CONSULT-II MAY DISPLAY “BATTERY VOLTAGE IS LOW. CHARGE BATTERY”, EVEN IN USING CHARGED BATTERY.</p>	When detecting EVAP vapor leak point of EVAP system
TARGET IDLE RPM ADJ*	<p>SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS.</p> <ul style="list-style-type: none"> ● ENGINE WARMED UP ● NO-LOAD 	When adjusting initial ignition timing and idle speed

*: This function is not necessary in the usual service procedure.

SELF-DIAGNOSTIC MODE

Self Diagnostic Item

Regarding items of “DTC and 1st trip DTC”, refer to “INDEX for DTC” (See [EC-576](#).)

Freeze Frame Data and 1st Trip Freeze Frame Data

Freeze frame data item *1	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> ● The engine control component part/control system has a trouble code, it is displayed as “PXXXX”. (Refer to EC-576. “INDEX FOR DTC” .)
FUEL SYS-B1 *2	<ul style="list-style-type: none"> ● “Fuel injection system status” at the moment a malfunction is detected is displayed.
FUEL SYS-B2 *2	<ul style="list-style-type: none"> ● One mode in the following is displayed. “MODE 2”: Open loop due to detected system malfunction “MODE 3”: Open loop due to driving conditions (power enrichment, deceleration enrichment) “MODE 4”: Closed loop - using oxygen sensor(s) as feedback for fuel control “MODE 5”: Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	<ul style="list-style-type: none"> ● The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> ● The engine coolant temperature at the moment a malfunction is detected is displayed.
S-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● “Short-term fuel trim” at the moment a malfunction is detected is displayed.
S-FUEL TRIM-B2 [%]	<ul style="list-style-type: none"> ● The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
L-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● “Long-term fuel trim” at the moment a malfunction is detected is displayed.
L-FUEL TRIM-B2 [%]	<ul style="list-style-type: none"> ● The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> ● The engine speed at the moment a malfunction is detected is displayed.
VHCL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> ● The vehicle speed at the moment a malfunction is detected is displayed.
ABSOL TH-P/S [%]	<ul style="list-style-type: none"> ● The throttle valve opening angle at the moment a malfunction is detected is displayed.

TROUBLE DIAGNOSIS

[VG33E]

Freeze frame data item *1	Description
B/FUEL SCHDL [msec]	<ul style="list-style-type: none"> The base fuel schedule at the moment a malfunction is detected is displayed.
INT/A TEMP SE [°C] or [°F]	<ul style="list-style-type: none"> The intake air temperature at the moment a malfunction is detected is displayed.

*1: The items are the same as those of 1st trip freeze frame data.

*2: Regarding WD22 model, "-B1" indicates right bank and "-B2" indicates left bank.

DATA MONITOR MODE

Monitored Item

x: Applicable

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks
ENG SPEED [rpm]	X	X	<ul style="list-style-type: none"> Indicates the engine speed computed from the REF signal (120° signal) of the camshaft position sensor. 	
MAS A/F SE-B1 [V]	X	X	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
B/FUEL SCHDL [msec]		X	<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	
A/F ALPHA-B1 [%]		X	<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control.
A/F ALPHA-B2 [%]		X		
COOLAN TEMP/S [°C] or [°F]	X	X	<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
HO2S1 (B1) [V]	X	X	<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 1 is displayed. 	
HO2S1 (B2) [V]	X	X		
HO2S2 (B1) [V]	X	X	<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 2 is displayed. 	
HO2S2 (B2) [V]	X	X		
HO2S1 MNTR (B1) [RICH/LEAN]	X		<ul style="list-style-type: none"> Display of heated oxygen sensor 1 signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. 	<ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously.
HO2S1 MNTR (B2) [RICH/LEAN]	X			
HO2S2 MNTR (B1) [RICH/LEAN]	X		<ul style="list-style-type: none"> Display of heated oxygen sensor 2 signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
HO2S2 MNTR (B2) [RICH/LEAN]	X			
VHCL SPEED SE [km/h] or [mph]	X	X	<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed sensor signal is displayed. 	
BATTERY VOLT [V]	X	X	<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 	
THRTL POS SEN [V]	X	X	<ul style="list-style-type: none"> The throttle position sensor signal voltage is displayed. 	

TROUBLE DIAGNOSIS

[VG33E]

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks
FUEL T/TMP SE [°C] or [°F]	X		<ul style="list-style-type: none"> The fuel temperature judged from the fuel tank temperature sensor signal voltage is displayed. 	
INT/A TEMP SE [°C] or [°F]	X	X	<ul style="list-style-type: none"> The intake air temperature determined by the signal voltage of the intake air temperature sensor is indicated. 	
EVAP SYS PRES [V]			<ul style="list-style-type: none"> The signal voltage of EVAP control system pressure sensor is displayed. 	
EGR TEMP SEN [V]	×	×	<ul style="list-style-type: none"> The signal voltage of the EGR temperature sensor is displayed. 	
FUEL LEVEL SE [V]	X		<ul style="list-style-type: none"> The signal voltage of the fuel level sensor is displayed. 	
START SIGNAL [ON/OFF]	X	X	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the starter signal. 	<ul style="list-style-type: none"> After starting the engine, [OFF] is displayed regardless of the starter signal.
CLSD THL POS [ON/OFF]	X	X	<ul style="list-style-type: none"> Indicates idle position [ON/OFF] computed by ECM according to the throttle position sensor signal. 	
CLSD THL/P SW [ON/OFF]	X		<ul style="list-style-type: none"> Indicates mechanical contact [ON/OFF] condition of the closed throttle position switch. 	
AIR COND SIG [ON/OFF]	X	X	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal. 	
P/N POSI SW [ON/OFF]	X	X	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal. 	
PW/ST SIGNAL [ON/OFF]	X	X	<ul style="list-style-type: none"> [ON/OFF] condition of the power steering oil pressure switch determined by the power steering oil pressure signal is indicated. 	
AMB TEMP SW [ON/OFF]	X		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the ambient air temperature switch signal. 	
IGNITION SW [ON/OFF]	X		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from ignition switch. 	
INJ PULSE-B1 [msec]		X	<ul style="list-style-type: none"> Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain computed value is indicated.
INJ PULSE-B2 [msec]				
IGN TIMING [BTDC]		X	<ul style="list-style-type: none"> Indicates the ignition timing computed by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
CAL/LD VALUE [%]			<ul style="list-style-type: none"> "Calculated load value" indicates the value of the current airflow divided by peak airflow. 	
ABSOL TH-P/S [%]			<ul style="list-style-type: none"> "Absolute throttle position sensor" indicates the throttle opening computed by ECM according to the signal voltage of the throttle position sensor. 	
MASS AIRFLOW [g·m/s]			<ul style="list-style-type: none"> Indicates the mass airflow computed by ECM according to the signal voltage of the mass airflow sensor. 	
IACV-AAC/V [%]		X	<ul style="list-style-type: none"> Indicates the IACV-AAC valve control value computed by ECM according to the input signals. 	

TROUBLE DIAGNOSIS

[VG33E]

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks	
PURG VOL C/V [%]			<ul style="list-style-type: none"> Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals. The opening becomes larger as the value increases. 		A EC C
AIR COND RLY [ON/OFF]		X	<ul style="list-style-type: none"> The air conditioner relay control condition (determined by ECM according to the input signal) is indicated. 		D
EGRC SOL/V [ON/OFF] (FLOW/CUT)		×	<ul style="list-style-type: none"> Indicates the control condition of the EGRC-solenoid valve determined by ECM according to the input signals. ON ... EGR valve is operational OFF ... EGR valve operation is cut-off 		E
FUEL PUMP RLY [ON/OFF]		X	<ul style="list-style-type: none"> Indicates the fuel pump relay control condition determined by ECM according to the input signals. 		F
VENT CONT/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the EVAP canister vent control valve (determined by ECM according to the input signal) is indicated. ON ... Closed OFF ... Open 		G H
VC/V BYPASS/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the vacuum cut valve bypass valve (determined by ECM according to the input signal) is indicated. ON ... Open OFF ... Closed 		I J
HO2S1 HTR (B1) [ON/OFF]			<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 1 heater determined by ECM according to the input signals. 		K
HO2S1 HTR (B2) [ON/OFF]					
HO2S2 HTR (B1) [ON/OFF]			<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to the input signals. 		L
HO2S2 HTR (B2) [ON/OFF]					
VOLTAGE [V]			<ul style="list-style-type: none"> Voltage measured by the voltage probe. 		M
FREQUENCY [msec] or [Hz] or [%]			<ul style="list-style-type: none"> Pulse width, frequency or duty cycle measured by the pulse probe. 	<ul style="list-style-type: none"> Only “#” is displayed if item is unable to be measured. Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured. 	

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.
- Regarding WD22 model, “B1” indicates bank 1 and “B2” indicates bank 2.

TROUBLE DIAGNOSIS

[VG33E]

DATA MONITOR (SPEC) MODE

Monitored Items

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks
MAS A/F SE-B1 [V]	X	X	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor specification is displayed. 	<ul style="list-style-type: none"> When the engine is running, specification range is indicated.
B/FUEL SCHDL [msec]		X	<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	<ul style="list-style-type: none"> When the engine is running, specification range is indicated.
A/F ALPHA-B1 [%]		X	<ul style="list-style-type: none"> Indicates the mean value of the air-fuel ratio feedback correction factor per cycle. 	<ul style="list-style-type: none"> When the engine is running, specification range is indicated. This data also includes the data for the air-fuel ratio learning control.
A/F ALPHA-B2 [%]		X		

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.
- Regarding WD22 model, "B1" indicates bank 1 and "B2" indicates bank 2.

ACTIVE TEST MODE

Test Item

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Fuel injectors Heated oxygen sensor 1
IGNITION TIMING	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Adjust initial ignition timing
IACV-AAC/V OPENING	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. Change the IACV-AAC valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> Harness and connector IACV-AAC valve
POWER BALANCE	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. A/C switch "OFF" Shift lever "N" Cut off each injector signal one at a time using CONSULT-II. 	Engine runs rough or dies.	<ul style="list-style-type: none"> Harness and connector Compression Injectors Power transistor Spark plugs Ignition coils
ENG COOLANT TEMP	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the engine coolant temperature using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Engine coolant temperature sensor Fuel injectors
FUEL PUMP RELAY	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the fuel pump relay "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> Harness and connector Fuel pump relay
EGRC SOLENOID VALVE	<ul style="list-style-type: none"> Ignition switch: ON Turn EGRC-solenoid valve "ON" and "OFF" using CONSULT-II and listen to operating sound. 	EGRC-solenoid valve makes an operating sound.	<ul style="list-style-type: none"> Harness and connector EGRC-solenoid valve

TROUBLE DIAGNOSIS

[VG33E]

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
PURG VOL CONT/V	<ul style="list-style-type: none"> ● Engine: After warming up, run engine at 1,500 rpm. ● Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve
FUEL/T TEMP SEN	<ul style="list-style-type: none"> ● Change the fuel tank temperature using CONSULT-II. 		
VENT CONTROL/V	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn solenoid valve "ON" and "OFF" with the CONSULT-II and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve
VC/V BYPASS/V	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn solenoid valve "ON" and "OFF" with the CONSULT-II and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve

DTC & SRT CONFIRMATION MODE

SRT STATUS Mode

For details, refer to "SYSTEM READINESS TEST (SRT) CODE", [EC-615, "SYSTEM READINESS TEST \(SRT\) CODE"](#).

SRT Work Support Mode

This mode enables a technician to drive a vehicle to set the SRT while monitoring the SRT status.

DTC Work Support Mode

Test mode	Test item	Condition	Reference page
EVAP SYSTEM	EVAP SML LEAK P0442/P1442	Refer to corresponding trouble diagnosis for DTC.	EC-901/EC-1059
	EVAP V/S LEAK P0456/P1456		EC-950/EC-1084
	PURG VOL CN/V P1444		EC-1061
	PURGE FLOW P0441		EC-893
	VC CUT/V BP/V P1491		EC-1103
HO2S1	HO2S1 (B1) P0134		EC-780
	HO2S1 (B1) P1143		EC-998
	HO2S1 (B1) P1144		EC-1005
	HO2S1 (B1) P0133		EC-767
	HO2S1 (B2) P0154		EC-780
	HO2S1 (B2) P1163		EC-998
	HO2S1 (B2) P1164		EC-1005
HO2S2	HO2S1 (B2) P0153		EC-767
	HO2S2 (B1) P1146		EC-1012
	HO2S2 (B1) P1147		EC-1023
	HO2S2 (B1) P0139	EC-800	
	HO2S2 (B2) P1166	EC-1012	
	HO2S2 (B2) P1167	EC-1023	
EGR SYSTEM	HO2S2 (B2) P0159	EC-800	
	EGR SYSTEM P0400	EC-866	
	EGR-BPT/ LV P0402	EC-875	
	EGR SYSTEM P1402	EC-1051	

REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

Description

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

1. "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT-II screen in real time.



In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM.

At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at left, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed. The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.

2. "MANU TRIG" (Manual trigger):

- DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.

DATA MONITOR can be performed continuously even though a malfunction is detected.



Operation

1. "AUTO TRIG"


- While trying to detect the DTC/1st trip DTC by performing the "DTC Confirmation Procedure", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.

- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent.

When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC Confirmation Procedure", the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .)

2. "MANU TRIG"


- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.



Generic Scan Tool (GST) Function DESCRIPTION

UBS007VI

Generic Scan Tool (OBDII scan tool) complying with SAE J1978 has 7 different functions explained on the next page. ISO9141 is used as the protocol. The name "GST" or "Generic Scan Tool" is used in this service manual.



FUNCTION

	Diagnostic test mode	Function
MODE 1	READINESS TESTS	This mode gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.
MODE 2	(FREEZE DATA)	This mode gains access to emission-related data value which were stored by ECM during the freeze frame. [For details, refer to "Freeze Frame Data" (EC-670).]
MODE 3	DTCs	This mode gains access to emission-related power train trouble codes which were stored by ECM.


TROUBLE DIAGNOSIS

[VG33E]

Diagnostic test mode		Function
MODE 4	CLEAR DIAG INFO	<p>This mode can clear all emission-related diagnostic information. This includes:</p> <ul style="list-style-type: none"> ● Clear number of diagnostic trouble codes (MODE 1) ● Clear diagnostic trouble codes (MODE 3) ● Clear trouble code for freeze frame data (MODE 1) ● Clear freeze frame data (MODE 2) ● Reset status of system monitoring test (MODE 1) ● Clear on board monitoring test results (MODE 6 and 7)
MODE 6	(ON BOARD TESTS)	This mode accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored.
MODE 7	(ON BOARD TESTS)	This mode enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions.
MODE 8	—	<p>This mode can close EVAP system in ignition switch "ON" position (Engine stopped). When this mode is performed, the following parts can be opened or closed.</p> <ul style="list-style-type: none"> ● EVAP canister vent control valve open ● Vacuum cut valve bypass valve closed <p>In the following conditions, this mode cannot function.</p> <ul style="list-style-type: none"> ● Low ambient temperature ● Low battery voltage ● Engine running ● Ignition switch OFF ● Low fuel temperature ● Too much pressure is applied to EVAP system
MODE 9	CALIBRATION ID	This mode is to enable the off-board to request vehicle specific vehicle information such as Vehicle Identification Number (VIN) and calibration IDs.


GST INSPECTION PROCEDURE

1. Turn ignition switch OFF.
2. Connect "GST" to data link connector which is located under LH dash panel near the fuse box cover.




3. Turn ignition switch ON.
4. Enter the program according to instruction on the screen or in the operation manual.

(*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.

For further information, see the GST Operation Manual of the tool maker.



CONSULT-II Reference Value in Data Monitor Mode

UBS007VJ

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.

i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION		SPECIFICATION
ENG SPEED	● Run engine and compare CONSULT-II value with the tachometer indication.		Almost the same speed as the tachometer indication.
MAS A/F SE-B1	● Engine: After warming up	Idle	1.0 - 1.7V
	● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	2,500 rpm	1.7 - 2.3V
COOLAN TEMP/S	● Engine: After warming up		More than 70°C (158°F)
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)			LEAN ↔ RICH Changes more than 5 times during 10 seconds.
HO2S2 (B1) HO2S2 (B2)	● Warm-up condition ● After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load.	Revving engine from idle up to 3,000 rpm quickly	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)			LEAN ↔ RICH
VHCL SPEED SE	● Turn drive wheels and compare CONSULT-II value with the speedometer indication.		Almost the same speed as the speedometer indication
BATTERY VOLT	● Ignition switch: ON (Engine stopped)		11 - 14V
THRTL POS SEN	● Engine: After warming up, idle the engine	Throttle valve: fully closed (a)	0.15 - 0.85V
	● Engine: After warming up ● Ignition switch: ON (Engine stopped)	Throttle valve: Partially open	Between (a) and (b)
		Throttle valve: fully opened (b)	3.5 - 4.7V
EGR TEMP SEN	● Engine: After warming up		Less than 4.5V
START SIGNAL	● Ignition switch: ON → START → ON		OFF → ON → OFF
CLSD THL POS CLSD THL/P SW	● Engine: After warming up, idle the engine	Throttle valve: Idle position	ON
		Throttle valve: Slightly open	OFF
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates.)	ON
P/N POSI SW	● Ignition switch: ON	Shift lever: "P" or "N"	ON
		Except above	OFF

TROUBLE DIAGNOSIS

[VG33E]

MONITOR ITEM	CONDITION	SPECIFICATION
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel in neutral position (forward direction) OFF
		The steering wheel is turned ON
AMB TEMP SW	● Ignition switch: ON	Below 19°C (66°F) OFF
	● Compare ambient air temperature with the following:	Above 25°C (77°F) ON
IGNITION SW	● Ignition switch: ON → OFF → ON	ON → OFF → ON
INJ PULSE-B1 INJ PULSE-B2	● Engine: After warming up	Idle 2.4 - 3.7 msec
	● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	2,000 rpm 1.9 - 3.3 msec
B/FUEL SCHDL	● Engine: After warming up	Idle 1.0 - 1.6 msec
	● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	2,000 rpm 0.7 - 1.4 msec
IGN TIMING	● Engine: After warming up	Idle 10°±2° BTDC
	● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	2,000 rpm More than 25° BTDC
IACV-AAC/V	● Engine: After warming up	Idle 10 - 20%
	● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	2,000 rpm —
PURG VOL C/V	● Engine: After warming up	Idle 0%
	● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	2,000 rpm —
A/F ALPHA-B1 A/F ALPHA-B2	● Engine: After warming up	Maintaining engine speed at 2,000 rpm 54 - 155%
EVAP SYS PRES	● Ignition switch: ON	1.8 – 4.8V
AIR COND RLY	● Air conditioner switch: OFF → ON	OFF → ON
FUEL PUMP RLY	● Ignition switch is turned to ON (Operates for 5 seconds) ● Engine running and cranking	ON
	Except as shown above	OFF
EGRC SOL/V	● Engine: After warming up	Idle OFF
	● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	Engine speed: Revving engine from idle to 3,000 rpm quickly. ON
VENT CONT/V	● Ignition switch: ON	OFF
HO2S1 HTR (B1) HO2S1 HTR (B2)	● Engine speed: Below 2,800 rpm	ON
	● Engine speed: Above 2,800 rpm	OFF
HO2S2 HTR (B1) HO2S2 HTR (B2)	● Engine speed: Below 3,600 rpm after the following conditions are met. ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load.	ON
	● Engine speed: Above 3,600 rpm	OFF
VC/V BYPASS/V	Ignition switch: ON	OFF

TROUBLE DIAGNOSIS

[VG33E]

MONITOR ITEM	CONDITION	SPECIFICATION	
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF 	Idle	18.5 - 26.0%
	<ul style="list-style-type: none"> ● Shift lever: "N" ● No-load 	2,500 rpm	18.0 - 21.0%
ABSOL TH-P/S	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON ● More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. 	Throttle valve: fully closed	0.0%
	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) 	Throttle valve: fully opened	Approx. 80%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF 	Idle	3.3 - 4.8 g·m/s
	<ul style="list-style-type: none"> ● Shift lever: "N" ● No-load 	2,500 rpm	12.0 - 14.9 g·m/s

Major Sensor Reference Graph in Data Monitor Mode


UBS007VK

The following are the major sensor reference graphs in "DATA MONITOR" mode.

THRTL POS SEN, ABSOL TH-P/S, CLSD THL POS

Below is the data for "THRTL POS SEN", "ABSOL TH-P/S" and "CLSD THL POS" when depressing the accelerator pedal with the ignition switch ON.

The signal of "THRTL POS SEN" and "ABSOL TH-P/S" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".




ENG SPEED, MAS A/F SE-B1, THRTL POS SEN, HO2S2 (B1), HO2S1 (B1), INJ PULSE-B1

Below is the data for "ENG SPEED", "MAS A/F SE-B1", "THRTL POS SEN", "HO2S2 (B1)", "HO2S1 (B1)" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently.


TROUBLE DIAGNOSIS

[VG33E]


Each value is for reference, the exact value may vary.




A
EC
C
D
E
F
G
H
I
J
K
L
M




- "THRTL POS SEN" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "HO2S1 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

PFP:00031

Description

UBS007VL

The specification (SP) value indicates the tolerance of the value that is displayed in “DATA MONITOR (SPEC)” mode of CONSULT-II during normal operation of the Engine Control System. When the value in “DATA MONITOR (SPEC)” mode is within the SP value, the Engine Control System is confirmed OK. When the value in “DATA MONITOR (SPEC)” mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MIL.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1/B2 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Testing Condition

UBS007VM

- Vehicle driven distance: More than 5,000 km (3,107 miles)
- Barometric pressure: 101.3 kPa (760.0 mmHg, 29.92 inHg)±3 kPa (22.5 mmHg, 0.89 inHg)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Transmission: Warmed-up*1
- Electrical load: Not applied*2
- Engine speed: Idle

*1: For A/T models, after the engine is warmed up to normal operating temperature, drive vehicle until “FLUID TEMP SE” (A/T fluid temperature sensor signal) indicates less than 0.9V. For M/T models, drive vehicle for 5 minutes after the engine is warmed up to normal operating temperature.

*2: Rear window defogger switch, air conditioner switch, lighting switch are “OFF”. Steering wheel is straight ahead.


Inspection Procedure

UBS007VN


NOTE:

Perform “DATA MONITOR (SPEC)” mode in maximum scale display.

1. Perform [EC-637, "Basic Inspection"](#) .
2. Confirm that the testing conditions indicated above are met.
3. Select “B/FUEL SCHDL”, “A/F ALPHA-B1”, “A/F ALPHA-B2” and “MAS A/F SE-B1” in “DATA MONITOR (SPEC)” mode with CONSULT-II.
4. Make sure that monitor items are within the SP value.
5. If NG, go to [EC-685, "Diagnostic Procedure"](#) .



Diagnostic Procedure




(Go to next page.)


SEF6132B

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[VG33E]



SEF768Z



A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT**Description**

UBS007VP

Intermittent incidents (I/I) may occur. In many cases, the malfunction resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific malfunction area.

Common I/I Report Situations

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "[1t]".
III	The symptom described by the customer does not recur.
IV	(1st trip) DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for PXXXX does not indicate the malfunction area.

Diagnostic Procedure

UBS007VQ

1. INSPECTION START

Erase (1st trip) DTCs. Refer to [EC-623, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

>> GO TO 2.

2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection.
Refer to [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).

OK or NG

OK >> GO TO 3.
NG >> Repair or replace.

3. SEARCH FOR ELECTRICAL INCIDENT

Perform [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).

OK or NG

OK >> GO TO 4.
NG >> Repair or replace.

4. CHECK CONNECTOR TERMINALS

Refer to [GI-22, "How to Check Terminal"](#).

OK or NG

OK >> **INSPECTION END.**
NG >> Repair or replace connector.

POWER SUPPLY CIRCUIT FOR ECM

[VG33E]

POWER SUPPLY CIRCUIT FOR ECM




PF:24110

Wiring Diagram



UBS007VR

EC-MAIN-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



Refer to the following.
 (E43) - SUPER MULTIPLE JUNCTION (SMJ)



POWER SUPPLY CIRCUIT FOR ECM

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
4	OR/B	ECM relay (Self-shutoff)	[Engine is running] [Ignition switch OFF] ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			[Ignition switch OFF] ● A few seconds passed after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
10	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
19	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
24	W/L	Ignition switch	[Ignition switch OFF]	0V
			[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
25	B/Y	ECM ground	[Engine is running] ● Idle speed	Engine ground
32	B/Y	ECM ground	[Engine is running] ● Idle speed	Engine ground
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P			
80	SB	Power supply (Back-up)	[Ignition switch OFF]	BATTERY VOLTAGE (11 - 14V)
116	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
117	B/P	Current return	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)
124	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground

Diagnostic Procedure

UBS007VS

1. INSPECTION START

Start engine.

Is engine running?

Yes or No

Yes >> GO TO 6.

No >> GO TO 2.


2. CHECK ECM POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF and then ON.
2. Check voltage between ECM terminal 24 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M59, F27
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair harness or connectors.

4. CHECK ECM GROUND CIRCUIT-I FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 10, 19, 25, 32, 116, 124 and engine ground. Refer to WIRING DIAGRAM.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 15.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open between ECM and engine ground

>> Repair open circuit or short to power in harness or connectors.


6. CHECK ECM POWER SUPPLY CIRCUIT-II

1. Stop engine.
2. Check voltage between ECM terminal 80 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.



7. DETECT MALFUNCTIONING PART

Check the following.


- Harness connectors M81, F36
- Fuse block (J/B) connector M27
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair harness or connectors.

8. CHECK ECM POWER SUPPLY CIRCUIT-III

1. Turn ignition switch ON and then OFF.
2. Check voltage between ECM terminals 67, 72, 117 and ground with CONSULT-II or tester.

Voltage : After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop to approximately 0V.




OK or NG

- OK >> GO TO 14.
- NG (Battery voltage does not exist.)>>GO TO 9.
- NG (Battery voltage exists for more than a few seconds.)>>GO TO 13.

9. CHECK ECM POWER SUPPLY CIRCUIT-IV

1. Disconnect ECM relay.




2. Check voltage between terminals 2, 5 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 11.
- NG >> GO TO 10.



10. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and harness connectors M59, F27

>> Repair open circuit or short to ground or short to power in harness or connectors.

11. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 4 and ECM relay terminal 1. Refer to WIRING DIAGRAM.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 12.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

12. CHECK HARNESS CONTINUITY BETWEEN ECM RELAY AND ECM FOR OPEN AND SHORT

1. Check harness continuity between ECM terminals 67, 72, 117 and ECM relay terminal 3. Refer to WIRING DIAGRAM.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 13.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.


13. CHECK ECM RELAY

1. Apply 12V direct current between relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5.

12V (1 - 2) applied : Continuity exists.
No voltage applied : No continuity

OK or NG

- OK >> GO TO 14.
 NG >> Replace ECM relay.



14. CHECK ECM GROUND CIRCUIT-II FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 10, 19, 25, 32, 116, 124 and engine ground. Refer to WIRING DIAGRAM.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 15.
 NG >> GO TO 5.

15. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER

[VG33E]

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER

PF2:22690

Description SYSTEM DESCRIPTION

UBS007VT

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heaters

The ECM performs ON/OFF control of the heated oxygen sensor 1 heaters corresponding to the engine speed.

OPERATION

Engine speed rpm	Heated oxygen sensor 1 heaters
Above 2,800	OFF
Below 2,800	ON

CONSULT-II Reference Value in Data Monitor Mode

UBS007VU

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1)	● Engine speed: Below 2,800 rpm	ON
HO2S1 HTR (B2)	● Engine speed: Above 2,800 rpm	OFF

On Board Diagnosis Logic

UBS007VV

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0031 (Bank 1)	Heated oxygen sensor 1 heater control circuit low	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 1 heater circuit is open or shorted.) ● Heater oxygen sensor 1 heater
P0051 (Bank 2)			
P0032 (Bank 1)	Heated oxygen sensor 1 heater control circuit high	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 1 heater circuit is shorted.) ● Heater oxygen sensor 1 heater
P0052 (Bank 2)			

DTC Confirmation Procedure

UBS007VW

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

 **WITH CONSULT-II**

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 6 seconds at idle speed.
3. If 1st trip DTC is detected, go to [EC-700, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **WITH GST**

1. Start engine and run it for at least 6 seconds at idle speed.
 2. Turn ignition switch OFF, wait at least 5 seconds and then turn ON.
 3. Start engine and run it for at 6 seconds at idle speed.
 4. Select "MODE 3" with GST.
 5. If DTC is detected, go to [EC-700, "Diagnostic Procedure"](#).
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER






[VG33E]

UBS007VX

Wiring Diagram BANK 1

EC-O2H1B1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P0031, P0032, P0051, P0052 HO2S1 HEATER

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
119	BR/Y	Heated oxygen sensor 1 heater (bank 1)	[Engine is running] ● Engine speed is below 2,800 rpm	Approximately 0.4V
			[Engine is running] ● Engine speed is above 2,800 rpm	BATTERY VOLTAGE (11 - 14V)
121	BR	Heated oxygen sensor 1 heater (bank 2)	[Engine is running] ● Engine speed is below 2,800 rpm	Approximately 0.4V
			[Engine is running] ● Engine speed is above 2,800 rpm	BATTERY VOLTAGE (11 - 14V)

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER





[VG33E]

BANK 2

EC-O2H1B2-01



A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P0031, P0032, P0051, P0052 HO2S1 HEATER

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
119	BR/Y	Heated oxygen sensor 1 heater (bank 1)	[Engine is running] ● Engine speed is below 2,800 rpm	Approximately 0.4V
			[Engine is running] ● Engine speed is above 2,800 rpm	BATTERY VOLTAGE (11 - 14V)
121	BR	Heated oxygen sensor 1 heater (bank 2)	[Engine is running] ● Engine speed is below 2,800 rpm	Approximately 0.4V
			[Engine is running] ● Engine speed is above 2,800 rpm	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


UBS007VY

1. CHECK HO2S1 POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check heated oxygen sensor 1 harness protector.



3. Disconnect corresponding heated oxygen sensor 1 harness connector.
4. Turn ignition switch ON.




5. Check voltage between HO2S1 terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- Fuse block (J/B) connector M26
- 10A fuse
- Harness for open or short between heated oxygen sensor 1 and fuse

>> Repair harness or connectors.

3. CHECK HO2S1 HEATER OUTPUT CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0031	119	3	Bank 1
P0051	121	3	Bank 2

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-701, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace malfunctioning heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1 HEATER

UBS007VZ


1. Check resistance between HO2S1 terminals 3 and 1.
Resistance : 2.3 - 4.3Ω at 25°C (77°F)
2. Check continuity between HO2S1 terminals 2 and 1, 3 and 2.

Continuity should not exist.

3. If NG, replace heated oxygen sensor 1.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



-
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation
HEATED OXYGEN SENSOR 1

UBS007W0

Refer to [EM-78. "OUTER COMPONENT PARTS"](#) .

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VG33E]

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

PF0:226A0

Description SYSTEM DESCRIPTION

UBS007W1

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heaters

The ECM performs ON/OFF control of the heated oxygen sensor 2 heaters corresponding to the engine speed.

OPERATION

Engine speed rpm	Heated oxygen sensor 2 heater
Above 3,600	OFF
Below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	ON

CONSULT-II Reference Value in Data Monitor Mode

UBS007W2

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none"> ● Engine speed: Below 3,600 rpm after the following conditions are met. ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,600 rpm 	OFF

On Board Diagnosis Logic

UBS007W3

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0037 (Bank 1) P0057 (Bank 2)	Heated oxygen sensor 2 heater control circuit low	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 2 heater circuit is open or shorted.) ● Heater oxygen sensor 2 heater
P0038 (Bank 1) P0058 (Bank 2)	Heated oxygen sensor 2 heater control circuit high	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 2 heater circuit is shorted.) ● Heater oxygen sensor 2 heater

DTC Confirmation Procedure

UBS007W4

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

CONSULT-II WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed at between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minute.
6. If 1st trip DTC is detected, go to [EC-709, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

GST WITH GST

1. Turn ignition switch "OFF" and wait at least 10 seconds.
 2. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
 3. Let engine idle for one minute.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
 6. Let engine idle for one minute.
 7. Select "MODE 3" with GST.
 8. If DTC is detected, go to [EC-709, "Diagnostic Procedure"](#) .
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER





[VG33E]

UBS007W5

Wiring Diagram BANK 1

EC-O2H2B1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
122	R/B	Heated oxygen sensor 2 heater (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm after the following conditions are met. – Engine: After warming up – Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - 1.0V
			[Ignition switch ON] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm 	BATTERY VOLTAGE (11 - 14V)

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VG33E]




BANK 2

EC-O2H2B2-01



: Detectable line for DTC
 : Non-detectable line for DTC

A
EC
C
D
E
F
G
H
I
J
K
L
M



WBWA0027E

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
123	R/Y	Heated oxygen sensor 2 heater (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm after the following conditions are met. – Engine: After warming up – Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - 1.0V
			[Ignition switch ON] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm 	BATTERY VOLTAGE (11 - 14V)


Diagnostic Procedure

1. CHECK HO2S2 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 2 harness protector color.



3. Disconnect corresponding heated oxygen sensor 2 harness connector.
4. Turn ignition switch ON.




5. Check voltage between HO2S2 terminal 3 and ground.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- Fuse block (J/B) connector M26
- 10A fuse
- Harness for open or short between heated oxygen sensor 2 and fuse

>> Repair harness or connectors.

3. CHECK HO2S2 HEATER OUTPUT CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0037, P0038	122	2	Bank 1
P0057, P0058	123	2	Bank 2

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Joint connector-3
- Harness for open or short between heated oxygen sensor 2 and engine ground.

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2 HEATER

Refer to [EC-711, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace malfunctioning heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT


Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection
HEATED OXYGEN SENSOR 2 HEATER

1. Check resistance between HO2S2 terminals 2 and 3.

Resistance : 2.3 - 4.3Ω at 25°C (77°F)



2. Check continuity.

Terminal No.	Continuity
1 and 2, 3, 4	No
4 and 1, 2, 3	

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation
HEATED OXYGEN SENSOR 2


Refer to [EX-3, "EXHAUST SYSTEM"](#) .

DTC P0101 MAF SENSOR

Component Description

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.

UBS007W9



CONSULT-II Reference Value in Data Monitor Mode

UBS007WA

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	1.0 - 1.7V
		2,500 rpm	1.7 - 2.3V
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	18.5 - 26.0%
		2,500 rpm	18.0 - 21.0%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	3.3 - 4.8 g·m/s
		2,500 rpm	12.0 - 14.9 g·m/s

On Board Diagnosis Logic

UBS007WB

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0101	Mass air flow sensor circuit range/performance problem	A)	A high voltage from the sensor is sent to ECM under light load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor
		B)	A low voltage from the sensor is sent to ECM under heavy load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor

DTC Confirmation Procedure

UBS007WC

Perform "PROCEDURE FOR MALFUNCTION A" first.

If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

NOTE:

If engine will not start or stops soon, wait at least 10 seconds with engine stopped (Ignition switch "ON") instead of running engine at idle speed.

With CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and warm it up to normal operating temperature.
4. Run engine for at least 10 seconds at idle speed.
5. If 1st trip DTC is detected, go to [EC-716, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

With GST

Follow the procedure "With CONSULT-II".


PROCEDURE FOR MALFUNCTION B

CAUTION:

Always drive vehicle at a safe speed.

With CONSULT-II

1. Turn ignition switch "ON".
2. Start engine and warm it up to normal operating temperature.
If engine cannot be started, go to [EC-716, "Diagnostic Procedure"](#) .
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Check the voltage of MAS AIR/FL SE with "DATA MONITOR".
5. Increases engine speed to about 4,000 rpm.
6. Monitor the linear voltage rise in response to engine speed increases.
If NG, go to [EC-716, "Diagnostic Procedure"](#) .
If OK, go to following step.



A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0101 MAF SENSOR

[VG33E]

7. Maintain the following conditions for at least 10 consecutive seconds.

ENG SPEED	More than 2,000 rpm
THRTL POS SEN	More than 3V
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V

SEF175Y

8. If 1st trip DTC is detected, go to [EC-716, "Diagnostic Procedure"](#)

Overall Function Check PROCEDURE FOR MALFUNCTION B

UBS007WD

Use this procedure to check the overall function of the mass air flow sensor circuit. During this check, a 1st trip DTC might not be confirmed.

With GST

1. Start engine and warm it up to normal operating temperature.
2. Select "MODE 1" with GST.
3. Check the mass air flow sensor signal with "MODE 1".
4. Check for linear mass air flow sensor signal value rise in response to increases to about 4,000 rpm in engine speed.
5. If NG, go to [EC-716, "Diagnostic Procedure"](#).

CALC LOAD	20%
COOLANT TEMP	95°C
SHORT FT #1	2%
LONG FT #1	0%
SHORT FT #2	4%
LONG FT #2	0%
ENGINE SPD	2637RPM
VEHICLE SPD	0MPH
IGN ADVANCE	41.0°
INTAKE AIR	41°C
MAF	14.1gm/sec
THROTTLE POS	3%

SEF534P


DTC P0101 MAF SENSOR

[VG33E]



UBS007WE

Wiring Diagram

EC-MAFS-01



A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M



BBWA0470E

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
54	R	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.0 - 1.7V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm	1.7 - 2.3V
55	G	Mass air flow sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS007WF

1. INSPECTION START

Which malfunction (A or B) is duplicated?

A or B

- A >> GO TO 3.
- B >> GO TO 2.

2. CHECK INTAKE SYSTEM

Check the following for connection.

- Air duct
- Vacuum hoses
- Intake air passage between air duct to intake manifold collector


OK or NG

- OK >> GO TO 3.
- NG >> Reconnect the parts.

3. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 4.



LEC518

4. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect mass air flow (MAF) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and mass air flow sensor
- Harness for open or short between mass air flow sensor and ECM

>> Repair harness or connectors.

6. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 3 and ECM terminal 55. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between MAF sensor terminal 4 and ECM terminal 54. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-718, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace mass air flow sensor.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component Inspection
MASS AIR FLOW SENSOR**


UBS007WG

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.0 - 1.7
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.7 - 2.3
Idle to about 4,000 rpm*	1.0 - 1.7 to Approx. 4.0

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

4. If the voltage is out of specification, proceed the following.
 - Turn ignition switch "OFF".
 - Disconnect mass air flow sensor harness connector and reconnect it again.
 - Perform step 2 and 3 again.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.
6. If NG, clean or replace mass air flow sensor.



SEF747U


DTC P0102, P0103 MAF SENSOR

PF2:22680

Component Description

UBS007WI

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

UBS007WJ

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	1.0 - 1.7V
		2,500 rpm	1.7 - 2.3V
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	18.5 - 26.0%
		2,500 rpm	18.0 - 21.0%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	3.3 - 4.8 g-m/s
		2,500 rpm	12.0 - 14.9 g-m/s

On Board Diagnosis Logic

UBS007WK

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM. This self-diagnosis has the one trip detection logic.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor
P0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

DTC Confirmation Procedure

UBS007WL

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR DTC P0102

With CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 5 seconds at most.
4. If DTC is detected, go to [EC-722, "Diagnostic Procedure"](#) .
If DTC is not detected, go to next step.
5. Start engine and let it idle for at least 6 seconds.
6. If DTC is detected, go to [EC-722, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II".

PROCEDURE FOR DTC P0103

With CONSULT-II

1. Turn ignition switch ON.
2. If 1st trip DTC is detected,
Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 6 seconds.
4. If 1st trip DTC is detected, go to [EC-722, "Diagnostic Procedure"](#) .
If 1st trip DTC is not detected, go to next step.
5. Start engine and let it idle for at least 6 seconds.
6. If 1st trip DTC is detected, go to [EC-722, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II".


DTC P0102, P0103 MAF SENSOR

[VG33E]






UBS007WM

Wiring Diagram

EC-MAFS-01



A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M



BBWA0470E

DTC P0102, P0103 MAF SENSOR

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
54	R	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.0 - 1.7V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm	1.7 - 2.3V
55	G	Mass air flow sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS007WN

1. INSPECTION START

Which malfunction (P0102 or P0103) is duplicated?

P0102 or P0103

P0102 >> GO TO 2.

P0103 >> GO TO 3.

2. CHECK INTAKE SYSTEM

Check the following for connection.

- Air duct
- Vacuum hoses
- Intake air passage between air duct to intake manifold collector

OK or NG


OK >> GO TO 3.

NG >> Reconnect the parts.

3. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.


>> GO TO 4.



LEC518

4. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect mass air flow sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and mass air flow sensor
- Harness for open or short between mass air flow sensor and ECM

>> Repair harness or connectors.

6. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 3 and ECM terminal 55. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 7.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between MAF sensor terminal 4 and ECM terminal 54. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-724, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace mass air flow sensor.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection MASS AIR FLOW SENSOR


UBS0090E

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.0 - 1.7
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.7 - 2.3
Idle to about 4,000 rpm*	1.0 - 1.7 to Approx. 4.0

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

4. If the voltage is out of specification, proceed the following.
 - Turn ignition switch "OFF".
 - Disconnect mass air flow sensor harness connector and reconnect it again.
 - Perform step 2 and 3 again.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.
6. If NG, clean or replace mass air flow sensor.




SEF747U

DTC P0112, P0113 IAT SENSOR

Component Description

The intake air temperature sensor is mounted to the air duct housing. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.




<Reference data>

Intake air temperature °C (°F)	Voltage* (V)	Resistance kΩ
20 (68)	3.5	2.1 - 2.9
80 (176)	1.23	0.27 - 0.38

*: These data are reference values and are measured between ECM terminal 61 (Intake air temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0112	Intake air temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air temperature sensor
P0113	Intake air temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	


DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-728. "Diagnostic Procedure"](#)





WITH GST

Follow the procedure "With CONSULT-II".


DTC P0112, P0113 IAT SENSOR

[VG33E]

UBS007WS

Wiring Diagram

EC-IATS-01




: Detectable line for DTC
 : Non-detectable line for DTC


EP : EARLY PRODUCTION
LP : LATE PRODUCTION

*1 EP : 22
*1 LP : 24

A
EC
C
D
E
F
G
H
I
J
K
L
M




Refer to the following.
E43 - SUPER MULTIPLE JUNCTION (SMJ)



WBWA0028E

Diagnostic Procedure**1. CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect intake air temperature sensor harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 1 and ground.

Voltage : **Approximately 5V**

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.

**2. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between ECM and intake air temperature sensor

>> Repair harness or connectors.

3. CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between intake air temperature sensor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between ECM and intake air temperature sensor

>> Repair open circuit or short to power in harness or connectors.

5. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-729, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace intake air temperature sensor.

6. CHECK INTERMITTENT INCIDENT


Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component Inspection
INTAKE AIR TEMPERATURE SENSOR**


Check resistance as shown in the figure.

UBS007WU



<Reference data>


Intake air temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38



DTC P0117, P0118 ECT SENSOR

Component Description


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 59 (Engine coolant temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Engine coolant temperature sensor
P0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC P0117, P0118 ECT SENSOR

[VG33E]

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned ON or Start	40°C (104°F)
	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)

DTC Confirmation Procedure

UBS007WY

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-733. "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

④ WITH GST

Follow the procedure "With CONSULT-II".



DTC P0117, P0118 ECT SENSOR

[VG33E]

UBS007WZ

Wiring Diagram

EC-ECTS-01




BBWA0472E

Diagnostic Procedure

1. CHECK ECT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect engine coolant temperature (ECT) sensor harness connector.
3. Turn ignition switch ON.




4. Check voltage between ECT sensor terminal 1 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM and engine coolant temperature sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between ECT sensor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM and engine coolant temperature sensor

>> Repair open circuit or short to power in harness or connectors.

5. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-734, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace engine coolant temperature sensor.

6. CHECK INTERMITTENT INCIDENT


Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component Inspection
ENGINE COOLANT TEMPERATURE SENSOR**

UBS007X1


Check resistance as shown in the figure.



SEF152P

<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260



SEF012P

**Removal and Installation
ENGINE COOLANT TEMPERATURE SENSOR**

UBS007X2

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

DTC P0121 TP SENSOR


Component Description

NOTE:

If DTC P0121 is displayed with DTC P0510, first perform the trouble diagnosis for DTC P0510. Refer to EC-983.

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit, is not used for engine control.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL POS SEN	● Engine: After warming up, idle the engine Throttle valve: fully closed (a)	0.15 - 0.85V
	● Engine: After warming up Throttle valve: Partially open	Between (a) and (b)
	● Ignition switch: ON (Engine stopped) Throttle valve: fully opened (b)	3.5 - 4.7V
ABSOL TH-P/S	● Engine: After warming up ● Ignition switch: ON ● More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. Throttle valve: fully closed	0.0%
	● Engine: After warming up ● Ignition switch: ON (Engine stopped) Throttle valve: fully opened	Approx. 80%

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0121	Throttle position sensor circuit range/performance problem	A)	A high voltage from the sensor is sent to ECM under light load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The TP sensor circuit is open or shorted.) ● TP sensor ● Fuel injector ● Camshaft position sensor ● Mass air flow sensor
		B)	A low voltage from the sensor is sent to ECM under heavy load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The TP sensor circuit is open or shorted.) ● Intake air leaks ● TP sensor

DTC Confirmation Procedure

NOTE:

- Perform “PROCEDURE FOR MALFUNCTION A” first. If the 1st trip DTC cannot be confirmed, perform “PROCEDURE FOR MALFUNCTION B”.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


PROCEDURE FOR MALFUNCTION A

④ With CONSULT-II

1. Turn ignition switch ON.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for at least 10 seconds.
If idle speed is over 1,000 rpm, maintain the following conditions for at least 10 seconds to keep engine speed below 1,000 rpm.

Selector lever	Suitable position except “P” or “N”
Brake pedal	Depressed
Vehicle speed	0 km/h (0 MPH)

4. If 1st trip DTC is detected, go to [EC-739, "Diagnostic Procedure"](#)



④ With GST

Follow the procedure “With CONSULT-II”.

PROCEDURE FOR MALFUNCTION B

CAUTION:

Always drive vehicle at a safe speed.

④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.
4. Select “MANU TRIG” in “DATA MONITOR” mode with CONSULT-II.


DTC P0121 TP SENSOR

[VG33E]

5. Select "THRTL POS SEN" and "ABSOL TH·P/S" in "DATA MONITOR" mode with CONSULT-II.
6. Press RECORD on CONSULT-II SCREEN at the same time accelerator pedal is depressed.
7. Print out the recorded graph and check the following:
 - The voltage rise is linear in response to accelerator pedal depression.
 - The voltage when accelerator pedal is fully depressed is approximately 4V.
 If NG, go to [EC-739, "Diagnostic Procedure"](#) .
 If OK, go to following step.

DATA MONITOR	
MONITOR	NO DTC
THRTL POS SEN	XXX V
ABSOL TH·P/S	XXX %

SEF177Y



8. Select "AUTO TRIG" in "DATA MONITOR" mode with CONSULT-II.
9. Maintain the following conditions for at least 10 consecutive seconds.

CMPS-RPM (REF)	More than 2,000 rpm
MAS AIR/FL SE	More than 3V
COOLAN TEMP/S	More than 70°C (158°F)
IACV-AAC/V	Less than 80%
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

DATA MONITOR	
MONITORING	NO DTC
ENG SPEED	XXX rpm
MAS AIR/FL SE	XXX V
COOLAN TEMP/S	XXX °C
IACV-AAC/V	XXX %

SEF805Z

10. If 1st trip DTC is detected, go to [EC-739, "Diagnostic Procedure"](#) .

With GST

Follow the procedure "With CONSULT-II".




DTC P0121 TP SENSOR

[VG33E]

UBS007X7

Wiring Diagram

EC-TPS-01



BBWA0473E

DTC P0121 TP SENSOR

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
23	L	Throttle position sensor	[Engine is running] ● Warm-up condition ● Accelerator pedal fully released	0.15 - 0.85V
			[Ignition switch ON] ● Accelerator pedal fully depressed	3.5 - 4.7V
42	B/W	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	BR	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS007X8

1. INSPECTION START

Which malfunction (A or B) is duplicated?

Type A or B

- A >> GO TO 4.
- B >> GO TO 2.

2. ADJUST THROTTLE POSITION SENSOR

Check the following items. Refer to [EC-637, "Basic Inspection"](#) .

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

>> GO TO 3.

3. CHECK INTAKE SYSTEM.

1. Turn ignition switch OFF.
2. Check the following for connection.
 - Air duct
 - Vacuum hoses
 - Intake air passage between air duct to intake manifold collector


OK or NG

- OK >> GO TO 4.
- NG >> Reconnect the parts.

4. RETIGHTEN GROUND SCREWS


1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 5.



5. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect throttle position sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between sensor terminal 3 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 6.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



6. CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between throttle position sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 8.
 NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the harness for open or short between ECM and throttle position sensor.

>> Repair open circuit or short to power in harness or connectors.

8. CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 23 and throttle position sensor terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK THROTTLE POSITION SENSOR

Refer to [EC-743, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.

10. ADJUST CLOSED THROTTLE POSITION SWITCH

Adjust closed throttle position switch. Refer to [EC-637, "Basic Inspection"](#) .

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

OK or NG

OK >> GO TO 11.

NG >> Replace throttle position sensor. To adjust it, perform [EC-637, "Basic Inspection"](#) .

11. CHECK MASS AIR FLOW SENSOR

Refer to [EC-718, "Component Inspection"](#) .



OK or NG

OK >> GO TO 12.


NG >> Replace mass air flow sensor.

12. CHECK CAMSHAFT POSITION SENSOR

1. Install any parts removed.
2. Start engine.
3. Check voltage between ECM terminals 44, 48 and ground, ECM terminal 49 and ground with DC range.
<Terminal 44 or 48 and engine ground>



<Terminal 49 and engine ground>



OK or NG

- OK >> GO TO 13.
- NG >> Replace distributor assembly with camshaft position sensor.


13. CHECK FUEL INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance : 10 - 14Ω [at 25°C (77°F)]

OK or NG

- OK >> GO TO 14.
- NG >> Replace fuel injector.



14. CHECK INTERMITTENT INCIDENT

Refer to [EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection
THROTTLE POSITION SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine (ignition switch OFF).
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Check voltage of "THRTL POS SEN" under the following conditions.

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	THRTL POS SEN
Completely closed (a)	0.15 - 0.85V
Partially open	Between (a) and (b)
Completely open (b)	3.5 - 4.7V

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
THRTL POS SEN	XXX V

SEF719Y

With GST

1. Start engine and warm it up to normal operating temperature.
2. Stop engine (ignition switch OFF).
3. Turn ignition switch ON.
4. Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground.
Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	Voltage [V]
Completely closed	0.15 - 0.85 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.7 (b)

A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0122, P0123 TP SENSOR

PF16119

Component Description


UBS007XB

NOTE:

If DTC P0122, P0123 is displayed with DTC P0510, first perform the trouble diagnosis for DTC P0510. Refer to EC-983.

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit, is not used for engine control.



CONSULT-II Reference Value in Data Monitor Mode

UBS007XC

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL POS SEN	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Throttle valve: fully closed (a) 0.15 - 0.85V
	<ul style="list-style-type: none"> Engine: After warming up Ignition switch: ON (Engine stopped) 	Throttle valve: Partially open Between (a) and (b)
	<ul style="list-style-type: none"> Engine: After warming up Ignition switch: ON (Engine stopped) 	Throttle valve: fully opened (b) 3.5 - 4.7V
ABSOL TH-P/S	<ul style="list-style-type: none"> Engine: After warming up Ignition switch: ON More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. 	Throttle valve: fully closed 0.0%
	<ul style="list-style-type: none"> Engine: After warming up Ignition switch: ON (Engine stopped) 	Throttle valve: fully opened Approx. 80%

On Board Diagnosis Logic

UBS007XD

These self-diagnoses have one trip detection logic.

DTC P0122, P0123 TP SENSOR

[VG33E]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0122	Throttle position sensor circuit low input	An excessively low voltage from the sensor is sent to ECM	<ul style="list-style-type: none"> ● Harness or connectors (The TP sensor circuit is open or shorted.) ● TP sensor
P0123	Throttle position sensor circuit high input	An excessively high voltage from the sensor is sent to ECM	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	
Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
	Condition	Driving condition
	When engine is idling	Normal
	When accelerating	Poor acceleration

DTC Confirmation Procedure

UBS007XE

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 10V at idle.
- This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and maintain the following conditions for at least 5 consecutive seconds.

Vehicle speed	More than 5 km/h (3 MPH)
Selector lever	Suitable position except "P" or "N" position

3. If 1st trip DTC is detected, go to [EC-747, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF

SEF065Y

WITH GST

Follow the procedure "With CONSULT-II".




DTC P0122, P0123 TP SENSOR

[VG33E]

UBS007XF

Wiring Diagram

EC-TPS-01



BBWA0473E

DTC P0122, P0123 TP SENSOR

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
23	L	Throttle position sensor	[Engine is running] ● Warm-up condition ● Accelerator pedal fully released	0.15 - 0.85V
			[Ignition switch ON] ● Accelerator pedal fully depressed	3.5 - 4.7V
42	B/W	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	BR	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V


Diagnostic Procedure

UBS007XG

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect throttle position sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between sensor terminal 3 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between throttle position sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the harness for open or short between ECM and throttle position sensor.

>> Repair open circuit or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 23 and throttle position sensor terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK THROTTLE POSITION SENSOR

Refer to [EC-743, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. ADJUST CLOSED THROTTLE POSITION SWITCH

Adjust closed throttle position switch. Refer to [EC-637, "Basic Inspection"](#) .

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

OK or NG

- OK >> GO TO 8.
- NG >> Replace throttle position sensor. To adjust it, perform [EC-637, "Basic Inspection"](#) .

8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-718, "Component Inspection"](#)



OK or NG

- OK >> GO TO 9.
- NG >> Replace mass air flow sensor.


A
EC
C
D
E
F
G
H
I
J
K
L
M

9. CHECK CAMSHAFT POSITION SENSOR

1. Install any parts removed.
2. Start engine.
3. Check voltage between ECM terminals 44, 48 and ground, ECM terminal 49 and ground with DC range.
<Terminal 44 or 48 and engine ground>



<Terminal 49 and engine ground>



OK or NG

- OK >> GO TO 10.
- NG >> Replace distributor assembly with camshaft position sensor.


10. CHECK FUEL INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance : 10 - 14Ω [at 25°C (77°F)]

OK or NG

- OK >> GO TO 11.
- NG >> Replace fuel injector.



11. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


DTC P0125 ECT SENSOR

Component Description

NOTE:

If DTC P0125 is displayed with P0117 or P0118, first perform the trouble diagnosis for DTC P0117 or P0118. Refer to [EC-730](#).


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
-10 (14)	4.4	9.2
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 59 (Engine coolant temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0125	Insufficient engine coolant temperature for closed loop fuel control	<ul style="list-style-type: none"> ● Voltage sent to ECM from the sensor is not practical, even when some time has passed after starting the engine. ● Engine coolant temperature is insufficient for closed loop fuel control. 	<ul style="list-style-type: none"> ● Harness or connectors (High resistance in the circuit) ● Engine coolant temperature sensor ● Thermostat

DTC Confirmation Procedure

CAUTION:

Be careful not to overheat engine.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Check that "COOLAN TEMP/S" is above 10°C (50°F).
If it is above 10°C (50°F), the test result will be OK.
If it is below 10°C (50°F), go to following step.
4. Start engine and run it for 65 minutes at idle speed.
If "COOLAN TEMP/S" increases to more than 10°C (50°F) within 65 minutes, stop engine because the test result will be OK.
5. If 1st trip DTC is detected, go to [EC-752, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

 **WITH GST**

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

UBS007XL

1. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-752, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Replace engine coolant temperature sensor.

2. CHECK THERMOSTAT OPERATION

When the engine is cold [lower than 70°C (158°F)] condition, grasp lower radiator hose and confirm the engine coolant does not flow.

OK or NG

- OK >> GO TO 3.
- NG >> Replace thermostat. Refer to [CO-28, "THERMOSTAT"](#) .

3. CHECK INTERMITTENT INCIDENT


Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection ENGINE COOLANT TEMPERATURE SENSOR

UBS007XM

1. Check resistance as shown in the figure.




DTC P0125 ECT SENSOR

[VG33E]

<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

- If NG, replace engine coolant temperature sensor.



Removal and Installation ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

UBS007XN


A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0127 IAT SENSOR

Component Description

The intake air temperature sensor is mounted to the air duct housing. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.




<Reference data>

Intake air temperature °C (°F)	Voltage* (V)	Resistance kΩ
20 (68)	3.5	2.1 - 2.9
80 (176)	1.23	0.27 - 0.38

*: These data are reference values and are measured between ECM terminal 61 (Intake air temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0127	Intake air temperature too high	Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Intake air temperature sensor

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

CAUTION:

Always drive vehicle at a safe speed.


TESTING CONDITION:

This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

WITH CONSULT-II

1. Wait until engine coolant temperature is less than 90°C (194°F).
 - a. Turn ignition switch ON.

- b. Select "DATA MONITOR" mode with CONSULT-II.
- c. Check the engine coolant temperature.
- d. If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch OFF and cool down engine.
 - Perform the following steps before engine coolant temperature is above 90°C (194°F).
2. Turn ignition switch ON.
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Start engine.
5. Hold vehicle speed at more than 70 km/h (43 MPH) for 100 consecutive seconds.
6. If 1st trip DTC is detected, go to [EC-755, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

1. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-755, "Component Inspection"](#)

OK or NG

- OK >> GO TO 6.
- NG >> Replace intake air temperature sensor.


2. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).
For Wiring Diagram, refer to [EC-727, "Wiring Diagram"](#).

>> INSPECTION END.

Component Inspection INTAKE AIR TEMPERATURE SENSOR


1. Check resistance as shown in the figure.



<Reference data>

Intake air temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38

2. If NG, replace in take air temperature sensor.



DTC P0128 THERMOSTAT FUNCTION

On Board Diagnosis Logic

UBS007XU

Engine coolant temperature has not risen enough to open the thermostat even though the engine has run long enough.

This is due to a leak in the seal or the thermostat stuck open.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0128	Thermostat function	The engine coolant temperature does not reach to specified temperature even though the engine has run long enough.	<ul style="list-style-type: none"> ● Thermostat ● Leakage from sealing portion of thermostat ● Engine coolant temperature sensor

DTC Confirmation Procedure

UBS007XV

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- For best results, perform at ambient temperature of **-10°C (14°F) or higher.**
- For best results, perform at engine coolant temperature of **-10°C (14°F) to 70°C (158°F).**

WITH CONSULT-II

1. Replace thermostat with new one. Refer to [CO-28, "THERMOSTAT"](#) . Use only a genuine NISSAN thermostat as a replacement. If an incorrect thermostat is used, the MIL may come on.
2. Turn ignition switch “ON”.
3. Select “COOLAN TEMP/S” in “DATA MONITOR” mode with CONSULT-II.
4. Check that the “COOLAN TEMP/S” is above 70°C (158°F).
If it is below 70°C (158°F), go to following step.
If it is above 70°C (158°F), stop engine and cool down the engine to less than 70°C (158°F), then retry from step 1.
5. Drive vehicle for 10 consecutive minutes under the following conditions.

VHCL SPEED SE	80 - 120 km/h (50 - 75 MPH)
---------------	-----------------------------

If 1st trip DTC is detected, go to [EC-756, "Diagnostic Procedure"](#) .

WITH GST

Follow the procedure “WITH CONSULT-II” above.

Diagnostic Procedure

UBS007XW

1. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-757, "Component Inspection"](#)


OK or NG

- OK >> **INSPECTION END.**
- NG >> Replace engine coolant temperature sensor.

UBS007XX

Component Inspection ENGINE COOLANT TEMPERATURE SENSOR


1. Check resistance as shown in the figure.



<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

2. If NG, replace engine coolant temperature sensor.



UBS007XY

Removal and Installation ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EM-78, "OUTER COMPONENT PARTS"](#).



DTC P0132, P0152 HO2S1

PFP:22690

Component Description

UBS007XZ

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS007Y0


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS007Y1

To judge the malfunction, the diagnosis checks that the heated oxygen sensor 1 output is not inordinately high.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0132 (Bank 1)	Heated oxygen sensor 1 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Heated oxygen sensor 1
P0152 (Bank 2)			

DTC Confirmation Procedure**NOTE:**

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

ⓑ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Restart engine and let it idle for 2 minutes.
6. If 1st trip DTC is detected, go to [EC-763, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C





SEF174Y

Ⓒ WITH GST

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 10 seconds.
 3. Restart engine and let it idle for 2 minutes.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Restart engine and let it idle for 2 minutes.
 6. Select "MODE 3" with GST.
 7. If DTC is detected, go to [EC-763, "Diagnostic Procedure"](#).
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

Wiring Diagram
BANK 1

EC-O2S1B1-01




DTC P0132, P0152 HO2S1

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.





TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Heated oxygen sensor 1 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p> 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

A
EC
C
D
E
F
G
H
I
J
K
L
M

BANK 2


EC-O2S1B2-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
51	G	Heated oxygen sensor 1 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p>  <p>SEF002V</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

UBS007Y4


1. INSPECTION START

1. Turn ignition switch OFF.
2. Check heated oxygen sensor 1 harness protector.



3. Disconnect corresponding heated oxygen sensor 1 harness connector.

>> GO TO 2.



2. RETIGHTEN HEATED OXYGEN SENSOR 1

1. Loosen and retighten corresponding heated oxygen sensor 1.

Tightening torque : 40 - 60 N·m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)

>> GO TO 3.

3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0132	50	2	Bank 1
P0152	51	2	Bank 2

Continuity should exist.

3. Check harness continuity between ECM terminal or HO2S1 terminal and ground as follows.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0132	50 or 2	Ground	Bank 1
P0152	51 or 2	Ground	Bank 2

Refer to Wiring Diagram.

Continuity should not exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FRONT HO2S1 CONNECTOR FOR WATER

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Check connectors for water.

Water should not exist.

OK or NG

OK (With CONSULT-II)>>GO TO 5.

OK (Without CONSULT-II)>>GO TO 6.

NG >> Repair or replace harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 1

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V


SEF967Y

5. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown right:
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5	
	HO2S1 MNTR (B1)	R	L	L	R	L	R
Bank 2	cycle	1	2	3	4	5	
	HO2S1 MNTR (B2)	R	L	L	R	L	R

R means HO2S1
MNTR (B1)/(B2) indicates RICH
L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 7.
- NG >> Replace malfunctioning heated oxygen sensor 1.

6. CHECK HEATED OXYGEN SENSOR 1

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.


- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



OK or NG

OK >> GO TO 7.

NG >> Replace malfunctioning heated oxygen sensor.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

UBS0090F

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .



DTC P0133, P0153 HO2S1

PFP:22690

Component Description

UBS007Y6

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS007Y7


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS007Y8

To judge the malfunction of heated oxygen sensor 1, this diagnosis measures response time of heated oxygen sensor 1 signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and heated oxygen sensor 1 temperature index. Judgment is based on whether the compensated time (heated oxygen sensor 1 cycling time index) is inordinately long or not.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0133 (Bank 1)	Heated oxygen sensor 1 circuit slow response	The response of the voltage signal from the sensor takes more than the specified time.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks ● Exhaust gas leaks ● PCV valve ● Mass air flow sensor
P0153 (Bank 2)			

DTC Confirmation Procedure

UBS007Y9

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above **-10°C (14°F)**.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch “ON” and select “HO2S1 (B1)/(B2) P0133/P0153” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.

HO2S1 (B1) P0133	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

SEF338Z

5. Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 5.

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 40 to 50 seconds.)


ENG SPEED	1,700 - 2,800 rpm
Vehicle speed	More than 80 km/h (50 MPH)
B/FUEL SCHDL	2.0 - 14.0 msec
Selector lever	Suitable position

HO2S1 (B1) P0133	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

SEF339Z

If “TESTING” is not displayed after 5 minutes, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-773, "Diagnostic Procedure"](#).



UBS007YA


Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.

WITHOUT GST





1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.

1 time : 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times : 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
4. If NG, go to [EC-773, "Diagnostic Procedure"](#).



Wiring Diagram
BANK 1

EC-O2S1B1-01




DTC P0133, P0153 HO2S1

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.





TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Heated oxygen sensor 1 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p> 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

A
EC
C
D
E
F
G
H
I
J
K
L
M

BANK 2


EC-O2S1B2-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
51	G	Heated oxygen sensor 1 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p> 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

UBS007YC

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. RETIGHTEN HEATED OXYGEN SENSOR 1


Loosen and retighten corresponding heated oxygen sensor 1.

Tightening torque : 40 - 60 N·m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)

>> GO TO 3.

3. CHECK FOR EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst (manifold).



OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.

4. CHECK FOR INTAKE AIR LEAK


Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace.

5. CLEAR THE SELF-LEARNING DATA**With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?**

**Without CONSULT-II**


1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure 1st trip DTC P0102 is displayed.
6. Erase the 1st trip DTC memory. Refer to [EC-623, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171, P0174 or P0175 detected?
Is it difficult to start engine?**

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to [EC-810](#) , [EC-818](#) .
No >> GO TO 6.


6. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check heated oxygen sensor 1 harness protector.



3. Disconnect corresponding heated oxygen sensor 1 harness connector.
4. Disconnect ECM harness connector.
5. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0133	50	2	Bank 1
P0153	51	2	Bank 2



Continuity should exist.

6. Check harness continuity between ECM terminal or HO2S1 terminal and ground as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0133	50 or 2	Ground	Bank 1
P0153	51 or 2	Ground	Bank 2

Continuity should not exist.

7. Also check harness for short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK HEATED OXYGEN SENSOR 1 HEATER

Check resistance between HO2S1 terminals 3 and 1.

Resistance : 2.3 - 4.3Ω at 25°C (77°F)

Check continuity between HO2S1 terminals 2 and 1, 3 and 2.

Continuity should not exist.


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 8.

NG >> Replace malfunctioning heated oxygen sensor 1.



8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-718, "Component Inspection"](#)

OK or NG

OK >> GO TO 9.

NG >> Replace mass air flow sensor.

9. CHECK PCV VALVE


With engine running at idle, remove PCV valve from rocker cover; make sure that a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.

OK or NG

OK (With CONSULT-II) >> GO TO 10.

OK (Without CONSULT-II) >> GO TO 11.

NG >> Replace PCV valve.



10. CHECK HEATED OXYGEN SENSOR 1

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V

SEF967Y

5. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	
cycle	1 2 3 4 5
HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R	
Bank 2	
cycle	1 2 3 4 5
HO2S1 MNTR (B2) R-L-R-L-R-L-R-L-R-L-R	
R means HO2S1	
MNTR (B1)/(B2) indicates RICH	
L means HO2S1	
MNTR (B1)/(B2) indicates LEAN	

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 12.
- NG >> Replace malfunctioning heated oxygen sensor 1.

11. CHECK FRONT HEATED OXYGEN SENSOR 1

⊗ Without CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



OK or NG

OK >> GO TO 12.

NG >> Replace malfunctioning heated oxygen sensor 1.

12. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .



DTC P0134, P0154 HO2S1

PF2:22690

Component Description

UBS007YE

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS007YF


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS007YG

Under the condition in which the heated oxygen sensor 1 signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0134 (Bank 1)	Heated oxygen sensor 1 circuit no activity detected	The voltage from the sensor is constantly approx. 0.3V.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Heated oxygen sensor 1
P0154 (Bank 2)			

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "HO2S1 (B1)/(B2) P0134/P0154" of "HO2S1" in "DTC WORK SUPPORT" mode with CONSULT-II.
3. Touch "START".
4. Let it idle for at least 3.5 minutes.


NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 4.




5. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 10 to 60 seconds.)

ENG SPEED	1,400 - 2,700 rpm
Vehicle speed	More than 65 km/h (40 MPH)
B/FUEL SCHDL	2.0 - 14.0 msec
Selector lever	Suitable position



If "TESTING" is not displayed after 5 minutes, retry from step 2.

6. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-787, "Diagnostic Procedure"](#). During this test, P1148 and P1168 may be stored in ECM.



Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.


WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal] and engine ground.

DTC P0134, P0154 HO2S1

[VG33E]





3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 to 0.4V.
4. If NG, go to [EC-787, "Diagnostic Procedure"](#).



Wiring Diagram
BANK 1

EC-O2S1B1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M




DTC P0134, P0154 HO2S1

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Heated oxygen sensor 1 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p> 


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

DTC P0134, P0154 HO2S1




[VG33E]

BANK 2

EC-O2S1B2-01



A
EC
C
D
E
F
G
H
I
J
K
L
M




DTC P0134, P0154 HO2S1

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
51	G	Heated oxygen sensor 1 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p>  <p style="text-align: right;">SEF002V</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)



Diagnostic Procedure

1. INSPECTION START

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.



3. Make sure HO2S 1 harness protector color, and disconnect corresponding heated oxygen sensor 1 harness connector.



>> GO TO 2.

A
EC
C
D
E
F
G
H
I
J
K
L
M

2. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0134	50	2	Bank 1
P0154	51	2	Bank 2

Continuity should exist.

3. Check harness continuity between ECM terminal or HO2S1 terminal and ground as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0134	50 or 2	Ground	Bank 1
P0154	51 or 2	Ground	Bank 2

Continuity should not exist.

4. Also check harness for short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 3.

OK (Without CONSULT-II)>> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HEATED OXYGEN SENSOR 1

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V


SEF967Y

5. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1 2 3 4 5
HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R		
Bank 2	cycle	1 2 3 4 5
HO2S1 MNTR (B2) R-L-R-L-R-L-R-L-R-L-R		

R means HO2S1 MNTR (B1)/(B2) indicates RICH
L means HO2S1 MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 5.
- NG >> Replace malfunctioning heated oxygen sensor 1.

4. CHECK HEATED OXYGEN SENSOR 1

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 (bank 1 signal) or 51 (bank 2 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 5.

NG >> Replace malfunctioning heated oxygen sensor 1.



5. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

UBS007YL

DTC P0138, P0158 HO2S2

PF2:226A0

Component Description


UBS007YM

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

UBS007YN


Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> Warm-up condition After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)		LEAN ↔ RICH
	Revsing engine from idle up to 3,000 rpm quickly	

On Board Diagnosis Logic

UBS007YO

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0138 (Bank 1)	Heated oxygen sensor 2 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2
P0158 (Bank 2)			

DTC Confirmation Procedure

UBS007YP

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

 **WITH CONSULT-II**

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for two minutes.
6. If 1st trip DTC is detected, go to [EC-796, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y





 **WITH GST**

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for two minutes.
5. Turn ignition switch "OFF" and wait at least 10 seconds.
6. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
7. Let engine idle for two minutes.
8. Select "Mode 3" with GST.
9. If DTC is detected, go to [EC-796, "Diagnostic Procedure"](#) .

Wiring Diagram
BANK 1

EC-O2S2B1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P0138, P0158 HO2S2

[VG33E]

Specification data are reference values and are measured between each terminal and ground.





CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none">● Engine speed is below 3.600 rpm after the following conditions are met.<ul style="list-style-type: none">– Engine after warming up.– Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load.● Revving engine from idle to 3,000 rpm quickly.	0 - Approximately 1.0V

BANK 2

EC-O2S2B2-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
57	Y	Heated oxygen sensor 2 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is below 3.600 rpm after the following conditions are met. <ul style="list-style-type: none"> – Engine after warming up. – Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. ● Revving engine from idle to 3,000 rpm quickly. 	0 - Approximately 1.0V

Diagnostic Procedure

UBS007YR


1. INSPECTION START

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.



3. Check heated oxygen sensor 2 harness protector color.
4. Disconnect corresponding heated oxygen sensor 2 harness connector.
5. Disconnect ECM harness connector.

>> GO TO 2.



2. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0138	56	1	Bank 1
P0158	57	1	Bank 2

Continuity should exist.

2. Check harness continuity between ECM terminal or HO2S2 terminal and ground as follows.

Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0138	56 or 1	Ground	Bank 1
P0158	57 or 1	Ground	Bank 2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between HO2S2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open between heated oxygen sensor 2 and engine ground.

>> Repair open circuit to ground or short to power in harness or connectors.

5. CHECK HO2S2 CONNECTORS FOR WATER

Check heated oxygen sensor 2 connector and harness connector for water.

Water should not exist.

OK or NG

OK (With CONSULT-II)>>GO TO 6.

OK (Without CONSULT-II)>>GO TO 7.

NG >> Repair or replace harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2


With CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minutes.
6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.62V at least once when the "FUEL INJECTION" is +25%.
 "HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
 NG >> Replace malfunctioning heated oxygen sensor 2.

7. CHECK HEATED OXYGEN SENSOR 2

⊗ Without CONSULT-II

1. Turn ignition switch "OFF" and wait at least 10 seconds.
2. Stop vehicle with engine running.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.62V at least once during this procedure.

If the voltage is above 0.62V at step 6, step 7 is not necessary.

7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.48V at least once during this procedure.

8. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
NG >> Replace malfunctioning heated oxygen sensor 2.


8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .




DTC P0139, P0159 HO2S2

Component Description

UBS007YT

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

UBS007YU


Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> Warm-up condition After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. Revving engine from idle up to 3,000 rpm quickly	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)		LEAN ↔ RICH

On Board Diagnosis Logic

UBS007YV

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the switching response of the sensor's voltage is faster than specified during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0139 (Bank 1)	Heated oxygen sensor 2 circuit slow response	It takes more time for the sensor to respond between rich and lean than the specified time.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2 Fuel pressure Injectors Intake air leaks
P0159 (Bank 2)			

DTC Confirmation Procedure

UBS007YW

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


TESTING CONDITION:

Open engine hood before conducting following procedure

Ⓟ WITH CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.

3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Select "HO2S2 (B1) P0139" or "HO2S2 (B2) P0159" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II and follow the instruction of CONSULT-II.
6. Start engine and following the instruction of CONSULT-II.



7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
 If "NG" is displayed, refer to [EC-805, "Diagnostic Procedure"](#).
 If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a. Turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle).
 - b. Turn ignition switch "ON" and select "COOLANTEMP/S" in "DATA MONITOR" mode with CONSULT-II.
 - c. Start engine and warm it up while monitoring "COOLANTEMP/S" indication on CONSULT-II.
 - d. When "COOLANTEMP/S" indication reaches to 70°C (158°F), go to step 3.

Overall Function Check

UBS007YX


Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.




WITH GST

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeter probes between ECM terminal 56 [HO2S2(B1) signal] or 57 [HO2S2(B2) signal] and ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
 (Depress and release accelerator pedal as soon as possible.)
The voltage should change at more than 0.06V for 1 second during this procedure.
If the voltage can be confirmed in step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should change at more than 0.06V for 1 second during this procedure.
8. If NG, go to [EC-805, "Diagnostic Procedure"](#).



Wiring Diagram
BANK 1

EC-O2S2B1-01



DTC P0139, P0159 HO2S2

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:





Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is below 3.600 rpm after the following conditions are met. <ul style="list-style-type: none"> – Engine after warming up. – Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. ● Revving engine from idle to 3,000 rpm quickly. 	0 - Approximately 1.0V

A
EC
C
D
E
F
G
H
I
J
K
L
M

BANK 2

EC-O2S2B2-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
57	Y	Heated oxygen sensor 2 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is below 3.600 rpm after the following conditions are met. <ul style="list-style-type: none"> - Engine after warming up. - Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. ● Revving engine from idle to 3,000 rpm quickly. 	0 - Approximately 1.0V


Diagnostic Procedure

UBS0090D

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.




LEC518

2. CLEAR THE SELF-LEARNING DATA

④ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?**



⊗ WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-623, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?**

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to [EC-810, "DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION"](#) or [EC-818, "DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION"](#).
- No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between HO2S2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART


Check the following.

- Harness for open between heated oxygen sensor 2 and engine ground.

>> Repair open circuit or short to power in harness or connectors.


5. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 2 harness protector color.



3. Disconnect corresponding heated oxygen sensor 2 harness connector.
4. Disconnect ECM harness connector.
5. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0139	56	1	Bank 1
P0159	57	1	Bank 2



Continuity should exist.

6. Check harness continuity between ECM terminal or HO2S2 terminal and ground as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0139	56 or 1	Ground	Bank 1
P0159	57 or 1	Ground	Bank 2

Continuity should not exist.

7. Also check harness for short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 6.

OK (Without CONSULT-II)>>GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2

With CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minutes.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANT TEMP/S	XXX °C


SEF174Y

6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to ±25%.



"HO2S2 (B1)/(B2)" should be above 0.62V at least once when the "FUEL INJECTION" is +25%.
 "HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


OK or NG

- OK >> GO TO 8.
 NG >> Replace malfunctioning heated oxygen sensor 2.

7. CHECK HEATED OXYGEN SENSOR 2

⊗ Without CONSULT-II

1. Turn ignition switch "OFF" and wait at least 10 seconds.
2. Stop vehicle with engine running.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.62V at least once during this procedure.
If the voltage is above 0.62V at step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.48V at least once during this procedure.
8. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
NG >> Replace malfunctioning heated oxygen sensor 2.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

UBS0090L

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

PFP:16600

On Board Diagnosis Logic

UBS007Z1

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensors 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and light up the MIL (2 trip detection logic).

Sensor	Input signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0171 (Bank 1)	Fuel injection system too lean	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	<ul style="list-style-type: none"> ● Intake air leaks ● Heated oxygen sensor 1 ● Injectors ● Exhaust gas leaks ● Incorrect fuel pressure ● Lack of fuel ● Mass air flow sensor ● Incorrect PCV hose connection
P0174 (Bank 2)			

DTC Confirmation Procedure


UBS007Z2

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON and select “SELF-LEARNING CONT” in “WORK SUPPORT” mode with CONSULT-II.
4. Clear the self-learning control coefficient by touching “CLEAR”.
5. Select “DATA MONITOR” mode with CONSULT-II.
6. Start engine again and let it idle for at least 10 minutes.
The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to [EC-814, "Diagnostic Procedure"](#).
7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
8. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-814, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.




WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 5 seconds.

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VG33E]

3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 3" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select "MODE 7" with GST. The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to [EC-814, "Diagnostic Procedure"](#).
9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-814, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.



A

EC

C

D

E

F

G

H

I

J

K

L

M




DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VG33E]

UBS007Z3

Wiring Diagram BANK 1

EC-FUELB1-01






BBWA0478E

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VG33E]

BANK 2


EC-FUELB2-01



Diagnostic Procedure

1. CHECK EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst (manifold).



OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

2. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.

3. CHECK FOR PCV HOSE

Check PCV hose for loose connection or disconnection.

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.

4. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect corresponding heated oxygen sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0171	50	2	Bank 1
P0174	51	2	Bank 2

Continuity should exist.

5. Check harness continuity between ECM terminal or HO2S1 terminal and ground as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0171	50 or 2	Ground	Bank 1
P0174	51 or 2	Ground	Bank 2

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK FUEL PRESSURE

1. Release fuel pressure to zero.
Refer to [EC-608, "FUEL PRESSURE RELEASE"](#) .
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-608, "Fuel Pressure Check"](#) .

At idling:

When fuel pressure regulator valve vacuum hose is connected. 235 kPa (2.4 kg/cm² , 34 psi)

When fuel pressure regulator valve vacuum hose is disconnected. 294 kPa (3.0 kg/cm² , 43 psi)

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-1142, "FUEL PUMP CIRCUIT"](#) .)
- Fuel pressure regulator (Refer to [EC-609, "Fuel Pressure Regulator Check"](#) .)
- Fuel lines (Refer to [MA-28, "Checking Fuel Lines"](#) .)
- Fuel filter for clogging

>> Repair or replace.

7. CHECK MASS AIR FLOW SENSOR

 **With CONSULT-II**

1. Install all parts removed.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

 **With GST**

1. Install all parts removed.
2. Check mass air flow sensor signal in MODE 1 with GST.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

OK or NG

- OK >> GO TO 8.
 NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-712, "DTC P0101 MAF SENSOR"](#) .

8. CHECK FUNCTION OF INJECTORS

 **With CONSULT-II**

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step

SEF070Y

 **Without CONSULT-II**

1. Start engine.
2. Listen to each injector operating sound.

Clicking noise should be heard.



OK or NG

- OK >> GO TO 9.
 NG >> Perform trouble diagnosis for [EC-1137, "INJECTOR"](#) .


9. CHECK INJECTOR

1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
2. Turn ignition switch OFF.
3. Disconnect injector harness connectors on bank 2 (for DTC P0171), bank 1 (for DTC P0174).
4. Remove injector gallery assembly. Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .
Keep fuel hose and all injectors connected to injector gallery.
The injector harness connectors on bank 1 (for DTC P0171), bank 2 (for DTC P0174) should remain connected.
5. Disconnect all ignition coil harness connectors.
6. Prepare pans or saucers under each injector.
7. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors.

Fuel should be sprayed evenly for each injector.

OK or NG

- OK >> GO TO 10.
NG >> Replace injectors from which fuel does not spray out.
Always replace O-ring with new ones.



10. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

PFP:16600

On Board Diagnosis Logic

UBS007Z5

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensors 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and light up the MIL (2 trip detection logic).

Sensor	Input signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0172 (Bank 1)	Fuel injection system too rich	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Injectors ● Exhaust gas leaks ● Incorrect fuel pressure ● Mass air flow sensor
P0175 (Bank 2)			

DTC Confirmation Procedure


UBS007Z6

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

ⓑ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON and select “SELF-LEARNING CONT” in “WORK SUPPORT” mode with CONSULT-II.
4. Clear the self-learning control coefficient by touching “CLEAR”.
5. Select “DATA MONITOR” mode with CONSULT-II.
6. Start engine again and let it idle for at least 10 minutes.
The 1st trip DTC P0172, P0175 should be detected at this stage, if a malfunction exists. If so, go to [EC-822, "Diagnostic Procedure"](#) .
7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
8. Crank engine while depressing accelerator pedal.
If engine starts, go to [EC-822, "Diagnostic Procedure"](#) . If engine does not start, remove ignition plugs and check for fouling, etc.




Ⓒ WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 5 seconds.

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VG33E]

3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 3" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select "MODE 7" with GST. The 1st trip DTC P0172 or P0175 should be detected at this stage, if a malfunction exists. If so, go to [EC-822, "Diagnostic Procedure"](#).
9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-822, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.



A

EC

C

D

E

F

G

H

I

J

K

L

M




DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VG33E]

UBS007Z7

Wiring Diagram BANK 1

EC-FUELB1-01






BBWA0478E

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VG33E]

BANK 2

EC-FUELB2-01




BBWA0479E

Diagnostic Procedure

1. CHECK EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst (manifold).



OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

2. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.

3. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect corresponding heated oxygen sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0172	50	2	Bank 1
P0175	51	2	Bank 2

Continuity should exist.

5. Check harness continuity between ECM terminal or HO2S1 terminal and ground as follows.

Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0172	50 or 2	Ground	Bank 1
P0175	51 or 2	Ground	Bank 2

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero.
Refer to [EC-608, "FUEL PRESSURE RELEASE"](#) .
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-608, "Fuel Pressure Check"](#) .

At idling:

When fuel pressure regulator valve vacuum hose is connected. 235 kPa (2.4 kg/cm² , 34 psi)

When fuel pressure regulator valve vacuum hose is disconnected. 294 kPa (3.0 kg/cm² , 43 psi)

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-1142, "FUEL PUMP CIRCUIT"](#) .)
- Fuel pressure regulator (Refer to [EC-609, "Fuel Pressure Regulator Check"](#) .)

>> Repair or replace.

6. CHECK MASS AIR FLOW SENSOR

With CONSULT-II

1. Install all parts removed.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

With GST

1. Install all parts removed.
2. Check mass air flow sensor signal in MODE 1 with GST.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

OK or NG

- OK >> GO TO 7.
 NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-712, "DTC P0101 MAF SENSOR"](#) .

7. CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step

SEF070Y


Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.

Clicking noise should be heard.

OK or NG

- OK >> GO TO 8.
 NG >> Perform trouble diagnosis for [EC-1133, "INJECTOR CIRCUIT"](#) .



8. CHECK INJECTOR

1. Remove injector assembly. Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .
Keep fuel hose and all injectors connected to injector gallery.
2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
3. Disconnect injector harness connectors bank 2 (for DTC P0172), bank 1 (for P0175).
The injector harness connectors on bank 1 (for P0172), bank 2 (for P0175) should remain connected.
4. Disconnect all ignition coil harness connectors.
5. Prepare pans or saucers under each injectors.
6. Crank engine for about 3 seconds.
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip)>>GO TO 9.

NG (Drips)>>Replace the injectors from which fuel is dripping. Always replace O-ring with new one.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

A

EC

C

D

E

F

G

H

I

J

K


L

M

DTC P0181 FTT SENSOR

Component Description

The fuel tank temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.




<Reference data>

Fluid temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
20 (68)	3.5	2.3 - 2.7
50 (122)	2.2	0.79 - 0.90

*: These data are reference values and are measured between ECM terminal 60 (Fuel tank temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0181	Fuel tank temperature sensor circuit range/performance	Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signals from engine coolant temperature sensor and intake air temperature sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Fuel tank temperature sensor

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 10 seconds.
If the result is NG, go to [EC-829, "Diagnostic Procedure"](#).
If the result is OK, go to following step.
4. Check "COOLAN TEMP/S" value.
If "COOLAN TEMP/S" is less than 60°C (140°F), the result will be OK.
If "COOLAN TEMP/S" is above 60°C (140°F), go to the following step.
5. Cool engine down until "COOLAN TEMP/S" is less than 60°C (140°F).
6. Wait at least 10 seconds.
7. If 1st trip DTC is detected, go to [EC-829, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C



WITH GST

Follow the procedure "With CONSULT-II".

A

EC

C

D

E

F

G

H

I

J

K

L

M


DTC P0181 FTT SENSOR

[VG33E]


UBS007ZC

Wiring Diagram

EC-FTTS-01




- : Detectable line for DTC
- : Non-detectable line for DTC
- : EARLY PRODUCTION
- : LATE PRODUCTION



WBWA0029E

Diagnostic Procedure**1. CHECK FUEL TANK TEMPERATURE SENSOR POWER SUPPLY CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit harness connector.
3. Turn ignition switch ON.




4. Check voltage between fuel level sensor unit terminal 1 and ground with CONSULT-II or tester.

Voltage : **Approximately 5V**

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.

**2. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors B103, M91
- Harness connectors M81, F36
- Harness for open or short between ECM and fuel tank temperature sensor

>> Repair harness or connector.

3. CHECK FUEL TANK TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between fuel level sensor unit terminal 4 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check harness for open between fuel tank temperature sensor and body ground.

>> Repair open circuit or short to power in harness or connectors.


5. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance fuel level sensor unit terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

OK or NG

- OK >> GO TO 6.
 NG >> Replace fuel tank temperature sensor.



6. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation FUEL TANK TEMPERATURE SENSOR

UBS007ZE

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .


DTC P0182, P0183 FTT SENSOR

PF2:22630

UBS007ZF

Component Description

The fuel tank temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.




<Reference data>

Fluid temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
20 (68)	3.5	2.3 - 2.7
50 (122)	2.2	0.79 - 0.90

*: These data are reference values and are measured between ECM terminal 60 (Fuel tank temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.



On Board Diagnosis Logic

UBS007ZG

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0182	Fuel tank temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Fuel tank temperature sensor
P0183	Fuel tank temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

UBS007ZH

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 10 seconds.
4. If 1st trip DTC is detected, go to [EC-833, "Diagnostic Procedure"](#)

WITH GST

Follow the procedure "With CONSULT-II".




DTC P0182, P0183 FTT SENSOR

[VG33E]



UBS007Z1

Wiring Diagram

EC-FTTS-01




- : Detectable line for DTC
- : Non-detectable line for DTC
- : EARLY PRODUCTION
- : LATE PRODUCTION



WBWA0029E

Diagnostic Procedure**1. CHECK FUEL TANK TEMPERATURE SENSOR POWER SUPPLY CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit harness connector.
3. Turn ignition switch ON.




4. Check voltage between fuel level sensor unit terminal 1 and ground with CONSULT-II or tester.

Voltage : **Approximately 5V**

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.

**2. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors B103, M91
- Harness connectors M81, F36
- Harness for open or short between ECM and fuel tank temperature sensor

>> Repair harness or connector.

3. CHECK FUEL TANK TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between fuel level sensor unit terminal 4 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check harness for open between fuel tank temperature sensor and body ground.

>> Repair open circuit or short to power in harness or connectors.


5. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance fuel level sensor unit terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

OK or NG

- OK >> GO TO 6.
 NG >> Replace fuel tank temperature sensor.



6. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Removal and Installation
 FUEL TANK TEMPERATURE SENSOR**

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

UBS007ZK

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

[VG33E]

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

PF0:00019

On Board Diagnosis Logic

UBS007ZL

This diagnosis checks whether the engine coolant temperature is extraordinary high, even when the load is not heavy.

When malfunction is detected, the malfunction indicator lamp (MIL) will light up even in the first trip.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0217	Engine coolant over temperature condition	Engine coolant temperature is excessively high under normal engine speed.	<ul style="list-style-type: none"> ● Cooling fan (crankshaft driven) ● Thermostat ● Improper ignition timing ● Engine coolant temperature sensor ● Blocked radiator ● Blocked front end (Improper fitting of nose mask) ● Crushed vehicle frontal area (Vehicle frontal is collided but not repaired) ● Blocked air passage by improper installation of front fog lamp or fog lamps ● Improper mixture ratio of coolant ● Damaged bumper <p>For more information, refer to EC-839, "Main 12 Causes of Overheating".</p>

CAUTION:

When a malfunction is indicated, be sure to replace the coolant. Refer to [MA-26, "Changing Engine Coolant"](#). Also, replace the engine oil. Refer to [MA-30, "Changing Engine Oil"](#).

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-14, "ANTI-FREEZE COOLANT MIXTURE RATIO"](#).
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Overall Function Check

UBS007ZM

Use this procedure to check the overall function of the engine coolant over temperature enrichment protection check, a DTC might not be confirmed.

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high-pressure fluid escaping from the radiator.


Wrap a thick cloth around the cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

WITH CONSULT-II

1. Check the coolant level and mixture ratio (Using coolant tester) in the reservoir tank and radiator.

Allow engine to cool before checking coolant level and mixture ratio.


- If the coolant level in the reservoir and/or the radiator is below the proper range, skip following steps and go to [EC-837, "Diagnostic Procedure"](#).
 - If the coolant mixture ratio is out of range between 45 to 55%, replace the coolant. Refer to [MA-26, "Changing Engine Coolant"](#).
- Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to [MA-14, "ANTI-FREEZE COOLANT MIXTURE RATIO"](#).
 - After refilling coolant, run engine to ensure that no water-flow noise is emitted.



DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION


[VG33E]

- After checking or replacing coolant, go to step 3) below.
2. Confirm whether customer filled the engine coolant or not. If customer filled the engine coolant, skip following steps and go to [EC-837, "Diagnostic Procedure"](#).
3. Start engine and make sure that cooling fan (crankshaft driven) operates. If NG, go to [EC-837, "Diagnostic Procedure"](#). After repair, go to next step.
4. Check for blocked coolant passage.
Warm up engine to normal operating temperature, then grasp upper and lower radiator hoses and make sure that coolant flows.
If NG, go to step 4 of [EC-837, "Diagnostic Procedure"](#). After repair, go to next step.
Be extremely careful not to touch any moving or adjacent parts.
5. Check radiator for blocked air passage
Check for blocked condenser or radiator (condenser or radiator fins damaged, condenser or radiator clogged), after market fog lamps ...etc. Check for condenser or radiator fin damage, shroud damage, vehicle front end for clogging of debris or insects ...etc.
Check for improper fitting of front end cover, damaged radiator grille or bumper, vehicle frontal area damaged by collision but not repaired.
If NG, take appropriate action and then go to next step.
6. Check ECT sensor for proper operation. Refer to step 5 of [EC-837, "Diagnostic Procedure"](#). If NG, replace ECT sensor and go to next step.
7. Check ignition timing. Refer to [EC-637, "Basic Inspection"](#).
Make sure that ignition timing is $10^\circ \pm 2^\circ$ at 700 ± 50 rpm.
If NG, adjust ignition timing and then recheck.



WITH GST

1. Check the coolant level and mixture ratio (Using coolant tester) in the reservoir tank and radiator.
Allow engine to cool before checking coolant level and mixture ratio.
 - If the coolant level in the reservoir and/or radiator is below the proper range, skip the following steps and go to [EC-837, "Diagnostic Procedure"](#).
 - If the coolant mixture ratio is out of range between 45 to 55%, replace the coolant. Refer to [MA-26, "Changing Engine Coolant"](#).
 - Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to [MA-14, "ANTI-FREEZE COOLANT MIXTURE RATIO"](#).
 - After refilling coolant, run engine to ensure that no water-flow noise is emitted.
 - After checking or replacing coolant, go to step 3) below.
2. Confirm whether customer filled the engine coolant or not. If customer filled engine coolant, skip following steps and go to [EC-837, "Diagnostic Procedure"](#).
3. Start engine and make sure that cooling fan (crankshaft driven) operates.
Be careful not to overheat engine.
If NG, go to step 1 of [EC-837, "Diagnostic Procedure"](#). After repair, go to next step.
4. Check for blocked coolant passage.
Warm up engine to normal operating temperature, then grasp upper and lower radiator hoses and make sure that coolant flows.
If NG, go to step 4 of [EC-837, "Diagnostic Procedure"](#). After repair, go to next step.




DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

[VG33E]

Be extremely careful not to touch any moving or adjacent parts.

5. Check radiator for blocked air passage
Check for blocked condenser or radiator (condenser or radiator fins damaged, condenser or radiator clogged), after market fog lamps ...etc. Check for condenser or radiator fin damage, shroud damage, vehicle front end for clogging of debris or insects ...etc.
Check for improper fitting of front end cover, damaged radiator grille or bumper, vehicle frontal area damaged by collision but not repaired.
If NG, take appropriate action and then go to next step.
6. Check ECT sensor for proper operation. Refer to step 5 of [EC-837, "Diagnostic Procedure"](#) . If NG, replace ECT sensor and go to next step.
7. Check ignition timing. Refer to [EC-637, "Basic Inspection"](#) .
Make sure that ignition timing is $10^{\circ} \pm 2^{\circ}$ at 700 ± 50 rpm.
If NG, adjust ignition timing and then recheck.



UBS0072N

Diagnostic Procedure

1. CHECK COOLING FAN (CRANKSHAFT DRIVEN) OPERATION

Start engine and make sure that cooling fan (crankshaft driven) operates.

OK or NG

OK >> GO TO 2.

NG >> Check cooling fan (crankshaft driven). Refer to [CO-32, "COOLING FAN \(CRANKSHAFT DRIVEN\)"](#) .

2. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.

CAUTION:

Higher than the specified pressure may cause radiator damage.

Testing pressure : 157 kPa (1.6 kg/cm² , 23 psi)

Pressure should not drop.


OK or NG

OK >> GO TO 3.

NG >> Check the following for leak:

- Hose
- Radiator
- Water pump

Refer to [CO-25, "WATER PUMP"](#) .




3. CHECK RADIATOR CAP

Apply pressure to cap with a tester and check radiator cap relief pressure.

Radiator cap relief pressure : 59 - 98 kPa (0.6 - 1.0 kg/cm² , 9 - 14 psi)

OK or NG

- OK >> GO TO 4.
- NG >> Replace radiator cap.



4. CHECK THERMOSTAT

1. Check valve seating condition at normal room temperatures. **It should seat tightly.**
2. Check valve opening temperature and valve lift.


Valve opening temperature : 76.5°C (170°F) [standard]
Valve lift : More than 10 mm/90°C (0.31 in/194°F)

3. Check if valve is closed at 5°C (9°F) below valve opening temperature.

For details, refer to [CO-28, "THERMOSTAT"](#) .


OK or NG

- OK >> GO TO 5.
- NG >> Replace thermostat.



5. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Check resistance as shown in the figure.




<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

OK or NG

- OK >> GO TO 6.
- NG >> Replace engine coolant temperature sensor.



DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

[VG33E]

6. CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to [EC-839, "Main 12 Causes of Overheating"](#) .

>> INSPECTION END.

Main 12 Causes of Overheating

UBS007ZO

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> Blocked radiator Blocked condenser Blocked radiator grille Blocked bumper 	<ul style="list-style-type: none"> Visual 	No blocking	—
	2	<ul style="list-style-type: none"> Coolant mixture 	<ul style="list-style-type: none"> Coolant tester 	50 - 50% coolant mixture	See MA-12, "RECOMMENDED FLUIDS AND LUBRICANTS" .
	3	<ul style="list-style-type: none"> Coolant level 	<ul style="list-style-type: none"> Visual 	Coolant up to MAX level in reservoir tank and radiator filler neck	See MA-26, "Changing Engine Coolant" .
	4	<ul style="list-style-type: none"> Radiator cap 	<ul style="list-style-type: none"> Pressure tester 	59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See CO-23, "System Check" .
ON*1	5	<ul style="list-style-type: none"> Coolant leaks 	<ul style="list-style-type: none"> Visual 	No leaks	See CO-23, "System Check" .
ON*1	6	<ul style="list-style-type: none"> Thermostat 	<ul style="list-style-type: none"> Touch the upper and lower radiator hoses 	Both hoses should be hot	See CO-28, "THERMOSTAT" .
ON*1	7	<ul style="list-style-type: none"> Cooling fan (Crankshaft driven) 	<ul style="list-style-type: none"> Visual 	Operating	See CO-32, "COOLING FAN (CRANKSHAFT DRIVEN)" .
OFF	8	<ul style="list-style-type: none"> Combustion gas leak 	<ul style="list-style-type: none"> Color checker chemical tester 4 Gas analyzer 	Negative	—
ON*2	9	<ul style="list-style-type: none"> Coolant temperature gauge 	<ul style="list-style-type: none"> Visual 	Gauge less than 3/4 when driving	—
		<ul style="list-style-type: none"> Coolant overflow to reservoir tank 	<ul style="list-style-type: none"> Visual 	No overflow during driving and idling	See MA-26, "Changing Engine Coolant" .
OFF*3	10	<ul style="list-style-type: none"> Coolant return from reservoir tank to radiator 	<ul style="list-style-type: none"> Visual 	Should be initial level in reservoir tank	See CO-22, "COOLING SYSTEM" .
OFF	11	<ul style="list-style-type: none"> Cylinder head 	<ul style="list-style-type: none"> Straight gauge feeler gauge 	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-100, "CYLINDER HEAD" .
	12	<ul style="list-style-type: none"> Cylinder block and pistons 	<ul style="list-style-type: none"> Visual 	No scuffing on cylinder walls or piston	See EM-130, "CYLINDER BLOCK" .

*1: Engine running at 3,000 rpm for 10 minutes.

*2: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*3: After 60 minutes of cool down time.

For more information, refer to [CO-21, "OVERHEATING CAUSE ANALYSIS"](#) .

DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6 CYLINDER MISFIRE

[VG33E]

DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6 CYLINDER MISFIRE

PFP:00000

On Board Diagnosis Logic

UBS0072P

When a misfire occurs, engine speed will fluctuate. If the engine speed fluctuates enough to cause the CKP sensor signal to vary, ECM can determine that a misfire is occurring.

Sensor	Input Signal to ECM	ECM function
Crankshaft position sensor (OBD)	Engine speed	On board diagnosis of misfire

The misfire detection logic consists of the following two conditions.

1. **One Trip Detection Logic (Three Way Catalyst Damage)**
 On the first trip that a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MIL will blink.
 When a misfire condition occurs, the ECM monitors the CKP sensor signal every 200 engine revolutions for a change.
 When the misfire condition decreases to a level that will not damage the TWC, the MIL will turn off.
 If another misfire condition occurs that can damage the TWC on a second trip, the MIL will blink.
 When the misfire condition decreases to a level that will not damage the TWC, the MIL will remain on.
 If another misfire condition occurs that can damage the TWC, the MIL will begin to blink again.
2. **Two Trip Detection Logic (Exhaust quality deterioration)**
 For misfire conditions that will not damage the TWC (but will affect vehicle emissions), the MIL will only light when the misfire is detected on a second trip. During this condition, the ECM monitors the CKP sensor signal every 1,000 engine revolutions.
 A misfire malfunction can be detected on any one cylinder or on multiple cylinders.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0300	Multiple cylinder misfire detected	Multiple cylinder misfire.	<ul style="list-style-type: none"> ● Improper spark plug ● Insufficient compression ● Incorrect fuel pressure ● The injector circuit is open or shorted ● Fuel injectors ● Intake air leak ● The ignition secondary signal circuit is open or shorted ● Lack of fuel ● Signal plate or flywheel ● Heated oxygen sensor 1 ● Incorrect PCV hose connection
P0301	No. 1 cylinder misfire detected	No. 1 cylinder misfires.	
P0302	No. 2 cylinder misfire detected	No. 2 cylinder misfires.	
P0303	No. 3 cylinder misfire detected	No. 3 cylinder misfires.	
P0304	No. 4 cylinder misfire detected	No. 4 cylinder misfires.	
P0305	No. 5 cylinder misfire detected	No. 5 cylinder misfires.	
P0306	No. 6 cylinder misfire detected	No. 6 cylinder misfires.	

DTC Confirmation Procedure

UBS0072Q

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

1. Turn ignition switch ON, and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF and wait at least 5 seconds.
4. Start engine again and drive at 1,500 to 3,000 rpm for at least 3 minutes.

Hold the accelerator pedal as steady as possible.

NOTE:

Refer to the freeze frame data for the test driving conditions.

5. If 1st trip DTC is detected, go to [EC-841, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF
B/FUEL SCHDL	XXX msec

SEF213Y

Ⓟ WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

UBS007ZR

1. CHECK FOR INTAKE AIR LEAK

1. Start engine and run it at idle speed.
2. Listen for the sound of the intake air leak.

OK or NG

- OK >> GO TO 2.
- NG >> Discover air leak location and repair.

2. CHECK FOR EXHAUST SYSTEM CLOGGING

Stop engine and visually check exhaust tube, three way catalyst and muffler for dents.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace it.

3. PERFORM POWER BALANCE TEST

With CONSULT-II

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step


SEF070Y

Without CONSULT-II

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes or No

- Yes >> GO TO 4.
 No >> GO TO 7.




4. CHECK INJECTOR

Does each injector make an operating sound at idle?

Yes or No

- Yes >> GO TO 5.
 No >> Check injector(s) and circuit(s). Refer to [EC-1133](#), "[INJECTOR CIRCUIT](#)".




5. CHECK IGNITION SPARK

1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 6.




6. CHECK IGNITION WIRES

1. Inspect wires for cracks, damage, burned terminals and for improper fit.
2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks.

Resistance:

Cylinder No.	Resistance kΩ [at 25°C (77°F)]
1	Approx. 6.5
2	Approx. 10.0
3	Approx. 8.5
4	Approx. 12.5
5	Approx. 8.5
6	Approx. 11.0



If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.

OK or NG

- OK >> Check the following:
- Distributor rotor head for incorrect parts
 - Ignition coil, power transistor and their circuits
- Refer to [EC-1127, "IGNITION SIGNAL"](#).


NG >> Replace.

7. CHECK SPARK PLUGS

Remove the spark plugs and check for fouling, etc.

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace spark plug(s) with standard type one(s). For spark plug type, refer to [MA-32, "Changing Spark Plugs"](#).



8. CHECK COMPRESSION PRESSURE

Refer to [EM-100, "Measurement of Compression"](#) .

- Check compression pressure.

Standard	: 1,196 kPa (12.2 kg/cm² , 173 psi)/300 rpm
Minimum	: 883 kPa (9.0 kg/cm² , 128 psi)/300 rpm
Difference between each cylinder	: 98 kPa (1.0 kg/cm² , 14 psi)/300 rpm

OK or NG

OK >> GO TO 9.

NG >> Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

9. CHECK FUEL PRESSURE


1. Install any parts removed.
2. Release fuel pressure to zero.
Refer to [EC-608, "FUEL PRESSURE RELEASE"](#) .
3. Install fuel pressure gauge and check fuel pressure. Refer to [EC-608, "Fuel Pressure Check"](#) .

At idle : Approx. 235 kPa (2.4 kg/cm² , 34 psi)

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.



10. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-1142, "FUEL PUMP CIRCUIT"](#) .)
- Fuel pressure regulator (Refer to [EC-609, "Fuel Pressure Regulator Check"](#) .)
- Fuel lines (Refer to [MA-28, "Checking Fuel Lines"](#) .)
- Fuel filter for clogging

>> Repair or replace.

11. CHECK IGNITION TIMING

Check the following items. Refer to [EC-637, "Basic Inspection"](#) .

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

OK or NG

OK (With CONSULT-II)>>GO TO 12.

OK (Without CONSULT-II)>>GO TO 13.

NG >> Adjust ignition timing.

A
EC
C
D
E
F
G
H
I
J
K
L
M

12. CHECK HEATED OXYGEN SENSOR 1

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select “MANU TRIG” and “HI SPEED” in “DATA MONITOR” mode with CONSULT-II, and select “HO2S1 (B1)/(B2)” and “HO2S1 MNTR (B1)/(B2)”.
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch “RECORD” on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V


SEF967Y

5. Check the following.
 - “HO2S1 MNTR (B1)/(B2)” in “DATA MONITOR” mode changes from “RICH” to “LEAN” to “RICH” 5 times in 10 seconds. 5 times (cycles) are counted as shown left:
 - “HO2S1 (B1)/(B2)” voltage goes above 0.6V at least once.
 - “HO2S1 (B1)/(B2)” voltage goes below 0.3V at least once.
 - “HO2S1 (B1)/(B2)” voltage never exceeds 1.0V.

Bank 1	cycle 1 2 3 4 5
HO2S1 MNTR (B1)	R-L-R-L-R-L-R-L-R-L-R
Bank 2	cycle 1 2 3 4 5
HO2S1 MNTR (B2)	R-L-R-L-R-L-R-L-R-L-R

R means HO2S1
MNTR (B1)/(B2) indicates RICH
L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 14.
- NG >> Replace malfunctioning heated oxygen sensor 1.

13. CHECK HEATED OXYGEN SENSOR 1 (BANK1)(BANK2)

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 (bank1 sensor signal) or 51 (bank2 sensor signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.


1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 14.
- NG >> Replace malfunctioning heated oxygen sensor 1.



14. CHECK MASS AIR FLOW SENSOR

Ⓜ With CONSULT-II

Check mass air flow sensor signal in "DATA MONITOR" mode with CONSULT-II.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

Ⓜ With GST

Check mass air flow sensor signal in MODE 1 with GST.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

OK or NG

- OK >> GO TO 15.
- NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-712, "DTC P0101 MAF SENSOR"](#) .

15. CHECK SYMPTOM MATRIX CHART

Check items on the rough idle symptom in [EC-650, "Symptom Matrix Chart"](#) .

OK or NG

- OK >> GO TO 16.
- NG >> Repair or replace.

16. ERASE THE 1ST TRIP DTC

Some tests may cause a 1st trip DTC to be set.

Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to [EC-623, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .

>> GO TO 17.

**DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6 CYLINDER MIS-
FIRE**

[VG33E]

17. CHECK INTERMITTENT INCIDENT


Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0327, P0328 KS

Component Description

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.



On Board Diagnosis Logic

The MIL will not light up for these diagnoses.

DTC No.	Trouble diagnosis name	DTC detected condition	Possible cause
P0327	Knock sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Knock sensor
P0328	Knock sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

NOTE:


If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
2. Start engine and run it for at least 5 seconds at idle speed.
3. If DTC is detected, go to [EC-851, "Diagnostic Procedure"](#) .



WITH GST

Follow the procedure “With CONSULT-II”.



DTC P0327, P0328 KS

[VG33E]

UBS007ZV

Wiring Diagram

EC-KS-01



BBWA0480E

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
64	W	Knock sensor	[Engine is running] ● Idle speed	Approximately 2.5V

Diagnostic Procedure

UBS007ZW

1. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check resistance between ECM terminal 64 and engine ground.

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

Resistance : Approximately 500 - 620 kΩ [at 25°C (77°F)]

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

2. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-II

1. Disconnect knock sensor harness connector.
2. Check harness continuity between ECM terminal 64 and knock sensor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connector F37, F101
- Harness for open or short between ECM and knock sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK KNOCK SENSOR

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 M Ω .

1. Disconnect knock sensor harness connector.
2. Check resistance between terminal 1 and ground.


Resistance: 500 - 620 k Ω [at 25°C (77°F)]

CAUTION:

Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.

OK or NG


- OK >> GO TO 5.
 NG >> Replace knock sensor.



5. RETIGHTEN GROUND SCREWS

Loose and retighten engine ground screws.

>> GO TO 6.



6. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0335 CKP SENSOR (OBD)

Component Description

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.



When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system. It is used only for the on board diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> Tachometer: Connect Run engine and compare tachometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value.

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335	Crankshaft position sensor (OBD) circuit	<ul style="list-style-type: none"> The proper pulse signal from the crankshaft position sensor (OBD) is not sent to ECM while the engine is running at the specified engine speed. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted) Crankshaft position sensor (OBD)


DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

- Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- Start engine and run it for at least 15 seconds at idle speed.
- If 1st trip DTC is detected, go to [EC-856, "Diagnostic Procedure"](#)





WITH GST

Follow the procedure "With CONSULT-II".

DTC P0335 CKP SENSOR (OBD)



[VG33E]

UBS00802

Wiring Diagram

EC-CKPS-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



BBWA0481E



DTC P0335 CKP SENSOR (OBD)

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (AC Voltage)
47	L	Crankshaft position sensor (OBD)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1 - 2V★ (AC range)</p>  <p>SEF690W</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>3 - 4V★ (AC range)</p>  <p>SEF691W</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

UBS00803

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK CKP SENSOR (OBD) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Disconnect crankshaft position (CKP) sensor (OBD) and ECM harness connectors.
2. Check continuity between ECM terminal 47 and sensor terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F38, F102
- Harness for open or short between ECM and crankshaft position sensor (OBD)

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK CKP SENSOR (OBD) GROUND CIRCUIT FOR OPEN AND SHORT

1. Reconnect ECM harness connector.
2. Check harness continuity between sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART


Check the following.

- Harness connectors F38, F102
- Harness for open between crankshaft position sensor (OBD) and ECM

>> Repair open circuit or short to power in harness or connectors.

6. CHECK CRANKSHAFT POSITION SENSOR (OBD)

1. Disconnect crankshaft position sensor (OBD) harness connector.
2. Loosen the fixing bolt of the sensor.
3. Remove the sensor.
4. Visually check the sensor for chipping.




5. Check resistance as shown in the figure.

Resistance : Approximately 512 - 632Ω [at 20°C (68°F)]

OK or NG

- OK >> GO TO 7.
- NG >> Replace crankshaft position sensor (OBD).



7. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0340 CMP SENSOR

Component Description

The camshaft position sensor is a basic component of the engine control system. It monitors engine speed and piston position. These input signals to the ECM are used to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for a 1° (POS) signal and 6 slits for a 120° (REF) signal. The wave-forming circuit consists of Light Emitting Diodes (LED) and photo diodes.



The rotor plate is positioned between the LED and the photo diode. The LED transmits light to the photo diode. As the rotor plate turns, the slits cut the light to generate rough-shaped pulses. These pulses are converted into on-off signals by the wave-forming circuit and sent to the ECM.

The distributor is not repairable and must be replaced as an assembly except distributor cap and rotor head.

NOTE:

The rotor screw which secures the distributor rotor head to the distributor shaft must be torqued properly.

 : 3.6±0.3 N·m (37±3 kg·cm, 32±3 in·lb)



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0340	Camshaft position sensor circuit	A)	<ul style="list-style-type: none"> Either 1° or 120° signal is not sent to ECM for the first few seconds during engine cranking. 	<ul style="list-style-type: none"> Harness or connectors (The CMP sensor circuit is open or shorted) Camshaft position sensor Starter motor (Refer to SC-9, "STARTING SYSTEM" .) Starting system circuit (Refer to SC-9, "STARTING SYSTEM" .) Dead (Weak) battery
		B)	<ul style="list-style-type: none"> Either 1° or 120° signal is not sent to ECM often enough while the engine speed is higher than the specified engine speed. 	
		C)	<ul style="list-style-type: none"> The relation between 1° and 120° signal is not in the normal range during the specified engine speed. 	

DTC Confirmation Procedure

NOTE:

- Perform "PROCEDURE FOR MALFUNCTION A" first. If DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B AND C".
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

PROCEDURE FOR MALFUNCTION A

 **WITH CONSULT-II**

1. Turn ignition switch ON.

DTC P0340 CMP SENSOR

[VG33E]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Crank engine for at least 2 seconds.
4. If 1st trip DTC is detected, go to [EC-863, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".

PROCEDURE FOR MALFUNCTION B AND C

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and run it for at least 2 seconds at idle speed.
4. If 1st trip DTC is detected, go to [EC-863, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".

DTC P0340 CMP SENSOR




[VG33E]

UBS00808

Wiring Diagram

EC-CMPS-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



BBWA0482E





DTC P0340 CMP SENSOR

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	OR/B	ECM relay (Self shut-off)	[Engine is running] [Ignition switch OFF] ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			[Ignition switch OFF] ● A few seconds passed after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
44 48	PU PU	Camshaft position sensor (Reference signal)	[Engine is running] ● Idle speed	0.3 - 0.5V★ 
			[Engine is running] ● Engine speed is 2,000 rpm	0.3 - 0.5V★ 
49	LG	Camshaft position sensor (Position signal)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.5V★ 
			[Engine is running] ● Engine speed is 2,000 rpm	Approximately 2.5V★ 
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
117	B/P	Current return	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK CMP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect camshaft position (CMP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between CMP sensor terminal 5 and ground with CONSULT-II or tester.

Voltage : **Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between camshaft position sensor and ECM relay
- Harness for open or short between camshaft position sensor and ECM

>> Repair harness or connectors.

4. CHECK CMP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between CMP sensor terminal 4 and ECM terminal 49, CMP sensor terminal 3 and ECM terminals 44, 48. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK CMP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between CMP sensor terminal 6 and engine ground.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART



Check the following.


- Harness for open between camshaft position sensor and engine ground

>> Repair open circuit or short to power in harness or connector.



7. CHECK CAMSHAFT POSITION SENSOR

1. Install any parts removed.
2. Start engine.
3. Check voltage between ECM terminals 44, 48 and ground, ECM terminal 49 and ground with DC range.
<Terminal 44 or 48 and engine ground>

Condition	Idle	2,000 rpm
Voltage	0.3 - 0.5V	0.3 - 0.5V
Pulse signal		



<Terminal 49 and engine ground>

Condition	Idle	2,000 rpm
Voltage	Approximately 2.5V	Approximately 2.5V
Pulse signal		

OK or NG

- OK >> GO TO 8.
- NG >> Replace distributor assembly with camshaft position sensor.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Removal and Installation
DISTRIBUTOR**

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

UBS0080A


DTC P0400 EGR FUNCTION

Description SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EGR control	EGRC-solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		

This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current does not flow through the solenoid valve. This causes the intake manifold vacuum to be discharged into the atmosphere. The EGR valve remains closed.


- Low engine coolant temperature
- Engine starting
- High-speed engine operation
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction



COMPONENT DESCRIPTION

Exhaust Gas Recirculation (EGR) Valve


The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening and EGRC-BPT valve operation. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.



EGRC-Solenoid Valve


The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. The vacuum signal (from the intake manifold collector to the EGR valve) passes through the solenoid valve. The signal then reaches the EGR valve.

When the ECM sends an OFF signal, a plunger will then move to cut the vacuum signal from the intake manifold collector.



On Board Diagnosis Logic

If the absence of EGR flow is detected by EGR temperature sensor under the condition that calls for EGR, a low-flow malfunction is diagnosed.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0400	EGRC-solenoid valve circuit close	<ul style="list-style-type: none"> No EGR flow is detected under conditions that call for EGR. 	<ul style="list-style-type: none"> EGR valve stuck closed EGRC-BPT valve Vacuum hose EGRC-solenoid valve EGR passage EGR temperature sensor Exhaust gas leaks

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.
- P0400 will not be displayed at "SELF-DIAG RESULTS" mode with CONSULT-II even though DTC work support test result is "NG".

WITH CONSULT-II

- Turn ignition switch "ON".
- Check "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II. Confirm COOLAN TEMP/S valve is within the range listed below.

COOLAN TEMP/S : Less than 40°C (104°F)


If the value is out of range, park the vehicle in a cool place and allow the engine temperature to stabilize. Do not attempt to lower the engine coolant temperature with a fan or means other than ambient air. Doing so may produce an inaccurate diagnostic result.

- Start engine and let it idle monitoring "COOLAN TEMP/S" value. When the "COOLAN TEMP/S" value reaches 70°C (158°F), immediately go to the next step.

DTC P0400 EGR FUNCTION


[VG33E]

4. Select "EGR SYSTEM P0400" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
5. Touch "START".
6. Accelerate vehicle to a speed of 40 km/h (25 MPH) once and then stop vehicle with engine running.
If "COMPLETED" appears on CONSULT-II screen, go to step 9.
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.
7. Check the output voltage of "THRTL POS SEN" (at closed throttle position) and note it.




8. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions until "TESTING" changes to "COMPLETED". (It will take approximately 60 seconds or more.)

ENG SPEED	1,600 - 2,400 rpm (A/T) 1,800 - 2,600 rpm (M/T)
B/FUEL SCHDL	6 - 9 msec
THRTL POS SEN	$X - (X + 0.82) V$ X = Voltage value measured at step 7
Selector lever	Suitable position



If "TESTING" is not displayed after 5 minutes, retry from step 2.

9. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-871, "Diagnostic Procedure"](#).




Overall Function Check

UBS0080E

Use this procedure to check the overall EGR function. During this check, a 1st trip DTC might not be confirmed.

⊗ WITHOUT CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Check the EGR valve lifting when revving engine from idle up to 3,000 rpm quickly under no load.
EGR valve should lift up and down without sticking.
If NG, go to [EC-871, "Diagnostic Procedure"](#).
3. Check voltage between ECM terminal 63 (EGR temperature sensor signal) and ground at idle speed.
Less than 4.5V should exist.
If NG, go to next step.
4. Turn ignition switch "OFF".



DTC P0400 EGR FUNCTION

[VG33E]


5. Disconnect EGR temperature sensor harness connector.





6. Check harness continuity between EGR temperature sensor harness connector terminal 2 and ground.

Continuity should exist.

7. Perform [EC-886, "Component Inspection"](#) .



Overall function check



Check the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm.

SEF642Q




DTC P0400 EGR FUNCTION

[VG33E]

UBS0080F


Wiring Diagram

EC-EGRC1-01



Refer to the following.

E43 - SUPER MULTIPLE JUNCTION (SMJ)




BBWA0504E

Diagnostic Procedure

1. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



OK or NG


- OK (With CONSULT-II)>>GO TO 2.
- OK (Without CONSULT-II)>>GO TO 3.
- NG >> Repair or replace.

2. CHECK VACUUM SOURCE TO EGR VALVE

With CONSULT-II

1. Warm engine up to normal operating temperature.
2. Disconnect vacuum hose to EGR valve.
3. Check for vacuum existence at idle.

Vacuum should not exist at idle.



4. Select "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode with CONSULT-II and turn the solenoid valve ON.
5. Check for vacuum existence when revving engine from idle up to 3,000rpm.

Vacuum should exist when revving engine.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.

ACTIVE TEST	
EGRC SOLENOID VALVE	OFF
MONITOR	
ENG SPEED	XXX rpm
ON	ON/OFF

Reference: SEF129Y

3. CHECK VACUUM SOURCE TO EGR VALVE

⊗ **Without CONSULT-II**

1. Warm engine up to normal operating temperature.
2. Disconnect vacuum hose to EGR valve.
3. Check for vacuum existence at idle.


Vacuum should not exist at idle.

4. Check for vacuum existence when revving engine from idle up to 3,000 rpm quickly.

Vacuum should exist when revving engine.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.



4. CHECK EGR VALVE

Refer to [EC-874, "Component Inspection"](#) .

OK or NG


- OK >> GO TO 11.
- NG >> Replace EGR valve.

5. CHECK VACUUM HOSE

1. Turn ignition switch "OFF".
2. Check vacuum hose for clogging, cracks or improper connection.

OK or NG

- OK (With CONSULT-II)>>GO TO 6.
- OK (Without CONSULT-II)>>GO TO 7.
- NG >> Repair or replace vacuum hose.



6. CHECK EGRC-SOLENOID VALVE OPERATION


Ⓜ **With CONSULT-II**

1. Turn ignition switch "ON".
2. Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.

Clicking noise should be heard.

OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace EGRC-solenoid valve or repair circuit.



7. CHECK EGRC-SOLENOID VALVE OPERATION

⊗ **Without CONSULT-II**

1. Disconnect ECM harness connector.
2. Turn ignition switch "ON".
3. Connect a suitable jumper wire between ECM terminal 103 and engine ground.
4. Check operating sound of EGRC-solenoid valve when disconnecting and connecting the jumper wire.

Clicking noise should be heard.

OK or NG

OK >> GO TO 9.

NG >> Repair or replace EGRC-solenoid valve or repair circuit.

8. CHECK EGRC-SOLENOID VALVE


1. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time under the following conditions.

Conditions	Air passage continuity between A and B	Air passage continuity between A and C
ON	Yes	No
OFF	No	Yes

OK or NG

OK >> GO TO 10.

NG >> Repair EGRC-solenoid valve.



9. CHECK EGRC-SOLENOID VALVE


1. Check air passage continuity and operation delay time under the following conditions.

Conditions	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

OK or NG

OK >> GO TO 10.

NG >> Repair EGRC-solenoid valve.



10. CHECK EGRC-BPT VALVE

Refer to [EC-874, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace EGRC-BPT valve.

11. CHECK EGR TEMPERATURE SENSOR

Refer to [EC-886, "Component Inspection"](#) .

OK or NG

OK >> GO TO 12.

NG >> Replace EGR temperature sensor.

12. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


Component Inspection
EGR VALVE

UBS0080H

1. Apply vacuum to EGR vacuum port with a hand vacuum pump.


EGR valve spring should lift.

2. Check for sticking.
3. If NG, repair or replace EGR valve.



EGRC-BPT VALVE

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂ O, 3.94 inH₂ O) from under EGRC-BPT valve.
3. If a leakage is noted, replace the valve.



Removal and Installation
EGR VALVE

UBS0080I


Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

DTC P0402 EGRC-BPT VALVE FUNCTION

PF0:14741

Description

UBS0080J



SYSTEM DESCRIPTION

The EGRC-BPT valve monitors exhaust pressure to activate the diaphragm, controlling intake manifold vacuum applied to the EGR valve. In other words, recirculated exhaust gas is controlled in response to positioning of the EGR valve or to engine operation.

On Board Diagnosis Logic

UBS0080K

If too much EGR flow exists due to an EGRC-BPT valve malfunction, off idle engine roughness will increase. If the roughness is large, then the vacuum to the EGR valve is interrupted through the EGRC-solenoid valve. If the engine roughness is reduced at that time, the EGRC-BPT valve malfunction is indicated.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0402	EGRC-BPT VALVE FUNCTION	<ul style="list-style-type: none"> The EGRC-BPT valve does not operate properly. 	<ul style="list-style-type: none"> EGRC-BPT valve EGR valve Loose or disconnected rubber tube Blocked rubber tube Camshaft position sensor Blocked exhaust system Orifice Mass air flow sensor EGRC-solenoid valve

DTC Confirmation Procedure

UBS0080L

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

DTC P0402 EGRC-BPT VALVE FUNCTION


[VG33E]

WITH CONSULT-II

1. Install vacuum gauge between EGRC-BPT valve and EGR valve as shown in the illustration.
2. Start engine and warm it up to normal operating temperature.
3. Stop engine and wait at least 5 seconds.
4. Turn ignition switch ON and select "EGRC-BPT VLV P0402" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
5. Start engine and let it idle.




6. Touch "START".
7. Check the output voltage of "THRTL POS SEN" (at closed throttle position) and note it.




8. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen and the bar chart may increase. Maintain the conditions many times until "COMPLETED" appears.

Selector lever	Suitable position
ENG SPEED	1,000 - 1,600 rpm
Vehicle speed	30 - 60 km/h (19 - 37 MPH) (A/T models) 30 - 100 km/h (19 - 62 MPH) (M/T models)
B/FUEL SCHDL	3.5 - 5.2 msec
THRTL POS SEN	$X - (X + 0.9) V$ X = Voltage value measured at step 7



NOTE:


- The bar chart on CONSULT-II screen indicates the status of this test. However, the test may be finished before the bar chart becomes full scale.
 - If the bar chart indication does not continue to progress, completely release accelerator pedal once and try to meet the conditions again.
 - If "TESTING" does not appear on CONSULT-II screen, retry from step 2.
9. If CONSULT-II instructs to carry out "Overall Function Check", go to next step. If "NG" is displayed, refer to [EC-878, "Diagnostic Procedure"](#).
 10. Open engine hood.



DTC P0402 EGRC-BPT VALVE FUNCTION

[VG33E]

11. Raise engine speed to 2,000 to 2,800 rpm under no-load and hold it. Then touch "NEXT" on CONSULT-II screen.



12. Check vacuum gauge while keeping engine speed at 2,000 to 2,800 rpm.

Vacuum should be 0 to -20 kPa (0 to -150 mmHg, 0 to -5.91 inHg).


If NG, go to [EC-878, "Diagnostic Procedure"](#).

If OK, touch "YES" on the CONSULT-II screen.

13. Check the rubber tube between intake manifold collector, EGRC-solenoid valve, EGR valve and EGRC-BPT valve for cracks, blockages or twisting.

If NG, repair or replace.

If OK, touch "YES" on the CONSULT-II screen.



Overall Function Check

UBS0080M

Use this procedure to check the overall function of the EGRC-BPT valve. During this check, a 1st trip DTC might not be confirmed.

⊗ WITHOUT CONSULT-II


1. Install vacuum gauge between EGRC-BPT valve and EGR valve as shown in the illustration.
2. Lift up vehicle.
3. Start engine and shift to 1st gear position.
4. Check vacuum gauge while keeping engine speed at 2,000 to 2,800 rpm.

Vacuum should be 0 to -20 kPa (0 to -150 mmHg, 0 to -5.91 inHg).

If NG, go to [EC-878, "Diagnostic Procedure"](#).

If OK, go to next step.

5. Check rubber tube between intake manifold collector, EGRC-solenoid valve, EGR valve and EGRC-BPT valve for misconnection, cracks or blockages.
6. If NG, go to [EC-878, "Diagnostic Procedure"](#).



Diagnostic Procedure

1. CHECK HOSE

Check vacuum hose for clogging and improper connection.

OK or NG

OK >> GO TO 2.

NG >> Repair or replace vacuum hose.

2. CHECK EXHAUST SYSTEM

Check exhaust system for collapse.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace exhaust system.

3. CHECK ORIFICE

Check if orifice is installed in vacuum hose between EGRC-BPT valve and EGRC-solenoid valve.

OK or NG

OK >> GO TO 4.

NG >> Replace vacuum hose.

4. CHECK EGRC-BPT VALVE

Refer to [EC-880, "Component Inspection"](#).

OK or NG


OK >> GO TO 5.

NG >> Replace EGRC-BPT valve.

5. CHECK CAMSHAFT POSITION SENSOR

1. Install any parts removed.
2. Start engine.
3. Check voltage between ECM terminals 44, 48 and ground, ECM terminal 49 and ground with DC range.
<Terminal 44 or 48 and engine ground>

Condition	Idle	2,000 rpm
Voltage	0.3 - 0.5V	0.3 - 0.5V
Pulse signal		



<Terminal 49 and engine ground>

Condition	Idle	2,000 rpm
Voltage	Approximately 2.5V	Approximately 2.5V
Pulse signal		

OK or NG

- OK >> GO TO 6.
- NG >> Replace camshaft position sensor.

6. CHECK MASS AIR FLOW SENSOR

Refer to [EC-718, "Component Inspection"](#) .

OK or NG


- OK >> GO TO 7.
- NG >> Replace mass air flow sensor.

7. CHECK EGRC-SOLENOID VALVE

④ With CONSULT-II

1. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time under the following conditions.


Conditions	Air passage continuity between A and B	Air passage continuity between A and C
ON	Yes	No
OFF	No	Yes



⊗ Without CONSULT-II

1. Check air passage continuity and operation delay time under the following conditions.

Conditions	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes



OK or NG

- OK >> GO TO 8.
- NG >> Replace EGRC-solenoid valve.

8. CHECK EGR VALVE

Refer to [EC-874, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace EGR valve.

9. CHECK INTERMITTENT INCIDENT

Perform [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END.

**Component Inspection
EGRC-BPT VALVE**

UBS00800

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check leakage without applying any pressure from under EGR-BPT valve.

Leakage should exist.




DTC P0405, P0406 EGRT SENSOR

Component Description

The EGR temperature sensor detects temperature changes in the EGR passageway. When the EGR valve opens, hot exhaust gases flow, and the temperature in the passageway changes. The EGR temperature sensor is a thermistor that modifies a voltage signal sent from the ECM. This modified signal then returns to the ECM as an input signal. As the temperature increases, EGR temperature sensor resistance decreases. This sensor is not used to control the engine system.

It is used only for the on board diagnosis.




<Reference data>

EGR temperature °C (°F)	Voltage* V	Resistance MΩ
0 (32)	4.56	0.62 - 1.05
50 (122)	2.25	0.065 - 0.094
100 (212)	0.59	0.011 - 0.015

*: These data are reference values and are measured between ECM terminal 63 (EGR temperature sensor) and ground.

When EGR system is operating.

Voltage: 0 - 1.5V



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P0405	EGR temperature circuit low input	An excessively low voltage from the EGR temperature sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The EGR temperature sensor circuit is shorted.) ● EGR temperature sensor ● Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve
P0406	EGR temperature circuit high input	An excessively high voltage from the EGR temperature sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The EGR temperature sensor circuit is open.) ● EGR temperature sensor ● Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve

DTC Confirmation Procedure

Perform "PROCEDURE FOR DTC P0405" first. If 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR DTC P0406".

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR DTC P0405

With CONSULT-II

1. Turn ignition switch ON.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Verify that engine coolant temperature is less than 50°C (122°F).
If the engine coolant temperature is above the range, cool the engine down.
4. Start engine and let it idle for at least 8 seconds.
5. If 1st trip DTC is detected, go to [EC-885, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

With GST

- Follow the procedure “With CONSULT-II”.

PROCEDURE FOR DTC P0406

CAUTION:

Always drive vehicle at a safe speed.

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Confirm that EGR valve is not lifting.
 If the result is NG, perform trouble diagnosis for DTC P1402. Refer to [EC-1051](#) .
3. Select “DATA MONITOR” mode with CONSULT-II.
4. Read “EGR TEMP SEN” at about 1,500 rpm while holding the EGR valve in full open position by hand.
Voltage should decrease to less than 1.5V.
 If the result is NG, go to [EC-885, "Diagnostic Procedure"](#) .
 If the result is OK, go to following step.
5. Turn ignition switch OFF and wait at least 5 seconds.
6. Turn ignition switch ON.
7. Check the output voltage of “THRTL POS SEN” (at closed throttle position) and note it.
8. Start engine.
9. Maintain the following conditions for at least 5 consecutive seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V
B/FUEL SCHDL	XXX msec

SEF201Y

ENG SPEED	1,600 - 2,400 rpm (A/T models) 1,800 - 2,600 rpm (M/T models)
VHCL SPEED SE	Above 80°C (176°F)
B/FUEL SCHDL	6 - 9 msec
THRTL POS SEN	X – (X + 0.82) V X = Voltage value measured at step 7
Selector lever	Suitable position

10. If 1st trip DTC is detected, go to [EC-885, "Diagnostic Procedure"](#) .

Overall Function Check


UBS0080T

Use this procedure to check the overall function of the EGR temperature sensor. During this check, a 1st trip DTC might not be confirmed.


PROCEDURE FOR DTC P0406

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Confirm that EGR valve is not lifting. If NG, perform trouble diagnosis for DTC P1402. Refer to [EC-1051](#).



3. Check voltage between ECM terminal 63 (EGR temperature sensor signal) and ground at about 1,500 rpm with EGR valve lifted up to the full position by hand.
Voltage should decrease to less than 1.5V.
4. If NG, go to [EC-885. "Diagnostic Procedure"](#).
If OK, perform trouble diagnoses for DTC P0400 and P1400. Refer to P0400 [EC-866](#) and P1400 [EC-1045](#).



A
EC
C
D
E
F
G
H
I
J
K
L
M




DTC P0405, P0406 EGRT SENSOR

[VG33E]

UBS0080U

Wiring Diagram

EC-EGR/TS-01




BBWA0506E

Diagnostic Procedure

1. CHECK POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect EGR temperature sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 2.
 NG >> Repair harness or connectors.



2. CHECK GROUND CIRCUIT


1. Turn ignition switch "OFF".
2. Check harness continuity between EGR temperature sensor terminal 2 and engine ground. Refer to the Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the harness for open or short between EGR temperature sensor and ECM.

>> Repair open circuit or short to ground or short to power in harness or connector.

4. CHECK EGR TEMPERATURE SENSOR

Refer to [EC-886, "Component Inspection"](#).

OK or NG

- OK >> GO TO 5.
 NG >> Replace EGR temperature sensor.

5. CHECK INTERMITTENT INCIDENT


Perform [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection EGR TEMPERATURE SENSOR


UBS0080W

1. Check resistance change and resistance value.



<Reference data>

EGR temperature °C (°F)	Voltage [V]	Resistance MΩ
0 (32)	4.56	0.62 - 1.05
50 (122)	2.25	0.065 - 0.094
100 (212)	0.59	0.011 - 0.015



2. If NG, replace EGR temperature sensor.

Removal and Installation EGR TEMPERATURE SENSOR

UBS0080X

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

DTC P0420, P0430 THREE WAY CATALYST FUNCTION

PFP:20905


On Board Diagnosis Logic

UBS0080Y

The ECM monitors the switching frequency ratio of heated oxygen sensors 1 and 2.

A three way catalyst (Manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2. As oxygen storage capacity decreases, the heated oxygen sensor 2 switching frequency will increase.

When the frequency ratio of heated oxygen sensors 1 and 2 approaches a specified limit value, the three way catalyst (Manifold) malfunction is diagnosed.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0420 (Bank 1)	Catalyst system efficiency below threshold	<ul style="list-style-type: none"> ● Three way catalyst (Manifold) does not operate properly. ● Three way catalyst (Manifold) does not have enough oxygen storage capacity. 	<ul style="list-style-type: none"> ● Three way catalyst (Manifold) ● Exhaust tube ● Intake air leaks ● Fuel injectors ● Fuel injector leaks ● Spark plug ● Improper ignition timing
P0430 (Bank 2)			

DTC Confirmation Procedure

UBS0080Z


NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

TESTING CONDITION

- **Do not hold engine speed for more than the specified minutes below.**
- 1. Start engine and warm it up to the normal operating temperature.
- 2. Turn ignition switch "OFF" and wait at least 5 seconds.
- 3. Start engine and keep the engine speed at between 3,500 and 4,000 rpm for at least one minute under no load.
- 4. Let engine idle for one minute.
- 5. Open engine hood.
- 6. Select "DTC & SRT CONFIRMATION" then "SRT WORK SUPPORT" mode with CONSULT-II.
- 7. Rev engine up to 2,000 to 3,000 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely. If "INCMP" of "CATALYST" changed to "COMPLT", go to step 10.
- 8. Wait 5 seconds at idle.



DTC P0420, P0430 THREE WAY CATALYST FUNCTION

[VG33E]

- Rev engine up to 2,000 to 3,000 rpm and maintain it until "INCMP" of "CATALYST" changes to "CMPLT" (It will take approximately 5 minutes).
If not "CMPLT", perform the following.

SRT WORK SUPPORT	
CATALYST	CMPLT
EVAP SYSTEM	INCMP
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
THRTL POS SEN	XXX V

SEF345Z

- Select "SELF-DIAG RESULTS" mode with CONSULT-II.
- Confirm that the 1st trip DTC is not detected.
If the 1st trip DTC is detected, go to [EC-890, "Diagnostic Procedure"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	

SEF560X

Overall Function Check

UBS00810


Use this procedure to check the overall function of the three way catalyst (manifold). During this check, a DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

WITH GST

- Start engine and warm it up to the normal operation temperature.
- Turn ignition switch "OFF" and wait at least 10 seconds.
- Start engine and keep the engine speed at between 3,500 and 4,000 rpm for at least one minute under no load.
- Let engine idle for one minutes.
- Set voltmeters probes between ECM terminals 50 [HO2S1 (bank 1) signal], 51 [HO2S1 (bank 2) signal] and engine ground, and ECM terminals 56 [HO2S2 (bank 1) signal], 57 [HO2S2 (bank 2) signal] and engine ground.
- Keep engine speed at 2,000 rpm constant under no load.



DTC P0420, P0430 THREE WAY CATALYST FUNCTION

[VG33E]

7. Make sure that the voltage switching frequency (high & low) between ECM terminals 56 and engine ground, or 57 and engine ground, or 51 and engine ground.

Switching frequency ratio = A/B

A: Heated oxygen sensor 2 voltage switching frequency


B: Heated oxygen sensor 1 voltage switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, it means three way catalyst (manifold) does not operate properly. Go to [EC-890, "Diagnostic Procedure"](#).

NOTE:

If the voltage at terminal 50 or 51 does not switch periodically more than 5 times within 10 seconds at step 5, perform trouble diagnosis for "DTC P0133, P0153" first. (See [EC-767, "DTC P0133, P0153 HO2S1"](#).)



A

EC

C

D

E

F

G

H

I

J

K

L

M

Diagnostic Procedure

1. CHECK EXHAUST SYSTEM


Visually check exhaust tubes and muffler for dent.

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace it.

2. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before the three way catalyst (manifold).



OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.

3. CHECK INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.

4. CHECK IGNITION TIMING

Check the following items. Refer to [EC-637, "Basic Inspection"](#) .

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

OK or NG

- OK >> GO TO 5.
- NG >> Adjust ignition timing.


5. CHECK INJECTORS

1. Refer to [EC-1134, "Wiring Diagram"](#) .
2. Stop engine and then turn ignition switch ON.
3. Check voltage between ECM terminals 102, 104, 106, 109, 111 and 113 and ground with CONSULT-II or tester.

Battery voltage should exist.

OK or NG

- OK >> GO TO 6.
- NG >> Perform [EC-1135, "Diagnostic Procedure"](#) .




6. CHECK IGNITION SPARK

1. Turn ignition switch OFF.
2. Disconnect ignition wire from spark plug.
3. Connect a known good spark plug to the ignition wire.
4. Place end of spark plug against a suitable ground and crank engine.
5. Check for spark.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.




7. CHECK IGNITION WIRES

1. Inspect wires for cracks, damage, burned terminals and for improper fit.
2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks.

Resistance:

Cylinder No.	Resistance kΩ [at 25°C (77°F)]
1	Approx. 6.5
2	Approx. 10.0
3	Approx. 8.5
4	Approx. 12.5
5	Approx. 8.5
6	Approx. 11.0



If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.

OK or NG

- OK >> Check ignition coil, power transistor and their circuits. Refer to [EC-1127, "IGNITION SIGNAL"](#) .
- NG >> Replace.

8. CHECK INJECTOR

1. Turn ignition switch OFF.
2. Remove injector assembly.
Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .
Keep fuel hose and all injectors connected to injector gallery.
3. Disconnect all ignition coil harness connectors.
4. Turn ignition switch ON.
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip)>>GO TO 9.

NG (Drips)>>Replace the injector(s) from which fuel is dripping.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

Trouble is fixed>>**INSPECTION END.**

Trouble is not fixed>>Replace three way catalyst (manifold).

DTC P0441 EVAP CONTROL SYSTEM


PDF:14950

System Description

UBS00812

NOTE:

If DTC P0441 is displayed with P0510, perform trouble diagnosis for DTC P0510 first. (See [EC-983](#), "[DTC P0510 CLOSED TP SWITCH](#)".)



In this evaporative emission (EVAP) control system, purge flow occurs during non-closed throttle conditions. Purge volume is related to air intake volume. Under normal purge conditions (non-closed throttle), the EVAP canister purge volume control solenoid valve is open. Purge flow exposes the EVAP control system pressure sensor to intake manifold vacuum.

On Board Diagnosis Logic

UBS00813

Under normal conditions (non-closed throttle), sensor output voltage indicates if pressure drop and purge flow are adequate. If not, a malfunction is determined.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0441	EVAP control system incorrect purge flow	EVAP control system does not operate properly, EVAP control system has a leak between intake manifold and EVAP control system pressure sensor.	<ul style="list-style-type: none"> ● EVAP canister purge volume control solenoid valve stuck closed ● EVAP control system pressure sensor and the circuit ● Loose, disconnected or improper connection of rubber tube ● Blocked rubber tube ● Blocked or bent rubber tube to MAP/BARO switch solenoid valve ● Cracked EVAP canister ● EVAP canister purge volume control solenoid valve circuit ● Closed throttle position switch ● Blocked purge port ● EVAP canister vent control valve

DTC Confirmation Procedure

UBS00814

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Start engine and let it idle for at least 70 seconds.
4. Select "PURG FLOW P0442" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
5. Touch "START".
If "COMPLETED" is displayed, go to step 7.
6. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 35 seconds.)

Selector lever	Suitable position
Vehicle speed	32 - 120 km/h (20 - 75 MPH)
ENG SPEED	500 - 3,400 rpm
B/FUEL SCHDL	1.0 - 11.0 msec
Engine coolant temperature	70 - 100°C (158 - 212°F)



If "TESTING" is not changed for a long time, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-895, "Diagnostic Procedure"](#)

Overall Function Check


UBS00815

Use this procedure to check the overall monitoring function of the EVAP control system purge flow monitoring. During this check, a DTC might not be confirmed.

WITH GST

1. Lift up drive wheels.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF, wait at least 5 seconds.
4. Start engine and wait at least 70 seconds.
5. Set voltmeter probes to ECM terminals 62 (EVAP control system pressure sensor signal) and ground.
6. Check EVAP control system pressure sensor value at idle speed and note it.
7. Establish and maintain the following conditions for at least 1 minute.

Air conditioner switch	ON
Headlamp switch	ON
Rear window defogger switch	ON



Engine speed	Approx. 3,000 rpm
Gear position	Any position other than "P", "N" or "R"

8. Verify that EVAP control system pressure sensor value stays 0.1V less than the value at idle speed (measured at step 6) for at least 1 second.
9. If NG, go to [EC-895, "Diagnostic Procedure"](#) .

Diagnostic Procedure

UBS00816

1. CHECK EVAP CANISTER

1. Turn ignition switch OFF.
2. Check EVAP canister for cracks.


OK or NG

- OK (With CONSULT-II)>>GO TO 2.
- OK (Without CONSULT-II)>>GO TO 3.
- NG >> Replace EVAP canister.

2. CHECK PURGE FLOW

With CONSULT-II

1. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port and install vacuum gauge.
2. Start engine and let it idle.
3. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II.
4. Rev engine up to 2,000 rpm.



5. Touch "Qd" and "Qu" on CONSULT-II screen to adjust "PURG VOL CONT/V" opening.

PURG VOL CONT/V	VACUUM
100.0%	Should exist
0.0%	Should not exist

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 4.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V

SEF677Y

3. CHECK PURGE FLOW

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port and install vacuum gauge.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum gauge indication when revving engine up to 2,000 rpm.


Vacuum should exist.

6. Release the accelerator pedal fully and let idle.

Vacuum should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 4.



4. CHECK EVAP PURGE LINE


1. Turn ignition switch OFF.
2. Check EVAP purge line for improper connection or disconnection. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 5.
 NG >> Repair it.

5. CHECK EVAP PURGE HOSE AND PURGE PORT


1. Disconnect purge hoses connected to EVAP service port **A** and EVAP canister purge volume control solenoid valve **B**.
2. Blow air into each hose and EVAP purge port **C**.



3. Check that air flows freely.

OK or NG

- OK (with CONSULT-II) >> GO TO 6.
 OK (without CONSULT-II) >> GO TO 7.
 NG >> Repair or clean hoses and/or purge port.



6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.
If OK, inspection end. If NG, go to following step.

ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y


3. Check air passage continuity.

Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

If NG, replace the EVAP canister purge volume control solenoid valve.

OK or NG

- OK >> GO TO 8.
- NG >> Replace EVAP canister purge volume control solenoid valve.



7. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Without CONSULT-II


Check air passage continuity.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

If NG, replace the EVAP canister purge volume control solenoid valve.

OK or NG

- OK >> GO TO 8.
- NG >> Replace EVAP canister purge volume control solenoid valve.



8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE


1. Turn ignition switch OFF.
2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG

- OK >> GO TO 9.
- NG >> Repair it.

9. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.
Water should not exist.



OK or NG

- OK >> GO TO 10.
- NG >> Replace EVAP control system pressure sensor.

10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION

Refer to [EC-926, "DTC Confirmation Procedure"](#) or [EC-932, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> GO TO 11.
- NG >> Replace EVAP control system pressure sensor.

11. CHECK EVAP CANISTER VENT CONTROL VALVE

Check air passage continuity.

With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.

ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 (B1)	XXX V
HO2S1 (B2)	XXX V
THRTL POS SEN	XXX V

CONNECT O-ring

SEF013Z

Without CONSULT-II

1. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.

FUSE

BAT BATTERY

O-ring

3.2 – 4.8 N·m
0.33 – 0.49 kg·m,
29 – 43 in·lb

BBA0309E

OK or NG

- OK (With CONSULT-II)>>GO TO 12.
- OK (Without CONSULT-II)>>GO TO 13.
- NG >> Replace EVAP canister vent control valve.

12. CHECK CLOSED THROTTLE POSITION SWITCH

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Check indication of "CLSD THL/P SW".
Measurement must be made with closed throttle position switch installed in vehicle.

Throttle valve conditions	CLSD THL/P SW
Completely closed	ON
Partially open or completely open	OFF

If NG, adjust closed throttle position switch.
Check the following items. Refer to [EC-637, "Basic Inspection"](#).

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

6. If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.

OK or NG

- OK >> GO TO 14.
- NG >> Replace throttle position switch with throttle position sensor.

A
EC
C
D
E
F
G
H
I
J
K
L
M

13. CHECK CLOSED THROTTLE POSITION SWITCH

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect closed throttle position switch harness connector.
4. Check continuity between closed throttle position switch terminals 4 and 5.
Resistance measurement must be made with closed throttle position switch installed in vehicle.

Throttle valve conditions	Continuity
Completely closed	Yes
Partially open or completely closed	No

If NG, adjust closed throttle position switch.
Check the following items. Refer to [EC-637, "Basic Inspection"](#).

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

5. If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.

OK or NG

- OK >> GO TO 14.
- NG >> Replace throttle position switch with throttle position sensor.

14. CHECK EVAP PURGE LINE

Inspect EVAP purge line (pipe and rubber tube). Check for evidence of leaks.
Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 15.
- NG >> Replace it.

15. CLEAN EVAP PURGE LINE


Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 16.

16. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END.



DTC P0442 EVAP CONTROL SYSTEM

PFP:14950

On Board Diagnosis Logic

UBS00817


NOTE:

If DTC P0442 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See [EC-1076](#), "DTC P1448 EVAP CANISTER VENT CONTROL VALVE".)

This diagnosis detects leaks in the EVAP purge line using engine intake manifold vacuum.

If pressure does not increase, the ECM will check for leaks in the line between the fuel tank and EVAP canister purge volume control solenoid valve, under the following "Vacuum test" conditions.

The vacuum cut valve bypass valve is opened to clear the line between the fuel tank and the EVAP canister purge volume control solenoid valve. The EVAP canister vent control valve will then be closed to shut the EVAP purge line off. The EVAP canister purge volume control solenoid valve is opened to depressurize the EVAP purge line using intake manifold vacuum. After this occurs, the EVAP canister purge volume control solenoid valve will be closed.



PBIB1438E

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0442	EVAP control system small leak detected (negative pressure)	EVAP control system has a leak, EVAP control system does not operate properly.	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged ● water separator ● EVAP canister is saturated with water ● EVAP control system pressure sensor ● Fuel level sensor and the circuit ● Refueling EVAP vapor cut ● ORVR system leaks

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS00818

NOTE:

- If DTC P0442 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See [EC-1076, "DTC P1448 EVAP CANISTER VENT CONTROL VALVE"](#) .)
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


TESTING CONDITION:

- Perform "DTC WORK SUPPORT" when the fuel level is between 1/4 to 3/4 full and vehicle is placed on flat level surface.
- Open engine hood before conducting the following procedure.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
4. Make sure that the following conditions are met.
COOLAN TEMP/S: 0 - 32°C (32 - 90°F)
INT/A TEMP SE: More than 0°C (32°F)
5. Select "EVAP SML LEAK P0442" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.

Follow the instruction displayed.




NOTE:

If the engine speed cannot be maintained within the range displayed on the CONSULT-II screen, go to [EC-637, "Basic Inspection"](#) .

- Make sure that "OK" is displayed.
If "NG" is displayed, refer to [EC-904, "Diagnostic Procedure"](#) .

NOTE:

Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.



WITH GST

NOTE:

Be sure to read the explanation of [EC-620, "Driving Pattern"](#) before driving vehicle.

- Start engine.
- Drive vehicle according to [EC-620, "Driving Pattern"](#) .
- Stop vehicle.
- Select "MODE 1" with GST.
 - If SRT of EVAP system is not set yet, go to the following step.
 - If SRT of EVAP system is set, the result will be OK.
- Turn ignition switch OFF and wait at least 5 seconds.
- Start engine.

It is not necessary to cool engine down before driving.
- Drive vehicle again according to the [EC-620, "Driving Pattern"](#) .
- Stop vehicle.
- Select "MODE 3" with GST.
 - If P0442 is displayed on the screen, go to [EC-904, "Diagnostic Procedure"](#) .
 - If P0441 is displayed on the screen, go to [EC-895, "Diagnostic Procedure"](#) .
 - If P0442 and P0441 are not displayed on the screen, go to the following step.
- Select "MODE 1" with GST.
 - If SRT of EVAP system is set, the result will be OK.
 - If SRT of EVAP system is not set, go to step 6.


Diagnostic Procedure

1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch "OFF".
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

- OK >> GO TO 2.
NG >> Replace with genuine NISSAN fuel filler cap.



2. CHECK FUEL FILLER CAP INSTALLATION

Check that the cap is tightened properly by rotating the cap clockwise.

OK or NG

- OK >> GO TO 3.
NG >> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.
● Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION

Check for air releasing sound while opening the fuel filler cap.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE



Refer to [EC-1160, "FUEL TANK VACUUM RELIEF VALVE \(BUILT INTO FUEL FULLER CAP\)"](#) .

OK or NG

- OK >> GO TO 5.
NG >> Replace fuel filler cap with a genuine one.

5. INSTALL THE PRESSURE PUMP

To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely.

**NOTE:**

Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking.

Models with CONSULT-II>>GO TO 6.

Models without CONSULT-II>>GO TO 7.


6. CHECK FOR EVAP LEAK

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.
3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:

- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.




PEF917U

4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.



SEF200U


7. CHECK FOR EVAP LEAK

⊗ **Without CONSULT-II**

1. Turn ignition switch "OFF".
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#) .

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.



8. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A** , and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 9.
 NG >> Replace water separator.



9. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

Refer to [EC-1073, "Diagnostic Procedure"](#) .

OK or NG


- OK >> GO TO 10.
 NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connector.

10. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

- Yes >> GO TO 11.
- No (With CONSULT-II)>>GO TO 13.
- No (Without CONSULT-II)>>GO TO 14.



11. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK (With CONSULT-II)>>GO TO 13.
- OK (Without CONSULT-II)>>GO TO 14.
- NG >> GO TO 12.

12. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

13. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

With CONSULT-II

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode.
4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 15.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V

SEF677Y

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.
Vacuum should exist.

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 15.

15. CHECK VACUUM HOSE

Check vacuum hoses for clogging or disconnection. Refer to [EC-590, "Vacuum Hose Drawing"](#) .

OK or NG

- OK >> GO TO 16.
- NG >> Repair or reconnect the hose.

16. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 18.
- NG >> GO TO 17.


ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V

SEF677Y


17. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A or B
100.0%	Yes
0.0%	No




⊗ Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A or B
12V direct supply between terminals 1 and 2	Yes
No supply	No



OK or NG

OK >> GO TO 18.

NG >> Replace EVAP canister purge volume control solenoid valve.


18. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance between fuel level sensor unit and fuel pump terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

OK or NG

- OK >> GO TO 19.
 NG >> Replace fuel tank temperature sensor.



19. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch "ON".
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.


Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kPa (-200 mmHg, -7.87 inHg)	2.1 to 2.5V lower than above value

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK >> GO TO 20.
 NG >> Replace EVAP control system pressure sensor.



20. CHECK EVAP PURGE LINE

Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 21.
 NG >> Repair or reconnect the hose.

21. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 22.

22. CHECK REFUELING EVAP VAPOR LINE

Check refueling EVAP vapor line between EVAP canister and fuel tank for clogging, kink, looseness and improper connection. For location, refer to [EC-1163, "ON BOARD REFUELING VAPOR RECOVERY \(ORVR\)"](#).

OK or NG

- OK >> GO TO 23.
 NG >> Repair or replace hoses and tubes.

23. CHECK SIGNAL LINE AND RECIRCULATION LINE

Check signal line and recirculation line between filler neck tube and fuel tank for clogging, kink, cracks, looseness and improper connection.

OK or NG

OK >> GO TO 24.

NG >> Repair or replace hoses, tubes or filler neck tube.

24. CHECK REFUELING CONTROL VALVE

Refer to [EC-1163, "ON BOARD REFUELING VAPOR RECOVERY \(ORVR\)"](#) .

OK or NG

OK >> GO TO 25.

NG >> Replace refueling control valve with fuel tank.

25. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

OK >> GO TO 26.

NG >> Replace fuel level sensor unit.

26. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VG33E]

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PFP:14920

Description SYSTEM DESCRIPTION


UBS0081A

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Throttle position switch	Closed throttle position		
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Fuel tank temperature sensor	Fuel temperature in fuel tank		
Vehicle speed sensor	Vehicle speed		

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



CONSULT-II Reference Value in Data Monitor Mode

UBS0081B

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PURG VOL C/V	● Engine: After warming up ● Air conditioner switch OFF ● Shift lever: "N" ● No-load	Idle (Vehicle stopped) 0%
	2,000 rpm	—

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VG33E]

UBS0081C

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0444	EVAP canister purge volume control solenoid valve circuit open	An excessively low voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is open or shorted.) ● EVAP canister purge volume control solenoid valve
P0445	EVAP canister purge volume control solenoid valve circuit shorted	An excessively high voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is shorted.) ● EVAP canister purge volume control solenoid valve

DTC Confirmation Procedure

UBS0081D

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 13 seconds.
4. If 1st trip DTC is detected, go to [EC-917, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".


DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VG33E]

UBS0081E


Wiring Diagram

EC-PGC/V-01




- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 13
- LP : 15

A
EC
C
D
E
F
G
H
I
J
K
L
M



Refer to the following.
E43 - SUPER MULTIPLE JUNCTION (SMJ)





DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	OR/B	ECM relay (Self shut-off)	[Engine is running] [Ignition switch OFF] <ul style="list-style-type: none"> For a few seconds after turning ignition switch OFF 	0 - 1.5V
			[Ignition switch OFF] <ul style="list-style-type: none"> A few seconds passed after turning ignition switch OFF 	BATTERY VOLTAGE (11 - 14V)
5	R/Y	EVAP canister purge volume control solenoid valve	[Engine is running] <ul style="list-style-type: none"> Idle speed 	BATTERY VOLTAGE (11 - 14V)★  <small>SEF994U</small>
			[Engine is running] <ul style="list-style-type: none"> Engine speed is 2,000 rpm (More than 100 seconds after starting engine) 	BATTERY VOLTAGE (11 - 14V)★  <small>SEF995U</small>
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
117	B/P	Current return	[Engine is running] <ul style="list-style-type: none"> Idle speed 	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

1. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch ON.




4. Check voltage between EVAP canister purge volume control solenoid valve terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F36, M81
- Harness connectors M65, E43
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay

>> Repair harness or connectors.

3. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 5 and solenoid terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK (With CONSULT-II)>>GO TO 5.
- OK (Without CONSULT-II)>>GO TO 6.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

Ⓟ **With CONSULT-II**

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 6.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V


SEF677Y

6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓟ **With CONSULT-II**

1. Check air passage continuity under the following conditions.

Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No




⊗ **Without CONSULT-II**

1. Check air passage continuity under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

OK or NG

- OK >> GO TO 7.
 NG >> Replace EVAP canister purge volume control solenoid valve.



DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VG33E]

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P0447 EVAP CANISTER VENT CONTROL VALVE

PFP:14935

Component Description



UBS0081H

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid valve responds to signals from the ECM. When the ECM sends an ON signal, the coil in the solenoid valve is energized. A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS0081I

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

UBS0081J

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0447	EVAP canister vent control valve circuit open	An improper voltage signal is sent to ECM through EVAP canister vent control valve.	<ul style="list-style-type: none"> ● Harness or connectors (The valve circuit is open or shorted.) ● EVAP canister vent control valve

DTC Confirmation Procedure

UBS0081K

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.

DTC P0447 EVAP CANISTER VENT CONTROL VALVE

[VG33E]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 8 seconds.
4. If 1st trip DTC is detected, go to [EC-923, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A

EC

C

D

E

F

G

H

I

J

K

L

M

WITH GST

Follow the procedure "With CONSULT-II".


DTC P0447 EVAP CANISTER VENT CONTROL VALVE

[VG33E]


UBS0081L

Wiring Diagram

EC-VENT/V-01



- Refer to PG-POWER.
- : Detectable line for DTC
 - : Non-detectable line for DTC
 - : EARLY PRODUCTION
 - : LATE PRODUCTION
 - *1 : 21
 - : 23



WBWA0031E

DTC P0447 EVAP CANISTER VENT CONTROL VALVE

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
108	R/G	EVAP canister vent control valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS0081M

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK EVAP CANISTER VENT CONTROL VALVE CIRCUIT

 **With CONSULT-II**

1. Turn ignition switch "OFF" and then turn "ON".
2. Select "VENT CONTROL/V" in "ACTIVE TEST" mode with CONSULT-II.
3. Touch "ON/OFF" on CONSULT-II screen.
4. Check for operating sound of the valve.
Clicking noise should be heard.

OK or NG


- OK >> GO TO 7.
- NG >> GO TO 3.

ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 (B1)	XXX V
HO2S1 (B2)	XXX V
THRTL POS SEN	XXX V

SEF989Y

3. CHECK EVAP CANISTER VENT CONTROL VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect EVAP canister vent control valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M67, B101
- Harness connectors B113, C3
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between EVAP canister vent control valve and fuse

>> Repair harness or connectors.

5. CHECK EVAP CANISTER VENT CONTROL VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 108 and EVAP canister vent control valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M81, F36
- Harness for open or short between EVAP canister vent control valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.


7. CHECK EVAP CANISTER VENT CONTROL VALVE

With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.



Without CONSULT-II

1. Check air passage continuity and operation delay time under the following conditions.


Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.



OK or NG

OK >> GO TO 8.

NG >> Replace EVAP canister vent control valve.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.



DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

PFP:25085

Component Description

UBS0081N

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases. The EVAP control system pressure sensor is not used to control the engine system. It is used only for on board diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS0081O

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EVAP SYS PRES	● Ignition switch: ON	1.8 - 4.8V

On Board Diagnosis Logic

UBS0081P

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0452	EVAP control system pressure sensor low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● EVAP control system pressure sensor

DTC Confirmation Procedure

UBS0081Q

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.

DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33E]

4. Select "DATA MONITOR" mode with CONSULT-II.
5. Make sure that "FUEL T/TMP SE" is more than 0°C (32°F).
6. Start engine and wait at least 20 seconds.
7. If 1st trip DTC is detected, go to [EC-929, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANT TEMP/S	XXX °C
FUEL T/TMP SE	XXX °C

SEF194Y

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Check that voltage between ECM terminal 60 (Fuel tank temperature sensor signal) and ground is less than 4.2V.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and wait at least 20 seconds.
5. Select "MODE 7" with GST.
If 1st trip DTC is detected, go to [EC-929, "Diagnostic Procedure"](#).

A

EC

C

D

E

F

G

H

I

J

K

L


M

DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33E]


UBS0081R

Wiring Diagram



EC-PRE/SE-01

- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 19
- LP : 21



WBWA0032E

DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
42	B/W	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	BR	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
62	Y	EVAP control system pressure sensor	[Ignition switch ON]	1.8 - 4.8V

Diagnostic Procedure


UBS0081S

1. CHECK RUBBER TUBE

1. Turn ignition switch "OFF".
2. Check rubber tube connected to the sensor for clogging, vent, kink, disconnection or improper connection.

OK or NG


- OK >> GO TO 2.
NG >> Reconnect, repair or replace.



2. RETIGHTEN GROUND SCREWS

1. Loosen and retighten engine ground screws.

>> GO TO 3.



3. CHECK CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check sensor harness connector for water.
Water should not exist.

OK or NG

- OK >> GO TO 4.
NG >> Repair or replace harness connector.


4. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "ON".
2. Check voltage between terminal 3 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 6.
 NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M81, F36
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair harness or connectors.

6. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between EVAP control system pressure sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 8.
 NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair open circuit or short to power in harness or connectors.

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 62 and EVAP control system pressure sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between ECM and EVAP control system pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch "ON".
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.


Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kpa (-200 mmHg, -7.87 inHg)	2.1 to 2.5 V lower than above value

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK >> GO TO 14.
- NG >> Replace EVAP control system pressure sensor.



11. CHECK INTERMITTENT INCIDENT

Refer to [EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33E]



DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

PF2:25085

Component Description

UBS0081U

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases. The EVAP control system pressure sensor is not used to control the engine system. It is used only for on board diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS0081V

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EVAP SYS PRES	● Ignition switch: ON	1.8 - 4.8V

On Board Diagnosis Logic

UBS0081W

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0453	EVAP control system pressure sensor high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● EVAP control system pressure sensor ● EVAP canister vent control valve ● EVAP canister ● Water separator ● Rubber hose from EVAP canister vent control valve to water separator

DTC Confirmation Procedure

UBS0081X

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.

DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33E]

4. Select "DATA MONITOR" mode with CONSULT-II.
5. Make sure that "FUEL T/TMP SE" is more than 0°C (32°F).
6. Start engine and wait at least 20 seconds.
7. If 1st trip DTC is detected, go to [EC-935, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANT TEMP/S	XXX °C
FUEL T/TMP SE	XXX °C

SEF194Y

A

EC

C

D

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Check that voltage between ECM terminal 60 (Fuel tank temperature sensor signal) and ground is less than 4.2V.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and wait at least 20 seconds.
5. Select "MODE 7" with GST.
If 1st trip DTC is detected, go to [EC-935, "Diagnostic Procedure"](#).

E

F

G

H

I

J

K

L


M

DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33E]


UBS0081Y

Wiring Diagram



EC-PRE/SE-01

- : Detectable line for DTC
- : Non-detectable line for DTC
- : EARLY PRODUCTION
- : LATE PRODUCTION
- *1 : 19
- : 21



WBWA0032E

DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
42	B/W	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	BR	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
62	Y	EVAP control system pressure sensor	[Ignition switch ON]	1.8 - 4.8V

Diagnostic Procedure


UBS0081Z

1. CHECK RUBBER TUBE

1. Turn ignition switch "OFF".
2. Check rubber tube connected to the sensor for clogging, vent, kink, disconnection or improper connection.

OK or NG


- OK >> GO TO 2.
NG >> Reconnect, repair or replace.



2. RETIGHTEN GROUND SCREWS

1. Loosen and retighten engine ground screws.

>> GO TO 3.



3. CHECK CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check sensor harness connector for water.
Water should not exist.

OK or NG

- OK >> GO TO 4.
NG >> Repair or replace harness connector.


4. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "ON".
2. Check voltage between terminal 3 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M81, F36
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair harness or connectors.

6. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between EVAP control system pressure sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair open circuit or short to power in harness or connectors.

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 62 and EVAP control system pressure sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between ECM and EVAP control system pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

A
EC
C
D
E
F
G
H
I
J
K
L
M


10. CHECK EVAP CANISTER VENT CONTROL VALVE

With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.



Without CONSULT-II

1. Check air passage continuity and operation delay time under the following conditions.


Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.



OK or NG

OK >> GO TO 11.

NG >> Replace EVAP canister vent control valve.

11. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch "ON".
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.

Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kPa (-200 mmHg, -7.87 inHg)	2.1 to 2.5 V lower than above value


CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

OK >> GO TO 12.

NG >> Replace EVAP control system pressure sensor.



12. CHECK RUBBER TUBE

Check obstructed rubber tube connected to EVAP canister vent control valve.

OK or NG

- OK >> GO TO 13.
- NG >> Clean, repair or replace rubber tube.

13. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 14.
- NG >> Replace water separator.




14. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

- Yes >> GO TO 15.
- No >> GO TO 17.



15. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 16.

16. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

17. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0455 EVAP CONTROL SYSTEM

PFP:14950


On Board Diagnosis Logic

UBS00821

NOTE:

If DTC P0455 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. ([EC-1076, "DTC P1448 EVAP CANISTER VENT CONTROL VALVE"](#) .)

This diagnosis detects a very large leak (fuel filler cap fell off etc.) in EVAP system between the fuel tank and EVAP canister purge volume control solenoid valve.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0455	EVAP control system gross leak detected	EVAP control system has a very large leak such as fuel filler cap fell off, EVAP control system does not operate properly.	<ul style="list-style-type: none"> ● Fuel filler cap remains open or fails to close. ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent. ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged. ● EVAP control system pressure sensor ● Refueling control valve ● ORVR system leaks

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS00822

CAUTION:

Never remove fuel filter cap during the DTC confirmation procedure.

NOTE:


- If DTC P0455 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See [EC-1076](#).)
- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Perform “DTC WORK SUPPORT” when the fuel level is between 1/4 to 3/4 full and vehicle is placed on flat level surface.
- Open engine hood before conducting the following procedure.

WITH CONSULT-II

1. Tighten fuel filler cap securely until ratcheting sound is heard.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 5 seconds.
4. Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
5. Make sure that the following conditions are met.
COOLAN TEMP/S: 0 - 32°C (32 - 90°F)
INT/A TEMP SE: More than 0°C (32°F)
6. Select “EVAP SML LEAK P0442” of “EVAPORATIVE SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II.
 Follow the instruction displayed.




PBIB0829E

NOTE:

If the engine speed cannot be maintained within the range displayed on the CONSULT-II screen, go to [EC-637, "Basic Inspection"](#).

7. Make sure that "OK" is displayed.
If "NG" is displayed, select "SELF-DIAG RESULTS" mode with CONSULT-II and make sure that "EVAP GROSS LEAK [P0455] is displayed, refer to [EC-943, "Diagnostic Procedure"](#) .
If P0442 is displayed, perform [EC-904, "Diagnostic Procedure"](#) .



WITH GST

NOTE:

Be sure to read the explanation of [EC-620, "Driving Pattern"](#) before driving vehicle.

1. Start engine.
2. Drive vehicle according to [EC-620, "Driving Pattern"](#) .
3. Stop vehicle.
4. Select "MODE 1" with GST.
 - If SRT of EVAP system is not set yet, go to the following step.
 - If SRT of EVAP system is set, the result will be OK.
5. Turn ignition switch "OFF" and wait at least 5 seconds.
6. Start engine.
It is not necessary to cool engine down before driving.
7. Drive vehicle again according to [EC-620, "Driving Pattern"](#) .
8. Stop vehicle.
9. Select "MODE 3" with GST.
 - If P0455 is displayed on the screen, go to [EC-943, "Diagnostic Procedure"](#) .
 - If P0442 or P1442 is displayed on the screen, go to [EC-904, "Diagnostic Procedure"](#) or [EC-1060, "Diagnostic Procedure"](#) .
 - If P0441 is displayed on the screen, go to [EC-895, "Diagnostic Procedure"](#) .
 - If P0442, P0455 and P0441 are not displayed on the screen, go to the following step.
10. Select "MODE 1" with GST.
 - If SRT of EVAP system is set, the result will be OK.
 - If SRT of EVAP system is not set, go to step 6.

Diagnostic Procedure


UBS00823

1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch OFF.
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

- OK >> GO TO 2.
NG >> Replace with genuine NISSAN fuel filler cap.



2. CHECK FUEL FILLER CAP INSTALLATION

Check that the cap is tightened properly by rotating the cap clockwise.

OK or NG

OK >> GO TO 3.

NG >> 1. Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.
2. Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION

Check for air releasing sound while opening the fuel filler cap.

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP)

Refer to [EC-1734, "FUEL TANK VACUUM RELIEF VALVE \(BUILT INTO FUEL FULLER CAP\)"](#)

OK or NG

OK >> GO TO 5.

NG >> Replace fuel filler cap with a genuine one.

5. CHECK EVAP PURGE LINE

Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks, improper connection or disconnection.

Refer to "Evaporative [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#) .

OK or NG

OK >> GO TO 6.

NG >> Repair or reconnect the hose.

6. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 7.

7. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

Refer to [EC-1076, "DTC Confirmation Procedure"](#) .


OK or NG

OK >> GO TO 8.

NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connector.


8. INSTALL THE PRESSURE PUMP

To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely.



NOTE:
Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking.

Models with CONSULT-II>>GO TO 9.
Models without CONSULT-II>>GO TO 10.




9. CHECK FOR EVAP LEAK

With CONSULT-II

1. Turn ignition switch ON.
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.
3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 11.
- NG >> Repair or replace.




10. CHECK FOR EVAP LEAK

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 12.
 NG >> Repair or replace.



11. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

Ⓜ With CONSULT-II

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode.
4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 14.
 NG >> GO TO 13.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V

SEF677Y

12. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 15.
- NG >> GO TO 13.

13. CHECK VACUUM HOSE

Check vacuum hoses for clogging or disconnection. Refer to [EC-590, "Vacuum Hose Drawing"](#).

OK or NG

- OK (With CONSULT-II)>>GO TO 14.
- OK (Without CONSULT-II)>>GO TO 15.
- NG >> Repair or reconnect the hose.

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.
If OK, inspection end. If NG, go to following step.

ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V


SEF985Y

3. Check air passage continuity.

Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

OK or NG



- OK >> GO TO 16.
- NG >> Replace EVAP canister purge volume control solenoid valve.



15. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

⊗ **Without CONSULT-II**
Check air passage continuity.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No




OK or NG

- OK >> GO TO 16.
- NG >> Replace EVAP canister purge volume control solenoid valve.

16. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance between fuel level sensor unit terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.78 - 0.90




OK or NG

- OK >> GO TO 17.
- NG >> Replace fuel tank temperature sensor.

17. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch ON.
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.



5. Check input voltage between ECM terminal 62 and ground.


Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kPa (-200 mmHg, -7.87 inHg)	2.1 to 2.5V lower than above value

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK >> GO TO 18.
- NG >> Replace EVAP control system pressure sensor.



18. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0456 EVAP CONTROL SYSTEM

PF0:14950

On Board Diagnosis Logic


UBS00824

This diagnosis detects very small leaks in the EVAP line between fuel tank and EVAP canister purge volume control solenoid valve, using the intake manifold vacuum in the same way as conventional EVAP small leak diagnosis.

If ECM judges a leak which corresponds to a very small leak, the very small leak P0456 will be detected.

If ECM judges a leak equivalent to a small leak, EVAP small leak P0442 will be detected.

If ECM judges there are no leaks, the diagnosis will be OK.



DTC P0456 EVAP CONTROL SYSTEM

[VG33E]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0456	Evaporative emission control system very small leak (negative pressure check)	<ul style="list-style-type: none"> ● EVAP system has a very small leak. ● EVAP system does not operate properly. 	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged ● Water separator ● EVAP canister is saturated with water ● EVAP control system pressure sensor ● Refueling control valve ● ORVR system leaks ● Fuel level sensor and the circuit ● Foreign matter caught in EVAP canister purge volume control solenoid valve

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS00825

CAUTION:

Never remove fuel filler cap during the DTC confirmation procedure.

NOTE:


- If DTC P0456 or P1456 is displayed with P0442, first perform trouble diagnosis for DTC P0456 or P1456.
- After repair, make sure that the hoses and clips are installed properly.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Open engine hood before conducting following procedure.
- If any of following condition is met just before the DTC confirmation procedure, leave the vehicle for more than 1 hour.
 - Fuel filler cap is removed.
 - Refilled or drained the fuel.
 - EVAP component parts is/are removed.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Make sure the following conditions are met.
FUEL LEVEL SE: 1.08 - 0.2V
COOLAN TEMP/S: 0 - 35°C (32 - 95°F)
FUEL T/TMP SE: 0 - 32°C (32 - 90°F)
INT A/TEMP SE: More than 0°C (32°F)
 If NG, turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle) or refilling/draining fuel until the output voltage condition of the "FUEL LEVEL SE" meets within the range above and leave the vehicle for more than 1 hour. Then start from step 1).
3. Turn ignition switch "OFF" and wait at least 5 seconds.
4. Turn ignition switch "ON".
5. Select "EVAP V/S LEAK P0456/P1456" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
 Follow the instruction displayed.



6. Make sure that "OK" is displayed.
 If "NG" is displayed, refer to [EC-953, "Diagnostic Procedure"](#).

NOTE:

- If the engine speed cannot be maintained within the range displayed on CONSULT-II screen, go to [EC-637, "Basic Inspection"](#).
- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

Overall Function Check

UBS00826


WITH GST

Use this procedure to check the overall function of the EVAP very small leak function. During this check, a DTC might not be confirmed.

CAUTION:

- Never use compressed air, doing so may damage the EVAP system.
- Do not start engine.
- Do not exceeded 4.12 kPa (0.042 kg/cm², 0.6 psi).

1. Attach the EVAP service port adapter securely to the EVAP service port.
2. Set the pressure pump and a hose.
3. Also set a vacuum gauge via 3-way connector and a hose.
4. Turn ignition switch "ON".
5. Connect GST and select mode 8.
6. Using mode 8 control the EVAP canister vent control valve (close) and vacuum cut valve bypass valve (open).
7. Apply pressure and make sure the following conditions are satisfied.



Pressure to be applied: 2.7 kPa (20 mmHg, 0.79 inHg)

Time to be waited after the pressure drawn in to the EVAP system and the pressure to be dropped: 60 seconds and the pressure should not be dropped more than 0.4 kPa (3 mmHg, 0.12 inHg)

If NG, go to [EC-953, "Diagnostic Procedure"](#) .

NOTE:

For more information, refer to GST instruction manual.

Diagnostic Procedure


UBS00827

1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch "OFF".
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

- OK >> GO TO 2.
NG >> Replace with genuine NISSAN fuel filler cap.

**2. CHECK FUEL FILLER CAP INSTALLATION**

Check that the cap is tightened properly by rotating the cap clockwise.

OK or NG

- OK >> GO TO 3.
NG >> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.
● Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION

Check for air releasing sound while opening the fuel filler cap.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE


Refer to [EC-1160, "FUEL TANK VACUUM RELIEF VALVE \(BUILT INTO FUEL FULLER CAP\)"](#)

OK or NG

- OK >> GO TO 5.
NG >> Replace fuel filler cap with a genuine one.


5. INSTALL THE PRESSURE PUMP

To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely.



NOTE:
Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking.

Models with CONSULT-II>>GO TO 6.
Models without CONSULT-II>>GO TO 7.




6. CHECK FOR EVAP LEAK

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.
3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 8.
NG >> Repair or replace.




7. CHECK FOR EVAP LEAK

⊗ **Without CONSULT-II**

1. Turn ignition switch "OFF".
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#) .

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.



8. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A** , and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

Do not disassemble water separator.

OK or NG

- OK >> GO TO 9.
 NG >> Replace water separator.



9. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

Refer to [EC-1070, "DTC Confirmation Procedure"](#) .

OK or NG


- OK >> GO TO 10.
 NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connector.

10. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Does water drain from the EVAP canister?

Yes or No

- Yes >> GO TO 11.
- No (With CONSULT-II)>>GO TO 13.
- No (Without CONSULT-II)>>GO TO 14.



11. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK (With CONSULT-II)>>GO TO 13.
- OK (Without CONSULT-II)>>GO TO 14.
- NG >> GO TO 12.

12. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

13. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

With CONSULT-II

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode.
4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 16.
- NG >> GO TO 15.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V

SEF677Y

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 15.

15. CHECK VACUUM HOSE

Check vacuum hoses for clogging or disconnection. Refer to [EC-590, "Vacuum Hose Drawing"](#).

OK or NG

- OK (With CONSULT-II)>>GO TO 16.
- OK (Without CONSULT-II)>>GO TO 17.
- NG >> Repair or reconnect the hose.

16. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ **With CONSULT-II**

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 18.
- NG >> GO TO 17.


ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y


17. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A and B
100 %	Yes
0.0%	No




⊗ Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No



OK or NG

OK >> GO TO 18.

NG >> Replace EVAP canister purge volume control solenoid valve.


18. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance between fuel level sensor unit terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

OK or NG

- OK >> GO TO 19.
 NG >> Replace fuel level sensor unit.



19. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch "ON".
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.


Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kPa (-200 mmHg, -7.87 inHg)	2.1 to 2.5V lower than above value

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK >> GO TO 20.
 NG >> Replace EVAP control system pressure sensor.



20. CHECK EVAP PURGE LINE

Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 21.
 NG >> Repair or reconnect the hose.

21. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 22.

22. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#).

OK or NG

- OK >> GO TO 23.
 NG >> Replace fuel level sensor unit.

23. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END.

DTC P0460 FUEL LEVEL SENSOR

Component Description

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



On Board Diagnosis Logic

When the vehicle is parked, naturally the fuel level in the fuel tank is stable. It means that output signal of the fuel level sensor does not change. If ECM senses sloshing signal from the sensor, fuel level sensor malfunction is detected.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0460	Fuel level sensor circuit noise	Even though the vehicle is parked, a signal being varied is sent from the fuel level sensor to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Fuel level sensor

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and wait maximum of 2 consecutive minutes.
4. If 1st trip DTC is detected, go to [EC-963, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
FUEL T/TMP SE	XXX °C
FUEL LEVEL SE	XXX V

WITH GST

Follow the procedure “WITH CONSULT-II” above.



DTC P0460 FUEL LEVEL SENSOR

[VG33E]

UBS0082B

Wiring Diagram

EC-FLS1-01



Refer to the following.
 (F29) - ELECTRICAL UNITS

DTC P0460 FUEL LEVEL SENSOR

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	G	Fuel level sensor	[Ignition switch ON]	Approximately 0 - 4.8V Output voltage varies with fuel level.
66	B	Fuel level sensor ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS0082C


1. CHECK FUEL LEVEL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit harness connector.
3. Turn ignition switch "ON".
4. Check voltage between fuel level sensor unit terminal 2 and ground with CONSULT-II or a tester.

Voltage: Approximately 12V

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, B103
- Harness for open or short between combination meter and fuel level sensor unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between fuel level sensor unit terminal 4 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check harness for open or short between fuel level sensor unit and ground

>> Repair open circuit or short to power in harness or connectors.

5. CHECK FUEL LEVEL SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 46 and fuel level sensor unit terminal 2, ECM terminal 66 and ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, B103
- Harness connectors M81, F36
- Harness for open or short between ECM and ground

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

- OK >> GO TO 8.
NG >> Replace fuel level sensor unit.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

Removal and Installation FUEL LEVEL SENSOR

UBS0082D


Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

DTC P0461 FUEL LEVEL SENSOR

Component Description

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



UBS0082F

On Board Diagnosis Logic

Driving long distances naturally affect fuel gauge level.

This diagnosis detects the fuel gauge malfunction of the gauge not moving even after a long distance has been driven.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0461	Fuel level sensor circuit range/performance	The output signal of the fuel level sensor does not change within the specified range even though the vehicle has been driven a long distance.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Fuel level sensor

Overall Function Check

UBS0082G

Use this procedure to check the overall function of the fuel level sensor function. During this check, a 1st trip DTC might not be confirmed.

WARNING:

When performing following procedure, be sure to observe the handling of the fuel. Refer to [FL-3, "FUEL TANK"](#).

TESTING CONDITION:

Before starting overall function check, preparation of draining fuel and refilling fuel is required.

WITH CONSULT-II

NOTE:

Start from step 11, if it is possible to confirm that the fuel cannot be drained by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) in advance.

1. Prepare a fuel container and a spare hose.
2. Release fuel pressure from fuel line, refer to [EC-608, "FUEL PRESSURE RELEASE"](#).
3. Remove the fuel feed hose on the fuel level sensor unit.
4. Connect a spare fuel hose where the fuel feed hose was removed.
5. Turn ignition switch "OFF" and wait at least 5 seconds then turn "ON".
6. Select "FUEL LEVEL SE" in "DATA MONITOR" mode with CONSULT-II.
7. Check "FUEL LEVEL SE" output voltage and note it.
8. Select "FUEL PUMP" in "ACTIVE TEST" mode with CONSULT-II.
9. Touch "ON" and drain fuel approximately 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) and stop it.
10. Fill fuel into the fuel tank for 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal).
11. Check "FUEL LEVEL SE" output voltage and note it.
12. Check "FUEL LEVEL SE" output voltage and confirm whether the voltage changes more than 0.03V during step 7 to 11.

If NG, check the fuel level sensor, refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#).

DATA MONITOR	
MONITOR	NO DTC
FUEL T/TMP SE	XXX °C
FUEL LEVEL SE	XXX V


SEF195Y

 WITH GST
NOTE:

Start from step 11, if it is possible to confirm that the fuel cannot be drained by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) in advance.

1. Prepare a fuel container and a spare hose.
2. Release fuel pressure from fuel line, refer to [EC-608, "FUEL PRESSURE RELEASE"](#) .
3. Remove the fuel feed hose on the fuel level sensor unit.
4. Connect a spare fuel hose where the fuel feed hose was removed.
5. Turn ignition switch "OFF".
6. Set voltmeters probe between ECM terminal 46 (fuel level sensor signal) and ground.
7. Turn ignition switch "ON".
8. Check voltage between ECM terminal 46 and ground and note it.
9. Drain fuel by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) from the fuel tank using proper equipment.
10. Fill fuel into the fuel tank for 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal).
11. Confirm that the voltage between ECM terminal 46 and ground changes more than 0.03V during step 8 - 10.

If NG, check component of fuel level sensor, refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .




DTC P0462, P0463 FUEL LEVEL SENSOR

Component Description

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



UBS0082I

On Board Diagnosis Logic

ECM receives two signals from the fuel level sensor circuit.

One is fuel level sensor power supply circuit, and the other is fuel level sensor ground circuit.

This diagnosis indicates the former, to detect open or short circuit malfunction.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0462	Fuel level sensor circuit low input	An excessively low voltage is sent from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Fuel level sensor
P0463	Fuel level sensor circuit high input	An excessively high voltage is sent from the sensor is sent to ECM.	

DTC Confirmation Procedure

UBS0082J

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at ignition switch "ON".

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-969, "Diagnostic Procedure"](#)



WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P0462, P0463 FUEL LEVEL SENSOR

[VG33E]


Wiring Diagram

UBS0082K

EC-FLS2-01



Refer to the following.
(F29) - ELECTRICAL UNITS



WBWA0034E

DTC P0462, P0463 FUEL LEVEL SENSOR

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	G	Fuel level sensor	[Ignition switch "ON"]	Approximately 0 - 4.8V Output voltage varies with fuel level.
66	B	Fuel level sensor ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS0082L


1. CHECK FUEL LEVEL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit harness connector.
3. Turn ignition switch "ON".
4. Check voltage between fuel level sensor unit terminal 2 and ground with CONSULT-II or tester.

Voltage: Approximately 12V

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, B103
- Harness for open or short between combination meter and fuel level sensor unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between fuel level sensor unit terminal 4 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check harness for open or short between fuel level sensor unit and ground.

>> Repair open circuit or short to power in harness or connectors.

5. CHECK FUEL LEVEL SENSOR INPUT CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 46 and fuel level sensor unit terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, B103
- Harness connectors M81, F36
- Harness for open or short between ECM and fuel level sensor unit

>> Repair open circuit or short to ground or short to power in harness on connectors.

7. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

- OK >> GO TO 8.
NG >> Replace fuel level sensor unit.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

Removal and Installation FUEL LEVEL SENSOR


UBS0082M

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

DTC P0500 VSS

Component Description

The vehicle speed sensor is installed in the transmission. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0500	Vehicle speed sensor	The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven.	<ul style="list-style-type: none"> ● Harness or connectors (The vehicle speed sensor circuit is open or shorted.) ● Vehicle speed sensor

DTC Confirmation Procedure

CAUTION:
Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Steps 1 and 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
B/FUEL SCHDL	XXX msec
PW/ST SIGNAL	OFF
VHCL SPEED SE	XXX km/h

WITH CONSULT-II

1. Start engine.
2. Read “VHCL SPEED SE” in “DATA MONITOR” mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
If NG, go to [EC-974, "Diagnostic Procedure"](#) .
If OK, go to following step.
3. Select “DATA MONITOR” mode with CONSULT-II.
4. Warm engine up to normal operating temperature.
5. Maintain the following conditions for at least 60 consecutive seconds.

END SPEED	More than 1,800 rpm (A/T models) More than 1,900 rpm (M/T models)
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	5.5 - 16.0 msec

Selector lever	Suitable position
PW/ST SIGNAL	OFF

6. If 1st trip DTC is detected, go to [EC-974, "Diagnostic Procedure"](#).

Overall Function Check

UBS0082Q


Use this procedure to check the overall function of the vehicle speed sensor circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Lift up drive wheels.
2. Start engine.
3. Read vehicle speed sensor signal in "MODE 1" with GST.
The vehicle speed sensor on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
4. If NG, go to [EC-974, "Diagnostic Procedure"](#).

Wiring Diagram


EC-VSS-01



Refer to PG-POWER.

- : Detectable line for DTC
- : Non-detectable line for DTC
- : With M/T
- : With A/T
- : EARLY PRODUCTION
- : LATE PRODUCTION
- *1 : 23
- : 12


COMBINATION METER (SPEEDOMETER) (M38, M39)



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
29	G/B	Vehicle speed sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Lift up the vehicle. ● In 2nd gear position ● Vehicle speed is 40 km/h (25 MPH) 	<p>2 - 3V★</p> 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

UBS0082S

1. CHECK VEHICLE SPEED SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and combination meter harness connector.
3. Check harness continuity between ECM terminal 29 and combination meter terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Harness for open or short between ECM and combination meter

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK SPEEDOMETER FUNCTION

Make sure that speedometer functions properly.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. CHECK SPEEDOMETER CIRCUIT FOR OPEN AND SHORT

Check the following.

- Harness connectors M58, F28
- Harness connectors F43, F201
- Harness for open or short between combination meter and vehicle speed sensor

OK or NG

- OK >> Check combination meter and vehicle speed sensor. Refer to [DI-3, "METERS AND GAUGES"](#).
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P0505 ISC SYSTEM

**Description
SYSTEM DESCRIPTION**


Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Idle air control	IACV-AAC valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Park/neutral position (PNP) switch	Park/neutral position		
Air conditioner switch	Air conditioner operation		
Power steering oil pressure switch	Power steering load signal		
Battery	Battery voltage		
Vehicle speed sensor	Vehicle speed		
Ambient air temperature switch	Ambient air temperature		
Intake air temperature sensor	Intake air temperature		

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which bypasses the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner and power steering).

COMPONENT DESCRIPTION

IACV-AAC Valve

The IACV-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
IACV-AAC/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	10 - 20%
		2,000 rpm	—

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name		DTC detecting condition	Possible cause
P0505	A)	Idle speed control system circuit	The IACV-AAC valve does not operate properly	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open) ● IACV-AAC valve
	B)	Idle speed control system RPM lower than expected	The IACV-AAC valve does not operate properly	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open) ● IACV-AAC valve
	C)	Idle speed control system RPM higher than expected	The IACV-AAC valve does not operate properly	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open) ● IACV-AAC valve

DTC Confirmation Procedure

NOTE:

- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.
- Perform “PROCEDURE FOR MALFUNCTION A” first. If 1st trip DTC cannot confirmed, perform “PROCEDURE FOR MALFUNCTION B AND C”.


PROCEDURE FOR MALFUNCTION A

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch “ON”.

With CONSULT-II

1. Turn ignition switch ON.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Wait at least 2 seconds.
4. If 1st trip DTC is detected, go to [EC-980, "Diagnostic Procedure"](#)



With GST

Follow the procedure “With CONSULT-II”.

PROCEDURE FOR MALFUNCTION B AND C

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 5 seconds.

DTC P0505 ISC SYSTEM

[VG33E]

3. Turn ignition switch "ON" again and select "DATA MONITOR" mode with CONSULT-II.
4. Start engine and run it for at least 1 minute at idle speed.
5. If 1st trip DTC is detected, go to [EC-980, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y




With GST

Follow the procedure "With CONSULT-II".

Wiring Diagram



EC-AAC/V-01



Refer to PG-POWER .

: Detectable line for DTC
 : Non-detectable line for DTC
EP : EARLY PRODUCTION
LP : LATE PRODUCTION
 *1 EP : 14
 LP : 16



A
EC
C
D
E
F
G
H
I
J
K
L
M



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	OR/L	IACV-AAC valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>8 - 11V★</p>  <p style="text-align: right; font-size: small;">SEF005V</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 3,000 rpm 	<p>7 - 10V★</p>  <p style="text-align: right; font-size: small;">SEF692W</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

UBS0082Z

1. CHECK IACV-AAC VALVE POWER SUPPLY CIRCUIT

1. Stop engine.
2. Disconnect IACV-AAC valve harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Harness connectors F37, F101
- Fuse block (J/B) connector M27
- 10A fuse
- Harness for open or short between IACV-AAC valve and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK IACV-AAC VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 101 and IACV-AAC valve terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F101, F37
- Harness for open or short between IACV-AAC valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK IACV-AAC VALVE

1. Disconnect IACV-AAC valve harness connector.
2. Remove IACV-AAC valve.
- Check IACV-AAC valve resistance.

Resistance : Approximately 10Ω [at 20°C (68°F)]


- Check plunger for seizing or sticking.
- Check for broken spring.
- 3. Supply battery voltage between IACV-AAC valve connector terminals.

Plunger should move.

OK or NG

OK >> GO TO 6.

NG >> Replace IACV-AAC valve.



6. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END.

Removal and Installation

IACV-AAC VALVE

UBS00830


Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

DTC P0510 CLOSED TP SWITCH

Component Description

A closed throttle position switch and wide open throttle position switch are built into the throttle position sensor unit. The wide open throttle position switch is used only for A/T control.

When the throttle valve is in the closed position, the closed throttle position switch sends a voltage signal to the ECM. The ECM only uses this signal to open or close the EVAP canister purge volume control solenoid valve when the throttle position sensor is malfunctioning.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
CLSD THL/P SW	● Engine: After warming up, idle the engine	Throttle valve: Idle position ON
		Throttle valve: Slightly open OFF

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0510	Closed throttle position switch	Battery voltage from the closed throttle position switch is sent to ECM with the throttle valve opened	<ul style="list-style-type: none"> ● Harness or connectors (The closed throttle position switch circuit is open or shorted) ● Closed throttle position switch ● Throttle position sensor

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF, wait at least 10 seconds and then start engine.
3. Select "CLSD THL/P SW" in "DATA MONITOR" mode.
4. Check the signal under the following conditions.

Condition	Signal indication
Throttle valve: Idle position	ON
Throttle valve: Slightly open	OFF

If the result is NG, go to [EC-986, "Diagnostic Procedure"](#) .
If OK, go to following step.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
CLSD THL/P SW	ON

SEF197Y

DTC P0510 CLOSED TP SWITCH

[VG33E]

5. Select "DATA MONITOR" mode with CONSULT-II.
6. Drive the vehicle for at least 5 consecutive seconds under the following condition.

THRTL POS SEN	More than 2.5V
VHCL SPEED SE	More than 5 km/h (3 MPH)
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

DATA MONITOR	
MONITOR	NO DTC
COOLANT TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V

SEF198Y

7. If 1st trip DTC is detected, go to [EC-986, "Diagnostic Procedure"](#)

Overall Function Check

UBS0083J

Use this procedure to check the overall function of the closed throttle position switch circuit. During this check, a 1st trip DTC might not be confirmed.


WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Check the voltage between ECM terminal 28 (Closed throttle position switch signal) and ground under the following conditions.

At idle : **Battery voltage**

At 2,000 rpm : **Approximately 0V**

3. If NG, go to [EC-986, "Diagnostic Procedure"](#).









DTC P0510 CLOSED TP SWITCH

[VG33E]

UBS0083K

Wiring Diagram

EC-TP/SW-01



BBWA0490E

DTC P0510 CLOSED TP SWITCH

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
28	BR/W	Throttle position switch (Closed position)	[Engine is running] ● Warm-up condition ● Accelerator pedal fully released	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] ● Accelerator pedal depressed	Approximately 0V

Diagnostic Procedure

UBS0083L

1. CHECK CLOSED THROTTLE POSITION SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect throttle position switch harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 5 and engine ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between throttle position switch and ECM relay
- Harness for open or short between throttle position switch and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK CLOSED THROTTLE POSITION SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 28 and throttle position switch terminal 4.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK IGNITION TIMING AND ENGINE IDLE SPEED

Check the following items. Refer to [EC-637, "Basic Inspection"](#) .

Items	Specifications
Ignition timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Target idle speed	750 ± 50 rpm (in P or N position)

With CONSULT-II>>GO TO 5.

Without CONSULT-II>>GO TO 6.

5. CHECK CLOSED THROTTLE POSITION SWITCH

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Check indication of "CLSD THL/P SW".
Measurement must be made with closed throttle position switch installed in vehicle.

Throttle valve conditions	CLSD THL/P SW
Completely closed	ON
Partially open or completely closed	OFF

OK or NG

OK >> GO TO 8.

NG >> GO TO 7.

6. CHECK CLOSED THROTTLE POSITION SWITCH


 **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect closed throttle position switch harness connector.
4. Check continuity between closed throttle position switch terminals 4 and 5.
Resistance measurement must be made with closed throttle position switch installed in vehicle.

Throttle valve conditions	Continuity
Completely closed	Yes
Partially open or completely closed	No

OK or NG

- OK >> GO TO 9.
NG >> GO TO 7.



7. ADJUST THROTTLE POSITION SWITCH

Check the following items. Refer to [EC-637, "Basic Inspection"](#).

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

If it is impossible to adjust closed throttle position switch in “Basic Inspection”, replace closed throttle position switch.

OK or NG

- OK (with CONSULT-II)>>GO TO 8.
OK (without CONSULT-II)>>GO TO 9.
NG >> Replace throttle position switch.

8. CHECK THROTTLE POSITION SENSOR**With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine (ignition switch OFF).
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Check voltage of "THRTL POS SEN".

Throttle valve conditions	Voltage [V]
Completely closed	0.15 - 0.85 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.7 (b)

Voltage measurement must be made with throttle position sensor installed in vehicle.

If NG, adjust closed throttle position switch. Refer to [EC-637, "Basic Inspection"](#) .

OK or NG

- OK >> GO TO 10.
 NG >> Replace throttle position sensor.

9. CHECK THROTTLE POSITION SENSOR**Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine (ignition switch OFF).
3. Turn ignition switch ON.
4. Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground.

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	Voltage [V]
Completely closed	0.15 - 0.85 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.7 (b)

If NG, adjust closed throttle position switch. Refer to [EC-637, "Basic Inspection"](#) .

OK or NG

- OK >> GO TO 10.
 NG >> Replace throttle position sensor.

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0600 A/T COMMUNICATION LINE

PF:P:23710

System Description

EBS00GN8

These circuit lines are used to control the smooth shifting up and down of A/T during the hard acceleration/ deceleration.

Voltage signals are exchanged between ECM and TCM (Transmission Control Module).

On Board Diagnosis Logic

EBS00GN9

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0600*	A/T control serial communication link	ECM receives incorrect voltage from TCM (Transmission Control Module) continuously.	<ul style="list-style-type: none"> Harness or connectors [The circuit between ECM and TCM (Transmission Control Module) is open or shorted.]

*: This DTC can be detected only by "DATA MONITOR (AUTO TRIG)" with CONSULT-II.

DTC Confirmation Procedure

EBS00GNA

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine, and rev engine more than 1,000 rpm once, then let it idle for more than 40 seconds.
4. If DTC 1st trip is detected, go to [EC-994, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".

DTC P0600 A/T COMMUNICATION LINE



[VG33E]

Wiring Diagram WITHOUT VDC

EBS00GNB

EC-AT/C-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



WBWA0037E

DTC P0600 A/T COMMUNICATION LINE

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
26	PU/W	A/T signal No. 1	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0 - 1.0V
27	P/B	A/T signal No. 2	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0 - 1.0V
35	G/R	A/T signal No. 3	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0 - 1.0V




DTC P0600 A/T COMMUNICATION LINE



[VG33E]

WITH VDC

EC-CAN-01

A
EC
C
D
E
F
G
H
I
J
K
L
M

-  : DETECTABLE LINE FOR DTC
-  : NON-DETECTABLE LINE FOR DTC
-  : DATA LINE



BBWA0503E


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
68	W/G	A/T signal	[Engine is running] ● Idle speed	Approximately 0 - 5.0V

Diagnostic Procedure

EBS00GNC

1. CHECK A/T CONTROL INPUT SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and TCM (Transmission Control Module) harness connector.




3. Check harness continuity between ECM terminal 26 and TCM terminal 5, ECM terminal 27 and TCM terminal 6, ECM terminal 35 and TCM terminal 7. Refer to Wiring Diagram.

Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between ECM and TCM (Transmission Control Module)

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK A/T CONTROL INPUT SIGNAL CIRCUIT FOR SHORT

1. Check harness continuity between ECM terminal 26 and ground, ECM terminal 27 and ground, ECM terminal 35 and ground. Refer to Wiring Diagram.

Continuity should not exist.

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the harness for open or short between ECM and TCM (Transmission Control Module).

>> Repair open circuit or short to ground or short to power in harness.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K


L

M

DTC P0605 ECM

Component Description

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the engine.



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0605	Engine control module	ECM calculation function is malfunctioning.	● ECM


DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine.
4. Run engine for at least 2 seconds at idle speed.
5. If 1st trip DTC is detected, go to [EC-997, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure “With CONSULT-II”.

Diagnostic Procedure

1. INSPECTION START

With CONSULT-II

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure".**
See [EC-996, "DTC Confirmation Procedure"](#).
5. Is the 1st trip DTC P0605 displayed again?

With GST

1. Turn ignition switch ON.
2. Select MODE 4 with GST.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure".**
See [EC-996, "DTC Confirmation Procedure"](#).
5. Is the 1st trip DTC P0605 displayed again?

Yes or No

- Yes >> Replace ECM.
No >> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K



L

M

DTC P1143, P1163 HO2S1

Component Description

The heated oxygen sensor 1 is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.




CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the "rich" output is sufficiently high and whether the "lean" output is sufficiently low. When both the outputs are shifting to the lean side, the malfunction will be detected.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1143 (Bank 1)	Heated oxygen sensor 1 lean shift monitoring	The maximum and minimum voltage from the sensor are not reached to the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks
P1163 (Bank 2)			

DTC Confirmation Procedure

UBS0083Z

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- **Always perform at a temperature above -10°C (14°F).**
- **Before performing following procedure, confirm that battery voltage is more than 11V at idle.**

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch “ON” and select “HO2S1 (B1)/(B2) P1143/ P1163” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.

HO2S1 (B1) P1143	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

LEC072A

5. Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 5.

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)


EGN SPEED	1,200 - 2,700 rpm
Vehicle speed	Less than 100 km/h (62 MPH)
B/FUEL SCHDL	2.0 - 14.0 msec
Selector lever	Suitable position

HO2S1 (B1) P1143	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

LEC073A

If “TESTING” is not displayed after 5 minutes, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-1000, "Diagnostic Procedure"](#).




UBS00840

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal 1] and engine ground.
3. Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is over 0.1V at least one time.
4. If NG, go to [EC-1000, "Diagnostic Procedure"](#).




UBS00841

Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten corresponding heated oxygen sensor 1.


Tightening torque : 40 - 60 N·m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)

>> GO TO 3.

3. CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?



Without CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-623, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174. Refer to [EC-810, "DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION"](#).
- No >> GO TO 4.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

1. Stop engine.
2. Check heated oxygen sensor 1 harness protector color.



3. Check resistance between HO2S1 terminals 3 and 1.


Resistance : 2.3 - 4.3Ω at 25°C (77°F)

4. Check continuity between HO2S1 terminals 2 and 1, 3 and 2.

Continuity should not exist.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



OK or NG

OK (With CONSULT-II)>>GO TO 5.

OK (Without CONSULT-II)>>GO TO 6.

NG >> Replace malfunctioning heated oxygen sensor 1.

5. CHECK HEATED OXYGEN SENSOR 1

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V


SEF967Y

5. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5	
	HO2S1 MNTR (B1)	R	L	L	R	L	R
Bank 2	cycle	1	2	3	4	5	
	HO2S1 MNTR (B2)	R	L	L	R	L	R

R means HO2S1 MNTR (B1)/(B2) indicates RICH
L means HO2S1 MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 7.
- NG >> Replace malfunctioning heated oxygen sensor 1.

6. CHECK HEATED OXYGEN SENSOR 1

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 7.

NG >> Replace malfunctioning heated oxygen sensor 1.


7. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .
For circuit, refer to [EC-783, "Wiring Diagram"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .





DTC P1144, P1164 HO2S1

PF2:22690

UBS00843

Component Description

The heated oxygen sensor 1 is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS00844


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS00845

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the “rich” output is sufficiently high. The “lean” output is sufficiently low. When both the outputs are shifting to the rich side, the malfunction will be detected.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1144 (Bank 1) P1164 (Bank 2)	Heated oxygen sensor 1 rich shift monitoring	The maximum and minimum voltages from the sensor are beyond the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch ON and select “HO2S1 (B1)/(B2) P1144/ P1164” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.

HO2S1 (B1) P1144	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

LEC074A

5. Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 5.

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)

ENG SPEED	1,200 - 2,700 rpm
Vehicle speed	Less than 100 km/h (62 MPH)
B/FUEL SCHDL	2.0 - 14.0 msec
Selector lever	Suitable position

HO2S1 (B1) P1144	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

LEC075A

If “TESTING” is not displayed after 5 minutes, retry from step 2.

7. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to [EC-1007, "Diagnostic Procedure"](#).

HO2S1 (B1) P1144	
COMPLETED	


LEC058A

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal] and engine ground.
3. Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is below 0.8V at least one time.
 - The minimum voltage is below 0.35V at least one time.
4. If NG, go to [EC-1007, "Diagnostic Procedure"](#) .




Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten corresponding heated oxygen sensor 1.

Tightening torque : 40 - 60 N·m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)


>> GO TO 3.

3. CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.

**Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?**



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch OFF.
 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
 4. Stop engine and reconnect mass air flow sensor harness connector.
 5. Make sure DTC P0102 is displayed.
 6. Erase the DTC memory. Refer to [EC-623, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
 7. Make sure DTC P0000 is displayed.
 8. Run engine for at least 10 minutes at idle speed.
- Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?**

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172, P0175. Refer to [EC-818, "DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION"](#).
- No >> GO TO 4.


4. CHECK HO2S 1 CONNECTOR FOR WATER

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 1 harness protector color.
3. Disconnect heated oxygen sensor 1 harness connector.
4. Check connectors for water.

Water should not exist.

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace harness or connectors.



5. CHECK HEATED OXYGEN SENSOR 1 HEATER

Check resistance between HO2S1 terminals 3 and 1.

Resistance : 2.3 - 4.3Ω at 25°C (77°F)

Check continuity between HO2S1 terminals 2 and 1, 3 and 2.

Continuity should not exist.

CAUTION:


- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK (With CONSULT-II)>>GO TO 6.

OK (Without CONSULT-II)>>GO TO 7.

NG >> Replace malfunctioning heated oxygen sensor 1.



A

EC

C

D

E

F

G

H

I

J

K

L

M

6. CHECK HEATED OXYGEN SENSOR 1

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V


SEF967Y

5. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5	
	HO2S1 MNTR (B1)	R	L	R	L	R	L
Bank 2	cycle	1	2	3	4	5	
	HO2S1 MNTR (B2)	R	L	R	L	R	L

R means HO2S1
MNTR (B1)/(B2) indicates RICH
L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO Replace malfunctioning heated oxygen sensor 1.

7. CHECK HEATED OXYGEN SENSOR 1

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B1) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one more.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 8.

NG >> Replace malfunctioning heated oxygen sensor 1.



8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For circuit, refer to [EC-783, "Wiring Diagram"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .


UBS00849

DTC P1146, P1166 HO2S2

Component Description

UBS0084A

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

UBS0084B


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> Warm-up condition After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	Revving engine from idle up to 3,000 rpm quickly	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)			LEAN ↔ RICH

On Board Diagnosis Logic

UBS0084C

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the minimum voltage of sensor is sufficiently low during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1146 (Bank 1)	Heated oxygen sensor 2 minimum voltage monitoring	The minimum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2 Fuel pressure Injectors
P1166 (Bank 2)			

DTC Confirmation Procedure

UBS0084D

NOTE:

If “DTC CONFIRMATION PROCEDURE” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


TESTING CONDITION:

Open engine hood before conducting following procedure

WITH CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch “OFF” and wait at least 10 seconds.
- Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.

4. Let engine idle for one minutes.
5. Select "HO2S2 (B1) P1146" or "HO2S2 (B2) P1166" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.



6. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
 If "NG" is displayed, refer to [EC-1606. "Diagnostic Procedure"](#) .
 If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a. Stop engine and cool down until "COOLAN TEMP/S" indicates less than 70°C (158°F).
 - b. Turn ignition switch "ON".
 - c. Select "DATA MONITOR" mode with CONSULT-II.
 - d. Start engine.
 - e. Return to step 6 again when the "COOLAN TEMP/S" reaches to 70°C (158°F).

A
EC
C
D
E
F
G
H
I
J
K
L
M

Overall Function Check


Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

WITH GST





1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be below 0.48V at least once during this procedure.
If the voltage can be confirmed in step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.48V at least once during this procedure.
8. If NG, go to [EC-1606, "Diagnostic Procedure"](#) .



Wiring Diagram
BANK 1

EC-O2S2B1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P1146, P1166 HO2S2

[VG33E]

Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.




TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none">● Engine after warming up.● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load.● Revving engine from idle to 3,000 rpm quickly.	0 - Approximately 1.0V

BANK 2

EC-O2S2B2-01



A
EC
C
D
E
F
G
H
I
J
K
L
M



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
57	Y	Heated oxygen sensor 2 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine after warming up. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. ● Revving engine from idle to 3,000 rpm quickly. 	0 - Approximately 1.0V


Diagnostic Procedure

UBS0084G

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.




LEC518

2. CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?**



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-623, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?**

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172, P0175. Refer to [EC-818, "DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION"](#).
- No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between HO2S2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.


4. DETECT MALFUNCTIONING PART

Check harness for open between heated oxygen sensor 2 and engine ground.


>> Repair open circuit or short to power in harness or connectors.

5. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 2 harness protector color.



3. Disconnect corresponding heated oxygen sensor 2 harness connector.
4. Disconnect ECM harness connector.
5. Check harness continuity between ECM terminal and HO2S2 (rear) terminal as follows.



Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P1146	56	1	Bank 1
P1166	57	1	Bank 2

Continuity should exist.

6. Check harness continuity between ECM terminal or HO2S2 terminal and ground as follows. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P1146	56 or 1	Ground	Bank 1
P1166	57 or 1	Ground	Bank 2

Continuity should not exist.

7. Also check harness for short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 6.

OK (Without CONSULT-II)>>GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2


With CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minutes.
6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.62V at least once when the "FUEL INJECTION" is +25%.
 "HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


OK or NG

- OK >> GO TO 8.
 NG >> Replace malfunctioning heated oxygen sensor 2.

7. CHECK HEATED OXYGEN SENSOR 2

⊗ Without CONSULT-II

1. Start engine warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.62V at least once during this procedure.
If the voltage is above 0.62V at step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.48V at least once during this procedure.
8. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
NG >> Replace malfunctioning heated oxygen sensor 2.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

UBS0084H

DTC P1147, P1167 HO2S2


Component Description

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.




CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> Warm-up condition After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	Revving engine from idle up to 3,000 rpm quickly	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)			LEAN ↔ RICH

On Board Diagnosis Logic

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the maximum voltage of the sensor is sufficiently high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1147 (Bank 1)	Heated oxygen sensor 2 maximum voltage monitoring	The maximum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2 Fuel pressure Injectors Intake air leaks
P1167 (Bank 2)			

DTC Confirmation Procedure

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Open engine hood before conducting following procedure


WITH CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P1147, P1167 HO2S2

[VG33E]

3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Select "HO2S2 (B1) P1147" or "HO2S2 (B2) P1167" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.



6. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-1029, "Diagnostic Procedure"](#).
If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a. Stop engine and cool down until "COOLAN TEMP/S" indicates less than 70°C (158°F).
 - b. Turn ignition switch "ON".
 - c. Select "DATA MONITOR" mode with CONSULT-II.
 - d. Start engine.
 - e. Return to step 6 again when the "COOLAN TEMP/S" reaches to 70°C (158°F).

Overall Function Check


Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.






WITH GST

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.62V at least once during this procedure.
If the voltage can be confirmed in step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be above 0.62V at least once during this procedure.
8. If NG, go to [EC-1029, "Diagnostic Procedure"](#) .



Wiring Diagram
BANK 1

EC-O2S2B1-01



DTC P1147, P1167 HO2S2

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:





Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine after warming up. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. ● Revving engine from idle to 3,000 rpm quickly. 	0 - Approximately 1.0V

A
EC
C
D
E
F
G
H
I
J
K
L
M

BANK 2

EC-O2S2B2-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
57	Y	Heated oxygen sensor 2 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine after warming up. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. ● Revving engine from idle to 3,000 rpm quickly. 	0 - Approximately 1.0V


Diagnostic Procedure

UBS00840

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.




2. CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.

**Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?**



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch OFF.
 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
 4. Stop engine and reconnect mass air flow sensor harness connector.
 5. Make sure DTC P0102 is displayed.
 6. Erase the DTC memory. Refer to [EC-623, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
 7. Make sure DTC P0000 is displayed.
 8. Run engine for at least 10 minutes at idle speed.
- Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?**

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174. Refer to [EC-810, "DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION"](#).
- No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between HO2S2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.


4. DETECT MALFUNCTIONING PART

Check harness for open between heated oxygen sensor 2 and engine ground.

>> Repair open circuit or short to power in harness or connectors.

5. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 2 harness protector color.
3. Disconnect corresponding heated oxygen sensor 2 harness connector.
4. Disconnect ECM harness connector.
5. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.



DTC	Terminals		Bank
	ECM	Sensor	
P1147	56	1	Bank 1
P1167	57	1	Bank 2

Continuity should exist.

6. Check harness continuity between ECM terminal or HO2S2 terminal and ground as follows.

Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P1147	56 or 1	Ground	Bank 1
P1167	57 or 1	Ground	Bank 2

Continuity should not exist.

7. Also check harness for short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 6.

OK (Without CONSULT-II)>>GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2


With CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minutes.
6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.62V at least once when the "FUEL INJECTION" is +25%.
 "HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


OK or NG

- OK >> GO TO 8.
 NG >> Replace malfunctioning heated oxygen sensor 2.

7. CHECK HEATED OXYGEN SENSOR 2

⊗ Without CONSULT-II

1. Start engine warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.62V at least once during this procedure.
If the voltage is above 0.62V at step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.48V at least once during this procedure.
8. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
NG >> Replace malfunctioning heated oxygen sensor 2.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3. "EXHAUST SYSTEM"](#) .

UBS0084P

DTC P1148, P1168 CLOSED LOOP CONTROL

PFP:22690

On Board Diagnosis Logic

UBS0084Q

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1148 (Bank 1)	Closed loop control function	The closed loop control function for bank 1 does not operate even when vehicle is driving in the specified condition.	<ul style="list-style-type: none"> ● The heated oxygen sensor 1 circuit is open or shorted. ● Heated oxygen sensor 1 ● Heated oxygen sensor heater
P1168 (Bank 2)		The closed loop control function for bank 2 does not operate even when vehicle is driving in the specified condition.	

DTC Confirmation Procedure

UBS0084R

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Never raise engine speed above 2,800 rpm during the "DTC Confirmation Procedure". If the engine speed limit is exceeded, retry the procedure from step 2.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

Ⓟ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Hold engine speed at 2,000 rpm and check one of the following.
 - "HO2S1 (B1)/(B2)" voltage should go above 0.70V at least once.
 - "HO2S1 (B1)/(B2)" voltage should go below 0.21V at least once. If the check result is NG, perform [EC-1035, "Diagnostic Procedure"](#) .
 If the check result is OK, perform the following step.
4. Let engine idle at least 5 minutes.
5. Maintain the following condition at least 50 consecutive seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANT TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V

SEF967Y

B/FUEL SCHDL	2.0 msec or more
ENG SPEED	1,500 rpm or more
Selector lever	Suitable position
VHCL SPEED SE	More than 71 km/h (44 MPH)

During this test, P0134 and/or P0154 may be displayed on CONSULT-II screen.

6. If DTC is detected, go to [EC-1035, "Diagnostic Procedure"](#) .

Overall Function Check

UBS0084S

Use this procedure to check the overall function of the closed loop control. During this check, a DTC might not be confirmed.


Ⓟ WITH GST

1. Start engine and warm it up to normal operating temperature.

DTC P1148, P1168 CLOSED LOOP CONTROL

[VG33E]

2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no-load.
 - The voltage should go above 0.70V at least once.
 - The voltage should go below 0.21V at least once.
4. If NG, go to [EC-1035, "Diagnostic Procedure"](#) .



Diagnostic Procedure

Perform trouble diagnosis for [EC-773, "Diagnostic Procedure"](#) .

A

EC

C

D

UBS0084T

E

F

G

H

I

J

K

L

M

DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

PFP:00021

On Board Diagnosis Logic

UBS0084U

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise. When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

This self-diagnosis has one trip detection logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1217	Engine over temperature (Overheat)	Engine coolant temperature reaches an abnormally high temperature.	<ul style="list-style-type: none"> ● Cooling fan (crankshaft driven) ● Radiator hose ● Radiator ● Radiator cap ● Water pump ● Thermostat <p>For more information, refer to EC-1038, "Main 12 Causes of Overheating".</p>

CAUTION:

When a malfunction is indicated be sure to replace the coolant, follow the procedure in [MA-26](#), "[Changing Engine Coolant](#)". Also, replace the engine oil.

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to [MA-14](#), "[ANTI-FREEZE COOLANT MIXTURE RATIO](#)".
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Overall Function Check

UBS0084V

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.


WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

WITH CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-1037](#), "[Diagnostic Procedure](#)".
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-1037](#), "[Diagnostic Procedure](#)".
3. Start engine.
4. Make sure that cooling fan (crankshaft driven) operates.
5. If NG, go to [EC-1037](#), "[Diagnostic Procedure](#)".



WITH GST

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-1037](#), "[Diagnostic Procedure](#)".
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-1037](#), "[Diagnostic Procedure](#)".
3. Start engine and make sure that cooling fan (crankshaft driven) operates.
Be careful not to overheat engine.
4. If NG, go to [EC-1037](#), "[Diagnostic Procedure](#)".

Diagnostic Procedure

1. CHECK COOLING FAN (CRANKSHAFT DRIVEN) OPERATION

Start engine and make sure that cooling fan (crankshaft driven) operates.

OK or NG

OK >> GO TO 2.

NG >> Check cooling fan (crankshaft driven). Refer to [CO-32, "COOLING FAN \(CRANKSHAFT DRIVEN\)"](#).

2. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.

CAUTION:

Higher than the specified pressure may cause radiator damage.

Testing pressure² : 157 kPa (1.6 kg/cm, 23 psi)

Pressure should not drop.


OK or NG

OK >> GO TO 3.

NG >> Check the following for leak

- Hose
- Radiator
- Water pump

Refer to [CO-25, "WATER PUMP"](#).



3. CHECK RADIATOR CAP


Apply pressure to cap with a tester and check radiator cap relief pressure.

Radiator cap relief pressure : 59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)

OK or NG

OK >> GO TO 4.

NG >> Replace radiator cap.



4. CHECK THERMOSTAT

1. Check valve seating condition at normal room temperatures. **It should seat tightly.**
2. Check valve opening temperature and valve lift.

Valve opening temperature : 76.5°C (170°F) [standard]

Valve lift : More than 10 mm/90°C (0.39 in/194°F)


3. Check if valve is closed at 5°C (9°F) below valve opening temperature.

For details, refer to [CO-28, "THERMOSTAT"](#).

OK or NG

OK >> GO TO 5.

NG >> Replace thermostat



DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)


[VG33E]

5. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Check resistance as shown in the figure.

<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260




SEF152P

OK or NG

OK >> GO TO 6.

NG >> Replace engine coolant temperature sensor.



SEF012P

6. CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to [EC-1038, "Main 12 Causes of Overheating"](#) .

>> INSPECTION END.

Main 12 Causes of Overheating

UBS0084X

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> Blocked radiator Blocked condenser Blocked radiator grille Blocked bumper 	<ul style="list-style-type: none"> Visual 	No blocking	—
	2	<ul style="list-style-type: none"> Coolant mixture 	<ul style="list-style-type: none"> Coolant tester 	50 - 50% coolant mixture	See MA-12, "Recommended Fluids and Lubricants" .
	3	<ul style="list-style-type: none"> Coolant level 	<ul style="list-style-type: none"> Visual 	Coolant up to MAX level in reservoir tank and radiator filler neck	See MA-26, "Changing Engine Coolant" .
	4	<ul style="list-style-type: none"> Radiator cap 	<ul style="list-style-type: none"> Pressure tester 	59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See CO-23, "System Check" .
ON*1	5	<ul style="list-style-type: none"> Coolant leaks 	<ul style="list-style-type: none"> Visual 	No leaks	See CO-23, "System Check" .
ON*1	6	<ul style="list-style-type: none"> Thermostat 	<ul style="list-style-type: none"> Touch the upper and lower radiator hoses 	Both hoses should be hot	See CO-28, "THERMOSTAT" .
ON*1	7	<ul style="list-style-type: none"> Cooling fan (crankshaft driven) 	<ul style="list-style-type: none"> Visual 	Operating	See CO-32, "COOLING FAN (CRANKSHAFT DRIVEN)" .
OFF	8	<ul style="list-style-type: none"> Combustion gas leak 	<ul style="list-style-type: none"> Color checker chemical tester 4 Gas analyzer 	Negative	—

DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

[VG33E]

Engine	Step	Inspection item	Equipment	Standard	Reference page
ON*2	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See MA-26, "Changing Engine Coolant" .
OFF*3	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See CO-22, "COOLING SYSTEM" .
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-100, "CYLINDER HEAD" .
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See EM-130, "CYLINDER BLOCK" .

*1: Engine running at 3,000 rpm for 10 minutes.

*2: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*3: After 60 minutes of cool down time.

For more information, refer to [CO-21, "OVERHEATING CAUSE ANALYSIS"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1336 CKP SENSOR (OBD)

PFP:23731

Component Description

UBS0084Y

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.



The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system.

It is used only for the on board diagnosis.



On Board Diagnosis Logic

UBS0084Z

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1336	Crankshaft position sensor (OBD) range/performance	A chipping of the flywheel or drive plate gear tooth (cog) is detected by the ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Crankshaft position sensor (OBD) ● Drive plate/Flywheel

DTC Confirmation Procedure


UBS00850

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 2 minutes at idle speed.
3. If 1st trip DTC is detected, go to [EC-1042, "Diagnostic Procedure"](#) .



WITH GST

Follow the procedure "With CONSULT-II".


DTC P1336 CKP SENSOR (OBD)

[VG33E]



UBS00851

Wiring Diagram

EC-CKPS-01



A
EC
C
D
E
F
G
H
I
J
K
L
M





DTC P1336 CKP SENSOR (OBD)

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	L	Crankshaft position sensor (OBD)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1 - 2V (AC range)★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>3 - 4V (AC range)★</p> 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

UBS00852

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK CKP SENSOR (OBD) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Disconnect crankshaft position sensor (OBD) and ECM harness connectors.
2. Check continuity between ECM terminal 47 and CKP sensor (OBD) terminal 2.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F38, F102
- Harness for open or short between ECM and crankshaft position sensor (OBD)

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK CKP SENSOR (OBD) GROUND CIRCUIT FOR OPEN AND SHORT

1. Reconnect ECM harness connectors.
2. Check harness continuity between CKP sensor (OBD) terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F38, F102
- Harness for open between crankshaft position sensor (OBD) and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK IMPROPER INSTALLATION


1. Loosen and retighten the fixing bolt of the crankshaft position sensor (OBD).
2. Perform [EC-1040, "DTC Confirmation Procedure"](#) .

Is a 1st trip DTC P1336 detected?

- Yes >> GO TO 7.
- No >> **INSPECTION END.**

7. CHECK CRANKSHAFT POSITION SENSOR (OBD)

1. Disconnect crankshaft position sensor (OBD) harness connector.
2. Loosen the fixing bolt of the sensor.
3. Remove the sensor.
4. Visually check the sensor for chipping.




5. Check resistance as shown in the figure.

Resistance : Approximately 512 - 632Ω [at 20°C (68°F)]

OK or NG

- OK >> GO TO 8.
 NG >> Replace crankshaft position sensor (OBD).



8. CHECK GEAR TOOTH

Visually check for chipping flywheel or drive plate gear tooth (cog).

OK or NG

- OK >> GO TO 9.
 NG >> Replace the flywheel or drive plate.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1400 EGRC-SOLENOID VALVE

PFP:14956

Component Description

UBS00854

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. The vacuum signal (from the intake manifold collector) passes through the solenoid valve. The signal then reaches the EGR valve.

When the ECM sends an OFF signal, a plunger will then move to cut the vacuum signal from the intake manifold collector to the EGR valve.

CONSULT-II Reference Value in Data Monitor Mode

UBS00855

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EGRC SOL/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" (A/T models) ● No-load 	Idle
		Rev engine up from idle to 3,000 rpm quickly.
		OFF
		ON

On Board Diagnosis Logic

UBS00856

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1400	EGRC-solenoid valve	<ul style="list-style-type: none"> ● The improper voltage signal is sent to ECM through EGRC-solenoid valve. 	<ul style="list-style-type: none"> ● Harness or connectors (The EGRC-solenoid valve circuit is open or shorted.) ● EGRC-solenoid valve

DTC Confirmation Procedure

UBS00857

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Maintain the following conditions for at least 5 consecutive seconds.

ENG SPEED	Less than 3,200 rpm
B/FUEL SCHDL	Less than 13 msec
VHCL SPEED SE	Suitable speed

4. If 1st trip DTC is detected, go to [EC-1048, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V
B/FUEL SCHDL	XXX msec

SEF201Y

WITH GST

- Follow the procedure with "CONSULT-II".

Overall Function Check

UBS00858

Use this procedure to check the overall function of the EGR temperature sensor. During this check, a 1st trip DTC might not be confirmed.

WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.


DTC P1400 EGRC-SOLENOID VALVE

[VG33E]

2. Check the voltage between ECM terminal 103 and ground at idle.

Voltage : 0 - 1V

3. Check that the voltage changes to battery voltage and returns to 0 - 1V when revving the engine from idle to 3,000 rpm quickly.
4. If NG, go to [EC-1048, "Diagnostic Procedure"](#) .



DTC P1400 EGRC-SOLENOID VALVE


[VG33E]

UBS00859

Wiring Diagram

EC-EGRC/V-01


A
EC
C
D
E
F
G
H
I
J
K
L
M



Refer to PG-POWER.
 — : Detectable line for DTC
 — : Non-detectable line for DTC



Refer to the following.
 (E43) - SUPER MULTIPLE JUNCTION (SMJ)



BBWA0505E

DTC P1400 EGRC-SOLENOID VALVE

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
103	G/W	EGRC-solenoid valve	[Engine is running] ● Warm-up condition ● Idle speed	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Warm-up condition ● M/T models: Lift up drive wheels and shift to 1st gear position. ● Revving engine from idle up to 3,000 rpm quickly.	0 - 1V

Diagnostic Procedure

UBS0085A

1. CHECK EGRC-SOLENOID VALVE

 **With CONSULT-II**

1. Turn ignition switch ON.
2. Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.

 **Without CONSULT-II**

1. Start engine and rev engine up to 3,000 rpm quickly.
2. When disconnecting and reconnecting the EGRC-solenoid valve harness connector, make sure that the EGRC-solenoid valve makes operating sound. (The DTC or the 1st trip DTC for the EGRC-solenoid valve will be displayed, however, ignore it.)

OK or NG


- OK (With CONSULT-II)>>GO TO 6.
- OK (Without CONSULT-II)>>GO TO 7.
- NG >> GO TO 2

ACTIVE TEST	
EGRC SOL/V	ON
MONITOR	
ENG SPEED	XXX rpm

SEF722Z

2. CHECK POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect EGRC-solenoid valve harness connector.




3. Turn ignition switch ON.
4. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M59, F27
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between EGRC-solenoid valve and 10A fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 103 and EGRC-solenoid valve terminal 1.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK (With CONSULT-II)>>GO TO 6.
- OK (Without CONSULT-II)>>GO TO 7.
- NG >> GO TO 5

5. DETECT MALFUNCTIONING PART

Check the harness for open or short between EGRC-solenoid valve and ECM.

>> Repair open circuit or short to ground or short to power in harness or connectors.


6. CHECK EGRC-SOLENOID VALVE

1. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time under the following conditions.

Conditions	Air passage continuity between A and B	Air passage continuity between A and C
ON	Yes	No
OFF	No	Yes

OK or NG

- OK >> GO TO 8.
- NG >> Replace EGRC-solenoid valve.




7. CHECK EGRC-SOLENOID VALVE

1. Check air passage continuity and operation delay time under the following conditions.

Conditions	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

OK or NG

- OK >> GO TO 8.
- NG >> Replace EGRC-solenoid valve.



8. CHECK INTERMITTENT INCIDENT

Perform [EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**


DTC P1402 EGR FUNCTION

Description SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EGR control	EGRC-solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		

This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current through the solenoid valve is cut. This causes the vacuum to be cut. The EGR valve remains closed.


- Low engine coolant temperature
- Engine starting
- High-speed engine operation
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction



COMPONENT DESCRIPTION

Exhaust Gas Recirculation (EGR) Valve


The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening and EGRC-BPT valve operation. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.



EGRC-solenoid Valve

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. Vacuum signal (from the intake manifold collector) passes through the solenoid valve. The signal then reaches the EGR valve.

When the ECM sends an OFF signal, a plunger will then move to cut the vacuum signal from the intake manifold collector to the EGR valve.




On Board Diagnosis Logic

If EGR temperature sensor detects EGR flow under the condition that does not call for EGR, a high-flow malfunction is diagnosed.

NOTE:

Diagnosis for this DTC will occur when engine coolant temperature is approx. 50 to 60°C (122 to 140°F). Therefore, it will be better to turn ignition switch “ON” (Start engine) at the engine coolant temperature below 40°C (104°F) when starting DTC confirmation procedure.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause
P1402	EGRC-solenoid valve circuit open	<ul style="list-style-type: none"> ● EGR flow is detected under conditions that do not call for EGR. 	<ul style="list-style-type: none"> ● EGRC-solenoid valve ● EGR valve leaking or stuck open ● EGR temperature sensor ● EGRC-BPT valve

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:


- Engine coolant temperature and EGR temperature must be verified in “DATA MONITOR” mode with CONSULT-II before starting DTC WORK SUPPORT test. If it is out of range below, the test cannot be conducted.

COOLANT TEMP/S: -10 to 40°C (14 to 104°F)*

EGR TEMP SEN: Less than 4.8V

If the values are out of the ranges indicated above, park the vehicle in a cool place and allow the engine temperature to stabilize. Do not attempt to reduce the engine coolant or EGR temperature with a fan or means other than ambient air. Doing so may produce an inaccurate diagnostic result.

*: Although CONSULT-II screen displays “-10 to 40°C (14 to 104°F)” as a range of engine coolant temperature, ignore it.




WITH CONSULT-II

1. Turn ignition switch OFF and wait at least 5 seconds, then turn ignition switch ON.


DTC P1402 EGR FUNCTION

[VG33E]



- Select "EGR SYSTEM P1402" of "EGR SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.



- Touch "START". Follow instruction of CONSULT-II.



- Start engine and let it idle until "TESTING" on CONSULT-II screen is turned to "COMPLETED". (It will take 60 seconds or more.)
If "TESTING" is not displayed after 5 minutes, turn ignition "OFF" and cool the engine coolant temperature to the range of -10 to 40°C (14 to 104°F). Retry from step 1.



- Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-1056, "Diagnostic Procedure"](#).

WITH GST

- Turn ignition switch ON and select "MODE 1" with GST.
- Check that engine coolant temperature is within the range of -10 to 40°C (14 to 104°F).
- Check that voltage between ECM terminal 63 (EGR temperature sensor signal) and ground is less than 4.8V.
- Start engine and let it idle for at least 60 seconds.
- Stop engine.
- Perform from step 1 to 4.

7. Select "MODE 3" with GST.
8. If 1st trip DTC is detected, go to [EC-1056, "Diagnostic Procedure"](#) .

DTC P1402 EGR FUNCTION


[VG33E]

UBS0085E




Wiring Diagram

EC-EGRC1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M




— : Detectable line for DTC
— : Non-detectable line for DTC



Refer to the following.

E43 - SUPER MULTIPLE JUNCTION (SMJ)



BBWA0504E


Diagnostic Procedure

1. CHECK VACUUM HOSE

Check vacuum hose for clogging, cracks or improper connection.

OK or NG

- OK (With CONSULT-II)>>GO TO 2.
- OK (Without CONSULT-II)>>GO TO 3.
- NG >> Repair or replace vacuum hose.



2. CHECK EGRC-SOLENOID VALVE CIRCUIT

Ⓟ With CONSULT-II

1. Turn ignition switch ON.
2. Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.
Clicking noise should be heard.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

ACTIVE TEST	
EGRC SOL/V	ON
(EGR)	CUT
MONITOR	
ENG SPEED	XXX rpm

SEF716Z

3. CHECK EGRC-SOLENOID VALVE CIRCUIT

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect EGRC-solenoid valve harness connector.
3. Turn ignition switch ON.
4. Check operating sound of the solenoid valve when disconnecting and reconnecting EGRC-solenoid valve harness connector. (The DTC or the 1st trip DTC for the EGRC-solenoid valve will be displayed, however, ignore it.)

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M59, F27
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between fuse and EGRC-solenoid valve
- Harness for open or short between ECM and EGRC-solenoid valve

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1402 EGR FUNCTION

[VG33E]

5. CHECK EGRC-SOLENOID VALVE


Ⓧ With CONSULT-II

1. Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time under the following conditions.

Conditions	Air passage continuity between A and B	Air passage continuity between A and C
ON	Yes	No
OFF	No	Yes

OK or NG

- OK >> GO TO 7.
- NG >> Replace EGRC-solenoid valve.



6. CHECK EGRC-SOLENOID VALVE


Ⓧ Without CONSULT-II

1. Check air passage continuity and operation delay time under the following conditions.

Conditions	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

OK or NG

- OK >> GO TO 7.
- NG >> Relace EGRC-solenoid valve.



7. CHECK EGR VALVE

Refer to [EC-1058, "Component Inspection"](#).

OK or NG

- OK >> GO TO 8.
- NG >> Replace EGR valve.

8. CHECK EGRC-BPT VALVE

Refer to [EC-1058, "Component Inspection"](#).

OK or NG

- OK >> GO TO 9.
- NG >> Replace EGRC-BPT valve.

9. CHECK EGR TEMPERATURE SENSOR

Refer to [EC-886, "Component Inspection"](#).

OK or NG

- OK >> GO TO 10.
- NG >> Replace EGR temperature sensor.

A
EC
C
D
E
F
G
H
I
J
K
L
M

10. CHECK INTERMITTENT INCIDENT

Perform [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


Component Inspection EGR VALVE

UBS0085G

1. Apply vacuum to EGR vacuum port with a hand vacuum pump.


EGR valve spring should lift.

2. Check for sticking.
3. If NG, repair or replace EGR valve.



EGRC-BPT VALVE

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂ O, 3.94 inH₂ O) from under EGRC-BPT valve.
3. If a leakage is noted, replace the valve.



SEF083P


DTC P1442 EVAP CONTROL SYSTEM

On Board Diagnosis Logic

NOTE:

If DTC P1442 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See [EC-1076](#), "DTC P1448 EVAP CANISTER VENT CONTROL VALVE".)

This diagnosis detects leaks in the EVAP purge line using of vapor pressure in the fuel tank. The EVAP canister vent control valve is closed to shut the EVAP purge line. The vacuum cut valve bypass valve will then be opened to clear the line between the fuel tank and the EVAP canister purge volume control solenoid valve. The EVAP control system pressure sensor can now monitor the pressure inside the fuel tank. If pressure increases, the ECM will check for leaks in the line between the vacuum cut valve and EVAP canister purge volume control solenoid valve.



PBIB1438E

DTC P1442 EVAP CONTROL SYSTEM

[VG33E]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1442	EVAP control system small leak detected (positive pressure)	EVAP control system has a leak, EVAP control system does not operate properly.	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged. ● Water separator ● EVAP canister is saturated with water ● Fuel level sensor and the circuit ● EVAP control system pressure sensor ● Refueling control valve ● ORVR system leaks ● Foreign matter caught in EVAP canister purge volume control solenoid valve

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS0085I

Refer to [EC-950, "DTC P0456 EVAP CONTROL SYSTEM"](#) or [EC-1084, "DTC P1456 EVAP CONTROL SYSTEM"](#).

Diagnostic Procedure

UBS0085J

Refer to [EC-950, "DTC P0456 EVAP CONTROL SYSTEM"](#) or [EC-1084, "DTC P1456 EVAP CONTROL SYSTEM"](#).

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33E]

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PFP:14920

Description SYSTEM DESCRIPTION


UBS0085K

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Throttle position switch	Closed throttle position		
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Fuel tank temperature sensor	Fuel temperature in fuel tank		
Vehicle speed sensor	Vehicle speed		

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



CONSULT-II Reference Value in Data Monitor Mode

UBS0085L

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PURG VOL C/V	● Engine: After warming up ● Air conditioner switch OFF ● Shift lever: "N" ● No-load	Idle (Vehicle stopped) 0%
	2,000 rpm	—

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33E]

UBS0085M

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1444	EVAP canister purge volume control solenoid valve	The canister purge flow is detected during the specified driving conditions, even when EVAP canister purge volume control solenoid valve is completely closed.	<ul style="list-style-type: none"> ● EVAP control system pressure sensor ● EVAP canister purge volume control solenoid valve (The valve is stuck open.) ● EVAP canister vent control valve ● EVAP canister ● Hoses (Hoses are connected incorrectly or clogged.)

DTC Confirmation Procedure

UBS0085N

NOTE:


If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.
4. Select “PURG VOL CN/V P1444” of “EVAPORATIVE SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II.
5. Touch “START”.



6. Start engine and let it idle until “TESTING” on CONSULT-II changes to “COMPLETED”. (It will take for approximately 10 seconds.)
If “TESTING” is not displayed after 5 minutes, retry from step 2.
7. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to [EC-1065, "Diagnostic Procedure"](#).

WITH GST


1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Start engine and let it idle for at least 20 seconds.
4. Select “MODE 7” with GST.
5. If 1st trip DTC is detected, go to [EC-1065, "Diagnostic Procedure"](#).

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33E]

UBS00850


Wiring Diagram

EC-PGC/V-01




- : Detectable line for DTC
- : Non-detectable line for DTC
- ⬡EP⬢ : EARLY PRODUCTION
- ⬡LP⬢ : LATE PRODUCTION
- *1 ⬡EP⬢ : 13
- *1 ⬡LP⬢ : 15

A
EC
C
D
E
F
G
H
I
J
K
L
M



Refer to the following.
⬡E43⬢ - SUPER MULTIPLE JUNCTION (SMJ)





DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	OR/B	ECM relay (Self shut-off)	[Engine is running] [Ignition switch OFF] <ul style="list-style-type: none"> For a few seconds after turning ignition switch OFF 	0 - 1.5V
			[Ignition switch OFF] <ul style="list-style-type: none"> A few seconds passed after turning ignition switch OFF 	BATTERY VOLTAGE (11 - 14V)
5	R/Y	EVAP canister purge volume control solenoid valve	[Engine is running] <ul style="list-style-type: none"> Idle speed 	BATTERY VOLTAGE (11 - 14V)★ 
			[Engine is running] <ul style="list-style-type: none"> Engine speed is 2,000 rpm 	BATTERY VOLTAGE (11 - 14V)★ 
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P			
117	B/P	Current return	[Engine is running] <ul style="list-style-type: none"> Idle speed 	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33E]

UBS0085P

Diagnostic Procedure

1. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 1 and engine ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F65, E43
- Harness connectors M82, E74
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair harness or connectors.

3. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 5 and EVAP canister purge volume control solenoid valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33E]

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG


- OK >> GO TO 6.
- NG >> Repair it.

6. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.
Water should not exist.

OK or NG

- OK >> GO TO 7.
- NG >> Replace EVAP control system pressure sensor.



7. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch ON.
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.


Applied vacuum	Voltage V
Not applied	1.4 - 4.8
-26.7 kPa (-200 mmHg, -7.87 inHg)	2.1 to 2.5V lower than above value

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK (with CONSULT-II) >> GO TO 8.
- OK (without CONSULT-II) >> GO TO 9.
- NG >> Replace EVAP control system pressure sensor.



DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33E]

8. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.
If OK, inspection end. If NG, go to following step.

ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y

3. Check air passage continuity.


Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

If NG, replace the EVAP canister purge volume control solenoid valve.

OK or NG

OK >> GO TO 10.

NG >> Replace EVAP canister purge volume control solenoid valve.



9. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Without CONSULT-II

Check air passage continuity.


Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

If NG, replace the EVAP canister purge volume control solenoid valve.

OK or NG

OK >> GO TO 10.

NG >> Replace EVAP canister purge volume control solenoid valve.



10. CHECK EVAP CANISTER VENT CONTROL VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.
If OK, inspection end. If NG, go to following step.

ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y


3. Check air passage continuity.

Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

If NG, replace the EVAP canister purge volume control solenoid valve.

OK or NG

- OK >> GO TO 11.
- NG >> Replace EVAP canister vent control valve.



11. CHECK RUBBER TUBE

Check for obstructed rubber tube connected to EVAP canister vent control valve.

OK or NG

- OK >> GO TO 12.
- NG >> Clean, repair or replace rubber tube.

12. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 13.
- NG >> Replace water separator.



- * **A** : Bottom hole (To atmosphere)
- B** : Emergency tube (From EVAP canister)
- C** : Inlet port (To member)


DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33E]

13. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

- Yes >> GO TO 14.
No >> GO TO 16.



14. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK >> GO TO 16.
NG >> GO TO 15.

15. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

16. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1446 EVAP CANISTER VENT CONTROL VALVE

PFP:14935

Component Description



UBS0085R

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid valve responds to signals from the ECM. When the ECM sends an ON signal, the coil in the solenoid valve is energized. A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS0085S

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

UBS0085T

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1446	EVAP canister vent control valve close	EVAP canister vent control valve remains closed under specified driving conditions.	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● EVAP control system pressure sensor and the circuit ● Blocked rubber tube to EVAP canister vent control valve ● Water separator ● EVAP canister is saturated with water

DTC Confirmation Procedure

UBS0085U

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.

DTC P1446 EVAP CANISTER VENT CONTROL VALVE

[VG33E]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine.
4. Drive vehicle at a speed of approximately 80 km/h (50 MPH) for a maximum of 15 minutes.

NOTE:

If a malfunction exists, NG result may be displayed quicker.

5. If 1st trip DTC is detected, go to [EC-1073, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V
B/FUEL SCHDL	XXX msec

SEF201Y

 **WITH GST**

Follow the procedure "With CONSULT-II".

A

EC

C

D

E

F

G

H

I

J

K

L

M



DTC P1446 EVAP CANISTER VENT CONTROL VALVE

[VG33E]

UBS0085V

Wiring Diagram

EC-VENT/V-01



WBWA0031E

DTC P1446 EVAP CANISTER VENT CONTROL VALVE

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
108	R/G	EVAP canister vent control valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


UBS0085W

1. CHECK RUBBER TUBE

1. Turn ignition switch OFF.
2. Check obstructed rubber tube connected to EVAP canister vent control valve.

OK or NG

- OK >> GO TO 2.
- NG >> Clean, repair or replace rubber tube.



2. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 3.
- NG >> Replace water separator.




3. CHECK EVAP CANISTER VENT CONTROL VALVE

With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.



Without CONSULT-II

1. Check air passage continuity and operation delay time under the following conditions.


Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.



OK or NG

OK >> GO TO 4.

NG >> Replace EVAP canister vent control valve.


4. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

Yes >> GO TO 5.

No >> GO TO 7.



5. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

7. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG

OK >> GO TO 8.

NG >> Repair it.

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.


2. Check connectors for water.

Water should not exist.

OK or NG

OK >> GO TO 9.

NG >> Replace EVAP control system pressure sensor.

**9. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION**

Refer to [EC-926, "DTC Confirmation Procedure"](#) or [EC-932, "DTC Confirmation Procedure"](#).

OK or NG

OK >> GO TO 10.

NG >> Replace EVAP control system pressure sensor.

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END.

DTC P1448 EVAP CANISTER VENT CONTROL VALVE

PFP:14935

Component Description

UBS0085X

NOTE:



If DTC P1448 is displayed with P0442, perform trouble diagnosis for DTC P1448 first.

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid valve responds to signals from the ECM. When the ECM sends an ON signal, the coil in the solenoid valve is energized. A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS0085Y

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

UBS0085Z

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1448	EVAP canister vent control valve open	EVAP canister vent control valve remains open under specified driving conditions.	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● EVAP control system pressure sensor and the circuit ● Blocked rubber tube to EVAP canister vent control valve ● Water separator ● EVAP canister is saturated with water ● Vacuum cut valve

DTC Confirmation Procedure

UBS00860

NOTE:

- If DTC P1448 is displayed with P0442, perform trouble diagnosis for DTC P1448 first.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

TESTING CONDITION:

- Perform "DTC WORK SUPPORT" when the fuel level is less than 3/4 full and vehicle is placed on flat level surface.


DTC P1448 EVAP CANISTER VENT CONTROL VALVE

[VG33E]

- Always perform test at a temperature of 0 to 30°C (32 to 86°F).
 - It is better that the fuel level is low.
1. Turn ignition switch ON.
 2. Turn ignition switch OFF and wait at least 5 seconds.
 3. Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
 4. Make sure that the following conditions are met.

COOLAN TEMP/S	0 - 32°C (32 - 90°F)
INT/A TEMP SE	More than 0°C (32°F)

5. Select “EVAP SML LEAK P0442” of “EVAPORATIVE SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II.
Follow the instruction displayed.



NOTE:

If the engine speed cannot be maintained within the range displayed on the CONSULT-II screen, go to [EC-637, "Basic Inspection"](#).

6. Make sure that “OK” is displayed.
If “NG” is displayed, go to the following step.


NOTE:

Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

7. Stop engine and wait at least 5 seconds, then turn “ON”.
8. Disconnect hose from water separator.
9. Select “VENT CONTROL/V” of “ACTIVE TEST” mode with CONSULT-II.
10. Touch “ON” and “OFF” alternately.
11. Make sure the following.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

If the result is NG, go to [EC-1080, "Diagnostic Procedure"](#).
If the result is OK, go to [EC-904, "Diagnostic Procedure"](#).



Overall Function Check

Use this procedure to check the overall function of the EVAP canister vent control valve circuit. During this check, a DTC might not be confirmed.

WITH GST

1. Disconnect hose from water separator.
2. Disconnect EVAP canister vent control valve harness connector.


DTC P1448 EVAP CANISTER VENT CONTROL VALVE

[VG33E]

3. Verify the following.

Condition	Air passage continuity
12V direct current supply between terminals 1 and 2	No
No supply	Yes

If the result is NG, go to [EC-1080, "Diagnostic Procedure"](#) .
If the result is OK, go to [EC-904, "Diagnostic Procedure"](#) .




DTC P1448 EVAP CANISTER VENT CONTROL VALVE

[VG33E]

UBS00862


Wiring Diagram

EC-VENT/V-01



Refer to PG-POWER.

- : Detectable line for DTC
- : Non-detectable line for DTC
- : EARLY PRODUCTION
- : LATE PRODUCTION
- *1 : 21
- : 23



Refer to the following.

- SUPER
MULTIPLE JUNCTION (SMJ)



WBWA0031E

DTC P1448 EVAP CANISTER VENT CONTROL VALVE

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
108	R/G	EVAP canister vent control valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


UBS00863

1. CHECK RUBBER TUBE

1. Turn ignition switch OFF.
2. Check obstructed rubber tube connected to EVAP canister vent control valve.

OK or NG

- OK >> GO TO 2.
- NG >> Clean, repair or replace rubber tube.



2. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 3.
- NG >> Replace water separator.




3. CHECK EVAP CANISTER VENT CONTROL VALVE

With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.



Without CONSULT-II

1. Check air passage continuity and operation delay time under the following conditions.


Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.



OK or NG

OK >> GO TO 4.

NG >> Replace EVAP canister vent control valve.

4. CHECK VACUUM CUT VALVE


Check vacuum cut valve as follows:

1. Plug port **C** and **D** with fingers.
2. Apply vacuum to port **A** and check that there is no suction from port **B**.
3. Apply vacuum to port **B** and check that there is suction from port **A**.
4. Blow air in port **B** and check that there is a resistance to flow out of port **A**.
5. Open port **C** and **D**.
6. Blow air in port **A** check that air flows freely out of port **C**.
7. Blow air in port **B** check that air flows freely out of port **D**.

OK or NG

OK >> GO TO 5.

NG >> Replace vacuum cut valve.




5. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 8.



6. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG


- OK >> GO TO 9.
- NG >> Repair it.

9. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.
Water should not exist.

OK or NG

- OK >> GO TO 10.
- NG >> Replace EVAP control system pressure sensor.



10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION

Refer to “DTC Confirmation Procedure” for DTC P0452 [EC-1513](#) or DTC P0453 [EC-1519](#).

OK or NG

- OK >> GO TO 11.
- NG >> Replace EVAP control system pressure sensor.

DTC P1448 EVAP CANISTER VENT CONTROL VALVE

[VG33E]

11. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1456 EVAP CONTROL SYSTEM

PFP:14710

On Board Diagnosis Logic


UBS00864

This diagnosis detects very small leaks in the EVAP line between fuel tank and EVAP canister purge volume control solenoid valve, using of vapor pressure in the fuel tank in the same way as conventional EVAP small leak diagnosis.

If ECM judges a leak which corresponds to a very small leak, the very small leak P1456 will be detected.

If ECM judges a leak equivalent to a small leak, EVAP small leak P1442 will be detected.

If ECM judges there are no leaks, the diagnosis will be OK.



PBIB1438E

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1456	Evaporative emission control system very small leak (positive pressure check)	<ul style="list-style-type: none"> ● EVAP system has a very small leak. ● EVAP system does not operate properly. 	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged ● Water separator ● EVAP canister is saturated with water ● Fuel level sensor and the circuit ● EVAP control system pressure sensor ● Refueling control valve ● ORVR system leaks

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS00865

CAUTION:

Never remove fuel filler cap during the DTC confirmation procedure.

NOTE:


- If DTC P0456 or P1456 is displayed with P0442 or P1442, perform TROUBLE DIAGNOSIS FOR DTC P0456 or P1456 first.
- After repair, make sure that the hoses and clips are installed properly.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Open engine hood before conducting following procedure.
- If any of following condition is met just before the DTC confirmation procedure, leave the vehicle for more than 1 hour.
 - Fuel filler cap is removed.
 - Refilled or drained the fuel.
 - EVAP component parts is/are removed.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Make sure the following conditions are met.
 - FUEL LEVEL SE: 1.08 - 0.2V**
 - COOLAN TEMP/S: 0 - 35°C (32 - 95°F)**
 - FUEL T/TMP SE: 0 - 32°C (32 - 90°F)**
 - INT A/TEMP SE: More than 0°C (32°F)**
 If NG, turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle) or refilling/draining fuel until the output voltage condition of the "FUEL LEVEL SE" meets within the range above and leave the vehicle for more than 1 hour. Then start from step 1).
3. Turn ignition switch "OFF" and wait at least 5 seconds.
4. Turn ignition switch "ON".
5. Select "EVAP V/S LEAK P0456/P1456" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
Follow the instruction displayed.



6. Make sure that "OK" is displayed.
If "NG" is displayed, refer to [EC-1086, "Diagnostic Procedure"](#).

NOTE:

- If the engine speed cannot be maintained within the range displayed on CONSULT-II screen, go to [EC-637, "Basic Inspection"](#).

- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

Overall Function Check

UBS00866


WITH GST

Use this procedure to check the overall function of the EVAP very small leak function. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

- Never use compressed air, doing so may damage the EVAP system.
- Do not start engine.
- Do not exceeded 4.12 kPa (0.042 kg/cm², 0.6 psi).

1. Attach the EVAP service port adapter securely to the EVAP service port.
2. Set the pressure pump and a hose.
3. Also set a vacuum gauge via 3-way connector and a hose.
4. Turn ignition switch "ON".
5. Connect GST and select mode 8.
6. Using mode 8 control the EVAP canister vent control valve (close) and vacuum cut valve bypass valve (open).
7. Apply pressure and make sure the following conditions are satisfied.



Pressure to be applied: 2.7 kPa (20 mmHg, 0.79 inHg)

Time to be waited after the pressure drawn in to the EVAP system and the pressure to be dropped: 60 seconds and the pressure should not be dropped more than 0.4 kPa (3 mmHg, 0.12 inHg)

If NG, go to [EC-1086, "Diagnostic Procedure"](#) .

NOTE:

For more information, refer to GST instruction manual.

Diagnostic Procedure


UBS00867

1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch "OFF".
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

- OK >> GO TO 2.
- NG >> Replace with genuine NISSAN fuel filler cap.



2. CHECK FUEL FILLER CAP INSTALLATION

Check that the cap is tightened properly by rotating the cap clockwise.

OK or NG

- OK >> GO TO 3.
- NG >> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.
 - Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION

Check for air releasing sound while opening the fuel filler cap.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE


Refer to [EC-1160, "FUEL TANK VACUUM RELIEF VALVE \(BUILT INTO FUEL FULLER CAP\)"](#).

OK or NG

- OK >> GO TO 5.
- NG >> Replace fuel filler cap with a genuine one.

5. INSTALL THE PRESSURE PUMP


To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely.



NOTE:

Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking.

- Models with CONSULT-II >> GO TO 6.
- Models without CONSULT-II >> GO TO 7.




6. CHECK FOR EVAP LEAK

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.
3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.




7. CHECK FOR EVAP LEAK

Without CONSULT-II

1. Turn ignition switch "OFF".
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.



8. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 9.
 NG >> Replace water separator.



9. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

Refer to [EC-1076. "DTC Confirmation Procedure"](#) .

OK or NG


- OK >> GO TO 10.
 NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connector.

10. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Does water drain from the EVAP canister?

Yes or No

- Yes >> GO TO 11.
 No (With CONSULT-II)>>GO TO 13.
 No (Without CONSULT-II)>>GO TO 14.



11. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK (With CONSULT-II)>>GO TO 13.
 OK (Without CONSULT-II)>>GO TO 14.
 NG >> GO TO 12.

12. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

13. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

With CONSULT-II

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode.
4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 16.
- NG >> GO TO 15.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V

SEF677Y

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 15.

15. CHECK VACUUM HOSE

Check vacuum hoses for clogging or disconnection. Refer to [EC-590, "Vacuum Hose Drawing"](#) .

OK or NG

- OK (With CONSULT-II)>>GO TO 16.
- OK (Without CONSULT-II)>>GO TO 17.
- NG >> Repair or reconnect the hose.

16. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 18.
- NG >> GO TO 17.


ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y


17. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

 With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0 %	Yes
0.0%	No




 Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No



OK or NG


OK >> GO TO 18.

NG >> Replace EVAP canister purge volume control solenoid valve.

18. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance between fuel level sensor unit terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90



OK or NG

- OK >> GO TO 19.
- NG >> Replace fuel level sensor unit.

19. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch "ON".
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.


Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kpa (-200 mmHg, -7.87 inHg)	2.1 to 2.5V lower than above value

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK >> GO TO 20.
- NG >> Replace EVAP control system pressure sensor.



20. CHECK EVAP PURGE LINE

Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 21.
- NG >> Repair or reconnect the hose.

21. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 22.

22. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

OK >> GO TO 23.

NG >> Replace fuel level sensor unit.

23. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L

M


DTC P1464 FUEL LEVEL SENSOR

Component Description

UBS00868

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



UBS00869

On Board Diagnosis Logic

ECM receives two signals from the fuel level sensor.

One is fuel level sensor power supply circuit, and the other is fuel level sensor ground circuit.

This diagnosis indicates the latter to detect open circuit malfunction.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1464	Fuel level sensor circuit ground signal	A high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted)

DTC Confirmation Procedure

UBS0086A

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-1096, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
FUEL T/TMP SE	XXX °C
FUEL LEVEL SE	XXX V

SEF195Y

WITH GST

Follow the procedure “WITH CONSULT-II” above.



DTC P1464 FUEL LEVEL SENSOR

[VG33E]


UBS0086B

Wiring Diagram

EC-FLS3-01



Refer to the following.
F29 - ELECTRICAL UNITS



DTC P1464 FUEL LEVEL SENSOR

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	G	Fuel level sensor	[Ignition switch ON]	Approximately 0 - 4.8V Output voltage varies with fuel level.
66	B	Fuel level sensor ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS0086C

1. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and body ground. Refer to Wiring Diagram.
Continuity should exist.
4. Also check harness for short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F36, M81
- Harness for open and short between ECM and body ground

>> Replace open circuit or short to power in harness or connectors.

3. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Replace fuel level sensor unit.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

Removal and Installation FUEL LEVEL SENSOR

UBS0086D

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

DTC P1490 VACUUM CUT VALVE BYPASS VALVE

Description


COMPONENT DESCRIPTION

The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.


The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.



EVAPORATIVE EMISSION SYSTEM DIAGRAM



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VC/V BYPASS/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1490	Vacuum cut valve bypass valve circuit	An improper voltage signal is sent to ECM through vacuum cut valve bypass valve.	<ul style="list-style-type: none"> ● Harness or connectors (The vacuum cut valve bypass valve circuit is open or shorted) ● Vacuum cut valve bypass valve

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle speed.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-1100, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".


DTC P1490 VACUUM CUT VALVE BYPASS VALVE

[VG33E]


UBS0086I

Wiring Diagram

EC-BYPS/V-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 15
- LP : 17



Refer to the following.
E43 - SUPER MULTIPLE JUNCTION (SMJ)

WBWA0039E

DTC P1490 VACUUM CUT VALVE BYPASS VALVE

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
120	P/B	Vacuum cut valve bypass valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS0086J

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK VACUUM CUT VALVE BYPASS VALVE CIRCUIT

 **With CONSULT-II**

1. Turn ignition switch "OFF" and then "ON".
2. Select "VC/V BYPASS/V" in "ACTIVE TEST" mode with CONSULT-II.
3. Touch "ON/OFF" on CONSULT-II screen.
4. Make sure that clicking sound is heard from the vacuum cut valve bypass valve.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 3.


ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	XXX V

SEF014Z

3. CHECK VACUUM CUT VALVE BYPASS VALVE POWER SUPPLY CIRCUIT

⊗ **Without CONSULT-II**

1. Turn ignition switch "OFF".
2. Disconnect vacuum cut valve bypass valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M67, B101
- Harness connectors B113, C3
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between vacuum cut valve bypass valve and fuse

>> Repair harness or connectors.

5. CHECK VACUUM CUT VALVE BYPASS VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 120 and vacuum cut valve bypass valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M81, F36
- Harness for open or short between vacuum cut valve bypass valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK VACUUM CUT VALVE BYPASS VALVE

With CONSULT-II

1. Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.


ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	XXX V

SEF014Z

2. Check air passage continuity and operation delay time under the following conditions.

Condition VC/V BYPASS/V	Air passage continuity between A and B
ON	Yes
OFF	No

Operation takes less than 1 second.



Without CONSULT-II


Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

Operation takes less than 1 second.

OK or NG

- OK >> GO TO 8.
- NG >> Replace vacuum cut valve bypass valve.



8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

Description


COMPONENT DESCRIPTION

The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.


The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.



EVAPORATIVE EMISSION SYSTEM DIAGRAM



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VC/V BYPASS/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1491	Vacuum cut valve bypass valve	Vacuum cut valve bypass valve does not operate properly.	<ul style="list-style-type: none"> ● Vacuum cut valve bypass valve ● Vacuum cut valve ● Bypass hoses for clogging ● EVAP control system pressure sensor and circuit ● EVAP canister vent control valve ● Hose between fuel tank and vacuum cut valve clogged ● Hose between vacuum cut valve and EVAP canister clogged ● EVAP canister ● EVAP purge port of fuel tank for clogging ● Refueling control valve ● Refueling EVAP vapor cut valve

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5 to 30°C (41 to 86°F).

WITH CONSULT-II

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF and wait at least 5 seconds.
4. Start engine and let it idle for at least 70 seconds.
5. Select "VC CUT/V BP/V P1491" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
6. Touch "START".



7. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 30 seconds.)

CMPS-RPM (POS)	More than 500 rpm
Selector lever	Suitable position
Vehicle speed	More than 37 km/h (23 MPH)
B/FUEL SCHDL	1.0 - 11.0 msec

If "TESTING" is not displayed after 5 minutes, retry from step 3.


8. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-1107, "Diagnostic Procedure"](#).

Overall Function Check

Use this procedure to check the overall function of vacuum cut valve bypass valve. During this check, the 1st trip DTC might not be confirmed.

WITH GST

1. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
2. Apply vacuum to port **A** and check that there is no suction from port **B**.
3. Apply vacuum to port **B** and check that there is suction from port **A**.
4. Blow air in port **B** and check that there is a resistance to flow out of port **A**.
5. Supply battery voltage to the terminal.
6. Blow air in port **A** and check that air flows freely out of port **B**.
7. Blow air in port **B** and check that air flows freely out of port **A**.
8. If NG, go to [EC-1107, "Diagnostic Procedure"](#).




DTC P1491 VACUUM CUT VALVE BYPASS VALVE

[VG33E]


UBS0086P

Wiring Diagram

EC-BYPS/V-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 15
- LP : 17



WBWA0039E

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
120	P/B	Vacuum cut valve bypass valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS0086Q

1. INSPECTION START

Do you have CONSULT-II?


Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK VACUUM CUT VALVE BYPASS VALVE OPERATION

 **With CONSULT-II**

1. Turn ignition switch OFF.
2. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
3. Apply vacuum to port A and check that there is no suction from port B.
4. Apply vacuum to port B and check that there is suction from port A.
5. Blow air in port B and check that there is a resistance to flow out of port A.
6. Turn ignition switch ON.
7. Select "VC/V BYPASS/V" in "ACTIVE TEST" mode with CONSULT-II and touch "ON".
8. Blow air in port A and check that air flows freely out of port B.
9. Blow air in port B and check that air flows freely out of port A.



ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	XXX V

SEF017Z


OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.

3. CHECK VACUUM CUT VALVE BYPASS VALVE OPERATION

⊗ **Without CONSULT-II**

1. Turn ignition switch OFF.
2. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
3. Apply vacuum to port A and check that there is no suction from port B.
4. Apply vacuum to port B and check that there is suction from port A.
5. Blow air in port B and check that there is a resistance to flow out of port A.
6. Disconnect vacuum cut valve bypass valve harness connector.
7. Supply battery voltage to the terminal.
8. Blow air in port A and check that air flows freely out of port B.
9. Blow air in port B and check that air flows freely out of port A.



OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.

4. CHECK EVAP PURGE LINE

1. Check EVAP purge line between EVAP canister and fuel tank for clogging or disconnection.
2. Check EVAP purge port of fuel tank for clogging.
3. Check EVAP canister. Refer to [EC-1160](#).

OK or NG

- OK >> GO TO 8.
- NG (Step 1)>>Repair it.
- NG (Step 2)>>Clean EVAP purge port.
- NG (Step 3)>>Replace EVAP canister.

5. CHECK BYPASS HOSE

Check bypass hoses for clogging.

OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace hoses.

6. CHECK VACUUM CUT VALVE BYPASS VALVE

With CONSULT-II

- Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.


ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	XXX V
<small>SEF014Z</small>	

- Check air passage continuity and operation delay time under the following conditions.

Condition VC/V BYPASS/V	Air passage continuity between A and B
ON	Yes
OFF	No

Operation takes less than 1 second.

- Check air passage continuity and operation delay time under the following conditions.




Without CONSULT-II

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

Operation takes less than 1 second.

OK or NG

- OK >> GO TO 7.
- NG >> Replace vacuum cut valve bypass valve.




7. CHECK VACUUM CUT VALVE

Check vacuum cut valve as follows:

- Plug port **C** and **D** with fingers.
- Apply vacuum to port **A** and check that there is no suction from port **B**.
- Apply vacuum to port **B** and check that there is suction from port **A**.
- Blow air in port **B** and check that there is a resistance to flow out of port **A**.
- Open port **C** and **D**.
- Blow air in port **A** check that air flows freely out of port **C**.
- Blow air in port **B** check that air flows freely out of port **D**.

OK or NG

- OK >> GO TO 8.
- NG >> Replace vacuum cut valve.



8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

1. Turn ignition switch OFF.
2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG


- OK >> GO TO 9.
- NG >> Repair or replace.

9. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.
Water should not exist.

OK or NG

- OK >> GO TO 10.
- NG >> Replace EVAP control system pressure sensor.



10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION

Refer to "DTC Confirmation Procedure" for DTC P0452 [EC-926](#) or DTC P0453 [EC-932](#) .

OK or NG

- OK >> GO TO 11.
- NG >> Replace EVAP control system pressure sensor.

11. CHECK EVAP CANISTER VENT CONTROL VALVE

Check air passage continuity.

With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	Yes
OFF	No

Operation takes less than 1 second.

ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 (B1)	XXX V
HO2S1 (B2)	XXX V
THRTL POS SEN	XXX V

Without CONSULT-II

1. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.


OK or NG

OK >> GO TO 12.

NG >> Replace EVAP canister vent control valve.

12. CHECK REFUELING CONTROL VALVE

1. Remove fuel filler cap.
2. Check air continuity between hose ends A and B.
Blow air into the hose end B. Air should flow freely into the fuel tank.
3. Blow air into hose end A and check there is no leakage.
4. Apply pressure to both hose ends A and B [20 kPa (150 mmHg, 5.91 inHg)] using a pressure pump and a suitable 3-way connector. Check that there is no leakage.



SEF706Z


OK or NG

- OK >> GO TO 13.
- NG >> Replace fuel tank.

13. CHECK REFUELING EVAP VAPOR CUT VALVE

④ With CONSULT-II

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#).
2. Drain fuel from the tank as follows:
 - Remove fuel feed hose located on the fuel level sensor unit retainer.
 - Connect a spare fuel hose, one side to fuel level sensor unit retainer where the hose was removed and the other side to a fuel container.
 - Drain fuel using "FUEL PUMP RELAY" in "ACTIVE TEST" mode with CONSULT-II.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows. Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
Always replace O-ring with new one.
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level sensor unit retainer remaining open and check that the pressure is applicable.




⊗ Without CONSULT-II

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#).
2. Drain fuel from the tank as follows:
 - Remove fuel level sensor unit retainer.
 - Drain fuel from the tank using a hand pump into a fuel container.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows. Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
Always replace O-ring with new one.
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

[VG33E]

sensor unit retainer remaining open and check that the pressure is applicable.



OK or NG

OK >> GO TO 14.

NG >> Replace fuel tank.

14. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

PFP:23710

Component Description

EBS00GND

The malfunction information related to A/T (Automatic Transmission) is transferred through the line (circuit) from TCM (Transmission control module) to ECM. Therefore, be sure to erase the malfunction information such as DTC not only in TCM (Transmission control module) but also ECM after the A/T related repair.

On Board Diagnosis Logic

EBS00GNE

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1605	A/T diagnosis communication line	An incorrect signal from TCM (Transmission Control Module) is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors [The communication line circuit between ECM and TCM (Transmission Control Module) is open or shorted.] ● Dead (Weak) battery ● TCM (Transmission Control Module)

DTC Confirmation Procedure

EBS00GNF

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 70 seconds.
4. If 1st trip DTC is detected, go to [EC-1119, "Diagnostic Procedure"](#).

ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y

WITH GST

Follow the procedure "With CONSULT-II".



DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

[VG33E]

EBS00GNG

Wiring Diagram WITHOUT VDC

EC-ATDIAG-01



WBWA0040E

DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
7	Y/G	A/T check signal	[Ignition switch ON] [Engine is running]	0 - 3.0V

A

EC

C

D

E

F

G

H

I

J

K

L




M



DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

[VG33E]

WITH VDC

EC-CAN-01

-  : DETECTABLE LINE FOR DTC
-  : NON-DETECTABLE LINE FOR DTC
-  : DATA LINE



BBWA0503E

Specification data are reference values and are measured between each terminal and ground.

DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

[VG33E]

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
68	W/G	A/T signal	[Ignition switch ON] ● Idle speed	0 - 5.0V

Diagnostic Procedure

EBS00GNH

1. CHECK A/T DIAGNOSIS COMMUNICATION LINE INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and TCM (Transmission Control Module) harness connector.




3. Check harness continuity between ECM terminal 7 and TCM terminal 15. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between ECM and TCM (Transmission Control Module)

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1706 PNP SWITCH


Component Description

UBS0086W

When the gear position is “P” (A/T models only) or “N”, park/neutral position (PNP) switch is “ON”.

ECM detects the position because the continuity of the line (the “ON” signal) exists.

For A/T models, the park/neutral position (PNP) switch assembly also includes a transmission range switch to detect selector lever position.



CONSULT-II Reference Value in Data Monitor Mode

UBS0086X

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: “P” or “N”	ON
		Except above	OFF

On Board Diagnosis Logic

UBS0086Y

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1706	Park/neutral position switch	The signal of the park/neutral position (PNP) switch is not changed in the process of engine starting and driving.	<ul style="list-style-type: none"> ● Harness or connectors [The park/neutral position (PNP) switch circuit is open or shorted.] ● Park/neutral position (PNP) switch

DTC Confirmation Procedure

UBS0086Z

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select “P/N POSI SW” in “DATA MONITOR” mode with CONSULT-II. Then check the “P/N POSI SW” signal under the following conditions.

Position (Selector lever)	Known good signal
“N” and “P” position	ON
Except the above position	OFF

If NG, go to [EC-1123, "Diagnostic Procedure"](#) .
If OK, go to following step.

3. Select “DATA MONITOR” mode with CONSULT-II.
4. Start engine and warm it up to normal operating temperature.

DATA MONITOR	
MONITOR	NO DTC
P/N POSI SW	ON

SEF212Y

DTC P1706 PNP SWITCH

[VG33E]

5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	1,400 - 2,700 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	2.0 - 14.0 msec
VHCL SPEED SE	More than 64 km/h (40 MPH)
Selector lever	Suitable position

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF
B/FUEL SCHDL	XXX msec

SEF213Y

6. If 1st trip DTC is detected, go to [EC-1123, "Diagnostic Procedure"](#).

Overall Function Check

UBS00870


Use this procedure to check the overall function of the park/neutral position (PNP) switch circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

- Turn ignition switch ON.
- Check voltage between ECM terminal 22 and body ground under the following conditions.

Condition (Gear position)	Voltage (V) (Known good data)
"P" and "N" position	Approx. 0
Except the above position	Approx. 5

3. If NG, go to [EC-1123, "Diagnostic Procedure"](#).





DTC P1706 PNP SWITCH

[VG33E]

UBS00871

Wiring Diagram

EC-PNP/SW-01



WBWA0041E

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22	L/B	Park/neutral position (PNP) switch	[Ignition switch ON] ● Gear position is "N" or "P"	Approximately 0V
			[Ignition switch ON] ● Except the above gear position	Approximately 5V

Diagnostic Procedure FOR M/T MODELS

UBS00872

1. CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch OFF.
2. Disconnect park/neutral position (PNP) switch harness connector.
3. Check harness continuity between PNP switch terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F201, F43
- Harness for open between park/neutral position (PNP) switch and engine ground

>> Repair open circuit or short to power in harness or connectors.

3. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 22 and PNP switch terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F43, F201
- Harness for open or short between ECM and park/neutral position (PNP) switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK PARK/NEUTRAL POSITION (PNP) SWITCH

Refer to [MT-46, "Position Switch Check"](#) .

OK or NG

- OK >> GO TO 6.
NG >> Replace park/neutral position (PNP) switch.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

FOR A/T MODELS


1. CHECK PNP SWITCH POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF.
2. Disconnect park/neutral position (PNP) relay.
3. Turn ignition switch ON.
4. Shift selector lever to "P" or "N" position.
5. Check voltage between PNP relay terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.



2. CHECK PNP SWITCH POWER SUPPLY CIRCUIT-II


1. Turn ignition switch OFF.
2. Disconnect park/neutral position (PNP) switch harness connector.
3. Check harness continuity between PNP switch terminal 2 and PNP relay terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK PNP SWITCH POWER SUPPLY CIRCUIT-III

1. Turn ignition switch ON.
2. Check voltage between PNP switch terminal 1 and ground with CONSULT-II or tester. Refer to Wiring Diagram.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E49
- 7.5A fuse
- Harness for open or short between PNP switch and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK PARK/NEUTRAL POSITION (PNP) SWITCH

Refer to [AT-103, "PNP SWITCH"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace park/neutral position (PNP) switch.

6. CHECK PNP RELAY GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between PNP relay terminals 1, 6 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 8.

NG (With vehicle security system)>>GO TO 7

NG (Without vehicle security system)>>Repair open circuit or short to power in harness or connectors.

7. DETECT MALFUNCTIONING PART

Check the circuit between PNP relay and body ground.

Refer to [SC-9, "STARTING SYSTEM"](#) .

OK or NG

OK >> GO TO 11.

NG >> Repair or replace.

8. CHECK PNP RELAY INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 22 and PNP relay terminal 7. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F36, M81
- Harness connectors M65, E43
- Harness for open or short between ECM and park/neutral position (PNP) relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK PARK/NEUTRAL POSITION (PNP) RELAY


1. Apply 12V direct current between park/neutral position (PNP) relay terminals 1 and 2.
2. Check continuity between park/neutral position (PNP) relay terminals 3 and 5, 6 and 7.

12V (1 and 2) applied : Continuity should exist.
No voltage applied : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Replace park/neutral position (PNP) relay.

**11. CHECK INTERMITTENT INCIDENT**

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

IGNITION SIGNAL

Component Description

IGNITION COIL & POWER TRANSISTOR


The power transistor switches on and off the ignition coil primary circuit according to the ECM signal. As the primary circuit is turned on and off, the proper high voltage is induced in the secondary circuit. The distributor is not repairable except for the distributor cap and rotor head.

NOTE:

The rotor screw which secures the distributor rotor head to the distributor shaft must be torqued properly.



: 3.6±0.3 N·m (37±3 kg-cm, 32±3 in-lb)



A
EC
C
D
E
F
G
H
I
J
K
L
M


IGNITION SIGNAL

[VG33E]

UBS00874

Wiring Diagram





EC-IGN/SG-01



: Detectable line for DTC
 : Non-detectable line for DTC

Refer to "PG-POWER".

Refer to the following.
 (E43) - SUPER MULTIPLE JUNCTION (SMJ)



BBWA0496E



IGNITION SIGNAL

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	PU/W	Ignition signal	[Engine is running] ● Idle speed	Approximately 0.7V★ 
			[Engine is running] ● Engine speed is 2,000 rpm	1.1 - 1.5V★ 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

UBS00875

1. INSPECTION START

Turn ignition switch "OFF", and restart engine.

Is engine running?

Yes or No

- Yes (With CONSULT-II)>>GO TO 2.
- Yes (Without CONSULT-II)>>GO TO 3.
- No >> GO TO 4.

2. CHECK OVERALL FUNCTION

 **With CONSULT-II**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
2. Make sure that all circuits do not produce a momentary engine speed drop.

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 4.



ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step

SEF070Y

3. CHECK OVERALL FUNCTION

⊗ **Without CONSULT-II**

1. Let engine idle.
2. Read the voltage signal between ECM terminal 1 and ground with an oscilloscope.
3. Verify that the oscilloscope screen shows the signal wave as shown below.




OK or NG

- OK >> **INSPECTION END.**
- NG >> **GO TO 4.**

4. CHECK IGNITION COIL POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ignition coil harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 7 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M59, F27
- Harness for open or short between ignition coil and ignition switch

>> Repair harness or connectors.

6. CHECK POWER TRANSISTOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect power transistor harness connector.
3. Check harness continuity between power transistor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to power in harness or connectors.

7. CHECK INPUT SIGNAL CIRCUIT

1. Strip tape covering resistor.
2. Disconnect resistor harness connector.
3. Check harness continuity between ignition coil terminal 8 and resistor terminal 1, resistor terminal 2 and ECM terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK RESISTOR


Check resistance between resistor terminals 1 and 2.

Resistance : Approximately 2.2 k Ω [at 25°C (77°F)]

OK or NG

OK >> GO TO 9.

NG >> Replace resistor.

**9. CHECK POWER TRANSISTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 1 and power transistor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG


OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK IGNITION COIL

1. Disconnect ignition coil harness connector.
2. Check resistance as shown in the figure.


Terminal	Resistance [at 20°C (68°F)]
7 - 8 (Primary coil)	Approx. 1.0Ω
7 - 9 (secondary coil)	Approx. 10 kΩ



For checking secondary coil, remove distributor cap and measure resistance between coil tower metal tip 9 and terminal 7.

OK or NG

- OK >> GO TO 11.
 NG >> Replace distributor assembly.




11. CHECK POWER TRANSISTOR

1. Disconnect camshaft position sensor & power transistor harness connector and ignition coil harness connector.
2. Check power transistor resistance between terminals 2 and 8.

Terminals	Resistance	Result
2 and 8	Except 0Ω	OK
	0Ω	NG

OK or NG

- OK >> GO TO 12.
 NG >> Replace distributor assembly.



12. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


Removal and Installation DISTRIBUTOR

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

INJECTOR CIRCUIT

Component Description

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the ball valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
INJ PULSE-B1 INJ PULSE-B2	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	2.4 - 3.7 msec
		2,000 rpm	1.9 - 3.3 msec
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	1.0 - 1.6 msec
		2,000 rpm	0.7 - 1.4 msec







INJECTOR CIRCUIT

[VG33E]

UBS00879

Wiring Diagram

EC-INJECT-01



BBWA0497E

INJECTOR CIRCUIT

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
102 104 106 109 111 113	W/B W/R W/G W/L W/PU W	Injector No. 1 Injector No. 3 Injector No. 5 Injector No. 2 Injector No. 4 Injector No. 6	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE★ (11 - 14V)</p> <p>SEF007V</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>BATTERY VOLTAGE★ (11 - 14V)</p> <p>SEF008V</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

UBS0087A

1. INSPECTION START

Turn ignition switch to START.

Is any cylinder ignited?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step


SEF070Y

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.
Clicking noise should be heard.

OK or NG

- OK >> **INSPECTION END.**
 NG >> GO TO 3.




3. CHECK INJECTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect injector harness connector.
3. Check voltage between injector terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- Harness connectors F37, F101
- Fuse block (J/B) connector M26
- 10A fuse
- Harness for open or short between injector and fuse

>> Repair harness or connectors.

5. CHECK INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between injector terminal 2 and ECM terminals 102, 104, 106, 109, 111, 113. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F37, F101
- Harness connectors F38, F102
- Harness for open or short between ECM and injector

>> Repair open circuit or short to ground or short to power in harness or connectors.


7. CHECK INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance : 10 - 14Ω [at 25°C (77°F)]

OK or NG

- OK >> GO TO 8.
- NG >> Replace injector.



8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation INJECTOR

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

START SIGNAL

[VG33E]

START SIGNAL

PF:48750

CONSULT-II Reference Value in Data Monitor Mode

UBS0087C

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
START SIGNAL	● Ignition switch: ON → START → ON	OFF → ON → OFF

START SIGNAL


[VG33E]

UBS0087D

Wiring Diagram



EC-S/SIG-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



Refer to PG-POWER.

- : Detectable line for DTC
- : Non-detectable line for DTC
- : EARLY PRODUCTION
- : LATE PRODUCTION



WBWA0042E

START SIGNAL

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
20	L/OR	Start signal	[Ignition switch ON]	Approximately 0V
			[Ignition switch START]	9 - 12V

Diagnostic Procedure

UBS0087E

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

 **With CONSULT-II**

- Turn ignition switch ON.
- Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.

Condition	"START SIGNAL"
Ignition switch "ON"	OFF
Ignition switch "START"	ON

DATA MONITOR	
MONITOR	NO DTC
START SIGNAL	OFF
CLSD THL POS	ON
AIR COND SIG	OFF
P/N POSI SW	ON

PBIB0182E

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 4.

3. CHECK OVERALL FUNCTION


 **Without CONSULT-II**

Check voltage between ECM terminal 20 and ground under the following conditions.

Condition	Voltage
Ignition switch START	Battery voltage
Other positions	Approx. 0V

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 4.



4. CHECK STARTING SYSTEM

Turn ignition switch OFF, then turn it to START.

Does starter motor operate?

Yes or No

- Yes >> GO TO 5.
- No >> Refer to [SC-9, "STARTING SYSTEM"](#) .

5. CHECK FUSE

1. Turn ignition switch OFF.
2. Disconnect 7.5A fuse.
3. Check if 7.5A fuse is OK.

OK or NG

- OK >> GO TO 6.
NG >> Replace 7.5A fuse.

6. CHECK START SIGNAL INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 20 and fuse block. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Harness for open or short between ECM and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L

M

FUEL PUMP CIRCUIT

[VG33E]

PF:17042

UBS0087F

FUEL PUMP CIRCUIT

Description SYSTEM DESCRIPTION


Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Fuel pump control	Fuel pump relay
Ignition switch	Start signal		

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a 120° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to operate. If the 120° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds
Engine running and cranking	Operates
When engine is stopped	Stops in 1.5 seconds
Except as shown above	Stops

COMPONENT DESCRIPTION

The fuel pump with a fuel damper is an in-tank type (the pump and damper are located in the fuel tank).



CONSULT-II Reference Value in Data Monitor Mode

UBS0087G

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> ● Ignition switch is turned to ON. (Operates for 5 seconds.) ● Engine running and cranking 	ON
	Except as shown above	OFF


FUEL PUMP CIRCUIT

[VG33E]

UBS0087H

Wiring Diagram


EC-F/PUMP-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- : EARLY PRODUCTION
- : LATE PRODUCTION

Refer to PG-POWER.

A
EC
C
D
E
F
G
H
I
J
K
L
M



WBWA0043E

FUEL PUMP CIRCUIT

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
11	W/R	Fuel pump relay	[Ignition switch ON] ● For 5 seconds after turning ignition switch ON [Engine is running]	0 - 1V
			[Ignition switch ON] ● More than 5 seconds after turning ignition switch ON	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


UBS00871

1. CHECK OVERALL FUNCTION

- Turn ignition switch "ON".
- Pinch fuel feed hose with fingers.
Fuel pressure pulsation should be felt on the fuel feed hose for 5 seconds after ignition switch is turned "ON".


OK or NG

- OK >> **INSPECTION END.**
 NG >> GO TO 2.



2. CHECK FUEL PUMP RELAY POWER SUPPLY CIRCUIT

- Turn ignition switch "OFF".
- Disconnect fuel pump relay.
- Turn ignition switch "ON".




- Check voltage between terminals 2, 5 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector M31
- 15A fuse
- Harness for open or short between fuse and fuel pump relay

>> Repair harness or connectors.

4. CHECK FUEL PUMP POWER SUPPLY AND GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect fuel pump harness connector.
3. Check harness continuity between fuel pump terminal 2 and body ground, fuel pump terminal 1 and fuel pump relay terminal 3. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B101, M67
- Harness for open or short between fuel pump and body ground
- Harness for open or short between fuel pump and fuel pump relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK FUEL PUMP RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 11 and fuel pump relay terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.


- Harness connectors M81, F36
- Harness for open or short between ECM and fuel pump relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK FUEL PUMP RELAY

With CONSULT-II

1. Reconnect fuel pump relay, fuel pump harness connector and ECM harness connector.
2. Turn ignition switch "ON".
3. Turn fuel pump relay "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.




Without CONSULT-II

Check continuity between terminals 3 and 5.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

OK or NG

- OK >> GO TO 9.
- NG >> Replace fuel pump relay.




9. CHECK FUEL PUMP

1. Disconnect fuel pump harness connector.
2. Check resistance between terminals 1 and 2.

Resistance : 0.2 - 5.0Ω [at 25°C (77°F)]

OK or NG

- OK >> GO TO 10.
- NG >> Replace fuel pump.



10. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


Removal and Installation FUEL PUMP

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

POWER STEERING OIL PRESSURE SWITCH

Component Description

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the IACV-AAC valve to increase the idle speed and adjust for the increased load.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel in neutral position (forward direction)	OFF
		The steering wheel is fully turned.	ON




POWER STEERING OIL PRESSURE SWITCH

[VG33E]

UBS0087M

Wiring Diagram

EC-PST/SW-01



BBWA0500E

POWER STEERING OIL PRESSURE SWITCH

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
39	GY/R	Power steering oil pressure switch	[Engine is running] ● Steering wheel is being turned	Approximately 0V
			[Engine is running] ● Steering wheel is not being turned	Approximately 5V

Diagnostic Procedure

UBS0087N

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION


With CONSULT-II

- Start engine.
- Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT-II.

Condition	PW/ST SIGNAL
Steering is in neutral position	OFF
Steering is turned	ON

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 4.



3. CHECK OVERALL FUNCTION


Without CONSULT-II

- Start engine.
- Check voltage between ECM terminal 39 and ground.

Condition	Voltage [V]
Steering is neutral position	Approx. 5
Steering is turned to full position	Approx. 0

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 4.



4. CHECK POWER STEERING OIL PRESSURE SWITCH GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch OFF.
2. Disconnect power steering oil pressure switch harness connector.
3. Check harness continuity between power steering oil pressure switch terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
 NG >> Repair open circuit or short to power in harness or connectors.



5. CHECK POWER STEERING OIL PRESSURE SWITCH INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 39 and power steering oil pressure switch terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.


6. CHECK POWER STEERING OIL PRESSURE SWITCH

1. Disconnect power steering oil pressure switch harness connector then start engine.
2. Check continuity between terminals 1 and 2.

Conditions	Continuity
Steering wheel is being fully turned	Yes
Steering wheel is not being turned	No

OK or NG

- OK >> GO TO 7.
 NG >> Replace power steering oil pressure switch.



7. CHECK INTERMITTENT INCIDENT

Refer to [EC-688, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

IACV-FICD SOLENOID VALVE

[VG33E]


PFP:23781

UBS00870

IACV-FICD SOLENOID VALVE

Component Description

When the air conditioner is on, the IACV-FICD solenoid valve supplies additional air to adjust to the increased load.



A

EC

C

D

E

F

G

H

I

J

K

L

M



IACV-FICD SOLENOID VALVE

[VG33E]

UBS0087P

Wiring Diagram

EC-FICD-01



WBWA0044E

IACV-FICD SOLENOID VALVE

[VG33E]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
9	B/Y	Ambient air temperature switch	[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is above 25°C (77°F) ● Air conditioner is operating 	0V
			[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is below 19°C (66°F) ● Air conditioner is operating 	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is below 19°C (66°F) ● Air conditioner is not operating 	Approximately 5V
12	P	Air conditioner relay	[Engine is running] <ul style="list-style-type: none"> ● Both A/C switch and blower switch are ON* 	0 - 1V
			[Engine is running] <ul style="list-style-type: none"> ● A/C switch is OFF 	BATTERY VOLTAGE (11 - 14V)

*: Any mode except OFF, ambient air temperature is above 25°C (77°F).

Diagnostic Procedure

UBS0087Q


1. CHECK OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.
750±50 rpm (in "P" or "N" position)
 If NG, adjust idle speed.
3. Turn air conditioner switch and blower fan switch ON.
4. Recheck idle speed.

850 rpm or more (in "P" or "N" position)

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 2.



SEF742U

2. CHECK AIR CONDITIONER FUNCTION


Check if air conditioner compressor functions normally.

OK or NG

- OK >> GO TO 3.
- NG >> Refer to [MTC-25. "SYMPTOM TABLE"](#).

3. CHECK IACV-FICD SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn air conditioner switch and blower fan switch OFF.
2. Stop engine.
3. Disconnect IACV-FICD solenoid valve harness connector.
4. Start engine, then turn air conditioner switch and blower fan switch ON.




5. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : **Battery voltage**

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F38, F102
- Harness for open or short between IACV-FICD solenoid valve and harness connector F27

>> Repair harness or connectors.

5. CHECK IACV-FICD SOLENOID VALVE GROUND CIRCUIT-I

1. Turn ignition switch OFF.
2. Disconnect ambient air temperature switch harness connector.
3. Check harness continuity between ambient air temperature switch terminal 1 and body ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to power in harness or connectors.

6. CHECK IACV-FICD SOLENOID VALVE GROUND CIRCUIT-II


1. Check harness continuity between ambient air temperature switch terminal 2 and IACV-FICD solenoid valve terminal 1.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.



7. DETECT MALFUNCTIONING PART


Check the following.

- Harness connectors F38, F102
- Harness connectors F36, M81
- Harness connectors M65, E43
- Diode-3
- Harness for open or short between IACV-FICD solenoid valve and ambient air temperature switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK IACV-FICD SOLENOID VALVE


1. Disconnect IACV-FICD solenoid valve harness connector.
2. Check for clicking sound when applying 12V direct current to terminals.
3. Check plunger for seizing or sticking.



4. Check for broken spring.

OK or NG

- OK >> GO TO 9.
- NG >> Replace IACV-FICD solenoid valve.



9. CHECK INTERMITTENT INCIDENT

Refer to [EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .



>> INSPECTION END.

MIL AND DATA LINK CONNECTOR



PF2:24814

Wiring Diagram

UBS0087S



Refer to the following.
F29 - ELECTRICAL UNITS




EVAPORATIVE EMISSION SYSTEM

PFP:14950

UBS0087T

Description SYSTEM DESCRIPTION



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister.

The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank.


The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases.

EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.

EVAPORATIVE EMISSION SYSTEM

[VG33E]

EVAPORATIVE EMISSION LINE DRAWING




NOTE:
Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.

BBA0184E

EVAPORATIVE EMISSION SYSTEM

[VG33E]




A
EC
C
D
E
F
G
H
I
J
K
L
M

AEC886A

Component Inspection EVAP CANISTER

Check EVAP canister as follows:


1. Pinch the fresh air hose.
2. Blow air into port **A** and check that it flows freely out of port **B**.



Tightening Torque


Tighten EVAP canister as shown in the figure.

Make sure new O-ring is installed properly between EVAP canister and EVAP canister vent control valve.



FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FULLER CAP)

1. Wipe clean valve housing.



2. Check valve opening pressure and vacuum.


Pressure: 15.3 - 20.0 kPa (0.156 - 0.204 kg/cm², 2.22 - 2.90 psi)

Vacuum: -6.0 to -3.3 kPa (-0.061 to -0.034 kg/cm², -0.87 to -0.48 psi)

3. If out of specification, replace fuel filler cap as an assembly.

CAUTION:

Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come ON



VACUUM CUT VALVE AND VACUUM CUT VALVE BYPASS VALVE

Refer to [EC-1097](#).

EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL SOLENOID VALVE


Refer to [EC-913](#).

FUEL TANK TEMPERATURE SENSOR

Refer to [EC-826](#).

EVAP SERVICE PORT

Positive pressure is delivered to the EVAP system through the EVAP service port. If fuel vapor leakage in the EVAP system occurs, use a leak detector to locate the leak.



How to Detect Fuel Vapor Leakage

UBS0087V

CAUTION:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in EVAP system.

NOTE:


- Do not start engine.
- Improper installation of EVAP service port adapter to the EVAP service port may cause a leak.

Ⓟ WITH CONSULT-II

1. Attach the EVAP service port adapter securely to the EVAP service port.
2. Also attach the pressure pump and hose to the EVAP service port adapter.
3. Turn ignition switch "ON".
4. Select the "EVAP SYSTEM CLOSE" of "WORK SUPPORT MODE" with CONSULT-II.
5. Touch "START". A bar graph (Pressure indicating display) will appear on the screen.




6. Apply positive pressure to the EVAP system until the pressure indicator reaches the middle of the bar graph.
7. Remove EVAP service port adapter and hose with pressure pump.



EVAPORATIVE EMISSION SYSTEM


[VG33E]

8. Locate the leak using a leak detector. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).




⊗ WITHOUT CONSULT-II

1. Attach the EVAP service port adapter securely to the EVAP service port.
2. Also attach the pressure pump with pressure gauge to the EVAP service port adapter.




3. Apply battery voltage to between the terminals of both EVAP canister vent control valve and vacuum cut valve bypass valve to make a closed EVAP system.
4. To locate the leak, deliver positive pressure to the EVAP system until pressure gauge points reach 1.38 to 2.76 kPa (0.014 to 0.028 kg/cm², 0.2 to 0.4 psi).
5. Remove EVAP service port adapter and hose with pressure pump.
6. Locate the leak using a leak detector. Refer to [EC-1158, "EVAPORATIVE EMISSION LINE DRAWING"](#).



ON BOARD REFUELING VAPOR RECOVERY (ORVR)

System Description



SEF206VA

From the beginning of refueling, the fuel tank pressure goes up. When the pressure reaches the setting value of the refueling control valve (RCV) opening pressure, the RCV is opened. After RCV opens, the air and vapor inside the fuel tank go through refueling EVAP vapor cut valve, RCV and refueling vapor line to the EVAP canister. The vapor is absorbed by the EVAP canister and the air is released to the atmosphere.

When the refueling has reached the full level of the fuel tank, the refueling EVAP vapor cut valve is closed and refueling is stopped because of auto shut-off. The vapor which was absorbed by the EVAP canister is purged during driving.

The RCV is always closed during driving and the evaporative emission control system is operated the same as conventional system.

WARNING:

When conducting inspections below, be sure to observe the following:

- Put a "CAUTION: INFLAMMABLE" sign in workshop.
- Do not smoke while servicing fuel system. Keep open flames and sparks away from work area.
- Be sure to furnish the workshop with a CO₂ fire extinguisher.

CAUTION:

- Before removing fuel line parts, carry out the following procedures:
 - Put drained fuel in an explosion-proof container and put lid on securely.
 - Release fuel pressure from fuel line. Refer to [EC-608. "FUEL PRESSURE RELEASE"](#).
 - Disconnect battery ground cable.
- Always replace O-ring when the fuel gauge retainer is removed.
- Do not kink or twist hose and tube when they are installed.
- Do not tighten hose and clamps excessively to avoid damaging hoses.
- After installation, run engine and check for fuel leaks at connection.
- Do not attempt to top off the fuel tank after the fuel pump nozzle shuts off automatically. Continued refueling may cause fuel overflow, resulting in fuel spray and possibly a fire.

Diagnostic Procedure

SYMPTOM: FUEL ODOR FROM EVAP CANISTER IS STRONG.

1. CHECK EVAP CANISTER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Weigh the EVAP canister with EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG


- OK >> GO TO 2.
- NG >> GO TO 3.

2. CHECK IF EVAP CANISTER SATURATED WITH WATER

- Does water drain from the EVAP canister?

Yes or No

- Yes >> GO TO 3.
- No (With CONSULT-II) >> GO TO 6.
- No (Without CONSULT-II) >> GO TO 7.



3. REPLACE EVAP CANISTER

Replace EVAP canister with a new one.

>> GO TO 4.

4. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 5.
- NG >> Replace water separator.



5. DETECT MALFUNCTIONING PART

Check the EVAP hose between EVAP canister and water separator for clogging or poor connection.


>> Repair or replace EVAP hose.

6. CHECK REFUELING EVAP VAPOR CUT VALVE

With CONSULT-II

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel feed hose located on the fuel level sensor unit retainer.
 - Connect a spare fuel hose, one side to fuel level sensor unit retainer where the hose was removed and the other side to a fuel container.
 - Drain fuel using "FUEL PUMP RELAY" in "ACTIVE TEST" mode with CONSULT-II.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.

Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
 - Always replace O-ring with new one.**
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level sensor unit retainer remaining open and check that the pressure is applicable.




OK or NG

- OK >> GO TO 8.
- NG >> Replace refueling EVAP vapor cut valve with fuel tank.

7. CHECK REFUELING EVAP VAPOR CUT VALVE

⊗ **Without CONSULT-II**

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel level sensor unit retainer.
 - Drain fuel from the tank using a hand pump into a fuel container.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.
Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
Always replace O-ring with new one.
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level sensor unit retainer remaining open and check that the pressure is applicable.




OK or NG

- OK >> GO TO 8.
- NG >> Replace refueling EVAP vapor cut valve with fuel tank.

8. CHECK REFUELING CONTROL VALVE

1. Remove fuel filler cap.
2. Check air continuity between hose ends A and B.
Blow air into the hose end B. Air should flow freely into the fuel tank.
3. Blow air into hose end A and check there is no leakage.
4. Apply pressure to both hose ends A and B [20 kPa (150 mmHg, 5.91 inHg)] using a pressure pump and a suitable 3-way connector. Check that there is no leakage.



OK or NG

OK >> **INSPECTION END.**

NG >> Replace refueling control valve with fuel tank.

SYMPTOM: CANNOT REFUEL/FUEL ODOR FROM THE FUEL FILLER OPENING IS STRONG WHILE REFUELING.

1. CHECK EVAP CANISTER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Weigh the EVAP canister with EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG

OK >> GO TO 2.

NG >> GO TO 3.


2. CHECK IF EVAP CANISTER SATURATED WITH WATER

- Does water drain from the EVAP canister?

Yes or No

Yes >> GO TO 3.

No >> GO TO 6.



3. REPLACE EVAP CANISTER

Replace EVAP canister with a new one.

>> GO TO 4.

4. CHECK WATER SEPARATOR

1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.


NOTE:

- Do not disassemble water separator.

OK or NG

OK >> GO TO 5.

NG >> Replace water separator.



5. DETECT MALFUNCTIONING PART

Check the EVAP hose between EVAP canister and water separator for clogging or poor connection.

>> Repair or replace EVAP hose.

6. CHECK VENT HOSES AND VENT TUBES

Check hoses and tubes between EVAP canister and refueling control valve for clogging, kink, looseness and improper connection.

OK or NG

OK >> GO TO 7.

NG >> Repair or replace hoses and tubes.

7. CHECK FILLER NECK TUBE

Check signal line and recirculation line for clogging, dents and cracks.


OK or NG

OK >> GO TO 8.

NG >> Replace filler neck tube.

8. CHECK REFUELING CONTROL VALVE

1. Remove fuel filler cap.
2. Check air continuity between hose ends A and B.
Blow air into the hose end B. Air should flow freely into the fuel tank.
3. Blow air into hose end A and check there is no leakage.
4. Apply pressure to both hose ends A and B [20 kPa (150 mmHg, 5.91 inHg)] using a pressure pump and a suitable 3-way connector. Check that there is no leakage.



OK or NG

OK (With CONSULT-II)>>GO TO 9.


OK (Without CONSULT-II)>>GO TO 10.

NG >> Replace refueling control valve with fuel tank.

9. CHECK REFUELING EVAP VAPOR CUT VALVE

With CONSULT-II

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel feed hose located on the fuel level sensor unit retainer.
 - Connect a spare fuel hose, one side to fuel level sensor unit retainer where the hose was removed and the other side to a fuel container.
 - Drain fuel using "FUEL PUMP RELAY" in "ACTIVE TEST" mode with CONSULT-II.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.
Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
Always replace O-ring with new one.
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level sensor unit retainer remaining open and check that the pressure is applicable.




OK or NG

- OK >> GO TO 11.
- NG >> Replace refueling EVAP vapor cut valve with fuel tank.

10. CHECK REFUELING EVAP VAPOR CUT VALVE

⊗ **Without CONSULT-II**

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel level sensor unit retainer.
 - Drain fuel from the tank using a hand pump into a fuel container.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows. Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
Always replace O-ring with new one.
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level sensor unit retainer remaining open and check that the pressure is applicable.



OK or NG

OK >> GO TO 11.

NG >> Replace refueling EVAP vapor cut valve with fuel tank.

11. CHECK FUEL FILLER TUBE

Check filler neck tube and hose connected to the fuel tank for clogging, dents and cracks.

OK or NG

OK >> GO TO 12.

NG >> Replace fuel filler tube.

12. CHECK ONE-WAY FUEL VALVE-I

Check one-way valve for clogging.

OK or NG

OK >> GO TO 13.

NG >> Repair or replace one-way fuel valve with fuel tank.

13. CHECK ONE-WAY FUEL VALVE-II


1. Make sure that fuel is drained from the tank.
2. Remove fuel filler tube and hose.
3. Check one-way fuel valve for operation as follows.
When a stick is inserted, the valve should open, when removing stick it should close.

Do not drop any material into the tank.

OK or NG

OK >> **INSPECTION END.**

NG >> Replace fuel filler tube or replace one-way fuel valve with fuel tank.



POSITIVE CRANKCASE VENTILATION

Description

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.

During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.



Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.


This system returns blow-by gas to the intake manifold.



Component Inspection


PCV (POSITIVE CRANKCASE VENTILATION) VALVE

With engine running at idle, remove PCV valve from rocker cover; if the valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.



PCV VALVE VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



SERVICE DATA AND SPECIFICATIONS (SDS)

[VG33E]

SERVICE DATA AND SPECIFICATIONS (SDS)

PF0:00030

Fuel Pressure Regulator

UBS00880

Fuel pressure at idling kPa (kg/cm ² , psi)	
Vacuum hose is connected	Approximately 235 (2.4, 34)
Vacuum hose is disconnected	Approximately 294 (3.0, 43)

Idle Speed and Ignition Timing

UBS00881

Base idle speed*1	No-load*4 (in "P" or "N" position)	700±50 rpm
Target idle speed*2	No-load*4 (in "P" or "N" position)	750±50 rpm
Air conditioner: ON	In "P" or "N" position	850 rpm or more
Ignition timing*3	In "P" or "N" position	10°±2° BTDC
Throttle position sensor idle position		0.15 - 0.85V

*1: Throttle position sensor harness connector disconnected or using CONSULT-II "WORK SUPPORT" mode

*2: Throttle position sensor harness connector connected

*3: Throttle position sensor harness connector disconnected

*4: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Ignition Coil

UBS00882

Primary voltage	12V
Primary resistance [at 20°C (68°F)]	Approximately 1.0Ω
Secondary resistance [at 20°C (68°F)]	Approximately 10 kΩ

Mass Air Flow Sensor

UBS00883

Supply voltage	Battery voltage (11 - 14)V
Output voltage at idle	1.0 - 1.7*V
Mass air flow (Using CONSULT-II or GST)	3.3 - 4.8 g-m/sec at idle* 12.0 - 14.9 g-m/sec at 2,500 rpm*

*: Engine is warmed up to normal operating temperature and running under no-load.

Engine Coolant Temperature Sensor

UBS00884

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

Heated Oxygen Sensor 1 Heater

UBS00885

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

Fuel Pump

UBS00886

Resistance [at 25°C (77°F)]	0.2 - 5.0Ω
-----------------------------	------------

IACV-AAC Valve

UBS00887

Resistance [at 20°C (68°F)]	Approximately 10.0Ω
-----------------------------	---------------------

Injector

UBS00888

Resistance [at 25°C (77°F)]	10 - 14Ω
-----------------------------	----------

SERVICE DATA AND SPECIFICATIONS (SDS)

[VG33E]

Throttle Position Sensor

UBS00889

Throttle valve conditions	Voltage (at normal operating temperature, engine off, ignition switch ON)
Completely closed (a)	0.15 - 0.85V
Partially open	Between (a) and (b)
Completely open (b)	3.5 - 4.7V

Calculated Load Value

UBS0088A

	Calculated load value % (Using CONSULT or GST)
At idle	18.0 - 26.0
At 2,500 rpm	18.0 - 21.0

Intake Air Temperature Sensor

UBS0088B

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38

Heated Oxygen Sensor 2 Heater

UBS0088C

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

Crankshaft Position Sensor (OBD)

UBS0088D

Resistance [at 20°C (68°F)]	512 - 632Ω
-----------------------------	------------

Fuel Tank Temperature Sensor

UBS0088E

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

INDEX FOR DTC

[VG33ER]

INDEX FOR DTC

PFP:00024

Alphabetical Index

UBS0088F

x: Applicable —: Not applicable

Item (CONSULT-II screen terms)	DTC*1*2	Trip	MIL Lighting up	Reference page
	CONSULT-II GST			
Unable to access ECM	—	—	—	EC-1237
A/T 1ST GR FNCTN	P0731	2	×	AT-119
A/T 2ND GR FNCTN	P0732	2	×	AT-125
A/T 3RD GR FNCTN	P0733	2	×	AT-131
A/T 4TH GR FNCTN	P0734	2	×	AT-137
A/T COMM LINE	P0600*4	2	—	EC-1578
A/T DIAG COMM LINE	P1605	2	×	EC-1689
A/T TCC S/V FNCTN	P0744	2	×	AT-149
ATF TEMP SEN/CIRC	P0710	2	×	AT-105
CKP SEN/CIRCUIT	P0335	2	×	EC-1461
CKP SENSOR (COG)	P1336	2	×	EC-1628
CLOSED LOOP-B1	P1148	1	×	EC-1622
CLOSED LOOP-B2	P1168	1	×	EC-1622
CLOSED TP SW/CIRC	P0510	2	×	EC-1571
CMP SEN/CIRCUIT	P0340	2	×	EC-1467
CYL1 MISFIRE	P0301	2	×	EC-1448
CYL2 MISFIRE	P0302	2	×	EC-1448
CYL3 MISFIRE	P0303	2	×	EC-1448
CYL4 MISFIRE	P0304	2	×	EC-1448
CYL5 MISFIRE	P0305	2	×	EC-1448
CYL6 MISFIRE	P0306	2	×	EC-1448
ECM	P0605	2	×	EC-1584
ECT SEN/CIRCUIT	P0117*3	1	×	EC-1335
ECT SEN/CIRCUIT	P0118*3	1	×	EC-1335
ECT SENSOR	P0125	2	×	EC-1356
ENG OVER TEMP	P0217	1	×	EC-1440
ENG OVER TEMP	P1217	1	×	EC-1624
ENG SPEED SIG	P0725	2	×	AT-115
EVAP GROSS LEAK	P0455	2	×	EC-1528
EVAP PURG FLOW/MON	P0441	2	×	EC-1480
EVAP SMALL LEAK	P0442	2	×	EC-1488
EVAP SMALL LEAK	P1442	2	×	EC-1633
EVAP SYS PRES SEN	P0452	2	×	EC-1513
EVAP SYS PRES SEN	P0453	2	×	EC-1519
EVAP VERY SML LEAK	P0456	2	×	EC-1538
EVAP VERY SML LEAK	P1456	2	×	EC-1658
FTT SEN/CIRCUIT	P0182	2	×	EC-1436
FTT SEN/CIRCUIT	P0183	2	×	EC-1436
FTT SENSOR	P0181	2	×	EC-1431
FUEL LEV SEN SLOSH	P0460	2	×	EC-1549

INDEX FOR DTC

[VG33ER]

Item (CONSULT-II screen terms)	DTC*1*2	Trip	MIL Lighting up	Reference page	
	CONSULT-II GST				
FUEL LEVEL SEN/CIRC	P1464	2	×	EC-1668	
FUEL LEVEL SENSOR	P0461	2	×	EC-1553	EC
FUEL LEVL SEN/CIRC	P0462	2	×	EC-1555	
FUEL LEVL SEN/CIRC	P0463	2	×	EC-1555	C
FUEL SYS-LEAN-B1	P0171	2	×	EC-1415	
FUEL SYS-LEAN-B2	P0174	2	×	EC-1415	
FUEL SYS-RICH-B1	P0172	2	×	EC-1423	D
FUEL SYS-RICH-B2	P0175	2	×	EC-1423	
HO2S1 (B1)	P0132	2	×	EC-1363	E
HO2S1 (B1)	P0133	2	×	EC-1372	
HO2S1 (B1)	P0134	2	×	EC-1385	
HO2S1 (B1)	P1143	2	×	EC-1586	F
HO2S1 (B1)	P1144	2	×	EC-1593	
HO2S1 (B2)	P0152	2	×	EC-1363	G
HO2S1 (B2)	P0153	2	×	EC-1372	
HO2S1 (B2)	P0154	2	×	EC-1385	
HO2S1 (B2)	P1163	2	×	EC-1586	H
HO2S1 (B2)	P1164	2	×	EC-1593	
HO2S1 HTR (B1)	P0031	2	×	EC-1294	I
HO2S1 HTR (B1)	P0032	2	×	EC-1294	
HO2S1 HTR (B2)	P0051	2	×	EC-1294	
HO2S1 HTR (B2)	P0052	2	×	EC-1294	J
HO2S2 HTR (B1)	P0037	2	×	EC-1308	
HO2S2 HTR (B1)	P0038	2	×	EC-1308	
HO2S2 HTR (B2)	P0057	2	×	EC-1308	K
HO2S2 HTR (B2)	P0058	2	×	EC-1308	
HO2S2 (B1)	P0138	2	×	EC-1396	L
HO2S2 (B1)	P0139	2	×	EC-1405	
HO2S2 (B1)	P1146	2	×	EC-1600	
HO2S2 (B1)	P1147	2	×	EC-1611	M
HO2S2 (B2)	P0158	2	×	EC-1396	
HO2S2 (B2)	P0159	2	×	EC-1405	
HO2S2 (B2)	P1166	2	×	EC-1600	
HO2S2 (B2)	P1167	2	×	EC-1611	
IAT SEN/CIRCUIT	P0112	2	×	EC-1330	
IAT SEN/CIRCUIT	P0113	2	×	EC-1330	
IAT SENSOR	P0127	2	×	EC-1359	
ISC SYSTEM/CIRC	P0505	2	×	EC-1564	
KNOCK SEN/CIRC-B1	P0327	2	—	EC-1457	
KNOCK SEN/CIRC-B1	P0328	2	—	EC-1457	
L/PRESS SOL/CIRC	P0745	2	×	AT-156	
MAF SEN/CIRCUIT	P0101	2	×	EC-1317	
MAF SEN/CIRCUIT	P0102*3	1	×	EC-1324	

INDEX FOR DTC

[VG33ER]

Item (CONSULT-II screen terms)	DTC*1*2	Trip	MIL Lighting up	Reference page
	CONSULT-II GST			
MAF SEN/CIRCUIT	P0103*3	2	×	EC-1324
MULTI CYL MISFIRE	P0300	2	×	EC-1448
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	—	—	—
O/R CLTCH SOL/CIRC	P1760	2	×	AT-178
P-N POS SW/CIRCUIT	P1706	2	×	EC-1694
PNP SW/CIRC	P0705	2	×	AT-99
PURG VOLUME CONT/V	P0444	2	×	EC-1500
PURG VOLUME CONT/V	P0445	2	×	EC-1500
PURG VOLUME CONT/V	P1444	2	×	EC-1635
SC FUNCTION	P0299	2	×	EC-1445
SCB/V CONT SOL/V	P0034	2	×	EC-1302
SFT SOL A/CIRC	P0750*3	2	×	AT-161
SFT SOL B/CIRC	P0755*3	2	×	AT-166
TCC SOLENOID/CIRC	P0740	2	×	AT-144
THERMSTAT FNCTN	P0128	2	×	EC-1361
TP SEN/CIRC A/T	P1705*5	1	×	AT-171
TP SEN/CIRCUIT	P0121	2	×	EC-1340
TP SEN/CIRCUIT	P0122*3	1	×	EC-1349
TP SEN/CIRCUIT	P0123*3	1	×	EC-1349
TW CATALYST SYS-B1	P0420	2	×	EC-1474
TW CATALYST SYS-B2	P0430	2	×	EC-1474
VC CUT/V BYPASS/V	P1491	2	×	EC-1677
VC/V BYPASS/V	P1490	2	×	EC-1671
VEH SPEED SEN/CIRC AT	P0720	2	×	AT-110
VEH SPEED SEN/CIRC	P0500*5	2	×	EC-1559
VENT CONTROL VALVE	P0447	2	×	EC-1507
VENT CONTROL VALVE	P1446	2	×	EC-1644
VENT CONTROL VALVE	P1448	2	×	EC-1650

*1: 1st trip DTC No. 1 is the same as DTC No.

*2: These numbers are prescribed by SAE J2012.

*3: When the fail-safe operation occurs, the MIL illuminates.

*4: This DTC is displayed with CONSULT-II only.

*5: The MIL illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

NOTE:

Regarding WD22 models, "B1" indicates bank 1, "B2" indicates bank 2.

DTC No. Index

UBS0088G

x: Applicable —: Not applicable

DTC*1*2	Items (CONSULT-II screen terms)	Trip	MIL Lighting up	Reference page
CONSULT-II GST				
—	Unable to access ECM	2	×	EC-1237
P0000	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—

INDEX FOR DTC

[VG33ER]

DTC*1*2	Items (CONSULT-II screen terms)	Trip	MIL Lighting up	Reference page
CONSULT-II GST				
P0031	HO2S1 HTR (B1)	2	×	EC-1294
P0032	HO2S1 HTR (B1)	2	×	EC-1294
P0034	SCB/V CONT SOL/V	2	×	EC-1302
P0037	HO2S2 HTR (B1)	2	×	EC-1308
P0038	HO2S2 HTR (B1)	2	×	EC-1308
P0051	HO2S1 HTR (B2)	2	×	EC-1294
P0052	HO2S1 HTR (B2)	2	×	EC-1294
P0057	HO2S2 HTR (B2)	2	×	EC-1308
P0058	HO2S2 HTR (B2)	2	×	EC-1308
P0101	MAF SEN/CIRCUIT	2	×	EC-1317
P0102*3	MAF SEN/CIRCUIT	1	×	EC-1324
P0103*3	MAF SEN/CIRCUIT	2	×	EC-1324
P0112	IAT SEN/CIRCUIT	2	×	EC-1330
P0113	IAT SEN/CIRCUIT	2	×	EC-1330
P0117*3	ECT SEN/CIRCUIT	1	×	EC-1335
P0118*3	ECT SEN/CIRCUIT	1	×	EC-1335
P0121	TP SEN/CIRCUIT	2	×	EC-1340
P0122*3	TP SEN/CIRCUIT	1	×	EC-1349
P0123*3	TP SEN/CIRCUIT	1	×	EC-1349
P0125	ECT SENSOR	2	×	EC-1356
P0127	IAT SENSOR	2	×	EC-1359
P0128	THERMSTAT FNCTN	2	×	EC-1361
P0132	HO2S1 (B1)	2	×	EC-1363
P0133	HO2S1 (B1)	2	×	EC-1372
P0134	HO2S1 (B1)	2	×	EC-1385
P0138	HO2S2 (B1)	2	×	EC-1396
P0139	HO2S2 (B1)	2	×	EC-1405
P0152	HO2S1 (B2)	2	×	EC-1363
P0153	HO2S1 (B2)	2	×	EC-1372
P0154	HO2S1 (B2)	2	×	EC-1385
P0158	HO2S2 (B2)	2	×	EC-1396
P0159	HO2S2 (B2)	2	×	EC-1405
P0171	FUEL SYS-LEAN-B1	2	×	EC-1415
P0172	FUEL SYS-RICH-B1	2	×	EC-1423
P0174	FUEL SYS-LEAN-B2	2	×	EC-1415
P0175	FUEL SYS-RICH-B2	2	×	EC-1423
P0181	FTT SENSOR	2	×	EC-1431
P0182	FTT SEN/CIRCUIT	2	×	EC-1436
P0183	FTT SEN/CIRCUIT	2	×	EC-1436
P0217	ENG OVER TEMP	1	×	EC-1440
P0299	SC FUNCTION	2	×	EC-1445
P0300	MULTI CYL MISFIRE	2	×	EC-1448
P0301	CYL1 MISFIRE	2	×	EC-1448

A
EC
C
D
E
F
G
H
I
J
K
L
M

INDEX FOR DTC

[VG33ER]

DTC*1*2	Items (CONSULT-II screen terms)	Trip	MIL Lighting up	Reference page
CONSULT-II GST				
P0302	CYL2 MISFIRE	2	×	EC-1448
P0303	CYL3 MISFIRE	2	×	EC-1448
P0304	CYL4 MISFIRE	2	×	EC-1448
P0305	CYL5 MISFIRE	2	×	EC-1448
P0306	CYL6 MISFIRE	2	×	EC-1448
P0327	KNOCK SEN/CIRC-B1	2	—	EC-1457
P0328	KNOCK SEN/CIRC-B1	2	—	EC-1457
P0335	CKP SEN/CIRCUIT	2	×	EC-1461
P0340	CMP SEN/CIRCUIT	2	×	EC-1467
P0420	TW CATALYST SYS-B1	2	×	EC-1474
P0430	TW CATALYST SYS-B2	2	×	EC-1474
P0441	EVAP PURG FLOW/MON	2	×	EC-1480
P0442	EVAP SMALL LEAK	2	×	EC-1488
P0444	PURG VOLUME CONT/V	2	×	EC-1500
P0445	PURG VOLUME CONT/V	2	×	EC-1500
P0447	VENT CONTROL VALVE	2	×	EC-1507
P0452	EVAP SYS PRES SEN	2	×	EC-1513
P0453	EVAP SYS PRES SEN	2	×	EC-1519
P0455	EVAP GROSS LEAK	2	×	EC-1528
P0456	EVAP VERY SML LEAK	2	×	EC-1538
P0460	FUEL LEV SEN SLOSH	2	×	EC-1549
P0461	FUEL LEVEL SENSOR	2	×	EC-1553
P0462	FUEL LEVL SEN/CIRC	2	×	EC-1555
P0463	FUEL LEVL SEN/CIRC	2	×	EC-1555
P0500*5	VEH SPEED SEN/CIRC	2	×	EC-1559
P0505	ISC SYSTEM/CIRC	2	×	EC-1564
P0510	CLOSED TP SW/CIRC	2	×	EC-1571
P0600*4	A/T COMM LINE	2	—	EC-1578
P0605	ECM	2	×	EC-1584
P0705	PNP SW/CIRC	2	×	AT-99
P0710	ATF TEMP SEN/CIRC	2	×	AT-105
P0720	VEH SPD SEN/CIR AT	2	×	AT-110
P0725	ENGINE SPEED SIG	2	×	AT-115
P0731	A/T 1ST GR FNCTN	2	×	AT-119
P0732	A/T 2ND GR FNCTN	2	×	AT-125
P0733	A/T 3RD GR FNCTN	2	×	AT-131
P0734	A/T 4TH GR FNCTN	2	×	AT-137
P0740	TCC SOLENOID/CIRC	2	×	AT-144
P0744	A/T TCC S/V FNCTN	2	×	AT-149
P0745	L/PRESS SOL/CIRC	2	×	AT-156
P0750*3	SFT SOL A/CIRC	2	×	AT-161
P0755*3	SFT SOL B/CIRC	2	×	AT-166
P1143	HO2S1 (B1)	2	×	EC-1586

INDEX FOR DTC

[VG33ER]

DTC*1*2	Items (CONSULT-II screen terms)	Trip	MIL Lighting up	Reference page
CONSULT-II GST				
P1144	HO2S1 (B1)	2	×	EC-1593
P1146	HO2S2 (B1)	2	×	EC-1600
P1147	HO2S2 (B1)	2	×	EC-1611
P1148	CLOSED LOOP-B1	1	×	EC-1622
P1163	HO2S1 (B2)	2	×	EC-1586
P1164	HO2S1 (B2)	2	×	EC-1593
P1166	HO2S2 (B2)	2	×	EC-1600
P1167	HO2S2 (B2)	2	×	EC-1611
P1168	CLOSED LOOP-B2	1	×	EC-1622
P1217	ENG OVER TEMP	1	×	EC-1624
P1336	CKP SENSOR (COG)	2	×	EC-1628
P1442	EVAP SMALL LEAK	2	×	EC-1633
P1444	PURG VOLUME CONT/V	2	×	EC-1635
P1446	VENT CONTROL VALVE	2	×	EC-1644
P1448	VENT CONTROL VALVE	2	×	EC-1650
P1456	EVAP VERY SML LEAK	2	×	EC-1658
P1464	FUEL LEVL SEN/CIRC	2	×	EC-1668
P1490	VC/V BYPASS/V	2	×	EC-1671
P1491	VC CUT/V BYPASS/V	2	×	EC-1677
P1605	A/T DIAG COMM LINE	2	×	EC-1689
P1705*5	TP SEN/CIRC A/T	2	×	AT-171
P1706	P-N POS SW/CIRCUIT	2	×	EC-1694
P1760	O/R CLTCH SOL/CIRC	2	×	AT-178

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by SAE J2012.

*3: When the fail-safe operation occurs, the MIL illuminates.

*4: This DTC is displayed with CONSULT-II only.

*5: The MIL illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

NOTE:

Regarding WD22 models, "B1" indicates bank 1, "B2" indicates bank 2.

A
EC
C
D
E
F
G
H
I
J
K
L
M

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

UBS0088H

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

The vehicle may be equipped with a passenger air bag deactivation switch. Because no rear seat exists where a rear-facing child restraint can be placed, the switch is designed to turn off the passenger air bag so that a rear-facing child restraint can be used in the front passenger seat. The switch is located in the center of the instrument panel, near the ashtray. When the switch is turned to the ON position, the passenger air bag is enabled and could inflate for certain types of collision. When the switch is turned to the OFF position, the passenger air bag is disabled and will not inflate. A passenger air bag OFF indicator on the instrument panel lights up when the passenger air bag is switched OFF. The driver air bag always remains enabled and is not affected by the passenger air bag deactivation switch.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.
- The vehicle may be equipped with a passenger air bag deactivation switch which can be operated by the customer. When the passenger air bag is switched OFF, the passenger air bag is disabled and will not inflate. When the passenger air bag is switched ON, the passenger air bag is enabled and could inflate for certain types of collision. After SRS maintenance or repair, make sure the passenger air bag deactivation switch is in the same position (ON or OFF) as when the vehicle arrived for service.

On Board Diagnostic (OBD) System of Engine and A/T

UBS0088I

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-4, "HARNES CONNECTOR"](#).
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM and TCM (Transmission control module) before returning the vehicle to the customer.

Precautions


A
EC
C
D
E
F
G
H
I
J
K
L
M

ECM

- Do not disassemble ECM.
- Do not turn on board diagnostic test mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value.
The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

WIRELESS EQUIPMENT

- When installing CB ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
- 1) Keep the antenna as far away as possible from the electronic control units
 - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls.
Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.



BATTERY

Always use a 12 volt battery as power source.
Do not attempt to disconnect battery cables while engine is running.

BEFORE STARTING

Do not depress accelerator pedal when starting.
Immediately after starting, do not rev up engine unnecessarily.
Do not rev up engine just prior to shutdown.

ECM PARTS HANDLING

- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor or crankshaft position sensor (OBD).



FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque. (Refer to MA section.)


ECM HARNESS HANDLING

- Securely connect ECM harness connectors.
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (3.9 in.) away from adjacent harnesses to prevent an ECM system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.


PRECAUTIONS

[VG33ER]

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- Before removing parts, turn ignition switch OFF and then disconnect battery ground cable.




- Do not disassemble ECM.
- If a battery terminal is disconnected, the memory will return to the ECM value. The ECM will not start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a malfunction. Do not replace parts because of a slight variation.




- When connecting ECM harness connector, tighten securing bolt until the gap between orange indicators disappears.



: 3 - 5 N·m (0.3 - 0.5 kg-m, 26 - 43 in-lb)





- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Securely connect ECM harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep engine control system harness at least 10 cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep engine control system parts and harness dry.




PRECAUTIONS

[VG33ER]

- Before replacing ECM, perform “ECM Terminals and Reference Value” inspection and make sure ECM functions properly. Refer to [EC-1258, "ECM Terminals and Reference Value"](#) .
- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Even a slight leak in the air intake system can cause serious incidents.
- Do not shock or jar the camshaft position sensor, crankshaft position sensor (OBD).
- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure” or “Overall Function Check”.
The DTC should not be displayed in the “DTC Confirmation Procedure” if the repair is completed. The “Overall Function Check” should be a good result if the repair is completed.



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.




A
EC
C
D
E
F
G
H
I
J
K
L
M

PRECAUTIONS

[VG33ER]

- Regarding model WD22, “B1” indicates the bank 1, “B2” indicates the bank 2 as shown in the figure.



Wiring Diagrams and Trouble Diagnosis

UBS0088K

When you read Wiring diagrams, refer to the following:

- [GI-13, "How to Read Wiring Diagrams"](#)
- [PG-8, "POWER SUPPLY ROUTING"](#)

When you perform trouble diagnosis, refer to the following:

- [GI-9, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)

PREPARATION

[VG33ER]





PF0:00002

UBS0088L

PREPARATION



Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
Hose clipper  <p>Approx. 20 mm (0.79 in)</p>	Clamping the EVAP purge hose between the fuel tank and EVAP canister applied to DTC P1442 [EVAP control system (small leak-positive pressure)]
Heated oxygen sensor wrench  <p>NT379</p>	Loosening or tightening heated oxygen sensor 1 with 22 mm (0.87 in) hexagon nut
KV10114400 (J-38365) Heated oxygen sensor wrench  <p>NT636</p>	Loosening or tightening heated oxygen sensor 2 a: 22 mm (0.87 in)
(J-45178) TPS test connector  <p>EC120A</p>	Used to test the throttle position sensor





Commercial Service Tools

UBS0088M

Tool name (Kent-Moore No.)	Description
Leak detector i.e.: (J41416)  <p>NT703</p>	Locating the EVAP leak
EVAP service port adapter i.e.: (J41413-OB0)  <p>NT704</p>	Applying positive pressure through EVAP service port

PREPARATION

[VG33ER]

Tool name (Kent-Moore No.)	Description
<p>Fuel filler cap adapter</p>  <p style="text-align: right;">NT653</p>	<p>Checking fuel tank vacuum relief valve opening pressure</p>
<p>Socket wrench</p>  <p style="text-align: right;">NT705</p>	<p>Removing and installing engine coolant temperature sensor</p>
<p>Oxygen sensor thread cleaner i.e.:(J-43897-18) (J-43897-12)</p>  <p style="text-align: right;">AEM488</p>	<p>Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown in "Commercial Service Tools". a: J-43897-18 (18 mm diameter with pitch 1.5 mm) for Zirconia Oxygen Sensor b: J-43897-12 (12 mm diameter with pitch 1.25 mm) for Titania Oxygen Sensor</p>
<p>Anti-seize lubricant i.e.:(Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907)</p>  <p style="text-align: right;">AEM489</p>	<p>Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.</p>

ENGINE CONTROL SYSTEM

System Diagram

PF2:23710

UBS0088N

A

EC

C

D

F

T

G

H


I

J

K

L

M




⇨ : Intake air flow
 ⇩ : Exhaust air flow

SEC667C

Vacuum Hose Drawing

UBS00880



NOTE:
Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.

PBIB1342E

System Chart

Input (Sensor)	ECM Function	Output (Actuator)	
<ul style="list-style-type: none"> ● Camshaft position sensor ● Mass air flow sensor ● Engine coolant temperature sensor ● Heated oxygen sensor 1 ● Ignition switch ● Throttle position sensor ● Closed throttle position switch *4 ● Park/neutral position (PNP) switch ● Air conditioner switch ● Knock sensor ● Intake air temperature sensor ● EVAP control system pressure sensor *1 ● Battery voltage ● Power steering oil pressure switch ● Vehicle speed sensor ● Fuel tank temperature sensor *1 ● Crankshaft position sensor (OBD) *1 ● Heated oxygen sensor 2 *3 ● TCM (Transmission control module) *2 ● Ambient air temperature switch 	Fuel injection & mixture ratio control	Injectors	
	Distributor ignition system	Power transistor	
	Idle air control system	IACV-AAC valve and IACV-FICD solenoid valve	
	Fuel pump control	Fuel pump relay	
	On board diagnostic system	MIL (On the instrument panel)	
	Supercharged air control	SCB valve control solenoid valve	
	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater	
	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater	
	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve	
	Air conditioning cut control	Air conditioner relay	
		ON BOARD DIAGNOSIS for EVAP system	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● Vacuum cut valve bypass valve

*1: These sensors are not used to control the engine system. They are used only for the on board diagnosis.

*2: The DTC related to A/T will be sent to ECM.

*3: This sensor is not used to control the engine system under normal conditions.

*4: This switch will operate in place of the throttle position sensor to control EVAP parts if the sensor malfunctions.

Multiport Fuel Injection (MFI) System INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed and piston position	Fuel injection & mixture ratio control	Injectors
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Heated oxygen sensor 1	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position Throttle valve idle position		
Park/neutral position (PNP) switch	Gear position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Air conditioner switch	Air conditioner operation		
Knock sensor	Engine knocking condition		
Battery	Battery voltage		
Power steering oil pressure switch	Power steering operation		
Heated oxygen sensor 2*	Density of oxygen in exhaust gas		

* Under normal conditions, this sensor is not for engine control operation.

SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined

by input signals (for engine speed and intake air) from both the camshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.


<Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from “N” to “D”
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (manifold) can then better reduce CO, HC and NOx emissions. This system uses a heated oxygen sensor 1 in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about the heated oxygen sensor 1, refer to [EC-1363](#). This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of the heated oxygen sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from the heated oxygen sensor 2.

Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of heated oxygen sensor 1 or its circuit
- Insufficient activation of heated oxygen sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the heated oxygen sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot wire) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.


Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the heated oxygen sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

FUEL INJECTION TIMING



Two types of systems are used.

Sequential Multiport Fuel Injection System

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous Multiport Fuel Injection System

Fuel is injected simultaneously into all six cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The six injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

Distributor Ignition (DI) System

UBS0088R

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed and piston position	Ignition timing control	Power transistor
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position Throttle valve idle position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Knock sensor	Engine knocking		
Park/neutral position (PNP) switch	Gear position		
Battery	Battery voltage		


SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown. The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

e.g., N: 1,800 rpm, Tp: 1.50 msec
A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration



The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

Air Conditioner Cut Control INPUT/OUTPUT SIGNAL CHART

UBS0088S

Sensor	Input Signal to ECM	ECM function	Actuator
Air conditioner switch	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
Throttle position sensor	Throttle valve opening angle		
Camshaft position sensor	Engine speed		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Vehicle speed sensor	Vehicle speed		
Power steering oil pressure switch	Power steering operation		

SYSTEM DESCRIPTION

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned OFF.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.

Fuel Cut Control (at No Load and High Engine Load) INPUT/OUTPUT SIGNAL CHART

UBS0088T

Sensor	Input Signal to ECM	ECM function	Actuator
Vehicle speed sensor	Vehicle speed	Fuel cut control	Injectors
Park/neutral position (PNP) switch	Neutral position		
Throttle position sensor	Throttle position		
Engine coolant temperature sensor	Engine coolant temperature		
Camshaft position sensor	Engine speed		

SYSTEM DESCRIPTION

If the engine speed is above 2,500 rpm with no load (for example, in neutral and engine speed over 2,500 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 2,000 rpm, then fuel cut is cancelled.

NOTE:

This function is different from deceleration control listed under [EC-1191, "Multiport Fuel Injection \(MFI\) System"](#).


A
EC
C
D
E
F
G
H
I
J
K
L
M

BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment PREPARATION

1. Make sure that the following parts are in good order.
 - Battery
 - Ignition system
 - Engine oil and coolant levels
 - Fuses
 - ECM harness connector
 - Vacuum hoses
 - Air intake system
(Oil filler cap, oil level gauge, etc.)
 - Fuel pressure
 - Engine compression
 - Throttle valve
 - Evaporative emission system
2. On air conditioner equipped models, checks should be carried out while the air conditioner is OFF.
3. On automatic transmission equipped models, when checking idle rpm, ignition timing and mixture ratio, checks should be carried out while shift lever is in "N" position.
4. When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
5. Turn off headlamps, heater blower, rear defogger.
6. Keep front wheels pointed straight ahead.
7. Make the check after the cooling fan has stopped.

OVERALL INSPECTION SEQUENCE



SEF554YA

NOTE:



If a vehicle contains a part which is operating outside of design specifications with no MIL illumination, the part shall not be replaced prior to emission testing unless it is determined that the part has been tampered with or abused in such a way that the diagnostic system cannot reasonably be expected to detect the resulting malfunction.

A
EC
C
D
E
F
G
H
I
J
K
L
M

INSPECTION PROCEDURE

1. INSPECTION START


1. Check service records for any recent repairs that may indicate a related malfunction, or a current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Wiring harness for improper connections, pinches and cut
 - Vacuum hoses for splits, kinks and improper connections
 - Hoses and ducts for leaks
 - Air cleaner clogging
 - Gasket
3. Confirm that electrical or mechanical loads are not applied.
 - Headlamp switch is OFF.
 - Air conditioner switch is OFF.
 - Rear window defogger switch is OFF.
 - Steering wheel is in the straight-ahead position, etc.
4. Visually check the following:
 - Air cleaner clogging
 - Hoses and ducts for leaks
 - Electrical connectors
 - Gasket
 - Throttle valve and throttle position sensor operation
5. Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge. Ensure engine stays below 1,000 rpm.



6. Open engine hood and run engine at about 2,000 rpm for about 2 minutes under no-load.
7. Make sure that no DTC is displayed with CONSULT-II or GST.


OK or NG

- OK >> GO TO 2.
 NG >> 1. Repair or replace components as necessary.
 2. GO TO 2.




2. CHECK IGNITION TIMING

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.



3. Turn off engine and disconnect throttle position sensor harness connector.
4. Start and rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run at idle speed.




5. Check ignition timing with a timing light.

M/T : $10^{\circ} \pm 2^{\circ}$ BTDC
A/T : $10^{\circ} \pm 2^{\circ}$ BTDC (in "P" or "N" position)

OK or NG


- OK >> GO TO 4.
 NG >> GO TO 3.



3. ADJUST IGNITION TIMING

1. Adjust ignition timing by turning distributor after loosening securing bolts.
2. Turn off engine and connect throttle position sensor harness connector to throttle position sensor.

>> GO TO 2.



4. CHECK BASE IDLE SPEED

With CONSULT-II


1. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T : 700±50 rpm
A/T : 700±50 rpm (in "P" or "N" position)

Without CONSULT-II

1. Check idle speed.

M/T : 700±50 rpm
A/T : 700±50 rpm (in "P" or "N" position)



OK or NG


- OK >> GO TO 6.
 NG >> GO TO 5.

5. ADJUST BASE IDLE SPEED

1. Rev engine (2,000 to 3,000 rpm) 2 or 3 times under no-load then run engine at idle speed.
2. Adjust idle speed by turning idle speed adjusting screw.

M/T : 700±50 rpm
A/T : 700±50 rpm (in "P" or "N" position)

>> GO TO 6.



6. CHECK TARGET IDLE SPEED

With CONSULT-II

1. Turn off engine and connect throttle position sensor harness connector.
2. Start and rev engine (2,000 to 3,000 rpm) 2 or 3 times under no-load then run at idle speed.
3. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T : 750±50 rpm
A/T : 750±50 rpm (in "P" or "N" position)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

Without CONSULT-II

1. Turn off engine and connect throttle position sensor harness connector.
2. Start and rev engine (2,000 to 3,000 rpm) 2 or 3 times under no-load then run at idle speed.
3. Check idle speed.

M/T : 750±50 rpm
A/T : 750±50 rpm (in "P" or "N" position)

OK or NG

- OK (With CONSULT-II)>>GO TO 8.
 OK (Without CONSULT-II)>>GO TO 9.
 NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

1. Check IACV-AAC valve and replace if necessary. Refer to [EC-1564](#) .
2. Check IACV-AAC valve harness and repair if necessary. Refer to [EC-1564](#) .
3. Check ECM function by substituting another known-good ECM. (ECM may be the cause of an incident, but this is rarely the case.)

- With CONSULT-II>>GO TO 8.
 Without CONSULT-II>>GO TO 9.

8. CHECK HEATED OXYGEN SENSOR 1 (BANK 2) SIGNAL

With CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. See "HO2S1 MNTR (B2)" in "DATA MONITOR" mode.
1 time: RICH → LEAN → RICH
2 times: RICH → LEAN → RICH → LEAN → RICH
3. Running engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	RICH

PBIB0120E

OK or NG

- OK >> GO TO 12.
 NG (Monitor does not fluctuate.)>>GO TO 17.
 NG (Monitor fluctuates less than 5 times.)>>GO TO 10.

9. CHECK HEATED OXYGEN SENSOR 1 (BANK 2) SIGNAL

⊗ Without CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Set voltmeter probe between ECM terminal 62 and ground.
3. Make sure that the voltage fluctuates between 0 - 0.3V and 0.6 - 1.0V more than 5 times during 10 seconds at 2,000 rpm.
1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG

- OK >> GO TO 12.
 NG (Voltage does not fluctuate.)>>GO TO 17.
 NG (Voltage fluctuates less than 5 times.)>>GO TO 10.

10. CHECK HEATED OXYGEN SENSOR 1 (BANK 2) SIGNAL

⊕ With CONSULT-II

1. Stop engine.
2. Replace heated oxygen sensor 1(bank 2).
3. Start engine and warm it up to normal operating temperature.
4. Run engine at approx. 2,000 rpm for approx. 2 minutes under no-load.
5. See "HO2S1 MNTR (B2)" in "DATA MONITOR" mode.
6. Running engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.
1 time: RICH → LEAN → RICH
2 times: RICH → LEAN → RICH → LEAN → RICH

⊗ Without CONSULT-II

1. Stop engine.
2. Replace heated oxygen sensor 1 (bank 2).
3. Start engine and warm it up to normal operating temperature.
4. Run engine at approx. 2,000 rpm for approx. 2 minutes under no-load.
5. Set voltmeter probe between ECM terminal 62 and ground.
6. Make sure that the voltage fluctuates between 0 - 0.3V and 0.6 - 1.0V more than 5 times during 10 seconds at 2,000 rpm.
1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG

- OK (With CONSULT-II)>>GO TO 12.
 OK (Without CONSULT-II)>>GO TO 13.
 NG >> GO TO 11.

11. DETECT MALFUNCTIONING PART

Check the following.

1. Check fuel pressure regulator. Refer to [EC-1209](#) .
2. Check mass air flow sensor and its circuit. Refer to [EC-1317](#) .
3. Check injector and its circuit. Refer to [EC-1707](#) .
Clean or replace if necessary.
4. Check engine coolant temperature sensor and its circuit. Refer to [EC-1335](#) .
5. Check ECM function by substituting another known-good ECM.
(ECM may be the cause of an incident, but this is rarely the case.)

>> GO TO 2.

12. CHECK HEATED OXYGEN SENSOR 1 (BANK 1) SIGNAL

With CONSULT-II

1. See "HO2S1 (B1)" in "DATA MONITOR" mode.
1 time: RICH → LEAN → RICH
2 times: RICH → LEAN → RICH → LEAN → RICH
2. Maintaining engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	RICH

PBIB0120E

OK or NG

- OK >> **INSPECTION END.**
- NG (Monitor does not fluctuate.)>>GO TO 16.
- NG (Monitor fluctuates less than 5 times.)>>GO TO 14.

13. CHECK HEATED OXYGEN SENSOR 1 (BANK 1) SIGNAL

Without CONSULT-II

1. Set voltmeter probe between ECM terminal 63 and ground.
2. Make sure that the voltage fluctuates between 0 - 0.3V and 0.6 - 1.0V more than 5 times during 10 seconds at 2,000 rpm.
1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG

- OK >> **INSPECTION END.**
- NG (Voltage does not fluctuate.)>>GO TO 16.
- NG (Voltage fluctuates less than 5 times.)>>GO TO 14.

14. CHECK HEATED OXYGEN SENSOR 1 (BANK 1) SIGNAL

With CONSULT-II

1. Stop engine.
2. Replace heated oxygen sensor 1 (bank 1).
3. Start engine and warm it up to normal operating temperature.
4. Run engine at approx. 2,000 rpm for approx. 2 minutes under no-load.
5. See "HO2S1 MNTR (B1)" in "DATA MONITOR" mode.
6. Maintaining engine at 2,000 rpm under no-load (engine is warmed up to normal operating temperature.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.
1 time: RICH → LEAN → RICH
2 times: RICH → LEAN → RICH → LEAN → RICH

Without CONSULT-II

1. Stop engine.
2. Replace heated oxygen sensor 1 (bank 1).
3. Start engine and warm it up to normal operating temperature.
4. Run engine at approx. 2,000 rpm for approx. 2 minutes under no-load.
5. Set voltmeter probe between ECM terminal 63 and ground.
6. Make sure that the voltage fluctuates between 0 - 0.3V and 0.6 - 1.0V more than 5 times during 10 seconds at 2,000 rpm.
1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 15.

15. DETECT MALFUNCTIONING PART

Check the following.

1. Check fuel pressure regulator. Refer to [EC-1209](#) .
2. Check mass air flow sensor and its circuit. Refer to [EC-1317](#) .
3. Check injector and its circuit. Refer to [EC-1707](#) .
Clean or replace if necessary.
4. Check engine coolant temperature sensor and its circuit. Refer to [EC-1335](#) .
5. Check ECM function by substituting another known-good ECM.
(ECM may be the cause of an incident, but this is rarely the case.)

>> GO TO 2.

16. CHECK HEATED OXYGEN SENSOR 1 (BANK 1) HARNESS

1. Turn off engine and disconnect battery ground cable.
2. Disconnect ECM harness connector.
3. Disconnect heated oxygen sensor 1 (bank 1) harness connector.
4. Check harness continuity between ECM terminal 50 and heated oxygen sensor 1 (bank 1) harness connector.

Continuity should exist.

OK or NG

- OK >> 1. Connect ECM harness connector.
2. GO TO 18.
- NG >> 1. Repair or replace harness.
2. GO TO 8 (With CONSULT-II).
GO TO 9 (Without CONSULT-II).

17. CHECK HEATED OXYGEN SENSOR 1 (BANK 2) HARNESS

1. Turn off engine and disconnect battery ground cable.
2. Disconnect ECM harness connector.
3. Disconnect heated oxygen sensor 1 (bank 2) harness connector.
4. Check harness continuity between ECM terminal 51 and heated oxygen sensor 1 (bank 2) harness connector.

Continuity should exist.

OK or NG

- OK >> 1. Connect ECM harness connector.
2. GO TO 18.
- NG >> 1. Repair or replace harness.
2. GO TO 8 (With CONSULT-II).
GO TO 9 (Without CONSULT-II).

18. PREPARATION FOR "CO" % CHECK

 **With CONSULT-II**

1. Select "ENG COOLANT TEMP" in "ACTIVE TEST" mode.
2. Set "ENG COOLANT TEMP" to 5°C (41°F) by touching "DWN" and "Qd".

 **Without CONSULT-II**


1. Disconnect engine coolant temperature sensor harness connector.

ACTIVE TEST	
ENG COOLANT TEMP	XXX °C
MONITOR	
ENG SPEED	XXX rpm
INJ PULSE-B1	XXX msec
IGN TIMING	XXX BTDC

SEF172Y


2. Connect a resistor (4.4 kΩ) between terminals of engine coolant temperature sensor harness connector.

>> GO TO 19.



19. CHECK "CO" %

1. Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge.




2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.
3. Check "CO" %.

Idle CO : 1.5 - 9.5%

 **Without CONSULT-II**

After checking CO%,

- Disconnect the resistor from terminals of engine coolant temperature sensor.
- Connect engine coolant temperature sensor harness connector to engine coolant temperature sensor.



OK or NG

- OK >> GO TO 10.
 NG >> GO TO 20.

20. DETECT MALFUNCTIONING PART

Check the following.

1. Connect heated oxygen sensor 1 harness connectors to heated oxygen sensors 1.
2. Check fuel pressure regulator. Refer to [EC-1209](#) .
3. Check mass air flow sensor and its circuit. Refer to [EC-1317](#) .
4. Check injector and its circuit. Refer to [EC-1707](#) .
Clean or replace if necessary.
5. Check engine coolant temperature sensor and its circuit. Refer to [EC-1335](#) .
6. Check ECM function by substituting another known-good ECM.
(ECM may be the cause of an incident, but this is rarely the case.)


>> GO TO 2.

**Fast Idle Cam (FIC) Inspection and Adjustment
OPERATION PROCEDURE**


UBS0088W

With CONSULT-II

1. Turn ignition switch ON.
2. See "COOLANT TEMP/S" in "DATA MONITOR" mode with CONSULT-II.



3. When engine coolant temperature is 20 to 30°C (68 to 86°F), make sure that the center of mark **A** is aligned with mark **B** as shown in the figure.



- If NG, adjust by turning adjusting screw.

Lock nut


: 0.98 - 1.96 N·m (10 - 20 kg-cm, 8.7 - 17.4 in-lb)

4. Start engine and warm it up.

BASIC SERVICE PROCEDURE


[VG33ER]

- When engine coolant temperature is 75 to 85°C (167 to 185°F), check the following.
 - The center of mark **A** is aligned with mark **C**.
 - The cam follower lever's roller is not touching the fast idle cam.
- If NG, replace thermo-element and perform the above inspection and adjustment again.



With GST


- Turn ignition switch ON.
- Check voltage between ECM terminal 59 (Engine coolant temperature sensor signal) and ground.




- When the voltage is between 3.12 to 3.52V, make sure that the center of mark **A** is aligned with mark **B** as shown in the figure.
- If NG, adjust by turning adjusting screw.

Lock nut

 : 0.98 - 1.96 N·m (10 - 20 kg-cm, 8.7 - 17.4 in-lb)



- Start engine and warm it up.
- When the voltage is between 1.10 to 1.36V, check the following.
 - The center of mark **A** is aligned with mark **C**.
 - The cam follower lever's roller is not touching the fast idle cam.
- If NG, replace thermo-element and perform the above inspection and adjustment again.



Fuel Pressure Check FUEL PRESSURE RELEASE

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.


With CONSULT-II

- Turn ignition switch ON.

BASIC SERVICE PROCEDURE


[VG33ER]

2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch OFF.



With CONSULT-II

1. Remove fuel pump fuse located in fuse box.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF.
5. Reinstall fuel pump fuse after servicing fuel system.



FUEL PRESSURE CHECK

- When reconnecting fuel line, always use new clamps.
 - Make sure that clamp screw does not contact adjacent pats.
 - Use a torque driver to tighten clamps.
 - Use Pressure Gauge to check fuel pressure.
 - Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
1. Release fuel pressure to zero.
 2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
 3. Install pressure gauge between fuel filter and fuel tube.
 4. Start engine and check for fuel leakage.
 5. Read the indication of fuel pressure gauge.


At idling

:With vacuum hose connected

Approximately 235 kPa
(2.4 kg/cm² , 34 psi)

With vacuum hose disconnected


Approximately 294 kPa
(3.0 kg/cm² , 43 psi)



If results are unsatisfactory, perform Fuel Pressure Regulator Check.


Fuel Pressure Regulator Check

1. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
2. Plug intake manifold with a blind cap.
3. Connect variable vacuum source to fuel pressure regulator.



4. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.



A
EC
C
D
E
F
G
H
I
J
K
L
M

ON BOARD DIAGNOSTIC (OBD) SYSTEM

PFP:00028

Introduction

UBS0088Z

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Emission-related diagnostic information	SAE Mode
Diagnostic Trouble Code (DTC)	Mode 3 of SAE J1979
Freeze Frame data	Mode 2 of SAE J1979
System Readiness Test (SRT) code	Mode 1 of SAE J1979
1st Trip Diagnostic Trouble Code (1st Trip DTC)	Mode 7 of SAE J1979
1st Trip Freeze Frame data	
Test values and Test limits	Mode 6 of SAE J1979
Calibration ID	Mode 9 of SAE J1979

The above information can be checked using procedures listed in the table below.

X: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data	SRT code	Test value
CONSULT-II	×	×	×	×	×	—
GST	×	×*1	×	—	×	×

*1: 1st trip DTCs for self-diagnoses concerning SRT items cannot be shown on the GST display.

The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to [EC-1237](#), "Fail-safe Chart" .)

Two Trip Detection Logic

UBS00890

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MIL will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MIL lights up. The MIL lights up at the same time when the DTC is stored. <2nd trip> The "trip" in the "Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MIL, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

X: Applicable —: Not applicable

Items	MIL				DTC		1st trip DTC	
	1st trip		2nd trip		1st trip displaying	2nd trip displaying	1st trip displaying	2nd trip displaying
	Blinking	Lighting up	Blinking	Lighting up				
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	×	—	—	—	—	—	×	—
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	—	—	×	—	—	×	—	—
One trip detection diagnosis (refer to EC-1176)	—	×	—	—	×	—	—	—
Except above	—	—	—	×	—	×	×	—

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33ER]

UBS00891

Emission-related Diagnostic Information EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

x: Applicable —: Not applicable

Items (CONSULT-II screen terms)	DTC*1*2	SRT code	Test value/ Test limit (GST only)	1st trip DTC*1	Reference page
	CONSULT-II GST				
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	—	—	—	—
HO2S1 HTR (B1)	P0031	x	x	x*5	EC-1294
HO2S1 HTR (B1)	P0032	x	x	x*5	EC-1294
SCB/V CONT SOL/V	P0034	—	—	x	EC-1302
HO2S2 HTR (B1)	P0037	x	x	x*5	EC-1308
HO2S2 HTR (B1)	P0038	x	x	x*5	EC-1308
HO2S1 HTR (B2)	P0051	x	x	x*5	EC-1294
HO2S1 HTR (B2)	P0052	x	x	x*5	EC-1294
HO2S2 HTR (B2)	P0057	x	x	x*5	EC-1308
HO2S2 HTR (B2)	P0058	x	x	x*5	EC-1308
MAF SEN/CIRCUIT	P0101	—	—	x	EC-1317
MAF SEN/CIRCUIT	P0102*3	—	—	—	EC-1324
MAF SEN/CIRCUIT	P0103*3	—	—	—	EC-1324
IAT SEN/CIRCUIT	P0112	—	—	—	EC-1330
IAT SEN/CIRCUIT	P0113	—	—	—	EC-1330
ECT SEN/CIRCUIT	P0117*3	—	—	—	EC-1335
ECT SEN/CIRCUIT	P0118*3	—	—	—	EC-1335
TP SEN/CIRCUIT	P0121	—	—	x	EC-1340
TP SEN/CIRCUIT	P0122*3	—	—	—	EC-1349
TP SEN/CIRCUIT	P0123*3	—	—	—	EC-1349
ECT SENSOR	P0125	—	—	x	EC-1356
IAT SENSOR	P0127	—	—	x	EC-1359
THERMSTAT FNCTN	P0128	—	—	x	EC-1361
HO2S1 (B1)	P0132	x	x	x*5	EC-1363
HO2S1 (B1)	P0133	x	x	x*5	EC-1372
HO2S1 (B1)	P0134	x	x	x*5	EC-1385
HO2S2 (B1)	P0138	x	x	x*5	EC-1396
HO2S2 (B1)	P0139	x	x	x*5	EC-1405
HO2S1 (B2)	P0152	x	x	x*5	EC-1363
HO2S1 (B2)	P0153	x	x	x*5	EC-1372
HO2S1 (B2)	P0154	x	x	x*5	EC-1385
HO2S2 (B2)	P0158	x	x	x*5	EC-1396
HO2S2 (B2)	P0159	x	x	x*5	EC-1405
FUEL SYS-LEAN-B1	P0171	—	—	x	EC-1415
FUEL SYS-RICH-B1	P0172	—	—	x	EC-1423
FUEL SYS-LEAN-B2	P0174	—	—	x	EC-1415
FUEL SYS-RICH-B2	P0175	—	—	x	EC-1423
FTT SENSOR	P0181	—	—	x	EC-1431
FTT SEN/CIRCUIT	P0182	—	—	x	EC-1436

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33ER]

Items (CONSULT-II screen terms)	DTC*1*2	SRT code	Test value/ Test limit (GST only)	1st trip DTC*1	Reference page
	CONSULT-II GST				
FTT SEN/CIRCUIT	P0183	—	—	×	EC-1436
ENG OVER TEMP	P0217	—	—	×	EC-1440
SC FUNCTION	P0299	—	—	×	EC-1445
MULTI CYL MISFIRE	P0300	—	—	×	EC-1448
CYL1 MISFIRE	P0301	—	—	×	EC-1448
CYL2 MISFIRE	P0302	—	—	×	EC-1448
CYL3 MISFIRE	P0303	—	—	×	EC-1448
CYL4 MISFIRE	P0304	—	—	×	EC-1448
CYL5 MISFIRE	P0305	—	—	×	EC-1448
CYL6 MISFIRE	P0306	—	—	×	EC-1448
KNOCK SEN/CIRC-B1	P0327	—	—	—	EC-1457
KNOCK SEN/CIRC-B1	P0328	—	—	—	EC-1457
CKP SEN/CIRCUIT	P0335	—	—	×	EC-1461
CMP SEN/CIRCUIT	P0340	—	—	×	EC-1467
TW CATALYST SYS-B1	P0420	×	×	×*5	EC-1474
TW CATALYST SYS-B2	P0430	×	×	×*5	EC-1474
EVAP PURG FLOW/MON	P0441	×	×	×*5	EC-1480
EVAP SMALL LEAK	P0442	×	×	×*5	EC-1488
PURG VOLUME CONT/V	P0444	—	—	×	EC-1500
PURG VOLUME CONT/V	P0445	—	—	×	EC-1500
VENT CONTROL VALVE	P0447	—	—	×	EC-1507
EVAP SYS PRES SEN	P0452	—	—	×	EC-1513
EVAP SYS PRES SEN	P0453	—	—	×	EC-1519
EVAP GROSS LEAK	P0455	×	×	×*5	EC-1528
EVAP VERY SML LEAK	P0456	×*4	×	×*5	EC-1538
FUEL LEV SEN SLOSH	P0460	—	—	×	EC-1549
FUEL LEVEL SENSOR	P0461	—	—	×	EC-1553
FUEL LEVL SEN/CIRC	P0462	—	—	×	EC-1555
FUEL LEVL SEN/CIRC	P0463	—	—	×	EC-1555
VEH SPEED SEN/CIRC	P0500*5	—	—	×	EC-1559
ISC SYSTEM/CIRC	P0505	—	—	×	EC-1564
CLOSED TP SW/CIRC	P0510	—	—	×	EC-1571
A/T COMM LINE	P0600*4	—	—	—	EC-1578
ECM	P0605	—	—	×	EC-1584
PNP SW/CIRC	P0705	—	—	×	AT-99
ATF TEMP SEN/CIRC	P0710	—	—	×	AT-105
VEH SPD SEN/CIR AT	P0720	—	—	×	AT-110
ENGINE SPEED SIG	P0725	—	—	×	AT-115
A/T 1ST GR FNCTN	P0731	—	—	×	AT-119
A/T 2ND GR FNCTN	P0732	—	—	×	AT-125
A/T 3RD GR FNCTN	P0733	—	—	×	AT-131
A/T 4TH GR FNCTN	P0734	—	—	×	AT-137
TCC SOLENOID/CIRC	P0740	—	—	×	AT-144

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33ER]

Items (CONSULT-II screen terms)	DTC*1*2	SRT code	Test value/ Test limit (GST only)	1st trip DTC*1	Reference page
	CONSULT-II GST				
A/T TCC S/V FNCTN	P0744	—	—	×	AT-149
L/PRESS SOL/CIRC	P0745	—	—	×	AT-156
SFT SOL A/CIRC	P0750*3	—	—	×	AT-161
SFT SOL B/CIRC	P0755*3	—	—	×	AT-166
HO2S1 (B1)	P1143	×	×	×*5	EC-1586
HO2S1 (B1)	P1144	×	×	×*5	EC-1593
HO2S2 (B1)	P1146	×	×	×*5	EC-1600
HO2S2 (B1)	P1147	×	×	×*5	EC-1611
CLOSED LOOP-B1	P1148	—	—	—	EC-1622
HO2S1 (B2)	P1163	×	×	×*5	EC-1586
HO2S1 (B2)	P1164	×	×	×*5	EC-1593
HO2S2 (B2)	P1166	×	×	×*5	EC-1600
HO2S2 (B2)	P1167	×	×	×*5	EC-1611
CLOSED LOOP-B2	P1168	—	—	—	EC-1622
ENG OVER TEMP	P1217	—	—	×	EC-1624
CKP SENSOR (COG)	P1336	—	—	×	EC-1628
EVAP SMALL LEAK	P1442	×	×	×*5	EC-1633
PURG VOLUME CONT/V	P1444	—	—	×	EC-1635
VENT CONTROL VALVE	P1446	—	—	×	EC-1644
VENT CONTROL VALVE	P1448	—	—	×	EC-1650
EVAP VERY SML LEAK	P1456	×*4	×	×*5	EC-1658
FUEL LEVEL SEN/CIRC	P1464	—	—	×	EC-1668
VC/V BYPASS/V	P1490	—	—	×	EC-1671
VC CUT/V BYPASS/V	P1491	—	—	×	EC-1677
A/T DIAG COMM LINE	P1605	—	—	×	EC-1689
TP SEN/CIRC A/T	P1705*5	—	—	×	AT-171
P-N POS SW/CIRCUIT	P1706	—	—	×	EC-1694
O/R CLTCH SOL/CIRC	P1760	—	—	×	AT-178

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by SAE J2012.

*3: When the fail-safe operation occurs, the MIL illuminates.

*4: SRT code will not be set if the self-diagnostic result is NG.

*5: These are not displayed with GST.

NOTE:

Regarding D22 models, "B1" indicates bank 1, "B2" indicates bank 2.

DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MIL will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MIL during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in [EC-1223, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .

For malfunctions in which 1st trip DTCs are displayed, refer to [EC-1211, "Emission-related Diagnostic Information"](#) . These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT-II.

1st trip DTC is specified in Mode 7 of SAE J1979. 1st trip DTC detection occurs without lighting up the MIL and therefore does not warn the driver of a malfunction. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in "Work Flow" procedure Step II, refer to [EC-1232, "WORK FLOW"](#) . Then perform "DTC Confirmation Procedure" or "Overall Function Check" to try to duplicate the malfunction. If the malfunction is duplicated, the item requires repair.

How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

 **With CONSULT-II**

 **With GST**

CONSULT-II or GST (Generic Scan Tool) Examples: P0340, P0705, P0750, etc.

These DTCs are prescribed by SAE J2012.

(CONSULT-II also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, GST do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".

If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

DTC display	SELF DIAG RESULTS		1st trip DTC display	SELF DIAG RESULTS	
	DTC RESULTS			DTC RESULTS	
	CKP SEN/CIRCUIT [P0335]	0		CKP SEN/CIRCUIT [P0335]	1t

PBIB0911E

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed and absolute pressure at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For details, see [EC-1269, "Freeze Frame Data and 1st Trip Freeze Frame Data"](#) .

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33ER]

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0306 Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175
2		Except the above items (Includes A/T related items)
3	1st trip freeze frame data	

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in [EC-1223, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

SYSTEM READINESS TEST (SRT) CODE

System Readiness Test (SRT) code is specified in Mode 1 of SAE J1979.

As part of enhanced emissions test for Inspection and Maintenance (I/M), certain states require that the status of SRT be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "INCMP", use the information in this service manual to set the SRT to "CMPLT".

In most cases, the ECM will automatically complete its self-diagnosis cycle during normal usage and the SRT status will indicate "CMPLT" for each application system. Once set as "CMPLT", the SRT status remains "CMPLT" until the self-diagnosis memory is erased.

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern and the SRT will indicate "INCMP" for these items.

NOTE:

The SRT will also indicate "INCMP" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.

If, during the state emissions inspection, the SRT indicates "CMPLT" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "INCMP" for one or more of the SRT items, the vehicle is returned to the customer untested.

NOTE:

If MIL is "ON" during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "CMPLT" for all test items. Therefore, it is important to check SRT ("CMPLT") and DTC (No DTCs) before the inspection.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33ER]

SRT Item

The following table shows required self-diagnostic items to set the SRT to "CMPLT".

SRT item (CONSULT-II indication)	Performance Priority *	Required self-diagnostic items to set the SRT to "CMPLT"	Corresponding DTC No.
CATALYST	2	Three way catalyst function	P0420, P0430
EVAP SYSTEM	1	EVAP control system	P0442, P1442
	2	EVAP control system	P0456, P1456
	2	EVAP control system purge flow monitoring	P0441
HO2S	2	Heated oxygen sensor 1	P0132, P0152
		Heated oxygen sensor 1	P0133, P0153
		Heated oxygen sensor 1	P0134, P0154
		Heated oxygen sensor 1	P1143, P1163
		Heated oxygen sensor 1	P1144, P1164
		Heated oxygen sensor 2	P0138, P0158
		Heated oxygen sensor 2	P0139, P0157
		Heated oxygen sensor 2	P1146, P1166
		Heated oxygen sensor 2	P1147, P1167
HO2S HEATER	2	Heated oxygen sensor 1 heater	P0031, P0032, P0051, P0052
		Heated oxygen sensor 2 heater	P0037, P0038, P0057, P0058

*: If completion of several SRTs is required, perform driving patterns (DTC confirmation procedure) one by one based on the priority for models with CONSULT-II.

SRT Set Timing

SRT is set as "CMPLT" after self-diagnosis has been performed one or more times. Completion of SRT is done regardless of whether the result is OK or NG. The set timing is different between OK and NG results and is shown in the table below.

Self-diagnosis result		Example				
		Diagnosis	Ignition OFF – ON – OFF	Ignition OFF – ON – OFF	Ignition OFF – ON – OFF	Ignition OFF – ON – OFF
All OK	Case 1	P0400	OK (1)	– (1)	OK (2)	– (2)
		P0402	OK (1)	– (1)	– (1)	OK (2)
		P1402	OK (1)	OK (2)	– (2)	– (2)
		SRT of EGR	"CMPLT"	"CMPLT"	"CMPLT"	"CMPLT"
	Case 2	P0400	OK (1)	– (1)	– (1)	– (1)
		P0402	– (0)	– (0)	OK (1)	– (1)
		P1402	OK (1)	OK (2)	– (2)	– (2)
		SRT of EGR	"INCMP"	"INCMP"	"CMPLT"	"CMPLT"
NG exists	Case 3	P0400	OK	OK	–	–
		P0402	–	–	–	–
		P1402	NG	–	NG	NG (Consecutive NG)
		(1st trip) DTC	1st trip DTC	–	1st trip DTC	DTC (=MIL "ON")
		SRT of EGR	"INCMP"	"INCMP"	"INCMP"	"CMPLT"

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is OK.

–: Self-diagnosis is not carried out.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33ER]

When all SRT related self-diagnoses showed OK results in a same cycle (Ignition OFF – ON – OFF), the SRT will indicate “CMPLT”. → Case 1 above

When all SRT related self-diagnoses show OK results through several different cycles, the SRT will indicate “CMPLT” at the time the respective self-diagnoses have at least one OK result. → Case 2 above

If one or more SRT related self-diagnoses showed NG results in 2 consecutive cycles, the SRT will also indicate “CMPLT”. → Case 3 above

The table above shows that the minimum number of cycles for setting SRT as “INCMP” is one (1) for each self-diagnosis (Case 1 and 2) or two (2) for one self-diagnosis (Case 3). However, in preparation for the State emissions inspection, it is unnecessary of each self-diagnosis to be executed twice (Case 3) for the following reasons;

- The SRT will indicate “CMPLT” at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires “CMPLT” of the SRT only with OK self-diagnosis result.
- When, during SRT driving pattern, 1st trip DTC (NG) is detected prior to “CMPLT” of SRT, the self-diagnosis memory must be erased from ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate “INCMP”.

NOTE:

SRT can be set as “CMPLT” together with the DTC(s). Therefore, DTC check must always be carried out prior to the State emission inspection even though the SRT indicates “CMPLT”.

A

EC

C

D

E

F

G

H

I

J


K

L

M

SRT Service Procedure

If a vehicle has failed the State emissions inspection due to one or more SRT items indicating "INCMP", review the following flowchart diagnostic sequence on the next page.



SEF573XA

*1 [EC-1214](#)

*2 [EC-1219](#)

*3 [EC-1219](#)

How to Display SRT Code

WITH CONSULT-II

Selecting "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT-II.

For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT-II screen; for items whose SRT codes are not set, "INCMP" is displayed.

A sample of CONSULT-II display for SRT code is shown below.

"INCMP" means the self-diagnosis is incomplete and SRT is not set.

"CMPLT" means the self-diagnosis is complete and SRT is set.

SRT STATUS	
CATALYST	CMPLT
EVAP SYSTEM	INCMP
HO2S HTR	CMPLT
HO2S	CMPLT

SEF935Z

WITH GST

Selecting Mode 1 with GST (Generic Scan Tool)

How to Set SRT Code

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions.

With CONSULT-II

Perform corresponding DTC confirmation procedure one by one based on "Performance Priority" in the table on [EC-1216, "SRT Item"](#).

Without CONSULT-II


The most efficient driving pattern in which SRT codes can be properly set is explained on the next page. The driving pattern should be performed one or more times to set all SRT codes.

A
EC
C
D
E
F
G
H
I
J
K
L
M

Driving Pattern

Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws. Refer to next page for more information and explanation of chart.

Driving pattern



ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33ER]

- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.
Zone A refers to the range where the time required, for the diagnosis under normal conditions*, is the shortest.
Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

*: Normal conditions refer to the following:

- Sea level
- Flat road
- Ambient air temperature: 20 - 30°C (68 - 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.
Under different conditions [For example: ambient air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1:

- **The engine is started at the engine coolant temperature of -10 to 35°C (14 to 95°F) (where the voltage between the ECM terminal 59 and ground is 3.0 - 4.3V).**
- **The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminal 59 and ground is lower than 1.4V).**
- **The engine is started at the tank fuel temperature of warmer than 0°C (32°F) (where the voltage between the ECM terminal 60 and ground is less than 4.1V).**

Pattern 2:

- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

Pattern 3:

- The driving pattern outlined in *2 must be repeated at least 3 times.

Pattern 4:


- Tests are performed after the engine has been operated for at least 17 minutes.
- The accelerator pedal must be held very steady during steady-state driving.
- If the accelerator pedal is moved, the test must be conducted all over again.

*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

*2: Operate the vehicle in the following driving pattern.

1. Decelerate vehicle to 0 km/h (0 MPH) and let engine idle.
2. Repeat driving pattern shown below at least 10 times.
- **During acceleration, hold the accelerator pedal as steady as possible.**

*3: Checking the vehicle speed with CONSULT-II or GST is advised.



Suggested Transmission Gear Position for A/T Models

Set the selector lever in the "D" position with the overdrive switch turned ON.

Suggested upshift speeds for M/T models

Shown below are suggested vehicle speeds for shifting into a higher gear. These suggestions relate to fuel economy and vehicle performance. Actual upshift speeds will vary according to road conditions, the weather and individual driving habits.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33ER]

	For normal acceleration in low altitude areas [less than 1,219 m (4,000 ft)]:	For quick acceleration in low altitude areas and high altitude areas [over 1,219 m (4,000 ft)]:
Gear change	ACCEL shift point km/h (MPH)	km/h (MPH)
1st to 2nd	24 (15)	24 (15)
2nd to 3rd	40 (25)	40 (25)
3rd to 4th	64 (40)	64 (40)
4th to 5th	72 (45)	72 (45)

Suggested Maximum Speed in Each Gear

Downshift to a lower gear if the engine is not running smoothly, or if you need to accelerate.

Do not exceed the maximum suggested speed (shown below) in any gear. For level road driving, use the highest gear suggested for that speed. Always observe posted speed limits and drive according to the road conditions to ensure safe operation. Do not over-rev the engine when shifting to a lower gear as it may cause engine damage or loss of vehicle control.

Gear	km/h (MPH) 2WD (AUTO mode)
1st	50 (30)
2nd	95 (60)

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

The following is the information specified in Mode 6 of SAE J1979.

The test value is a parameter used to determine whether a system/circuit diagnostic test is “OK” or “NG” while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items (30 test items).

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

X: Applicable —: Not applicable

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
CATALYST	Three way catalyst function (Bank 1)	01H	01H	Max.	×
	Three way catalyst function (Bank 2)	03H	02H	Max.	×
EVAP SYSTEM	EVAP control system (Small leak)	05H	03H	Max.	×
	EVAP control system purge flow monitoring	06H	83H	Min.	×

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33ER]

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
HO2S	Heated oxygen sensor 1 (bank 1)	09H	04H	Max.	×
		0AH	84H	Min.	×
		0BH	04H	Max.	×
		0CH	04H	Max.	×
		0DH	04H	Max.	×
	Heated oxygen sensor 1 (bank 2)	11H	05H	Max.	×
		12H	85H	Min.	×
		13H	05H	Max.	×
		14H	05H	Max.	×
		15H	05H	Max.	×
	Heated oxygen sensor 2 (bank 1)	19H	86H	Min.	×
		1AH	86H	Min.	×
		1BH	06H	Max.	×
		1CH	06H	Max.	×
	Heated oxygen sensor 2 (bank 2)	21H	87H	Min.	×
		22H	87H	Min.	×
23H		07H	Max.	×	
24H		07H	Max.	×	
HO2S HEATER	Heated oxygen sensor 1 (bank 1)	29H	08H	Max.	×
		2AH	88H	Min.	×
	Heated oxygen sensor 1 (bank 2)	2BH	09H	Max.	×
		2CH	89H	Min.	×
	Heated oxygen sensor 2 (bank 1)	2DH	0AH	Max.	×
		2EH	8AH	Min.	×
	Heated oxygen sensor 2 (bank 2)	2FH	0BH	Max.	×
		30H	8BH	Min.	×

HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION


🔧 How to Erase DTC (With CONSULT-II)

NOTE:

If the DTC is not for A/T related items (see [EC-1176](#)), skip steps 2 through 4.

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it ON (engine stopped) again.
2. Turn CONSULT-II "ON" and touch "A/T".
3. Touch "SELF-DIAG RESULTS".
4. Touch "ERASE". [The DTC in the TCM (Transmission control module) will be erased.] Then touch "BACK" twice.
5. Touch "ENGINE".
6. Touch "SELF-DIAG RESULTS".
7. Touch "ERASE". (The DTC in the ECM will be erased.)

- If DTCs are displayed for both ECM and TCM (Transmission control module), they need to be erased individually from the ECM and TCM (Transmission control module).



The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

How to Erase DTC (With GST)

The emission related diagnostic information in the ECM can be erased by selecting Mode 4 with GST.

NOTE:

If the DTC is not for A/T related items (see [EC-1176](#)), skip step 2.

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 5 seconds and then turn it ON (engine stopped) again.
 2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
 3. Select Mode 4 with GST (Generic Scan Tool).
- **If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.**
 - **Erasing the emission-related diagnostic information using CONSULT-II or GST is easier and quicker than switching the mode selector on the ECM.**
 - **The following data are cleared when the ECM memory is erased.**
 1. Diagnostic trouble codes
 2. 1st trip diagnostic trouble codes
 3. Freeze frame data
 4. 1st trip freeze frame data
 5. System readiness test (SRT) codes

6. Test values
7. Others


Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

Malfunction Indicator Lamp (MIL) DESCRIPTION

UBS00892




The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
If the MIL does not light up, refer to [EC-1730](#) or see [DI-22](#).
2. When the engine is started, the MIL should go off.
If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.



ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following two functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in ON position 	BULB CHECK	This function checks the MIL bulb for damage (blown, open circuit, etc.). If the MIL does not come on, check MIL circuit. (See EC-1730 .)
	Engine stopped 		
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MIL will light up to inform the driver that a malfunction has been detected. The following malfunctions will light up or blink the MIL in the 1st trip. <ul style="list-style-type: none"> ● "Misfire (Possible three way catalyst damage)" ● "One trip detection diagnoses"

DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MIL on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to [DI-22](#) or see [EC-1730](#).

DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MIL	Condition
ON	When the malfunction is detected or the ECM's CPU is malfunctioning.
OFF	No malfunction.

OBD System Operation Chart

UBS00893

RELATIONSHIP BETWEEN MIL, 1ST TRIP DTC, DTC, AND DETECTABLE ITEMS

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MIL will come on. For details, refer to "Two Trip Detection Logic" on [EC-1210](#).

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[VG33ER]

- The MIL will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The "TIME" in "SELF-DIAGNOSTIC RESULTS" mode of CONSULT-II will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in "OK" for the 2nd trip.

SUMMARY CHART

Items	Fuel Injection System	Misfire	Other
MIL (goes off)	3 (pattern B)	3 (pattern B)	3 (pattern B)
DTC, Freeze Frame Data (no display)	80 (pattern C)	80 (pattern C)	40 (pattern A)
1st Trip DTC (clear)	1 (pattern C), *1	1 (pattern C), *1	1 (pattern B)
1st Trip Freeze Frame Data (clear)	*1, *2	*1, *2	1 (pattern B)


For details about patterns "B" and "C" under "Fuel Injection System" and "Misfire", see [EC-1228](#) .

For details about patterns "A" and "B" under "Other", see [EC-1230](#) .

*1: Clear timing is at the moment OK is detected.

*2: Clear timing is when the same malfunction is detected in the 2nd trip.

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS FOR “MIS-FIRE” <EXHAUST QUALITY DETERIORATION>, “FUEL INJECTION SYSTEM”



*1: When the same malfunction is detected in two consecutive trips, MIL will light up.

*2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)

*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.

*6: The 1st trip DTC and the 1st trip freeze frame data will be cleared at the moment OK is detected.

*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

*8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

EXPLANATION FOR DRIVING PATTERNS FOR “MISFIRE <EXHAUST QUALITY DETERIORATION>”, “FUEL INJECTION SYSTEM”

<Driving Pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MIL will go off when the B counter reaches 3. (*2 in “OBD SYSTEM OPERATION CHART”)

<Driving Pattern C>

Driving pattern C means the vehicle operation as follows:

The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

Calculated load value: (Calculated load value in the freeze frame data) $\times (1 \pm 0.1)$ [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), “T” should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), “T” should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:


Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)

- The C counter will be cleared when the malfunction is detected regardless of the vehicle conditions described above.
- The C counter will be counted up when the vehicle conditions described above is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"



*1: When the same malfunction is detected in two consecutive trips, MIL will light up.

*2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)


*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.

*6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.

*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

<Driving Pattern A>



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

<Driving Pattern B>

Driving pattern B means the vehicle operation as follows:


All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MIL will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").


TROUBLE DIAGNOSIS

Trouble Diagnosis Introduction
INTRODUCTION

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no malfunctions such as vacuum leaks, fouled spark plugs, or other malfunctions with the engine.




It is much more difficult to diagnose an incident that occurs intermittently rather than continuously. Most intermittent incidents are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.



A visual check only may not find the cause of the incidents. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on [EC-1232](#).


Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such incidents, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on next page should be used.

Start your diagnosis by looking for "conventional" malfunctions first. This will help troubleshoot driveability malfunctions on an electronically controlled engine vehicle.



WORK FLOW

Flow Chart



*1 If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

*4 If malfunctioning part cannot be detected, perform [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

*2 If the incident cannot be verified, perform [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

*5 [EC-1220, "Driving Pattern"](#)

*3 If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to [EC-1288, "POWER SUPPLY CIRCUIT FOR ECM"](#) .

*6 [EC-1283, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#)

SEF510ZF

TROUBLE DIAGNOSIS

[VG33ER]

Description For Work Flow

STEP	DESCRIPTION	A
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the EC-634. "DIAGNOSTIC WORKSHEET" .	EC
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II or GST) the (1st trip) DTC and the (1st trip) freeze frame data, then erase the DTC and the data. (Refer to EC-1223 .) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV. If the incident cannot be verified, perform EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. EC-650 .) Also check related service bulletins for information.	C
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . If the malfunction code is detected, skip STEP IV and perform STEP V.	D E
STEP IV	Try to detect the (1st trip) DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT-II or GST. During the (1st trip) DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the (1st trip) DTC detection.	F G
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-1237 .) If CONSULT-II is available, perform "DATA MONITOR (SPEC)" mode with CONSULT-II and proceed to the EC-684. "TROUBLE DIAGNOSIS - SPECIFICATION VALUE" . (If malfunction is detected, proceed to "REPAIR/REPLACE".) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-650. "Symptom Matrix Chart" .)	H I
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-1258 , EC-1278 . The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to GI-25. "How to Perform Efficient Diagnosis for an Electrical Incident" , "Circuit Inspection". Repair or replace the malfunction parts. If malfunctioning part cannot be detected, perform EC-688. "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" .	J K L
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code [DTC No. P0000 or 0505] is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM and TCM (Transmission control module). (Refer to EC-1223 .)	M

DIAGNOSTIC WORKSHEET**Description**

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, each customer feels differently about an incident. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

Some conditions may cause the MIL to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere [for the models with EVAP (SMALL LEAK) diagnosis].

KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

DTC Inspection Priority Chart

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> ● P0101, P0102, P0103 Mass air flow sensor ● P0112, P0113, P0127 Intake air temperature sensor ● P0117, P0118, P0125 Engine coolant temperature sensor ● P0121, P0122, P0123 Throttle position sensor ● P0181, P0182, P0183 Fuel tank temperature sensor ● P0327, P0328 Knock sensor ● P0335 P1336 CKP sensor (OBD) ● P0340 CMP sensor ● P0460 P0461 P1464 Fuel level sensor ● P0500 VSS ● P0600 A/T control ● P0605 ECM ● P1605 A/T diagnosis communication line ● P1706 PNP switch
2	<ul style="list-style-type: none"> ● P0132-P0134, P1143, P1144/P0152-P0154, P1163, P1164 HO2S1 ● P0031, P0032/P0051, P0052 HO2S1 heater ● P0138, P0139, P1146, P1147/P0158, P0159, P1166, P1167 HO2S2 ● P0037, P0038/P0057, P0058 HO2S2 heater ● P0217 Engine coolant overtemperature enrichment protection ● P0444, P0445, P1444 EVAP canister purge volume control solenoid valve ● P0447, P1446, P1448 EVAP canister vent control valve ● P0452, P0453 EVAP control system pressure sensor ● P0510 CTP switch ● P0705-P0755, P1705, P1760 A/T related sensors, solenoid valves and switches ● P0456, P1456 EVAP control system ● P0441 EVAP control system purge flow monitoring ● P1490 P1491 Vacuum cut valve bypass valve
3	<ul style="list-style-type: none"> ● P0171, P0172, P0174, P0175 Fuel injection system function ● P0306 - P0300 Misfire ● P0420, P0430 Three way catalyst function ● P0442/P1442 EVAP control system ● P0455 EVAP control system ● P0505 ISC valve ● P0731-P0734 P0744 A/T function ● P1148, P1168 Closed loop control

TROUBLE DIAGNOSIS

[VG33ER]

UBS00896

Fail-safe Chart

When the DTC listed below is detected, the ECM enters the fail-safe mode and the MIL illuminates.

DTC No.	Detected items	Engine operating condition in fail-safe mode	
P0102 P0103	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.	
P0117 P0118	Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
		Condition	Engine coolant temperature decided (CONSULT-II display)
		Just as ignition switch is turned ON or Start	40°C (104°F)
		More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
		Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
P0122 P0123	Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
		Condition	Driving condition
		When engine is idling	Normal
		When accelerating	Poor acceleration
Unable to access ECM	ECM	ECM fail-safe activating condition The computing function of the ECM was judged to be malfunctioning. When the fail-safe system activates (i.e., if the ECM detects a malfunction condition in the CPU of ECM), the MIL on the instrument panel lights to warn the driver. However it is not possible to access ECM and DTC cannot be confirmed.	
		Engine control with fail-safe When ECM fail-safe is operating, fuel injection, ignition timing, fuel pump operation, and IACV-AAC valve operation are controlled under certain limitations.	
		ECM fail-safe operation	
		Engine speed	Engine speed will not rise more than 3,000 rpm
		Fuel injection	Simultaneous multiport fuel injection system
		Ignition timing	Ignition timing is fixed at the preset value
		Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls
		IACV-AAC valve	Full open
		Replace ECM, if ECM fail-safe condition is confirmed.	

Basic Inspection

UBS00897

Precaution:


Perform Basic Inspection without electrical or mechanical loads applied;

- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear window defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.

1. INSPECTION START

1. Check service records for any recent repairs that may indicate a related incident, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Vacuum hoses for splits, kinks, or improper connections
 - Wiring for improper connections, pinches, or cuts

Models with CONSULT-II>>GO TO 2.
Models with GST>>GO TO 2.
Models with No Tools>> GO TO 15.



2. CONNECT CONSULT-II OR GST TO THE VEHICLE

With CONSULT-II

Connect "CONSULT-II" to the data link connector for CONSULT-II and select "ENGINE" from the menu. Refer to [EC-1268](#).

With GST


Connect "GST" to the data link connector for GST.
Refer to [EC-1277](#).

Models with CONSULT-II>>GO TO 3.
Models with GST>>GO TO 14.

3. CHECK FI CAM FUNCTION

 With CONSULT-II


1. Turn ignition switch ON.
2. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
3. Start engine and warm it up.



4. When engine coolant temperature is 75 to 85°C (167 to 185°F), check the following.
 - The center of mark **A** is aligned with mark **C**.
 - The cam follower lever's roller is not touching the fast idle cam.

OK or NG


- OK >> GO TO 4.
- NG >> 1. Check FI cam. Refer to [EC-1206, "Fast Idle Cam \(FIC\) Inspection and Adjustment"](#).
- 2. GO TO 4.



4. CHECK IGNITION TIMING

 With CONSULT-II

1. Warm up engine to normal operating temperature.
2. Select "IGNITION TIMING ADJ" in "WORK SUPPORT" mode and touch "START".




3. Check ignition timing at idle using a timing light.

Ignition timing : 10°±2° BTDC

OK or NG

- OK >> GO TO 5.
- NG >> 1. Adjust ignition timing by turning distributor. Refer to [EC-1196, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#).
- 2. GO TO 5.



5. CHECK BASE IDLE SPEED


With CONSULT-II

1. Select "IGNITION TIMING ADJ" in "WORK SUPPORT" mode and touch "START".
2. Check idle speed.

700±50 rpm (in "P" or "N" position)

OK or NG

- OK >> GO TO 6.
 NG >> 1. Adjust engine speed by turning idle speed adjusting screw. Refer to [EC-1196, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#) .
 2. GO TO 6.



6. CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION-I

With CONSULT-II

NOTE:


Always check ignition timing and base idle speed before performing the following.

1. Warm up engine to normal operating temperature.
2. Check FI cam, refer to procedure 3.
3. Stop engine.

>> GO TO 7.

7. CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION-II

1. Turn ignition switch ON.
2. Select "TP SW/TP SEN IDLE POSI ADJ" in "WORK SUPPORT" mode.
3. Read "CLSD THL/P SW" signal under the following conditions.
 - Insert a 0.3 mm (0.012 in) and 0.4 mm (0.016 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure and check the signal.



TP SW/TP SEN IDLE POSI ADJ	
MONITOR	
COOLAN TEMP/S	91 °C
CLSD THL POS	ON
CLSD THL/P SW	ON

SEF715Y

"CLSD THL/P SW" signal should remain "ON" while inserting 0.3 mm (0.012 in) feeler gauge.
 "CLSD THL/P SW" signal should remain "OFF" while inserting 0.4 mm (0.016 in) feeler gauge.

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 8.

8. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION

Ⓜ With CONSULT-II

NOTE:


- Never adjust throttle adjust screw (TAS).
- Do not touch throttle drum when checking "CLSD THL/P SW" signal, doing so may cause an incorrect adjustment.

1. Warm up engine to normal operating temperature.
2. Check FI cam. Refer to procedure 3.
3. Stop engine.
4. Loosen throttle position sensor fixing bolts.

>> GO TO 9.

9. ADJUSTMENT CLOSED THROTTLE POSITION SWITCH IDLE POSITION-II

1. Turn ignition switch ON.
2. Select "TP SW/TP SEN IDLE POSI ADJ" in "WORK SUPPORT" mode.
3. Insert 0.35 mm (0.0138 in) feeler gauge between throttle adjust screw and throttle drum as shown in the figure.
4. Open throttle valve and then close.



5. Check "CLSD THL/P SW" signal.
"CLSD THL/P SW" signal should remain "OFF" when the throttle valve is closed.

OK or NG

- OK >> GO TO 11.
- NG >> GO TO 10.

TP SW/TP SEN IDLE POSI ADJ	
MONITOR	
COOLAN TEMP/S	91°C
CLSD THL POS	ON
CLSD THL/P SW	ON


SEF715Y

10. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-III

 **With CONSULT-II**

Turn throttle position sensor body counterclockwise until "CLSD THL/P SW" signal switches to "OFF".


>> GO TO 11.



11. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-IV

With CONSULT-II

1. Remove 0.35 mm (0.0138 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge.
2. Temporarily tighten sensor body fixing bolts as follows.
 - Gradually move the sensor body clockwise and stop it when "CLSD THL/P SW" signal switches from "OFF" to "ON", then temporarily tighten sensor body fixing bolts.
3. Make sure two or three times that the signal is "ON" when the throttle valve is closed and "OFF" when it is opened.
4. Remove 0.3 mm (0.012 in) feeler gauge then insert 0.4 mm (0.016 in) feeler gauge.
5. Make sure two or three times that the signal remains "OFF" when the throttle valve is closed.
6. Tighten throttle position sensor.
7. Check the "CLSD THL/P SW" signal again.
The signal remains "OFF" while closing throttle valve.



OK or NG

- OK >> GO TO 12.
- NG >> GO TO 8.


12. RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY

With CONSULT-II

NOTE:

Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.

1. Remove feeler gauge.
2. Start engine.
3. Warm up engine to normal operating temperature.
4. Select "TP SW/TP SEN IDLE POSI ADJ" in "WORK SUPPORT" mode.
5. Stop engine. (Turn ignition switch OFF.)
6. Turn ignition switch ON and wait at least 5 seconds.
7. Turn ignition switch OFF and wait at least 5 seconds.



8. Repeat steps 5 and 6 until "CLSD THL POS" signal changes to "ON".

>> GO TO 13.

TP SW/TP SEN IDLE POSI ADJ	
MONITOR	
COOLAN TEMP/S	91 °C
CLSD THL POS	ON
CLSD THL/P SW	ON

13. CHECK TARGET IDLE SPEED

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "ENG SPEED" in "DATA MONITOR" mode.
3. Check idle speed.

750±50 rpm (in "P" or "N" position)

OK or NG

OK >> **INSPECTION END.**

NG >> 1. Adjust idle speed. Refer to [EC-1196, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#)

2. GO TO 27.

14. CHECK FI CAM FUNCTION

With GST


1. Turn ignition switch ON.
2. Select "MODE 1" with GST.
3. Start engine and warm it up.
4. When engine coolant temperature is 75 to 85°C (167 to 185°F), check the following.
 - The center of mark **A** is aligned with mark **C**.
 - The cam follower lever's roller is not touching the fast idle cam.

OK or NG

OK >> GO TO 16.

NG >> 1. Check FI cam. Refer to [EC-1206, "Fast Idle Cam \(FIC\) Inspection and Adjustment"](#).


2. GO TO 16.



15. CHECK FI CAM FUNCTION

 **No Tools**

1. Set the voltmeter between ECM terminal 59 (Engine coolant temperature sensor signal) and ground.
2. Start engine and warm it up.




3. When the voltage is between 1.10 to 1.36V, check the following.
 - The center of mark **A** is aligned with mark **C**.
 - The cam follower lever's roller is not touching the fast idle cam.

OK or NG

OK >> GO TO 16.

NG >> 1. Check FI cam. Refer to [EC-1206, "Fast Idle Cam \(FIC\) Inspection and Adjustment"](#).


2. GO TO 16.



16. CHECK IGNITION TIMING

 **Without CONSULT-II**

1. Warm up engine to normal operating temperature.
2. Stop engine and disconnect throttle position sensor harness connector.
3. Start engine.



4. Check ignition timing at idle using a timing light.


Ignition timing : 10°±2° BTDC

OK or NG

OK >> GO TO 17.

NG >> 1. Adjust ignition timing by turning distributor. Refer to [EC-1196, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#).

2. GO TO 17.



17. CHECK BASE IDLE SPEED

⊗ Without CONSULT-II

1. Make sure that throttle position sensor harness connector remain disconnected.
2. Does engine speed fall to the following speed?

700±50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 18.

NG >> 1. Adjust engine speed by turning idle speed adjusting screw. Refer to [EC-1196, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#) .

2. GO TO 18.

18. CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION

⊗ Without CONSULT-II

NOTE:


Always check ignition timing and base idle speed before performing the following.

1. Warm up engine to normal operating temperature.
2. Check FI cam, refer to procedure 14 or 15.
3. Stop engine.

>> GO TO 19.

19. CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION-I

1. Disconnect closed throttle position switch harness connector.
2. Check continuity between closed throttle position switch terminals **4** and **5** under the following conditions.




- Insert the 0.3 mm (0.012 in) and 0.4 mm (0.016 in) feeler gauge alternately between the throttle adjust screw (TAS) and throttle drum as shown in the figure.
"Continuity should exist" while inserting 0.3 mm (0.012 in) feeler gauge.
"Continuity should not exist" while inserting 0.4 mm (0.016 in) feeler gauge.

OK or NG

OK >> GO TO 24.

NG >> GO TO 20.



20. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION

⊗ Without CONSULT-II


NOTE:

- Never adjust throttle adjust screw (TAS).
 - Do not touch throttle drum when checking “continuity”, doing so may cause an incorrect adjustment.
1. Warm up engine to normal operating temperature.
 2. Check FI cam. Refer to procedure 12 or 13.
 3. Stop engine.
 4. Loosen throttle position sensor fixing bolts.

>> GO TO 21.

21. ADJUSTMENT CLOSED THROTTLE POSITION SWITCH IDLE POSITION-II

1. Disconnect closed throttle position switch harness connector.
2. Insert 0.35 mm (0.0138 in) feeler gauge between the throttle adjust screw and throttle drum as shown in the figure.
3. Open throttle valve then close.




4. Check continuity between closed throttle position switch terminals 4 and 5.

Continuity should not exist while closing the throttle position sensor.

OK or NG

- OK >> GO TO 23.
- NG >> GO TO 22.




22. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-III

⊗ Without CONSULT-II

Turn throttle position sensor body counterclockwise until continuity does not exist.


>> GO TO 23.



23. ADJUSTMENT THROTTLE POSITION SWITCH IDLE POSITION-IV

⊗ Without CONSULT-II

1. Remove 0.35 mm (0.0138 in) feeler gauge then insert 0.3 mm (0.012 in) feeler gauge.
2. Temporarily tighten sensor body fixing bolts as follows.
 - **Gradually move the sensor body clockwise and stop it when the continuity comes to exist, then temporarily tighten sensor body fixing bolts.**
3. Make sure two or three times that the continuity exists when the throttle valve is closed and continuity does not exist when it is opened.
4. Remove 0.3 mm (0.012 in) feeler gauge then insert 0.4 mm (0.016 in) feeler gauge.
5. Make sure two or three times that the continuity does not exist when the throttle valve is closed.
6. Tighten throttle position sensor.
7. Check the continuity again.



Continuity does not exist while closing the throttle valve.

OK or NG

- OK >> GO TO 24.
- NG >> GO TO 20.

24. RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY


⊗ Without CONSULT-II

NOTE:

Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.

1. Remove feeler gauge.
2. Start engine.
3. Warm up engine to normal operating temperature.
4. Stop engine. (Turn ignition switch OFF.)
5. Turn ignition switch ON and wait at least 5 seconds.
6. Turn ignition switch OFF and wait at least 5 seconds.
7. Repeat steps 4 and 5, 20 times.

>> GO TO 25.



25. REINSTALLATION

⊗ **Without CONSULT-II**

1. Reconnect throttle position sensor harness connector and closed throttle position switch harness connector.
2. Start engine and rev it (2,000 to 3,000 rpm) two or three times under no-load and then run engine at idle speed.

>> GO TO 26.

26. CHECK TARGET IDLE SPEED

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.

750±50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 27.

NG >> 1. Adjust idle speed. Refer to [EC-1196, "Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment"](#)

2. GO TO 27.

27. ERASE UNNECESSARY DTC

After this inspection, unnecessary DTC No. might be displayed.

Erase the stored memory in ECM and TCM (Transmission control module).

Refer to [EC-1223, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) and [AT-35, "HOW TO ERASE DTC"](#).

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS

[VG33ER]

UBS00898

Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

		SYMPTOM													Reference page
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		A A	A B	A C	A D	A E	AF	A G	AH	AJ	A K	AL	A M	H A	
Fuel	Fuel pump circuit	1	1	2	3	2		3 2	2			3		1	EC-1716
	Injector circuit														EC-1707
	Fuel pressure regulator system														EC-1209
	Evaporative emission system	4	4	4	4	4	4	4	3	3		4			EC-1731
Air	Positive crankcase ventilation system												1		EC-1747
	Incorrect idle speed adjustment	3	3				1	1	1	1		1			EC-1196
	IACV-AAC valve circuit	2	1	3	3	3	2	2				3		1	EC-1564
	IACV-FICD solenoid valve circuit		2				3	3	2	2					EC-1725
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			EC-1196
	Ignition circuit	1	1	2	2	2		2	2			2			EC-1701
Main power supply and ground circuit		1									1				EC-1288
Air conditioner circuit		2	2	3	3	3	3	3	2	2		3		1	MTC-25

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

TROUBLE DIAGNOSIS

[VG33ER]

	SYMPTOM													Reference page
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATSWATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	A A	A B	A C	A D	A E	AF	A G	AH	AJ	A K	AL	A M	H A	
Camshaft position sensor circuit	1			2				2						EC-1467
Mass air flow sensor circuit														
Heated oxygen sensor 1 circuit		1	2	3	2		2				2			EC-1363 , EC-1372 , EC-1385 , EC-1586 , EC-1593
Engine coolant temperature sensor circuit	1	2	3		3	3			2			3		
Throttle position sensor circuit		1	2		2	2					2			EC-1340 , EC-1349
Incorrect throttle position sensor adjustment		3	1		1	1	1	1	1		1			EC-1237
Vehicle speed sensor circuit		2												EC-1559
Knock sensor circuit			3	3	3						3			EC-1457
ECM	2	2			3	3	3	2	2	1				
Start signal circuit	1													EC-1712
Park/neutral position (PNP) switch circuit			3		3						3			EC-1694
Power steering oil pressure switch circuit		2					3	2						EC-1721

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[VG33ER]

SYSTEM — ENGINE MECHANICAL & OTHER

		SYMPTOM													Reference section
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		A A	A B	A C	A D	A E	AF	A G	AH	AJ	A K	AL	A M	H A	
Fuel	Fuel tank	5													FL-2
	Fuel piping			5	5	5		5	4			5			
	Vapor lock		5												
	Valve deposit														
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5		5	4			5			
Air	Air duct														—
	Air cleaner														
	Air leakage from air duct (Mass air flow sensor — throttle body)		5	5	5	5		5	4			5			
	Throttle body, Throttle wire	5					5			4					EM-78
	Air leakage from intake manifold/Collector/Gasket				5										—
Cranking	Battery		1	1		1		1	1			1		1	SC-4
	Generator circuit														SC-24
	Starter circuit	1													SC-9
	Park/neutral position (PNP) switch														MT-46, AT-99
	Drive plate/Flywheel	6													EM-78

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

TROUBLE DIAGNOSIS


[VG33ER]

		SYMPTOM												Reference section	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATSWATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		A A	A B	A C	A D	A E	AF	A G	AH	AJ	A K	AL	A M	HA	
Engine	Cylinder head	5	5	5	5	5		5	5			5			EM-100
	Cylinder head gasket										2	5	2		
	Cylinder block												3		
	Piston														
	Piston ring							6	6			6			
	Connecting rod	6	6	6	6	6									
	Bearing														
	Crankshaft														
Valve mechanism	Timing chain														EM-130 , EM-89
	Camshaft	6	6	6	6	6		6	6		6	2			
	Intake valve														
	Exhaust valve														
	Hydraulic lash adjuster														
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	6	6	6	6	6		6	6		6			EX-3	
	Three way catalyst														
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	6	6	6	6	6		6	6		6	2		LU-14 , LU-15 , LU-16 , EM-86 MA-30	
	Oil level (Low/Filthy) oil														
Cooling	Radiator/Hose/Radiator filler cap													CO-23 , CO-25 , CO-28 , CO-30 , CO-32 MA-26	
	Thermostat						5			5					
	Water pump														
	Water gallery	6	6	6	6	6		6	6		2	6			
	Cooling fan						5			5					
	Coolant level (low)/Contaminated coolant														

1 - 6: The numbers refer to the order of inspection.

Engine Control Component Parts Location






UBS00899



BBIA0185E

TROUBLE DIAGNOSIS

[VG33ER]





A
EC
C
D
E
F
G
H
I
J
K
L
M


BBIA0186E

TROUBLE DIAGNOSIS

[VG33ER]



Circuit Diagram



BBWA0537E-MF

BBWA0537E

EC

C

D

E

F

G

H

I

J


K

L

M

ECM Harness Connector Terminal Layout

UBS0089B




SEF533P

ECM Terminals and Reference Value PREPARATION


UBS0089C

1. ECM is located behind the instrument lower cover. For this inspection:

- Remove instrument lower cover.




2. Remove ECM harness protector.



3. Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.

- Open harness securing clip to make testing easier.
- Use extreme care not to touch 2 pins at one time.
- Data is for comparison and may not be exact.



ECM INSPECTION TABLE





Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TROUBLE DIAGNOSIS



[VG33ER]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	PU/W	Ignition signal	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>Approximately 0.7V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>1.1 - 1.5V★</p> 
3	P/L	Tachometer	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1 - 2V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>3 - 5V★</p> 
4	OR/B	ECM relay (Self shut-off)	<p>[Engine is running] [Ignition switch OFF]</p> <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch OFF 	0 - 1.5V
			<p>[Ignition switch OFF]</p> <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch OFF 	BATTERY VOLTAGE (11 - 14V)

A
EC
C
D
E
F
G
H
I
J
K
L
M


TROUBLE DIAGNOSIS

[VG33ER]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
5	R/Y	EVAP canister purge volume control solenoid valve	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	BATTERY VOLTAGE (11 - 14V)★ 
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm (More than 100 seconds after starting engine) 	BATTERY VOLTAGE (11 - 14V)★ 
6	G/W	SCB valve control solenoid valve	[Ignition switch ON] <ul style="list-style-type: none"> ● Engine stopped 	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
7	Y/G	A/T check signal	[Ignition switch ON] [Engine is running]	0 - 3.0V
9	B/Y	Ambient air temperature switch	[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is above 25°C (77°F) ● Air conditioner is operating 	0V
			[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is below 19°C (66°F) ● Air conditioner is operating 	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is below 19°C (66°F) ● Air conditioner is not operating 	Approximately 5V
10	B/R	ECM ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Engine ground
11	W/R	Fuel pump relay	[Ignition switch ON] <ul style="list-style-type: none"> ● For 5 seconds after turning ignition switch ON 	0 - 1V
			[Engine is running] [Ignition switch ON] <ul style="list-style-type: none"> ● More than 5 seconds after turning ignition switch ON 	BATTERY VOLTAGE (11 - 14V)
12	P	Air conditioner relay	[Engine is running] <ul style="list-style-type: none"> ● Both A/C switch and blower switch are ON* 	0 - 1V
			[Engine is running] <ul style="list-style-type: none"> ● A/C switch is OFF 	BATTERY VOLTAGE (11 - 14V)

TROUBLE DIAGNOSIS





[VG33ER]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	A
18	R/W	Malfunction indicator lamp	[Ignition switch ON]	0 - 1V	EC
			[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)	
19	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground	C
20	L/OR	Start signal	[Ignition switch ON]	Approximately 0V	D
			[Ignition switch START]	9 - 12V	
21	G/R	Air conditioner switch	[Engine is running] ● Both A/C switch and blower switch are ON (Compressor operates)*	Approximately 0V	E
			[Engine is running] ● A/C switch is OFF	BATTERY VOLTAGE (11 - 14V)	
22	L/B	Park/neutral position (PNP) switch	[Ignition switch ON] ● Gear position is "N" or "P"	Approximately 0V	F
			[Ignition switch ON] ● Except the above gear position	Approximately 5V	G
23	L	Throttle position sensor	[Engine is running] ● Warm-up condition ● More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. ● Accelerator pedal fully released	0.15 - 0.85V	H
			[Ignition switch ON] ● Accelerator pedal fully depressed	3.5 - 4.7V	I
24	W/L	Ignition switch	[Ignition switch OFF]	0V	J
			[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)	K
25	B/Y	ECM ground	[Engine is running] ● Idle speed	Engine ground	L
26	PU/W	A/T signal No. 1	[Engine is running] ● Idle speed	Approximately 0 - 1.0V	M
27	P/B	A/T signal No. 2	[Engine is running] ● Idle speed	Approximately 0 - 1.0V	M
28	BR/W	Throttle position switch (Closed position)	[Engine is running] ● Warm-up condition ● More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. ● Accelerator pedal fully released	BATTERY VOLTAGE (11 - 14V)	M
			[Ignition switch ON] ● Accelerator pedal depressed	Approximately 0V	
29	G/B	Vehicle speed sensor	[Engine is running] ● Lift up the vehicle. ● In 2nd gear position ● Vehicle speed is 40 km/h (25 MPH)	2 - 3V★ 	M

SEF996U





TROUBLE DIAGNOSIS

[VG33ER]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
32	B/Y	ECM ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Engine ground
35	G/R	A/T signal No. 3	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0 - 1.0V
39	GY/R	Power steering oil pressure switch	[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is being turned 	Approximately 0V
			[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is not being turned 	Approximately 5V
42	B/W	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	BR	Sensors' ground	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
44	PU	Camshaft position sensor (Reference signal)	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	0.3 - 0.5V★  <small>SEF997U</small>
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	0.3 - 0.5V★  <small>SEF998U</small>
46	G	Fuel level sensor	[Ignition switch ON]	Approximately 0 - 4.8V Output voltage varies with fuel level.
47	L	Crankshaft position sensor (OBD)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	1 - 2V (AC range)★  <small>SEF690W</small>
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	3 - 4V (AC range)★  <small>SEF691W</small>

TROUBLE DIAGNOSIS



[VG33ER]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
49	LG	Camshaft position sensor (Position signal)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 2.5V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 2.5V★</p> 
50	B	Heated oxygen sensor 1 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p> 
51	G	Heated oxygen sensor 1 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p> 
54	R	Mass air flow sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	1.0 - 1.7V
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,500 rpm 	1.7 - 2.3V
55	G	Mass air flow sensor ground	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
56	OR	Heated oxygen sensor 2 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Revving engine from idle to 3,000 rpm quickly after the following conditions are met. <ul style="list-style-type: none"> - Engine after warming up. - Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - Approximately 1.0V

A
EC
C
D
E
F
G
H
I
J
K
L
M



TROUBLE DIAGNOSIS

[VG33ER]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
57	Y	Heated oxygen sensor 2 (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Revving engine from idle to 3,000 rpm quickly after the following conditions are met. <ul style="list-style-type: none"> - Engine after warming up. - Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - Approximately 1.0V
59	LG/R	Engine coolant temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature
60	Y/B	Fuel tank temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with fuel temperature
61	PU/R	Intake air temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with intake air temperature.
62	Y	EVAP control system pressure sensor	[Ignition switch ON]	1.8 - 4.8V
64	W	Knock sensor	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 2.5V
66	B	Fuel level sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
69	LG/R	Data link connector	[Engine is running] <ul style="list-style-type: none"> ● Idle speed (CONSULT-II or GST is disconnected) 	6 - 10V
72	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
80	SB	Power supply (Back-up)	[Ignition switch OFF]	BATTERY VOLTAGE (11 - 14V)
101	OR/L	IACV-AAC valve	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	8 - 11V★  <small>SEF005V</small>
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 3,000 rpm 	7 - 10V★  <small>SEF692W</small>

TROUBLE DIAGNOSIS

[VG33ER]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
102 104 106 109 111 113	W/B W/R W/G W/L W/PU W	Injector No. 1 Injector No. 3 Injector No. 5 Injector No. 2 Injector No. 4 Injector No. 6	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	BATTERY VOLTAGE (11 - 14V)★  <p style="text-align: right; font-size: small;">SEF007V</p>	<div style="background-color: black; color: white; padding: 2px; font-weight: bold;">EC</div> C D E F
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	BATTERY VOLTAGE (11 - 14V)★  <p style="text-align: right; font-size: small;">SEF008V</p>	
108	R/G	EVAP canister vent control valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)	G
116	B/R	ECM ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Engine ground	H
117	B/P	Current return	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	BATTERY VOLTAGE (11 - 14V)	I
119	BR/Y	Heated oxygen sensor 1 heater (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 2,800 rpm 	Approximately 0.4V	J
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 2,800 rpm 	BATTERY VOLTAGE (11 - 14V)	
120	P/B	Vacuum cut valve bypass valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)	K
121	BR	Heated oxygen sensor 1 heater (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 2,800 rpm 	Approximately 0.4V	L
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 2,800 rpm 	BATTERY VOLTAGE (11 - 14V)	
122	R/B	Heated oxygen sensor 2 heater (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> - Engine: After warming up - Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - 1.0V	M
			[Ignition switch ON] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm 	BATTERY VOLTAGE (11 - 14V)	

TROUBLE DIAGNOSIS

[VG33ER]

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
123	R/Y	Heated oxygen sensor 2 heater (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> - Engine: After warming up - Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - 1.0V
			[Ignition switch ON] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm 	BATTERY VOLTAGE (11 - 14V)
124	B/R	ECM ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Engine ground

*: Any mode except OFF, ambient air temperature is above 25°C (77°F).

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

CONSULT-II Function FUNCTION

UBS0089D

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*1
Data monitor	Input/Output data in the ECM can be read.
Data monitor (SPEC)	Input/Output specification of the basic fuel schedule, AFM, A/F feedback control value and the other data monitor items can be read.
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
DTC confirmation	The status of system monitoring tests and the self-diagnosis status/result can be confirmed.
Function test	This mode is used to inform customs when their vehicle condition requires periodic maintenance.
ECM part number	ECM part number can be read.

*1 The following emission-related diagnostic information is cleared when the ECM memory is erased.

1. Diagnostic trouble codes
2. 1st trip diagnostic trouble codes
3. Freeze frame data
4. 1st trip freeze frame data
5. System readiness test (SRT) codes
6. Test values
7. Others

TROUBLE DIAGNOSIS

[VG33ER]

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

Item		DIAGNOSTIC TEST MODE							
		WORK SUP-PORT	SELF-DIAGNOS-TIC RESULTS		DATA MONI-TOR	DATA MONI-TOR (SPEC)	ACTIVE TEST	DTC & SRT CON-FIRMATION	
			DTC*1	FREEZE FRAME DATA*2				SRT STA-TUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS	INPUT	Camshaft position sensor		X	X	X	X		
	Mass air flow sensor		X		X	X			
	Engine coolant temperature sensor		X	X	X	X	X		
	Heated oxygen sensor 1		X		X	X		X	
	Heated oxygen sensor 2		X		X	X		X	
	Vehicle speed sensor		X	X	X	X			
	Throttle position sensor	X	X		X	X			
	Fuel tank temperature sensor		X		X	X	X		
	EVAP control system pressure sensor		X		X	X			
	Intake air temperature sensor		X		X	X			
	Crankshaft position sensor (OBD)		X						
	Knock sensor		X						
	Ignition switch (start signal)				X	X			
	Closed throttle position switch		X		X	X			
	Closed throttle position switch (throttle position sensor signal)				X	X			
	Air conditioner switch				X	X			
	Park/neutral position (PNP) switch		X		X	X			
	Power steering oil pressure switch				X	X			
	Battery voltage				X	X			
	Ambient air temperature switch				X	X			
ENGINE CONTROL COMPONENT PARTS	OUTPUT	Injectors			X	X	X		
	Power transistor (Ignition timing)	X			X	X	X		
	IACV-AAC valve	X	X		X	X	X		
	EVAP canister purge volume control solenoid valve		X		X	X	X	X	
	Air conditioner relay				X	X			
	Fuel pump relay	X			X	X	X		
	Heated oxygen sensor 1 heater		X		X	X		X	
	Heated oxygen sensor 2 heater		X		X	X		X	
	EVAP canister vent control valve		X		X	X	X		
	Vacuum cut valve bypass valve		X		X	X	X	X	
	SCB valve control solenoid valve		X		X	X	X		
	Calculated load value			X	X	X			


X: Applicable

*1: This item includes 1st trip DTCs.


*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to [EC-1269](#).

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" and CONSULT-II CONVERTER to data link connector which is located under LH dash panel near the fuse box cover.




3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "ENGINE".
If "ENGINE" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



6. Perform each diagnostic test mode according to each service procedure.
For further information, see the CONSULT-II Operation Manual.



TROUBLE DIAGNOSIS

[VG33ER]

WORK SUPPORT MODE

Work Item

WORK ITEM	CONDITION	USAGE
TP SW/TP SEN IDLE POSI ADJ	<ul style="list-style-type: none"> FOLLOW THE BASIC INSPECTION INSTRUCTION IN THE SERVICE MANUAL. 	When adjusting the idle throttle position
IGNITION TIMING ADJ	<ul style="list-style-type: none"> IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR. 	When adjusting target ignition timing After adjustment, confirm target ignition timing with a timing light by turning the distributor.
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line
SELF-LEARNING CONT	<ul style="list-style-type: none"> THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT. 	When clean the coefficient of self-learning control valve
EVAP SYSTEM CLOSE	<p>OPEN THE VACUUM CUT VALVE BYPASS VALVE AND CLOSE THE EVAP CANISTER VENT CONTROL VALVE IN ORDER TO MAKE EVAP SYSTEM CLOSE UNDER THE FOLLOWING CONDITIONS.</p> <ul style="list-style-type: none"> IGN SW ON ENGINE NOT RUNNING AMBIENT TEMPERATURE IS ABOVE 0°C (32°F). NO VACUUM AND NO HIGH PRESSURE IN EVAP SYSTEM FUEL TANK TEMP. IS MORE THAN 0°C (32°F). WITHIN 10 MINUTES AFTER STARTING "EVAP SYSTEM CLOSE" WHEN TRYING TO EXECUTE "EVAP SYSTEM CLOSE" UNDER THE CONDITION EXCEPT ABOVE, CONSULT-II WILL DISCONTINUE IT AND DISPLAY APPROPRIATE INSTRUCTION. <p>NOTE: WHEN STARTING ENGINE, CONSULT-II MAY DISPLAY "BATTERY VOLTAGE IS LOW. CHARGE BATTERY", EVEN IN USING CHARGED BATTERY.</p>	When detecting EVAP vapor leak point of EVAP system
TARGET IDLE RPM ADJ*	<p>SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS.</p> <ul style="list-style-type: none"> ENGINE WARMED UP NO-LOAD 	When adjusting initial ignition timing and idle speed

*: This function is not necessary in the usual service procedure.

SELF-DIAGNOSTIC MODE

Self Diagnostic Item

Regarding items of "DTC and 1st trip DTC", refer to "INDEX for DTC" (See [EC-1176](#).)

Freeze Frame Data and 1st Trip Freeze Frame Data

Freeze frame data item *1	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> The engine control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to EC-1176.)

TROUBLE DIAGNOSIS

[VG33ER]

Freeze frame data item *1	Description
FUEL SYS-B1 *2	<ul style="list-style-type: none"> ● "Fuel injection system status" at the moment a malfunction is detected is displayed.
FUEL SYS-B2 *2	<ul style="list-style-type: none"> ● One mode in the following is displayed. "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	<ul style="list-style-type: none"> ● The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> ● The engine coolant temperature at the moment a malfunction is detected is displayed.
S-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Short-term fuel trim" at the moment a malfunction is detected is displayed.
S-FUEL TRIM-B2 [%]	<ul style="list-style-type: none"> ● The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
L-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Long-term fuel trim" at the moment a malfunction is detected is displayed.
L-FUEL TRIM-B2 [%]	<ul style="list-style-type: none"> ● The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> ● The engine speed at the moment a malfunction is detected is displayed.
VHCL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> ● The vehicle speed at the moment a malfunction is detected is displayed.
ABSOL TH·P/S [%]	<ul style="list-style-type: none"> ● The throttle valve opening angle at the moment a malfunction is detected is displayed.
B/FUEL SCHDL [msec]	<ul style="list-style-type: none"> ● The base fuel schedule at the moment a malfunction is detected is displayed.
INT/A TEMP SE [°C] or [°F]	<ul style="list-style-type: none"> ● The intake air temperature at the moment a malfunction is detected is displayed.

*1: The items are the same as those of 1st trip freeze frame data.

*2: Regarding WD22 model, "-B1" indicates right bank and "-B2" indicates left bank.

DATA MONITOR MODE

Monitored Item

x: Applicable

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks
ENG SPEED [rpm]	X	X	<ul style="list-style-type: none"> ● Indicates the engine speed computed from the REF signal (120° signal) of the camshaft position sensor. 	
MAS A/F SE-B1 [V]	X	X	<ul style="list-style-type: none"> ● The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> ● When the engine is stopped, a certain value is indicated.
B/FUEL SCHDL [msec]		X	<ul style="list-style-type: none"> ● "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	
A/F ALPHA-B1 [%]		X	<ul style="list-style-type: none"> ● The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> ● When the engine is stopped, a certain value is indicated.
A/F ALPHA-B2 [%]		X		<ul style="list-style-type: none"> ● This data also includes the data for the air-fuel ratio learning control.
COOLAN TEMP/S [°C] or [°F]	X	X	<ul style="list-style-type: none"> ● The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> ● When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.

TROUBLE DIAGNOSIS

[VG33ER]

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks	
HO2S1 (B1) [V]	X	X	● The signal voltage of the heated oxygen sensor 1 is displayed.		A EC
HO2S1 (B2) [V]	X	X			
HO2S2 (B1) [V]	X	X	● The signal voltage of the heated oxygen sensor 2 is displayed.		C
HO2S2 (B2) [V]	X	X			
HO2S1 MNTR (B1) [RICH/LEAN]	X		● Display of heated oxygen sensor 1 signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture.	● After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. ● When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously.	D E
HO2S1 MNTR (B2) [RICH/LEAN]	X				
HO2S2 MNTR (B1) [RICH/LEAN]	X		● Display of heated oxygen sensor 2 signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large.	● When the engine is stopped, a certain value is indicated.	F
HO2S2 MNTR (B2) [RICH/LEAN]	X				
VHCL SPEED SE [km/h] or [mph]	X	X	● The vehicle speed computed from the vehicle speed sensor signal is displayed.		G
BATTERY VOLT [V]	X	X	● The power supply voltage of ECM is displayed.		H
THRTL POS SEN [V]	X	X	● The throttle position sensor signal voltage is displayed.		I
FUEL T/TMP SE [°C] or [°F]	X		● The fuel temperature judged from the fuel tank temperature sensor signal voltage is displayed.		J
INT/A TEMP SE [°C] or [°F]	X	X	● The intake air temperature determined by the signal voltage of the intake air temperature sensor is indicated.		K
EVAP SYS PRES [V]			● The signal voltage of EVAP control system pressure sensor is displayed.		L
ABSOL PRES/SE [V]			● The signal voltage of the absolute pressure sensor is displayed.		M
FUEL LEVEL SE [V]	X		● The signal voltage of the fuel level sensor is displayed.		
START SIGNAL [ON/OFF]	X	X	● Indicates [ON/OFF] condition from the starter signal.	● After starting the engine, [OFF] is displayed regardless of the starter signal.	
CLSD THL POS [ON/OFF]	X	X	● Indicates idle position [ON/OFF] computed by ECM according to the throttle position sensor signal.		
CLSD THL/P SW [ON/OFF]	X		● Indicates mechanical contact [ON/OFF] condition of the closed throttle position switch.		
AIR COND SIG [ON/OFF]	X	X	● Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal.		
P/N POSI SW [ON/OFF]	X	X	● Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal.		
PW/ST SIGNAL [ON/OFF]	X	X	● [ON/OFF] condition of the power steering oil pressure switch determined by the power steering oil pressure signal is indicated.		

TROUBLE DIAGNOSIS

[VG33ER]

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks
AMB TEMP SW [ON/OFF]	X		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the ambient air temperature switch signal. 	
IGNITION SW [ON/OFF]	X		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from ignition switch. 	
INJ PULSE-B1 [msec]		X	<ul style="list-style-type: none"> Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain computed value is indicated.
INJ PULSE-B2 [msec]				
IGN TIMING [BTDC]		X	<ul style="list-style-type: none"> Indicates the ignition timing computed by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
CAL/LD VALUE [%]			<ul style="list-style-type: none"> "Calculated load value" indicates the value of the current airflow divided by peak airflow. 	
ABSOL TH-P/S [%]			<ul style="list-style-type: none"> "Absolute throttle position sensor" indicates the throttle opening computed by ECM according to the signal voltage of the throttle position sensor. 	
MASS AIRFLOW [g·m/s]			<ul style="list-style-type: none"> Indicates the mass airflow computed by ECM according to the signal voltage of the mass airflow sensor. 	
IACV-AAC/V [%]		X	<ul style="list-style-type: none"> Indicates the IACV-AAC valve control value computed by ECM according to the input signals. 	
PURG VOL C/V [%]			<ul style="list-style-type: none"> Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals. The opening becomes larger as the value increases. 	
AIR COND RLY [ON/OFF]		X	<ul style="list-style-type: none"> The air conditioner relay control condition (determined by ECM according to the input signal) is indicated. 	
FUEL PUMP RLY [ON/OFF]		X	<ul style="list-style-type: none"> Indicates the fuel pump relay control condition determined by ECM according to the input signals. 	
VENT CONT/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the EVAP canister vent control valve (determined by ECM according to the input signal) is indicated. ON ... Closed OFF ... Open 	
VC/V BYPASS/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the vacuum cut valve bypass valve (determined by ECM according to the input signal) is indicated. ON ... Open OFF ... Closed 	
HO2S1 HTR (B1) [ON/OFF]			<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 1 heater determined by ECM according to the input signals. 	
HO2S1 HTR (B1) [ON/OFF]				

TROUBLE DIAGNOSIS

[VG33ER]

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks
HO2S2 HTR (B1) [ON/OFF]			<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to the input signals. 	
HO2S2 HTR (B2) [ON/OFF]				
SCB/V CON S/V			<ul style="list-style-type: none"> The control condition of the SCB valve control solenoid valve (determined by ECM according to the input signals) is indicated. ON ... SCB valve is closed. OFF ... SCB valve is opened. 	
VOLTAGE [V]			<ul style="list-style-type: none"> Voltage measured by the voltage probe. 	
FREQUENCY [msec] or [Hz] or [%]			<ul style="list-style-type: none"> Pulse width, frequency or duty cycle measured by the pulse probe. 	<ul style="list-style-type: none"> Only “#” is displayed if item is unable to be measured. Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.
- Regarding WD22 model, “B1” indicates bank 1 and “B2” indicates bank 2.

DATA MONITOR (SPEC) MODE

Monitored Items

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	Description	Remarks
MAS A/F SE-B1 [V]	X	X	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor specification is displayed. 	<ul style="list-style-type: none"> When the engine is running, specification range is indicated.
B/FUEL SCHDL [msec]		X	<ul style="list-style-type: none"> “Base fuel schedule” indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	<ul style="list-style-type: none"> When the engine is running, specification range is indicated.
A/F ALPHA-B1 [%]		X	<ul style="list-style-type: none"> Indicates the mean value of the air-fuel ratio feedback correction factor per cycle. 	<ul style="list-style-type: none"> When the engine is running, specification range is indicated. This data also includes the data for the air-fuel ratio learning control.
A/F ALPHA-B2 [%]		X		

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.
- Regarding WD22 model, “B1” indicates bank 1 and “B2” indicates bank 2.

ACTIVE TEST MODE

Test Item

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Fuel injectors Heated oxygen sensor 1
IGNITION TIMING	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Adjust initial ignition timing

TROUBLE DIAGNOSIS

[VG33ER]

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
IACV-AAC/V OPENING	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● Change the IACV-AAC valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> ● Harness and connector ● IACV-AAC valve
POWER BAL- ANCE	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● A/C switch "OFF" ● Shift lever "N" ● Cut off each injector signal one at a time using CONSULT-II. 	Engine runs rough or dies.	<ul style="list-style-type: none"> ● Harness and connector ● Compression ● Injectors ● Power transistor ● Spark plugs ● Ignition coils
ENG COOLANT TEMP	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the engine coolant temperature using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connector ● Engine coolant temperature sensor ● Fuel injectors
FUEL PUMP RELAY	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn the fuel pump relay "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Fuel pump relay
PURG VOL CONT/V	<ul style="list-style-type: none"> ● Engine: After warming up, run engine at 1,500 rpm. ● Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve
FUEL/T TEMP SEN	<ul style="list-style-type: none"> ● Change the fuel tank temperature using CONSULT-II. 		
VENT CON- TROL/V	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn solenoid valve "ON" and "OFF" with the CONSULT-II and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve
VC/V BYPASS/V	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn solenoid valve "ON" and "OFF" with the CONSULT-II and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve

DTC & SRT CONFIRMATION MODE

SRT STATUS Mode

For details, refer to [EC-1215, "SYSTEM READINESS TEST \(SRT\) CODE"](#) .

SRT Work Support Mode

This mode enables a technician to drive a vehicle to set the SRT while monitoring the SRT status.

DTC Work Support Mode

Test mode	Test item	Condition	Reference page
EVAP SYSTEM	EVAP SML LEAK P0442/P1442	Refer to corresponding trouble diagnosis for DTC.	EC-1488/EC-1633
	EVAP V/S LEAK P0456/P1456		EC-1538/EC-1658
	PURG VOL CN/V P1444		EC-1635
	PURGE FLOW P0441		EC-1480
	VC CUT/V BP/V P1491		EC-1677
HO2S1	HO2S1 (B1) P0134		EC-1385
	HO2S1 (B1) P1143		EC-1586
	HO2S1 (B1) P1144		EC-1593
	HO2S1 (B1) P0133		EC-1372
	HO2S1 (B2) P0154		EC-1385
	HO2S1 (B2) P1163	EC-1586	
	HO2S1 (B2) P1164	EC-1593	
	HO2S1 (B2) P0153	EC-1372	
HO2S2	HO2S2 (B1) P1146	EC-1600	
	HO2S2 (B1) P1147	EC-1611	
	HO2S2 (B1) P0139	EC-1405	
	HO2S2 (B2) P1166	EC-1600	
	HO2S2 (B2) P1167	EC-1611	
	HO2S2 (B2) P0159	EC-1405	

REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

Description

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

1. "AUTO TRIG" (Automatic trigger):

The malfunction will be identified on the CONSULT-II screen in real time.


In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM.

At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at left, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed. The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.


2. "MANU TRIG" (Manual trigger):

DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.

DATA MONITOR can be performed continuously even though a malfunction is detected.




"REAL-TIME DIAG" screen is also displayed.



Operation

1. "AUTO TRIG"


- While trying to detect the DTC/1st trip DTC by performing the “DTC Confirmation Procedure”, be sure to select to “DATA MONITOR (AUTO TRIG)” mode. You can confirm the malfunction at the moment it is detected.
 - While narrowing down the possible causes, CONSULT-II should be set in “DATA MONITOR (AUTO TRIG)” mode, especially in case the incident is intermittent.
When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the “DTC Confirmation Procedure”, the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .)
2. “MANU TRIG”
- If the malfunction is displayed as soon as “DATA MONITOR” is selected, reset CONSULT-II to “MANU TRIG”. By selecting “MANU TRIG” you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.



Generic Scan Tool (GST) Function DESCRIPTION

UBS0089E

Generic Scan Tool (OBDII scan tool) complying with SAE J1978 has 7 different functions explained on the next page. ISO9141 is used as the protocol. The name “GST” or “Generic Scan Tool” is used in this service manual.



TROUBLE DIAGNOSIS


[VG33ER]

FUNCTION


Diagnostic test mode		Function
MODE 1	READINESS TESTS	This mode gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.
MODE 2	(FREEZE DATA)	This mode gains access to emission-related data value which were stored by ECM during the freeze frame. [For details, refer to "Freeze Frame Data" (EC-1269).]
MODE 3	DTCs	This mode gains access to emission-related power train trouble codes which were stored by ECM.
MODE 4	CLEAR DIAG INFO	This mode can clear all emission-related diagnostic information. This includes: <ul style="list-style-type: none"> ● Clear number of diagnostic trouble codes (MODE 1) ● Clear diagnostic trouble codes (MODE 3) ● Clear trouble code for freeze frame data (MODE 1) ● Clear freeze frame data (MODE 2) ● Reset status of system monitoring test (MODE 1) ● Clear on board monitoring test results (MODE 6 and 7)
MODE 6	(ON BOARD TESTS)	This mode accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored.
MODE 7	(ON BOARD TESTS)	This mode enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions.
MODE 8	—	This mode can close EVAP system in ignition switch "ON" position (Engine stopped). When this mode is performed, the following parts can be opened or closed. <ul style="list-style-type: none"> ● EVAP canister vent control valve open ● Vacuum cut valve bypass valve closed In the following conditions, this mode cannot function. <ul style="list-style-type: none"> ● Low ambient temperature ● Low battery voltage ● Engine running ● Ignition switch OFF ● Low fuel temperature ● Too much pressure is applied to EVAP system
MODE 9	CALIBRATION ID	This mode is to enable the off-board to request vehicle specific vehicle information such as Vehicle Identification Number (VIN) and calibration IDs.

GST INSPECTION PROCEDURE


1. Turn ignition switch OFF.
2. Connect "GST" to data link connector which is located under LH dash panel near the fuse box cover.



3. Turn ignition switch ON.
 4. Enter the program according to instruction on the screen or in the operation manual.
- (*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.
- For further information, see the GST Operation Manual of the tool maker.**



CONSULT-II Reference Value in Data Monitor Mode

UBS0089F

Remarks:

- Specification data are reference values.
 - Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.

i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION		SPECIFICATION
ENG SPEED	● Run engine and compare CONSULT-II value indication with the tachometer indication.		Almost the same speed as the tachometer indication
MAS A/F SE-B1	● Engine: After warming up	Idle	1.0 - 1.7V
	● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	2,500 rpm	1.7 - 2.3V
COOLAN TEMP/S	● Engine: After warming up		More than 70°C (158°F)
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)			LEAN ↔ RICH Changes more than 5 times during 10 seconds.
HO2S2 (B1) HO2S2 (B2)	● Warm-up condition ● After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load.	Revving engine from idle up to 3,000 rpm quickly	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)			LEAN ↔ RICH
VHCL SPEED SE	● Turn drive wheels and compare CONSULT-II value with the speedometer indication.		Almost the same speed as the speed meter indication
BATTERY VOLT	● Ignition switch: ON (Engine stopped)		11 - 14V
THRTL POS SEN	● Engine: After warming up, idle the engine	Throttle valve: fully closed (a)	0.15 - 0.85V
	● Engine: After warming up ● Ignition switch: ON (Engine stopped)	Throttle valve: Partially open	Between (a) and (b)
		Throttle valve: fully opened (b)	3.5 - 4.7V

TROUBLE DIAGNOSIS

[VG33ER]

MONITOR ITEM	CONDITION	SPECIFICATION	
START SIGNAL	● Ignition switch: ON → START → ON	OFF → ON → OFF	
CLSD THL POS CLSD THL/P SW	● Engine: After warming up, idle the engine	Throttle valve: Idle position	ON
		Throttle valve: Slightly open	OFF
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates.)	ON
P/N POSI SW	● Ignition switch: ON	Shift lever: "P" or "N"	ON
		Except above	OFF
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel in neutral position (forward direction)	OFF
		The steering wheel is turned	ON
AMB TEMP SW	● Ignition switch: ON ● Compare ambient air temperature with the following:	Below 19°C (66°F)	OFF
		Above 25°C (77°F)	ON
IGNITION SW	● Ignition switch: ON → OFF → ON	ON → OFF → ON	
INJ PULSE-B1 INJ PULSE-B2	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	Idle	2.4 - 3.7 msec
		2,000 rpm	1.9 - 3.3 msec
B/FUEL SCHDL	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	Idle	1.0 - 1.6 msec
		2,000 rpm	0.7 - 1.4 msec
IGN TIMING	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	Idle	10°±2° BTDC
		2,000 rpm	More than 25° BTDC
IACV-AAC/V	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	Idle	10 - 20%
		2,000 rpm	—
PURG VOL C/V	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load	Idle	0 %
		2,000 rpm	—
A/F ALPHA-B1 A/F ALPHA-B2	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	54 - 155%
EVAP SYS PRES	● Ignition switch: ON		1.8 – 4.8V
AIR COND RLY	● Air conditioner switch: OFF → ON		OFF → ON
FUEL PUMP RLY	● Ignition switch is turned to ON (Operates for 5 seconds) ● Engine running and cranking		ON
	Except as shown above		OFF
VENT CONT/V	● Ignition switch: ON		OFF
HO2S1 HTR (B1) HO2S1 HTR (B2)	● Engine speed: Below 2,800 rpm		ON
	● Engine speed: Above 2,800 rpm		OFF

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[VG33ER]

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none"> ● Engine speed: Below 3,600 rpm after the following conditions are met. ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,600 rpm 	OFF
SCB/V CON S/V	<ul style="list-style-type: none"> ● More than 5 seconds after turning ignition switch ON (Engine stopped) 	OFF
	<ul style="list-style-type: none"> ● Engine speed: Idle 	ON
VC/V BYPASS/V	Ignition switch: ON	OFF
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle 18.5 - 26.0%
		2,500 rpm 18.0 - 21.0%
ABSOL TH·P/S	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON ● More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. 	Throttle valve: fully closed 0.0%
	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) 	Throttle valve: fully opened Approx. 80%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle 3.3 - 4.8 g·m/s
		2,500 rpm 12.0 - 14.9 g·m/s

Major Sensor Reference Graph in Data Monitor Mode


UBS0089G

The following are the major sensor reference graphs in "DATA MONITOR" mode.

THRTL POS SEN, ABSOL TH·P/S, CLSD THL POS

Below is the data for "THRTL POS SEN", "ABSOL TH·P/S" and "CLSD THL POS" when depressing the accelerator pedal with the ignition switch ON.

The signal of "THRTL POS SEN" and "ABSOL TH·P/S" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".



SEF306Y


ENG SPEED, MAS A/F SE-B1, THRTL POS SEN, HO2S2 (B1), HO2S1 (B1), INJ PULSE-B1

Below is the data for "ENG SPEED", "MAS A/F SE-B1", "THRTL POS SEN", "HO2S2 (B1)", "HO2S1 (B1)" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently.

TROUBLE DIAGNOSIS

[VG33ER]

Each value is for reference, the exact value may vary.



A

EC

C

D

E

F

G

H


I

J

K

L


M




- "THRTL POS SEN" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "HO2S1 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

PFP:00031

Description

UBS0089H

The specification (SP) value indicates the tolerance of the value that is displayed in “DATA MONITOR (SPEC)” mode of CONSULT-II during normal operation of the Engine Control System. When the value in “DATA MONITOR (SPEC)” mode is within the SP value, the Engine Control System is confirmed OK. When the value in “DATA MONITOR (SPEC)” mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MIL.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1/B2 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Testing Condition

UBS0089I

- Vehicle driven distance: More than 5,000 km (3,107 miles)
- Barometric pressure: 101.3 kPa (760.0 mmHg, 29.92 inHg)±3 kPa (22.5 mmHg, 0.89 inHg)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Transmission: Warmed-up*1
- Electrical load: Not applied*2
- Engine speed: Idle

*1: For A/T models, after the engine is warmed up to normal operating temperature, drive vehicle until “FLUID TEMP SE” (A/T fluid temperature sensor signal) indicates less than 0.9V. For M/T models, drive vehicle for 5 minutes after the engine is warmed up to normal operating temperature.

*2: Rear window defogger switch, air conditioner switch, lighting switch are “OFF”. Steering wheel is straight ahead.


Inspection Procedure

UBS0089J


NOTE:

Perform “DATA MONITOR (SPEC)” mode in maximum scale display.

1. Perform [EC-1237, "Basic Inspection"](#) .
2. Confirm that the testing conditions indicated above are met.
3. Select “B/FUEL SCHDL”, “A/F ALPHA-B1”, “A/F ALPHA-B2” and “MAS A/F SE-B1” in “DATA MONITOR (SPEC)” mode with CONSULT-II.
4. Make sure that monitor items are within the SP value.
5. If NG, go to [EC-1284, "Diagnostic Procedure"](#) .




Diagnostic Procedure




TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[VG33ER]



A
EC
C
D
E
F
G
H
I
J
K
L
M

SEF768Z



TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT**Description**

Intermittent incidents (I/I) may occur. In many cases, the malfunction resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific malfunctioning area.

Common I/I Report Situations

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "[1t]".
III	The symptom described by the customer does not recur.
IV	(1st trip) DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for PXXXX does not indicate the malfunctioning area.

Diagnostic Procedure**1. INSPECTION START**

Erase (1st trip) DTCs. Refer to [EC-1223, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

>> GO TO 2.

2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection.
Refer to [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).

OK or NG

OK >> GO TO 3.
NG >> Repair or replace.

3. SEARCH FOR ELECTRICAL INCIDENT

Perform [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).

OK or NG

OK >> GO TO 4.
NG >> Repair or replace.

4. CHECK CONNECTOR TERMINALS

Refer to [GI-22, "How to Check Terminal"](#).

OK or NG

OK >> **INSPECTION END.**
NG >> Repair or replace connector.

POWER SUPPLY CIRCUIT FOR ECM

[VG33ER]




POWER SUPPLY CIRCUIT FOR ECM

FFP:24110



Wiring Diagram

UBS0089N

EC-MAIN-01



Refer to the following.
 (E43) - SUPER MULTIPLE JUNCTION (SMJ)



POWER SUPPLY CIRCUIT FOR ECM

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
4	OR/B	ECM relay (Self-shutoff)	[Engine is running] [Ignition switch OFF] ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			[Ignition switch OFF] ● A few seconds passed after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
10	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
19	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
24	W/L	Ignition switch	[Ignition switch OFF]	0V
			[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
25	B/Y	ECM ground	[Engine is running] ● Idle speed	Engine ground
32	B/Y	ECM ground	[Engine is running] ● Idle speed	Engine ground
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P			
80	SB	Power supply (Back-up)	[Ignition switch OFF]	BATTERY VOLTAGE (11 - 14V)
116	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground
117	B/P	Current return	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)
124	B/R	ECM ground	[Engine is running] ● Idle speed	Engine ground

Diagnostic Procedure

UBS00890

1. INSPECTION START

Start engine.

Is engine running?

Yes or No

Yes >> GO TO 6.

No >> GO TO 2.


2. CHECK ECM POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF and then ON.
2. Check voltage between ECM terminal 24 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M59, F27
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair harness or connectors.

4. CHECK ECM GROUND CIRCUIT-I FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 10, 19, 25, 32, 116, 124 and engine ground. Refer to WIRING DIAGRAM.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 15.
 NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open between ECM and engine ground

>> Repair open circuit or short to power in harness or connectors.


6. CHECK ECM POWER SUPPLY CIRCUIT-II

1. Stop engine.
2. Check voltage between ECM terminal 80 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.



7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Fuse block (J/B) connector M27
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair harness or connectors.


8. CHECK ECM POWER SUPPLY CIRCUIT-III

1. Turn ignition switch ON and then OFF.
2. Check voltage between ECM terminals 67, 72, 117 and ground with CONSULT-II or tester.

Voltage : After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop to approximately 0V.


OK or NG

- OK >> GO TO 14.
- NG (Battery voltage does not exist.)>>GO TO 9.
- NG (Battery voltage exists for more than a few seconds.)>>GO TO 13.



9. CHECK ECM POWER SUPPLY CIRCUIT-IV

1. Disconnect ECM relay.




2. Check voltage between terminals 2, 5 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 11.
 NG >> GO TO 10.



10. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and harness connectors M59, F27

>> Repair open circuit or short to ground or short to power in harness or connectors.

11. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 4 and ECM relay terminal 1. Refer to WIRING DIAGRAM.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 12.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

12. CHECK HARNESS CONTINUITY BETWEEN ECM RELAY AND ECM FOR OPEN AND SHORT

1. Check harness continuity between ECM terminals 67, 72, 117 and ECM relay terminal 3. Refer to WIRING DIAGRAM.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 13.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.


13. CHECK ECM RELAY

1. Apply 12V direct current between relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5.

12V (1 - 2) applied : Continuity exists.
No voltage applied : No continuity

OK or NG

- OK >> GO TO 14.
 NG >> Replace ECM relay.

**14. CHECK ECM GROUND CIRCUIT-II FOR OPEN AND SHORT**

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 10, 19, 25, 32, 116, 124 and engine ground. Refer to WIRING DIAGRAM.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 15.
 NG >> GO TO 5.

15. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER

[VG33ER]

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER

PF2:22690

Description SYSTEM DESCRIPTION

UBS0089P

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heaters

The ECM performs ON/OFF control of the heated oxygen sensor 1 heaters corresponding to the engine speed.

OPERATION

Engine speed rpm	Heated oxygen sensor 1 heaters
Above 2,800	OFF
Below 2,800	ON

CONSULT-II Reference Value in Data Monitor Mode

UBS0089Q

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1)	● Engine speed: Below 2,800 rpm	ON
HO2S1 HTR (B2)	● Engine speed: Above 2,800 rpm	OFF

On Board Diagnosis Logic

UBS0089R

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0031 (Bank 1)	Heated oxygen sensor 1 heater control circuit low	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 1 heater circuit is open or shorted.) ● Heater oxygen sensor 1 heater
P0051 (Bank 2)			
P0032 (Bank 1)	Heated oxygen sensor 1 heater control circuit high	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 1 heater circuit is shorted.) ● Heater oxygen sensor 1 heater
P0052 (Bank 2)			

DTC Confirmation Procedure

UBS0089S

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

 **WITH CONSULT-II**

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 6 seconds at idle speed.
3. If 1st trip DTC is detected, go to [EC-1299, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **WITH GST**

1. Start engine and run it for at least 6 seconds at idle speed.
 2. Turn ignition switch "OFF", wait at least 5 seconds and then turn ON.
 3. Start engine and run it for at 6 seconds at idle speed.
 4. Select "MODE 3" with GST.
 5. If DTC is detected, go to [EC-1299, "Diagnostic Procedure"](#) .
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**





DTC P0031, P0032, P0051, P0052 HO2S1 HEATER

[VG33ER]

UBS0089T

Wiring Diagram BANK 1

EC-O2H1B1-01



DTC P0031, P0032, P0051, P0052 HO2S1 HEATER

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
119	BR/Y	Heated oxygen sensor 1 heater (bank 1)	[Engine is running] ● Engine speed is below 2,800 rpm	Approximately 0.4V
			[Engine is running] ● Engine speed is above 2,800 rpm	BATTERY VOLTAGE (11 - 14V)
121	BR	Heated oxygen sensor 1 heater (bank 2)	[Engine is running] ● Engine speed is below 2,800 rpm	Approximately 0.4V
			[Engine is running] ● Engine speed is above 2,800 rpm	BATTERY VOLTAGE (11 - 14V)






A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER

[VG33ER]

BANK 2

EC-O2H1B2-01



BBWA0467E

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
119	BR/Y	Heated oxygen sensor 1 heater (bank 1)	[Engine is running] ● Engine speed is below 2,800 rpm	Approximately 0.4V
			[Engine is running] ● Engine speed is above 2,800 rpm	BATTERY VOLTAGE (11 - 14V)
121	BR	Heated oxygen sensor 1 heater (bank 2)	[Engine is running] ● Engine speed is below 2,800 rpm	Approximately 0.4V
			[Engine is running] ● Engine speed is above 2,800 rpm	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


UBS0089U

1. CHECK HO2S1 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 1 harness protector.



3. Disconnect corresponding heated oxygen sensor 1 harness connector.
4. Turn ignition switch "ON".




5. Check voltage between HO2S1 terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- Fuse block (J/B) connector M26
- 10A fuse
- Harness for open or short between heated oxygen sensor 1 and fuse

>> Repair harness or connectors.

3. CHECK HO2S1 HEATER OUTPUT CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal and HO2S1 terminal as follows. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0031	119	3	Bank 1
P0051	121	3	Bank 2

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-1300, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace malfunctioning heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION EN

Component Inspection HEATED OXYGEN SENSOR 1 HEATER

UBS0089V

1. Check resistance between HO2S1 terminals 3 and 1.

Resistance : 2.3 - 4.3Ω at 25°C (77°F)


2. Check continuity between HO2S1 terminals 2 and 1, 3 and 2.

Continuity should not exist.

3. If NG, replace heated oxygen sensor 1.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

A

Removal and Installation
HEATED OXYGEN SENSOR 1

UBS0089W

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P0034 SCB VALVE CONTROL SOLENOID VALVE

PFP:14110


Description SYSTEM DESCRIPTION

UBS0089X

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Super-charged air control	SCB valve control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		

This system controls supercharged air according to the engine operating conditions. This control operation is accomplished through the ECM and the SCB valve control solenoid valve. When the solenoid valve is ON, the SCB valve shuts. Then intake air is lead to supercharger, and super-charged air is sent to the cylinder. When the solenoid valve is OFF, the SCB valve opens. Then intake air is sent to the cylinder directly. When the ECM detects any of the following conditions, current does not flow through the solenoid valve.

- Engine stopped
- Engine starting
- High-load, high-speed engine operation
- Excessively low engine coolant temperature
- Mass air flow sensor malfunction
- Engine coolant temperature sensor malfunction
- Throttle position sensor malfunction




COMPONENT DESCRIPTION

SCB Valve Control Solenoid Valve

The SCB valve control solenoid valve responds to signals from the ECM.

When the ECM sends an OFF signal, the solenoid valve is bypassed to apply intake manifold vacuum to the SCB valve actuator. This operation opens the SCB valve. When the ECM sends ON (ground) signal, the SCB valve opens or closes depend on the throttle valve position, regarding to the pressure difference between atmosphere and throttle body.



CONSULT-II Reference Value in Data Monitor Mode

UBS0089Y

Specification data are reference values.

DTC P0034 SCB VALVE CONTROL SOLENOID VALVE

[VG33ER]

MONITOR ITEM	CONDITION	SPECIFICATION
SCB/V CON S/V	More than 5 seconds after turning ignition switch ON (Engine stopped)	OFF
	Engine speed: Idle	ON

On Board Diagnosis Logic

UBS0089Z

DTC No.	Trouble diagnosis name	DTC detection condition	Possible cause
P0034	SCB valve control solenoid valve circuit problem	Improper voltage signal from SCB valve control solenoid valve is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The SCB valve control solenoid valve circuit is open or shorted) ● SCB valve control solenoid valve.

DTC Confirmation Procedure

UBS008A0

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 10 seconds.
4. If 1st trip DTC is detected, go to [EC-1305, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.


DTC P0034 SCB VALVE CONTROL SOLENOID VALVE

[VG33ER]


UBS008A1

Wiring Diagram


EC-S/CHGR-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 17
- LP : 19



Refer to the following.
E43 - SUPER MULTIPLE JUNCTION (SMJ)



WBWA0046E

DTC P0034 SCB VALVE CONTROL SOLENOID VALVE

[VG33ER]

Specification data are reference values, and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
6	G/W	SCB valve control solenoid valve	[Ignition switch ON] ● Engine stopped	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS008A2

1. CHECK SCB VALVE CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect SCB valve control solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between SCB valve control solenoid valve terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between SCB valve control solenoid valve and fuse

>> Repair harness or connectors.

3. CHECK SCB VALVE CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 6 and SCB valve control solenoid valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M58, F28
- Harness for open or short between SCB valve control solenoid valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK SCB VALVE CONTROL SOLENOID VALVE

Refer to [EC-1306, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace SCB valve control solenoid valve.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

**Component Inspection
SCB VALVE CONTROL SOLENOID VALVE**

UBS008A3

 **With CONSULT-II**

1. Perform "SCB/V CONT SOL/V" in "ACTIVE TEST" mode.

ACTIVE TEST	
SCB/V CONT SOL/V	ON
MONITOR	
ENG SPEED	XXXrpm
IACV-AAC/V	XXX%


PBIB1439E

DTC P0034 SCB VALVE CONTROL SOLENOID VALVE

[VG33ER]

2. Check air passage continuity and operation delay time under the following conditions.


Conditions	Air passage between continuity between A and B	Air passage between continuity between A and C
ON	Yes	No
OFF	No	Yes



⊗ Without CONSULT-II

Check air passage continuity and operation delay time under the following conditions.

Conditions	Air passage between continuity between A and B	Air passage between continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes



A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VG33ER]

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

PFP:226A0

Description SYSTEM DESCRIPTION

UBS008A5

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heaters

The ECM performs ON/OFF control of the heated oxygen sensor 2 heaters corresponding to the engine speed.

OPERATION

Engine speed rpm	Heated oxygen sensor 2 heater
Above 3,600	OFF
Below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	ON

CONSULT-II Reference Value in Data Monitor Mode

UBS008A6

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none"> ● Engine speed: Below 3,600 rpm after the following conditions are met. ● Engine: After warming up ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,600 rpm 	OFF

On Board Diagnosis Logic

UBS008A7

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0037 (Bank 1)	Heated oxygen sensor 2 heater control circuit low	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 2 heater circuit is open or shorted.) ● Heater oxygen sensor 2 heater
P0057 (Bank 2)			
P0038 (Bank 1)	Heated oxygen sensor 2 heater control circuit high	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 2 heater circuit is shorted.) ● Heater oxygen sensor 2 heater
P0058 (Bank 2)			

DTC Confirmation Procedure

UBS008A8

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

CONSULT-II WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed at between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minute.
6. If 1st trip DTC is detected, go to [EC-1314, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

GST WITH GST

1. Start engine and warm it up to the normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 10 seconds.
 3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
 4. Let engine idle for one minute.
 5. Turn ignition switch "OFF" and wait at least 10 seconds.
 6. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
 7. Let engine idle for one minute.
 8. Select "MODE 3" with GST.
 9. If DTC is detected, go to [EC-1314, "Diagnostic Procedure"](#).
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

A
EC
C
D
E
F
G
H
I
J
K
L
M


DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VG33ER]




UBS008A9

Wiring Diagram BANK 1

EC-O2H2B1-01



— : Detectable line for DTC
— : Non-detectable line for DTC



WBWA0026E

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
122	R/B	Heated oxygen sensor 2 heater (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> – Engine: After warning up – Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - 1.0V
			[Ignition switch ON] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm 	BATTERY VOLTAGE (11 - 14V)


A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER




[VG33ER]

BANK 2

EC-O2H2B2-01



— : Detectable line for DTC
 — : Non-detectable line for DTC



DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
123	R/Y	Heated oxygen sensor 2 heater (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm after the following conditions are met. – Engine: After warning up – Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - 1.0V
			[Ignition switch ON] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm 	BATTERY VOLTAGE (11 - 14V)

A
EC
C
D
E
F
G
H
I
J
K
L
M


Diagnostic Procedure

1. CHECK HO2S2 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 2 harness protector color.



3. Disconnect corresponding heated oxygen sensor 2 harness connector.
4. Turn ignition switch "ON".




5. Check voltage between HO2S2 terminal 3 and ground.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- Fuse block (J/B) connector M26
- 10A fuse
- Harness for open or short between heated oxygen sensor 2 and fuse

>> Repair harness or connectors.

3. CHECK HO2S2 HEATER OUTPUT CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0037, P0038	122	2	Bank 1
P0057, P0058	123	2	Bank 2

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Joint connector-3
- Harness for open or short between heated oxygen sensor 2 and engine ground.

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2 HEATER

Refer to [EC-1315, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace malfunctioning heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


Component Inspection HEATED OXYGEN SENSOR 2 HEATER

Check the following.

UBS008AB

1. Check resistance between HO2S2 terminals 2 and 3.

Resistance : 2.3 - 4.3Ω at 25°C (77°F)



2. Check continuity.

Terminal No.	Continuity
1 and 2, 3, 4	No
4 and 1, 2, 3	

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

**Removal and Installation
HEATED OXYGEN SENSOR 2**


Refer to [EX-3, "EXHAUST SYSTEM"](#) .

UBS008AC

DTC P0101 MAF SENSOR

Component Description

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	1.0 - 1.7V
		2,500 rpm	1.7 - 2.3V
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	18.5 - 26.0%
		2,500 rpm	18.0 - 21.0%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	3.3 - 4.8 g·m/s
		2,500 rpm	12.0 - 14.9 g·m/s

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0101	Mass air flow sensor circuit range/performance problem	A)	A high voltage from the sensor is sent to ECM under light load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor
		B)	A low voltage from the sensor is sent to ECM under heavy load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor

DTC Confirmation Procedure

Perform "PROCEDURE FOR MALFUNCTION A" first.

If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

NOTE:

If engine will not start or stops soon, wait at least 10 seconds with engine stopped (Ignition switch "ON") instead of running engine at idle speed.

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and warm it up to normal operating temperature.
4. Run engine for at least 10 seconds at idle speed.
5. If 1st trip DTC is detected, go to [EC-1321, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

With GST

Follow the procedure "With CONSULT-II".


PROCEDURE FOR MALFUNCTION B

CAUTION:

Always drive vehicle at a safe speed.

With CONSULT-II

1. Turn ignition switch "ON".
2. Start engine and warm it up to normal operating temperature.
If engine cannot be started, go to [EC-1321, "Diagnostic Procedure"](#).
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Check the voltage of MAS AIR/FL SE with "DATA MONITOR".
5. Increases engine speed to about 4,000 rpm.
6. Monitor the linear voltage rise in response to engine speed increases.
If NG, go to [EC-1321, "Diagnostic Procedure"](#).
If OK, go to following step.



DTC P0101 MAF SENSOR

[VG33ER]

7. Maintain the following conditions for at least 10 consecutive seconds.

ENG SPEED	More than 2,000 rpm
THRTL POS SEN	More than 3V
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V

SEF175Y

8. If 1st trip DTC is detected, go to [EC-1321, "Diagnostic Procedure"](#).

Overall Function Check PROCEDURE FOR MALFUNCTION B

UBS008AH

Use this procedure to check the overall function of the mass air flow sensor circuit. During this check, a 1st trip DTC might not be confirmed.

With GST

1. Start engine and warm it up to normal operating temperature.
2. Select "MODE 1" with GST.
3. Check the mass air flow sensor signal with "MODE 1".
4. Check for linear mass air flow sensor signal value rise in response to increases to about 4,000 rpm in engine speed.
5. If NG, go to [EC-1321, "Diagnostic Procedure"](#).

CALC LOAD	20%
COOLANT TEMP	95°C
SHORT FT #1	2%
LONG FT #1	0%
SHORT FT #2	4%
LONG FT #2	0%
ENGINE SPD	2637RPM
VEHICLE SPD	0MPH
IGN ADVANCE	41.0°
INTAKE AIR	41°C
MAF	14.1gm/sec
THROTTLE POS	3%

SEF534P




DTC P0101 MAF SENSOR

[VG33ER]

UBS008AI

Wiring Diagram

EC-MAFS-01



BBWA0470E

DTC P0101 MAF SENSOR

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
54	R	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.0 - 1.7V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm	1.7 - 2.3V
55	G	Mass air flow sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS008AJ

1. INSPECTION START

Which malfunction (A or B) is duplicated?

A or B

- A >> GO TO 3.
- B >> GO TO 2.

2. CHECK INTAKE SYSTEM

Check the following for connection.

- Air duct
- Vacuum hoses
- Intake air passage between air duct to intake manifold collector


OK or NG

- OK >> GO TO 3.
- NG >> Reconnect the parts.

3. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 4.



4. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect mass air flow (MAF) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and mass air flow sensor
- Harness for open or short between mass air flow sensor and ECM

>> Repair harness or connectors.

6. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 3 and ECM terminal 55. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between MAF sensor terminal 4 and ECM terminal 54. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-1323, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace mass air flow sensor.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component Inspection
MASS AIR FLOW SENSOR**


UBS008AK

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 54 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.0 - 1.7
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.7 - 2.3
Idle to about 4,000 rpm*	1.0 - 1.7 to Approx. 4.0

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

4. If the voltage is out of specification, proceed the following.
 - Turn ignition switch "OFF".
 - Disconnect mass air flow sensor harness connector and reconnect it again.
 - Perform step 2 and 3 again.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.
6. If NG, clean or replace mass air flow sensor.



SEF747U


DTC P0102, P0103 MAF SENSOR

PFP:22680

Component Description

UBS008AM

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

UBS008AN

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	1.0 - 1.7V
		2,500 rpm	1.7 - 2.3V
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	18.5 - 26.0%
		2,500 rpm	18.0 - 21.0%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	3.3 - 4.8 g·m/s
		2,500 rpm	12.0 - 14.9 g·m/s

On Board Diagnosis Logic

UBS008AO

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM. This self-diagnosis has one trip detection logic.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor
P0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

DTC Confirmation Procedure

UBS008AP

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

PROCEDURE FOR DTC P0102

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 5 seconds at most.
4. If DTC is detected, go to [EC-1327, "Diagnostic Procedure"](#) .
If DTC is not detected, go to next step.
5. Start engine and let it idle for at least 6 seconds.
6. If DTC is detected, go to [EC-1327, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II".

PROCEDURE FOR DTC P0103

With CONSULT-II

1. Turn ignition switch "ON".
2. If 1st trip DTC is detected,
Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 6 seconds.
4. If 1st trip DTC is detected, go to [EC-1327, "Diagnostic Procedure"](#) .
If 1st trip DTC is not detected, go to next step.
5. Start engine and let it idle for at least 6 seconds.
6. If 1st trip DTC is detected, go to [EC-1327, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II".

A
EC
C
D
E
F
G
H
I
J
K
L
M







DTC P0102, P0103 MAF SENSOR

[VG33ER]

UBS008AQ

Wiring Diagram

EC-MAFS-01



BBWA0470E

DTC P0102, P0103 MAF SENSOR

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
54	R	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.0 - 1.7V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm	1.7 - 2.3V
55	G	Mass air flow sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS008AR

1. INSPECTION START

Which malfunction (P0102 or P0103) is duplicated?

P0102 or P0103

P0102 >> GO TO 2.

P0103 >> GO TO 3.

2. CHECK INTAKE SYSTEM

Check the following for connection.

- Air duct
- Vacuum hoses
- Intake air passage between air duct to intake manifold collector

OK or NG


OK >> GO TO 3.

NG >> Reconnect the parts.

3. RETIGHTEN GROUND SCREWS


1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 4.



4. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect mass air flow sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and mass air flow sensor
- Harness for open or short between mass air flow sensor and ECM

>> Repair harness or connectors.

6. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 3 and ECM terminal 55. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 7.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between MAF sensor terminal 4 and ECM terminal 54. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-1327, "Diagnostic Procedure"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace mass air flow sensor.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L


M

DTC P0112, P0113 IAT SENSOR

Component Description

The intake air temperature sensor is mounted to the air duct housing. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.




<Reference data>

Intake air temperature °C (°F)	Voltage* (V)	Resistance kΩ
20 (68)	3.5	2.1 - 2.9
80 (176)	1.23	0.27 - 0.38

*: These data are reference values and are measured between ECM terminal 61 (Intake air temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0112	Intake air temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air temperature sensor
P0113	Intake air temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	


DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-1333, "Diagnostic Procedure"](#).



DTC P0112, P0113 IAT SENSOR

[VG33ER]



WITH GST

Follow the procedure "With CONSULT-II".

A

EC

C

D

E

F

G

H

I

J

K

L

M


DTC P0112, P0113 IAT SENSOR

[VG33ER]

UBS008AW

Wiring Diagram

EC-IATS-01





— : Detectable line for DTC
 - - - : Non-detectable line for DTC

⬠ (EP) : EARLY PRODUCTION

⬠ (LP) : LATE PRODUCTION


⬠ (EP) : 22

*1 ⬠ (LP) : 24



Refer to the following.

⬠ (E43) - SUPER MULTIPLE JUNCTION (SMJ)




⬠ (F29) GY



WBWA0028E

Diagnostic Procedure**1. CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect intake air temperature sensor harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 1 and ground.

Voltage : **Approximately 5V**

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.

**2. DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between ECM and intake air temperature sensor

>> Repair harness or connectors.

3. CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between intake air temperature sensor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between ECM and intake air temperature sensor

>> Repair open circuit or short to power in harness or connectors.

5. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-1334, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace intake air temperature sensor.

6. CHECK INTERMITTENT INCIDENT


Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection INTAKE AIR TEMPERATURE SENSOR

Check resistance as shown in the figure.


UBS008AY



SEF947Q

<Reference data>

Intake air temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38




SEF012P

DTC P0117, P0118 ECT SENSOR

Component Description


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 59 (Engine coolant temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Engine coolant temperature sensor
P0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned ON or Start	40°C (104°F)
	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.		

DTC Confirmation Procedure

UBS008B2

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1338, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".




DTC P0117, P0118 ECT SENSOR

[VG33ER]

UBS008B3

Wiring Diagram

EC-ECTS-01




BBWA0508E

Diagnostic Procedure

1. CHECK ECTS POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect engine coolant temperature (RG) sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between ECT sensor terminal 1 and ground with CONSULT-II or tester.

Voltage : **Approximately 5V**

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F38, F102
- Harness for open or short between ECM and engine coolant temperature sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between ECT sensor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F38, F102
- Harness for open or short between ECM and engine coolant temperature sensor

>> Repair open circuit or short to power in harness or connectors.

5. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-1339, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace engine coolant temperature sensor.

6. CHECK INTERMITTENT INCIDENT


Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Component Inspection
ENGINE COOLANT TEMPERATURE SENSOR**


Check resistance as shown in the figure.

UBS008B5



<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260



**Removal and Installation
ENGINE COOLANT TEMPERATURE SENSOR**

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

UBS008B6

DTC P0121 TP SENSOR


Component Description

NOTE:

If DTC P0121 is displayed with DTC P0510, first perform the trouble diagnosis for DTC P0510. Refer to [EC-1571](#).

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit, is not used for engine control.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL POS SEN	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Throttle valve: fully closed (a) 0.15 - 0.85V
	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) 	Throttle valve: Partially open Between (a) and (b)
		Throttle valve: fully opened (b) 3.5 - 4.7V
ABSOL TH-P/S	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON ● More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. 	Throttle valve: fully closed 0.0%
	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) 	Throttle valve: fully opened Approx. 80%

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0121	Throttle position sensor circuit range/performance problem	A)	A high voltage from the sensor is sent to ECM under light load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The TP sensor circuit is open or shorted.) ● TP sensor ● Fuel injector ● Camshaft position sensor ● Mass air flow sensor
		B)	A low voltage from the sensor is sent to ECM under heavy load driving condition.	<ul style="list-style-type: none"> ● Harness or connectors (The TP sensor circuit is open or shorted.) ● Intake air leaks ● TP sensor

DTC Confirmation Procedure

NOTE:

- Perform “PROCEDURE FOR MALFUNCTION A” first. If the 1st trip DTC cannot be confirmed, perform “PROCEDURE FOR MALFUNCTION B”.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


PROCEDURE FOR MALFUNCTION A

④ With CONSULT-II

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for at least 10 seconds.
If idle speed is over 1,000 rpm, maintain the following conditions for at least 10 seconds to keep engine speed below 1,000 rpm.

Selector lever	Suitable position except “P” or “N”
Brake pedal	Depressed
Vehicle speed	0 km/h (0 MPH)

4. If 1st trip DTC is detected, go to [EC-1344, "Diagnostic Procedure"](#) .



④ With GST

Follow the procedure “With CONSULT-II”.

PROCEDURE FOR MALFUNCTION B

CAUTION:

Always drive vehicle at a safe speed.

④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 5 seconds.
3. Turn ignition switch “ON”.
4. Select “MANU TRIG” in “DATA MONITOR” mode with CONSULT-II.


DTC P0121 TP SENSOR

[VG33ER]

5. Select "THRTL POS SEN" and "ABSOL TH·P/S" in "DATA MONITOR" mode with CONSULT-II.
6. Press RECORD on CONSULT-II SCREEN at the same time accelerator pedal is depressed.
7. Print out the recorded graph and check the following:
 - The voltage rise is linear in response to accelerator pedal depression.
 - The voltage when accelerator pedal is fully depressed is approximately 4V.
 If NG, go to [EC-1344, "Diagnostic Procedure"](#) .
 If OK, go to following step.

DATA MONITOR	
MONITOR	NO DTC
THRTL POS SEN	XXX V
ABSOL TH·P/S	XXX %

SEF177Y



8. Select "AUTO TRIG" in "DATA MONITOR" mode with CONSULT-II.
9. Maintain the following conditions for at least 10 consecutive seconds.

CMPS-RPM (REF)	More than 2,000 rpm
MAS AIR/FL SE	More than 3V
COOLAN TEMP/S	More than 70°C (158°F)
IACV-AAC/V	Less than 80%
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

DATA MONITOR	
MONITORING	NO DTC
ENG SPEED	XXX rpm
MAS AIR/FL SE	XXX V
COOLAN TEMP/S	XXX °C
IACV-AAC/V	XXX %

SEF805Z

10. If 1st trip DTC is detected, go to [EC-1344, "Diagnostic Procedure"](#) .

With GST

Follow the procedure "With CONSULT-II".

DTC P0121 TP SENSOR




[VG33ER]

UBS008BB

Wiring Diagram

EC-TPS-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



BBWA0473E

DTC P0121 TP SENSOR

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
23	L	Throttle position sensor	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Accelerator pedal fully released	0.15 - 0.85V
			[Ignition switch ON] <ul style="list-style-type: none">● Accelerator pedal fully depressed	3.5 - 4.7V
42	B/W	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	BR	Sensors' ground	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Idle speed	Approximately 0V

Diagnostic Procedure

UBS008BC

1. INSPECTION START

Which malfunction (A or B) is duplicated?

A or B

- A >> GO TO 4.
- B >> GO TO 2.

2. ADJUST THROTTLE POSITION SENSOR

Check the following items. Refer to [EC-1237, "Basic Inspection"](#).

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

>> GO TO 3.

3. CHECK INTAKE SYSTEM.

1. Turn ignition switch "OFF".
2. Check the following for connection.
 - Air duct
 - Vacuum hoses
 - Intake air passage between air duct to intake manifold collector


OK or NG

- OK >> GO TO 4.
- NG >> Reconnect the parts.

4. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 5.



5. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect throttle position sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between sensor terminal 3 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



6. CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between throttle position sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the harness for open or short between ECM and throttle position sensor.

>> Repair open circuit or short to power in harness or connectors.

A
EC
C
D
E
F
G
H
I
J
K
L
M

8. CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 23 and throttle position sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK THROTTLE POSITION SENSOR

Refer to [EC-1348, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.

10. ADJUST CLOSED THROTTLE POSITION SWITCH

Adjust closed throttle position switch. Refer to [EC-1237, "Basic Inspection"](#) .

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

OK or NG

OK >> GO TO 11.

NG >> Replace throttle position sensor. To adjust it, perform [EC-1237, "Basic Inspection"](#) .

11. CHECK MASS AIR FLOW SENSOR

Refer to [EC-1323, "Component Inspection"](#) .



OK or NG

OK >> GO TO 12.


NG >> Replace mass air flow sensor.

12. CHECK CAMSHAFT POSITION SENSOR

1. Install any parts removed.
2. Start engine.
3. Check voltage between ECM terminals 44, 48 and ground, ECM terminal 49 and ground with DC range.
<Terminal 44 or 48 and engine ground>



<Terminal 49 and engine ground>



OK or NG

- OK >> GO TO 13.
- NG >> Replace distributor assembly with camshaft position sensor.


13. CHECK FUEL INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance : 10 - 14Ω [at 25°C (77°F)]

OK or NG

- OK >> GO TO 14.
- NG >> Replace fuel injector.



14. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Component Inspection
THROTTLE POSITION SENSOR

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine (ignition switch OFF).
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Check voltage of "THRTL POS SEN" under the following conditions.

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	THRTL POS SEN
Completely closed (a)	0.15 - 0.85V
Partially open	Between (a) and (b)
Completely open (b)	3.5 - 4.7V

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
THRTL POS SEN	XXX V

SEF719Y

With GST

1. Start engine and warm it up to normal operating temperature.
2. Stop engine (ignition switch OFF).
3. Turn ignition switch ON.
4. Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground.

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	Voltage [V]
Completely closed	0.15 - 0.85 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.7 (b)

DTC P0122, P0123 TP SENSOR

PF16119

Component Description


UBS008BF

NOTE:

If DTC P0122, P0123 is displayed with DTC P0510, first perform the trouble diagnosis for DTC P0510. Refer to EC-1571.

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit, is not used for engine control.



CONSULT-II Reference Value in Data Monitor Mode

UBS008BG

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL POS SEN	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Throttle valve: fully closed (a) 0.15 - 0.85V
	<ul style="list-style-type: none"> Engine: After warming up Ignition switch: ON (Engine stopped) 	Throttle valve: Partially open Between (a) and (b)
	<ul style="list-style-type: none"> Engine: After warming up Ignition switch: ON (Engine stopped) 	Throttle valve: fully opened (b) 3.5 - 4.7V
ABSOL TH-P/S	<ul style="list-style-type: none"> Engine: After warming up Ignition switch: ON More than -40.0 kpa (-300 mmHg, -11.81 inHg) of vacuum is applied to the throttle opener with a hand vacuum pump. 	Throttle valve: fully closed 0.0%
	<ul style="list-style-type: none"> Engine: After warming up Ignition switch: ON (Engine stopped) 	Throttle valve: fully opened Approx. 80%

On Board Diagnosis Logic

UBS008BH

These self-diagnoses have one trip detection logic.

DTC P0122, P0123 TP SENSOR

[VG33ER]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0122	Throttle position sensor circuit low input	An excessively low voltage from the sensor is sent to ECM	<ul style="list-style-type: none"> ● Harness or connectors (The TP sensor circuit is open or shorted.) ● TP sensor
P0123	Throttle position sensor circuit high input	An excessively high voltage from the sensor is sent to ECM	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	
Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
	Condition	Driving condition
	When engine is idling	Normal
	When accelerating	Poor acceleration

DTC Confirmation Procedure

UBS008BI

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 10V at idle.
- This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and maintain the following conditions for at least 5 consecutive seconds.

Vehicle speed	More than 5 km/h (3 MPH)
Selector lever	Suitable position except "P" or "N" position

3. If 1st trip DTC is detected, go to [EC-1352, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF

SEF065Y

WITH GST

Follow the procedure "With CONSULT-II".

DTC P0122, P0123 TP SENSOR




[VG33ER]

UBS008BJ

Wiring Diagram

EC-TPS-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



BBWA0473E

DTC P0122, P0123 TP SENSOR

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
23	L	Throttle position sensor	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Accelerator pedal fully released	0.15 - 0.85V
			[Ignition switch ON] <ul style="list-style-type: none">● Accelerator pedal fully depressed	3.5 - 4.7V
42	B/W	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	BR	Sensors' ground	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Idle speed	Approximately 0V


Diagnostic Procedure

UBS008BK

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect throttle position sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between sensor terminal 3 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 3.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between throttle position sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the harness for open or short between ECM and throttle position sensor.

>> Repair open circuit or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 23 and throttle position sensor terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK THROTTLE POSITION SENSOR

Refer to [EC-1348, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. ADJUST CLOSED THROTTLE POSITION SWITCH

Adjust closed throttle position switch. Refer to [EC-1237, "Basic Inspection"](#) .

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

OK or NG

- OK >> GO TO 8.
- NG >> Replace throttle position sensor. To adjust it, perform [EC-1237, "Basic Inspection"](#) .

8. CHECK MASS AIR FLOW SENSOR



Refer to [EC-1323, "Component Inspection"](#)

OK or NG


- OK >> GO TO 9.
- NG >> Replace mass air flow sensor.

9. CHECK CAMSHAFT POSITION SENSOR

1. Install any parts removed.
2. Start engine.
3. Check voltage between ECM terminals 44, 48 and ground, ECM terminal 49 and ground with DC range.
<Terminal 44 or 48 and engine ground>



<Terminal 49 and engine ground>



OK or NG

- OK >> GO TO 10.
- NG >> Replace distributor assembly with camshaft position sensor.


10. CHECK FUEL INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance : 10 - 14Ω [at 25°C (77°F)]

OK or NG

- OK >> GO TO 11.
- NG >> Replace fuel injector.



11. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


DTC P0125 ECT SENSOR

Component Description

NOTE:

If DTC P0125 is displayed with P0117 or P0118, first perform the trouble diagnosis for DTC P0117 or P0118. Refer to [EC-1335](#).


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
-10 (14)	4.4	9.2
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 59 (Engine coolant temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0125	Insufficient engine coolant temperature for closed loop fuel control	<ul style="list-style-type: none"> ● Voltage sent to ECM from the sensor is not practical, even when some time has passed after starting the engine. ● Engine coolant temperature is insufficient for closed loop fuel control. 	<ul style="list-style-type: none"> ● Harness or connectors (High resistance in the circuit) ● Engine coolant temperature sensor ● Thermostat

DTC Confirmation Procedure

CAUTION:

Be careful not to overheat engine.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Check that "COOLAN TEMP/S" is above 10°C (50°F).
If it is above 10°C (50°F), the test result will be OK.
If it is below 10°C (50°F), go to following step.
4. Start engine and run it for 65 minutes at idle speed.
If "COOLAN TEMP/S" increases to more than 10°C (50°F) within 65 minutes, stop engine because the test result will be OK.
5. If 1st trip DTC is detected, go to [EC-1357, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

 **WITH GST**

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

UBS008BP

1. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-1357, "Component Inspection"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Replace engine coolant temperature sensor.

2. CHECK THERMOSTAT OPERATION

When the engine is cold [lower than 70°C (158°F)] condition, grasp lower radiator hose and confirm the engine coolant does not flow.

OK or NG

- OK >> GO TO 3.
- NG >> Replace thermostat. Refer to [CO-28, "THERMOSTAT"](#).

3. CHECK INTERMITTENT INCIDENT


Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END.

Component Inspection ENGINE COOLANT TEMPERATURE SENSOR

UBS008BQ

1. Check resistance as shown in the figure.




DTC P0125 ECT SENSOR

[VG33ER]

<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

- If NG, replace engine coolant temperature sensor.



UBS008BR

Removal and Installation ENGINE COOLANT TEMPERATURE SENSOR


Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

DTC P0127 IAT SENSOR

Component Description

The intake air temperature sensor is mounted to the air duct housing. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.




<Reference data>

Intake air temperature °C (°F)	Voltage* (V)	Resistance kΩ
20 (68)	3.5	2.1 - 2.9
80 (176)	1.23	0.27 - 0.38

*: These data are reference values and are measured between ECM terminal 61 (Intake air temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0127	Intake air temperature too high	Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Intake air temperature sensor

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

CAUTION:

Always drive vehicle at a safe speed.


TESTING CONDITION:

This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

WITH CONSULT-II

1. Wait until engine coolant temperature is less than 90°C (194°F).
 - a. Turn ignition switch "ON".

- b. Select "DATA MONITOR" mode with CONSULT-II.
- c. Check the engine coolant temperature.
- d. If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch OFF and cool down engine.
 - Perform the following steps before engine coolant temperature is above 90°C (194°F).
2. Turn ignition switch ON.
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Start engine.
5. Hold vehicle speed at more than 70 km/h (43 MPH) for 100 consecutive seconds.
6. If 1st trip DTC is detected, go to [EC-1360, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

UBS008BV

1. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-1360, "Component Inspection"](#).

OK or NG

- OK >> GO TO 6.
- NG >> Replace intake air temperature sensor.

2. CHECK INTERMITTENT INCIDENT


Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).
For Wiring Diagram, refer to [EC-1332, "Wiring Diagram"](#).

>> INSPECTION END.

Component Inspection INTAKE AIR TEMPERATURE SENSOR

UBS008BV


1. Check resistance as shown in the figure.



<Reference data>

Intake air temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38

2. If NG, replace in take air temperature sensor.



DTC P0128 THERMOSTAT FUNCTION

PF2:21200

On Board Diagnosis Logic

UBS008BY

Engine coolant temperature has not risen enough to open the thermostat even though the engine has run long enough.

This is due to a leak in the seal or the thermostat stuck open.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0128	Thermostat function	The engine coolant temperature does not reach to specified temperature even though the engine has run long enough.	<ul style="list-style-type: none"> ● Thermostat ● Leakage from sealing portion of thermostat ● Engine coolant temperature sensor

DTC Confirmation Procedure

UBS008BZ

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- For best results, perform at ambient temperature of **-10°C (14°F) or higher.**
- For best results, perform at engine coolant temperature of **-10°C (14°F) to 70°C (158°F).**

WITH CONSULT-II

1. Replace thermostat with new one. Refer to [CO-28, "THERMOSTAT"](#) . Use only a genuine NISSAN thermostat as a replacement. If an incorrect thermostat is used, the MIL may come on.
2. Turn ignition switch “ON”.
3. Select “COOLAN TEMP/S” in “DATA MONITOR” mode with CONSULT-II.
4. Check that the “COOLAN TEMP/S” is above 70°C (158°F).
If it is below 70°C (158°F), go to following step.
If it is above 70°C (158°F), stop engine and cool down the engine to less than 70°C (158°F), then retry from step 1.
5. Drive vehicle for 10 consecutive minutes under the following conditions.

VHCL SPEED SE	80 - 120 km/h (50 - 75 MPH)
---------------	-----------------------------

If 1st trip DTC is detected, go to [EC-1361, "Diagnostic Procedure"](#) .

WITH GST

Follow the procedure “WITH CONSULT-II” above.

Diagnostic Procedure

UBS008C0

1. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-1362, "Component Inspection"](#) .

OK or NG

- OK >> **INSPECTION END.**
- NG >> Replace engine coolant temperature sensor.

DTC P0128 THERMOSTAT FUNCTION


[VG33ER]

UBS008C1

Component Inspection

ENGINE COOLANT TEMPERATURE SENSOR

1. Check resistance as shown in the figure.




SEF152P

<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

2. If NG, replace engine coolant temperature sensor.



SEF012P

UBS008C2

Removal and Installation

ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .



DTC P0132, P0152 HO2S1

PFP:22690

Component Description

UBS008C3

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS008C4


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS008C5

To judge the malfunction, the diagnosis checks that the heated oxygen sensor 1 output is not inordinately high.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0132 (Bank 1)	Heated oxygen sensor 1 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Heated oxygen sensor 1
P0152 (Bank 2)			

DTC Confirmation Procedure

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.
4. Select “DATA MONITOR” mode with CONSULT-II.
5. Restart engine and let it idle for 2 minutes.
6. If 1st trip DTC is detected, go to [EC-1368, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEP174Y


Ⓢ WITH GST

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch “OFF” and wait at least 10 seconds.
 3. Restart engine and let it idle for 2 minutes.
 4. Turn ignition switch “OFF” and wait at least 10 seconds.
 5. Restart engine and let it idle for 2 minutes.
 6. Select “MODE 3” with GST.
 7. If DTC is detected, go to [EC-1368, "Diagnostic Procedure"](#) .
- **When using GST, “DTC Confirmation Procedure” should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**




Wiring Diagram
BANK 1

EC-O2S1B1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



— : Detectable line for DTC
— : Non-detectable line for DTC




DTC P0132, P0152 HO2S1

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Heated oxygen sensor 1 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p>  <p style="text-align: right; font-size: small;">SEF002V</p>




★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

BANK 2

EC-O2S1B2-01



A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
51	G	Heated oxygen sensor 1 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

UBS008C8


1. INSPECTION START

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 1 harness protector.



3. Disconnect corresponding heated oxygen sensor 1 harness connector.

>> GO TO 2.



2. RETIGHTEN HEATED OXYGEN SENSOR 1

1. Loosen and retighten corresponding heated oxygen sensor 1.

Tightening torque : 40 - 60 N·m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)

>> GO TO 3.

3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0132	50	2	Bank 1
P0152	51	2	Bank 2

Continuity should exist.

3. Check harness continuity between ECM terminal or HO2S1 terminal and ground as follows.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0132	50 or 2	Ground	Bank 1
P0152	51 or 2	Ground	Bank 2

Refer to Wiring Diagram.

Continuity should not exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FRONT HO2S1 CONNECTOR FOR WATER

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Check connectors for water.

Water should not exist.

OK or NG

OK (With CONSULT-II)>>GO TO 5.

OK (Without CONSULT-II)>>GO TO 6.

NG >> Repair or replace harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 1

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V


SEF967Y

5. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown right:
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5	
	HO2S1 MNTR (B1)	R-L-R-L-R-L-R-L-R-L-R					
Bank 2	cycle	1	2	3	4	5	
	HO2S1 MNTR (B2)	R-L-R-L-R-L-R-L-R-L-R					

R means HO2S1
 MNTR (B1)/(B2) indicates RICH
 L means HO2S1
 MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 7.
- NG >> Replace malfunctioning heated oxygen sensor 1.

6. CHECK HEATED OXYGEN SENSOR 1

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 8.

NG >> GO TO 7.



7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

UBS008C9



DTC P0133, P0153 HO2S1

PF0:22690

Component Description

UBS008CA

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS008CB


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS008CC

To judge the malfunction of heated oxygen sensor 1, this diagnosis measures response time of heated oxygen sensor 1 signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and heated oxygen sensor 1 temperature index. Judgment is based on whether the compensated time (heated oxygen sensor 1 cycling time index) is inordinately long or not.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0133 (Bank 1)	Heated oxygen sensor 1 circuit slow response	The response of the voltage signal from the sensor takes more than the specified time.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks ● Exhaust gas leaks ● PCV valve ● Mass air flow sensor
P0153 (Bank 2)			

DTC Confirmation Procedure

UBS008CD

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch “ON” and select “HO2S1 (B1)/(B2) P0133/ P0153” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.

HO2S1 (B1) P0133	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

SEF338Z

5. Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 5.

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 40 to 50 seconds.)


ENG SPEED	1,700 - 2,800 rpm
Vehicle speed	More than 80 km/h (50 MPH)
B/FUEL SCHDL	2.0 - 14.0 msec
Selector lever	Suitable position

HO2S1 (B1) P0133	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

SEF339Z

If “TESTING” is not displayed after 5 minutes, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-1378, "Diagnostic Procedure"](#).



Overall Function Check

UBS008CE

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.


WITHOUT GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HOS1 (B1) signal] or 51 [HOS1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.

1 time : 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times : 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V


4. If NG, go to [EC-1378, "Diagnostic Procedure"](#).






Wiring Diagram
BANK 1

EC-O2S1B1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M




— : Detectable line for DTC
— : Non-detectable line for DTC



Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Heated oxygen sensor 1 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p>  <p style="text-align: right;"><small>SEF002V</small></p>




★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

BANK 2

EC-O2S1B2-01




A
EC
C
D
E
F
G
H
I
J
K
L
M



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
51	G	Heated oxygen sensor 1 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p>  <p>SEF002V</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

UBS008CG

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. RETIGHTEN HEATED OXYGEN SENSOR 1


Loosen and retighten corresponding heated oxygen sensor 1.

Tightening torque : 40 - 60 N·m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)

>> GO TO 3.

3. CHECK FOR EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



OK or NG

- OK >> GO TO 4.
 NG >> Repair or replace.

4. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG


- OK >> GO TO 5.
 NG >> Repair or replace.

5. CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.

**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?**



Without CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure 1st trip DTC P0102 is displayed.
6. Erase the 1st trip DTC memory. Refer to [EC-1223, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?**

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to [EC-1415](#) or [EC-1423](#) .
- No >> GO TO 6.


6. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check heated oxygen sensor 1 harness protector.



3. Disconnect corresponding heated oxygen sensor 1 harness connector.
4. Disconnect ECM harness connector.
5. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0133	50	2	Bank 1
P0153	51	2	Bank 2



Continuity should exist.

6. Check harness continuity between ECM terminal or HO2S1 terminal and ground as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0133	50 or 2	Ground	Bank 1
P0153	51 or 2	Ground	Bank 2

Continuity should not exist.

7. Also check harness for short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK HEATED OXYGEN SENSOR 1 HEATER

Check resistance between HO2S1 terminals 3 and 1.

Resistance : 2.3 - 4.3Ω at 25°C (77°F)

Check continuity between HO2S1 terminals 2 and 1, 3 and 2.

Continuity should not exist.


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 8.

NG >> Replace malfunctioning heated oxygen sensor 1.



8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-1323, "Component Inspection"](#).

OK or NG

OK >> GO TO 9.

NG >> Replace mass air flow sensor.

9. CHECK PCV VALVE


With engine running at idle, remove PCV valve from rocker cover; make sure that a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.

OK or NG

OK (With CONSULT-II) >> GO TO 10.

OK (Without CONSULT-II) >> GO TO 11.

NG >> Replace PCV valve.



10. CHECK HEATED OXYGEN SENSOR 1

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V


SEF967Y

5. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5	
	HO2S1 MNTR (B1)	R	L	R	L	R	L
Bank 2	cycle	1	2	3	4	5	
	HO2S1 MNTR (B2)	R	L	R	L	R	L

R means HO2S1
MNTR (B1)/(B2) indicates RICH
L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 12.
- NG >> Replace malfunctioning heated oxygen sensor 1.

11. CHECK FRONT HEATED OXYGEN SENSOR 1

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 12.

NG >> Replace malfunctioning heated oxygen sensor 1.



12. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

UBS008CH



DTC P0134, P0154 HO2S1

PF2:22690

Component Description

UBS008CI

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS008CJ


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS008CK

Under the condition in which the heated oxygen sensor 1 signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0134 (Bank 1)	Heated oxygen sensor 1 circuit no activity detected	The voltage from the sensor is constantly approx. 0.3V.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Heated oxygen sensor 1
P0154 (Bank 2)			

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "HO2S1 (B1)/(B2) P0134/P0154" of "HO2S1" in "DTC WORK SUPPORT" mode with CONSULT-II.
3. Touch "START".
4. Let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 4.

HO2S1 (B1) P0134	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

LEC068A

5. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 10 to 60 seconds.)

ENG SPEED	1,400 - 2,700 rpm
Vehicle speed	More than 65 km/h (40 MPH)
B/FUEL SCHDL	2.0 - 14.0 msec
Selector lever	Suitable position

HO2S1 (B1) P0134	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

LEC069A

If "TESTING" is not displayed after 5 minutes, retry from step 2.

6. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-1392, "Diagnostic Procedure"](#).
During this test, P1148 and P1168 may be stored in ECM.

HO2S1 (B1) P0134	
COMPLETED	

LEC034A

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.


WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal] and engine ground.

DTC P0134, P0154 HO2S1

[VG33ER]

3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 to 0.4V.
4. If NG, go to [EC-1392, "Diagnostic Procedure"](#) .



A

EC

C

D

E

F

G

H

I

J





K

L

M

Wiring Diagram
BANK 1

EC-O2S1B1-01




DTC P0134, P0154 HO2S1

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.





TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Heated oxygen sensor 1 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p>  <p style="text-align: right;"><small>SEF002V</small></p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

A
EC
C
D
E
F
G
H
I
J
K
L
M

BANK 2

EC-O2S1B2-01




DTC P0134, P0154 HO2S1

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
51	G	Heated oxygen sensor 1 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V★</p> 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)



A
EC
C
D
E
F
G
H
I
J
K
L
M

Diagnostic Procedure**1. INSPECTION START**

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.



3. Make sure HO2S 1 harness protector color, and disconnect corresponding heated oxygen sensor 1 harness connector.



>> GO TO 2.

2. CHECK HO2S 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0134	50	2	Bank 1
P0154	51	2	Bank 2

Continuity should exist.

3. Check harness continuity between ECM terminal or HO2S1 terminal and ground as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0134	50 or 2	Ground	Bank 1
P0154	51 or 2	Ground	Bank 2

Continuity should not exist.

4. Also check harness for short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 3.

OK (Without CONSULT-II)>> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

A
EC
C
D
E
F
G
H
I
J
K
L
M

3. CHECK HEATED OXYGEN SENSOR 1

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V


SEF967Y

5. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1 2 3 4 5
	HO2S1 MNTR (B1)	R-L-R-L-R-L-R-L-R-L-R
Bank 2	cycle	1 2 3 4 5
	HO2S1 MNTR (B2)	R-L-R-L-R-L-R-L-R-L-R

R means HO2S1
 MNTR (B1)/(B2) indicates RICH
 L means HO2S1
 MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 5.
- NG >> Replace malfunctioning heated oxygen sensor 1.

4. CHECK HEATED OXYGEN SENSOR 1

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 (bank 1 signal) or 51 (bank 2 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 5.

NG >> Replace malfunctioning heated oxygen sensor 1.



5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

DTC P0138, P0158 HO2S2

PF:226A0

Component Description


UBS008CQ

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

UBS008CR


Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> Warm-up condition After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. Revving engine from idle up to 3,000 rpm quickly	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)		LEAN ↔ RICH

On Board Diagnosis Logic

UBS008CS

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0138 (Bank 1)	Heated oxygen sensor 2 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2
P0158 (Bank 2)			

DTC Confirmation Procedure

UBS008CT

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

 **WITH CONSULT-II**

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for two minutes.
6. If 1st trip DTC is detected, go to [EC-1401, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **WITH GST**

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for two minutes.
5. Turn ignition switch "OFF" and wait at least 10 seconds.
6. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
7. Let engine idle for two minutes.
8. Select "Mode 3" with GST.
9. If DTC is detected, go to [EC-1401, "Diagnostic Procedure"](#) .

A

EC

C

D

E

F

G

H

I

J


K

L




M

Wiring Diagram
BANK 1

EC-O2S2B1-01



— : Detectable line for DTC
— : Non-detectable line for DTC



DTC P0138, P0158 HO2S2

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:





Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Revving engine from idle to 3,000 rpm quickly after the following conditions are met. <ul style="list-style-type: none"> – Engine after warming up. – Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - Approximately 1.0V

A
EC
C
D
E
F
G
H
I
J
K
L
M

BANK 2

EC-O2S2B2-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
57	Y	Heated oxygen sensor 2 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Revving engine from idle to 3,000 rpm quickly after the following conditions are met. <ul style="list-style-type: none"> - Engine after warming up. - Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - Approximately 1.0V

Diagnostic Procedure

UBS008CV


1. INSPECTION START

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.



3. Check heated oxygen sensor 2 harness protector color.
4. Disconnect corresponding heated oxygen sensor 2 harness connector.
5. Disconnect ECM harness connector.

>> GO TO 2.



2. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0138	56	1	Bank 1
P0158	57	1	Bank 2

Continuity should exist.

2. Check harness continuity between ECM terminal or HO2S2 terminal and ground as follows.

Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0138	56 or 1	Ground	Bank 1
P0158	57 or 1	Ground	Bank 2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between HO2S2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open between heated oxygen sensor 2 and engine ground.

>> Repair open circuit to ground or short to power in harness or connectors.

5. CHECK HO2S2 CONNECTORS FOR WATER

Check heated oxygen sensor 2 connector and harness connector for water.

Water should not exist.

OK or NG

OK (With CONSULT-II)>>GO TO 6.

OK (Without CONSULT-II)>>GO TO 7.

NG >> Repair or replace harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2


 With CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minutes.
6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.62V at least once when the "FUEL INJECTION" is +25%.
 "HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
 NG >> Replace malfunctioning heated oxygen sensor 2.

7. CHECK HEATED OXYGEN SENSOR 2

⊗ Without CONSULT-II

1. Turn ignition switch "OFF" and wait at least 10 seconds.
2. Stop vehicle with engine running.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.62V at least once during this procedure.

If the voltage is above 0.62V at step 6, step 7 is not necessary.

7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.48V at least once during this procedure.

8. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
NG >> Replace malfunctioning heated oxygen sensor 2.


8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .



DTC P0139, P0159 HO2S2

PF2:226A0

Component Description


UBS008CX

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

UBS008CY


Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> Warm-up condition After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)		LEAN ↔ RICH
	Revsing engine from idle up to 3,000 rpm quickly	

On Board Diagnosis Logic

UBS008CZ

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the switching response of the sensor's voltage is faster than specified during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0139 (Bank 1)	Heated oxygen sensor 2 circuit slow response	It takes more time for the sensor to respond between rich and lean than the specified time.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2 Fuel pressure Injectors Intake air leaks
P0159 (Bank 2)			

DTC Confirmation Procedure

UBS008D0

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


TESTING CONDITION:

Open engine hood before conducting following procedure

WITH CONSULT-II

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.

3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Select "HO2S2 (B1) P0139" or "HO2S2 (B2) P0159" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II and follow the instruction of CONSULT-II.
6. Start engine and following the instruction of CONSULT-II.



7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
 If "NG" is displayed, refer to [EC-1410, "Diagnostic Procedure"](#) .
 If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a. Turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle).
 - b. Turn ignition switch "ON" and select "COOLANTEMP/S" in "DATA MONITOR" mode with CONSULT-II.
 - c. Start engine and warm it up while monitoring "COOLANTEMP/S" indication on CONSULT-II.
 - d. When "COOLANTEMP/S" indication reaches to 70°C (158°F), go to step 3.

Overall Function Check

UBS008D1


Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

WITH GST





1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Set voltmeter probes between ECM terminal 56 [HO2S2(B1) signal] or 57 [HO2S2(B2) signal] and ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
 (Depress and release accelerator pedal as soon as possible.)
The voltage should change at more than 0.06V for 1 second during this procedure.
If the voltage can be confirmed in step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should change at more than 0.06V for 1 second during this procedure.
8. If NG, go to [EC-1410, "Diagnostic Procedure"](#) .



Wiring Diagram
BANK 1

EC-O2S2B1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P0139, P0159 HO2S2

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.




TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none">● Revving engine from idle to 3,000 rpm quickly after the following conditions are met.<ul style="list-style-type: none">– Engine after warming up.– Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load.	0 - Approximately 1.0V

BANK 2

EC-O2S2B2-01



— : Detectable line for DTC
 — : Non-detectable line for DTC



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
57	Y	Heated oxygen sensor 2 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Revving engine from idle to 3,000 rpm quickly after the following conditions are met. <ul style="list-style-type: none"> – Engine after warming up. – Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - Approximately 1.0V


Diagnostic Procedure

UBS008D3

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?**



WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-1223, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?**

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to [EC-1415](#) or [EC-1423](#).
- No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between HO2S2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART


Check the following.

- Harness for open between heated oxygen sensor 2 and engine ground.

>> Repair open circuit or short to power in harness or connectors.


5. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 2 harness protector color.



3. Disconnect corresponding heated oxygen sensor 2 harness connector.
4. Disconnect ECM harness connector.
5. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0139	56	1	Bank 1
P0159	57	1	Bank 2



Continuity should exist.

6. Check harness continuity between ECM terminal or HO2S2 terminal and ground as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0139	56 or 1	Ground	Bank 1
P0159	57 or 1	Ground	Bank 2

Continuity should not exist.

7. Also check harness for short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 6.

OK (Without CONSULT-II)>>GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2


 With CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minutes.
6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.62V at least once when the "FUEL INJECTION" is +25%.
 "HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


OK or NG

- OK >> GO TO 8.
 NG >> Replace malfunctioning heated oxygen sensor 2.

7. CHECK HEATED OXYGEN SENSOR 2

⊗ Without CONSULT-II

1. Turn ignition switch "OFF" and wait at least 10 seconds.
2. Stop vehicle with engine running.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.62V at least once during this procedure.
If the voltage is above 0.62V at step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.48V at least once during this procedure.
8. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
NG >> Replace malfunctioning heated oxygen sensor 2.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

UBS008D4

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

PFP:16600

On Board Diagnosis Logic

UBS008D5

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensors 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and light up the MIL (2 trip detection logic).

Sensor	Input signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0171 (Bank 1)	Fuel injection system too lean	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	<ul style="list-style-type: none"> ● Intake air leaks ● Heated oxygen sensor 1 ● Injectors ● Exhaust gas leaks ● Incorrect fuel pressure ● Lack of fuel ● Mass air flow sensor ● Incorrect PCV hose connection
P0174 (Bank 2)			

DTC Confirmation Procedure


UBS008D6

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON and select “SELF-LEARNING CONT” in “WORK SUPPORT” mode with CONSULT-II.
4. Clear the self-learning control coefficient by touching “CLEAR”.
5. Select “DATA MONITOR” mode with CONSULT-II.
6. Start engine again and let it idle for at least 10 minutes.
The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to [EC-1419, "Diagnostic Procedure"](#).
7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
8. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-1419, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.



WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 5 seconds.
3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select “MODE 3” with GST. Make sure DTC P0102 is detected.
6. Select “MODE 4” with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VG33ER]

-
8. Select "MODE 7" with GST. The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to [EC-1419, "Diagnostic Procedure"](#).
 9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
 10. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-1419, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.





DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VG33ER]

UBS008D7

Wiring Diagram BANK 1

EC-FUELB1-01







BBWA0509E

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION

[VG33ER]

BANK 2


EC-FUELB2-01



Diagnostic Procedure

1. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

2. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.

3. CHECK FOR PCV HOSE

Check PCV hose for loose connection or disconnection.

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.

4. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect corresponding heated oxygen sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0171	50	2	Bank 1
P0174	51	2	Bank 2

Continuity should exist.

5. Check harness continuity between ECM terminal or HO2S1 terminal and ground as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0171	50 or 2	Ground	Bank 1
P0174	51 or 2	Ground	Bank 2

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK FUEL PRESSURE

1. Release fuel pressure to zero.
Refer to [EC-1207, "FUEL PRESSURE RELEASE"](#) .
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-1207, "Fuel Pressure Check"](#) .

At idling:

When fuel pressure regulator valve vacuum hose is connected. 235 kPa (2.4 kg/cm² , 34 psi)

When fuel pressure regulator valve vacuum hose is disconnected. 294 kPa (3.0 kg/cm² , 43 psi)

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-1716, "FUEL PUMP CIRCUIT"](#) .)
- Fuel pressure regulator (Refer to [EC-1209, "Fuel Pressure Regulator Check"](#) .)
- Fuel lines (Refer to [MA-28, "Checking Fuel Lines"](#) .)
- Fuel filter for clogging

>> Repair or replace.

7. CHECK MASS AIR FLOW SENSOR

With CONSULT-II

1. Install all parts removed.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

With GST

1. Install all parts removed.
2. Check mass air flow sensor in MODE 1 with GST.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

OK or NG

OK >> GO TO 8.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-1317, "DTC P0101 MAF SENSOR"](#) .

8. CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step

SEF070Y

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.

Clicking noise should be heard.



OK or NG

OK >> GO TO 9.

NG >> Perform trouble diagnosis for [EC-1711, "INJECTOR"](#) .


9. CHECK INJECTOR

1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
2. Turn ignition switch OFF.
3. Disconnect injector harness connectors on left bank (for DTC P0171), right bank (for DTC P0174).
4. Remove injector gallery assembly. Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .
Keep fuel hose and all injectors connected to injector gallery.
The injector harness connectors on right bank (for DTC P0171), left bank (for DTC P0174) should remain connected.
5. Disconnect all ignition coil harness connectors.
6. Prepare pans or saucers under each injector.
7. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors.

Fuel should be sprayed evenly for each injector.

OK or NG

- OK >> GO TO 10.
NG >> Replace injectors from which fuel does not spray out.
Always replace O-ring with new ones.



10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

PFP:16600

On Board Diagnosis Logic

UBS008D9

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensors 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and light up the MIL (2 trip detection logic).

Sensor	Input signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0172 (Bank 1)	Fuel injection system too rich	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Injectors ● Exhaust gas leaks ● Incorrect fuel pressure ● Mass air flow sensor
P0175 (Bank 2)			

DTC Confirmation Procedure


UBS008DA

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

ⓑ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON and select “SELF-LEARNING CONT” in “WORK SUPPORT” mode with CONSULT-II.
4. Clear the self-learning control coefficient by touching “CLEAR”.
5. Select “DATA MONITOR” mode with CONSULT-II.
6. Start engine again and let it idle for at least 10 minutes.
The 1st trip DTC P0172, P0175 should be detected at this stage, if a malfunction exists. If so, go to [EC-1427, "Diagnostic Procedure"](#) .
7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
8. Crank engine while depressing accelerator pedal.
If engine starts, go to [EC-1427, "Diagnostic Procedure"](#) . If engine does not start, remove ignition plugs and check for fouling, etc.




Ⓒ WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 5 seconds.

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VG33ER]

3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 3" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select "MODE 7" with GST. The 1st trip DTC P0172 or P0175 should be detected at this stage, if a malfunction exists. If so, go to [EC-1427, "Diagnostic Procedure"](#).
9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal.
If engine starts, go to [EC-1427, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.







DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VG33ER]

Wiring Diagram BANK 1

UBS008DB

EC-FUELB1-01







BBWA0509E

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION

[VG33ER]

BANK 2


EC-FUELB2-01



Diagnostic Procedure

1. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

2. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.

3. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect corresponding heated oxygen sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0172	50	2	Bank 1
P0175	51	2	Bank 2

Continuity should exist.

5. Check harness continuity between ECM terminal or HO2S1 terminal and ground as follows.

Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P0172	50 or 2	Ground	Bank 1
P0175	51 or 2	Ground	Bank 2

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero.
Refer to [EC-1207, "FUEL PRESSURE RELEASE"](#) .
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-1207, "Fuel Pressure Check"](#) .

At idling:

When fuel pressure regulator valve vacuum hose is connected. 235 kPa (2.4 kg/cm² , 34 psi)

When fuel pressure regulator valve vacuum hose is disconnected. 294 kPa (3.0 kg/cm² , 43 psi)

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-1716, "FUEL PUMP CIRCUIT"](#) .)
- Fuel pressure regulator (Refer to [EC-1209, "Fuel Pressure Regulator Check"](#) .)

>> Repair or replace.

6. CHECK MASS AIR FLOW SENSOR

With CONSULT-II

1. Install all parts removed.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

With GST

1. Install all parts removed.
2. Check mass air flow sensor in MODE 1 with GST.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

OK or NG

OK >> GO TO 7.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-1317, "DTC P0101 MAF SENSOR"](#) .

7. CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step

SEF070Y

Without CONSULT-II


1. Start engine.
2. Listen to each injector operating sound.

Clicking noise should be heard.

OK or NG

OK >> GO TO 8.

NG >> Perform trouble diagnosis for [EC-1707, "INJECTOR CIRCUIT"](#) .



8. CHECK INJECTOR

1. Remove injector assembly. Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .
Keep fuel hose and all injectors connected to injector gallery.
2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
3. Disconnect injector harness connectors bank 2 (for DTC P0172), right bank (for P0175).
The injector harness connectors on bank 1 (for P0172), left bank (for P0175) should remain connected.
4. Disconnect all ignition coil harness connectors.
5. Prepare pans or saucers under each injectors.
6. Crank engine for about 3 seconds.
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip)>>GO TO 9.

NG (Drips)>>Replace the injectors from which fuel is dripping. Always replace O-ring with new one.

9. CHECK INTERMITTENT INCIDENT


Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0181 FTT SENSOR

Component Description

The fuel tank temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.




<Reference data>

Fluid temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
20 (68)	3.5	2.3 - 2.7
50 (122)	2.2	0.79 - 0.90

*: These data are reference values and are measured between ECM terminal 60 (Fuel tank temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0181	Fuel tank temperature sensor circuit range/performance	Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signals from engine coolant temperature sensor and intake air temperature sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Fuel tank temperature sensor

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 10 seconds.
If the result is NG, go to [EC-1434, "Diagnostic Procedure"](#).
If the result is OK, go to following step.
4. Check "COOLAN TEMP/S" value.
If "COOLAN TEMP/S" is less than 60°C (140°F), the result will be OK.
If "COOLAN TEMP/S" is above 60°C (140°F), go to the following step.
5. Cool engine down until "COOLAN TEMP/S" is less than 60°C (140°F).
6. Wait at least 10 seconds.
7. If 1st trip DTC is detected, go to [EC-1434, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y



WITH GST

Follow the procedure "With CONSULT-II".


DTC P0181 FTT SENSOR

[VG33ER]

Wiring Diagram




UBS008DG

EC-FTTS-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- : EARLY PRODUCTION
- : LATE PRODUCTION

A
EC
C
D
E
F
G
H
I
J
K
L
M




WBWA0047E

Diagnostic Procedure

1. CHECK FUEL TANK TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit harness connector.
3. Turn ignition switch ON.




4. Check voltage between fuel level sensor unit terminal 1 and ground with CONSULT-II or tester.

Voltage : **Approximately 5V**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B103, M91
- Harness connectors M81, F36
- Harness for open or short between ECM and fuel tank temperature sensor

>> Repair harness or connector.

3. CHECK FUEL TANK TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between fuel level sensor unit terminal 4 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check harness for open between fuel tank temperature sensor and body ground.

>> Repair open circuit or short to power in harness or connectors.


5. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance fuel level sensor unit terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

OK or NG

- OK >> GO TO 6.
- NG >> Replace fuel tank temperature sensor.



6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Removal and Installation
FUEL TANK TEMPERATURE SENSOR**

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

UBS008DI


DTC P0182, P0183 FTT SENSOR

PFP:22630

Component Description

UBS008DJ

The fuel tank temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.




<Reference data>

Fluid temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
20 (68)	3.5	2.3 - 2.7
50 (122)	2.2	0.79 - 0.90

*: These data are reference values and are measured between ECM terminal 60 (Fuel tank temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.



On Board Diagnosis Logic

UBS008DK

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0182	Fuel tank temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Fuel tank temperature sensor
P0183	Fuel tank temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

UBS008DL

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 10 seconds.
4. If 1st trip DTC is detected, go to [EC-1438, "Diagnostic Procedure"](#).

WITH GST

Follow the procedure "With CONSULT-II".

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y


DTC P0182, P0183 FTT SENSOR

[VG33ER]

UBS008DM




Wiring Diagram

EC-FTTS-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION

A
EC
C
D
E
F
G
H
I
J
K
L
M




WBWA0047E

Diagnostic Procedure

1. CHECK FUEL TANK TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit harness connector.
3. Turn ignition switch "ON".




4. Check voltage between fuel level sensor unit terminal 1 and ground with CONSULT-II or tester.

Voltage : **Approximately 5V**

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B103, M91
- Harness connectors M81, F36
- Harness for open or short between ECM and fuel tank temperature sensor

>> Repair harness or connector.

3. CHECK FUEL TANK TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between fuel level sensor unit terminal 4 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check harness for open between fuel tank temperature sensor and body ground.

>> Repair open circuit or short to power in harness or connectors.


5. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance fuel level sensor unit terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

OK or NG

- OK >> GO TO 6.
- NG >> Replace fuel tank temperature sensor.



6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Removal and Installation
FUEL TANK TEMPERATURE SENSOR**

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

UBS008DO

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

[VG33ER]

DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

PF0:00019

On Board Diagnosis Logic

UBS008DP

This diagnosis checks whether the engine coolant temperature is extraordinary high, even when the load is not heavy.

When malfunction is detected, the malfunction indicator lamp (MIL) will light up even in the first trip.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0217	Engine coolant over temperature condition	Engine coolant temperature is excessively high under normal engine speed.	<ul style="list-style-type: none">● Cooling fan (crankshaft driven)● Thermostat● Improper ignition timing● Engine coolant temperature sensor● Blocked radiator● Blocked front end (Improper fitting of nose mask)● Crushed vehicle frontal area (Vehicle frontal is collided but not repaired)● Blocked air passage by improper installation of front fog lamp or fog lamps● Improper mixture ratio of coolant● Damaged bumper For more information, refer to EC-1444 , " Main 12 Causes of Overheating ".

CAUTION:

When a malfunction is indicated, be sure to replace the coolant. Refer to [MA-26](#), "[Changing Engine Coolant](#)". Also, replace the engine oil. Refer to [MA-30](#), "[Changing Engine Oil](#)".

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-14](#), "[ANTI-FREEZE COOLANT MIXTURE RATIO](#)".
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Overall Function Check

UBS008DQ

Use this procedure to check the overall function of the engine coolant over temperature enrichment protection check, a DTC might not be confirmed.

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high-pressure fluid escaping from the radiator.


Wrap a thick cloth around the cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

WITH CONSULT-II

1. Check the coolant level and mixture ratio (Using coolant tester) in the reservoir tank and radiator.

Allow engine to cool before checking coolant level and mixture ratio.


- If the coolant level in the reservoir and/or the radiator is below the proper range, skip following steps and go to [EC-1442](#), "[Diagnostic Procedure](#)".
 - If the coolant mixture ratio is out of range between 45 to 55%, replace the coolant. Refer to [MA-26](#), "[Changing Engine Coolant](#)".
- Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to [MA-14](#), "[ANTI-FREEZE COOLANT MIXTURE RATIO](#)".
 - After refilling coolant, run engine to ensure that no water-flow noise is emitted.



DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION


[VG33ER]

- After checking or replacing coolant, go to step 3) below.
- 2. Confirm whether customer filled the engine coolant or not. If customer filled the engine coolant, skip following steps and go to "Diagnostic Procedure", [EC-1442, "Diagnostic Procedure"](#).
- 3. Start engine and make sure that cooling fan (crankshaft driven) operates. If NG, go to [EC-1442, "Diagnostic Procedure"](#). After repair, go to next step.
- 4. Check for blocked coolant passage.
Warm up engine to normal operating temperature, then grasp upper and lower radiator hoses and make sure that coolant flows.
If NG, go to step 4 of [EC-1442, "Diagnostic Procedure"](#). After repair, go to next step.
Be extremely careful not to touch any moving or adjacent parts.
- 5. Check radiator for blocked air passage
Check for blocked condenser or radiator (condenser or radiator fins damaged, condenser or radiator clogged), after market fog lamps ...etc. Check for condenser or radiator fin damage, shroud damage, vehicle front end for clogging of debris or insects ...etc.
Check for improper fitting of front end cover, damaged radiator grille or bumper, vehicle frontal area damaged by collision but not repaired.
If NG, take appropriate action and then go to next step.
- 6. Check ECT sensor for proper operation. Refer to step 5 of [EC-1442, "Diagnostic Procedure"](#). If NG, replace ECT sensor and go to next step.
- 7. Check ignition timing. Refer to [EC-1237, "Basic Inspection"](#).
Make sure that ignition timing is $10^{\circ} \pm 2^{\circ}$ at 700 ± 50 rpm.
If NG, adjust ignition timing and then recheck.



WITH GST

- 1. Check the coolant level and mixture ratio (Using coolant tester) in the reservoir tank and radiator.
Allow engine to cool before checking coolant level and mixture ratio.
 - If the coolant level in the reservoir and/or radiator is below the proper range, skip the following steps and go to [EC-1442, "Diagnostic Procedure"](#).
 - If the coolant mixture ratio is out of range between 45 to 55%, replace the coolant. Refer to [MA-26, "Changing Engine Coolant"](#).
 - Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to [MA-14, "ANTI-FREEZE COOLANT MIXTURE RATIO"](#).
 - After refilling coolant, run engine to ensure that no water-flow noise is emitted.
 - After checking or replacing coolant, go to step 3) below.
- 2. Confirm whether customer filled the engine coolant or not. If customer filled engine coolant, skip following steps and go to [EC-1442, "Diagnostic Procedure"](#).
- 3. Start engine and make sure that cooling fan (crankshaft driven) operates.
Be careful not to overheat engine.
If NG, go to step 1 of [EC-1442, "Diagnostic Procedure"](#). After repair, go to next step.
- 4. Check for blocked coolant passage.
Warm up engine to normal operating temperature, then grasp upper and lower radiator hoses and make sure that coolant flows.
If NG, go to step 4 of [EC-1442, "Diagnostic Procedure"](#). After repair, go to next step.




DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

[VG33ER]

Be extremely careful not to touch any moving or adjacent parts.

5. Check radiator for blocked air passage
Check for blocked condenser or radiator (condenser or radiator fins damaged, condenser or radiator clogged), after market fog lamps ...etc. Check for condenser or radiator fin damage, shroud damage, vehicle front end for clogging of debris or insects ...etc.
Check for improper fitting of front end cover, damaged radiator grille or bumper, vehicle frontal area damaged by collision but not repaired.
If NG, take appropriate action and then go to next step.
6. Check ECT sensor for proper operation. Refer to step 5 of [EC-1442, "Diagnostic Procedure"](#) . If NG, replace ECT sensor and go to next step.
7. Check ignition timing. Refer to [EC-1237, "Basic Inspection"](#) .
Make sure that ignition timing is $10^{\circ} \pm 2^{\circ}$ at 700 ± 50 rpm.
If NG, adjust ignition timing and then recheck.



UBS008DR

Diagnostic Procedure

1. CHECK COOLING FAN (CRANKSHAFT DRIVEN) OPERATION

Start engine and make sure that cooling fan (crankshaft driven) operates.

OK or NG

OK >> GO TO 2.

NG >> Check cooling fan (crankshaft driven). Refer to [CO-32, "COOLING FAN \(CRANKSHAFT DRIVEN\)"](#) .

2. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.

CAUTION:

Higher than the specified pressure may cause radiator damage.

Testing pressure : 157 kPa (1.6 kg/cm² , 23 psi)

Pressure should not drop.


OK or NG

OK >> GO TO 3.

NG >> Check the following for leak:

- Hose
- Radiator
- Water pump

Refer to [CO-25, "WATER PUMP"](#) .



DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

[VG33ER]


3. CHECK RADIATOR CAP

Apply pressure to cap with a tester and check radiator cap relief pressure.

Radiator cap relief pressure : 59 - 98 kPa (0.6 - 1.0 kg/cm² , 9 - 14 psi)

OK or NG

- OK >> GO TO 4.
- NG >> Replace radiator cap.



4. CHECK THERMOSTAT

1. Check valve seating condition at normal room temperatures. **It should seat tightly.**
2. Check valve opening temperature and valve lift.

Valve opening temperature : 76.5°C (170°F) [standard]


Valve lift : More than 10 mm/90°C (0.31 in/194°F)

3. Check if valve is closed at 5°C (9°F) below valve opening temperature.

For details, refer to [CO-28, "THERMOSTAT"](#) .


OK or NG

- OK >> GO TO 5.
- NG >> Replace thermostat.



5. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Check resistance as shown in the figure.




<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

OK or NG

- OK >> GO TO 6.
- NG >> Replace engine coolant temperature sensor.



DTC P0217 COOLANT OVERTEMPERATURE ENRICHMENT PROTECTION

[VG33ER]

6. CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to [EC-1444, "Main 12 Causes of Overheating"](#) .

>> INSPECTION END.

Main 12 Causes of Overheating

UBS008DS

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> Blocked radiator Blocked condenser Blocked radiator grille Blocked bumper 	<ul style="list-style-type: none"> Visual 	No blocking	—
	2	<ul style="list-style-type: none"> Coolant mixture 	<ul style="list-style-type: none"> Coolant tester 	50 - 50% coolant mixture	See MA-14, "ANTI-FREEZE COOLANT MIXTURE RATIO" .
	3	<ul style="list-style-type: none"> Coolant level 	<ul style="list-style-type: none"> Visual 	Coolant up to MAX level in reservoir tank and radiator filler neck	See MA-26, "Changing Engine Coolant" .
	4	<ul style="list-style-type: none"> Radiator cap 	<ul style="list-style-type: none"> Pressure tester 	59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See CO-23, "System Check" .
ON*1	5	<ul style="list-style-type: none"> Coolant leaks 	<ul style="list-style-type: none"> Visual 	No leaks	See CO-23, "System Check" .
ON*1	6	<ul style="list-style-type: none"> Thermostat 	<ul style="list-style-type: none"> Touch the upper and lower radiator hoses 	Both hoses should be hot	See CO-28, "THERMOSTAT" .
ON*1	7	<ul style="list-style-type: none"> Cooling fan (Crankshaft driven) 	<ul style="list-style-type: none"> Visual 	Operating	See CO-32, "COOLING FAN (CRANKSHAFT DRIVEN)" .
OFF	8	<ul style="list-style-type: none"> Combustion gas leak 	<ul style="list-style-type: none"> Color checker chemical tester 4 Gas analyzer 	Negative	—
ON*2	9	<ul style="list-style-type: none"> Coolant temperature gauge 	<ul style="list-style-type: none"> Visual 	Gauge less than 3/4 when driving	—
		<ul style="list-style-type: none"> Coolant overflow to reservoir tank 	<ul style="list-style-type: none"> Visual 	No overflow during driving and idling	See MA-26, "Changing Engine Coolant" .
OFF*3	10	<ul style="list-style-type: none"> Coolant return from reservoir tank to radiator 	<ul style="list-style-type: none"> Visual 	Should be initial level in reservoir tank	See CO-22, "COOLING SYSTEM" .
OFF	11	<ul style="list-style-type: none"> Cylinder head 	<ul style="list-style-type: none"> Straight gauge feeler gauge 	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-100, "CYLINDER HEAD" .
	12	<ul style="list-style-type: none"> Cylinder block and pistons 	<ul style="list-style-type: none"> Visual 	No scuffing on cylinder walls or piston	See EM-130, "CYLINDER BLOCK" .

*1: Engine running at 3,000 rpm for 10 minutes.

*2: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*3: After 60 minutes of cool down time.

For more information, refer to [CO-21, "OVERHEATING CAUSE ANALYSIS"](#) .

DTC P0299 SUPERCHARGER FUNCTION

PFP:14110

On Board Diagnosis Logic

UBS008DT

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0299	Supercharger function	ECM detects that amount of fuel injected is smaller than the specified value when supercharger is operating.	<ul style="list-style-type: none"> ● Supercharger ● Supercharger driving belt ● Stuck open of supercharger bypass valve ● Clogging, cracks or improper connection of vacuum hose

DTC Confirmation Procedure

UBS008DU

WITH CONSULT-II

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

1. Turn ignition switch “ON” and select “DATA MONITOR” mode with CONSULT-II.
2. Start engine.
3. Maintain the following conditions for at least 5 seconds.

ENG SPEED	Model with A/T: 3,200 - 4,400 rpm (A constant rotation is maintained.) Model with M/T: 3,600 - 4,400 rpm (A constant rotation is maintained.)
VHCL SPEED SE	More than 64 km/h (40 MPH)
THRTL POS SEN	Model with A/T: More than 2.53V Model with M/T: More than 2.30V

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

4. If 1st trip DTC is detected, go to [EC-1446, "Diagnostic Procedure"](#) .

WITH GST

Follow the procedure “WITH CONSULT-II” above.

Diagnostic Procedure

1. CHECK SUPERCHARGER BYPASS VALVE CONTROL SOLENOID VALVE

 **With CONSULT-II**


1. Stop the engine and turn ignition switch "ON".
2. Perform "SCB/V CONT SOL/V" in "ACTIVE TEST" mode.

ACTIVE TEST	
SCB/V CONT SOL/V	ON
MONITOR	
ENG SPEED	XXXrpm
IACV-AAC/V	XXX%

PBIB1439E

3. Check air passage continuity and operation delay time under the following conditions.


Conditions	Air passage continuity between A and B	Air passage continuity between A and C
ON	Yes	No
OFF	No	Yes



 **With GST**

Check air passage continuity and operation delay time under the following conditions

Conditions	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes



OK or NG

- OK >> GO TO 2.
- NG >> Replace the supercharger bypass valve control solenoid valve.

2. CHECK SUPERCHARGER BYPASS VALVE ACTUATOR FOR PROPER OPERATION

1. Stop the engine
2. Start the engine and keep it at idle speed.
3. Stop the engine again.
4. Check the supercharger bypass valve actuator operation when the engine starts and stops.

Does supercharge bypass valve actuator operate properly

Yes or No

- Yes >> GO TO 3.
- No >> Replace supercharger bypass valve actuator.

3. CHECK SUPERCHARGER DRIVING BELT

1. Visually check the supercharger driving belt for damage or worn.
2. Start engine and keep it at idle speed.
3. Check the supercharger driving belt for skipping.

Is driving belt skipping, damaged or worn?

Yes or No

- Yes >> Replace the supercharger drive belt.
No >> GO TO 4.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6 CYLINDER MISFIRE

[VG33ER]

DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6 CYLINDER MISFIRE

PFP:00000

On Board Diagnosis Logic

UBS008DW

When a misfire occurs, engine speed will fluctuate. If the engine speed fluctuates enough to cause the CKP sensor signal to vary, ECM can determine that a misfire is occurring.

Sensor	Input Signal to ECM	ECM function
Crankshaft position sensor (OBD)	Engine speed	On board diagnosis of misfire

The misfire detection logic consists of the following two conditions.

- One Trip Detection Logic (Three Way Catalyst Damage)**
 On the first trip that a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MIL will blink.
 When a misfire condition occurs, the ECM monitors the CKP sensor signal every 200 engine revolutions for a change.
 When the misfire condition decreases to a level that will not damage the TWC, the MIL will turn off.
 If another misfire condition occurs that can damage the TWC on a second trip, the MIL will blink.
 When the misfire condition decreases to a level that will not damage the TWC, the MIL will remain on.
 If another misfire condition occurs that can damage the TWC, the MIL will begin to blink again.
- Two Trip Detection Logic (Exhaust quality deterioration)**
 For misfire conditions that will not damage the TWC (but will affect vehicle emissions), the MIL will only light when the misfire is detected on a second trip. During this condition, the ECM monitors the CKP sensor signal every 1,000 engine revolutions.
 A misfire malfunction can be detected on any one cylinder or on multiple cylinders.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0300	Multiple cylinder misfire detected	Multiple cylinder misfire.	<ul style="list-style-type: none"> ● Improper spark plug ● Insufficient compression ● Incorrect fuel pressure ● The injector circuit is open or shorted ● Fuel injectors ● Intake air leak ● The ignition secondary signal circuit is open or shorted ● Lack of fuel ● Signal plate or flywheel ● Heated oxygen sensor 1 ● Incorrect PCV hose connection
P0301	No. 1 cylinder misfire detected	No. 1 cylinder misfires.	
P0302	No. 2 cylinder misfire detected	No. 2 cylinder misfires.	
P0303	No. 3 cylinder misfire detected	No. 3 cylinder misfires.	
P0304	No. 4 cylinder misfire detected	No. 4 cylinder misfires.	
P0305	No. 5 cylinder misfire detected	No. 5 cylinder misfires.	
P0306	No. 6 cylinder misfire detected	No. 6 cylinder misfires.	

DTC Confirmation Procedure

UBS008DX

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

1. Turn ignition switch ON, and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF and wait at least 5 seconds.
4. Start engine again and drive at 1,500 to 3,000 rpm for at least 3 minutes.

Hold the accelerator pedal as steady as possible.

NOTE:

Refer to the freeze frame data for the test driving conditions.

5. If 1st trip DTC is detected, go to [EC-1449, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF
B/FUEL SCHDL	XXX msec

SEF213Y

Ⓟ WITH GST

Follow the procedure "With CONSULT-II".

Diagnostic Procedure

UBS008DY

1. CHECK FOR INTAKE AIR LEAK

1. Start engine and run it at idle speed.
2. Listen for the sound of the intake air leak.

OK or NG

- OK >> GO TO 2.
- NG >> Discover air leak location and repair.

2. CHECK FOR EXHAUST SYSTEM CLOGGING

Stop engine and visually check exhaust tube, three way catalyst and muffler for dents.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace it.

3. PERFORM POWER BALANCE TEST

With CONSULT-II

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step


SEF070Y

Without CONSULT-II

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes or No

- Yes >> GO TO 4.
 No >> GO TO 7.




4. CHECK INJECTOR

Does each injector make an operating sound at idle?

Yes or No

- Yes >> GO TO 5.
 No >> Check injector(s) and circuit(s). Refer to [EC-1707](#), "[INJECTOR CIRCUIT](#)".




5. CHECK IGNITION SPARK

1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 6.




6. CHECK IGNITION WIRES

1. Inspect wires for cracks, damage, burned terminals and for improper fit.
2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks.

Resistance:

Cylinder No.	Resistance kΩ [at 25°C (77°F)]
1	Approx. 6.5
2	Approx. 10.0
3	Approx. 8.5
4	Approx. 12.5
5	Approx. 8.5
6	Approx. 11.0



If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.

OK or NG

- OK >> Check the following:
- Distributor rotor head for incorrect parts
 - Ignition coil, power transistor and their circuits
- Refer to [EC-1701, "IGNITION SIGNAL"](#).


NG >> Replace.

7. CHECK SPARK PLUGS

Remove the spark plugs and check for fouling, etc.

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace spark plug(s) with standard type one(s). For spark plug type, refer to [MA-32, "Changing Spark Plugs"](#).



8. CHECK COMPRESSION PRESSURE

Refer to [EM-100, "Measurement of Compression"](#) .

- Check compression pressure.

Standard	: 1,196 kPa (12.2 kg/cm² , 173 psi)/300 rpm
Minimum	: 883 kPa (9.0 kg/cm² , 128 psi)/300 rpm
Difference between each cylinder	: 98 kPa (1.0 kg/cm² , 14 psi)/300 rpm

OK or NG

OK >> GO TO 9.

NG >> Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

9. CHECK FUEL PRESSURE


1. Install any parts removed.
2. Release fuel pressure to zero.
Refer to [EC-1207, "FUEL PRESSURE RELEASE"](#) .
3. Install fuel pressure gauge and check fuel pressure. Refer to [EC-1207, "Fuel Pressure Check"](#) .

At idle : Approx. 235 kPa (2.4 kg/cm² , 34 psi)

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.



10. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-1716, "FUEL PUMP CIRCUIT"](#) .)
- Fuel pressure regulator (Refer to [EC-1209, "Fuel Pressure Regulator Check"](#) .)
- Fuel lines (Refer to [MA-28, "Checking Fuel Lines"](#) .)
- Fuel filter for clogging

>> Repair or replace.

11. CHECK IGNITION TIMING

Check the following items. Refer to [EC-1237, "Basic Inspection"](#) .

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

OK or NG

OK (With CONSULT-II)>>GO TO 12.

OK (Without CONSULT-II)>>GO TO 13.

NG >> Adjust ignition timing.

A
EC
C
D
E
F
G
H
I
J
K
L
M

12. CHECK HEATED OXYGEN SENSOR 1

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V


SEF967Y

5. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown left:
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5	
	HO2S1 MNTR (B1)	R	L	R	L	R	L
Bank 2	cycle	1	2	3	4	5	
	HO2S1 MNTR (B2)	R	L	R	L	R	L

R means HO2S1
MNTR (B1)/(B2) indicates RICH
L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 14.
- NG >> Replace malfunctioning heated oxygen sensor 1.

13. CHECK HEATED OXYGEN SENSOR 1 (BANK1)(BANK2)

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 (bank1 sensor signal) or 51 (bank2 sensor signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.


1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 14.
- NG >> Replace malfunctioning heated oxygen sensor 1.



14. CHECK MASS AIR FLOW SENSOR

Ⓜ **With CONSULT-II**

Check mass air flow sensor signal in "DATA MONITOR" mode with CONSULT-II.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

Ⓜ **With GST**

Check mass air flow sensor signal in MODE 1 with GST.

3.3 - 4.8 g-m/sec : at idling
12.0 - 14.9 g-m/sec : at 2,500 rpm

OK or NG

- OK >> GO TO 15.
- NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-1317, "DTC P0101 MAF SENSOR"](#) .

15. CHECK SYMPTOM MATRIX CHART

Check items on the rough idle symptom in "Symptom Matrix Chart", [EC-1250](#) .

OK or NG

- OK >> GO TO 16.
- NG >> Repair or replace.

16. ERASE THE 1ST TRIP DTC

Some tests may cause a 1st trip DTC to be set.

Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to [EC-1223, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .

>> GO TO 17.

**DTC P0300 - P0306 MULTIPLE CYLINDER MISFIRE, NO. 1 - 6 CYLINDER MIS-
FIRE**

[VG33ER]

17. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.


DTC P0327, P0328 KS

PF2:22060

Component Description

UBS008DZ

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.



UBS008E0

On Board Diagnosis Logic

The MIL will not light up for these diagnoses.

DTC No.	Trouble diagnosis name	DTC detected condition	Possible cause
P0327	Knock sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Knock sensor
P0328	Knock sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

UBS008E1

NOTE:


If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
2. Start engine and run it for at least 5 seconds at idle speed.
3. If DTC is detected, go to [EC-1459, "Diagnostic Procedure"](#) .






WITH GST

Follow the procedure “With CONSULT-II”.

Wiring Diagram

EC-KS-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
64	W	Knock sensor	[Engine is running] ● Idle speed	Approximately 2.5V

Diagnostic Procedure

UBS008E3

1. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check resistance between ECM terminal 64 and engine ground.

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

Resistance : Approximately 500 - 620 kΩ [at 25°C (77°F)]

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

2. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-II

1. Disconnect knock sensor harness connector.
2. Check harness continuity between ECM terminal 64 and knock sensor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connector F37, F101
- Harness for open or short between ECM and knock sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK KNOCK SENSOR

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 M Ω .

1. Disconnect knock sensor harness connector.
2. Check resistance between terminal 1 and ground.


Resistance: 500 - 620 k Ω [at 25°C (77°F)]

CAUTION:

Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.

OK or NG


- OK >> GO TO 5.
 NG >> Replace knock sensor.



5. RETIGHTEN GROUND SCREWS

Loose and retighten engine ground screws.

>> GO TO 6.



6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0335 CKP SENSOR (OBD)

PF2:23731

Component Description

UBS008E5

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.



When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system. It is used only for the on board diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS008E6

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> Tachometer: Connect Run engine and compare tachometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value.

On Board Diagnosis Logic

UBS008E7

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335	Crankshaft position sensor (OBD) circuit	<ul style="list-style-type: none"> The proper pulse signal from the crankshaft position sensor (OBD) is not sent to ECM while the engine is running at the specified engine speed. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted) Crankshaft position sensor (OBD)

DTC Confirmation Procedure


UBS008E8

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

- Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- Start engine and run it for at least 15 seconds at idle speed.
- If 1st trip DTC is detected, go to [EC-1464, "Diagnostic Procedure"](#).



 **WITH GST**

Follow the procedure "With CONSULT-II".


DTC P0335 CKP SENSOR (OBD)

[VG33ER]




UBS008E9

Wiring Diagram

EC-CKPS-01



A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M



DTC P0335 CKP SENSOR (OBD)

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (AC Voltage)
47	L	Crankshaft position sensor (OBD)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1 - 2V★ (AC range)</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>3 - 4V★ (AC range)</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

UBS008EA

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK CKP SENSOR (OBD) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Disconnect crankshaft position (CKP) sensor (OBD) and ECM harness connectors.
2. Check continuity between ECM terminal 47 and sensor terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F38, F102
- Harness for open or short between ECM and crankshaft position sensor (OBD)

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK CKP SENSOR (OBD) GROUND CIRCUIT FOR OPEN AND SHORT

1. Reconnect ECM harness connector.
2. Check harness continuity between sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART


Check the following.

- Harness connectors F38, F102
- Harness for open between crankshaft position sensor (OBD) and ECM

>> Repair open circuit or short to power in harness or connectors.

6. CHECK CRANKSHAFT POSITION SENSOR (OBD)

1. Disconnect crankshaft position sensor (OBD) harness connector.
2. Loosen the fixing bolt of the sensor.
3. Remove the sensor.
4. Visually check the sensor for chipping.




5. Check resistance as shown in the figure.

Resistance : Approximately 512 - 632Ω [at 20°C (68°F)]

OK or NG

- OK >> GO TO 7.
- NG >> Replace crankshaft position sensor (OBD).



7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0340 CMP SENSOR

Component Description

The camshaft position sensor is a basic component of the engine control system. It monitors engine speed and piston position. These input signals to the ECM are used to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for a 1° (POS) signal and 6 slits for a 120° (REF) signal. The wave-forming circuit consists of Light Emitting Diodes (LED) and photo diodes.



The rotor plate is positioned between the LED and the photo diode. The LED transmits light to the photo diode. As the rotor plate turns, the slits cut the light to generate rough-shaped pulses. These pulses are converted into on-off signals by the wave-forming circuit and sent to the ECM.

The distributor is not repairable and must be replaced as an assembly except distributor cap and rotor head.

NOTE:

The rotor screw which secures the distributor rotor head to the distributor shaft must be torqued properly.

 : **3.6±0.3 N·m (37±3 kg-cm, 32±3 in-lb)**



On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0340	Camshaft position sensor circuit	A)	<ul style="list-style-type: none"> Either 1° or 120° signal is not sent to ECM for the first few seconds during engine cranking. 	<ul style="list-style-type: none"> Harness or connectors (The CMP sensor circuit is open or shorted) Camshaft position sensor Starter motor (Refer to SC-9, "STARTING SYSTEM" .) Starting system circuit (Refer to SC-9, "STARTING SYSTEM" .) Dead (Weak) battery
		B)	<ul style="list-style-type: none"> Either 1° or 120° signal is not sent to ECM often enough while the engine speed is higher than the specified engine speed. 	
		C)	<ul style="list-style-type: none"> The relation between 1° and 120° signal is not in the normal range during the specified engine speed. 	

DTC Confirmation Procedure

NOTE:

- Perform "PROCEDURE FOR MALFUNCTION A" first. If DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B AND C".
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

PROCEDURE FOR MALFUNCTION A

 **WITH CONSULT-II**

1. Turn ignition switch ON.

DTC P0340 CMP SENSOR

[VG33ER]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Crank engine for at least 2 seconds.
4. If 1st trip DTC is detected, go to [EC-1471, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".

PROCEDURE FOR MALFUNCTION B AND C

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and run it for at least 2 seconds at idle speed.
4. If 1st trip DTC is detected, go to [EC-1471, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".

DTC P0340 CMP SENSOR




[VG33ER]

UBS008EF

Wiring Diagram

EC-CMPS-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



BBWA0482E





DTC P0340 CMP SENSOR

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	OR/B	ECM relay (Self shut-off)	[Engine is running] [Ignition switch OFF] ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			[Ignition switch OFF] ● A few seconds passed after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
44	PU	Camshaft position sensor (Reference signal)	[Engine is running] ● Idle speed	0.3 - 0.5V★ 
			[Engine is running] ● Engine speed is 2,000 rpm	0.3 - 0.5V★ 
49	LG	Camshaft position sensor (Position signal)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.5V★ 
			[Engine is running] ● Engine speed is 2,000 rpm	Approximately 2.5V★ 
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P		[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
117	B/P	Current return	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope).

Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK CMP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect camshaft position (CMP) sensor harness connector.
2. Turn ignition switch ON.




3. Check voltage between CMP sensor terminal 5 and ground with CONSULT-II or tester.

Voltage : **Battery voltage**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between camshaft position sensor and ECM relay
- Harness for open or short between camshaft position sensor and ECM

>> Repair harness or connectors.

4. CHECK CMP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between CMP sensor terminal 4 and ECM terminal 49, CMP sensor terminal 3 and ECM terminals 44, 48. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK CMP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between CMP sensor terminal 6 and engine ground.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART



Check the following.


- Harness for open between camshaft position sensor and engine ground

>> Repair open circuit or short to power in harness or connector.



7. CHECK CAMSHAFT POSITION SENSOR

1. Install any parts removed.
2. Start engine.
3. Check voltage between ECM terminals 44, 48 and ground, ECM terminal 49 and ground with DC range.
<Terminal 44 or 48 and engine ground>

Condition	Idle	2,000 rpm
Voltage	0.3 - 0.5V	0.3 - 0.5V
Pulse signal		



<Terminal 49 and engine ground>

Condition	Idle	2,000 rpm
Voltage	Approximately 2.5V	Approximately 2.5V
Pulse signal		

OK or NG

- OK >> GO TO 8.
- NG >> Replace distributor assembly with camshaft position sensor.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

**Removal and Installation
DISTRIBUTOR**

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

UBS008EH

DTC P0420, P0430 THREE WAY CATALYST FUNCTION

PFP:20905


On Board Diagnosis Logic

UBS008EI

The ECM monitors the switching frequency ratio of heated oxygen sensors 1 and 2.

A three way catalyst (Manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2. As oxygen storage capacity decreases, the heated oxygen sensor 2 switching frequency will increase.

When the frequency ratio of heated oxygen sensors 1 and 2 approaches a specified limit value, the three way catalyst (Manifold) malfunction is diagnosed.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0420 (Bank 1)	Catalyst system efficiency below threshold	<ul style="list-style-type: none"> ● Three way catalyst (Manifold) does not operate properly. ● Three way catalyst (Manifold) does not have enough oxygen storage capacity. 	<ul style="list-style-type: none"> ● Three way catalyst (Manifold) ● Exhaust tube ● Intake air leaks ● Fuel injectors ● Fuel injector leaks ● Spark plug ● Improper ignition timing
P0430 (Bank 2)			

DTC Confirmation Procedure

UBS008EJ

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

TESTING CONDITION

- **Do not hold engine speed for more than the specified minutes below.**
1. Start engine and warm it up to the normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 5 seconds.
 3. Start engine and keep the engine speed at between 3,500 and 4,000 rpm for at least one minute under no load.
 4. Let engine idle for one minute.
 5. Open engine hood.
 6. Select "DTC & SRT CONFIRMATION" then "SRT WORK SUPPORT" mode with CONSULT-II.
 7. Rev engine up to 2,000 to 3,000 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely. If "INCMP" of "CATALYST" changed to "COMPLT", go to step 10.
 8. Wait 5 seconds at idle.

SRT WORK SUPPORT	
CATALYST	INCMP
EVAP SYSTEM	INCMP
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
THRTL POS SEN	XXX V

SEF344Z

DTC P0420, P0430 THREE WAY CATALYST FUNCTION

[VG33ER]

- Rev engine up to 2,000 to 3,000 rpm and maintain it until "INCMP" of "CATALYST" changes to "CMPLT" (It will take approximately 5 minutes).
If not "CMPLT", perform the following.

SRT WORK SUPPORT	
CATALYST	CMPLT
EVAP SYSTEM	INCMP
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
THRTL POS SEN	XXX V

SEF345Z

- Select "SELF-DIAG RESULTS" mode with CONSULT-II.
- Confirm that the 1st trip DTC is not detected.
If the 1st trip DTC is detected, go to [EC-1477, "Diagnostic Procedure"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	

SEF560X

Overall Function Check

UBS008EK


Use this procedure to check the overall function of the three way catalyst (manifold). During this check, a DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

WITH GST

- Start engine and warm it up to the normal operation temperature.
- Turn ignition switch "OFF" and wait at least 10 seconds.
- Start engine and keep the engine speed at between 3,500 and 4,000 rpm for at least one minute under no load.
- Let engine idle for one minutes.
- Set voltmeters probes between ECM terminals 50 [HO2S1 (bank 1) signal], 51 [HO2S1 (bank 2) signal] and engine ground, and ECM terminals 56 [HO2S2 (bank 1) signal], 57 [HO2S2 (bank 2) signal] and engine ground.
- Keep engine speed at 2,000 rpm constant under no load.



DTC P0420, P0430 THREE WAY CATALYST FUNCTION

[VG33ER]

7. Make sure that the voltage switching frequency (high & low) between ECM terminals 56 and engine ground, or 57 and engine ground is very less than that of ECM terminals 50 and engine ground, or 51 and engine ground.

Switching frequency ratio = A/B

A: Heated oxygen sensor 2 voltage switching frequency


B: Heated oxygen sensor 1 voltage switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, it means three way catalyst (manifold) does not operate properly. Go to [EC-1477, "Diagnostic Procedure"](#).

NOTE:

If the voltage at terminal 50 or 51 does not switch periodically more than 5 times within 10 seconds at step 5, perform trouble diagnosis for "DTC P0133, P0153" first. (See [EC-1372, "DTC P0133, P0153 HO2S1"](#).)



Diagnostic Procedure

1. CHECK EXHAUST SYSTEM


Visually check exhaust tubes and muffler for dent.

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace it.

2. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before the three way catalyst (manifold).



OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.

3. CHECK INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.

4. CHECK IGNITION TIMING

Check the following items. Refer to [EC-1237, "Basic Inspection"](#).

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

OK or NG

- OK >> GO TO 5.
- NG >> Adjust ignition timing.


5. CHECK INJECTORS

1. Refer to [EC-1708, "Wiring Diagram"](#) , for circuit.
2. Stop engine and then turn ignition switch ON.
3. Check voltage between ECM terminals 102, 104, 106, 109, 111 and 113 and ground with CONSULT-II or tester.

Battery voltage should exist.

OK or NG

- OK >> GO TO 6.
 NG >> Perform [EC-1709, "Diagnostic Procedure"](#) .




6. CHECK IGNITION SPARK

1. Turn ignition switch OFF.
2. Disconnect ignition wire from spark plug.
3. Connect a known good spark plug to the ignition wire.
4. Place end of spark plug against a suitable ground and crank engine.
5. Check for spark.

OK or NG

- OK >> GO TO 8.
 NG >> GO TO 7.




7. CHECK IGNITION WIRES

1. Inspect wires for cracks, damage, burned terminals and for improper fit.
2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks.

Resistance:

Cylinder No.	Resistance kΩ [at 25°C (77°F)]
1	Approx. 6.5
2	Approx. 10.0
3	Approx. 8.5
4	Approx. 12.5
5	Approx. 8.5
6	Approx. 11.0



If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.

OK or NG

- OK >> Check ignition coil, power transistor and their circuits. Refer to [EC-1701, "IGNITION SIGNAL"](#) .
 NG >> Replace.

8. CHECK INJECTOR

1. Turn ignition switch OFF.
2. Remove injector assembly.
Keep fuel hose and all injectors connected to injector gallery.
3. Disconnect all ignition coil harness connectors.
4. Turn ignition switch ON.
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip)>>GO TO 9.

NG (Drips)>>Replace the injector(s) from which fuel is dripping.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

Trouble is fixed>>**INSPECTION END.**

Trouble is not fixed>>Replace three way catalyst (manifold).

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P0441 EVAP CONTROL SYSTEM


PFP:14950

System Description

UBS008EM

NOTE:

If DTC P0441 is displayed with P0510, perform trouble diagnosis for DTC P0510 first. (See [EC-1571](#), "DTC P0510 CLOSED TP SWITCH" .)



PBIB1438E

In this evaporative emission (EVAP) control system, purge flow occurs during non-closed throttle conditions. Purge volume is related to air intake volume. Under normal purge conditions (non-closed throttle), the EVAP canister purge volume control solenoid valve is open. Purge flow exposes the EVAP control system pressure sensor to intake manifold vacuum.

On Board Diagnosis Logic

UBS008EN

Under normal conditions (non-closed throttle), sensor output voltage indicates if pressure drop and purge flow are adequate. If not, a malfunction is determined.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0441	EVAP control system incorrect purge flow	EVAP control system does not operate properly, EVAP control system has a leak between intake manifold and EVAP control system pressure sensor.	<ul style="list-style-type: none"> ● EVAP canister purge volume control solenoid valve stuck closed ● EVAP control system pressure sensor and the circuit ● Loose, disconnected or improper connection of rubber tube ● Blocked rubber tube ● Blocked or bent rubber tube to MAP/ BARO switch solenoid valve ● Cracked EVAP canister ● EVAP canister purge volume control solenoid valve circuit ● Closed throttle position switch ● Blocked purge port ● EVAP canister vent control valve

DTC Confirmation Procedure

UBS008EO

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Start engine and let it idle for at least 70 seconds.
4. Select "PURG FLOW P0442" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
5. Touch "START".
If "COMPLETED" is displayed, go to step 7.
6. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 35 seconds.)

Selector lever	Suitable position
Vehicle speed	32 - 120 km/h (20 - 75 MPH)
ENG SPEED	500 - 3,400 rpm
B/FUEL SCHDL	1.0 - 11.0 msec
Engine coolant temperature	70 - 100°C (158 - 212°F)



If "TESTING" is not changed for a long time, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-1482, "Diagnostic Procedure"](#).

Overall Function Check


UBS008EP

Use this procedure to check the overall monitoring function of the EVAP control system purge flow monitoring. During this check, a DTC might not be confirmed.

WITH GST

1. Lift up drive wheels.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF, wait at least 5 seconds.
4. Start engine and wait at least 70 seconds.
5. Set voltmeter probes to ECM terminals 62 (EVAP control system pressure sensor signal) and ground.
6. Check EVAP control system pressure sensor value at idle speed and note it.
7. Establish and maintain the following conditions for at least 1 minute.

Air conditioner switch	ON
Headlamp switch	ON
Rear window defogger switch	ON
Engine speed	Approx. 3,000 rpm
Gear position	Any position other than "P", "N" or "R"



8. Verify that EVAP control system pressure sensor value stays 0.1V less than the value at idle speed (measured at step 6) for at least 1 second.
9. If NG, go to [EC-1482, "Diagnostic Procedure"](#) .

Diagnostic Procedure

UBS008EQ

1. CHECK EVAP CANISTER

1. Turn ignition switch OFF.
2. Check EVAP canister for cracks.


OK or NG

- OK (With CONSULT-II)>>GO TO 2.
- OK (Without CONSULT-II)>>GO TO 3.
- NG >> Replace EVAP canister.

2. CHECK PURGE FLOW

With CONSULT-II

1. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port and install vacuum gauge.
2. Start engine and let it idle.
3. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II.
4. Rev engine up to 2,000 rpm.



5. Touch "Qd" and "Qu" on CONSULT-II screen to adjust "PURG VOL CONT/V" opening.

PURG VOL CONT/V	VACUUM
100.0%	Should exist
0.0%	Should not exist

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 4.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V

SEF677Y

3. CHECK PURGE FLOW

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port and install vacuum gauge.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum gauge indication when revving engine up to 2,000 rpm.


Vacuum should exist.

6. Release the accelerator pedal fully and let idle.

Vacuum should not exist.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 4.



4. CHECK EVAP PURGE LINE


1. Turn ignition switch OFF.
2. Check EVAP purge line for improper connection or disconnection. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 5.
- NG >> Repair it.

5. CHECK EVAP PURGE HOSE AND PURGE PORT


1. Disconnect purge hoses connected to EVAP service port **A** and EVAP canister purge volume control solenoid valve **B**.
2. Blow air into each hose and EVAP purge port **C**.



3. Check that air flows freely.

OK or NG

- OK (with CONSULT-II)>>GO TO 6.
- OK (without CONSULT-II)>>GO TO 7.
- NG >> Repair or clean hoses and/or purge port.



6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.
If OK, inspection end. If NG, go to following step.

ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y


3. Check air passage continuity.

Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

If NG, replace the EVAP canister purge volume control solenoid valve.

OK or NG

- OK >> GO TO 8.
- NG >> Replace EVAP canister purge volume control solenoid valve.



7. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Without CONSULT-II


Check air passage continuity.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

If NG, replace the EVAP canister purge volume control solenoid valve.

OK or NG

- OK >> GO TO 8.
- NG >> Replace EVAP canister purge volume control solenoid valve.



8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

1. Turn ignition switch OFF.
2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG


- OK >> GO TO 9.
- NG >> Repair it.

9. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.
Water should not exist.

OK or NG

- OK >> GO TO 10.
- NG >> Replace EVAP control system pressure sensor.



10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION

Refer to [EC-1519, "DTC Confirmation Procedure"](#) or [EC-1513, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> GO TO 11.
- NG >> Replace EVAP control system pressure sensor.


11. CHECK EVAP CANISTER VENT CONTROL VALVE

With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.



Without CONSULT-II

1. Check air passage continuity and operation delay time under the following condition.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.


If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.

OK or NG

- OK (With CONSULT-II)>>GO TO 12.
- OK (Without CONSULT-II)>>GO TO 13.
- NG >> Replace EVAP canister vent control valve.



12. CHECK CLOSED THROTTLE POSITION SWITCH

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Check indication of "CLSD THL/P SW".
Measurement must be made with closed throttle position switch installed in vehicle.

Throttle valve conditions	CLSD THL/P SW
Completely closed	ON
Partially open or completely open	OFF

If NG, adjust closed throttle position switch.
Check the following items. Refer to [EC-1237, "Basic Inspection"](#) .

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

6. If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace closed throttle position switch.

OK or NG

- OK >> GO TO 14.
NG >> Replace throttle position switch with throttle position sensor.


13. CHECK CLOSED THROTTLE POSITION SWITCH

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect closed throttle position switch harness connector.
4. Check continuity between closed throttle position switch terminals 4 and 5.
Resistance measurement must be made with closed throttle position switch installed in vehicle.

Throttle valve conditions	Continuity
Completely closed	Yes
Partially open or completely closed	No

If NG, adjust closed throttle position switch.
Check the following items. Refer to [EC-1237, "Basic Inspection"](#)



Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

5. If it is impossible to adjust closed throttle position switch in “Basic Inspection”, replace closed throttle position switch.

OK or NG

- OK >> GO TO 14.
- NG >> Replace throttle position switch with throttle position sensor.

14. CHECK EVAP PURGE LINE

Inspect EVAP purge line (pipe and rubber tube). Check for evidence of leaks.
Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 15.
- NG >> Replace it.

15. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 16.

16. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END.

DTC P0442 EVAP CONTROL SYSTEM

PF1:14950

On Board Diagnosis Logic

UBS008ER


NOTE:

If DTC P0442 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See [EC-1650, "DTC P1448 EVAP CANISTER VENT CONTROL VALVE"](#) .)

This diagnosis detects leaks in the EVAP purge line using engine intake manifold vacuum.

If pressure does not increase, the ECM will check for leaks in the line between the fuel tank and EVAP canister purge volume control solenoid valve, under the following "Vacuum test" conditions.

The vacuum cut valve bypass valve is opened to clear the line between the fuel tank and the EVAP canister purge volume control solenoid valve. The EVAP canister vent control valve will then be closed to shut the EVAP purge line off. The EVAP canister purge volume control solenoid valve is opened to depressurize the EVAP purge line using intake manifold vacuum. After this occurs, the EVAP canister purge volume control solenoid valve will be closed.



PBIB1438E

DTC P0442 EVAP CONTROL SYSTEM

[VG33ER]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0442	EVAP control system small leak detected (negative pressure)	EVAP control system has a leak, EVAP control system does not operate properly.	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged ● water separator ● EVAP canister is saturated with water ● EVAP control system pressure sensor ● Fuel level sensor and the circuit ● Refueling EVAP vapor cut ● ORVR system leaks

A
EC
C
D
E
F
G
H
I
J

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS008ES

NOTE:

- If DTC P0442 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See [EC-1650, "DTC P1448 EVAP CANISTER VENT CONTROL VALVE"](#) .)
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


TESTING CONDITION:

- Perform "DTC WORK SUPPORT" when the fuel level is between 1/4 to 3/4 full and vehicle is placed on flat level surface.
- Open engine hood before conducting the following procedure.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
4. Make sure that the following conditions are met.
COOLAN TEMP/S: 0 - 32°C (32 - 90°F)
INT/A TEMP SE: More than 0°C (32°F)
5. Select "EVAP SML LEAK P0442" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.

Follow the instruction displayed.




NOTE:

If the engine speed cannot be maintained within the range displayed on the CONSULT-II screen, go to [EC-1237, "Basic Inspection"](#) .

6. Make sure that "OK" is displayed.
If "NG" is displayed, refer to [EC-1491, "Diagnostic Procedure"](#) .

NOTE:

Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.



 **WITH GST**

NOTE:

Be sure to read the explanation of [EC-1220, "Driving Pattern"](#) before driving vehicle.


1. Start engine.
2. Drive vehicle according to [EC-1220, "Driving Pattern"](#) .
3. Stop vehicle.
4. Select "MODE 1" with GST.
 - If SRT of EVAP system is not set yet, go to the following step.
 - If SRT of EVAP system is set, the result will be OK.
5. Turn ignition switch OFF and wait at least 5 seconds.
6. Start engine.
It is not necessary to cool engine down before driving.
7. Drive vehicle again according to the [EC-1220, "Driving Pattern"](#) .
8. Stop vehicle.
9. Select "MODE 3" with GST.
 - If P0442 is displayed on the screen, go to [EC-1491, "Diagnostic Procedure"](#) .
 - If P0441 is displayed on the screen, go to [EC-1482, "Diagnostic Procedure"](#) .
 - If P0442 and P0441 are not displayed on the screen, go to the following step.
10. Select "MODE 1" with GST.
 - If SRT of EVAP system is set, the result will be OK.
 - If SRT of EVAP system is not set, go to step 6.

Diagnostic Procedure**1. CHECK FUEL FILLER CAP DESIGN**

1. Turn ignition switch "OFF".
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

- OK >> GO TO 2.
 NG >> Replace with genuine NISSAN fuel filler cap.

**2. CHECK FUEL FILLER CAP INSTALLATION**

Check that the cap is tightened properly by rotating the cap clockwise.

OK or NG

- OK >> GO TO 3.
 NG >> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.
 ● Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION

Check for air releasing sound while opening the fuel filler cap.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE

Refer to [EC-1734, "FUEL TANK VACUUM RELIEF VALVE \(BUILT INTO FUEL FULLER CAP\)"](#).

OK or NG

- OK >> GO TO 5.
 NG >> Replace fuel filler cap with a genuine one.

A

EC

C

D

E

F

G

H

I

J



K

L

M

5. INSTALL THE PRESSURE PUMP

To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely.



NOTE:

Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking.

Models with CONSULT-II>>GO TO 6.


Models without CONSULT-II>>GO TO 7.

6. CHECK FOR EVAP LEAK**With CONSULT-II**

1. Turn ignition switch "ON".
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.
3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.




7. CHECK FOR EVAP LEAK

⊗ **Without CONSULT-II**

1. Turn ignition switch "OFF".
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace.



8. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 9.
- NG >> Replace water separator.



9. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

Refer to [EC-1647, "Diagnostic Procedure"](#).

OK or NG


- OK >> GO TO 10.
- NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connector.

10. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

- Yes >> GO TO 11.
- No (With CONSULT-II)>>GO TO 13.
- No (Without CONSULT-II)>>GO TO 14.



11. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK (With CONSULT-II)>>GO TO 13.
- OK (Without CONSULT-II)>>GO TO 14.
- NG >> GO TO 12.

12. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

13. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

With CONSULT-II

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode.
4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 15.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V

SEF677Y

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.
Vacuum should exist.

OK or NG

- OK >> GO TO 17.
NG >> GO TO 15.

15. CHECK VACUUM HOSE

Check vacuum hoses for clogging or disconnection. Refer to [EC-1190, "Vacuum Hose Drawing"](#) .

OK or NG

- OK >> GO TO 16.
NG >> Repair or reconnect the hose.

16. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ **With CONSULT-II**

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 18.
NG >> GO TO 17.


ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V

SEF677Y


17. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

 With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A or B
100.0%	Yes
0.0%	No




 Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A or B
12V direct supply between terminals 1 and 2	Yes
No supply	No



OK or NG

OK >> GO TO 18.

NG >> Replace EVAP canister purge volume control solenoid valve.


18. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance between fuel level sensor unit and fuel pump terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

OK or NG

- OK >> GO TO 19.
 NG >> Replace fuel tank temperature sensor.



19. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch "ON".
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 84 and ground.


Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kPa (-200 mmHg, -7.87 inHg)	2.1 to 2.5V lower than above value

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK >> GO TO 20.
 NG >> Replace EVAP control system pressure sensor.



20. CHECK EVAP PURGE LINE

Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 21.
 NG >> Repair or reconnect the hose.

21. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 22.

22. CHECK REFUELING EVAP VAPOR LINE

Check refueling EVAP vapor line between EVAP canister and fuel tank for clogging, kink, looseness and improper connection. For location, refer to [EC-1737, "ON BOARD REFUELING VAPOR RECOVERY \(ORVR\)"](#).

OK or NG

- OK >> GO TO 23.
 NG >> Repair or replace hoses and tubes.

23. CHECK SIGNAL LINE AND RECIRCULATION LINE

Check signal line and recirculation line between filler neck tube and fuel tank for clogging, kink, cracks, looseness and improper connection.

OK or NG

OK >> GO TO 24.

NG >> Repair or replace hoses, tubes or filler neck tube.

24. CHECK REFUELING CONTROL VALVE

[EC-1737, "ON BOARD REFUELING VAPOR RECOVERY \(ORVR\)"](#)

OK or NG

OK >> GO TO 25.

NG >> Replace refueling control valve with fuel tank.

25. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

OK >> GO TO 26.

NG >> Replace fuel level sensor unit.

26. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VG33ER]

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PF1:14920

Description SYSTEM DESCRIPTION


UBS008EU

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Throttle position switch	Closed throttle position		
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Fuel tank temperature sensor	Fuel temperature in fuel tank		
Vehicle speed sensor	Vehicle speed		

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



CONSULT-II Reference Value in Data Monitor Mode

UBS008EV

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PURG VOL C/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch OFF ● Shift lever: "N" ● No-load 	Idle (Vehicle stopped)	0%
		2,000 rpm	—

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VG33ER]

UBS008EW

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0444	EVAP canister purge volume control solenoid valve circuit open	An excessively low voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is open or shorted.) ● EVAP canister purge volume control solenoid valve
P0445	EVAP canister purge volume control solenoid valve circuit shorted	An excessively high voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is shorted.) ● EVAP canister purge volume control solenoid valve

DTC Confirmation Procedure

UBS008EX

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 13 seconds.
4. If 1st trip DTC is detected, go to [EC-1504, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".


DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VG33ER]


UBS008EY

Wiring Diagram


EC-PGC/V-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- ⬡EP⬡ : EARLY PRODUCTION
- ⬡LP⬡ : LATE PRODUCTION
- *1 ⬡EP⬡ : 13
- *1 ⬡LP⬡ : 15



Refer to the following.
 ⬡E43⬡ - SUPER MULTIPLE JUNCTION (SMJ)





DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	OR/B	ECM relay (Self shut-off)	[Engine is running] [Ignition switch OFF] <ul style="list-style-type: none"> For a few seconds after turning ignition switch OFF 	0 - 1.5V
			[Ignition switch OFF] <ul style="list-style-type: none"> A few seconds passed after turning ignition switch OFF 	BATTERY VOLTAGE (11 - 14V)
5	R/Y	EVAP canister purge volume control solenoid valve	[Engine is running] <ul style="list-style-type: none"> Idle speed 	BATTERY VOLTAGE (11 - 14V)★ 
			[Engine is running] <ul style="list-style-type: none"> Engine speed is 2,000 rpm (More than 100 seconds after starting engine) 	BATTERY VOLTAGE (11 - 14V)★ 
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
117	B/P	Current return	[Engine is running] <ul style="list-style-type: none"> Idle speed 	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

1. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch ON.




4. Check voltage between EVAP canister purge volume control solenoid valve terminal 1 and ground with CONSULT-II or tester.

Voltage : **Battery voltage**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F36, M81
- Harness connectors M65, E43
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay

>> Repair harness or connectors.

3. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 5 and solenoid terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK (With CONSULT-II)>>GO TO 5.
- OK (Without CONSULT-II)>>GO TO 6.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

Ⓜ With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 6.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V


SEF677Y

6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ With CONSULT-II

1. Check air passage continuity under the following conditions.

Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No




⊗ Without CONSULT-II

1. Check air passage continuity under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

OK or NG

- OK >> GO TO 7.
 NG >> Replace EVAP canister purge volume control solenoid valve.



**DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID
VALVE**

[VG33ER]

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0447 EVAP CANISTER VENT CONTROL VALVE

PFP:14935

Component Description



UBS008F1

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid valve responds to signals from the ECM. When the ECM sends an ON signal, the coil in the solenoid valve is energized. A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS008F2

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

UBS008F3

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0447	EVAP canister vent control valve circuit open	An improper voltage signal is sent to ECM through EVAP canister vent control valve.	<ul style="list-style-type: none"> ● Harness or connectors (The valve circuit is open or shorted.) ● EVAP canister vent control valve

DTC Confirmation Procedure

UBS008F4

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.

DTC P0447 EVAP CANISTER VENT CONTROL VALVE

[VG33ER]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 8 seconds.
4. If 1st trip DTC is detected, go to [EC-1510, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y



WITH GST

Follow the procedure "With CONSULT-II".


DTC P0447 EVAP CANISTER VENT CONTROL VALVE

[VG33ER]

Wiring Diagram

UBS008F5

EC-VENT/V-01




Refer to PG-POWER.

— : Detectable line for DTC
 - - - : Non-detectable line for DTC

EP : EARLY PRODUCTION

LP : LATE PRODUCTION

*1 EP : 21
 LP : 23



Refer to the following.

E43 - SUPER
 MULTIPLE JUNCTION (SMJ)



WBWA0031E

DTC P0447 EVAP CANISTER VENT CONTROL VALVE

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
108	R/G	EVAP canister vent control valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS008F6

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK EVAP CANISTER VENT CONTROL VALVE CIRCUIT

 **With CONSULT-II**

1. Turn ignition switch "OFF" and then turn "ON".
2. Select "VENT CONTROL/V" in "ACTIVE TEST" mode with CONSULT-II.
3. Touch "ON/OFF" on CONSULT-II screen.
4. Check for operating sound of the valve.
Clicking noise should be heard.

OK or NG


- OK >> GO TO 7.
- NG >> GO TO 3.

ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 (B1)	XXX V
HO2S1 (B2)	XXX V
THRTL POS SEN	XXX V

SEF989Y

3. CHECK EVAP CANISTER VENT CONTROL VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect EVAP canister vent control valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M67, B101
- Harness connectors B113, C3
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between EVAP canister vent control valve and fuse

>> Repair harness or connectors.

5. CHECK EVAP CANISTER VENT CONTROL VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 108 and EVAP canister vent control valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M81, F36
- Harness for open or short between EVAP canister vent control valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK EVAP CANISTER VENT CONTROL VALVE


With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.

ACTIVE TEST	
VENT CONTROL/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 (B1)	XXX V
HO2S1 (B2)	XXX V
THRTL POS SEN	XXX V



SEF013Z

Without CONSULT-II


1. Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.



3.2 – 4.8 N·m
0.33 – 0.49 kg·m,
29 – 43 in·lb)

BBIA0309E

OK or NG

OK >> GO TO 8.

NG >> Replace EVAP canister vent control valve.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33ER]



DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

PF2:25085

Component Description

UBS008F7

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases. The EVAP control system pressure sensor is not used to control the engine system. It is used only for on board diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS008F8

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EVAP SYS PRES	● Ignition switch: ON	1.8 - 4.8V

On Board Diagnosis Logic

UBS008F9

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0452	EVAP control system pressure sensor low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● EVAP control system pressure sensor

DTC Confirmation Procedure

UBS008FA

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.

DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33ER]

4. Select "DATA MONITOR" mode with CONSULT-II.
5. Make sure that "FUEL T/TMP SE" is more than 0°C (32°F).
6. Start engine and wait at least 20 seconds.
7. If 1st trip DTC is detected, go to [EC-1516, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANTEMP/S	XXX °C
FUEL T/TMP SE	XXX °C

SEF194Y



WITH GST


1. Start engine and warm it up to normal operating temperature.
2. Check that voltage between ECM terminal 60 (Fuel tank temperature sensor signal) and ground is less than 4.2V.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and wait at least 20 seconds.
5. Select "MODE 7" with GST.
If 1st trip DTC is detected, go to [EC-1516, "Diagnostic Procedure"](#).

DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33ER]

UBS008FB


Wiring Diagram



EC-PRE/SE-01

- : Detectable line for DTC
- : Non-detectable line for DTC
- : EARLY PRODUCTION
- : LATE PRODUCTION
- *1 : 19
- : 21

A
EC
C
D
E
F
G
H
I
J
K
L
M



WBWA0032E

DTC P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
42	B/W	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	BR	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
62	Y	EVAP control system pressure sensor	[Ignition switch ON]	1.8 - 4.8V

Diagnostic Procedure


UBS008FC

1. CHECK RUBBER TUBE

1. Turn ignition switch "OFF".
2. Check rubber tube connected to the sensor for clogging, vent, kink, disconnection or improper connection.

OK or NG


- OK >> GO TO 2.
NG >> Reconnect, repair or replace.



2. RETIGHTEN GROUND SCREWS

1. Loosen and retighten engine ground screws.

>> GO TO 3.



3. CHECK CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check sensor harness connector for water.
Water should not exist.

OK or NG

- OK >> GO TO 4.
NG >> Repair or replace harness connector.


4. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "ON".
2. Check voltage between terminal 3 and ground with CONSULT-II or tester.

Voltage : Approximately 5V

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M81, F36
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair harness or connectors.

6. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between EVAP control system pressure sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair open circuit or short to power in harness or connectors.

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 62 and EVAP control system pressure sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between ECM and EVAP control system pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch "ON".
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.


Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kPa (-200 mmHg, -7.87 inHg)	2.1 to 2.5 V lower than above value

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK >> GO TO 11.
- NG >> Replace EVAP control system pressure sensor.



11. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33ER]



DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

PF2:25085

Component Description

UBS008FE

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases. The EVAP control system pressure sensor is not used to control the engine system. It is used only for on board diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS008FF

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EVAP SYS PRES	● Ignition switch: ON	1.8 - 4.8V

On Board Diagnosis Logic

UBS008FG

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0453	EVAP control system pressure sensor high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● EVAP control system pressure sensor ● EVAP canister vent control valve ● EVAP canister ● Water separator ● Rubber hose from EVAP canister vent control valve to water separator

DTC Confirmation Procedure

UBS008FH

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.

DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33ER]

4. Select "DATA MONITOR" mode with CONSULT-II.
5. Make sure that "FUEL T/TMP SE" is more than 0°C (32°F).
6. Start engine and wait at least 20 seconds.
7. If 1st trip DTC is detected, go to [EC-1522, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANTEMP/S	XXX °C
FUEL T/TMP SE	XXX °C

SEF194Y



WITH GST


1. Start engine and warm it up to normal operating temperature.
2. Check that voltage between ECM terminal 60 (Fuel tank temperature sensor signal) and ground is less than 4.2V.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and wait at least 20 seconds.
5. Select "MODE 7" with GST.
If 1st trip DTC is detected, go to [EC-1516, "Diagnostic Procedure"](#).

DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33ER]

UBS008F1


Wiring Diagram



EC-PRE/SE-01

- : Detectable line for DTC
- : Non-detectable line for DTC
- : EARLY PRODUCTION
- : LATE PRODUCTION
- *1 : 19
- : 21

A
EC
C
D
E
F
G
H
I
J
K
L
M



WBWA0032E

DTC P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
42	B/W	Sensors' power supply	[Ignition switch ON]	Approximately 5V
43	BR	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
62	Y	EVAP control system pressure sensor	[Ignition switch ON]	1.8 - 4.8V

Diagnostic Procedure


UBS008FJ

1. CHECK RUBBER TUBE

1. Turn ignition switch "OFF".
2. Check rubber tube connected to the sensor for clogging, vent, kink, disconnection or improper connection.

OK or NG


- OK >> GO TO 2.
NG >> Reconnect, repair or replace.



2. RETIGHTEN GROUND SCREWS

1. Loosen and retighten engine ground screws.

>> GO TO 3.



3. CHECK CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check sensor harness connector for water.
Water should not exist.

OK or NG

- OK >> GO TO 4.
NG >> Repair or replace harness connector.


4. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "ON".
2. Check voltage between terminal 3 and ground with CONSULT-II or tester.

Voltage : **Approximately 5V**

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M81, F36
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair harness or connectors.

6. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between EVAP control system pressure sensor terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 8.
NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between EVAP control system pressure sensor and ECM

>> Repair open circuit or short to power in harness or connectors.

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 62 and EVAP control system pressure sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 10.
NG >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M59, F27
- Harness for open or short between ECM and EVAP control system pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK EVAP CANISTER VENT CONTROL VALVE

With CONSULT-II

- Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
- Check air passage continuity and operation delay time under the following conditions.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.

Without CONSULT-II

- Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.



If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.

OK or NG

OK >> GO TO 11.

NG >> Replace EVAP canister vent control valve.



11. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

- Remove EVAP control system pressure sensor with its harness connector connected.
- Remove hose from EVAP control system pressure sensor.
- Turn ignition switch "ON".
- Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
- Check input voltage between ECM terminal 62 and ground.

Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kPa (-200 mmHg, -7.87 inHg)	2.1 to 2.5 V lower than above value


CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

OK >> GO TO 12.

NG >> Replace EVAP control system pressure sensor.



12. CHECK RUBBER TUBE

Check obstructed rubber tube connected to EVAP canister vent control valve.

OK or NG

- OK >> GO TO 13.
- NG >> Clean, repair or replace rubber tube.

13. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 14.
- NG >> Replace water separator.




14. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

- Yes >> GO TO 15.
- No >> GO TO 17.



15. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 16.

16. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

17. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P0455 EVAP CONTROL SYSTEM

PFP:14950


On Board Diagnosis Logic

UBS008FL

NOTE:

If DTC P0455 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. ([EC-1650, "DTC P1448 EVAP CANISTER VENT CONTROL VALVE"](#) .)

This diagnosis detects a very large leak (fuel filler cap fell off etc.) in EVAP system between the fuel tank and EVAP canister purge volume control solenoid valve.



PBIB1438E

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0455	EVAP control system gross leak detected	EVAP control system has a very large leak such as fuel filler cap fell off, EVAP control system does not operate properly.	<ul style="list-style-type: none"> ● Fuel filler cap remains open or fails to close. ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent. ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged. ● EVAP control system pressure sensor ● Refueling control valve ● ORVR system leaks

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS008FM

CAUTION:

Never remove fuel filter cap during the DTC confirmation procedure.

NOTE:


- If DTC P0455 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See [EC-1650, "DTC P1448 EVAP CANISTER VENT CONTROL VALVE"](#) .)
- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Perform "DTC WORK SUPPORT" when the fuel level is between 1/4 to 3/4 full and vehicle is placed on flat level surface.
- Open engine hood before conducting the following procedure.

WITH CONSULT-II


1. Tighten fuel filler cap securely until ratcheting sound is heard.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 5 seconds.
4. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
5. Make sure that the following conditions are met.
COOLAN TEMP/S: 0 - 32°C (32 - 90°F)
INT/A TEMP SE: More than 0°C (32°F)
6. Select "EVAP SML LEAK P0442" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
 Follow the instruction displayed.



NOTE:

If the engine speed cannot be maintained within the range displayed on the CONSULT-II screen, go to [EC-1237, "Basic Inspection"](#) .

7. Make sure that "OK" is displayed.
 If "NG" is displayed, select "SELF-DIAG RESULTS" mode with CONSULT-II and make sure that "EVAP GROSS LEAK [P0455] is displayed, refer to [EC-1530, "Diagnostic Procedure"](#).
 If P0442 is displayed, perform [EC-1491, "Diagnostic Procedure"](#).



WITH GST

NOTE:

Be sure to read the explanation of [EC-1220, "Driving Pattern"](#) before driving vehicle.

1. Start engine.
2. Drive vehicle according to [EC-1220, "Driving Pattern"](#).
3. Stop vehicle.
4. Select "MODE 1" with GST.
 - If SRT of EVAP system is not set yet, go to the following step.
 - If SRT of EVAP system is set, the result will be OK.
5. Turn ignition switch "OFF" and wait at least 5 seconds.
6. Start engine.
It is not necessary to cool engine down before driving.
7. Drive vehicle again according to [EC-1220, "Driving Pattern"](#).
8. Stop vehicle.
9. Select "MODE 3" with GST.
 - If P0455 is displayed on the screen, go to [EC-1530, "Diagnostic Procedure"](#).
 - If P0442 or P1442 is displayed on the screen, go to [EC-1491, "Diagnostic Procedure"](#) or [EC-1634, "Diagnostic Procedure"](#).
 - If P0441 is displayed on the screen, go to [EC-1482, "Diagnostic Procedure"](#).
 - If P0442, P0455 and P0441 are not displayed on the screen, go to the following step.
10. Select "MODE 1" with GST.
 - If SRT of EVAP system is set, the result will be OK.
 - If SRT of EVAP system is not set, go to step 6.

Diagnostic Procedure


UBS008FN

1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch OFF.
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

- OK >> GO TO 2.
 NG >> Replace with genuine NISSAN fuel filler cap.



2. CHECK FUEL FILLER CAP INSTALLATION

Check that the cap is tightened properly by rotating the cap clockwise.

OK or NG

OK >> GO TO 3.

NG >> 1. Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.
2. Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION

Check for air releasing sound while opening the fuel filler cap.

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP)

Refer to [EC-1734, "FUEL TANK VACUUM RELIEF VALVE \(BUILT INTO FUEL FULLER CAP\)"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace fuel filler cap with a genuine one.

5. CHECK EVAP PURGE LINE

Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks, improper connection or disconnection.

Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#) .

OK or NG

OK >> GO TO 6.

NG >> Repair or reconnect the hose.

6. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 7.

7. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

Refer to [EC-1650, "DTC Confirmation Procedure"](#) .


OK or NG

OK >> GO TO 8.

NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connector.


8. INSTALL THE PRESSURE PUMP

To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely.



NOTE:
Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking.

Models with CONSULT-II >> GO TO 9.
Models without CONSULT-II >> GO TO 10.




9. CHECK FOR EVAP LEAK

With CONSULT-II

1. Turn ignition switch ON.
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.
3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system.



4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 11.
NG >> Repair or replace.




10. CHECK FOR EVAP LEAK

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 12.
- NG >> Repair or replace.



11. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

Ⓜ With CONSULT-II

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode.
4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 14.
- NG >> GO TO 13.

ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y

12. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 15.
- NG >> GO TO 13.

13. CHECK VACUUM HOSE

Check vacuum hoses for clogging or disconnection. Refer to [EC-1190, "Vacuum Hose Drawing"](#) .

OK or NG

- OK (With CONSULT-II)>>GO TO 14.
- OK (Without CONSULT-II)>>GO TO 15.
- NG >> Repair or reconnect the hose.

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ **With CONSULT-II**

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.
If OK, inspection end. If NG, go to following step.

ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V


SEF985Y

3. Check air passage continuity.

Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

OK or NG



- OK >> GO TO 16.
- NG >> Replace EVAP canister purge volume control solenoid valve.



15. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

⊗ **Without CONSULT-II**
Check air passage continuity.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No



OK or NG

OK >> GO TO 16.



NG >> Replace EVAP canister purge volume control solenoid valve.

A
EC
C
D
E
F
G
H
I
J
K
L
M

16. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance between fuel level sensor unit terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.78 - 0.90




OK or NG

- OK >> GO TO 17.
- NG >> Replace fuel tank temperature sensor.


17. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch ON.
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.



5. Check input voltage between ECM terminal 62 and ground.

Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kPa (-200 mmHg, -7.87 inHg)	2.1 to 2.5V lower than above value



CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK >> GO TO 18.
- NG >> Replace EVAP control system pressure sensor.

18. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0456 EVAP CONTROL SYSTEM

PFP:14950

On Board Diagnosis Logic


UBS008FO

This diagnosis detects very small leaks in the EVAP line between fuel tank and EVAP canister purge volume control solenoid valve, using the intake manifold vacuum in the same way as conventional EVAP small leak diagnosis.

If ECM judges a leak which corresponds to a very small leak, the very small leak P0456 will be detected.

If ECM judges a leak equivalent to a small leak, EVAP small leak P0442 will be detected.

If ECM judges there are no leaks, the diagnosis will be OK.



DTC P0456 EVAP CONTROL SYSTEM

[VG33ER]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0456	Evaporative emission control system very small leak (negative pressure check)	<ul style="list-style-type: none"> ● EVAP system has a very small leak. ● EVAP system does not operate properly. 	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve and the circuit ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged ● Water separator ● EVAP canister is saturated with water ● EVAP control system pressure sensor ● Refueling control valve ● ORVR system leaks ● Fuel level sensor and the circuit ● Foreign matter caught in EVAP canister purge volume control solenoid valve

A
EC
C
D
E
F
G
H
I
J

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

K
L

DTC Confirmation Procedure

UBS008FP

CAUTION:

Never remove fuel filler cap during the DTC confirmation procedure.

M

NOTE:


- If DTC P0456 or P1456 is displayed with P0442, first perform trouble diagnosis for DTC P0456 or P1456.
- After repair, make sure that the hoses and clips are installed properly.
- If “DTC CONFIRMATION PROCEDURE” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Open engine hood before conducting following procedure.
- If any of following condition is met just before the DTC confirmation procedure, leave the vehicle for more than 1 hour.
 - Fuel filler cap is removed.
 - Refilled or drained the fuel.
 - EVAP component parts is/are removed.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Make sure the following conditions are met.
FUEL LEVEL SE: 1.08 - 0.2V
COOLAN TEMP/S: 0 - 35°C (32 - 95°F)
FUEL T/TMP SE: 0 - 32°C (32 - 90°F)
INT A/TEMP SE: More than 0°C (32°F)
 If NG, turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle) or refilling/draining fuel until the output voltage condition of the "FUEL LEVEL SE" meets within the range above and leave the vehicle for more than 1 hour. Then start from step 1).
3. Turn ignition switch "OFF" and wait at least 5 seconds.
4. Turn ignition switch "ON".
5. Select "EVAP V/S LEAK P0456/P1456" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
 Follow the instruction displayed.



6. Make sure that "OK" is displayed.
 If "NG" is displayed, refer to [EC-1541, "Diagnostic Procedure"](#).

NOTE:

- If the engine speed cannot be maintained within the range displayed on CONSULT-II screen, go to [EC-1237, "Basic Inspection"](#).
- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

Overall Function Check

UBS008FQ


WITH GST

Use this procedure to check the overall function of the EVAP very small leak function. During this check, a DTC might not be confirmed.

CAUTION:

- Never use compressed air, doing so may damage the EVAP system.
- Do not start engine.
- Do not exceeded 4.12 kPa (0.042 kg/cm², 0.6 psi).

1. Attach the EVAP service port adapter securely to the EVAP service port.
2. Set the pressure pump and a hose.
3. Also set a vacuum gauge via 3-way connector and a hose.
4. Turn ignition switch "ON".
5. Connect GST and select mode 8.
6. Using mode 8 control the EVAP canister vent control valve (close) and vacuum cut valve bypass valve (open).
7. Apply pressure and make sure the following conditions are satisfied.



Pressure to be applied: 2.7 kPa (20 mmHg, 0.79 inHg)

Time to be waited after the pressure drawn in to the EVAP system and the pressure to be dropped: 60 seconds and the pressure should not be dropped more than 0.4 kPa (3 mmHg, 0.12 inHg)

If NG, go to [EC-1541, "Diagnostic Procedure"](#) .

NOTE:

For more information, refer to GST instruction manual.

Diagnostic Procedure


UBS008FR

1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch "OFF".
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

- OK >> GO TO 2.
 NG >> Replace with genuine NISSAN fuel filler cap.

**2. CHECK FUEL FILLER CAP INSTALLATION**

Check that the cap is tightened properly by rotating the cap clockwise.

OK or NG

- OK >> GO TO 3.
 NG >> ● Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.
 ● Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION

Check for air releasing sound while opening the fuel filler cap.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE


Refer to [EC-1734, "FUEL TANK VACUUM RELIEF VALVE \(BUILT INTO FUEL FULLER CAP\)"](#)

OK or NG

- OK >> GO TO 5.
 NG >> Replace fuel filler cap with a genuine one.


5. INSTALL THE PRESSURE PUMP

To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely.



NOTE:
Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking.

Models with CONSULT-II >> GO TO 6.
Models without CONSULT-II >> GO TO 7.




6. CHECK FOR EVAP LEAK

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.
3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in the system.



4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 8.
NG >> Repair or replace.




7. CHECK FOR EVAP LEAK

⊗ **Without CONSULT-II**

1. Turn ignition switch "OFF".
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.



8. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A** , and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

Do not disassemble water separator.

OK or NG

- OK >> GO TO 9.
 NG >> Replace water separator.



9. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

Refer to [EC-1644, "DTC Confirmation Procedure"](#).

OK or NG


- OK >> GO TO 10.
 NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connector.

10. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Does water drain from the EVAP canister?

Yes or No

- Yes >> GO TO 11.
 No (With CONSULT-II)>>GO TO 13.
 No (Without CONSULT-II)>>GO TO 14.



11. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK (With CONSULT-II)>>GO TO 13.
 OK (Without CONSULT-II)>>GO TO 14.
 NG >> GO TO 12.

12. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

13. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

 **With CONSULT-II**

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform “PURG VOL CONT/V” in “ACTIVE TEST” mode.
4. Touch “Qu” on CONSULT-II screen to increase “PURG VOL CONT/V” opening to 100.0%.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 16.
 NG >> GO TO 15.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V

SEF677Y

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 15.

15. CHECK VACUUM HOSE

Check vacuum hoses for clogging or disconnection. Refer to [EC-1190, "Vacuum Hose Drawing"](#).

OK or NG

- OK (With CONSULT-II)>>GO TO 16.
- OK (Without CONSULT-II)>>GO TO 17.
- NG >> Repair or reconnect the hose.

16. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ **With CONSULT-II**

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 18.
- NG >> GO TO 17.


ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y


17. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A and B
100 %	Yes
0.0%	No



⊗ Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

OK or NG

OK >> GO TO 18.

NG >> Replace EVAP canister purge volume control solenoid valve.




18. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance between fuel level sensor unit terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

OK or NG

- OK >> GO TO 19.
- NG >> Replace fuel level sensor unit.



19. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch "ON".
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.


Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kPa (-200 mmHg, -7.87 inHg)	2.1 to 2.5V lower than above value

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK >> GO TO 20.
- NG >> Replace EVAP control system pressure sensor.



20. CHECK EVAP PURGE LINE

Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-1732. "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 21.
- NG >> Repair or reconnect the hose.

21. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 22.

22. CHECK FUEL LEVEL SENSOR

Refer to [DI-17. "FUEL LEVEL SENSOR UNIT CHECK"](#).

OK or NG

- OK >> GO TO 23.
- NG >> Replace fuel level sensor unit.

23. CHECK INTERMITTENT INCIDENT

- Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0460 FUEL LEVEL SENSOR


PF2:25060

Component Description

UBS008FS

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



SEF800Z

On Board Diagnosis Logic

UBS008FT

When the vehicle is parked, naturally the fuel level in the fuel tank is stable. It means that output signal of the fuel level sensor does not change. If ECM senses sloshing signal from the sensor, fuel level sensor malfunction is detected.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0460	Fuel level sensor circuit noise	Even though the vehicle is parked, a signal being varied is sent from the fuel level sensor to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Fuel level sensor

DTC Confirmation Procedure

UBS008FU

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait maximum of 2 consecutive minutes.
4. If 1st trip DTC is detected, go to [EC-1551, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
FUEL T/TMP SE	XXX °C
FUEL LEVEL SE	XXX V

SEF195Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P0460 FUEL LEVEL SENSOR

[VG33ER]

UBS008FV

Wiring Diagram

EC-FLS1-01



Refer to the following.
 (F29) - ELECTRICAL UNITS

WBWA0033E

DTC P0460 FUEL LEVEL SENSOR

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	G	Fuel level sensor	[Ignition switch ON]	Approximately 0 - 4.8V Output voltage varies with fuel level.
66	B	Fuel level sensor ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS008FW


1. CHECK FUEL LEVEL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit harness connector.
3. Turn ignition switch "ON".
4. Check voltage between fuel level sensor unit terminal 2 and ground with CONSULT-II or a tester.

Voltage: Approximately 12V

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, B103
- Harness for open or short between combination meter and fuel level sensor unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between fuel level sensor unit terminal 4 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check harness for open or short between fuel level sensor unit and ground.

>> Repair open circuit or short to power in harness or connectors.

5. CHECK FUEL LEVEL SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 46 and fuel level sensor unit terminal 2, ECM terminal 66 and ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, B013
- Harness connectors M81, F36
- Harness for open or short between ECM and ground

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

- OK >> GO TO 8.
NG >> Replace fuel level sensor unit.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

Removal and Installation FUEL LEVEL SENSOR

UBS008FX


Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

DTC P0461 FUEL LEVEL SENSOR

Component Description

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



UBS008FY

UBS008FZ

On Board Diagnosis Logic

Driving long distances naturally affect fuel gauge level.

This diagnosis detects the fuel gauge malfunction of the gauge not moving even after a long distance has been driven.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0461	Fuel level sensor circuit range/performance	The output signal of the fuel level sensor does not change within the specified range even though the vehicle has been driven a long distance.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Fuel level sensor

Overall Function Check

Use this procedure to check the overall function of the fuel level sensor function. During this check, a 1st trip DTC might not be confirmed.

WARNING:

When performing following procedure, be sure to observe the handling of the fuel. Refer to [FL-3, "FUEL TANK"](#).

TESTING CONDITION:

Before starting overall function check, preparation of draining fuel and refilling fuel is required.

WITH CONSULT-II

NOTE:

Start from step 11, if it is possible to confirm that the fuel cannot be drained by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) in advance.

1. Prepare a fuel container and a spare hose.
2. Release fuel pressure from fuel line, refer to [EC-1207, "FUEL PRESSURE RELEASE"](#).
3. Remove the fuel feed hose on the fuel level sensor unit.
4. Connect a spare fuel hose where the fuel feed hose was removed.
5. Turn ignition switch "OFF" and wait at least 5 seconds then turn "ON".
6. Select "FUEL LEVEL SE" in "DATA MONITOR" mode with CONSULT-II.
7. Check "FUEL LEVEL SE" output voltage and note it.
8. Select "FUEL PUMP" in "ACTIVE TEST" mode with CONSULT-II.
9. Touch "ON" and drain fuel approximately 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) and stop it.
10. Fill fuel into the fuel tank for 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal).
11. Check "FUEL LEVEL SE" output voltage and note it.
12. Check "FUEL LEVEL SE" output voltage and confirm whether the voltage changes more than 0.03V during step 7 to 11.

If NG, check the fuel level sensor, refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#).


DATA MONITOR	
MONITOR	NO DTC
FUEL T/TMP SE	XXX °C
FUEL LEVEL SE	XXX V

SEF195Y

 WITH GST
NOTE:

Start from step 11, if it is possible to confirm that the fuel cannot be drained by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) in advance.

1. Prepare a fuel container and a spare hose.
2. Release fuel pressure from fuel line, refer to [EC-1207, "FUEL PRESSURE RELEASE"](#) .
3. Remove the fuel feed hose on the fuel level sensor unit.
4. Connect a spare fuel hose where the fuel feed hose was removed.
5. Turn ignition switch "OFF".
6. Set voltmeters probe between ECM terminal 46 (fuel level sensor signal) and ground.
7. Turn ignition switch "ON".
8. Check voltage between ECM terminal 46 and ground and note it.
9. Drain fuel by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) from the fuel tank using proper equipment.
10. Fill fuel into the fuel tank for 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal).
11. Confirm that the voltage between ECM terminal 46 and ground changes more than 0.03V during step 8 - 10.
If NG, check component of fuel level sensor, refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .




DTC P0462, P0463 FUEL LEVEL SENSOR

Component Description

UBS008G1

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



UBS008G2

On Board Diagnosis Logic

ECM receives two signals from the fuel level sensor circuit.

One is fuel level sensor power supply circuit, and the other is fuel level sensor ground circuit.

This diagnosis indicates the former, to detect open or short circuit malfunction.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0462	Fuel level sensor circuit low input	An excessively low voltage is sent from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Fuel level sensor
P0463	Fuel level sensor circuit high input	An excessively high voltage is sent from the sensor is sent to ECM.	

DTC Confirmation Procedure

UBS008G3

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at ignition switch "ON".

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-1557, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
FUEL T/TMP SE	XXX °C
FUEL LEVEL SE	XXX V

SEF195Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P0462, P0463 FUEL LEVEL SENSOR

[VG33ER]


UBS008G4

Wiring Diagram

EC-FLS2-01



Refer to the following.
(F29) - ELECTRICAL UNITS



WBWA0034E

DTC P0462, P0463 FUEL LEVEL SENSOR

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	G	Fuel level sensor	[Ignition switch "ON"]	Approximately 0 - 4.8V Output voltage varies with fuel level.
66	B	Fuel level sensor ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS008G5


1. CHECK FUEL LEVEL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit harness connector.
3. Turn ignition switch "ON".
4. Check voltage between fuel level sensor unit terminal 2 and ground with CONSULT-II or tester.

Voltage: Approximately 12V

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M91, B103
- Harness for open or short between combination meter and fuel level sensor unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between fuel level sensor unit terminal 4 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check harness for open or short between fuel level sensor unit and ground.

>> Repair open circuit or short to power in harness or connectors.

5. CHECK FUEL LEVEL SENSOR INPUT CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 46 and fuel level sensor unit terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors 917, B103
- Harness connectors M81, F36
- Harness for open or short between ECM and fuel level sensor unit

>> Repair open circuit or short to ground or short to power in harness on connectors.

7. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

- OK >> GO TO 8.
NG >> Replace fuel level sensor unit.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

Removal and Installation
FUEL LEVEL SENSOR

UBS008G6

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .


DTC P0500 VSS

PFP:32702

Component Description

UBS008G7

The vehicle speed sensor is installed in the transmission. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.



On Board Diagnosis Logic

UBS008G8

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0500	Vehicle speed sensor	The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven.	<ul style="list-style-type: none"> ● Harness or connectors (The vehicle speed sensor circuit is open or shorted.) ● Vehicle speed sensor

DTC Confirmation Procedure

UBS008G9

CAUTION:
Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Steps 1 and 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

Ⓟ WITH CONSULT-II

1. Start engine.
2. Read "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position. If NG, go to [EC-1562, "Diagnostic Procedure"](#). If OK, go to following step.
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Warm engine up to normal operating temperature.
5. Maintain the following conditions for at least 60 consecutive seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
B/FUEL SCHDL	XXX msec
PW/ST SIGNAL	OFF
VHCL SPEED SE	XXX km/h

SEF196Y

END SPEED	More than 1,800 rpm (A/T models) More than 1,900 rpm (M/T models)
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	5.5 - 16.0 msec
Selector lever	Suitable position
PW/ST SIGNAL	OFF

6. If 1st trip DTC is detected, go to [EC-1562, "Diagnostic Procedure"](#).

Overall Function Check

UBS008GA

Use this procedure to check the overall function of the vehicle speed sensor circuit. During this check, a 1st trip DTC might not be confirmed.






WITH GST

1. Lift up drive wheels.
2. Start engine.
3. Read vehicle speed sensor signal in "MODE 1" with GST.
The vehicle speed sensor on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
4. If NG, go to [EC-1562, "Diagnostic Procedure"](#) .

Wiring Diagram

EC-VSS-01

A
EC
C
D
E
F
G
H
I
J
K
L
M




Refer to the following.
 (E43) - SUPER MULTIPLE JUNCTION (SMJ)
 (F29) - ELECTRICAL UNITS

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
29	G/B	Vehicle speed sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Lift up the vehicle. ● In 2nd gear position ● Vehicle speed is 40 km/h (25 MPH) 	<p>2 - 3V★</p>  <p>SEF996U</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

UBS008GC

1. CHECK VEHICLE SPEED SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and combination meter harness connector.
3. Check harness continuity between ECM terminal 29 and combination meter terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Harness for open or short between ECM and combination meter

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK SPEEDOMETER FUNCTION

Make sure that speedometer functions properly.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. CHECK SPEEDOMETER CIRCUIT FOR OPEN AND SHORT

Check the following.

- Harness connectors M58, F28
- Harness connectors F43, F201
- Harness for open or short between combination meter and vehicle speed sensor

OK or NG

- OK >> Check combination meter and vehicle speed sensor. Refer to [DI-3, "METERS AND GAUGES"](#).
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P0505 ISC SYSTEM

**Description
SYSTEM DESCRIPTION**


Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Idle air control	IACV-AAC valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Park/neutral position (PNP) switch	Park/neutral position		
Air conditioner switch	Air conditioner operation		
Power steering oil pressure switch	Power steering load signal		
Battery	Battery voltage		
Vehicle speed sensor	Vehicle speed		
Ambient air temperature switch	Ambient air temperature		
Intake air temperature sensor	Intake air temperature		

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which bypasses the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner and power steering).

COMPONENT DESCRIPTION

IACV-AAC Valve

The IACV-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
IACV-AAC/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	10 - 20%
		2,000 rpm	—

On Board Diagnosis Logic

UBS008GG

DTC No.	Trouble diagnosis name		DTC detecting condition	Possible cause
P0505	A)	Idle speed control system circuit	The IACV-AAC valve does not operate properly	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open) ● IACV-AAC valve
	B)	Idle speed control system RPM lower than expected	The IACV-AAC valve does not operate properly	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open) ● IACV-AAC valve
	C)	Idle speed control system RPM higher than expected	The IACV-AAC valve does not operate properly	<ul style="list-style-type: none"> ● Harness or connectors (The IACV-AAC valve circuit is open) ● IACV-AAC valve

DTC Confirmation Procedure

UBS008GH

NOTE:

- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.
- Perform “PROCEDURE FOR MALFUNCTION A” first. If 1st trip DTC cannot confirmed, perform “PROCEDURE FOR MALFUNCTION B AND C”.


PROCEDURE FOR MALFUNCTION A

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch “ON”.

With CONSULT-II

1. Turn ignition switch ON.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Wait at least 2 seconds.
4. If 1st trip DTC is detected, go to [EC-1568, "Diagnostic Procedure"](#) .



With GST

Follow the procedure “With CONSULT-II”.

PROCEDURE FOR MALFUNCTION B AND C

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch “OFF” and wait at least 5 seconds.

DTC P0505 ISC SYSTEM

[VG33ER]

3. Turn ignition switch "ON" again and select "DATA MONITOR" mode with CONSULT-II.
4. Start engine and run it for at least 1 minute at idle speed.
5. If 1st trip DTC is detected, go to [EC-1568, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y




With GST

Follow the procedure "With CONSULT-II".



Wiring Diagram

EC-AAC/V-01

A
EC
C
D
E
F
G
H
I
J
K
L
M





— : Detectable line for DTC
 — : Non-detectable line for DTC
 EP : Early production
 LP : Late production
 *1 EP : 14
 LP : 16



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	OR/L	IACV-AAC valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>8 - 11V★</p>  <p style="text-align: right; font-size: small;">SEF005V</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 3,000 rpm 	<p>7 - 10V★</p>  <p style="text-align: right; font-size: small;">SEF692W</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

UBS008GJ

1. CHECK IACV-AAC VALVE POWER SUPPLY CIRCUIT

1. Stop engine.
2. Disconnect IACV-AAC valve harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Harness connectors F37, F101
- Fuse block (J/B) connector M27
- 10A fuse
- Harness for open or short between IACV-AAC valve and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK IACV-AAC VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 101 and IACV-AAC valve terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F101, F37
- Harness for open or short between IACV-AAC valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK IACV-AAC VALVE

1. Disconnect IACV-AAC valve harness connector.
2. Remove IACV-AAC valve.
- Check IACV-AAC valve resistance.

Resistance : Approximately 10Ω [at 20°C (68°F)]


- Check plunger for seizing or sticking.
- Check for broken spring.
- 3. Supply battery voltage between IACV-AAC valve connector terminals.

Plunger should move.

OK or NG

OK >> GO TO 6.

NG >> Replace IACV-AAC valve.



6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation

IACV-AAC VALVE

UBS008GK

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

DTC P0510 CLOSED TP SWITCH


PFP:22620

Component Description

UBS008GZ

A closed throttle position switch and wide open throttle position switch are built into the throttle position sensor unit. The wide open throttle position switch is used only for A/T control.

When the throttle valve is in the closed position, the closed throttle position switch sends a voltage signal to the ECM. The ECM only uses this signal to open or close the EVAP canister purge volume control solenoid valve when the throttle position sensor is malfunctioning.



CONSULT-II Reference Value in Data Monitor Mode

UBS008H0

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
CLSD THL/P SW	● Engine: After warming up, idle the engine	Throttle valve: Idle position ON
		Throttle valve: Slightly open OFF

On Board Diagnosis Logic

UBS008H1

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0510	Closed throttle position switch	Battery voltage from the closed throttle position switch is sent to ECM with the throttle valve opened	<ul style="list-style-type: none"> ● Harness or connectors (The closed throttle position switch circuit is open or shorted) ● Closed throttle position switch ● Throttle position sensor

DTC Confirmation Procedure

UBS008H2

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF, wait at least 10 seconds and then start engine.
3. Select "CLSD THL/P SW" in "DATA MONITOR" mode.
4. Check the signal under the following conditions.

Condition	Signal indication
Throttle valve: Idle position	ON
Throttle valve: Slightly open	OFF

If the result is NG, go to [EC-1574, "Diagnostic Procedure"](#) .
If OK, go to following step.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
CLSD THL/P SW	ON


SEF197Y

DTC P0510 CLOSED TP SWITCH

[VG33ER]

5. Select "DATA MONITOR" mode with CONSULT-II.
6. Drive the vehicle for at least 5 consecutive seconds under the following condition.

THRTL POS SEN	More than 2.5V
VHCL SPEED SE	More than 5 km/h (3 MPH)
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.



7. If 1st trip DTC is detected, go to [EC-1574, "Diagnostic Procedure"](#).

Overall Function Check

UBS008H3


Use this procedure to check the overall function of the closed throttle position switch circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Check the voltage between ECM terminal 28 (Closed throttle position switch signal) and ground under the following conditions.

At idle : **Battery voltage**
At 2,000 rpm : **Approximately 0V**

3. If NG, go to [EC-1574, "Diagnostic Procedure"](#).








DTC P0510 CLOSED TP SWITCH

[VG33ER]

UBS008H4

Wiring Diagram

EC-TP/SW-01



BBWA0490E

DTC P0510 CLOSED TP SWITCH

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
28	BR/W	Throttle position switch (Closed position)	[Engine is running] ● Warm-up condition ● Accelerator pedal fully released	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] ● Accelerator pedal depressed	Approximately 0V

Diagnostic Procedure

UBS008H5

1. CHECK CLOSED THROTTLE POSITION SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect throttle position switch harness connector.
3. Turn ignition switch ON.




AEC653A

4. Check voltage between terminal 5 and engine ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



SEF715U

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between throttle position switch and ECM relay
- Harness for open or short between throttle position switch and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK CLOSED THROTTLE POSITION SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 28 and throttle position switch terminal 4.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK IGNITION TIMING AND ENGINE IDLE SPEED

Check the following items. Refer to [EC-1237, "Basic Inspection"](#) .

Items	Specifications
Ignition timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Target idle speed	750 ± 50 rpm (in P or N position)

With CONSULT-II>>GO TO 5.

Without CONSULT-II>>GO TO 6.

5. CHECK CLOSED THROTTLE POSITION SWITCH

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Check indication of "CLSD THL/P SW".
Measurement must be made with closed throttle position switch installed in vehicle.

Throttle valve conditions	CLSD THL/P SW
Completely closed	ON
Partially open or completely closed	OFF

OK or NG

OK >> GO TO 8.

NG >> GO TO 7.

6. CHECK CLOSED THROTTLE POSITION SWITCH


Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect closed throttle position switch harness connector.
4. Check continuity between closed throttle position switch terminals 4 and 5.
Resistance measurement must be made with closed throttle position switch installed in vehicle.

Throttle valve conditions	Continuity
Completely closed	Yes
Partially open or completely closed	No

OK or NG

- OK >> GO TO 9.
NG >> GO TO 7.



7. ADJUST THROTTLE POSITION SWITCH

Check the following items. Refer to [EC-1237, "Basic Inspection"](#).

Items	Specifications
Ignitions timing	10° ± 2° BTDC
Base idle speed	700 ± 50 rpm (in P or N position)
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.3 mm (0.012 in): ON 0.4 mm (0.016 in): OFF
Target idle speed	750 ± 50 rpm (in P or N position)

If it is impossible to adjust closed throttle position switch in “Basic Inspection”, replace closed throttle position switch.

OK or NG

- OK (with CONSULT-II)>>GO TO 8.
OK (without CONSULT-II)>>GO TO 9.
NG >> Replace throttle position switch.

8. CHECK THROTTLE POSITION SENSOR**With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine (ignition switch OFF).
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Check voltage of "THRTL POS SEN".

Throttle valve conditions	Voltage [V]
Completely closed	0.15 - 0.85 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.7 (b)

Voltage measurement must be made with throttle position sensor installed in vehicle.

If NG, adjust closed throttle position switch. Refer to [EC-1237, "Basic Inspection"](#) .

OK or NG

- OK >> GO TO 10.
 NG >> Replace throttle position sensor.

9. CHECK THROTTLE POSITION SENSOR**Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Stop engine (ignition switch OFF).
3. Turn ignition switch ON.
4. Check voltage between ECM terminal 23 (Throttle position sensor signal) and ground.

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	Voltage [V]
Completely closed	0.15 - 0.85 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.7 (b)

If NG, adjust closed throttle position switch. Refer to [EC-1237, "Basic Inspection"](#) .

OK or NG

- OK >> GO TO 10.
 NG >> Replace throttle position sensor.

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P0600 A/T COMMUNICATION LINE

PF0:23710

System Description

EBS00GNI

These circuit lines are used to control the smooth shifting up and down of A/T during the hard acceleration/ deceleration.

Voltage signals are exchanged between ECM and TCM (Transmission Control Module).

On Board Diagnosis Logic

EBS00GNJ

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0600*	A/T control serial communication link	ECM receives incorrect voltage from TCM (Transmission Control Module) continuously.	<ul style="list-style-type: none"> Harness or connectors [The circuit between ECM and TCM (Transmission Control Module) is open or shorted.]

*: This DTC can be detected only by "DATA MONITOR (AUTO TRIG)" with CONSULT-II.

DTC Confirmation Procedure

EBS00GNK

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine, and rev engine more than 1,000 rpm once, then let it idle for more than 40 seconds.
4. If DTC 1st trip is detected, go to [EC-1582, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".

DTC P0600 A/T COMMUNICATION LINE



[VG33ER]

Wiring Diagram WITHOUT VDC

EBS00GNL

EC-AT/C-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



WBWA0037E

DTC P0600 A/T COMMUNICATION LINE

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
26	PU/W	A/T signal No. 1	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0 - 1.0V
27	P/B	A/T signal No. 2	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0 - 1.0V
35	G/R	A/T signal No. 3	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0 - 1.0V




DTC P0600 A/T COMMUNICATION LINE



[VG33ER]

WITH VDC

EC-CAN-01

A
EC
C
D
E
F
G
H
I
J
K
L
M

-  : DETECTABLE LINE FOR DTC
-  : NON-DETECTABLE LINE FOR DTC
-  : DATA LINE



BBWA0503E


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
68	W/G	A/T signal	[Engine is running] ● Idle speed	Approximately 0 - 5.0V

Diagnostic Procedure

EBS00GNM

1. CHECK A/T CONTROL INPUT SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and TCM (Transmission Control Module) harness connector.




3. Check harness continuity between ECM terminal 26 and TCM terminal 5, ECM terminal 27 and TCM terminal 6, ECM terminal 35 and TCM terminal 7. Refer to Wiring Diagram.

Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between ECM and TCM (Transmission Control Module)

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK A/T CONTROL INPUT SIGNAL CIRCUIT FOR SHORT

1. Check harness continuity between ECM terminal 26 and ground, ECM terminal 27 and ground, ECM terminal 35 and ground. Refer to Wiring Diagram.

Continuity should not exist.

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the harness for open or short between ECM and TCM (Transmission Control Module).

>> Repair open circuit or short to ground or short to power in harness.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L


M

DTC P0605 ECM

Component Description

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the engine.

UBS008HC



On Board Diagnosis Logic

UBS008HD

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0605	Engine control module	ECM calculation function is malfunctioning.	● ECM

DTC Confirmation Procedure


UBS008HE

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine.
4. Run engine for at least 2 seconds at idle speed.
5. If 1st trip DTC is detected, go to [EC-1585, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure “With CONSULT-II”.

Diagnostic Procedure**1. INSPECTION START** **With CONSULT-II**

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure".**
See [EC-1584, "DTC Confirmation Procedure"](#) .
5. Is the 1st trip DTC P0605 displayed again?

 **With GST**

1. Turn ignition switch ON.
2. Select MODE 4 with GST.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure".**
See [EC-1584, "DTC Confirmation Procedure"](#) .
5. Is the 1st trip DTC P0605 displayed again?

Yes or No

- Yes >> Replace ECM.
No >> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L

M



DTC P1143, P1163 HO2S1

PF2:22690

Component Description

UBS008HG

The heated oxygen sensor 1 is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS008HH


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS008HI

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the “rich” output is sufficiently high and whether the “lean” output is sufficiently low. When both the outputs are shifting to the lean side, the malfunction will be detected.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1143 (Bank 1)	Heated oxygen sensor 1 lean shift monitoring	The maximum and minimum voltage from the sensor are not reached to the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks
P1163 (Bank 2)			

DTC Confirmation Procedure

UBS008HJ

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- **Always perform at a temperature above -10°C (14°F).**
- **Before performing following procedure, confirm that battery voltage is more than 11V at idle.**

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch “ON” and select “HO2S1 (B1)/(B2) P1143/ P1163” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.

HO2S1 (B1) P1143	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

LEC072A

5. Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 5.

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)


EGN SPEED	1,200 - 2,700 rpm
Vehicle speed	Less than 100 km/h (62 MPH)
B/FUEL SCHDL	2.0 - 14.0 msec
Selector lever	Suitable position

HO2S1 (B1) P1143	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

LEC073A

If “TESTING” is not displayed after 5 minutes, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-1588, "Diagnostic Procedure"](#).




UBS008HK

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1(B1) signal] or 51 [HO2S1(B2) signal] and engine ground.
3. Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is over 0.1V at least one time.
4. If NG, go to [EC-1588, "Diagnostic Procedure"](#).




UBS008HL

Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



LEC657

2. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten corresponding heated oxygen sensor 1.


Tightening torque : 40 - 60 N·m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)

>> GO TO 3.

3. CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?



Without CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-1223, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174. Refer to [EC-1415, "DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION"](#).
- No >> GO TO 4.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

1. Stop engine.
2. Check heated oxygen sensor 1 harness protector color.



3. Check resistance between HO2S1 terminals 3 and 1.


Resistance : 2.3 - 4.3Ω at 25°C (77°F)

4. Check continuity between HO2S1 terminals 2 and 1, 3 and 2.

Continuity should not exist.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



OK or NG

OK (With CONSULT-II)>>GO TO 5.

OK (Without CONSULT-II)>>GO TO 6.

NG >> Replace malfunctioning heated oxygen sensor 1.

5. CHECK HEATED OXYGEN SENSOR 1

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V

SEF967Y


5. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5	
HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R							
Bank 2	cycle	1	2	3	4	5	
HO2S1 MNTR (B2) R-L-R-L-R-L-R-L-R-L-R							

R means HO2S1
MNTR (B1)/(B2) indicates RICH

L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 7.
- NG >> Replace malfunctioning heated oxygen sensor 1.

6. CHECK HEATED OXYGEN SENSOR 1

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 (bank 1 signal) or 51 (bank 2 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 7.

NG >> Replace malfunctioning heated oxygen sensor 1.



7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For circuit, refer to [EC-1388, "Wiring Diagram"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

UBS008HM



DTC P1144, P1164 HO2S1

PF2:22690

Component Description

UBS008HN

The heated oxygen sensor 1 is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

UBS008HO


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

UBS008HP

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the “rich” output is sufficiently high. The “lean” output is sufficiently low. When both the outputs are shifting to the rich side, the malfunction will be detected.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1144 (Bank 1) P1164 (Bank 2)	Heated oxygen sensor 1 rich shift monitoring	The maximum and minimum voltages from the sensor are beyond the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above –10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch ON and select “HO2S1 (B1)/(B2) P1144/ P1164” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.

HO2S1 (B1) P1144	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

LEC074A

5. Start engine and let it idle for at least 3.5 minutes.

NOTE:

Never raise engine speed above 2,800 rpm after this step. If the engine speed limit is exceeded, return to step 5.

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)

ENG SPEED	1,200 - 2,700 rpm
Vehicle speed	Less than 100 km/h (62 MPH)
B/FUEL SCHDL	2.0 - 14.0 msec
Selector lever	Suitable position

HO2S1 (B1) P1144	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

LEC075A

If “TESTING” is not displayed after 5 minutes, retry from step 2.

7. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to [EC-1595, "Diagnostic Procedure"](#).

HO2S1 (B1) P1144	
COMPLETED	


LEC058A

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 [HO2S1(B1) signal] or 51 [HO2S1(B2) signal] and engine ground.
3. Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is below 0.8V at least one time.
 - The minimum voltage is below 0.35V at least one time.
4. If NG, go to [EC-1595. "Diagnostic Procedure"](#) .




UBS008HS

Diagnostic Procedure**1. RETIGHTEN GROUND SCREWS**

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.

**2. RETIGHTEN HEATED OXYGEN SENSOR 1**

Loosen and retighten corresponding heated oxygen sensor 1.

Tightening torque : 40 - 60 N·m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)


>> GO TO 3.

3. CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.

**Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?**



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch OFF.
 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
 4. Stop engine and reconnect mass air flow sensor harness connector.
 5. Make sure DTC P0102 is displayed.
 6. Erase the DTC memory. Refer to [EC-1223, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
 7. Make sure DTC P0000 is displayed.
 8. Run engine for at least 10 minutes at idle speed.
- Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?**

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172, P0175. Refer to [EC-1423, "DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION"](#).
- No >> GO TO 4.


4. CHECK HO2S 1 CONNECTOR FOR WATER

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 1 harness protector color.
3. Disconnect heated oxygen sensor 1 harness connector.
4. Check connectors for water.

Water should not exist.

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace harness or connectors.



5. CHECK HEATED OXYGEN SENSOR 1 HEATER

Check resistance between HO2S1 terminals 3 and 1.

Resistance : 2.3 - 4.3Ω at 25°C (77°F)

Check continuity between HO2S1 terminals 2 and 1, 3 and 2.

Continuity should not exist.

CAUTION:


- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK (With CONSULT-II)>>GO TO 6.

OK (Without CONSULT-II)>>GO TO 7.

NG >> Replace malfunctioning heated oxygen sensor 1.



A

EC

C

D

E

F

G

H

I

J

K

L

M

6. CHECK HEATED OXYGEN SENSOR 1

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V

SEF967Y

5. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	
cycle	1 2 3 4 5
HO2S1 MNTR (B1)	R-L-R-L-R-L-R-L-R-L-R
Bank 2	
cycle	1 2 3 4 5
HO2S1 MNTR (B2)	R-L-R-L-R-L-R-L-R-L-R
R means HO2S1 MNTR (B1)/(B2) indicates RICH	
L means HO2S1 MNTR (B1)/(B2) indicates LEAN	

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
- NG >> Replace malfunctioning heated oxygen sensor 1.

7. CHECK HEATED OXYGEN SENSOR 1

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 50 (bank 1 signal) or 51 (bank 2 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

OK >> GO TO 8.

NG >> Replace malfunctioning heated oxygen sensor 1.



8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For circuit, refer to [EC-1388, "Wiring Diagram"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .


UBS008HT

DTC P1146, P1166 HO2S2

Component Description

UBS008HU

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



SEF327R

CONSULT-II Reference Value in Data Monitor Mode

UBS008HV


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> Warm-up condition After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	Revving engine from idle up to 3,000 rpm quickly	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)			LEAN ↔ RICH

On Board Diagnosis Logic

UBS008HW

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the minimum voltage of sensor is sufficiently low during the various driving condition such as fuel-cut.



SEF972Z

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1146 (Bank 1)	Heated oxygen sensor 2 minimum voltage monitoring	The minimum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2 Fuel pressure Injectors
P1166 (Bank 2)			

DTC Confirmation Procedure

UBS008HX

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


TESTING CONDITION:

Open engine hood before conducting following procedure

WITH CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 10 seconds.
- Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.

4. Let engine idle for one minutes.
5. Select "HO2S2 (B1) P1146" or "HO2S2 (B2) P1166" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.



6. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
 If "NG" is displayed, refer to [EC-1606, "Diagnostic Procedure"](#).
 If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a. Stop engine and cool down until "COOLAN TEMP/S" indicates less than 70°C (158°F).
 - b. Turn ignition switch "ON".
 - c. Select "DATA MONITOR" mode with CONSULT-II.
 - d. Start engine.
 - e. Return to step 6 again when the "COOLAN TEMP/S" reaches to 70°C (158°F).

A
EC
C
D
E
F
G
H
I
J
K
L
M

Overall Function Check


Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

WITH GST






1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be below 0.48V at least once during this procedure.
If the voltage can be confirmed in step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.48V at least once during this procedure.
8. If NG, go to [EC-1606, "Diagnostic Procedure"](#) .



Wiring Diagram
BANK 1

EC-O2S2B1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P1146, P1166 HO2S2

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.





CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none">● Revving engine from idle to 3,000 rpm quickly after the following conditions are met.● Engine after warming up.● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load.	0 - Approximately 1.0V

BANK 2

EC-O2S2B2-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
57	Y	Heated oxygen sensor 2 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Revving engine from idle to 3,000 rpm quickly after the following conditions are met. ● Engine after warming up. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - Approximately 1.0V


Diagnostic Procedure

UBS00810

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?**



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-1223, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?**

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172, P0175. Refer to [EC-1423, "DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION"](#).
- No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between HO2S2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.


4. DETECT MALFUNCTIONING PART

Check harness for open between heated oxygen sensor 2 and engine ground.


>> Repair open circuit or short to power in harness or connectors.

5. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 2 harness protector color.



3. Disconnect corresponding heated oxygen sensor 2 harness connector.
4. Disconnect ECM harness connector.
5. Check harness continuity between ECM terminal and HO2S2 terminal as follows.



Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P1146	56	1	Bank 1
P1166	57	1	Bank 2

Continuity should exist.

6. Check harness continuity between ECM terminal or HO2S2 terminal and ground as follows. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P1146	56 or 1	Ground	Bank 1
P1166	57 or 1	Ground	Bank 2

Continuity should not exist.

7. Also check harness for short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 6.

OK (Without CONSULT-II)>>GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2


With CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minutes.
6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.62V at least once when the "FUEL INJECTION" is +25%.
 "HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


OK or NG

- OK >> GO TO 8.
- NG >> Replace malfunctioning heated oxygen sensor 2.

7. CHECK HEATED OXYGEN SENSOR 2

⊗ Without CONSULT-II

1. Start engine warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.62V at least once during this procedure.
If the voltage is above 0.62V at step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.48V at least once during this procedure.
8. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
NG >> Replace malfunctioning heated oxygen sensor 2.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

UBS0081

DTC P1147, P1167 HO2S2


Component Description

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.




CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> Warm-up condition After keeping engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	Revving engine from idle up to 3,000 rpm quickly	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)			LEAN ↔ RICH

On Board Diagnosis Logic

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the maximum voltage of the sensor is sufficiently high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1147 (Bank 1)	Heated oxygen sensor 2 maximum voltage monitoring	The maximum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted) Heated oxygen sensor 2 Fuel pressure Injectors Intake air leaks
P1167 (Bank 2)			

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.


TESTING CONDITION:

Open engine hood before conducting following procedure

WITH CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 10 seconds.

3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minute.
5. Select "HO2S2 (B1) P1147" or "HO2S2 (B2) P1167" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.



6. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
 If "NG" is displayed, refer to [EC-1617, "Diagnostic Procedure"](#).
 If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a. Stop engine and cool down until "COOLAN TEMP/S" indicates less than 70°C (158°F).
 - b. Turn ignition switch "ON".
 - c. Select "DATA MONITOR" mode with CONSULT-II.
 - d. Start engine.
 - e. Return to step 6 again when the "COOLAN TEMP/S" reaches to 70°C (158°F).

Overall Function Check


Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.





WITH GST

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.62V at least once during this procedure.
If the voltage can be confirmed in step 6, step 7 is not necessary.
7. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be above 0.62V at least once during this procedure.
8. If NG, go to [EC-1617, "Diagnostic Procedure"](#) .



Wiring Diagram
BANK 1

EC-O2S2B1-01



DTC P1147, P1167 HO2S2

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:





Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
56	OR	Heated oxygen sensor 2 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Revving engine from idle to 3,000 rpm quickly after the following conditions are met. ● Engine after warming up. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - Approximately 1.0V

A
EC
C
D
E
F
G
H
I
J
K
L
M

BANK 2

EC-O2S2B2-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
57	Y	Heated oxygen sensor 2 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Revving engine from idle to 3,000 rpm quickly after the following conditions are met. ● Engine after warming up. ● Keeping the engine speed between 3,500 and 4,000 rpm for one minute and at idle for one minute under no load. 	0 - Approximately 1.0V


Diagnostic Procedure

UBS00818

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.




2. CLEAR THE SELF-LEARNING DATA

④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.

**Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch OFF.
 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
 4. Stop engine and reconnect mass air flow sensor harness connector.
 5. Make sure DTC P0102 is displayed.
 6. Erase the DTC memory. Refer to [EC-1223, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
 7. Make sure DTC P0000 is displayed.
 8. Run engine for at least 10 minutes at idle speed.
- Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?**

Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174. Refer to [EC-1415, "DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION"](#).
- No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between HO2S2 terminal 4 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.


4. DETECT MALFUNCTIONING PART

Check harness for open between heated oxygen sensor 2 and engine ground.

>> Repair open circuit or short to power in harness or connectors.

5. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 2 harness protector color.
3. Disconnect corresponding heated oxygen sensor 2 harness connector.
4. Disconnect ECM harness connector.
5. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.



DTC	Terminals		Bank
	ECM	Sensor	
P1147	56	1	Bank 1
P1167	57	1	Bank 2

Continuity should exist.

6. Check harness continuity between ECM terminal or HO2S2 terminal and ground as follows.

Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or sensor	Ground	
P1147	56 or 1	Ground	Bank 1
P1167	57 or 1	Ground	Bank 2

Continuity should not exist.

7. Also check harness for short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 6.

OK (Without CONSULT-II)>>GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2


With CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to the normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
5. Let engine idle for one minutes.
6. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

7. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.62V at least once when the "FUEL INJECTION" is +25%.
 "HO2S2 (B1)/(B2)" should be below 0.48V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
 NG >> Replace malfunctioning heated oxygen sensor 2.

7. CHECK HEATED OXYGEN SENSOR 2


⊗ Without CONSULT-II

1. Start engine warm it up to the normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least one minute under no load.
4. Let engine idle for one minutes.
5. Set voltmeter probes between ECM terminal 56 [HO2S2 (B1) signal] or 57 [HO2S2 (B2) signal] and engine ground.
6. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.62V at least once during this procedure.

If the voltage is above 0.62V at step 6, step 7 is not necessary.

7. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.48V at least once during this procedure.



8. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

OK or NG

- OK >> GO TO 8.
NG >> Replace malfunctioning heated oxygen sensor 2.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

UBS00819

DTC P1148, P1168 CLOSED LOOP CONTROL

PFP:22690

On Board Diagnosis Logic

UBS008IA

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1148 (Bank 1)	Closed loop control function	The closed loop control function for bank 1 does not operate even when vehicle is driving in the specified condition.	<ul style="list-style-type: none"> ● The heated oxygen sensor 1 circuit is open or shorted. ● Heated oxygen sensor 1 ● Heated oxygen sensor heater
P1168 (Bank 2)		The closed loop control function for bank 2 does not operate even when vehicle is driving in the specified condition.	

DTC Confirmation Procedure

UBS008IB

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Never raise engine speed above 2,800 rpm during the “DTC Confirmation Procedure”. If the engine speed limit is exceeded, retry the procedure from step 2.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

Ⓟ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Hold engine speed at 2,000 rpm and check one of the following.
 - “HO2S1 (B1)/(B2)” voltage should go above 0.70V at least once.
 - “HO2S1 (B1)/(B2)” voltage should go below 0.21V at least once. If the check result is NG, perform [EC-1623, "Diagnostic Procedure"](#) . If the check result is OK, perform the following step.
4. Let engine idle at least 5 minutes.
5. Maintain the following condition at least 50 consecutive seconds.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANT TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S2 (B2)	XXX V

SEF967Y

B/FUEL SCHDL	2.0 msec or more
ENG SPEED	1,500 rpm or more
Selector lever	Suitable position
VHCL SPEED SE	More than 71 km/h (44 MPH)

During this test, P0134 and/or P0154 may be displayed on CONSULT-II screen.

6. If DTC is detected, go to [EC-1623, "Diagnostic Procedure"](#) .

Overall Function Check

UBS008IC

Use this procedure to check the overall function of the closed loop control. During this check, a DTC might not be confirmed.


Ⓟ WITH GST

1. Start engine and warm it up to normal operating temperature.

DTC P1148, P1168 CLOSED LOOP CONTROL

[VG33ER]

2. Set voltmeter probes between ECM terminal 50 [HO2S1 (B1) signal] or 51 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no-load.
 - The voltage should go above 0.70V at least once.
 - The voltage should go below 0.21V at least once.
4. If NG, go to [EC-1623, "Diagnostic Procedure"](#) .



Diagnostic Procedure

Perform trouble diagnosis for [EC-1378, "Diagnostic Procedure"](#) .

A

EC

C

D

UBS0081D

E

F

G

H

I

J

K

L

M

DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

PFP:00021

On Board Diagnosis Logic

UBS0081E

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise. When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

This self-diagnosis has one trip detection logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1217	Engine over temperature (Overheat)	Engine coolant temperature reaches an abnormally high temperature.	<ul style="list-style-type: none"> ● Cooling fan (crankshaft driven) ● Radiator hose ● Radiator ● Radiator cap ● Water pump ● Thermostat <p>For more information, refer to EC-1626, "Main 12 Causes of Overheating".</p>

CAUTION:

When a malfunction is indicated be sure to replace the coolant, follow the procedure in [MA-26](#), "[Changing Engine Coolant](#)". Also, replace the engine oil.

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to [MA-14](#), "[ANTI-FREEZE COOLANT MIXTURE RATIO](#)".
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Overall Function Check

UBS0081F

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.


WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

WITH CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-1625](#), "[Diagnostic Procedure](#)".
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-1625](#), "[Diagnostic Procedure](#)".
3. Start engine.
4. Make sure that cooling fan (crankshaft driven) operates.
5. If NG, go to [EC-1625](#), "[Diagnostic Procedure](#)".



WITH GST

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-1625](#), "[Diagnostic Procedure](#)".
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-1625](#), "[Diagnostic Procedure](#)".
3. Start engine and make sure that cooling fan (crankshaft driven) operates.
Be careful not to overheat engine.
4. If NG, go to [EC-1625](#), "[Diagnostic Procedure](#)".

Diagnostic Procedure

1. CHECK COOLING FAN (CRANKSHAFT DRIVEN) OPERATION

Start engine and make sure that cooling fan (crankshaft driven) operates.

OK or NG

OK >> GO TO 2.

NG >> Check cooling fan (crankshaft driven). Refer to [CO-32, "COOLING FAN \(CRANKSHAFT DRIVEN\)"](#).

2. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.

CAUTION:

Higher than the specified pressure may cause radiator damage.

Testing pressure² : 157 kPa (1.6 kg/cm, 23 psi)

Pressure should not drop.


OK or NG

OK >> GO TO 3.

NG >> Check the following for leak

- Hose
- Radiator
- Water pump

Refer to [CO-25, "WATER PUMP"](#).



3. CHECK RADIATOR CAP


Apply pressure to cap with a tester and check radiator cap relief pressure.

Radiator cap relief pressure : 59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)

OK or NG

OK >> GO TO 4.

NG >> Replace radiator cap.



4. CHECK THERMOSTAT

1. Check valve seating condition at normal room temperatures. **It should seat tightly.**
2. Check valve opening temperature and valve lift.

Valve opening temperature : 76.5°C (170°F) [standard]

Valve lift : More than 10 mm/90°C (0.39 in/194°F)


3. Check if valve is closed at 5°C (9°F) below valve opening temperature.

For details, refer to [CO-28, "THERMOSTAT"](#).

OK or NG

OK >> GO TO 5.

NG >> Replace thermostat



DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)


[VG33ER]

5. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Check resistance as shown in the figure.

<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260




SEF152P

OK or NG

OK >> GO TO 6.

NG >> Replace engine coolant temperature sensor.



SEF012P

6. CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to [EC-1626, "Main 12 Causes of Overheating"](#) .

>> INSPECTION END.

Main 12 Causes of Overheating

UBS0081H

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> Blocked radiator Blocked condenser Blocked radiator grille Blocked bumper 	<ul style="list-style-type: none"> Visual 	No blocking	—
	2	<ul style="list-style-type: none"> Coolant mixture 	<ul style="list-style-type: none"> Coolant tester 	50 - 50% coolant mixture	See MA-14, "ANTI-FREEZE COOLANT MIXTURE RATIO" .
	3	<ul style="list-style-type: none"> Coolant level 	<ul style="list-style-type: none"> Visual 	Coolant up to MAX level in reservoir tank and radiator filler neck	See MA-26, "Changing Engine Coolant" .
	4	<ul style="list-style-type: none"> Radiator cap 	<ul style="list-style-type: none"> Pressure tester 	59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See CO-23, "System Check" .
ON*1	5	<ul style="list-style-type: none"> Coolant leaks 	<ul style="list-style-type: none"> Visual 	No leaks	See CO-23, "System Check" .
ON*1	6	<ul style="list-style-type: none"> Thermostat 	<ul style="list-style-type: none"> Touch the upper and lower radiator hoses 	Both hoses should be hot	See CO-28, "THERMOSTAT" .
ON*1	7	<ul style="list-style-type: none"> Cooling fan (crankshaft driven) 	<ul style="list-style-type: none"> Visual 	Operating	See CO-32, "COOLING FAN (CRANKSHAFT DRIVEN)" .
OFF	8	<ul style="list-style-type: none"> Combustion gas leak 	<ul style="list-style-type: none"> Color checker chemical tester 4 Gas analyzer 	Negative	—

DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

[VG33ER]

Engine	Step	Inspection item	Equipment	Standard	Reference page
ON*2	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See MA-26, "Changing Engine Coolant" .
OFF*3	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See CO-22, "COOLING SYSTEM" .
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-100, "CYLINDER HEAD" .
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See EM-130, "CYLINDER BLOCK" .

*1: Engine running at 3,000 rpm for 10 minutes.

*2: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*3: After 60 minutes of cool down time.

For more information, refer to [CO-21, "OVERHEATING CAUSE ANALYSIS"](#) .

A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P1336 CKP SENSOR (OBD)

PFP:23731

Component Description

UBS008II

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.



The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system.

It is used only for the on board diagnosis.



On Board Diagnosis Logic

UBS008II

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1336	Crankshaft position sensor (OBD) range/performance	A chipping of the flywheel or drive plate gear tooth (cog) is detected by the ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Crankshaft position sensor (OBD) ● Drive plate/Flywheel

DTC Confirmation Procedure

UBS008IK

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 2 minutes at idle speed.
3. If 1st trip DTC is detected, go to [EC-1630, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".




DTC P1336 CKP SENSOR (OBD)

[VG33ER]

UBS008L

Wiring Diagram

EC-CKPS-01





DTC P1336 CKP SENSOR (OBD)

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	L	Crankshaft position sensor (OBD)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1 - 2V (AC range)★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>3 - 4V (AC range)★</p> 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

UBS008IM

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch OFF.
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK CKP SENSOR (OBD) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Disconnect crankshaft position sensor (OBD) and ECM harness connectors.
2. Check continuity between ECM terminal 47 and CKP sensor (OBD) terminal 2.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F38, F102
- Harness for open or short between ECM and crankshaft position sensor (OBD)

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK CKP SENSOR (OBD) GROUND CIRCUIT FOR OPEN AND SHORT

1. Reconnect ECM harness connectors.
2. Check harness continuity between CKP sensor (OBD) terminal 1 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F38, F102
- Harness for open between crankshaft position sensor (OBD) and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK IMPROPER INSTALLATION


1. Loosen and retighten the fixing bolt of the crankshaft position sensor (OBD).
2. Perform [EC-1628, "DTC Confirmation Procedure"](#) .

Is a 1st trip DTC P1336 detected?

- Yes >> GO TO 7.
- No >> **INSPECTION END.**

7. CHECK CRANKSHAFT POSITION SENSOR (OBD)

1. Disconnect crankshaft position sensor (OBD) harness connector.
2. Loosen the fixing bolt of the sensor.
3. Remove the sensor.
4. Visually check the sensor for chipping.




5. Check resistance as shown in the figure.

Resistance : Approximately 512 - 632Ω [at 20°C (68°F)]

OK or NG

- OK >> GO TO 8.
 NG >> Replace crankshaft position sensor (OBD).



8. CHECK GEAR TOOTH

Visually check for chipping flywheel or drive plate gear tooth (cog).

OK or NG

- OK >> GO TO 9.
 NG >> Replace the flywheel or drive plate.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1442 EVAP CONTROL SYSTEM

PFP:14950

On Board Diagnosis Logic

UBS00810


NOTE:

If DTC P1442 is displayed with P1448, perform trouble diagnosis for DTC P1448 first. (See [EC-1650](#).)

This diagnosis detects leaks in the EVAP purge line using of vapor pressure in the fuel tank.

The EVAP canister vent control valve is closed to shut the EVAP purge line. The vacuum cut valve bypass valve will then be opened to clear the line between the fuel tank and the EVAP canister purge volume control solenoid valve. The EVAP control system pressure sensor can now monitor the pressure inside the fuel tank.

If pressure increases, the ECM will check for leaks in the line between the vacuum cut valve and EVAP canister purge volume control solenoid valve.



DTC P1442 EVAP CONTROL SYSTEM

[VG33ER]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1442	EVAP control system small leak detected (positive pressure)	EVAP control system has a leak, EVAP control system does not operate properly.	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged. ● Water separator ● EVAP canister is saturated with water ● Fuel level sensor and the circuit ● EVAP control system pressure sensor ● Refueling control valve ● ORVR system leaks ● Foreign matter caught in EVAP canister purge volume control solenoid valve

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS0081P

Refer to [EC-1538, "DTC P0456 EVAP CONTROL SYSTEM"](#) or [EC-1658, "DTC P1456 EVAP CONTROL SYSTEM"](#).

Diagnostic Procedure

UBS0081Q

Refer to [EC-1538, "DTC P0456 EVAP CONTROL SYSTEM"](#) or [EC-1658, "DTC P1456 EVAP CONTROL SYSTEM"](#).

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33ER]

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PFP:14920

UBS0081R


Description SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Throttle position switch	Closed throttle position		
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Fuel tank temperature sensor	Fuel temperature in fuel tank		
Vehicle speed sensor	Vehicle speed		

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



CONSULT-II Reference Value in Data Monitor Mode

UBS0081S

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PURG VOL C/V	● Engine: After warming up ● Air conditioner switch OFF ● Shift lever: "N" ● No-load	Idle (Vehicle stopped) 0%
	2,000 rpm	—

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33ER]

UBS0081U

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1444	EVAP canister purge volume control solenoid valve	The canister purge flow is detected during the specified driving conditions, even when EVAP canister purge volume control solenoid valve is completely closed.	<ul style="list-style-type: none"> ● EVAP control system pressure sensor ● EVAP canister purge volume control solenoid valve (The valve is stuck open.) ● EVAP canister vent control valve ● EVAP canister ● Hoses (Hoses are connected incorrectly or clogged.)

DTC Confirmation Procedure

UBS0081U

NOTE:


If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Turn ignition switch ON.
4. Select “PURG VOL CN/V P1444” of “EVAPORATIVE SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II.
5. Touch “START”.



6. Start engine and let it idle until “TESTING” on CONSULT-II changes to “COMPLETED”. (It will take for approximately 10 seconds.)
If “TESTING” is not displayed after 5 minutes, retry from step 2.
7. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to [EC-1639, "Diagnostic Procedure"](#).

WITH GST


1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 5 seconds.
3. Start engine and let it idle for at least 20 seconds.
4. Select “MODE 7” with GST.
5. If 1st trip DTC is detected, go to [EC-1639, "Diagnostic Procedure"](#).

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33ER]


UBS008IV

Wiring Diagram


EC-PGC/V-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 13
- LP : 15



Refer to the following.
 (E43) - SUPER MULTIPLE JUNCTION (SMJ)





DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	OR/B	ECM relay (Self shutoff)	[Engine is running] [Ignition switch OFF] ● For a few seconds after turning ignition switch OFF	0 - 1.5V
			[Ignition switch OFF] ● A few seconds passed after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
5	R/Y	EVAP canister purge volume control solenoid valve	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)★ 
			[Engine is running] ● Engine speed is 2,000 rpm	BATTERY VOLTAGE (11 - 14V)★ 
67	B/P	Power supply for ECM	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)
72	B/P			
117	B/P	Current return	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33ER]

UBS0081W

Diagnostic Procedure

1. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 1 and engine ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F36, M81
- Harness connectors M65, E43
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair harness or connectors.

3. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 5 and EVAP canister purge volume control solenoid valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33ER]

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M81, F36
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG


- OK >> GO TO 6.
- NG >> Repair it.

6. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.
Water should not exist.

OK or NG

- OK >> GO TO 7.
- NG >> Replace EVAP control system pressure sensor.



7. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch ON.
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.


Applied vacuum	Voltage V
Not applied	1.4 - 4.8
-26.7 kPa (-200 mmHg, -7.87 inHg)	2.1 to 2.5V lower than above value

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK (with CONSULT-II) >> GO TO 8.
- OK (without CONSULT-II) >> GO TO 9.
- NG >> Replace EVAP control system pressure sensor.



DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33ER]

8. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.
If OK, inspection end. If NG, go to following step.

ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y

3. Check air passage continuity.


Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

If NG, replace the EVAP canister purge volume control solenoid valve.

OK or NG

OK >> GO TO 10.

NG >> Replace EVAP canister purge volume control solenoid valve.



9. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Without CONSULT-II

Check air passage continuity.


Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

If NG, replace the EVAP canister purge volume control solenoid valve.

OK or NG

OK >> GO TO 10.

NG >> Replace EVAP canister purge volume control solenoid valve.



DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33ER]


10. CHECK EVAP CANISTER VENT CONTROL VALVE

With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.




Without CONSULT-II

1. Check air passage continuity and operation delay time under the following condition.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.



If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.

If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.

OK or NG

OK >> GO TO 11.

NG >> Replace EVAP canister vent control valve.

11. CHECK RUBBER TUBE

Check for obstructed rubber tube connected to EVAP canister vent control valve.

OK or NG

OK >> GO TO 12.

NG >> Clean, repair or replace rubber tube.

12. CHECK WATER SEPARATOR

1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.


NOTE:

Do not disassemble water separator.

OK or NG

OK >> GO TO 13.

NG >> Replace water separator.




DTC P1444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [VG33ER]

13. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

- Yes >> GO TO 14.
No >> GO TO 16.



14. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK >> GO TO 16.
NG >> GO TO 15.

15. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

16. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1446 EVAP CANISTER VENT CONTROL VALVE

PFP:14935

Component Description



UBS0081Y

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid valve responds to signals from the ECM. When the ECM sends an ON signal, the coil in the solenoid valve is energized. A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS0081Z

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

UBS00810

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1446	EVAP canister vent control valve close	EVAP canister vent control valve remains closed under specified driving conditions.	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● EVAP control system pressure sensor and the circuit ● Blocked rubber tube to EVAP canister vent control valve ● Water separator ● EVAP canister is saturated with water

DTC Confirmation Procedure

UBS00811

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.

DTC P1446 EVAP CANISTER VENT CONTROL VALVE

[VG33ER]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine.
4. Drive vehicle at a speed of approximately 80 km/h (50 MPH) for a maximum of 15 minutes.

NOTE:

If a malfunction exists, NG result may be displayed quicker.

5. If 1st trip DTC is detected, go to [EC-1647, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V
B/FUEL SCHDL	XXX msec

SEF201Y

 **WITH GST**

Follow the procedure "With CONSULT-II".

A

EC

C

D

E

F

G

H

I

J

K

L

M


DTC P1446 EVAP CANISTER VENT CONTROL VALVE

[VG33ER]


UBS008J2

Wiring Diagram

EC-VENT/V-01



- Refer to PG-POWER.
- : Detectable line for DTC
 - : Non-detectable line for DTC
 - : EARLY PRODUCTION
 - : LATE PRODUCTION
 - *1 : 21
 - : 23



WBWA0031E

DTC P1446 EVAP CANISTER VENT CONTROL VALVE

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
108	R/G	EVAP canister vent control valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


UBS008J3

1. CHECK RUBBER TUBE

1. Turn ignition switch OFF.
2. Check obstructed rubber tube connected to EVAP canister vent control valve.

OK or NG

- OK >> GO TO 2.
- NG >> Clean, repair or replace rubber tube.



2. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 3.
- NG >> Replace water separator.




3. CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING

④ With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.



⊗ Without CONSULT-II

1. Check air passage continuity and operation delay time under the following condition.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.


If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.

OK or NG

OK >> GO TO 4.

NG >> Replace EVAP canister vent control valve and O-ring.




4. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

Yes or No

Yes >> GO TO 5.

No >> GO TO 7.



5. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

7. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG

OK >> GO TO 8.

NG >> Repair it.


8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.
Water should not exist.

OK or NG

OK >> GO TO 9.

NG >> Replace EVAP control system pressure sensor.



9. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION

Refer to [EC-1513, "DTC Confirmation Procedure"](#) or [EC-1519, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> GO TO 10.

NG >> Replace EVAP control system pressure sensor.

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1448 EVAP CANISTER VENT CONTROL VALVE

PFP:14935

Component Description

UBS008J4

NOTE:



If DTC P1448 is displayed with P0442, perform trouble diagnosis for DTC P1448 first.

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid valve responds to signals from the ECM. When the ECM sends an ON signal, the coil in the solenoid valve is energized. A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.



CONSULT-II Reference Value in Data Monitor Mode

UBS008J5

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

UBS008J6

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1448	EVAP canister vent control valve open	EVAP canister vent control valve remains open under specified driving conditions.	<ul style="list-style-type: none"> ● EVAP canister vent control valve ● EVAP control system pressure sensor and the circuit ● Blocked rubber tube to EVAP canister vent control valve ● Water separator ● EVAP canister is saturated with water ● Vacuum cut valve

DTC Confirmation Procedure

UBS008J7

NOTE:

- If DTC P1448 is displayed with P0442, perform trouble diagnosis for DTC P1448 first.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

TESTING CONDITION:

- Perform "DTC WORK SUPPORT" when the fuel level is less than 3/4 full and vehicle is placed on flat level surface.


DTC P1448 EVAP CANISTER VENT CONTROL VALVE

[VG33ER]

- Always perform test at a temperature of 0 to 30°C (32 to 86°F).
 - It is better that the fuel level is low.
1. Turn ignition switch ON.
 2. Turn ignition switch OFF and wait at least 5 seconds.
 3. Turn ignition switch ON and select “DATA MONITOR” mode with CONSULT-II.
 4. Make sure that the following conditions are met.

COOLAN TEMP/S	0 - 32°C (32 - 90°F)
INT/A TEMP SE	More than 0°C (32°F)

5. Select “EVAP SML LEAK P0442” of “EVAPORATIVE SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II.
Follow the instruction displayed.



NOTE:

If the engine speed cannot be maintained within the range displayed on the CONSULT-II screen, go to [EC-1237, "Basic Inspection"](#) .

6. Make sure that “OK” is displayed.
If “NG” is displayed, go to the following step.


NOTE:

Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

7. Stop engine and wait at least 5 seconds, then turn “ON”.
8. Disconnect hose from water separator.
9. Select “VENT CONTROL/V” of “ACTIVE TEST” mode with CONSULT-II.
10. Touch “ON” and “OFF” alternately.
11. Make sure the following.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

If the result is NG, go to [EC-1654, "Diagnostic Procedure"](#) .
If the result is OK, go to [EC-1491, "Diagnostic Procedure"](#) .



Overall Function Check

UBS008J8

Use this procedure to check the overall function of the EVAP canister vent control valve circuit. During this check, a DTC might not be confirmed.

WITH GST

1. Disconnect hose from water separator.
2. Disconnect EVAP canister vent control valve harness connector.


DTC P1448 EVAP CANISTER VENT CONTROL VALVE

[VG33ER]

3. Verify the following.

Condition	Air passage continuity
12V direct current supply between terminals 1 and 2	No
No supply	Yes

If the result is NG, go to [EC-1654, "Diagnostic Procedure"](#) .
If the result is OK, go to [EC-1491, "Diagnostic Procedure"](#) .




DTC P1448 EVAP CANISTER VENT CONTROL VALVE

[VG33ER]

UBS008J9

Wiring Diagram

EC-VENT/V-01




Refer to PG-POWER.

— : Detectable line for DTC
 - - - : Non-detectable line for DTC

EP : EARLY PRODUCTION

LP : LATE PRODUCTION

*1 EP : 21
 LP : 23



Refer to the following.

(E43) - SUPER
 MULTIPLE JUNCTION (SMJ)



WBWA0031E

DTC P1448 EVAP CANISTER VENT CONTROL VALVE

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
108	R/G	EVAP canister vent control valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


UBS008JA

1. CHECK RUBBER TUBE

1. Turn ignition switch OFF.
2. Check obstructed rubber tube connected to EVAP canister vent control valve.

OK or NG

- OK >> GO TO 2.
- NG >> Clean, repair or replace rubber tube.



2. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 3.
- NG >> Replace water separator.




3. CHECK EVAP CANISTER VENT CONTROL VALVE AND O-RING

With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.



Without CONSULT-II

1. Check air passage continuity and operation delay time under the following condition.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.


If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.

OK or NG

OK >> GO TO 4.

NG >> Replace EVAP canister vent control valve and O-ring.



4. CHECK VACUUM CUT VALVE


Check vacuum cut valve as follows:

1. Plug port **C** and **D** with fingers.
2. Apply vacuum to port **A** and check that there is no suction from port **B**.
3. Apply vacuum to port **B** and check that there is suction from port **A**.
4. Blow air in port **B** and check that there is a resistance to flow out of port **A**.
5. Open port **C** and **D**.
6. Blow air in port **A** check that air flows freely out of port **C**.
7. Blow air in port **B** check that air flows freely out of port **D**.

OK or NG

OK >> GO TO 5.

NG >> Replace vacuum cut valve.




5. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Check if water will drain from the EVAP canister.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 8.



6. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG


- OK >> GO TO 9.
- NG >> Repair it.

9. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.
Water should not exist.

OK or NG

- OK >> GO TO 10.
- NG >> Replace EVAP control system pressure sensor.



10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION

Refer to “DTC Confirmation procedure” for DTC P0452 [EC-1513](#) or DTC P0453 [EC-1519](#) .

OK or NG

- OK >> GO TO 11.
- NG >> Replace EVAP control system pressure sensor.

11. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1456 EVAP CONTROL SYSTEM

PFP:14710

On Board Diagnosis Logic


UBS008JB

This diagnosis detects very small leaks in the EVAP line between fuel tank and EVAP canister purge volume control solenoid valve, using of vapor pressure in the fuel tank in the same way as conventional EVAP small leak diagnosis.

If ECM judges a leak which corresponds to a very small leak, the very small leak P1456 will be detected.

If ECM judges a leak equivalent to a small leak, EVAP small leak P1442 will be detected.

If ECM judges there are no leaks, the diagnosis will be OK.



PBIB1438E

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1456	Evaporative emission control system very small leak (positive pressure check)	<ul style="list-style-type: none"> ● EVAP system has a very small leak. ● EVAP system does not operate properly. 	<ul style="list-style-type: none"> ● Incorrect fuel tank vacuum relief valve ● Incorrect fuel filler cap used ● Fuel filler cap remains open or fails to close. ● Foreign matter caught in fuel filler cap. ● Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. ● Foreign matter caught in EVAP canister vent control valve. ● EVAP canister or fuel tank leaks ● EVAP purge line (pipe and rubber tube) leaks ● EVAP purge line rubber tube bent ● Blocked or bent rubber tube to EVAP control system pressure sensor ● Loose or disconnected rubber tube ● EVAP canister vent control valve and the circuit ● EVAP canister purge volume control solenoid valve ● Fuel tank temperature sensor ● O-ring of EVAP canister vent control valve is missing or damaged ● Water separator ● EVAP canister is saturated with water ● Fuel level sensor and the circuit ● EVAP control system pressure sensor ● Refueling control valve ● ORVR system leaks

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC Confirmation Procedure

UBS008JC

CAUTION:

Never remove fuel filler cap during the DTC confirmation procedure.

NOTE:


- If DTC P0456 or P1456 is displayed with P0442 or P1442, perform TROUBLE DIAGNOSIS FOR DTC P0456 or P1456 first.
- After repair, make sure that the hoses and clips are installed properly.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

- Open engine hood before conducting following procedure.
- If any of following condition is met just before the DTC confirmation procedure, leave the vehicle for more than 1 hour.
 - Fuel filler cap is removed.
 - Refilled or drained the fuel.
 - EVAP component parts is/are removed.
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Make sure the following conditions are met.
 - FUEL LEVEL SE: 1.08 - 0.2V**
 - COOLAN TEMP/S: 0 - 35°C (32 - 95°F)**
 - FUEL T/TMP SE: 0 - 32°C (32 - 90°F)**
 - INT A/TEMP SE: More than 0°C (32°F)**
 If NG, turn ignition switch "OFF" and leave the vehicle in a cool place (soak the vehicle) or refilling/draining fuel until the output voltage condition of the "FUEL LEVEL SE" meets within the range above and leave the vehicle for more than 1 hour. Then start from step 1).
3. Turn ignition switch "OFF" and wait at least 5 seconds.
4. Turn ignition switch "ON".
5. Select "EVAP V/S LEAK P0456/P1456" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode with CONSULT-II.
Follow the instruction displayed.



6. Make sure that "OK" is displayed.
If "NG" is displayed, refer to [EC-1660, "Diagnostic Procedure"](#).

NOTE:

- If the engine speed cannot be maintained within the range displayed on CONSULT-II screen, go to [EC-1237, "Basic Inspection"](#).

- Make sure that EVAP hoses are connected to EVAP canister purge volume control solenoid valve properly.

Overall Function Check

UBS008JD


WITH GST

Use this procedure to check the overall function of the EVAP very small leak function. During this check, a 1st trip DTC might not be confirmed.

CAUTION:

- Never use compressed air, doing so may damage the EVAP system.
- Do not start engine.
- Do not exceeded 4.12 kPa (0.042 kg/cm², 0.6 psi).

1. Attach the EVAP service port adapter securely to the EVAP service port.
2. Set the pressure pump and a hose.
3. Also set a vacuum gauge via 3-way connector and a hose.
4. Turn ignition switch "ON".
5. Connect GST and select mode 8.
6. Using mode 8 control the EVAP canister vent control valve (close) and vacuum cut valve bypass valve (open).
7. Apply pressure and make sure the following conditions are satisfied.



Pressure to be applied: 2.7 kPa (20 mmHg, 0.79 inHg)

Time to be waited after the pressure drawn in to the EVAP system and the pressure to be dropped: 60 seconds and the pressure should not be dropped more than 0.4 kPa (3 mmHg, 0.12 inHg)

If NG, go to [EC-1660, "Diagnostic Procedure"](#) .

NOTE:

For more information, refer to GST instruction manual.

Diagnostic Procedure

UBS008JE


1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch "OFF".
2. Check for genuine NISSAN fuel filler cap design.

OK or NG

OK >> GO TO 2.

NG >> Replace with genuine NISSAN fuel filler cap.



2. CHECK FUEL FILLER CAP INSTALLATION

- Check that the cap is tightened properly by rotating the cap clockwise.

OK or NG

OK >> GO TO 3.

NG >> 1. Open fuel filler cap, then clean cap and fuel filler neck threads using air blower.

2. Retighten until ratcheting sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION

- Check for air releasing sound while opening the fuel filler cap.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE


Refer to [EC-1734, "FUEL TANK VACUUM RELIEF VALVE \(BUILT INTO FUEL FULLER CAP\)"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Replace fuel filler cap with a genuine one.

5. INSTALL THE PRESSURE PUMP


To locate the EVAP leak, install EVAP service port adapter and pressure pump to EVAP service port securely.



NOTE:

Improper installation of the EVAP service port adapter to the EVAP service port may cause leaking.

- Models with CONSULT-II >> GO TO 6.
- Models without CONSULT-II >> GO TO 7.




6. CHECK FOR EVAP LEAK

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "EVAP SYSTEM CLOSE" of "WORK SUPPORT" mode with CONSULT-II.
3. Touch "START" and apply pressure into the EVAP line until the pressure indicator reaches the middle of the bar graph.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



4. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.




7. CHECK FOR EVAP LEAK

Without CONSULT-II

1. Turn ignition switch "OFF".
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12 volts until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Pressurize the EVAP line using pressure pump with 1.3 to 2.7 kPa (10 to 20 mmHg, 0.39 to 0.79 inHg), then remove pump and EVAP service port adapter.

NOTE:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm² , 0.6 psi) of pressure in the system.



5. Using EVAP leak detector, locate the EVAP leak. For the leak detector, refer to the instruction manual for more details. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.



8. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

Do not disassemble water separator.

OK or NG

- OK >> GO TO 9.
 NG >> Replace water separator.



9. CHECK EVAP CANISTER VENT CONTROL VALVE, O-RING AND CIRCUIT

Refer to [EC-1650, "DTC Confirmation Procedure"](#) .

OK or NG


- OK >> GO TO 10.
 NG >> Repair or replace EVAP canister vent control valve and O-ring or harness/connector.

10. CHECK IF EVAP CANISTER SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Does water drain from the EVAP canister?

Yes or No

- Yes >> GO TO 11.
 No (With CONSULT-II)>>GO TO 13.
 No (Without CONSULT-II)>>GO TO 14.



11. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve attached.

The weight should be less than 1.8 kg (4.0 lb).

OK or NG

- OK (With CONSULT-II)>>GO TO 13.
 OK (Without CONSULT-II)>>GO TO 14.
 NG >> GO TO 12.

12. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and water separator for clogging or poor connection

>> Repair hose or replace EVAP canister.

13. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

With CONSULT-II

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode.
4. Touch "Qu" on CONSULT-II screen to increase "PURG VOL CONT/V" opening to 100.0%.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 16.
- NG >> GO TO 15.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XX %
A/F ALPHA-B2	XX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	X. XX V

SEF677Y

14. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

OK or NG

- OK >> GO TO 17.
- NG >> GO TO 15.

15. CHECK VACUUM HOSE

Check vacuum hoses for clogging or disconnection. Refer to [EC-1190, "Vacuum Hose Drawing"](#) .

OK or NG

- OK (With CONSULT-II)>>GO TO 16.
- OK (Without CONSULT-II)>>GO TO 17.
- NG >> Repair or reconnect the hose.

16. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

With CONSULT-II

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

- OK >> GO TO 18.
- NG >> GO TO 17.


ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y


17. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

 With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0 %	Yes
0.0%	No




 Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No



OK or NG


OK >> GO TO 18.

NG >> Replace EVAP canister purge volume control solenoid valve.

18. CHECK FUEL TANK TEMPERATURE SENSOR

1. Remove fuel level sensor unit.
2. Check resistance between fuel level sensor unit terminals 1 and 4 by heating with hot water or heat gun as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90



OK or NG

- OK >> GO TO 19.
- NG >> Replace fuel level sensor unit.

19. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Turn ignition switch "ON".
4. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
5. Check input voltage between ECM terminal 62 and ground.


Applied vacuum	Voltage V
Not applied	1.8 - 4.8
-26.7 kpa (-200 mmHg, -7.87 inHg)	2.1 to 2.5V lower than above value

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-700 mmHg, -27.56 inHg) or over 101.3 kPa (760 mmHg, 29.92 inHg) of pressure.

OK or NG

- OK >> GO TO 20.
- NG >> Replace EVAP control system pressure sensor.



20. CHECK EVAP PURGE LINE

Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 21.
- NG >> Repair or reconnect the hose.

21. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 22.

22. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

OK >> GO TO 23.

NG >> Replace fuel level sensor unit.

23. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L

M


DTC P1464 FUEL LEVEL SENSOR

UBS008JF

Component Description

The fuel level sensor is mounted in the fuel level sensor unit. The sensor detects a fuel level in the fuel tank and transmits a signal to the ECM.

It consists of two parts, one is mechanical float and the other side is variable resistor. Fuel level sensor output voltage changes depending on the movement of the fuel mechanical float.



UBS008JG

On Board Diagnosis Logic

ECM receives two signals from the fuel level sensor.

One is fuel level sensor power supply circuit, and the other is fuel level sensor ground circuit.

This diagnosis indicates the latter to detect open circuit malfunction.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1464	Fuel level sensor circuit ground signal	A high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted)

DTC Confirmation Procedure

UBS008JH

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

④ WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-1670, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
FUEL T/TMP SE	XXX °C
FUEL LEVEL SE	XXX V

SEF195Y

④ WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P1464 FUEL LEVEL SENSOR

[VG33ER]



Wiring Diagram

UBS008J1

EC-FLS3-01



Refer to the following.
F29 - ELECTRICAL UNITS



DTC P1464 FUEL LEVEL SENSOR

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	G	Fuel level sensor	[Ignition switch ON]	Approximately 0 - 4.8V Output voltage varies with fuel level.
66	B	Fuel level sensor ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure

UBS008JJ

1. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and body ground. Refer to Wiring Diagram.
Continuity should exist.
4. Also check harness for short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F36, M81
- Harness for open and short between ECM and body ground

>> Replace open circuit or short to power in harness or connectors.

3. CHECK FUEL LEVEL SENSOR

Refer to [DI-17, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Replace fuel level sensor unit.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

Removal and Installation FUEL LEVEL SENSOR

UBS008JK

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

DTC P1490 VACUUM CUT VALVE BYPASS VALVE

PFP:17372

Description

UBS008JL


COMPONENT DESCRIPTION

The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.


The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.



EVAPORATIVE EMISSION SYSTEM DIAGRAM



CONSULT-II Reference Value in Data Monitor Mode

UBS008JM

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VC/V BYPASS/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

UBS008JN

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1490	Vacuum cut valve bypass valve circuit	An improper voltage signal is sent to ECM through vacuum cut valve bypass valve.	<ul style="list-style-type: none"> ● Harness or connectors (The vacuum cut valve bypass valve circuit is open or shorted) ● Vacuum cut valve bypass valve

DTC Confirmation Procedure

UBS008JO

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle speed.

DTC P1490 VACUUM CUT VALVE BYPASS VALVE

[VG33ER]

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-1674, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II".


DTC P1490 VACUUM CUT VALVE BYPASS VALVE

[VG33ER]


Wiring Diagram

UBS008.JP

EC-BYPS/V-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 15
- LP : 17



Refer to the following.
E43 - SUPER MULTIPLE JUNCTION (SMJ)

WBWA0039E

DTC P1490 VACUUM CUT VALVE BYPASS VALVE

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
120	P/B	Vacuum cut valve bypass valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS008JQ

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK VACUUM CUT VALVE BYPASS VALVE CIRCUIT

With CONSULT-II

1. Turn ignition switch "OFF" and then "ON".
2. Select "VC/V BYPASS/V" in "ACTIVE TEST" mode with CONSULT-II.
3. Touch "ON/OFF" on CONSULT-II screen.
4. Make sure that clicking sound is heard from the vacuum cut valve bypass valve.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 3.


ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	XXX V

SEF014Z

3. CHECK VACUUM CUT VALVE BYPASS VALVE POWER SUPPLY CIRCUIT

⊗ Without CONSULT-II

1. Turn ignition switch "OFF".
2. Disconnect vacuum cut valve bypass valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M67, B101
- Harness connectors B113, C3
- Fuse block (J/B) connector E49
- 10A fuse
- Harness for open or short between vacuum cut valve bypass valve and fuse

>> Repair harness or connectors.

5. CHECK VACUUM CUT VALVE BYPASS VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 120 and vacuum cut valve bypass valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors C3, B113
- Harness connectors B101, M67
- Harness connectors M81, F36
- Harness for open or short between vacuum cut valve bypass valve and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK VACUUM CUT VALVE BYPASS VALVE

With CONSULT-II

1. Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.


ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	XXX V

SEF014Z

2. Check air passage continuity and operation delay time under the following conditions.

Condition VC/V BYPASS/V	Air passage continuity between A and B
ON	Yes
OFF	No

Operation takes less than 1 second.



Without CONSULT-II


Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

Operation takes less than 1 second.

OK or NG

- OK >> GO TO 8.
- NG >> Replace vacuum cut valve bypass valve.



8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

Description


COMPONENT DESCRIPTION

The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.


The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.



EVAPORATIVE EMISSION SYSTEM DIAGRAM



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VC/V BYPASS/V	● Ignition switch: ON	OFF

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1491	Vacuum cut valve bypass valve	Vacuum cut valve bypass valve does not operate properly.	<ul style="list-style-type: none"> ● Vacuum cut valve bypass valve ● Vacuum cut valve ● Bypass hoses for clogging ● EVAP control system pressure sensor and circuit ● EVAP canister vent control valve ● Hose between fuel tank and vacuum cut valve clogged ● Hose between vacuum cut valve and EVAP canister clogged ● EVAP canister ● EVAP purge port of fuel tank for clogging ● Refueling control valve ● Refueling EVAP vapor cut valve

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:


If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always perform test at a temperature of 5 to 30°C (41 to 86°F).

WITH CONSULT-II

1. Turn ignition switch ON.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF and wait at least 5 seconds.
4. Start engine and let it idle for at least 70 seconds.
5. Select “VC CUT/V BP/V P1491” of “EVAPORATIVE SYSTEM” in “DTC WORK SUPPORT” mode with CONSULT-II.
6. Touch “START”.



7. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take at least 30 seconds.)

CMPS-RPM (POS)	More than 500 rpm
Selector lever	Suitable position
Vehicle speed	More than 37 km/h (23 MPH)
B/FUEL SCHDL	1.0 - 11.0 msec

If “TESTING” is not displayed after 5 minutes, retry from step 3.


8. Make sure that “OK” is displayed after touching “SELF-DIAG RESULTS”. If “NG” is displayed, refer to [EC-1681, "Diagnostic Procedure"](#).

Overall Function Check

Use this procedure to check the overall function of vacuum cut valve bypass valve. During this check, the 1st trip DTC might not be confirmed.

WITH GST

1. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
2. Apply vacuum to port **A** and check that there is no suction from port **B**.
3. Apply vacuum to port **B** and check that there is suction from port **A**.
4. Blow air in port **B** and check that there is a resistance to flow out of port **A**.
5. Supply battery voltage to the terminal.
6. Blow air in port **A** and check that air flows freely out of port **B**.
7. Blow air in port **B** and check that air flows freely out of port **A**.
8. If NG, go to [EC-1681, "Diagnostic Procedure"](#).




DTC P1491 VACUUM CUT VALVE BYPASS VALVE

[VG33ER]


Wiring Diagram

UBS006JW

EC-BYPS/V-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- EP : EARLY PRODUCTION
- LP : LATE PRODUCTION
- *1 EP : 15
- LP : 17



Refer to the following.
 E49 - SUPER MULTIPLE JUNCTION (SMJ)



WBWA0039E

DTC P1491 VACUUM CUT VALVE BYPASS VALVE

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
120	P/B	Vacuum cut valve bypass valve	[Ignition switch ON]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS008JX

1. INSPECTION START

Do you have CONSULT-II?


Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK VACUUM CUT VALVE BYPASS VALVE OPERATION

 **With CONSULT-II**

1. Turn ignition switch OFF.
2. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
3. Apply vacuum to port A and check that there is no suction from port B.
4. Apply vacuum to port B and check that there is suction from port A.
5. Blow air in port B and check that there is a resistance to flow out of port A.
6. Turn ignition switch ON.
7. Select "VC/V BYPASS/V" in "ACTIVE TEST" mode with CONSULT-II and touch "ON".
8. Blow air in port A and check that air flows freely out of port B.
9. Blow air in port B and check that air flows freely out of port A.



ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	XXX V

SEF017Z


OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.

3. CHECK VACUUM CUT VALVE BYPASS VALVE OPERATION

⊗ **Without CONSULT-II**

1. Turn ignition switch OFF.
2. Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
3. Apply vacuum to port A and check that there is no suction from port B.
4. Apply vacuum to port B and check that there is suction from port A.
5. Blow air in port B and check that there is a resistance to flow out of port A.
6. Disconnect vacuum cut valve bypass valve harness connector.
7. Supply battery voltage to the terminal.
8. Blow air in port A and check that air flows freely out of port B.
9. Blow air in port B and check that air flows freely out of port A.



OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.

4. CHECK EVAP PURGE LINE

1. Check EVAP purge line between EVAP canister and fuel tank for clogging or disconnection.
2. Check EVAP purge port of fuel tank for clogging.
3. Check EVAP canister. Refer to [EC-1734, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG (Step 1)>>Repair it.
- NG (Step 2)>>Clean EVAP purge port.
- NG (Step 3)>>Replace EVAP canister.

5. CHECK BYPASS HOSE

Check bypass hoses for clogging.

OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace hoses.

6. CHECK VACUUM CUT VALVE BYPASS VALVE

With CONSULT-II


1. Perform "VC/V BYPASS/V" in "ACTIVE TEST" mode.

ACTIVE TEST	
VC/V BYPASS/V	OFF
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	LEAN
HO2S1 MNTR (B2)	LEAN
THRTL POS SEN	XXX V
<small>SEF014Z</small>	

2. Check air passage continuity and operation delay time under the following conditions.

Condition VC/V BYPASS/V	Air passage continuity between A and B
ON	Yes
OFF	No

Operation takes less than 1 second.



Without CONSULT-II


Check air passage continuity and operation delay time under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

Operation takes less than 1 second.

OK or NG


- OK >> GO TO 7.
- NG >> Replace vacuum cut valve bypass valve.



7. CHECK VACUUM CUT VALVE

Check vacuum cut valve as follows:

1. Plug port **C** and **D** with fingers.
2. Apply vacuum to port **A** and check that there is no suction from port **B**.
3. Apply vacuum to port **B** and check that there is suction from port **A**.
4. Blow air in port **B** and check that there is a resistance to flow out of port **A**.
5. Open port **C** and **D**.
6. Blow air in port **A** check that air flows freely out of port **C**.
7. Blow air in port **B** check that air flows freely out of port **D**.



OK or NG

- OK >> GO TO 8.
 NG >> Replace vacuum cut valve.

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR HOSE

1. Turn ignition switch OFF.
2. Check disconnection or improper connection of hose connected to EVAP control system pressure sensor.

OK or NG


- OK >> GO TO 9.
 NG >> Repair or replace.

9. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.
Water should not exist.

OK or NG

- OK >> GO TO 10.
 NG >> Replace EVAP control system pressure sensor.



10. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION

Refer to "DTC Confirmation Procedure" for DTC P0452 [EC-1513](#) or DTC P0453 [EC-1519](#).

OK or NG

- OK >> GO TO 11.
 NG >> Replace EVAP control system pressure sensor.


11. CHECK EVAP CANISTER VENT CONTROL VALVE

With CONSULT-II

1. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode.
2. Check air passage continuity and operation delay time.

Condition VENT CONTROL/V	Air passage continuity between A and B
ON	No
OFF	Yes

Operation takes less than 1 second.



Without CONSULT-II

1. Check air passage continuity and operation delay time under the following condition.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
OFF	Yes

Operation takes less than 1 second.

If NG or operation takes more than 1 second, clean valve using air blower or replace as necessary.


If portion **B** is rusted, replace control valve.

Make sure new O-ring is installed properly.

OK or NG


OK >> GO TO 12.

NG >> Replace EVAP canister vent control valve.



12. CHECK REFUELING CONTROL VALVE

1. Remove fuel filler cap.
2. Check air continuity between hose ends A and B.
Blow air into the hose end B. Air should flow freely into the fuel tank.
3. Blow air into hose end A and check there is no leakage.
4. Apply pressure to both hose ends A and B [20 kPa (150 mmHg, 5.91 inHg)] using a pressure pump and a suitable 3-way connector. Check that there is no leakage.



OK or NG

OK (With CONSULT-II) >> GO TO 13.


OK (Without CONSULT-II) >> GO TO 14.

NG >> Replace refueling control valve with fuel tank.

13. CHECK REFUELING EVAP VAPOR CUT VALVE

With CONSULT-II

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel feed hose located on the fuel level sensor unit retainer.
 - Connect a spare fuel hose, one side to fuel level sensor unit retainer where the hose was removed and the other side to a fuel container.
 - Drain fuel using "FUEL PUMP RELAY" in "ACTIVE TEST" mode with CONSULT-II.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.
Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
Always replace O-ring with new one.
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level sensor unit retainer remaining open and check that the pressure is applicable.




OK or NG

- OK >> GO TO 15.
 NG >> Replace refueling EVAP vapor cut valve with fuel tank.

14. CHECK REFUELING EVAP VAPOR CUT VALVE

⊗ Without CONSULT-II

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel level sensor unit retainer.
 - Drain fuel from the tank using a hand pump into a fuel container.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.
Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
Always replace O-ring with new one.
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level sensor unit retainer remaining open and check that the pressure is applicable.



OK or NG

- OK >> GO TO 15.
 NG >> Replace refueling EVAP vapor cut valve with fuel tank.

15. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

PFP:23710

Component Description

EBS00GNN

The malfunction information related to A/T (Automatic Transmission) is transferred through the line (circuit) from TCM (Transmission control module) to ECM. Therefore, be sure to erase the malfunction information such as DTC not only in TCM (Transmission control module) but also ECM after the A/T related repair.

On Board Diagnosis Logic

EBS00GNO

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1605	A/T diagnosis communication line	An incorrect signal from TCM (Transmission Control Module) is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors [The communication line circuit between ECM and TCM (Transmission Control Module) is open or shorted.] ● Dead (Weak) battery ● TCM (Transmission Control Module)

DTC Confirmation Procedure

EBS00GNP

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait at least 70 seconds.
4. If 1st trip DTC is detected, go to [EC-1693, "Diagnostic Procedure"](#).

ACTIVE TEST	
PURG VOL CONT/V	0.0%
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
A/F ALPHA-B2	XXX %
HO2S1 MNTR (B1)	RICH
HO2S1 MNTR (B2)	RICH
THRTL POS SEN	XXX V

SEF985Y

WITH GST

Follow the procedure "With CONSULT-II".



DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

[VG33ER]

EBS00GNO

Wiring Diagram WITHOUT VDC

EC-ATDIAG-01



WBWA0040E

DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
7	Y/G	A/T check signal	[Ignition switch ON] [Engine is running]	0 - 3.0V

A

EC

C

D

E

F

G

H

I

J

K

L




M



DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

[VG33ER]

WITH VDC

EC-CAN-01

-  : DETECTABLE LINE FOR DTC
-  : NON-DETECTABLE LINE FOR DTC
-  : DATA LINE



BBWA0503E

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
68	W/G	A/T signal	[Ignition switch ON] ● Idle speed	0 - 5.0V

Diagnostic Procedure

EBS00GNR

1. CHECK A/T DIAGNOSIS COMMUNICATION LINE INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector and TCM (Transmission Control Module) harness connector.




3. Check harness continuity between ECM terminal 7 and TCM terminal 15. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M58, F28
- Harness for open or short between ECM and TCM (Transmission Control Module)

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

DTC P1706 PNP SWITCH

PFP:32006


Component Description

UBS008K3

When the gear position is “P” (A/T models only) or “N”, park/neutral position (PNP) switch is “ON”.

ECM detects the position because the continuity of the line (the “ON” signal) exists.

For A/T models, the park/neutral position (PNP) switch assembly also includes a transmission range switch to detect selector lever position.



CONSULT-II Reference Value in Data Monitor Mode

UBS008K4

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: “P” or “N”	ON
		Except above	OFF

On Board Diagnosis Logic

UBS008K5

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1706	Park/neutral position switch	The signal of the park/neutral position (PNP) switch is not changed in the process of engine starting and driving.	<ul style="list-style-type: none"> ● Harness or connectors [The park/neutral position (PNP) switch circuit is open or shorted.] ● Park/neutral position (PNP) switch

DTC Confirmation Procedure

UBS008K6

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch OFF and wait at least 5 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select “P/N POSI SW” in “DATA MONITOR” mode with CONSULT-II. Then check the “P/N POSI SW” signal under the following conditions.

Position (Selector lever)	Known good signal
“N” and “P” position	ON
Except the above position	OFF

If NG, go to [EC-1697, "Diagnostic Procedure"](#) .
If OK, go to following step.

3. Select “DATA MONITOR” mode with CONSULT-II.
4. Start engine and warm it up to normal operating temperature.

DATA MONITOR	
MONITOR	NO DTC
P/N POSI SW	ON

SEF212Y

DTC P1706 PNP SWITCH

[VG33ER]

5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	1,400 - 2,700 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	2.0 - 14.0 msec
VHCL SPEED SE	More than 64 km/h (40 MPH)
Selector lever	Suitable position

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF
B/FUEL SCHDL	XXX msec

SEF213Y

6. If 1st trip DTC is detected, go to [EC-1697, "Diagnostic Procedure"](#).

Overall Function Check

UBS008K7


Use this procedure to check the overall function of the park/neutral position (PNP) switch circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

- Turn ignition switch ON.
- Check voltage between ECM terminal 22 and body ground under the following conditions.

Condition (Gear position)	Voltage (V) (Known good data)
"P" and "N" position	Approx. 0
Except the above position	Approx. 5

3. If NG, go to [EC-1697, "Diagnostic Procedure"](#).



DTC P1706 PNP SWITCH



[VG33ER]

UBS008K8

Wiring Diagram

- : With vehicle security system
- : Without vehicle security system
- : With A/T
- : With M/T
- : EARLY PRODUCTION
- : LATE PRODUCTION
- *1 : 12
- : 14

EC-PNP/SW-01



WBWA0041E

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22	L/B	Park/neutral position (PNP) switch	[Ignition switch ON] ● Gear position is "N" or "P"	Approximately 0V
			[Ignition switch ON] ● Except the above gear position	Approximately 5V

Diagnostic Procedure FOR M/T MODELS

UBS008K9

1. CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch OFF.
2. Disconnect park/neutral position (PNP) switch harness connector.
3. Check harness continuity between PNP switch terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F201, F43
- Harness for open between park/neutral position (PNP) switch and engine ground

>> Repair open circuit or short to power in harness or connectors.

3. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 22 and PNP switch terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F43, F201
- Harness for open or short between ECM and park/neutral position (PNP) switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK PARK/NEUTRAL POSITION (PNP) SWITCH

Refer to [MT-46, "Position Switch Check"](#) .

OK or NG

- OK >> GO TO 6.
 NG >> Replace park/neutral position (PNP) switch.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

FOR A/T MODELS


1. CHECK PNP SWITCH POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF.
2. Disconnect park/neutral position (PNP) relay.
3. Turn ignition switch ON.
4. Shift selector lever to "P" or "N" position.
5. Check voltage between PNP relay terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
 NG >> GO TO 2.



2. CHECK PNP SWITCH POWER SUPPLY CIRCUIT-II


1. Turn ignition switch OFF.
2. Disconnect park/neutral position (PNP) switch harness connector.
3. Check harness continuity between PNP switch terminal 2 and PNP relay terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK PNP SWITCH POWER SUPPLY CIRCUIT-III

1. Turn ignition switch ON.
2. Check voltage between PNP switch terminal 1 and ground with CONSULT-II or tester. Refer to Wiring Diagram.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E49
- 7.5A fuse
- Harness for open or short between PNP switch and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK PARK/NEUTRAL POSITION (PNP) SWITCH

Refer to [AT-103, "PNP SWITCH"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace park/neutral position (PNP) switch.

6. CHECK PNP RELAY GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check harness continuity between PNP relay terminals 1, 6 and body ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 8.

NG (With vehicle security system)>>GO TO 7

NG (Without vehicle security system)>>Repair open circuit or short to power in harness or connectors.

7. DETECT MALFUNCTIONING PART

Check the circuit between PNP relay and body ground.

Refer to [SC-9, "STARTING SYSTEM"](#) .

OK or NG

OK >> GO TO 11.

NG >> Repair or replace.

8. CHECK PNP RELAY INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 22 and PNP relay terminal 7. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F36, M81
- Harness connectors M65, E43
- Harness for open or short between ECM and park/neutral position (PNP) relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK PARK/NEUTRAL POSITION (PNP) RELAY


1. Apply 12V direct current between park/neutral position (PNP) relay terminals 1 and 2.
2. Check continuity between park/neutral position (PNP) relay terminals 3 and 5, 6 and 7.

12V (1 and 2) applied : Continuity should exist.
No voltage applied : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Replace park/neutral position (PNP) relay.

**11. CHECK INTERMITTENT INCIDENT**

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

IGNITION SIGNAL

Component Description

IGNITION COIL & POWER TRANSISTOR


The power transistor switches on and off the ignition coil primary circuit according to the ECM signal. As the primary circuit is turned on and off, the proper high voltage is induced in the secondary circuit. The distributor is not repairable except for the distributor cap and rotor head.

NOTE:

The rotor screw which secures the distributor rotor head to the distributor shaft must be torqued properly.



: 3.6±0.3 N·m (37±3 kg-cm, 32±3 in-lb)



A
EC
C
D
E
F
G
H
I
J
K
L
M






IGNITION SIGNAL

[VG33ER]


UBS008KB

Wiring Diagram

EC-IGN/SG-01



Refer to the following.
 (E43) - SUPER MULTIPLE JUNCTION (SMJ)



BBWA0496E



IGNITION SIGNAL

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	PU/W	Ignition signal	[Engine is running] ● Idle speed	Approximately 0.7V★ 
			[Engine is running] ● Engine speed is 2,000 rpm	1.1 - 1.5V★ 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

UBS008KC

1. INSPECTION START

Turn ignition switch "OFF", and restart engine.

Is engine running?

Yes or No

- Yes (With CONSULT-II)>>GO TO 2.
- Yes (Without CONSULT-II)>>GO TO 3.
- No >> GO TO 4.

2. CHECK OVERALL FUNCTION

 **With CONSULT-II**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
2. Make sure that all circuits do not produce a momentary engine speed drop.

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 4.



ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step

SEF070Y

3. CHECK OVERALL FUNCTION

⊗ **Without CONSULT-II**

1. Let engine idle.
2. Read the voltage signal between ECM terminal 1 and ground with an oscilloscope.
3. Verify that the oscilloscope screen shows the signal wave as shown below.




OK or NG

- OK >> **INSPECTION END.**
- NG >> **GO TO 4.**

4. CHECK IGNITION COIL POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ignition coil harness connector.
3. Turn ignition switch ON.




4. Check voltage between terminal 7 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E43, M65
- Harness connectors M59, F27
- Harness for open or short between ignition coil and ignition switch

>> Repair harness or connectors.

6. CHECK POWER TRANSISTOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect power transistor harness connector.
3. Check harness continuity between power transistor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to power in harness or connectors.

7. CHECK INPUT SIGNAL CIRCUIT

1. Strip tape covering resistor.
2. Disconnect resistor harness connector.
3. Check harness continuity between ignition coil terminal 8 and resistor terminal 1, resistor terminal 2 and ECM terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK RESISTOR


Check resistance between resistor terminals 1 and 2.

Resistance : Approximately 2.2 kΩ [at 25°C (77°F)]

OK or NG

OK >> GO TO 9.

NG >> Replace resistor.



9. CHECK POWER TRANSISTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 1 and power transistor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG


OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK IGNITION COIL

1. Disconnect ignition coil harness connector.
2. Check resistance as shown in the figure.


Terminal	Resistance [at 20°C (68°F)]
7 - 8 (Primary coil)	Approx. 1.0Ω
7 - 9 (secondary coil)	Approx. 10 kΩ



For checking secondary coil, remove distributor cap and measure resistance between coil tower metal tip 9 and terminal 7.

OK or NG

- OK >> GO TO 11.
 NG >> Replace distributor assembly.




11. CHECK POWER TRANSISTOR

1. Disconnect camshaft position sensor & power transistor harness connector and ignition coil harness connector.
2. Check power transistor resistance between terminals 2 and 8.

Terminals	Resistance	Result
2 and 8	Except 0Ω	OK
	0Ω	NG

OK or NG

- OK >> GO TO 12.
 NG >> Replace distributor assembly.



12. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation DISTRIBUTOR


Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

UBS008KD

INJECTOR CIRCUIT

Component Description

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the ball valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
INJ PULSE-B1 INJ PULSE-B2	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	2.4 - 3.7 msec
		2,000 rpm	1.9 - 3.3 msec
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	1.0 - 1.6 msec
		2,000 rpm	0.7 - 1.4 msec





INJECTOR CIRCUIT

[VG33ER]

Wiring Diagram

UBS008KG

EC-INJECT-01



BBWA0515E

INJECTOR CIRCUIT

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
102	W/B	Injector No. 1	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE★ (11 - 14V)</p> <p>SEF007V</p>
104	W/R	Injector No. 3		<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm
106	W/G	Injector No. 5		
109	W/L	Injector No. 2		
111	W/PU	Injector No. 4		
113	W	Injector No. 6		

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

UBS008KH

1. INSPECTION START

Turn ignition switch to START.

Is any cylinder ignited?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step


SEF070Y

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.
Clicking noise should be heard.

OK or NG

- OK >> **INSPECTION END.**
 NG >> GO TO 3.




3. CHECK INJECTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect injector harness connector.
3. Check voltage between injector terminal 1 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M59, F27
- Harness connectors F37, F101
- Fuse block (J/B) connector M26
- 10A fuse
- Harness for open or short between injector and fuse

>> Repair harness or connectors.

5. CHECK INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between injector terminal 2 and ECM terminals 102, 104, 106, 109, 111, 113. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F37, F101
- Harness connectors F38, F102
- Harness for open or short between ECM and injector

>> Repair open circuit or short to ground or short to power in harness or connectors.


7. CHECK INJECTOR

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance : 10 - 14Ω [at 25°C (77°F)]

OK or NG

- OK >> GO TO 8.
- NG >> Replace injector.



8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation INJECTOR

Refer to [EM-78, "OUTER COMPONENT PARTS"](#) .

START SIGNAL

[VG33ER]

START SIGNAL

PF:48750

CONSULT-II Reference Value in Data Monitor Mode

UBS008KJ

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
START SIGNAL	● Ignition switch: ON → START → ON	OFF → ON → OFF

START SIGNAL


[VG33ER]

Wiring Diagram



UBS008KK

EC-S/SIG-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



- : Detectable line for DTC
- : Non-detectable line for DTC
- : EARLY PRODUCTION
- : LATE PRODUCTION



WBWA0042E

START SIGNAL

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLO R	ITEM	CONDITION	DATA (DC Voltage)
20	L/OR	Start signal	[Ignition switch ON]	Approximately 0V
			[Ignition switch START]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

UBS008KL

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

 **With CONSULT-II**

- Turn ignition switch ON.
- Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.

Condition	"START SIGNAL"
Ignition switch "ON"	OFF
Ignition switch "START"	ON

DATA MONITOR	
MONITOR	NO DTC
START SIGNAL	OFF
CLSD THL POS	ON
AIR COND SIG	OFF
P/N POSI SW	ON

PBIB0182E

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 4.

3. CHECK OVERALL FUNCTION


 **Without CONSULT-II**

Check voltage between ECM terminal 20 and ground under the following conditions.

Condition	Voltage
Ignition switch START	Battery voltage
Other positions	Approx. 0V

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 4.



4. CHECK STARTING SYSTEM

Turn ignition switch OFF, then turn it to START.

Does starter motor operate?

Yes or No

- Yes >> GO TO 5.
- No >> Refer to [SC-9, "STARTING SYSTEM"](#).

5. CHECK FUSE

1. Turn ignition switch OFF.
2. Disconnect 7.5A fuse.
3. Check if 7.5A fuse is OK.

OK or NG

- OK >> GO TO 6.
NG >> Replace 7.5A fuse.

6. CHECK START SIGNAL INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 20 and fuse block. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M81, F36
- Harness for open or short between ECM and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

A

EC

C

D

E

F

G

H

I

J

K

L

M

FUEL PUMP CIRCUIT

[VG33ER]

FUEL PUMP CIRCUIT

PF17042

Description SYSTEM DESCRIPTION

UBS008KM


Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Fuel pump control	Fuel pump relay
Ignition switch	Start signal		

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a 120° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to operate. If the 120° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds
Engine running and cranking	Operates
When engine is stopped	Stops in 1.5 seconds
Except as shown above	Stops

COMPONENT DESCRIPTION

The fuel pump with a fuel damper is an in-tank type (the pump and damper are located in the fuel tank).



CONSULT-II Reference Value in Data Monitor Mode

UBS008KN

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> ● Ignition switch is turned to ON. (Operates for 5 seconds.) ● Engine running and cranking 	ON
	Except as shown above	OFF


FUEL PUMP CIRCUIT

[VG33ER]

UBS008KO


Wiring Diagram

EC-F/PUMP-01



- : Detectable line for DTC
- : Non-detectable line for DTC
- : EARLY PRODUCTION
- : LATE PRODUCTION

A
EC
C
D
E
F
G
H
I
J
K
L
M



WBWA0043E

FUEL PUMP CIRCUIT

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
11	W/R	Fuel pump relay	[Ignition switch ON] ● For 5 seconds after turning ignition switch ON [Engine is running]	0 - 1V
			[Ignition switch ON] ● More than 5 seconds after turning ignition switch ON	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


UBS008KP

1. CHECK OVERALL FUNCTION

- Turn ignition switch "ON".
- Pinch fuel feed hose with fingers.
Fuel pressure pulsation should be felt on the fuel feed hose for 5 seconds after ignition switch is turned "ON".


OK or NG

- OK >> **INSPECTION END.**
 NG >> GO TO 2.



2. CHECK FUEL PUMP RELAY POWER SUPPLY CIRCUIT

- Turn ignition switch "OFF".
- Disconnect fuel pump relay.
- Turn ignition switch "ON".




- Check voltage between terminals 2, 5 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector M31
- 15A fuse
- Harness for open or short between fuse and fuel pump relay

>> Repair harness or connectors.

4. CHECK FUEL PUMP POWER SUPPLY AND GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect fuel pump harness connector.
3. Check harness continuity between fuel pump terminal 2 and body ground, fuel pump terminal 1 and fuel pump relay terminal 3. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B101, M67
- Harness for open or short between fuel pump and body ground
- Harness for open or short between fuel pump and fuel pump relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK FUEL PUMP RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 11 and fuel pump relay terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.


- Harness connectors M81, F36
- Harness for open or short between ECM and fuel pump relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK FUEL PUMP RELAY

With CONSULT-II

1. Reconnect fuel pump relay, fuel pump harness connector and ECM harness connector.
2. Turn ignition switch "ON".
3. Turn fuel pump relay "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.




Without CONSULT-II

Check continuity between terminals 3 and 5.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

OK or NG

- OK >> GO TO 9.
 NG >> Replace fuel pump relay.




9. CHECK FUEL PUMP

1. Disconnect fuel pump harness connector.
2. Check resistance between terminals 1 and 2.

Resistance : 0.2 - 5.0Ω [at 25°C (77°F)]

OK or NG

- OK >> GO TO 10.
 NG >> Replace fuel pump.



10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

Removal and Installation FUEL PUMP

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT AND FUEL PUMP ASSEMBLY"](#) .

POWER STEERING OIL PRESSURE SWITCH

[VG33ER]


PF:49761

UBS008KR

POWER STEERING OIL PRESSURE SWITCH

Component Description

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the IACV-AAC valve to increase the idle speed and adjust for the increased load.



CONSULT-II Reference Value in Data Monitor Mode

UBS008KS

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel in neutral position (forward direction) OFF
		The steering wheel is fully turned. ON




POWER STEERING OIL PRESSURE SWITCH

[VG33ER]

UBS008KT

Wiring Diagram

EC-PST/SW-01



BBWA0500E

POWER STEERING OIL PRESSURE SWITCH

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
39	GY/R	Power steering oil pressure switch	[Engine is running] ● Steering wheel is being turned	Approximately 0V
			[Engine is running] ● Steering wheel is not being turned	Approximately 5V

Diagnostic Procedure

UBS008KU

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION


With CONSULT-II

- Start engine.
- Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT-II.

Condition	PW/ST SIGNAL
Steering is in neutral position	OFF
Steering is turned	ON

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 4.



3. CHECK OVERALL FUNCTION


Without CONSULT-II

- Start engine.
- Check voltage between ECM terminal 39 and ground.

Condition	Voltage [V]
Steering is neutral position	Approx. 5
Steering is turned to full position	Approx. 0

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 4.



4. CHECK POWER STEERING OIL PRESSURE SWITCH GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch OFF.
2. Disconnect power steering oil pressure switch harness connector.
3. Check harness continuity between power steering oil pressure switch terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
 NG >> Repair open circuit or short to power in harness or connectors.



5. CHECK POWER STEERING OIL PRESSURE SWITCH INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 39 and power steering oil pressure switch terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.


6. CHECK POWER STEERING OIL PRESSURE SWITCH

1. Disconnect power steering oil pressure switch harness connector then start engine.
2. Check continuity between terminals 1 and 2.

Conditions	Continuity
Steering wheel is being fully turned	Yes
Steering wheel is not being turned	No

OK or NG

- OK >> GO TO 7.
 NG >> Replace power steering oil pressure switch.



7. CHECK INTERMITTENT INCIDENT


Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END.**

IACV-FICD SOLENOID VALVE

Component Description

When the air conditioner is on, the IACV-FICD solenoid valve supplies additional air to adjust to the increased load.



A

EC

C

D

E

F

G

H

I

J

K

L

M



IACV-FICD SOLENOID VALVE

[VG33ER]

UBS008KW

Wiring Diagram

EC-FICD-01



WBWA0048E

IACV-FICD SOLENOID VALVE

[VG33ER]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than the ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
9	B/Y	Ambient air temperature switch	[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is above 25°C (77°F) ● Air conditioner is operating 	0V
			[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is below 19°C (66°F) ● Air conditioner is operating 	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] <ul style="list-style-type: none"> ● Idle speed ● Ambient air temperature is below 19°C (66°F) ● Air conditioner is not operating 	Approximately 5V
12	P	Air conditioner relay	[Engine is running] <ul style="list-style-type: none"> ● Both A/C switch and blower switch are ON* 	0 - 1V
			[Engine is running] <ul style="list-style-type: none"> ● A/C switch is OFF 	BATTERY VOLTAGE (11 - 14V)


*: Any mode except OFF, ambient air temperature is above 25°C (77°F).

Diagnostic Procedure

UBS008KX

1. CHECK OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.
750±50 rpm (in "P" or "N" position)
 If NG, adjust idle speed.
3. Turn air conditioner switch and blower fan switch ON.
4. Recheck idle speed.
850 rpm or more (in "P" or "N" position)



SEF742U

OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 2.

2. CHECK AIR CONDITIONER FUNCTION


Check if air conditioner compressor functions normally.

OK or NG

- OK >> GO TO 3.
- NG >> Refer to [MTC-25. "SYMPTOM TABLE"](#).

3. CHECK IACV-FICD SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn air conditioner switch and blower fan switch OFF.
2. Stop engine.
3. Disconnect IACV-FICD solenoid valve harness connector.
4. Start engine, then turn air conditioner switch and blower fan switch ON.




5. Check voltage between terminal 2 and ground with CONSULT-II or tester.

Voltage : Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F38, F102
- Harness for open or short between IACV-FICD solenoid valve and harness connector F27

>> Repair harness or connectors.

5. CHECK IACV-FICD SOLENOID VALVE GROUND CIRCUIT-I

1. Turn ignition switch OFF.
2. Disconnect ambient air temperature switch harness connector.
3. Check harness continuity between ambient air temperature switch terminal 1 and body ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to power in harness or connectors.

6. CHECK IACV-FICD SOLENOID VALVE GROUND CIRCUIT-II


1. Check harness continuity between ambient air temperature switch terminal 2 and IACV-FICD solenoid valve terminal 1.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.



7. DETECT MALFUNCTIONING PART


Check the following.

- Harness connectors F38, F102
- Harness connectors F36, M81
- Harness connectors M65, E43
- Diode-3
- Harness for open or short between IACV-FICD solenoid valve and ambient air temperature switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK IACV-FICD SOLENOID VALVE


1. Disconnect IACV-FICD solenoid valve harness connector.
2. Check for clicking sound when applying 12V direct current to terminals.
3. Check plunger for seizing or sticking.



4. Check for broken spring.

OK or NG

- OK >> GO TO 9.
- NG >> Replace IACV-FICD solenoid valve.



9. CHECK INTERMITTENT INCIDENT

Refer to [EC-1287, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END.

MIL AND DATA LINK CONNECTOR



[VG33ER]

MIL AND DATA LINK CONNECTOR



PF2:24814

Wiring Diagram

UBS008KZ




Refer to the following.
F29 - ELECTRICAL UNITS



EVAPORATIVE EMISSION SYSTEM

Description SYSTEM DESCRIPTION



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister.

The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank.


The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases.

EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.

EVAPORATIVE EMISSION SYSTEM

[VG33ER]

EVAPORATIVE EMISSION LINE DRAWING




NOTE:
Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.

PBIB1463E

EVAPORATIVE EMISSION SYSTEM

[VG33ER]




A
EC
C
D
E
F
G
H
I
J
K
L
M

AEC886A

Component Inspection EVAP CANISTER

Check EVAP canister as follows:


1. Pinch the fresh air hose.
2. Blow air into port **A** and check that it flows freely out of port **B**.



Tightening Torque


Tighten EVAP canister as shown in the figure.

Make sure new O-ring is installed properly between EVAP canister and EVAP canister vent control valve.



FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FULLER CAP)

1. Wipe clean valve housing.



2. Check valve opening pressure and vacuum.


Pressure: 15.3 - 20.0 kPa (0.156 - 0.204 kg/cm², 2.22 - 2.90 psi)

Vacuum: -6.0 to -3.3 kPa (-0.061 to -0.034 kg/cm², -0.87 to -0.48 psi)

3. If out of specification, replace fuel filler cap as an assembly.

CAUTION:

Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come ON



VACUUM CUT VALVE AND VACUUM CUT VALVE BYPASS VALVE

Refer to [EC-1671](#).

EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL SOLENOID VALVE


Refer to [EC-1500](#).

FUEL TANK TEMPERATURE SENSOR

Refer to [EC-1431](#).

EVAP SERVICE PORT

Positive pressure is delivered to the EVAP system through the EVAP service port. If fuel vapor leakage in the EVAP system occurs, use a leak detector to locate the leak.



How to Detect Fuel Vapor Leakage

UBS008L2

CAUTION:


- Never use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in EVAP system.

NOTE:


- Do not start engine.
- Improper installation of EVAP service port adapter to the EVAP service port may cause a leak.

Ⓟ WITH CONSULT-II

1. Attach the EVAP service port adapter securely to the EVAP service port.
2. Also attach the pressure pump and hose to the EVAP service port adapter.
3. Turn ignition switch "ON".
4. Select the "EVAP SYSTEM CLOSE" of "WORK SUPPORT MODE" with CONSULT-II.
5. Touch "START". A bar graph (Pressure indicating display) will appear on the screen.




6. Apply positive pressure to the EVAP system until the pressure indicator reaches the middle of the bar graph.
7. Remove EVAP service port adapter and hose with pressure pump.



EVAPORATIVE EMISSION SYSTEM


[VG33ER]

8. Locate the leak using a leak detector. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#) .




⊗ **WITHOUT CONSULT-II**

1. Attach the EVAP service port adapter securely to the EVAP service port.
2. Also attach the pressure pump with pressure gauge to the EVAP service port adapter.



3. Apply battery voltage to between the terminals of both EVAP canister vent control valve and vacuum cut valve bypass valve to make a closed EVAP system.
4. To locate the leak, deliver positive pressure to the EVAP system until pressure gauge points reach 1.38 to 2.76 kPa (0.014 to 0.028 kg/cm² , 0.2 to 0.4 psi).
5. Remove EVAP service port adapter and hose with pressure pump.
6. Locate the leak using a leak detector. Refer to [EC-1732, "EVAPORATIVE EMISSION LINE DRAWING"](#) .




ON BOARD REFUELING VAPOR RECOVERY (ORVR)

PFP:00032

System Description

UBS008L3



SEF206VA

From the beginning of refueling, the fuel tank pressure goes up. When the pressure reaches the setting value of the refueling control valve (RCV) opening pressure, the RCV is opened. After RCV opens, the air and vapor inside the fuel tank go through refueling EVAP vapor cut valve, RCV and refueling vapor line to the EVAP canister. The vapor is absorbed by the EVAP canister and the air is released to the atmosphere.

When the refueling has reached the full level of the fuel tank, the refueling EVAP vapor cut valve is closed and refueling is stopped because of auto shut-off. The vapor which was absorbed by the EVAP canister is purged during driving.

The RCV is always closed during driving and the evaporative emission control system is operated the same as conventional system.

WARNING:

When conducting inspections below, be sure to observe the following:

- Put a "CAUTION: INFLAMMABLE" sign in workshop.
- Do not smoke while servicing fuel system. Keep open flames and sparks away from work area.
- Be sure to furnish the workshop with a CO₂ fire extinguisher.

CAUTION:

- Before removing fuel line parts, carry out the following procedures:
 - Put drained fuel in an explosion-proof container and put lid on securely.
 - Release fuel pressure from fuel line. Refer to [EC-1207. "FUEL PRESSURE RELEASE"](#).
 - Disconnect battery ground cable.
- Always replace O-ring when the fuel gauge retainer is removed.
- Do not kink or twist hose and tube when they are installed.
- Do not tighten hose and clamps excessively to avoid damaging hoses.
- After installation, run engine and check for fuel leaks at connection.
- Do not attempt to top off the fuel tank after the fuel pump nozzle shuts off automatically. Continued refueling may cause fuel overflow, resulting in fuel spray and possibly a fire.

Diagnostic Procedure

SYMPTOM: FUEL ODOR FROM EVAP CANISTER IS STRONG.

1. CHECK EVAP CANISTER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Weigh the EVAP canister with EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG


- OK >> GO TO 2.
- NG >> GO TO 3.

2. CHECK IF EVAP CANISTER SATURATED WITH WATER

- Does water drain from the EVAP canister?

Yes or No

- Yes >> GO TO 3.
- No (With CONSULT-II) >> GO TO 6.
- No (Without CONSULT-II) >> GO TO 7.



3. REPLACE EVAP CANISTER

Replace EVAP canister with a new one.

>> GO TO 4.

4. CHECK WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.

NOTE:

- Do not disassemble water separator.

OK or NG

- OK >> GO TO 5.
- NG >> Replace water separator.



5. DETECT MALFUNCTIONING PART

Check the EVAP hose between EVAP canister and water separator for clogging or poor connection.


>> Repair or replace EVAP hose.

6. CHECK REFUELING EVAP VAPOR CUT VALVE

With CONSULT-II

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel feed hose located on the fuel level sensor unit retainer.
 - Connect a spare fuel hose, one side to fuel level sensor unit retainer where the hose was removed and the other side to a fuel container.
 - Drain fuel using "FUEL PUMP RELAY" in "ACTIVE TEST" mode with CONSULT-II.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.

Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
 - Always replace O-ring with new one.**
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level sensor unit retainer remaining open and check that the pressure is applicable.




OK or NG

- OK >> GO TO 8.
 NG >> Replace refueling EVAP vapor cut valve with fuel tank.

7. CHECK REFUELING EVAP VAPOR CUT VALVE

⊗ **Without CONSULT-II**

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#) .
2. Drain fuel from the tank as follows:
 - Remove fuel level sensor unit retainer.
 - Drain fuel from the tank using a hand pump into a fuel container.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.
Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
Always replace O-ring with new one.
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level sensor unit retainer remaining open and check that the pressure is applicable.




OK or NG

- OK >> GO TO 8.
 NG >> Replace refueling EVAP vapor cut valve with fuel tank.

8. CHECK REFUELING CONTROL VALVE

1. Remove fuel filler cap.
2. Check air continuity between hose ends A and B.
Blow air into the hose end B. Air should flow freely into the fuel tank.
3. Blow air into hose end A and check there is no leakage.
4. Apply pressure to both hose ends A and B [20 kPa (150 mmHg, 5.91 inHg)] using a pressure pump and a suitable 3-way connector. Check that there is no leakage.



OK or NG

OK >> **INSPECTION END.**

NG >> Replace refueling control valve with fuel tank.

SYMPTOM: CANNOT REFUEL/FUEL ODOR FROM THE FUEL FILLER OPENING IS STRONG WHILE REFUELING.

1. CHECK EVAP CANISTER

1. Remove EVAP canister with EVAP canister vent control valve attached.
2. Weigh the EVAP canister with EVAP canister vent control valve attached.
The weight should be less than 1.8 kg (4.0 lb).

OK or NG

OK >> GO TO 2.

NG >> GO TO 3.


2. CHECK IF EVAP CANISTER SATURATED WITH WATER

- Does water drain from the EVAP canister?

Yes or No

Yes >> GO TO 3.

No >> GO TO 6.



3. REPLACE EVAP CANISTER

Replace EVAP canister with a new one.

>> GO TO 4.

4. CHECK WATER SEPARATOR

1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Check that **A** and **C** are not clogged by blowing air into **B** with **A**, and then **C** plugged.
5. In case of NG in items 2 - 4, replace the parts.


NOTE:

- Do not disassemble water separator.

OK or NG

OK >> GO TO 5.

NG >> Replace water separator.



5. DETECT MALFUNCTIONING PART

Check the EVAP hose between EVAP canister and water separator for clogging or poor connection.

>> Repair or replace EVAP hose.

6. CHECK VENT HOSES AND VENT TUBES

Check hoses and tubes between EVAP canister and refueling control valve for clogging, kink, looseness and improper connection.

OK or NG

OK >> GO TO 7.

NG >> Repair or replace hoses and tubes.

7. CHECK FILLER NECK TUBE

Check signal line and recirculation line for clogging, dents and cracks.


OK or NG

OK >> GO TO 8.

NG >> Replace filler neck tube.

8. CHECK REFUELING CONTROL VALVE

1. Remove fuel filler cap.
2. Check air continuity between hose ends A and B.
Blow air into the hose end B. Air should flow freely into the fuel tank.
3. Blow air into hose end A and check there is no leakage.
4. Apply pressure to both hose ends A and B [20 kPa (150 mmHg, 5.91 inHg)] using a pressure pump and a suitable 3-way connector. Check that there is no leakage.



OK or NG

OK (With CONSULT-II)>>GO TO 9.

OK (Without CONSULT-II)>>GO TO 10.


NG >> Replace refueling control valve with fuel tank.

9. CHECK REFUELING EVAP VAPOR CUT VALVE

With CONSULT-II

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#)
2. Drain fuel from the tank as follows:
 - Remove fuel feed hose located on the fuel level sensor unit retainer.
 - Connect a spare fuel hose, one side to fuel level sensor unit retainer where the hose was removed and the other side to a fuel container.
 - Drain fuel using "FUEL PUMP RELAY" in "ACTIVE TEST" mode with CONSULT-II.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows.

Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
 - Always replace O-ring with new one.**
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level sensor unit retainer remaining open and check that the pressure is applicable.




OK or NG

- OK >> GO TO 11.
 NG >> Replace refueling EVAP vapor cut valve with fuel tank.

10. CHECK REFUELING EVAP VAPOR CUT VALVE

⊗ Without CONSULT-II

1. Remove fuel tank. Refer to [FL-3, "FUEL TANK"](#).
2. Drain fuel from the tank as follows:
 - Remove fuel level sensor unit retainer.
 - Drain fuel from the tank using a hand pump into a fuel container.
3. Check refueling EVAP vapor cut valve for being stuck to close as follows. Blow air into the refueling EVAP vapor cut valve (from hose end B), and check that the air flows freely into the tank.
4. Check EVAP vapor cut valve for being stuck to open as follows.
 - Connect vacuum pump to hose ends A and B using a suitable 3-way connector.
 - Remove fuel level sensor unit retainer with fuel level sensor unit.
Always replace O-ring with new one.
 - Put fuel tank upside down.
 - Apply vacuum pressure to both hose ends A and B [-13.3 kPa (-100 mmHg, -3.94 inHg)] with fuel level sensor unit retainer remaining open and check that the pressure is applicable.



OK or NG

OK >> GO TO 11.

NG >> Replace refueling EVAP vapor cut valve with fuel tank.

11. CHECK FUEL FILLER TUBE

Check filler neck tube and hose connected to the fuel tank for clogging, dents and cracks.

OK or NG

OK >> GO TO 12.

NG >> Replace fuel filler tube.

12. CHECK ONE-WAY FUEL VALVE-I

Check one-way valve for clogging.

OK or NG

OK >> GO TO 13.

NG >> Repair or replace one-way fuel valve with fuel tank.

13. CHECK ONE-WAY FUEL VALVE-II


1. Make sure that fuel is drained from the tank.
2. Remove fuel filler tube and hose.
3. Check one-way fuel valve for operation as follows.
When a stick is inserted, the valve should open, when removing stick it should close.

Do not drop any material into the tank.

OK or NG

OK >> **INSPECTION END.**

NG >> Replace fuel filler tube or replace one-way fuel valve with fuel tank.



POSITIVE CRANKCASE VENTILATION

Description

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.

During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.



Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.


This system returns blow-by gas to the intake manifold.



Component Inspection


PCV (POSITIVE CRANKCASE VENTILATION) VALVE

With engine running at idle, remove PCV valve from rocker cover; if the valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.



PCV VALVE VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



SERVICE DATA AND SPECIFICATIONS (SDS)

[VG33ER]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Fuel Pressure Regulator

UBS008L7

Fuel pressure at idling kPa (kg/cm ² , psi)	
Vacuum hose is connected	Approximately 235 (2.4, 34)
Vacuum hose is disconnected	Approximately 294 (3.0, 43)

Idle Speed and Ignition Timing

UBS008L8

Base idle speed*1	No-load*4 (in "P" or N" position)	700±50 rpm
Target idle speed*2	No-load*4 (in "P" or N" position)	750±50 rpm
Air conditioner: ON	In "P" or N" position	850 rpm or more
Ignition timing*3	In "P" or N" position	10°±2° BTDC
Throttle position sensor idle position		0.15 - 0.85V

*1: Throttle position sensor harness connector disconnected or using CONSULT-II "WORK SUPPORT" mode

*2: Throttle position sensor harness connector connected

*3: Throttle position sensor harness connector disconnected

*4: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Ignition Coil

UBS008L9

Primary voltage	12V
Primary resistance [at 20°C (68°F)]	Approximately 1.0Ω
Secondary resistance [at 20°C (68°F)]	Approximately 10 kΩ

Mass Air Flow Sensor

UBS008LA

Supply voltage	Battery voltage (11 - 14)V
Output voltage at idle	1.0 - 1.7*V
Mass air flow (Using CONSULT-II or GST)	3.3 - 4.8 g-m/sec at idle* 12.0 - 14.9 g-m/sec at 2,500 rpm*

*: Engine is warmed up to normal operating temperature and running under no-load.

Engine Coolant Temperature Sensor

UBS008LB

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

Heated Oxygen Sensor 1 Heater

UBS008LC

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

Fuel Pump

UBS008LD

Resistance [at 25°C (77°F)]	0.2 - 5.0Ω
-----------------------------	------------

IACV-AAC Valve

UBS008LE

Resistance [at 20°C (68°F)]	Approximately 10.0Ω
-----------------------------	---------------------

Injector

UBS008LF

Resistance [at 25°C (77°F)]	10 - 14Ω
-----------------------------	----------

SERVICE DATA AND SPECIFICATIONS (SDS)

[VG33ER]

Throttle Position Sensor

UBS008LG

Throttle valve conditions	Voltage (at normal operating temperature, engine off, ignition switch ON)
Completely closed (a)	0.15 - 0.85V
Partially open	Between (a) and (b)
Completely open (b)	3.5 - 4.7V

Calculated Load Value

UBS008LH

	Calculated load value % (Using CONSULT or GST)
At idle	18.0 - 26.0
At 2,500 rpm	18.0 - 21.0

Intake Air Temperature Sensor

UBS008LI

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38

Heated Oxygen Sensor 2 Heater

UBS008LJ

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

Crankshaft Position Sensor (OBD)

UBS008LK

Resistance [at 20°C (68°F)]	512 - 632Ω
-----------------------------	------------

Fuel Tank Temperature Sensor

UBS008LL

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

