

# **VCON**

**VISUAL COMMUNICATIONS**

## **Videoconferencing Systems**



## **HD100**

# **Videoconferencing Engine**

### **API Programmer's Guide**

DOC01114 Rev. 4.0 08.03

## © 2003 VCON Ltd. All Rights Reserved.

This material is proprietary of VCON, Ltd. No part of this document can be reproduced or transmitted in any form or by any means - electronic or mechanical - for any purpose without written permission from VCON Ltd. Information in this document is subject to change without notice.

### ***Limited Warranty***

VCON Ltd. warrants that SOFTWARE will perform according to accompanying user documentation for a period of 90 (ninety) days from the date of receipt; replacement SOFTWARE will be warranted for 90 (ninety) days from the date of receipt. This Limited Warranty shall not apply to any product that in the opinion of VCON Ltd. has not been installed or upgraded according to accompanying documentation from VCON Ltd. or been subject to misuse, misapplication, negligence or accident while in the hands of the purchaser.

**GRANT OF LICENCE** VCON Ltd. grants the Purchaser a non-exclusive and non-transferable license to use the SOFTWARE product and to make one copy solely for backup or archival purposes, which may include user documentation provided via online or other electronic form. Additional copies may not be made nor may anyone else be allowed to copy or otherwise reproduce any part of the licensed software without prior written consent of VCON Ltd.

**COPYRIGHT** All trademarks(s), logo(s), name(s), software, documentation and other supporting materials relating to the Product are trademarked, copyrighted or owned by VCON Ltd. as proprietary information protected by United States copyright laws and international and applicable national treaty provisions and laws. Software protection extends beyond its literal code to structure, sequence and organization; any unauthorized use or modification would constitute a misappropriation of VCON's proprietary rights and a violation of the License agreement.

**LIABILITIES** VCON's entire liability and the Purchaser's exclusive remedy shall be at VCON's option, either return of the price paid or repair/replacement of the Product not meeting VCON's declared Limited warranty. VCON or its suppliers shall not be liable in any event to anyone for any indirect, incidental, consequential, special or exemplary damages including without limitation damages for loss of business profits, business interruptions, business information or other pecuniary loss arising out of the use of or inability to use the said Product even if advised of the possibility of such damages. In any case, VCON's entire liability under any provision of this agreement shall be limited to the amount actually paid by the Purchase for the Product.

## ***VCON Technical Support***

This API & Setup Guide was designed to help you set up and work with the HD100 Integrator system easily.

If a situation occurs that is not covered by the supplied documentation, please request help from our Technical Support channels. VCON's organization will make its strongest efforts to help you resume your software integration activities as soon as possible.

1. Contact your local VCON distributor, and request assistance from its technical support department.
2. Send an e-mail message fully describing the condition plus your system's configuration to [zapi@vcon.com](mailto:zapi@vcon.com).

# TABLE OF CONTENTS

Limited Warranty.....	2
VCON Technical Support.....	3
<b>1 Welcome to HD100.....</b>	<b>9</b>
<b>2 Accessing the HD100 Programming Interface .....</b>	<b>10</b>
2.1 Setting Up an RS-232 Connection.....	10
2.2 Setting Up a Telnet Session.....	11
Hiding the HD100 User Interface.....	12
<b>3 Syntax Conventions .....</b>	<b>13</b>
<b>4 Commands .....</b>	<b>14</b>
4.1 Call Commands.....	14
Dial.....	14
Hangup.....	15
CallAnswer .....	16
CallReject.....	17
CallGetParam.....	18
STATE.....	20
REMOTE_TERMINAL_TYPE .....	21
DIRECTION.....	22
BITRATE .....	23
TX_VIDEO_CODEC .....	24
RX_VIDEO_CODEC.....	25
TX_VIDEO_SEC_CODEC.....	26
RX_VIDEO_SEC_CODEC .....	27
TX_AUDIO_CODEC.....	28
RX_AUDIO_CODEC .....	29
TX_VIDEO_BITRATE.....	30
RX_VIDEO_BITRATE .....	31
TX_VIDEO_SEC_BITRATE .....	32
RX_VIDEO_SEC_BITRATE.....	33
TX_AUDIO_BITRATE .....	34
RX_AUDIO_BITRATE.....	35
TX_VIDEO_HANDLE.....	36
RX_VIDEO_HANDLE.....	37
TX_VIDEO_SEC_HANDLE.....	38
RX_VIDEO_SEC_HANDLE.....	39

	TX_AUDIO_HANDLE.....	40
	RX_AUDIO_HANDLE .....	41
	TX_VIDEO_FRAMERATE .....	42
	RX_VIDEO_FRAMERATE .....	43
	TX_VIDEO_SEC_FRAMERATE.....	44
	RX_VIDEO_SEC_FRAMERATE.....	45
	DURATION .....	46
	REMOTE_NAME .....	47
	REMOTE_ADDRESS.....	48
	AUDIO_TO_VIDEO_DELAY .....	49
	JITTER_BUFFER_SIZE.....	50
	CallSetBitrate.....	51
	CallSendIntra .....	52
	CallRequestIntra .....	53
	CallSendDTMF.....	54
	CallEvents.....	55
4.2	LAN Commands .....	56
	GetParam .....	56
	GATEKEEPER_LOGIN_STATE.....	59
	GATEKEEPER_ADDRESS .....	60
	STATION_NUMBER.....	61
	STATION_NAME .....	62
	SERVER_LOGIN_STATE.....	63
	SERVER_ADDRESS.....	64
	AUTO_ADDRESS.....	65
	MAC_ADDRESS.....	66
	IP_ADDRESS .....	67
	SUBNET_MASK.....	68
	DEFAULT_GATEWAY.....	69
	DNS_SERVER_ADDRESS.....	70
	WINS_SERVER_ADDRESS .....	71
	DOMAIN_NAME .....	72
	NAT_ADDRESS.....	73
	AUTO_ANSWER.....	74
	LIPSYNC_ENABLE.....	75
	AUTO_JITTER_ENABLE.....	76
	ABA_ENABLE .....	77
	MAX_BITRATE.....	78
	MIN_BITRATE.....	79
	DEF_BITRATE.....	80
	USE_GATEKEEPER.....	81

USE_SERVER	82
MIN_UDP_PORT	83
MAX_UDP_PORT	84
MIN_TCP_PORT	85
MAX_TCP_PORT	86
AUDIO_QOS	87
VIDEO_QOS	88
RTCP_QOS	89
QOS_TYPE	90
AUTO_ACCEPT_MULTICAST_FLOOR	91
DHCP_STATE	92
WINS_LOGIN_STATE	93
STREAMING_ENABLE	94
STREAMING_ADDRESS	95
STREAMING_VIDEO_PORT	96
STREAMING_AUDIO_PORT	97
STREAMING_BITRATE	98
STREAMING_TTL	99
STREAMING_TIMEOUT	100
STREAMING_ENABLE_ANNOUNCEMENT	101
ETHERNET_SPEED	102
MAX_ACTIVE_CALLS	103
ACTIVE_CALLS	104
FECC_ALLOWED	105
SetParam	106
ServerEvents	107
GatekeeperEvents	108
4.3 Streaming Commands	109
StreamingStart	109
StreamingStop	110
StreamingResume	111
StreamingEvents	112
4.4 Interactive Multicast Commands	113
MulticastSendPassword	113
MulticastSendText	114
MulticastRequestFloor	115
MulticastRejectFloor	116
MulticastAcceptFloor	117
MulticastEvents	118
4.5 Camera Commands	119
CameraGetSelected	119

	CameraSetSelected .....	120
	CameraPresetSet .....	121
	CameraPresetRecall .....	122
	CameraMove .....	123
4.6	Audio Commands .....	124
	MuteMic .....	124
	MuteSpeaker .....	125
	VolumeGet .....	126
	VolumeSet .....	127
4.7	Phonebook Commands .....	128
	PhonebookGetEntry .....	128
	PhonebookGetNumOfEntries .....	129
	PhonebookAddEntry .....	130
	PhonebookDeleteEntry .....	131
	PhonebookShow .....	132
	PhonebookDial .....	133
4.8	System Commands .....	134
	IniRead .....	134
	IniWrite .....	135
	Reboot .....	136
	KeyPressed .....	137
	ConsoleGetParam .....	139
	ConsoleSetParam .....	140
<b>5</b>	<b>Events .....</b>	<b>141</b>
5.1	Call Events .....	141
	EVENT_CALL_DIALTONE .....	141
	EVENT_CALL_RINGBACK .....	142
	EVENT_CALL_CONNECTED .....	143
	EVENT_CALL_OFFERING .....	144
	EVENT_CALL_DISCONNECTED .....	145
	EVENT_CALL_IDLE .....	146
	EVENT_CALL_CHANNEL_ON .....	147
	EVENT_CALL_CHANNEL_OFF .....	148
	EVENT_CALL_REMOTE_NOT_RESPONDING .....	149
5.2	Server Events .....	150
	EVENT_SERVER_DATA_CHANGED .....	150
	EVENT_SERVER_COMMAND .....	151
	EVENT_SERVER_STATE_CHANGED .....	152
5.3	Gatekeeper Events .....	153
	EVENT_GATEKEEPER_STATE_CHANGED .....	153

5.4	Multicast Events .....	154
	EVENT_MULTICAST_CONNECTED .....	154
	EVENT_MULTICAST_FLOOR_OFFERING .....	155
	EVENT_MULTICAST_FLOOR_REQUEST_REJECTED .....	156
	EVENT_MULTICAST_FLOOR_CHANGED .....	157
	EVENT_MULTICAST_FLOOR_GRANTED .....	158
	EVENT_MULTICAST_PASSWORD_REJECTED .....	159
	EVENT_MULTICAST_PASSWORD_REQUESTED .....	160
5.5	Streaming Events .....	161
	EVENT_STREAMING_STARTED .....	161
	EVENT_STREAMING_STOPPED .....	162
5.6	System Events .....	163
	EVENT_SYSTEM_INIT_COMPLETED_SUCCESS .....	163
	EVENT_SYSTEM_INIT_COMPLETED_FAILURE .....	164
	EVENT_SYSTEM_DHCP_STATE_RECEIVED_ADDRESS .....	165
	EVENT_DHCP_STATE_FAILED_RECEIVING_ADDRESS .....	166
<b>6</b>	<b>The User.ini File .....</b>	<b>167</b>
6.1	Configuration Parameters .....	168
	CallEvents .....	168
	MulticastEvents .....	169
	StreamingEvents .....	170
	GatekeeperEvents .....	171
	ServerEvents .....	172
6.2	GUI Parameters .....	173
	HideAll .....	173
	HideDlg .....	174
<b>7</b>	<b>WorkFlow Examples .....</b>	<b>175</b>
7.1	Incoming Call Flow .....	175
7.2	Outgoing Call Flow .....	177



# 1 **WELCOME TO HD100**

The HD100 API Programmer's Guide contain description, syntaxes, and examples of the HD100 API system events, commands, and parameters.

The HD100 is a videoconferencing engine for integration into a custom multimedia room environment. When combined with external audio mixers, video switches and touch-screen control devices, virtually any rich media communication solution can be created. The HD100 produces high quality video with extremely low latency and IP conferencing data rates up to 2 Mbps. With an embedded MCU and streaming capabilities, as well as a suite of integration APIs, the HD100 can be used to create any custom application in an array of industries such as healthcare, large education facilities and corporate boardrooms.

Key Features Include:

- Compact form-factor ready for integration
- TV-quality video at 60 fields per second
- VCON PacketAssist™ architecture for advanced Quality of Service (QoS) over IP
- H.323 v4 and VCON Interactive Multicast
- Embedded 4-port MCU with speed matching and audio transcoding
- Multicast and unicast streaming
- Integration APIs for custom integration
- VCON Media Xchange Manager™ management and administration agent
- Embedded web server for remote management
- Compact flash memory for easy software upgrade

## 2 ACCESSING THE HD100 PROGRAMMING INTERFACE

Use COM2 for sending Integrator API commands to the HD100.

### 2.1 Setting Up an RS-232 Connection

This section includes procedures for setting up an RS-232 communications session.

#### ► To connect the RS-232 serial cable

1. Connect one end of the RS-232 serial cable (DB9-to-DB9) to the serial port of your computer.
2. Connect the other end to the RS-232 serial port on the rear panel of the HD100 Integrator (default is **COM2**).

#### ► To start a communications session

1. Set up a HyperTerminal session. In the Windows desktop, run **Start>Programs>Accessories>Communications>HyperTerminal**.
2. In the Connection Description dialog box, enter a **Name**. Select an icon. Click **OK**.
3. In the Connect To dialog box, select **COM1** from the **Connect Using** list. Click **OK**.
4. In the COM Properties dialog box, enter the following Port Settings:

<b>Bits per second</b>	9600
<b>Data Bits</b>	8
<b>Parity</b>	None
<b>Stop Bit</b>	1
<b>Flow Control</b>	None

5. Click **OK**.

- Restart the HD100. After the HD100 initializes, the following prompt appears on the screen:


```
Welcome to HD100:  
Version      : 0150.M07.D17.H12  
Board Type   : Tetra VC Board  
Camera Input: PAL  
  
HD>>  
EVENT_SYSTEM_INIT_COMPLETED_SUCCESS  
HD>>
```

## 2.2 Setting Up a Telnet Session

Use standard Telnet client configured with the HD100 IP address and **port 5005**.

### ► To start a Telnet session from Windows

- Turn the HD100 on.
- From the Windows **Start** menu, open **Programs>Accessories>Communications>HyperTerminal**.
- Enter a session.



- From the **Connect Using** list, choose **TCP/IP (Winsock)**.
- Enter the HD100 IP address.

6. As the **Port Number**, type **5005**.
7. Click **OK**.

You are now in an active Telnet session. Information from the HD100 appears on the screen.

```
Welcome to HD100:
```

```
Version      : 0150.M07.D16.H14
```

```
Board Type   : Tetra VC Board
```

```
Camera Input: NTSC
```

```
HD>>
```

```
EVENT_SYSTEM_INIT_COMPLETED_SUCCESS
```

```
HD>>
```



To display the list of available API commands, type **help**.

## Hiding the HD100 User Interface

If you want to remove the entire user interface or only its dialog boxes from view, perform the procedures below.

### ➤ To hide the HD100 user interface

1. Connect to the HD100 over Telnet (see [“Setting Up a Telnet Session” on page 11](#)).
2. In the Telnet session screen, type **IniWrite user.ini gui hideall 0**.


### ➤ To hide only dialog boxes (icons and popup messages remain visible):

1. Connect to the HD100 over Telnet (see [“Setting Up a Telnet Session” on page 11](#)).
2. In the Telnet session screen, type **IniWrite user.ini gui hidedlg 0**.

### 3 SYNTAX CONVENTIONS

The following conventions are used for the API command syntaxes:

- Parameters placed between < > are mandatory.
  - Parameters placed between [ ] are optional.
  - Only one of the parameters placed between { } and separated by | may be used at a single time.
  - Available values appear in **bold**.
  - Default values appear in ***bold italics***.
  - Words or characters appearing in *italics* represent variable values that you must supply.
  - Examples of text that appear on the monitor (application console) appear in `Courier` font.
  - The return string for all commands is structured as follows:  

```
<CommandName> <Status={OK|ERROR}> [Value]
```
  - Links to other events, commands, and parameters appear in [blue](#).
-  Commands are not case sensitive.

## 4 COMMANDS

### 4.1 Call Commands

#### Dial

**Description** Initiate a videoconference call to a remote user associated with the entered address.

**Format** Dial <*RemoteAddress*> [*Bitrate=384000*]

**Parameters** **RemoteAddress** – The address of the remote user (IP Address, DNS Name H.323-ID or E.164).

**Bitrate** – The bitrate of the call.

**Return** **OK** on success together with the created call ID.

**ERROR** – with an error code.

**Example**

```
Dial 10.0.11.25 128000  
DIAL OK 0
```

```
Dial danny.vcon.co.il 128000  
DIAL OK 1
```

**Remarks**

## Hangup

<b>Description</b>	Disconnect an active call.
<b>Format</b>	Hangup [ <i>CallID=0</i> ]
<b>Parameters</b>	<b>CallID</b> – The ID of the call to disconnect.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> – with an error code.
<b>Example</b>	Hangup 0 HANGUP OK
<b>Remarks</b>	

## CallAnswer

<b>Description</b>	Answer an incoming call.
<b>Format</b>	CallAnswer [ <i>CallID=0</i> ]
<b>Parameters</b>	<b>CallID</b> – The ID of the incoming call.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> – with an error code.
<b>Example</b>	CallAnswer 0 CALLANSWER OK
<b>Remarks</b>	When the system is set to auto-answer mode, this command is unnecessary.



## CallReject

<b>Description</b>	Reject an incoming call.
<b>Format</b>	CallReject [ <i>CallID=0</i> ]
<b>Parameters</b>	<b>CallID</b> – The ID of the incoming call.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> – with an error code.
<b>Example</b>	CallReject 0 REJECTCALL OK
<b>Remarks</b>	When the system is set to auto-answer mode, this command is unnecessary.

## CallGetParam

<b>Description</b>	Retrieve a call parameter.
<b>Format</b>	CallGetParam [ <i>CallID=0</i> ] < <i>CallParameter</i> >
<b>Parameters</b>	<b>CallID</b> – The ID of the call. <b>CallParameter</b> – The specific call parameter.
<b>Return</b>	<b>OK</b> on success together with the parameter value. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>CallGetParam 0 REMOTE_NAME CALLGETPARAM OK DemoRoom</pre>
<b>Remarks</b>	To retrieve all the Call parameters, type <b>GetCallParam</b> . NULL string represents a null value. Supported call parameters list: STATE REMOTE_TERMINAL_TYPE DIRECTION BITRATE TX_VIDEO_CODEC RX_VIDEO_CODEC TX_VIDEO_SEC_CODEC RX_VIDEO_SEC_CODEC TX_AUDIO_CODEC RX_AUDIO_CODEC TX_VIDEO_BITRATE RX_VIDEO_BITRATE TX_VIDEO_SEC_BITRATE RX_VIDEO_SEC_BITRATE

**Remarks  
(cont.)**

TX\_AUDIO\_BITRATE  
RX\_AUDIO\_BITRATE  
TX\_VIDEO\_HANDLE  
RX\_VIDEO\_HANDLE  
TX\_VIDEO\_SEC\_HANDLE  
RX\_VIDEO\_SEC\_HANDLE  
TX\_AUDIO\_HANDLE  
RX\_AUDIO\_HANDLE  
TX\_VIDEO\_FRAMERATE  
RX\_VIDEO\_FRAMERATE  
TX\_VIDEO\_SEC\_FRAMERATE  
RX\_VIDEO\_SEC\_FRAMERATE  
DURATION  
REMOTE\_NAME  
REMOTE\_ADDRESS  
AUDIO\_TO\_VIDEO\_DELAY  
JITTER\_BUFFER\_SIZE

Descriptions for the parameters listed above appear on the following pages.

## **STATE**

<b>Description</b>	Start or stop sending call event to the console. Type of call event to the console. Current call state.
<b>Valid Value</b>	<b>DIALTONE</b> - A dialtone state followed dialing. <b>DISCONNECTED</b> - A call was disconnected. <b>RINGBACK</b> - An “Alerting” or “Proceeding” message was received from the remote side. <b>CONNECTED</b> - A call connected successfully. <b>IDLE</b> - A call was disconnected, and its resources are no longer valid. <b>OFFERING</b> - An incoming call indication was received.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **REMOTE\_TERMINAL\_TYPE**

<b>Description</b>	Type of remote H.323 terminal.
<b>Valid Value</b>	<b>TERMINAL</b> <b>GATEWAY</b> <b>MCU</b> <b>GATEKEEPER</b>
<b>Access</b>	Read only.
<b>Remarks</b>	

## **DIRECTION**

<b>Description</b>	The direction of call.
<b>Valid Value</b>	<b>RX</b> - incoming. <b>TX</b> - outgoing.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **BITRATE**

<b>Description</b>	Current call bit rate.
<b>Valid Value</b>	From <b>0</b> to <b>max</b> supported bit rate.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **TX\_VIDEO\_CODEC**

<b>Description</b>	The call's main outgoing video codec.
<b>Valid Value</b>	<b>OFF</b> <b>H261</b> <b>H263</b>
<b>Access</b>	Read only.
<b>Remarks</b>	



## **RX\_VIDEO\_CODEC**

<b>Description</b>	The call's main incoming video codec.
<b>Valid Value</b>	<b>OFF</b> <b>H261</b> <b>H263</b>
<b>Access</b>	Read only.
<b>Remarks</b>	

## **TX\_VIDEO\_SEC\_CODEC**

<b>Description</b>	The call's secondary outgoing video codec.
<b>Valid Value</b>	<b>OFF</b> <b>H261</b> <b>H263</b>
<b>Access</b>	Read only.
<b>Remarks</b>	

## **RX\_VIDEO\_SEC\_CODEC**

<b>Description</b>	The call's secondary incoming video codec.
<b>Valid Value</b>	<b>OFF</b> <b>H261</b> <b>H263</b>
<b>Access</b>	Read only.
<b>Remarks</b>	

## **TX\_AUDIO\_CODEC**

**Description** The call's outgoing audio codec.

**Valid Value** OFF  
G711A  
G711U  
G722  
G723  
G728  
G729

**Access** Read only.

**Remarks**

## **RX\_AUDIO\_CODEC**

**Description** The call's incoming audio codec.

**Valid Value** OFF  
G711A  
G711U  
G722  
G723  
G728  
G729

**Access** Read only.

**Remarks**

## **TX\_VIDEO\_BITRATE**

<b>Description</b>	Actual main outgoing video bit rate.
<b>Valid Value</b>	From <b>0</b> to <b>max</b> supported bit rate.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **RX\_VIDEO\_BITRATE**

<b>Description</b>	Actual main incoming video bit rate.
<b>Valid Value</b>	From <b>0</b> to <b>max</b> supported bit rate.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **TX\_VIDEO\_SEC\_BITRATE**

<b>Description</b>	Actual secondary outgoing video bit rate.
<b>Valid Value</b>	From <b>0</b> to <b>max</b> supported bit rate.
<b>Access</b>	Read only.
<b>Remarks</b>	



## **RX\_VIDEO\_SEC\_BITRATE**

<b>Description</b>	Actual secondary incoming video bit rate.
<b>Valid Value</b>	From <b>0</b> to <b>max</b> supported bit rate.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **TX\_AUDIO\_BITRATE**

<b>Description</b>	Actual outgoing audio bit rate.
<b>Valid Value</b>	From <b>0</b> to <b>64</b> Kb.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **RX\_AUDIO\_BITRATE**

**Description**            Actual incoming audio bit rate.

**Valid Value**            From **0** to **64** Kb

**Access**                  Read only.

**Remarks**

## **TX\_VIDEO\_HANDLE**

<b>Description</b>	The main outgoing video codec handle.
<b>Valid Value</b>	Any value.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **RX\_VIDEO\_HANDLE**

<b>Description</b>	The main incoming video codec handle.
<b>Valid Value</b>	Any value.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **TX\_VIDEO\_SEC\_HANDLE**

<b>Description</b>	The secondary outgoing video codec handle.
<b>Valid Value</b>	Any value.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **RX\_VIDEO\_SEC\_HANDLE**

<b>Description</b>	The secondary incoming video codec handle.
<b>Valid Value</b>	Any value.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **TX\_AUDIO\_HANDLE**

<b>Description</b>	The outgoing audio codec handle.
<b>Valid Value</b>	Any value.
<b>Access</b>	Read only.
<b>Remarks</b>	



## **RX\_AUDIO\_HANDLE**

<b>Description</b>	The incoming audio codec handle.
<b>Valid Value</b>	Any value.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **TX\_VIDEO\_FRAMERATE**

<b>Description</b>	The main outgoing video codec frame rate.
<b>Valid Value</b>	<b>0 – 60</b> frames per second.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **RX\_VIDEO\_FRAMERATE**

<b>Description</b>	The main incoming video codec frame rate.
<b>Valid Value</b>	0 – 60 frames per second.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **TX\_VIDEO\_SEC\_FRAMERATE**

<b>Description</b>	The secondary outgoing video codec frame rate.
<b>Valid Value</b>	<b>0 – 60</b> frames per second.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **RX\_VIDEO\_SEC\_FRAMERATE**

<b>Description</b>	The secondary incoming video codec frame rate.
<b>Valid Value</b>	<b>0 – 60</b> frames per second.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **DURATION**

<b>Description</b>	Call duration in seconds.
<b>Valid Value</b>	value > 0.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **REMOTE\_NAME**

<b>Description</b>	Name of remote endpoint.
<b>Valid Value</b>	Any value.
<b>Access</b>	Read only.
<b>Remarks</b>	

## **REMOTE\_ADDRESS**

<b>Description</b>	IP address of remote endpoint.
<b>Valid Value</b>	A valid IP address.
<b>Access</b>	Read only.
<b>Remarks</b>	



## **AUDIO TO VIDEO DELAY**

<b>Description</b>	The delay between the incoming video and audio streams (in percent).
<b>Valid Value</b>	<b>0 - 100</b> percent
<b>Access</b>	Read/Write.
<b>Remarks</b>	

## **JITTER\_BUFFER\_SIZE**

<b>Description</b>	Returns the size of the used jitter buffer (in percent).
<b>Valid Value</b>	<b>0 - 100</b> percent
<b>Access</b>	Read / Write.
<b>Remarks</b>	Relevant only when <code>AUTO_JITTER_ENABLE = 0</code>

## CallSetBitrate

**Description** Set the video transmission rate for a specific call.

**Format** CallSetBitrate [*CallID=0*] <*Bitrate=384000*>

**Parameters** **CallID** – The ID of the call.  
**Bitrate** – The new call bit per seconds.

**Return** **OK** on success.  
**ERROR** on error together with an error code.

**Example**  
CallSetBitrate 0 192000  
CALLSETBITRATE OK

**Remarks**

## CallSendIntra

<b>Description</b>	Send an intra frame to the remote party during a specific call.
<b>Format</b>	CallSendIntra [ <i>CallID=0</i> ]
<b>Parameters</b>	<b>CallID</b> – The ID of the call.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>CallSendIntra 0 CALLSENDINTRA OK</pre>
<b>Remarks</b>	

## CallRequestIntra

<b>Description</b>	Request an intra frame from the remote party during a specific call.
<b>Format</b>	CallRequestIntra [ <i>CallID=0</i> ]
<b>Parameters</b>	<b>CallID</b> – The ID of the call.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>CallRequestIntra 0 CALLREQUESTINTRA OK</pre>
<b>Remarks</b>	

## CallSendDTMF

<b>Description</b>	Send a DTMF tone to the remote party for a specific call.
<b>Format</b>	CallSendDTMF <CallID= <b>0</b> > <DTMF>
<b>Parameters</b>	<b>CallID</b> – The ID of the call. <b>DTMF</b> – The DTMF tone to send { <b>0..9</b>   <b>#</b>   <b>*</b> }
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	CallSendDTMF 0 3 CALLSENDDTMF OK
<b>Remarks</b>	

## CallEvents

<b>Description</b>	Start or stop sending call event to the console.
<b>Format</b>	CallEvents [ <i>IsEnable=1</i> ]
<b>Parameters</b>	<b>IsEnable</b> – {0   1} <b>0</b> - Stop sending call event to the console. <b>1</b> - Start sending call event to the console.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	CallEvents 1 CALLEVENTS OK
<b>Remarks</b>	Supported call events: EVENT_CALL_DIALTONE <CallID> EVENT_CALL_RINGBACK <CallID> EVENT_CALL_CONNECTED <CallID> EVENT_CALL_OFFERING <CallID> <RemoteAddress> <RemoteName> EVENT_CALL_DISCONNECTED <CallID> <DisconnectionReason> EVENT_CALL_IDLE <CallID> EVENT_CALL_CHANNEL_ON <CallID> <ChannelID> <Dir> <Type> EVENT_CALL_CHANNEL_OFF <CallID> < ChannelID > <Dir> <Type> EVENT_CALL_REMOTE_NOT_RESPONDING <CallID>

## 4.2 LAN Commands

### GetParam

<b>Description</b>	Retrieve the value of a specific LAN configuration parameter.
<b>Format</b>	GetParam <LANParameter>
<b>Parameters</b>	<b>LANParameter</b> – The name of the LAN parameter.
<b>Return</b>	<b>OK</b> on success together with the LAN parameter value. <b>ERROR</b> on error together with an error code.
<b>Example</b>	GetParam IP_ADDRESS GETPARAM OK 10.0.11.25
<b>Remarks</b>	To retrieve all the LAN parameters, type <b>GetParam</b> . NULL string represents a null value. Supported LAN parameters: GATEKEEPER_LOGIN_STATE GATEKEEPER_ADDRESS STATION_NUMBER STATION_NAME SERVER_LOGIN_STATE SERVER_ADDRESS AUTO_ADDRESS MAC_ADDRESS IP_ADDRESS SUBNET_MASK DEFAULT_GATEWAY



**Remarks  
(cont.)**

DNS\_SERVER\_ADDRESS  
WINS\_SERVER\_ADDRESS  
DOMAIN\_NAME  
NAT\_ADDRESS  
AUTO\_ANSWER  
LIPSYNC\_ENABLE  
AUTO\_JITTER\_ENABLE  
ABA\_ENABLE  
MAX\_BITRATE  
MIN\_BITRATE  
DEF\_BITRATE  
USE\_GATEKEEPER  
USE\_SERVER  
MIN\_UDP\_PORT  
MAX\_UDP\_PORT  
MIN\_TCP\_PORT  
MAX\_TCP\_PORT  
AUDIO\_QOS  
VIDEO\_QOS  
RTCP\_QOS  
QOS\_TYPE  
AUTO\_ACCEPT\_MULTICAST\_FLOOR  
DHCP\_STATE  
WINS\_LOGIN\_STATE  
STREAMING\_ENABLE  
STREAMING\_ADDRESS  
STREAMING\_VIDEO\_PORT

**Remarks  
(cont.)**

STREAMING\_AUDIO\_PORT  
STREAMING\_BITRATE  
STREAMING\_TTL  
STREAMING\_TIMEOUT  
STREAMING\_ENABLE\_ANNOUNCEMENT  
ETHERNET\_SPEED  
MAX\_ACTIVE\_CALLS  
ACTIVE\_CALLS  
FECC\_ALLOWED

Descriptions for the parameters listed above appear on the following pages.

## GATEKEEPER LOGIN STATE

<b>Description</b>	Login state of the gatekeeper.
<b>Valid Value</b>	LOGGED_IN LOGIN_FAILED_DUPLICATE_ALIAS LOGIN_FAILED_GENERAL_ERROR LOGGED_OFF
<b>Default Value</b>	<i>LOGGED_OFF</i>
<b>Access</b>	Read only.
<b>Set Effect</b>	N/A.
<b>Remarks</b>	

## **GATEKEEPER\_ADDRESS**

<b>Description</b>	IP address of the gatekeeper.
<b>Valid Value</b>	Should match IP addressing conventions (x.x.x.x where x= <b>0–255</b> ).
<b>Default Value</b>	NULL
<b>Access</b>	Read / Write.
<b>Set effect</b>	Reboot.
<b>Remarks</b>	

## **STATION\_NUMBER**

<b>Description</b>	E.164 alias of a H.323 station.
<b>Valid Value</b>	A string of digits.
<b>Default Value</b>	NULL
<b>Access</b>	Read / Write.
<b>Set effect</b>	Reboot.
<b>Remarks</b>	Dialing a STATION_NUMBER as a remote address is only relevant when endpoint is configured to work with a gatekeeper.

## **STATION\_NAME**

<b>Description</b>	Name of the endpoint.
<b>Valid Value</b>	String of characters, with a letter as the first character.
<b>Default Value</b>	NULL
<b>Access</b>	Read / Write.
<b>Set effect</b>	Reboot.
<b>Remarks</b>	Dialing a STATION_NAME as a remote address is only relevant when endpoint is configured to work with a gatekeeper.

## **SERVER\_LOGIN\_STATE**

<b>Description</b>	The endpoint's login state in the MXM server.
<b>Valid Value</b>	<b>LOGGED_IN</b> <b>LOGIN_FAILED_DUPLICATE_ALIAS</b> <b>LOGIN_FAILED_LICENSE_VIOLATION</b> <b>LOGIN_FAILED_UNSUPPORTED_VERSION</b> <b>LOGIN_FAILED_TIME_OUT</b> <b>LOGIN_FAILED_WAIT_FOR_GRANT</b> <b>LOGIN_FAILED_GENERAL_ERROR</b> <b>LOGGED_OFF</b>
<b>Default Value</b>	<b><i>LOGGED_OFF</i></b>
<b>Access</b>	Read only.
<b>Set effect</b>	N/A.
<b>Remarks</b>	

## **SERVER\_ADDRESS**

<b>Description</b>	The IP address of the MXM server.
<b>Valid Value</b>	Should match IP addressing conventions (x.x.x.x where x= <b>0–255</b> ).
<b>Default Value</b>	NULL
<b>Access</b>	Read / Write.
<b>Set effect</b>	Reboot.
<b>Remarks</b>	



## **AUTO\_ADDRESS**

<b>Description</b>	Enable or disable automatic get of IP address from DHCP server.
<b>Valid Value</b>	{0 1} 0 – Disable. 1 – Enable.
<b>Default Value</b>	0
<b>Access</b>	Read / Write.
<b>Set effect</b>	Reboot.
<b>Remarks</b>	

## **MAC\_ADDRESS**

<b>Description</b>	Returns the MAC address of the endpoint.
<b>Valid Value</b>	A string in the following format <i>XX:XX:XX:XX:XX</i> where <i>X</i> can be either a digit OR a letter in the following range <b>A-F</b> .
<b>Default Value</b>	N/A.
<b>Access</b>	Read only.
<b>Set effect</b>	N/A.
<b>Remarks</b>	

## **IP\_ADDRESS**

<b>Description</b>	Local endpoint IP address.
<b>Valid Value</b>	Should match IP addressing conventions (x.x.x.x where x= <b>0–255</b> ).
<b>Default Value</b>	N/A.
<b>Access</b>	Read / Write.
<b>Set effect</b>	Reboot.
<b>Remarks</b>	

## **SUBNET\_MASK**

<b>Description</b>	Subnet mask of the local endpoint.
<b>Valid Value</b>	Should match IP addressing conventions (x.x.x.x where x= <b>0–255</b> ).
<b>Default Value</b>	N/A.
<b>Access</b>	Read / Write.
<b>Set effect</b>	Reboot.
<b>Remarks</b>	

## **DEFAULT\_GATEWAY**

<b>Description</b>	The network's default gateway.
<b>Valid Value</b>	Should match IP addressing conventions (x.x.x.x where x= <b>0–255</b> ).
<b>Default Value</b>	N/A.
<b>Access</b>	Read / Write.
<b>Set effect</b>	Reboot.
<b>Remarks</b>	

## **DNS\_SERVER\_ADDRESS**

<b>Description</b>	IP Address of network's DNS Server.
<b>Valid Value</b>	Should match IP addressing conventions (x.x.x.x where x= <b>0–255</b> ).
<b>Default Value</b>	NULL.
<b>Access</b>	Read / Write.
<b>Set effect</b>	Reboot.
<b>Remarks</b>	

## **WINS\_SERVER\_ADDRESS**

<b>Description</b>	IP Address of network's WINS Server.
<b>Valid Value</b>	Should match IP addressing conventions (x.x.x.x where x= <b>0-255</b> ).
<b>Default Value</b>	NULL.
<b>Access</b>	Read / Write.
<b>Set effect</b>	Reboot.
<b>Remarks</b>	

## **DOMAIN\_NAME**

<b>Description</b>	The name of the domain in which the endpoint is located.
<b>Valid Value</b>	String of dot-separated name elements.
<b>Default Value</b>	NULL.
<b>Access</b>	Read / Write.
<b>Set effect</b>	Reboot.
<b>Remarks</b>	



## **NAT\_ADDRESS**

<b>Description</b>	The NAT IP address of the endpoint.
<b>Valid Value</b>	Should match IP addressing conventions (x.x.x.x where x= <b>0–255</b> ).
<b>Default Value</b>	NULL.
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **AUTO\_ANSWER**

<b>Description</b>	Enable/disable automatic answer of incoming call.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	1
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **LIPSYNC\_ENABLE**

<b>Description</b>	Enable/disable lip synchronization mechanism.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	1
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **AUTO\_JITTER\_ENABLE**

<b>Description</b>	Enable/disable automatic buffering control, which allows manual or automatic control over delay and picture smoothness.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	1
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **ABA\_ENABLE**

<b>Description</b>	Enable/disable Adaptive Bandwidth Adjustment mechanism for overcoming network congestion problems.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	1
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **MAX\_BITRATE**

<b>Description</b>	Maximum bandwidth the system can allocate to initiate a call, according to its capabilities and/or license permissions.
<b>Valid Value</b>	<b>0 – 2048000</b>
<b>Default Value</b>	<b>2048000</b>
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **MIN\_BITRATE**

<b>Description</b>	Minimum bandwidth the system can allocate to initiate a call, according to its capabilities and/or license permissions.
<b>Valid Value</b>	<b>0 - 2048000</b>
<b>Default Value</b>	<b>64000</b>
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **DEF\_BITRATE**

<b>Description</b>	Default bandwidth the system can allocate to initiate a call, according to its capabilities and/or license permissions.
<b>Valid Value</b>	<b>0 - 2048000</b>
<b>Default Value</b>	<b>768000</b>
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	



## **USE\_GATEKEEPER**

<b>Description</b>	Enable or disable usage of gatekeeper management and services.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	0
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Reboot.
<b>Remarks</b>	

## **USE\_SERVER**

<b>Description</b>	Enable/disable usage of VCON Server management and services.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	0
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Reboot.
<b>Remarks</b>	

## **MIN\_UDP\_PORT**

<b>Description</b>	Lowest UDP port allowed.
<b>Valid Value</b>	<b>1024 - 65536</b>
<b>Default Value</b>	<b>5004</b>
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **MAX\_UDP\_PORT**

<b>Description</b>	Highest UDP port allowed.
<b>Valid Value</b>	<b>1024 - 65536</b>
<b>Default Value</b>	<b>6004</b>
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **MIN\_TCP\_PORT**

<b>Description</b>	Lowest TCP port allowed.
<b>Valid Value</b>	<b>1024 - 65536</b>
<b>Default Value</b>	<b>5004</b>
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **MAX\_TCP\_PORT**

<b>Description</b>	Highest TCP port allowed.
<b>Valid Value</b>	<b>1024 - 65536</b>
<b>Default Value</b>	<b>6004</b>
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **AUDIO\_QOS**

<b>Description</b>	The QOS value appended to each audio packet.
<b>Valid Value</b>	<b>0 - 255</b>
<b>Default Value</b>	<b>160</b>
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **VIDEO\_QOS**

<b>Description</b>	The QOS value appended to each video packet.
<b>Valid Value</b>	<b>0 - 255</b>
<b>Default Value</b>	<b>128</b>
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	



## **RTCP\_QOS**

<b>Description</b>	The QOS value appended to each RTCP packet.
<b>Valid Value</b>	<b>0 - 255</b>
<b>Default Value</b>	<b>192</b>
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **QOS\_TYPE**

<b>Description</b>	Type of QOS which is currently used during the endpoint's calls.
<b>Valid Value</b>	<b>NONE</b> <b>IPPRECEDENCE</b> <b>DIFFSERV</b>
<b>Default Value</b>	<b><i>IPPRECEDENCE</i></b>
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **AUTO\_ACCEPT\_MULTICAST\_FLOOR**

<b>Description</b>	Automatically accept a multicast floor grant from the chair.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	1
<b>Access</b>	Read / Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **DHCP\_STATE**

<b>Description</b>	The endpoint received or did not receive IP address from the DHCP server.
<b>Valid Value</b>	<b>NOT_IN_USE</b> <b>RECEIVED_ADDRESS</b> <b>FAILED_RECEIVING_ADDRESS</b>
<b>Default Value</b>	<b>NOT_IN_USE</b>
<b>Access</b>	Read only.
<b>Set effect</b>	N/A.
<b>Remarks</b>	

## **WINS LOGIN STATE**

<b>Description</b>	The endpoint's login state in the WINS server.
<b>Valid Value</b>	<b>LOGGED_OFF</b> <b>LOGIN_IN</b> <b>LOGIN_FAILED_NAME_FORMAT_ERROR</b> <b>LOGIN_FAILED_GENERAL_ERROR</b> <b>LOGIN_FAILED_NAME_ALREADY_USED</b> <b>LOGIN_FAILED_SERVER_NOT_RESPONDING</b>
<b>Default Value</b>	<i>LOGGED_OFF</i>
<b>Access</b>	Read only.
<b>Set effect</b>	N/A.
<b>Remarks</b>	

## **STREAMING\_ENABLE**

<b>Description</b>	The streaming option is enabled or disabled.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	1
<b>Access</b>	Read \ Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **STREAMING ADDRESS**

<b>Description</b>	The destination multicast address for streaming video and audio.
<b>Valid Value</b>	Should match IP addressing conventions ( <i>x.x.x.x</i> where <i>x=0–255</i> ).
<b>Default Value</b>	<b>239.XXX.YYY.ZZZ</b>
<b>Access</b>	Read \ Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **STREAMING\_VIDEO\_PORT**

<b>Description</b>	The destination port for the streaming video.
<b>Valid Value</b>	<b>1024 – 65536</b>
<b>Default Value</b>	<b>36100</b>
<b>Access</b>	Read \ Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	



## **STREAMING AUDIO PORT**

<b>Description</b>	The destination port for the streaming audio.
<b>Valid Value</b>	<b>1024 – 65536</b>
<b>Default Value</b>	<b>18100</b>
<b>Access</b>	Read \ Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **STREAMING\_BITRATE**

<b>Description</b>	The bit rate of the streaming session.
<b>Valid Value</b>	<b>0 - 2048000</b>
<b>Default Value</b>	<b>384000</b>
<b>Access</b>	Read \ Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **STREAMING TTL**

<b>Description</b>	The time-to-live value appended to each multicast streaming packet.
<b>Valid Value</b>	<b>0 - 255</b>
<b>Default Value</b>	<b>1</b>
<b>Access</b>	Read \ Write.
<b>Set effect</b>	Next Call.d
<b>Remarks</b>	

## **STREAMING\_TIMEOUT**

<b>Description</b>	Unicast streaming stops automatically if the remote viewer has not requested resume-streaming within this time value.
<b>Valid Value</b>	<i>value</i> > <b>0</b> (in milliseconds)
<b>Default Value</b>	<b>1800000</b>
<b>Access</b>	Read \ Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	Relevant to unicast streaming sessions only.

## **STREAMING\_ENABLE\_ANNOUNCEMENT**

<b>Description</b>	Send SDP announcement for a multicast streaming session.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	1
<b>Access</b>	Read \ Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	

## **ETHERNET\_SPEED**

<b>Description</b>	Get the current speed at which the LAN card is configured to work.
<b>Valid Value</b>	<b>10_HALF_DUPLEX</b> <b>10_FULL_DUPLEX</b> <b>100_HALF_DUPLEX</b> <b>100_FULL_DUPLEX</b>
<b>Default Value</b>	N/A.
<b>Access</b>	Read only.
<b>Set effect</b>	N/A.
<b>Remarks</b>	

## **MAX\_ACTIVE\_CALLS**

<b>Description</b>	Get the maximum number of concurrent calls supported.
<b>Valid Value</b>	<i>value</i> > <b>0</b>
<b>Default Value</b>	<b>3</b>
<b>Access</b>	Read only.
<b>Set effect</b>	N/A.
<b>Remarks</b>	

## **ACTIVE\_CALLS**

<b>Description</b>	Get the set of active CallIDs.
<b>Valid Value</b>	See Remarks section.
<b>Default Value</b>	NULL
<b>Access</b>	Read only.
<b>Set effect</b>	N/A.
<b>Remarks</b>	<p>For example:</p> <p>If the endpoint is running two active calls with IDs 1 &amp; 2, the result is:</p> <pre>SetParam ACTIVE_CALLS SETPARAM OK 1 2</pre>



## **FECC\_ALLOWED**

<b>Description</b>	Enable remote party to control the local camera.
<b>Valid Value</b>	{0 1} 0 -Disable 1 - Enable
<b>Default Value</b>	1
<b>Access</b>	Read \ Write.
<b>Set effect</b>	Next Call.
<b>Remarks</b>	SetParam FECC_ALLOWED 1 SETPARAM OK

## SetParam

<b>Description</b>	Edit the value of a LAN configuration parameter.
<b>Format</b>	GetParam <LANParameter> <Value>
<b>Parameters</b>	<b>LANParameter</b> – The name of the LAN parameter to edit. <b>Value</b> – The new value
<b>Return</b>	<b>OK</b> on success together with the expected result and an indication of when the effect occurs. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>SetParam IP_ADDRESS 10.0.11.25 SETPARAM OK EFFECT_REBOOT</pre>
<b>Remarks</b>	To retrieve all the LAN parameters, type <b>SetParam</b> . For a list of LAN parameters, see <a href="#">“GetParam” on page 56</a> . NULL string represents a null value. Supported Effects: EFFECT_NONE — No change was made. EFFECT_IMMEDIATE — Effect occurs immediately. EFFECT_NEXT_CALL — Effect occurs during the next call. EFFECT_REBOOT — Effect occurs after the computer restarts.

## ServerEvents

<b>Description</b>	Start or stop sending server event to the console.
<b>Format</b>	ServerEvents [ <i>IsEnable=1</i> ]
<b>Parameters</b>	<b>IsEnable</b> – {0 1} <b>0</b> - Stop sending server events to the console. <b>1</b> - Start sending server events to the console.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	ServerEvents 1 SERVEREVENTS OK
<b>Remarks</b>	Supported server events: <a href="#">EVENT_SERVER_DATA_CHANGED</a> <Action> <a href="#">EVENT_SERVER_COMMAND</a> <Command> <a href="#">EVENT_SERVER_STATE_CHANGED</a> <NewState>

## GatekeeperEvents

<b>Description</b>	Start or stop sending gatekeeper event to the console.
<b>Format</b>	GatekeeperEvents [ <i>IsEnable=1</i> ]
<b>Parameters</b>	<b>IsEnable</b> – {0 1} <b>0</b> - Stop sending gatekeeper events to the console. <b>1</b> - Start sending gatekeeper events to the console.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	GatekeeperEvents 1 GATEKEEPEREVENTS OK
<b>Remarks</b>	Gatekeeper supported events: <a href="#">EVENT_GATEKEEPER_STATE_CHANGED</a> <NewState>

## 4.3 Streaming Commands

### StreamingStart

<b>Description</b>	Start a new streaming session.
<b>Format</b>	StreamingStart [ <i>RemoteAddress</i> =” ”]
<b>Parameters</b>	<b>RemoteAddress</b> – The IP address to where to send the media.
<b>Return</b>	<b>OK</b> on success together with a SessionID. <b>ERROR</b> on error together with an error code.
<b>Example</b>	StreamingStart STREAMINGSTART OK 0
<b>Remarks</b>	<ol style="list-style-type: none"><li>1. When the RemoteAddress is NULL a multicast session will be created.</li><li>2. If the value is a valid IP a unicast streaming session will be created.</li><li>3. There may be only one Multicast session. For the maximum number of permitted unicast sessions, see the HD100 Integrator data sheet.</li></ol>

## StreamingStop

<b>Description</b>	End an active streaming session.
<b>Format</b>	StreamingStop < <i>SessionID</i> >
<b>Parameters</b>	<b>SessionID</b> – The ID of the session to stop.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	StreamingStop 1 STREAMINGSTOP OK
<b>Remarks</b>	

## StreamingResume

<b>Description</b>	Resume an active streaming session.
<b>Format</b>	StreamingResume < <i>SessionID</i> >
<b>Parameters</b>	<b>SessionID</b> – The ID of the streaming session.
<b>Return</b>	<b>OK</b> on success together with a new resume timeout. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>StreamingResume 1 STREAMINGRESUME OK 180000</pre>
<b>Remarks</b>	Unicast streaming session has a watchdog mechanism. Users must call this function periodically at intervals smaller than the interval returned by this command; otherwise, the unicast session shall be terminated by the HD.

## StreamingEvents

<b>Description</b>	Start or stop sending streaming event to the console.
<b>Format</b>	StreamingEvents [ <i>IsEnable=1</i> ]
<b>Parameters</b>	<b>IsEnable</b> – {0 1} <b>0</b> - Stop sending streaming event to the console. <b>1</b> - Start sending streaming event to the console.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>StreamingEvents 1 STREAMINGEVENTS OK</pre>
<b>Remarks</b>	Streaming supported events: <b>EVENT_STREAMING_STARTED</b> < <i>SessionID</i> > < <i>IsFirstSession</i> > <b>EVENT_STREAMING_STOPPED</b> < <i>SessionID</i> > < <i>IsLastSession</i> >



## 4.4 Interactive Multicast Commands

### MulticastSendPassword

<b>Description</b>	Send the multicast password to the multicast chair.
<b>Format</b>	MulticastSendPassword [ <i>CallID=0</i> ] < <i>Password</i> >
<b>Parameters</b>	<b>CallID</b> – The ID of the call. <b>Password</b> – The session's password.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>MulticastSendPassword 0 1234 MULTICASTSENDPASSWORD OK</pre>
<b>Remarks</b>	This function is the required response to the <a href="#">EVENT_MULTICAST_PASSWORD_REQUESTED</a> event received from the multicast chair.

## MulticastSendText

<b>Description</b>	Send a text message to the multicast chair.
<b>Format</b>	MulticastSendText [ <i>CallID=0</i> ] < <i>Text</i> >
<b>Parameters</b>	<b>CallID</b> – The ID of the call. <b>Text</b> – The text message.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>MulticastSendText 0 "Hello Chair" MULTICASTSENDTEXT OK</pre>
<b>Remarks</b>	

## MulticastRequestFloor

<b>Description</b>	Request the multicast floor from the chair.
<b>Format</b>	MulticastRequestFloor [ <i>CallID=0</i> ]
<b>Parameters</b>	<b>CallID</b> – The ID of the call.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	MulticastRequestFloor 0 MULTICASTREQUESTFLOOR OK
<b>Remarks</b>	

## MulticastRejectFloor

<b>Description</b>	Reject a floor grant from the chair.
<b>Format</b>	MulticastRejectFloor [ <i>CallID=0</i> ]
<b>Parameters</b>	<b>CallID</b> – The ID of the call.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	MulticastRejectFloor 0 MULTICASTREJECTFLOOR OK
<b>Remarks</b>	

## MulticastAcceptFloor

<b>Description</b>	Accept a floor grant from the chair.
<b>Format</b>	MulticastAcceptFloor [ <i>CallID=0</i> ]
<b>Parameters</b>	<b>CallID</b> – The ID of the call.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	MulticastAcceptFloor 0 MULTICASTACCEPTFLOOR OK
<b>Remarks</b>	

## MulticastEvents

<b>Description</b>	Start or stop sending multicast event to the console.
<b>Format</b>	MulticastEvents [ <i>IsEnable=1</i> ]
<b>Parameters</b>	<b>IsEnable</b> – {0 1}  <b>0</b> - Stop sending multicast event to the console. <b>1</b> - Start sending multicast event to the console.
<b>Return</b>	<b>OK</b> on success.  <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>MulticastEvents 1 MULTICASTEVENTS OK</pre>
<b>Remarks</b>	Supported multicast events:  EVENT_MULTICAST_CONNECTED <CallID> EVENT_MULTICAST_FLOOR_OFFERING <CallID> EVENT_MULTICAST_FLOOR_REQUEST_REJECTED <CallID> EVENT_MULTICAST_FLOOR_CHANGED <CallID> <Type> <Name> EVENT_MULTICAST_FLOOR_GRANTED <CallID> EVENT_MULTICAST_PASSWORD_REJECTED <CallID> EVENT_MULTICAST_PASSWORD_REQUESTED <CallID>

## 4.5 Camera Commands

### CameraGetSelected

<b>Description</b>	Get the selected local or remote camera.
<b>Format</b>	CameraGetSelected <Location={l   r}>
<b>Parameters</b>	<b>Location</b> – {l   r} <b>l</b> - local camera. <b>r</b> - remote camera.
<b>Return</b>	<b>OK</b> on success together with the selected camera number. <b>ERROR</b> on error together with an error code.
<b>Example</b>	CameraGetSelected l CAMERAGETSELECTED OK 1
<b>Remarks</b>	

## CameraSetSelected

<b>Description</b>	Switch the selected camera to either the local or remote camera.
<b>Format</b>	CameraSetSelected <Location={l   r}> <CameraNumber={1..4}>
<b>Parameters</b>	<b>Location</b> – {l   r} <b>l</b> - local camera. <b>r</b> - remote camera.  <b>CameraNumber</b> <b>1..4</b> - The selected camera number
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	CameraSetSelected l 3 CAMERASETSELECTED OK
<b>Remarks</b>	The “Main” camera’s number is <b>1</b> .



## CameraPresetSet

**Description** Set the selected local or remote camera's preset position.

**Format** CameraPresetSet <Location={l | r}>  
<PresetNumber={0..9}>

**Parameters** **Location** – {l | r}

**l** - local camera.

**r** - remote camera.

**PresetNumber** – {0..9}

**0..9** - The preset position number

**Return** **OK** on success.

**ERROR** on error together with an error code.

**Example** CameraPresetSet l 9

CAMERAPRESETSET OK

**Remarks**

## CameraPresetRecall

<b>Description</b>	Move the selected local or remote camera to one of the preset positions.
<b>Format</b>	CameraPresetRecall <Location={l   r}> <PresetNumber={0..9}>
<b>Parameters</b>	<b>Location</b> – {l   r} <b>l</b> - local camera. <b>r</b> - remote camera. <b>PresetNumber</b> – {0..9} <b>0..9</b> - The preset position number
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	CameraPresetRecall l 3 CAMERAPRESETRECALL OK
<b>Remarks</b>	

## CameraMove

<b>Description</b>	Move the camera's position.
<b>Format</b>	CameraMove <Location={l   r}> <Dir={u   d   r   l   i   o   s}>
<b>Parameters</b>	<b>Location</b> – {l   r} <b>l</b> - local camera. <b>r</b> - remote camera.  <b>Dir</b> – The direction in which to move the camera <b>u   d   r   l   i   o   s</b> <b>u</b> - up <b>d</b> - down <b>r</b> - right <b>l</b> left <b>i</b> - in <b>o</b> - out <b>s</b> - stop
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	CameraMove l u CAMERAMOVE OK
<b>Remarks</b>	

## 4.6 Audio Commands

### MuteMic

<b>Description</b>	Mute or unmute the microphone.
<b>Format</b>	MuteMic [ <i>Enable=1</i> ]
<b>Parameters</b>	<b>Enable:</b> { <b>0 1</b> } <b>0</b> – Unmute <b>1</b> – Mute
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>MuteMic 1 MUTEMIC OK</pre>
<b>Remarks</b>	

## MuteSpeaker

<b>Description</b>	Mute or unmute the speaker.
<b>Format</b>	MuteSpeaker [ <i>Enable=1</i> ]
<b>Parameters</b>	<b>Enable</b> – { <b>0</b>   <b>1</b> } <b>0</b> – Unmute <b>1</b> – Mute
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>MuteSpeaker 1 MUTESPEAKER OK</pre>
<b>Remarks</b>	

## VolumeGet

<b>Description</b>	Get the current volume level.
<b>Format</b>	VolumeGet
<b>Parameters</b>	N/A
<b>Return</b>	<b>OK</b> on success together with the current volume level. <b>ERROR</b> on error together with an error code.
<b>Example</b>	VolumeGet VOLUMEGET OK 60
<b>Remarks</b>	

## VolumeSet

<b>Description</b>	Change the current volume level.
<b>Format</b>	VolumeSet <Level>
<b>Parameters</b>	<b>Level</b> - The volume level { <b>0-99</b> }. <b>0</b> - Lowest. <b>99</b> - Highest.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	VolumeSet 50 VOLUMESET OK
<b>Remarks</b>	

## 4.7 Phonebook Commands

### PhonebookGetEntry

**Description** Get the phonebook entry that matches the specified number.

**Format** PhonebookGetEntry <EntryNum>

**Parameters** **EntryNum** - The number of the entry to get.

**Return** **OK** on success together with the entry details.  
**ERROR** on error together with an error code.

**Example** PhonebookGetEntry 1  
PHONEBOOKGETENTRY OK JohnY 10.0.11.24  
768000

**Remarks**



## PhonebookGetNumOfEntries

<b>Description</b>	Get the number of entries in the phonebook.
<b>Format</b>	PhonebookGetNumOfEntries
<b>Parameters</b>	N/A
<b>Return</b>	<b>OK</b> on success together with the number of entries in the phonebook. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<code>PhonebookGetNumOfEntries</code> <code>PHONEBOOKGETNUMOFENTRIES OK 100</code>
<b>Remarks</b>	

## PhonebookAddEntry

<b>Description</b>	Add a new entry to the phonebook.
<b>Format</b>	PhonebookAddEntry <Name> <Address> [Bitrate= <b>768000</b> ]
<b>Parameters</b>	<b>Name</b> - The name of the entry. <b>Address</b> - The remote party address (IP , DNS name , E164 , H323-ID). <b>Bitrate</b> - The bit rate of the call.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	PhonebookAddEntry PHONEBOOKADDEENTRY OK
<b>Remarks</b>	

## PhonebookDeleteEntry

<b>Description</b>	Delete the specified entry.
<b>Format</b>	PhonebookDeleteEntry < <i>Name</i> >
<b>Parameters</b>	<b>Name</b> - The name of the entry.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	PhonebookDeleteEntry JohnY PHONEBOOKDELETEENTRY OK
<b>Remarks</b>	

## PhonebookShow

<b>Description</b>	Show the content of the phonebook.
<b>Format</b>	PhonebookShow
<b>Parameters</b>	N/A
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.

<b>Example</b>	PhonebookShow												
	<table><thead><tr><th>##</th><th>Name</th><th>Address</th><th>Bitrate</th></tr></thead><tbody><tr><td>0.</td><td>JohnY</td><td>10.0.11.24</td><td>768000</td></tr><tr><td>1.</td><td>DavidS</td><td>10.0.11.25</td><td>384000</td></tr></tbody></table>	##	Name	Address	Bitrate	0.	JohnY	10.0.11.24	768000	1.	DavidS	10.0.11.25	384000
##	Name	Address	Bitrate										
0.	JohnY	10.0.11.24	768000										
1.	DavidS	10.0.11.25	384000										

## Remarks

## PhonebookDial

<b>Description</b>	Dial to the address of the specified entry.
<b>Format</b>	PhonebookDial <EntryName>
<b>Parameters</b>	EntryName - The name of the specific entry.
<b>Return</b>	<b>OK</b> on success together with the CallID. <b>ERROR</b> on error together with an error code.
<b>Example</b>	PhonebookDial JohnY PHONEBOOKDIAL OK 0
<b>Remarks</b>	

## 4.8 System Commands

### IniRead

**Description** Read a configuration entry value from an INI file. The INI is in the HD non-volatile memory.

**Format** IniRead <FileName> <Section> <Entry>

**Parameters** **FileName** – The INI file name.

**Section** – The section name.

**Entry** – The entry name.

**Return** **OK** on success together with the entry value.

**ERROR** on error together with an error code.

**Example**

```
IniRead H323.ini Configuration AutoIP
INIREAD OK 1
```

**Remarks**

## IniWrite

<b>Description</b>	Write a configuration entry value to an INI file.
<b>Format</b>	IniWrite <FileName> <Section> <Entry> <Value>
<b>Parameters</b>	<b>FileName</b> – The INI file name. <b>Section</b> – The section name. <b>Entry</b> – The entry name. <b>Value</b> – The new value to be written.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>IniWrite H323.ini Configuration AutoIP 0 INIWRITE OK</pre>
<b>Remarks</b>	

## Reboot

<b>Description</b>	Reboot the system.
<b>Format</b>	Reboot
<b>Parameters</b>	None.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	Reboot REBOOT OK
<b>Remarks</b>	



## KeyPressed

<b>Description</b>	Simulate the pressing of a remote control key.
<b>Format</b>	KeyPressed <KeyName>
<b>Parameters</b>	<b>KeyName</b> - The name of the key that was pressed.
<b>Return</b>	<b>OK</b> on success. <b>ERROR</b> on error together with an error code.
<b>Example</b>	KeyPressed Dial KEYPRESSED OK
<b>Remarks</b>	To get all the supported key names, type <b>KeyPressed</b> . The supported key names are: Zero One Two Three Four Five Six Seven Eight Nine Asterisk Pound Clear Display PIP Dial

**Remarks  
(cont.)**

Hangup  
Menu  
Multipoint  
Status  
Help  
OK  
Cancel  
Select  
Pound  
Up  
Left  
Down  
Right  
ZoomIn  
ZoomOut  
MuteMic  
MuteSpeaker  
VolumePlus  
VolumeMinus  
Red  
Green  
Blue  
Yellow

## ConsoleGetParam

<b>Description</b>	Retrieve a console parameter.
<b>Format</b>	ConsoleGetParam < <i>ConsoleParam</i> >
<b>Parameters</b>	<b>ConsoleParam</b> - The specific console parameter.
<b>Return</b>	<b>OK</b> on success together with the parameter value. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>ConsoleGetParam BAUD_RATE CONSOLEGETPARAM OK 9600</pre>
<b>Remarks</b>	To get a list of supported commands, type <b>ConsoleGetParam</b> . Supported call parameters: COM_NUMBER BAUD_RATE

## ConsoleSetParam

<b>Description</b>	Edit a console parameter.
<b>Format</b>	ConsoleSetParam < <i>ConsoleParam</i> > < <i>Value</i> >
<b>Parameters</b>	<b>ConsoleParam</b> - The specific console parameter. <b>Value</b> - The value that will replace the current value.
<b>Return</b>	<b>OK</b> on success together with the parameter value. <b>ERROR</b> on error together with an error code.
<b>Example</b>	<pre>ConsoleSetParam BAUD_RATE 115200 CONSOLESETPARAM OK</pre>
<b>Remarks</b>	To get a list of supported commands, type <b>ConsoleSetParam</b> . Supported call parameters: COM_NUMBER BAUD_RATE

## 5 EVENTS

### 5.1 Call Events

#### EVENT\_CALL\_DIALTONE

<b>Description</b>	A dialtone state followed dialing.
<b>Format</b>	EVENT_CALL_DIALTONE <CallID>
<b>Parameters</b>	<b>CallID</b> – The ID of the call.
<b>Example</b>	EVENT_CALL_DIALTONE 0
<b>Remarks</b>	<ol style="list-style-type: none"><li>1. Relevant for outgoing calls only.</li><li>2. This is the first event for outgoing calls.</li></ol>

## EVENT\_CALL\_RINGBACK

<b>Description</b>	An “Alerting” or “Proceeding” message was received from the remote side.
<b>Format</b>	EVENT_CALL_RINGBACK <CallID>
<b>Parameters</b>	<b>CallID</b> – The ID of the call.
<b>Example</b>	EVENT_CALL_RINGBACK 0
<b>Remarks</b>	Relevant for outgoing calls only.

## EVENT\_CALL\_CONNECTED

<b>Description</b>	A call connects successfully.
<b>Format</b>	EVENT_CALL_CONNECTED <CallID>
<b>Parameters</b>	<b>CallID</b> – The ID of the call.
<b>Example</b>	EVENT_CALL_CONNECTED 0
<b>Remarks</b>	Relevant for both outgoing and incoming calls.

## EVENT\_CALL\_OFFERING

<b>Description</b>	An incoming call indication was received.
<b>Format</b>	EVENT_CALL_OFFERING <CallID> <RemoteAddress> <RemoteName>
<b>Parameters</b>	<b>CallID</b> – The ID of the call <b>RemoteAddress</b> – The remote party IP address <b>RemoteName</b> – The remote party name
<b>Example</b>	EVENT_CALL_OFFERING 0 10.0.11.25 DemoRoom
<b>Remarks</b>	<ol style="list-style-type: none"><li>1. Relevant for incoming calls.</li><li>2. When working in manual answer the user will need to call either <a href="#">CallAnswer</a> or <a href="#">CallReject</a> commands.</li></ol>



## EVENT\_CALL\_DISCONNECTED

<b>Description</b>	A call was disconnected.
<b>Format</b>	EVENT_CALL_DISCONNECTED <CallID> <DisconnectionReason>
<b>Parameters</b>	<b>CallID</b> – The ID of the call <b>DisconnectionReason</b> – The disconnection reason
<b>Example</b>	EVENT_CALL_DISCONNECTED 0 REMOTE
<b>Remarks</b>	<ol style="list-style-type: none"><li>1. Relevant for incoming and outgoing calls.</li><li>2. Disconnection reason<ul style="list-style-type: none"><li>— LOCAL – Call disconnected by local party</li><li>— REMOTE – Call disconnected by remote party</li><li>— BUSY – Remote party is busy</li><li>— REJECT - Remote party rejected the call</li><li>— UNREACHABLE – Remote party is unreachable</li><li>— NO_ANSWER – Remote party hasn't answered the calls</li><li>— UNKNOWN – Call disconnected due to unknown reason.</li></ul></li></ol>

## EVENT\_CALL\_IDLE

<b>Description</b>	Fired after a call is disconnected. The disconnected call's resources are no longer valid.
<b>Format</b>	EVENT_CALL_IDLE <CallID>
<b>Parameters</b>	<b>CallID</b> – The ID of the call
<b>Example</b>	EVENT_CALL_IDLE 0
<b>Remarks</b>	Relevant for incoming and outgoing calls.

## EVENT\_CALL\_CHANNEL\_ON

<b>Description</b>	A new channel has been established on a call.
<b>Format</b>	EVENT_CALL_CHANNEL_ON <CallID> <ChannelID> <Dir> <Type>
<b>Parameters</b>	<b>CallID</b> – The ID of the call <b>ChannelID</b> – The ID of the Channel <b>Dir</b> – The Channel Direction {RX   TX} <b>Type</b> – The Channel media type {AUDIO   VIDEO   DATA}
<b>Example</b>	EVENT_CALL_CHANNEL_ON 0 0 TX AUDIO EVENT_CALL_CHANNEL_ON 0 1 TX VIDEO EVENT_CALL_CHANNEL_ON 0 2 TX DATA EVENT_CALL_CHANNEL_ON 0 3 RX AUDIO EVENT_CALL_CHANNEL_ON 0 4 RX VIDEO EVENT_CALL_CHANNEL_ON 0 5 RX DATA
<b>Remarks</b>	Relevant for incoming and outgoing calls.

## EVENT\_CALL\_CHANNEL\_OFF

**Description** An active channel was disconnected on a call.

**Format** EVENT\_CALL\_CHANNEL\_OFF <CallID>  
<ChannelID> <Dir> <Type>

**Parameters** **CallID** – The ID of the call  
**ChannelID** – The ID of the Channel  
**Dir** – The Channel Direction  
(RX | TX)  
**Type** – The Channel media type  
(AUDIO | VIDEO | DATA)

**Example**

```
EVENT_CALL_CHANNEL_OFF 0 0 TX AUDIO
EVENT_CALL_CHANNEL_OFF 0 1 TX VIDEO
EVENT_CALL_CHANNEL_OFF 0 2 TX DATA
EVENT_CALL_CHANNEL_OFF 0 3 RX AUDIO
EVENT_CALL_CHANNEL_OFF 0 4 RX VIDEO
EVENT_CALL_CHANNEL_OFF 0 5 RX DATA
```

**Remarks** Relevant for incoming and outgoing calls.

## EVENT\_CALL\_REMOTE\_NOT\_RESPONDING

<b>Description</b>	During an active call, no signal is received from the remote side.
<b>Format</b>	EVENT_CALL_REMOTE_NOT_RESPONDING <CallID>
<b>Parameters</b>	<b>CallID</b> – The ID of the call
<b>Example</b>	EVENT_CALL_REMOTE_NOT_RESPONDING 0
<b>Remarks</b>	<ol style="list-style-type: none"><li>1. Relevant for outgoing and incoming calls only.</li><li>2. The application may disconnect the call or display a message to the user.</li></ol>

## 5.2 Server Events

### EVENT\_SERVER\_DATA\_CHANGED

**Description** Configuration data was changed by the MXM server.

**Format** EVENT\_SERVER\_DATA\_CHANGED <Action>

**Parameters** **Action** –The current action the application should perform.

**REBOOT** the system.

**REFRESH** the application dialog.

**Example** EVENT\_SERVER\_DATA\_CHANGED REBOOT

EVENT\_SERVER\_DATA\_CHANGED REFRESH

**Remarks**

## EVENT\_SERVER\_COMMAND

**Description** A server command was received and must be addressed by the application.

**Format** EVENT\_SERVER\_COMMAND <*Command*>

**Parameters** **Command** – The command the application should perform.

**REBOOT** the system.

**Example** EVENT\_SERVER\_COMMAND REBOOT

**Remarks**

## EVENT\_SERVER\_STATE\_CHANGED

<b>Description</b>	The endpoint's login state with the MXM server has changed.
<b>Format</b>	EVENT_SERVER_STATE_CHANGED <NewState>
<b>Parameters</b>	<b>NewState</b> – The current state with the MXM server.
<b>Example</b>	EVENT_SERVER_STATE_CHANGED LOGGED_IN
<b>Remarks</b>	<p>Possible states with the MXM:</p> <ol style="list-style-type: none"><li>1. <b>LOGGED_IN:</b> Endpoint is logged in the the MXM server.</li><li>2. <b>LOGIN_FAILED_DUPLICATE_ALIAS:</b> Another end point with the same H.323-ID   E.164 is already logged in to the MXM.</li><li>3. <b>LOGIN_FAILED_UNSUPPORTED_VERSION:</b> The MXM version doesn't support the endpoint.</li><li>4. <b>LOGIN_FAILED_LICENSE_VIOLATION:</b> Failed to login due to license violation.</li><li>5. <b>LOGIN_FAILED_TIME_OUT:</b> The login timeout has expired.</li><li>6. <b>LOGIN_FAILED_WAIT_FOR_GRANT:</b> The endpoint is waiting for administrator to grant login.</li><li>7. <b>LOGIN_FAILED_GENERAL_ERROR:</b> Failed to login due to unspecified reason.</li><li>8. <b>LOGGED_OFF:</b> The endpoint isn't configured to work with MXM server.</li></ol>



## 5.3 Gatekeeper Events

### EVENT\_GATEKEEPER\_STATE\_CHANGED

<b>Description</b>	The endpoint's login state with the gatekeeper has changed.
<b>Format</b>	EVENT_GATEKEEPER_STATE_CHANGED <NewState>
<b>Parameters</b>	<b>NewState</b> – The current state with the gatekeeper
<b>Example</b>	EVENT_GATEKEEPER_STATE_CHANGED LOGGED_IN
<b>Remarks</b>	Possible states with the gatekeeper: <ol style="list-style-type: none"><li>1. LOGGED_IN: Endpoint is logged in to the Gatekeeper.</li><li>2. LOGIN_FAILED_DUPLICATE_ALIAS: Another end point with the same H.323-ID   E.164 is already logged in to the gatekeeper.</li><li>3. LOGIN_FAILED_GENERAL_ERROR: Failed to login due to an unspecified reason.</li><li>4. LOGGED_OFF: The endpoint isn't configured to work with this gatekeeper.</li></ol>

## 5.4 Multicast Events

VCON developed a type of H.323 session called Interactive Multicast, in which one end point (*Chair*) transmits the same video and audio at a single time to all the other end points (*Participants*) in the session.

The Chair manages one “floor” token. An end point must have the token in order to speak. End points may request the token and wait for the Chair to accept its request. In addition, the Chair may give the token to any end point without a specific end point request.

### EVENT\_MULTICAST\_CONNECTED

<b>Description</b>	Fired after a multicast session is connected.
<b>Format</b>	EVENT_MULTICAST_CONNECTED <CallID>
<b>Parameters</b>	<b>CallID</b> – The ID of the call.
<b>Example</b>	EVENT_MULTICAST_CONNECTED 0
<b>Remarks</b>	

## EVENT\_MULTICAST\_FLOOR\_OFFERING

<b>Description</b>	Fired when the multicast chair offers the floor to this endpoint. Only the endpoint who has the multicast floor can broadcast video and audio to all the other endpoints in the session.
<b>Format</b>	EVENT_MULTICAST_FLOOR_OFFERING <CallID>
<b>Parameters</b>	<b>CallID</b> – The ID of the call.
<b>Example</b>	EVENT_MULTICAST_FLOOR_OFFERING 0
<b>Remarks</b>	Application may call <a href="#">MulticastAcceptFloor</a> to accept the floor or <a href="#">MulticastRejectFloor</a> to reject it.

## EVENT\_MULTICAST\_FLOOR\_REQUEST\_REJECTED

<b>Description</b>	Fired when the multicast chair rejected this endpoint's floor request.
<b>Format</b>	EVENT_MULTICAST_FLOOR_REQUEST_REJECTED <CallID>
<b>Parameters</b>	<b>CallID</b> – The ID of the call
<b>Example</b>	EVENT_MULTICAST_FLOOR_REQUEST_REJECTED 0
<b>Remarks</b>	

## EVENT\_MULTICAST\_FLOOR\_CHANGED

<b>Description</b>	Fired when the floor is given to another endpoint.
<b>Format</b>	EVENT_MULTICAST_FLOOR_CHANGED <CallID> <Type> <Name>
<b>Parameters</b>	<b>CallID</b> – The ID of the call. <b>Type</b> – The type of floor that has been changed { <b>VIDEO</b>   <b>AUDIO</b> }. <b>Name</b> – The name of the participant who now owns the floor.
<b>Example</b>	EVENT_MULTICAST_FLOOR_CHANGED 0 VIDEO DemoRoom
<b>Remarks</b>	

## EVENT\_MULTICAST\_FLOOR\_GRANTED

<b>Description</b>	Fired when the multicast chair has granted the floor to this endpoint.
<b>Format</b>	EVENT_MULTICAST_FLOOR_GRANTED <CallID> <Type>
<b>Parameters</b>	<b>CallID</b> – The ID of the call <b>Type</b> – The type of floor that has been granted ( <b>VIDEO</b>   <b>AUDIO</b> )
<b>Example</b>	EVENT_MULTICAST_FLOOR_GRANTED 0 VIDEO
<b>Remarks</b>	

## EVENT\_MULTICAST\_PASSWORD\_REJECTED

<b>Description</b>	Fired when this endpoint enters an incorrect password while attempting to join a multicast session.
<b>Format</b>	EVENT_MULTICAST_PASSWORD_REJECTED <CallID>
<b>Parameters</b>	<b>CallID</b> – The ID of the call.
<b>Example</b>	EVENT_MULTICAST_PASSWORD_REJECTED 0
<b>Remarks</b>	Fired as a result of a call to <a href="#">MulticastSendPassword</a> .

## EVENT\_MULTICAST\_PASSWORD\_REQUESTED

<b>Description</b>	Fired when the endpoint must enter a password in order to join a multicast session.
<b>Format</b>	EVENT_MULTICAST_PASSWORD_REQUESTED <CallID>
<b>Parameters</b>	<b>CallID</b> – The ID of the call
<b>Example</b>	EVENT_MULTICAST_PASSWORD_REQUESTED 0
<b>Remarks</b>	Call <a href="#">MulticastSendPassword</a> to provide the password



## 5.5 Streaming Events

### EVENT\_STREAMING\_STARTED

<b>Description</b>	Fired when a streaming session starts.
<b>Format</b>	EVENT_STREAMING_STARTED <SessionID> <IsFirstSession>
<b>Parameters</b>	<b>SessionID</b> – The streaming session ID. <b>IsFirstSession</b> – {0   1} Set to <b>1</b> if this is the first active streaming session.
<b>Example</b>	EVENT_STREAMING_STARTED 0 1
<b>Remarks</b>	

## EVENT\_STREAMING\_STOPPED

<b>Description</b>	Fired after the streaming session ends.
<b>Format</b>	EVENT_STREAMING_STOPPED < <i>SessionID</i> > < <i>IsLastSession</i> >
<b>Parameters</b>	<b>SessionID</b> – The ID of the streaming session. <b>IsLastSession</b> – { <b>0</b>   <b>1</b> } Set to <b>1</b> if this is the last active streaming session.
<b>Example</b>	EVENT_STREAMING_STOPPED 0 1
<b>Remarks</b>	

## 5.6 System Events

### EVENT\_SYSTEM\_INIT\_COMPLETED\_SUCCESS

<b>Description</b>	Fired when the system initializes successfully.
<b>Format</b>	EVENT_SYSTEM_INIT_COMPLETED_SUCCESS
<b>Parameters</b>	None.
<b>Example</b>	EVENT_SYSTEM_INIT_COMPLETED_SUCCESS
<b>Remarks</b>	Calling some of the commands prior to receiving this event may result in an error.

## EVENT\_SYSTEM\_INIT\_COMPLETED\_FAILURE

<b>Description</b>	Fired when the system fails to initialize.
<b>Format</b>	EVENT_SYSTEM_INIT_COMPLETED_FAILURE
<b>Parameters</b>	None.
<b>Example</b>	EVENT_SYSTEM_INIT_COMPLETED_FAILURE
<b>Remarks</b>	User may try to <a href="#">Reboot</a> the system to recover.

## **EVENT\_SYSTEM\_DHCP\_STATE\_RECEIVED\_ADDRESS**

<b>Description</b>	Fired when the system received a valid IP address from the DHCP server.
<b>Format</b>	EVENT_SYSTEM_DHCP_STATE_RECEIVED_ADDRESS
<b>Parameters</b>	None.
<b>Example</b>	EVENT_ SYSTEM_ DHCP_STATE_RECEIVED_ADDRESS
<b>Remarks</b>	Relevant only when the endpoint is configured to work with a DHCP.

## EVENT\_DHCP\_STATE\_FAILED\_RECEIVING\_ADDRESS

<b>Description</b>	Fired when system failed to receive an IP address from the DHCP server.
<b>Format</b>	EVENT_DHCP_STATE_FAILED_RECEIVING_ADDRESS
<b>Parameters</b>	None.
<b>Example</b>	EVENT_DHCP_STATE_FAILED_RECEIVING_ADDRESS
<b>Remarks</b>	<ol style="list-style-type: none"><li>1. Relevant only when the endpoint is configured to work with a DHCP.</li><li>2. Notify the user, check that the HD is connected to the network, and the DHCP server is working properly.</li></ol>

## 6 THE USER.INI FILE

**Description** The *user.ini* file contains several configuration parameters that you may edit. The file is located in the HD100 system's */ver/ini* folder.

**Parameters**  Configuration parameters:

[CallEvents](#)

[MulticastEvents](#)

[StreamingEvents](#)

[GatekeeperEvents](#)

[ServerEvents](#)

GUI parameters:

[HideAll](#)

[HideDlg](#)

## 6.1 Configuration Parameters

### CallEvents

<b>Description</b>	System sends all Call Events automatically. User does not need to manually call the CallEvents command.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	0



## MulticastEvents

<b>Description</b>	System sends all Multicast Events automatically. User does not need to manually call the MulticastEvents command.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	0

## StreamingEvents

<b>Description</b>	System sends all Streaming Events automatically. User does not need to manually call the StreamingEvents command.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	0

## GatekeeperEvents

<b>Description</b>	System sends all Gatekeeper Events automatically. User does not need to manually call the GatekeeperEvents command.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	0

## ServerEvents

<b>Description</b>	System sends all Server Events automatically. User does not need to manually call the ServerEvents command.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	0

## 6.2 GUI Parameters

### HideAll

<b>Description</b>	Hides the HD100 user interface. Only video is displayed on the screen.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	0

## HideDlg

<b>Description</b>	Hides the HD100 dialog boxes. Only video, messages and icons are displayed on the screen.
<b>Valid Value</b>	{0 1} 0 –Disable 1 - Enable
<b>Default Value</b>	0

## 7 WORKFLOW EXAMPLES

This section provides examples of the workflow of the HD100 system during basic operations. By following the numbered order of the commands, screen text, and actions presented in the tables, you can understand the action/effect relationship among the application interface, the screen console, and the HD100.

In the following examples:

- Commands listed in the Application column are entered into the end-user application.
- Text that appears on the screen, resulting either from the entry of command or an action by the HD100, appears in the Console column.
- Actions that occur in the HD100 are described in the HD100 column.

### 7.1 Incoming Call Flow

The following table presents the flow of events and actions that result in a successful incoming videoconference call:

APPLICATION	CONSOLE	HD100
1. <b>Connect to console</b>	2. Welcome to HD100 Version Board Type Camera Input	3. System completes the initialization phase.
	4. <code>EVENT_SYSTEM_INIT_COMPLETED_SUCCESS</code>	
5. <b>CallEvents 1</b>	6. CALLEVENTS OK	7. Incoming call.
	8. <code>EVENT_CALL_OFFERING 0 10.11.24 Demo</code>	
9. <b>CallAnswer 1</b>	10. CALLANSWER OK	11. Call is connected successfully.
	12. <code>EVENT_CALL_CONNECTED 0</code>	13. Outgoing video channel opened.

	14. EVENT_CALL_CHANNEL_ON 0 0 TX VIDEO	15. Outgoing audio channel opened.
	16. EVENT_CALL_CHANNEL_ON 0 1 TX AUDIO	17. Outgoing data channel opened.
	18. EVENT_CALL_CHANNEL_ON 0 2 TX DATA	19. Incoming Video channel opened.
	20. EVENT_CALL_CHANNEL_ON 0 3 RX VIDEO	21. Incoming Audio channel opened.
	22. EVENT_CALL_CHANNEL_ON 0 4 RX AUDIO	23. Incoming Data channel opened.
	24. EVENT_CALL_CHANNEL_ON 0 5 RX DATA	
25. <b>Hangup 0</b>	26. HANGUP OK	27. Outgoing video channel closed.
	28. EVENT_CALL_CHANNEL_OF F 0 0 TX VIDEO	29. Outgoing audio channel closed.
	30. EVENT_CALL_CHANNEL_OF F 0 1 TX AUDIO	31. Outgoing data channel closed.
	32. EVENT_CALL_CHANNEL_OF F 0 2 TX DATA	33. Incoming Video channel closed.
	34. EVENT_CALL_CHANNEL_OF F 0 3 RX VIDEO	35. Incoming Audio channel closed.
	36. EVENT_CALL_CHANNEL_OF F 0 4 RX AUDIO	37. Incoming Data channel closed.
	38. EVENT_CALL_CHANNEL_OF F 0 5 RX DATA	39. Call is disconnected.
	40. EVENT_CALL_DISCONNECTED 0 LOCAL	41. System becomes idle.
	42. EVENT_CALL_IDLE 0	



## 7.2 Outgoing Call Flow

The following table presents the flow of events and actions that result in a successful outgoing videoconference call:

APPLICATION	CONSOLE	HD100
1. Connect to console	2. Welcome to HD100 Version Board Type Camera Input	3. System completes the initialization phase.
	4. <code>EVENT_SYSTEM_INIT_COMPLETED_SUCCESS</code>	
5. <b>CallEvents 1</b>	6. CALLEVENTS OK	
7. <b>Dial 10.0.11.12</b>	8. DIAL OK	9. Call state dialtone arrived
	10. <code>EVENT_CALL_DIALTONE 0</code>	11. Call state ringback arrived
	12. <code>EVENT_CALL_RINGBACK 0</code>	13. Call become connected
	14. <code>EVENT_CALL_CONNECTED 0</code>	15. Outgoing video channel opened
	16. <code>EVENT_CALL_CHANNEL_ON 0 0 TX VIDEO</code>	17. Outgoing audio channel opened.
	18. <code>EVENT_CALL_CHANNEL_ON 0 1 TX AUDIO</code>	19. Outgoing data channel opened.
	20. <code>EVENT_CALL_CHANNEL_ON 0 2 TX DATA</code>	21. Incoming Video channel opened.

	22. <code>EVENT_CALL_CHANNEL_ON</code> <code>0 3 RX VIDEO</code>	23. Incoming Audio channel opened.
	24. <code>EVENT_CALL_CHANNEL_ON</code> <code>0 4 RX AUDIO</code>	25. Incoming Data channel opened.
	26. <code>EVENT_CALL_CHANNEL_ON</code> <code>0 5 RX DATA</code>	27. Remote party disconnects the call
		28. Outgoing video channel closed.
	29. <code>EVENT_CALL_CHANNEL_OFF</code> <code>0 0 TX VIDEO</code>	30. Outgoing audio channel closed.
	31. <code>EVENT_CALL_CHANNEL_OFF</code> <code>0 1 TX AUDIO</code>	32. Outgoing data channel closed.
	33. <code>EVENT_CALL_CHANNEL_OFF</code> <code>0 2 TX DATA</code>	34. Incoming Video channel closed.
	35. <code>EVENT_CALL_CHANNEL_OFF</code> <code>0 3 RX VIDEO</code>	36. Incoming Audio channel closed.
	37. <code>EVENT_CALL_CHANNEL_OFF</code> <code>0 4 RX AUDIO</code>	38. Incoming Data channel closed.
	39. <code>EVENT_CALL_CHANNEL_OFF</code> <code>0 5 RX DATA</code>	40. Call is disconnected.
	41. <code>EVENT_CALL_DISCONNECTED</code> <code>0 REMOTE</code>	42. Call become idle
	43. <code>EVENT_CALL_IDLE</code> 0	