



AT&T

**CLASSIC MAIL**  
**VOICE MESSAGING SYSTEM**

Quick  
Reference  
Card

# Using Your CLASSIC MAIL System

This easy-to-follow reference guide will help you quickly navigate through your voice mailbox.

## To enter your CLASSIC MAIL System:

### FROM YOUR MERLIN TELEPHONE:


1. Press the labeled outside button
2. Press **\*** or access code
3. Enter your mailbox number
4. Enter your password

### FROM AN OUTSIDE TELEPHONE:

1. Dial your company number
2. Ask to be transferred to Classic Mail, or wait for Classic Mail to answer
3. Press **\***
4. Enter your mailbox number
5. Enter your password

# Quick Reference

Refer to your *Mailbox User Guide* for additional information.




## Commonly Used Keys:

- To go to main menu Press \* \*
- To backup or cancel Press \*
- To accept an entry Press #
- To transfer to attendant Press 0

**Note:** If you have a Merlin Plus, Merlin 1030, or a Merlin with Feature Package 2 installed, you may have to press the pound key twice to generate a tone. If you do not hear a tone when first pressing the pound key, try pressing it again.

# Quick Reference

Refer to your *Mailbox User Guide* for additional information.



## Commonly Used Keys:

- To go to main menu                      Press **\* \***
- To backup or cancel                      Press **\***
- To accept an entry                        Press **#**
- To transfer to attendant                Press **0**

**Note:** If you have a Merlin Plus, Merlin 1030, or a Merlin with Feature Package 2 installed, you may have to press the pound key twice to generate a tone. If you do not hear a tone when first pressing the pound key, try pressing it again.

## TO LISTEN TO A MESSAGE:

From the Main Menu	Press	<b>1</b>
To replay a message	Press	<b>1</b>
To stop the next message	Press	<b>2</b>
To delete a message	Press	<b>3</b>
To forward a message	Press	<b>5</b>

## TO SEND MESSAGE:

From the Main Menu	Press	<b>2</b>
Record your message, then	Press	<b>#</b>
To accept your recording	Press	<b>#</b>
Enter the destination mailbox number [    ]		
or, to use the Directory	Press	<b>#</b>
To send a normal delivery	Press	<b>#</b>
or, to send an urgent delivery	Press	<b>1</b>
or, to send a certified delivery	Press	<b>2</b>
or, to send an urgent and certified delivery	Press	<b>3</b>

## IMPORTANT MAILBOX NUMBERS

Name \_\_\_\_\_ Mailbox \_\_\_\_\_

Name \_\_\_\_\_ Mailbox \_\_\_\_\_

Name \_\_\_\_\_ Mailbox \_\_\_\_\_

Name \_\_\_\_\_ Mailbox \_\_\_\_\_

## GROUP LISTS

\_\_\_\_\_

\_\_\_\_\_

## NEW ACCESS CODE

New Access Code (if changed from **\***)

Document No. 585-321-102  
Issue 1  
December 1993

*CLASSIC MAIL is a trademark of  
American Telephone and Telegraph Company.  
Merlin is a registered trademark of  
American Telephone and Telegraph Company.*