

SECTION **IDX**
ALPHABETICAL INDEX

A
B
C
D
E
F
G
H
I
J
K
L

IDX

ALPHABETICAL INDEX

A

- A/C - Wiring diagram [MTC-27](#)
A/C air flow [MTC-21](#)
A/C component layout [MTC-19](#)
A/C compressor clutch removal and installation . [MTC-65](#)
A/C compressor mounting [MTC-64](#)
A/C compressor precaution [MTC-8](#)
A/C compressor special service tool [MTC-11](#)
A/C control linkage adjustment (manual A/C) . [MTC-37](#)
A/C control operation (manual A/C) [MTC-20](#)
A/C diagnostic work flow (manual A/C) [MTC-30](#)
A/C HFC134a (R134a) system identification [MTC-4](#)
A/C HFC134a (R134a) system introduction ... [MTC-15](#)
A/C HFC134a (R134a) system precaution [MTC-3](#)
A/C HFC134a (R134a) system service procedure [MTC-78](#)
A/C HFC134a (R134a) system service tools .. [MTC-12](#)
A/C HFC134a system service equipment precaution ... [MTC-8](#)
A/C lubricant (R134a) [MTC-16](#)
A/C lubrication oil [MTC-16](#)
A/C operational check [MTC-31](#)
A/C performance chart [MTC-54](#)
A/C performance test diagnoses [MTC-54](#)
A/C pressure switch [MTC-15](#)
A/C push control [MTC-20](#)
A/C reray [MTC-51](#)
A/C service data specification [MTC-87](#)
A/C switch [MTC-20](#)
A/C, M - Wiring diagram [MTC-27](#)
A/F - Wiring diagram ... [EC-482](#), [EC-488](#), [EC-494](#), [EC-501](#), [EC-508](#), [EC-514](#), [EC-522](#), [EC-1185](#), [EC-1191](#), [EC-1197](#), [EC-1204](#), [EC-1212](#), [EC-1219](#), [EC-1228](#)
A/FH - Wiring diagram [EC-386](#), [EC-1100](#)
A/T - Wiring diagram [AT-406](#)
A/T fluid temperature sensor [AT-125](#), [AT-493](#)
A/T self-diagnoses [AT-431](#), [AT-438](#), [AT-439](#)
A/T shift lock system [AT-252](#), [AT-632](#)
A/T shift lock system - Wiring diagram [AT-253](#), [AT-633](#)
A/T trouble diagnoses [AT-56](#)
A/T Wiring diagram AT - 1ST [AT-137](#), [AT-510](#)
A/T Wiring diagram AT - 2ND [AT-142](#), [AT-515](#)
A/T Wiring diagram AT - 3RD [AT-147](#), [AT-520](#)
A/T Wiring diagram AT - 4TH [AT-153](#), [AT-525](#)
A/T Wiring diagram AT - BA/FTS [AT-199](#), [AT-571](#)
A/T Wiring diagram AT - CAN [AT-209](#), [AT-587](#)
A/T Wiring diagram AT - ENG SS [AT-132](#), [AT-505](#)
A/T Wiring diagram AT - FTS [AT-122](#), [AT-495](#)
A/T Wiring diagram AT - LPSV [AT-174](#), [AT-545](#)
A/T Wiring diagram AT - MAIN [AT-112](#), [AT-484](#)
A/T Wiring diagram AT - NONDTC [AT-215](#), [AT-593](#)
A/T Wiring diagram AT - OVRCSV [AT-194](#), [AT-566](#)
A/T Wiring diagram AT - PNP/SW [AT-116](#), [AT-489](#)
A/T Wiring diagram AT - SSV/A [AT-180](#), [AT-551](#)
A/T Wiring diagram AT - SSV/B [AT-184](#), [AT-556](#)
A/T Wiring diagram AT - TCCSIG [AT-166](#), [AT-537](#)
A/T Wiring diagram AT - TCV [AT-160](#), [AT-532](#)
A/T Wiring diagram AT - TPS [AT-190](#), [AT-561](#)
A/T Wiring diagram AT - VSS A/T [AT-128](#), [AT-501](#)
A/T Wiring diagram AT - VSSMTR ... [AT-205](#), [AT-578](#), [AT-583](#)
ABS - Wiring diagram [BRC-10](#)
ABS sensor rotor [RAX-6](#)
Accelerator pedal position (APP) sensor [EC-573](#), [EC-594](#), [EC-1284](#), [EC-1291](#), [EC-1306](#)
Air bag [SRS-3](#)
Air bag precautions [GI-3](#)
Air bleeding (hydraulic clutch) [CL-7](#), [CL-24](#)
Air bleeding for brake system [BR-7](#)
Air cleaner and air duct [EM-106](#)
Air cleaner filter replacementQG18DE [MA-19](#)
Air cleaner filter replacementQR25DE [MA-26](#)
Air conditioner - Wiring diagram [MTC-27](#)
Air control cable adjustment [MTC-39](#)
Air flow meter - See Mass air flow sensor [EC-861](#), [EC-870](#)
Air fuel ratio sensor 1 .. [EC-479](#), [EC-485](#), [EC-491](#), [EC-498](#), [EC-505](#), [EC-511](#), [EC-519](#), [EC-1183](#), [EC-1189](#), [EC-1195](#), [EC-1202](#), [EC-1209](#), [EC-1216](#), [EC-1225](#)
Air fuel ratio sensor 1 heater [EC-385](#), [EC-1099](#)
Air mix door control linkage adjustment [MTC-41](#)
Air spoiler, rear [EI-22](#)
Alternator [SC-30](#)
Angular tightening application [EM-5](#), [EM-94](#)
Antenna [AV-17](#)
Anti-lock brake system - Wiring diagram [BRC-10](#)
APPS1 - Wiring diagram [EC-575](#), [EC-1286](#)
APPS2 - Wiring diagram [EC-582](#), [EC-1293](#)
APPS3 - Wiring diagram [EC-596](#), [EC-1308](#)
ASC/BS - Wiring diagram [EC-552](#), [EC-1258](#)
ASC/SW - Wiring diagram [EC-544](#), [EC-1251](#)
ASCSOF - Wiring diagram [EC-644](#), [EC-1371](#)
ASCD [EC-33](#), [EC-678](#)
ASCD (automatic speed control device) [ACS-2](#)
ASCD brake switch [EC-1370](#)
ASCD clutch switch [EC-1370](#)
ASCD indicator lamp [EC-1380](#)
ASCIND - Wiring diagram [EC-653](#), [EC-1381](#)
Audio [AV-2](#)
AUDIO - Wiring diagram [AV-4](#)
Audio and A/C control removal and installation - See Instrument panel [IP-10](#)
Automatic transaxle number [GI-50](#)
Automatic transmission fluid replacement [MA-31](#)
Axle [MA-36](#)

B

- Back door window [GW-12](#)
BACK/L - Wiring diagram [LT-22](#)
Back-up lamp [LT-22](#)
Back-up lamp switch (M/T) [MT-12](#)
Back-up lamp switch (M/T)Back-up lamp switch [MT-75](#)
Ball joint (front) [FSU-14](#)
Basic inspection [EC-74](#), [EC-722](#)
Battery [SC-4](#)

ALPHABETICAL INDEX

Battery/Starting/Charging System Tester [SC-6](#), [SC-13](#), [SC-24](#)
 Baulk ring (M/T) [MT-19](#), [MT-82](#)
 Bi-level door control linkage adjustment [MTC-39](#)
 Block heater [EM-164](#)
 Blower motor [MTC-46](#)
 Blower resistor [MTC-46](#)
 Blower unit [MTC-75](#)
 Body alignment [BL-116](#)
 Brake booster [BR-16](#)
 Brake control valve (Proportioning valve) [BR-10](#)
 Brake fluid change [BR-6](#)
 Brake fluid level [MA-32](#)
 Brake fluid level and line check [BR-6](#)
 Brake hydraulic line [BR-8](#)
 Brake inspectionDisc Brake [MA-33](#)
 Brake inspectionDrum Brake [MA-34](#)
 Brake lines and cables inspection [MA-32](#)
 Brake lining wear temporary checkingDisc Brake . [MA-34](#)
 Brake lining wear temporary checkingDrum Brake [MA-34](#)
 Brake pedal [BR-11](#)
 Brake switch [EC-567](#), [EC-1279](#), [EC-1370](#)
 BRK/SW - Wiring diagram [EC-568](#), [EC-1280](#)
 Bulb specifications [LT-49](#)
 Bumper, front [EI-13](#)
 Bumper, rear [EI-18](#)

C

Camshaft [EM-126](#)
 Camshaft inspection [EM-35](#), [EM-37](#), [EM-128](#)
 Camshaft position sensor (PHASE) .. [EC-291](#), [EC-999](#)
 CAN - Wiring diagram . [EC-174](#), [EC-843](#), [LAN-7](#), [LAN-18](#)
 CAN (Controller Area Network) [LAN-6](#), [LAN-17](#)
 CAN communication ... [EC-173](#), [EC-842](#), [AT-208](#), [AT-586](#), [LAN-6](#), [LAN-17](#)
 Canister-See EVAP canister [EC-39](#), [EC-684](#)
 CHARGE - Wiring diagram [SC-23](#)
 Charging system [SC-22](#)
 Chassis and body maintenance [MA-9](#), [MA-30](#)
 CHIME - Wiring diagram [DI-44](#)
 CIGAR - Wiring diagram [WW-10](#)
 Cigarette lighter [WW-10](#)
 Circuit breaker [PG-46](#)
 Closed loop control [EC-29](#), [EC-674](#)
 Closed loop control (Bank 1) [EC-1159](#)
 Clutch cover [CL-17](#), [CL-33](#)
 Clutch disc [CL-17](#), [CL-33](#)
 Clutch fluid level [MA-30](#)
 Clutch master cylinder [CL-9](#), [CL-26](#)
 Clutch operating cylinder [CL-11](#), [CL-28](#)
 Clutch pedal [CL-7](#), [CL-24](#)
 Clutch release bearing [CL-14](#), [CL-31](#)
 Clutch release mechanism [CL-14](#), [CL-31](#)
 Clutch withdrawal lever [CL-14](#), [CL-31](#)
 Coil spring (front) [FSU-9](#)

Coil spring (rear) [RSU-10](#)
 Collision diagnosis [SRS-47](#)
 Combination lamp, front, removal and installation [EI-13](#)
 Combination lamp, rear, removal and installation [EI-22](#)
 Combination meter [DI-4](#), [DI-26](#)
 Combination meter removal and installation - See Instrument panel [IP-10](#), [DI-26](#)
 Combination switch [LT-4](#)
 Component Location (manual A/C) [MTC-23](#)
 Compression pressure [EM-55](#)
 Compressor clutch removal and installation ... [MTC-65](#)
 Compressor mounting [MTC-64](#)
 Compressor precaution [MTC-8](#)
 Compressor special service tool [MTC-11](#)
 Connecting rod [EM-72](#)
 Connecting rod bearing clearance [EM-77](#)
 Connecting rod bushing clearance [EM-78](#)
 Connector inspection [GI-24](#)
 Console box - See Instrument panel [IP-10](#)
 CONSULT for ABS [BRC-16](#)
 CONSULT for engine [EC-134](#), [EC-791](#)
 CONSULT general information [GI-37](#)
 Control lever (M/T) [MT-13](#)
 Control valve (A/T) [AT-297](#)
 Controller Area Network (CAN) [LAN-6](#), [LAN-17](#)
 Converter housing installation [AT-379](#), [AT-740](#)
 COOL/F - Wiring diagram [EC-459](#), [EC-1164](#)
 Coolant mixture ratio [MA-14](#)
 Coolant replacementQG18DE [MA-16](#)
 Coolant replacementQR25DE [MA-23](#)
 Cooling circuit (engine) [CO-7](#)
 Cooling fan control [EC-1161](#)
 Cooling fan motor [EC-1161](#)
 Cooling fan relay [EC-468](#), [EC-1173](#)
 Cooling unit (A/C evaporator) [MTC-76](#)
 Coupling sleeve (M/T) [MT-19](#), [MT-82](#)
 Crankcase ventilation system - See Positive crankcase ventilation [EC-49](#), [EC-694](#)
 Crankshaft [EM-74](#), [EM-165](#)
 Crankshaft position sensor (POS) [EC-284](#), [EC-992](#)
 Cylinder block [EM-69](#), [EM-164](#)
 Cylinder block boring [EM-184](#)
 Cylinder head [EM-55](#), [EM-148](#)

D

D/LOCK - Wiring diagram [BL-14](#)
 Data link connector [EC-1383](#)
 Daytime light system [LT-10](#)
 Daytime running light - See Daytime light system .. [LT-10](#)
 DEF - Wiring diagram [GW-20](#)
 Detonation sensor - See Knock sensor [EC-279](#)
 Diagnosis sensor unit [SRS-38](#)
 Diagnostic trouble code (DTC) for OBD system [EC-15](#), [EC-55](#), [EC-658](#), [EC-701](#)
 Diagnostic trouble code (DTC) inspection priority chart [EC-103](#), [EC-762](#)
 Differential gear (FF A/T) [AT-355](#)

ALPHABETICAL INDEX

Differential gear (FF M/T) [MT-21](#), [MT-55](#), [MT-85](#)
Dimensions [GI-50](#)
DLC - Wiring diagram [EC-655](#), [EC-1383](#)
Dome light - See Interior lamp [LT-36](#)
Door adjustment (front) [BL-31](#)
Door adjustment (rear) [BL-31](#)
Door glass [BL-31](#), [GW-6](#), [GW-12](#), [GW-13](#)
Door glass Fitting Adjustment [BL-31](#)
Door mirror [GW-14](#), [GW-16](#)
Door trim [EI-31](#)
Door, front [BL-31](#), [GW-12](#)
Door, rear [BL-31](#), [GW-13](#)
Drive belt [EM-103](#)
Drive belt inspectionQG18DE [MA-16](#)
Drive belt inspectionQR25DE [MA-23](#)
Drive plate runout [EM-79](#)
Drive shaft [MA-37](#)
Drive shaft (front) [FAX-5](#), [FAX-11](#)
Dropping resistor (A/T) [AT-178](#), [AT-543](#)
DTC work support [EC-144](#), [EC-803](#)
DTRL - Wiring diagram [LT-14](#)

E

ECM input/output signal [EC-126](#), [EC-784](#), [EC-807](#)
ECM power supply [EC-165](#), [EC-390](#), [EC-835](#), [EC-1104](#)
ECM relay [EC-841](#)
ECM/PW - Wiring diagram [EC-391](#), [EC-1105](#)
ECTS - Wiring diagram [EC-210](#), [EC-886](#)
Electric throttle control actuator [EC-398](#), [EC-400](#), [EC-412](#), [EC-1112](#), [EC-1114](#), [EC-1126](#)
Electrical diagnoses [GI-24](#)
Electrical load signal circuit [EC-631](#), [EC-1352](#)
Electrical units location [PG-43](#)
Electronic ignition (EI) system [EC-30](#), [EC-675](#)
Engine compartment [BL-117](#)
Engine control circuit diagram [EC-122](#), [EC-780](#)
Engine control component parts location . [EC-110](#), [EC-769](#)
Engine control module (ECM) [EC-382](#), [EC-1096](#)
Engine control system diagram and chart . [EC-27](#), [EC-671](#)
Engine coolant temperature sensor (ECTS) ... [EC-208](#), [EC-220](#), [EC-884](#), [EC-897](#)
Engine fail-safe system [EC-105](#), [EC-764](#)
Engine oil filter replacementQG18DE [MA-20](#)
Engine oil filter replacementQR25DE [MA-27](#)
Engine oil precautions [GI-7](#)
Engine oil replacementQG18DE [MA-20](#)
Engine oil replacementQR25DE [MA-26](#)
Engine outer component parts [EM-15](#)
Engine removal [EM-65](#), [EM-159](#)
Engine room - See Engine compartment [BL-117](#)
Engine serial number [GI-49](#)
ETC1 - Wiring diagram [EC-401](#), [EC-1115](#)
ETC2 - Wiring diagram [EC-409](#), [EC-1123](#)
ETC3 - Wiring diagram [EC-413](#), [EC-1127](#)
EVAP canister [EC-39](#), [EC-684](#)
EVAP canister purge volume control solenoid valve

[EC-318](#), [EC-527](#), [EC-1031](#), [EC-1234](#)
EVAP canister vent control valve [EC-325](#), [EC-535](#), [EC-1038](#), [EC-1242](#)
EVAP control system (small leak) diagnosis .. [EC-309](#), [EC-348](#), [EC-1022](#), [EC-1061](#), [EC-1069](#)
EVAP control system pressure sensor ... [EC-332](#), [EC-335](#), [EC-341](#), [EC-1045](#), [EC-1048](#), [EC-1054](#)
EVAP control system purge flow monitoring diagnosis . [EC-303](#), [EC-1016](#)
EVAP vapor lines inspectionQG18DE [MA-22](#)
EVAP vapor lines inspectionQR25DE [MA-29](#)
Evaporative emission (EVAP) system [EC-36](#), [EC-681](#)
Exhaust system [EX-3](#)
Exhaust system inspection [MA-30](#)
Exterior [EI-22](#)

F

F/FOG - Wiring diagram [LT-25](#)
F/PUMP - Wiring diagram [EC-622](#), [EC-1343](#)
Fan switch [MTC-46](#)
Final drive (FF A/T) [AT-355](#)
Final drive (FF M/T) [MT-21](#), [MT-55](#), [MT-85](#)
Finisher, interior - See Trim [EI-28](#)
Finisher, trunk lid [EI-33](#)
Floor trim [EI-28](#)
Flow charts [GI-27](#)
Fluid temperature sensor (A/T) [AT-125](#), [AT-493](#)
Fluids [MA-13](#)
Flywheel (clutch) [CL-18](#), [CL-34](#)
Flywheel runout [EM-79](#)
Fog lamp, front [LT-24](#)
Fog lamp, front, removal and installation [EI-13](#)
Fork rod (M/T) [MT-20](#), [MT-84](#)
Forward clutch [AT-324](#)
Freeze frame data [EC-56](#), [EC-702](#)
Front axle [FAX-5](#)
Front bumper [EI-13](#)
Front combination lamp removal and installation [EI-13](#)
Front door [BL-31](#), [GW-12](#)
Front fog lamp [LT-24](#)
Front fog lamp removal and installation [EI-13](#)
Front passenger air bag [SRS-45](#)
Front seat [SE-3](#)
Front seat belt [SB-3](#)
Front washer [WW-3](#)
Front wiper [WW-3](#)
FTTS - Wiring diagram [EC-258](#), [EC-262](#), [EC-966](#), [EC-970](#)
FUEL - Wiring diagram [EC-244](#), [EC-251](#), [EC-945](#), [EC-956](#)
Fuel cut control (at no load high engine speed) [EC-31](#), [EC-676](#)
Fuel gauge [DI-4](#)
Fuel injection system .. [EC-242](#), [EC-249](#), [EC-943](#), [EC-954](#)
Fuel injector and fuel tube [EM-21](#), [EM-121](#)
Fuel level sensor [EC-365](#), [EC-367](#), [EC-369](#), [EC-1079](#), [EC-1081](#), [EC-1083](#)

ALPHABETICAL INDEX

Fuel line inspection [FL-2](#), [MA-19](#)
Fuel line inspection QR25DE [MA-25](#)
Fuel precautions [GI-3](#), [GI-5](#)
Fuel pressure check [EC-94](#), [EC-752](#)
Fuel pressure release [EC-94](#), [EC-752](#)
Fuel pump [EC-621](#), [EC-1342](#)
Fuel tank temperature sensor ... [EC-256](#), [EC-261](#), [EC-964](#), [EC-969](#)
Fuel tank vacuum relief valve [EC-39](#), [EC-684](#)
Fuel tank Removal and Installation [FL-7](#)
Fuse [PG-46](#)
Fuse and fusible link box [PG-54](#)
Fuse block [PG-53](#)
Fusible link [PG-46](#)

G

Gauges [DI-4](#)
Gear components (M/T) [MT-19](#), [MT-82](#)
Generator [SC-30](#)
Generator - See Alternator [SC-30](#)
Generic scan tool (GST) [EC-146](#), [EC-805](#)
Ground distribution [PG-13](#)

H

H/LAMP - Wiring diagram [LT-7](#)
H/MIRROR - Wiring diagram [GW-15](#)
Harness connector [PG-47](#)
Harness connector inspection [GI-24](#)
Harness layout [PG-22](#)
Hazard warning lamp [LT-27](#)
Headlamp [LT-6](#)
Headlamp removal and installation [EI-13](#)
Headlining - See Roof trim [EI-32](#)
Heated oxygen sensor 1 ... [EC-905](#), [EC-912](#), [EC-922](#), [EC-1131](#), [EC-1137](#)
Heated oxygen sensor 1 heater [EC-849](#)
Heated oxygen sensor 2 ... [EC-234](#), [EC-438](#), [EC-446](#), [EC-929](#), [EC-935](#), [EC-1143](#), [EC-1151](#)
Heated oxygen sensor 2 heater [EC-180](#), [EC-855](#)
HEATER - Wiring diagram [MTC-25](#)
Heater mirror [GW-15](#)
Heater system - Wiring diagram [MTC-25](#)
Heater unit (heater core) [MTC-74](#)
Height (Dimensions) [GI-50](#)
HFC134a (R134a) system identification [MTC-4](#)
HFC134a (R134a) system introduction [MTC-15](#)
HFC134a (R134a) system precaution [MTC-3](#)
HFC134a (R134a) system service procedure [MTC-78](#)
HFC134a (R134a) system service tools [MTC-12](#)
HFC134a system service equipment precaution [MTC-8](#)
High clutch [AT-318](#)
HO2S1 - Wiring diagram [EC-907](#), [EC-915](#), [EC-925](#)
HO2S1H - Wiring diagram [EC-851](#)
HO2S2 - Wiring diagram ... [EC-237](#), [EC-441](#), [EC-449](#), [EC-931](#), [EC-938](#), [EC-1146](#), [EC-1154](#)
HO2S2H - Wiring diagram [EC-182](#), [EC-857](#)
Hood [EI-13](#)

Horn [WW-9](#)
HORN - Wiring diagram [WW-9](#)
How to erase DTC for OBD system [EC-64](#), [EC-712](#)

I

IATS - Wiring diagram [EC-205](#), [EC-880](#)
Identification plate [GI-49](#)
Idle air volume learning [EC-92](#), [EC-750](#)
Idle mixture ratio [EC-80](#), [EC-728](#), [EC-738](#)
Idle speed ... [EC-74](#), [EC-80](#), [EC-722](#), [EC-728](#), [EC-738](#)
Idle speed control (ISC) [EC-373](#), [EC-375](#), [EC-1087](#), [EC-1089](#)
Ignition coil [EM-118](#), [EC-602](#), [EC-1314](#)
Ignition control system [EC-602](#), [EC-1314](#)
Ignition timing [EC-74](#), [EC-80](#), [EC-722](#), [EC-728](#), [EC-738](#)
IGNSYS - Wiring diagram [EC-603](#), [EC-1315](#)
ILL - Wiring diagram [LT-34](#)
Illumination [LT-33](#)
INJECT - Wiring diagram [EC-616](#), [EC-1337](#)
Injector [EC-615](#), [EC-1336](#)
Input shaft (FF M/T) [MT-19](#), [MT-38](#), [MT-82](#)
Instrument panel [IP-10](#)
INT/L - Wiring diagram [LT-38](#)
Intake air temperature sensor [EC-204](#), [EC-223](#), [EC-878](#), [EC-900](#)
Intake door control linkage adjustment [MTC-37](#)
Intake door motor [MTC-34](#)
Intake manifold [EM-15](#), [EM-108](#)
Intake sensor [MTC-62](#)
Intake valve timing control ... [EC-176](#), [EC-394](#), [EC-845](#)
Intake valve timing control solenoid valve [EC-394](#), [EC-1108](#)
Interior [EI-28](#)
Interior lamp [LT-36](#)
IVC - Wiring diagram [EC-395](#), [EC-1109](#)
IVIS (Infiniti vehicle immobilizer system) precautions ... [GI-5](#)

J

Junction box (J/B) [PG-53](#)

K

Keyless entry system - See Multi-remote control system [BL-34](#)
Knock sensor (KS) [EC-279](#), [EC-987](#)
KS - Wiring diagram [EC-280](#), [EC-988](#)

L

Length (Dimensions) [GI-50](#)
License lamp [LT-19](#)
Lifting points [GI-40](#)
Line pressure solenoid valve [AT-158](#), [AT-543](#)
Line pressure test (A/T) [AT-67](#), [AT-453](#)
Liquid gasket application [EM-6](#), [EM-95](#)
LOAD - Wiring diagram [EC-632](#)

ALPHABETICAL INDEX

Location of electrical units [PG-43](#)
Low and reverse brake [AT-332](#)
Lubricant (R134a) A/C [MTC-16](#)
Lubrication circuit (engine) [LU-4](#)
Lubrication oil A/C [MTC-16](#)
Lubrication-locks, hinges and hood latches [MA-37](#)
Luggage room lamp [LT-36](#)

M

M/T major overhaul [MT-18](#), [MT-85](#)
M/T oil replacement/M/T oil replacement [MT-73](#)
M/T removal and installation [MT-15](#)
MAFS - Wiring diagram [EC-189](#), [EC-198](#), [EC-864](#), [EC-872](#)
Magnet clutch [MTC-65](#)
MAIN - Wiring diagram [EC-165](#), [EC-835](#)
Main drive gear (M/T) [MT-19](#)
Mainshaft (M/T) [MT-19](#), [MT-45](#), [MT-82](#)
Maintenance [MA-5](#)
Maintenance (engine)QG18DE [MA-16](#)
Maintenance (engine)QR25DE [MA-23](#)
Malfunction indicator lamp (MIL) [EC-65](#), [EC-714](#)
Manual air conditioner - Wiring diagram [MTC-27](#)
Manual transaxle number [GI-50](#)
Manual transmission oil replacement [MA-30](#)
Mass air flow sensor (MAFS) [EC-186](#), [EC-196](#), [EC-861](#), [EC-870](#)
Master cylinder (clutch) [CL-9](#), [CL-26](#)
Meter [DI-4](#)
METER - Wiring diagram [DI-13](#), [DI-62](#)
MIL data link connectors circuit [EC-655](#)
MIRROR - Wiring diagram [GW-14](#)
Mirror defogger [GW-15](#)
Mirror, door [GW-14](#), [GW-16](#)
Mirror, out side [GW-16](#)
Misfire [EC-272](#), [EC-980](#)
Model variation [GI-47](#)
Molding - See Exterior [EI-22](#)
MULTI - Wiring diagram [BL-38](#)
Multiport fuel injection (MFI) system [EC-28](#), [EC-673](#)
Multiport fuel injection precautions [GI-3](#), [GI-6](#)
Multi-remote control system [BL-34](#)

N

NATS (Nissan anti-theft system) [BL-96](#)
NVH troubleshooting (BR) [BR-5](#)
NVH troubleshooting (EM) [EM-13](#), [EM-101](#)
NVH troubleshooting (FA) [FAX-4](#)
NVH troubleshooting (RA) [RAX-4](#)
NVH troubleshooting (WT) [WT-2](#)
NVIS (Nissan vehicle immobilizer system) [BL-96](#)
NVIS (Nissan vehicle immobilizer system) precautions [GI-3](#), [GI-5](#)

O

Oil change (capacity) [MA-13](#)

Oil pan (engine) [EM-18](#), [EM-115](#)
Oil pump (A/T) [AT-292](#)
Oil pump (engine) [LU-8](#), [LU-19](#)
Oil pump regulator valve (engine) [LU-10](#)
Oil seal replacement (engine) [EM-52](#), [EM-144](#)
On board diagnostic system [EC-51](#), [EC-697](#)
Operating cylinder (clutch) [CL-11](#), [CL-28](#)
ORVR (On-board Refueling Vapor Recovery) . [EC-43](#), [EC-688](#)
Overdrive control switch [AT-249](#), [AT-251](#), [AT-627](#)
Overheat [EC-455](#), [EC-1161](#)
Overrun clutch [AT-324](#)
Overrun clutch solenoid valve [AT-564](#)

P

Park/Neutral position switch [EC-563](#), [EC-1269](#)
Park/neutral position switch (A/T) [AT-115](#), [AT-487](#)
Park/neutral position switch (M/T) [MT-12](#)
Park/neutral position switch (M/T)Park/neutral position switch (M/T) [MT-75](#)
Parking brake control [PB-2](#)
Parking drum brake [BR-38](#)
Parking lamp [LT-19](#)
PCV (positive crankcase ventilation) .. [EC-49](#), [EC-694](#)
Periodic maintenance [MA-7](#)
PGC/V - Wiring diagram .. [EC-320](#), [EC-529](#), [EC-1033](#), [EC-1236](#)
PHASE - Wiring diagram [EC-293](#), [EC-1001](#)
Piston assembly [EM-79](#)
Piston pin inspection [EM-71](#)
Piston ring inspection [EM-72](#)
Piston to bore clearance [EM-73](#), [EM-184](#)
PNP/SW - Wiring diagram [EC-565](#), [EC-1271](#)
POS - Wiring diagram [EC-286](#), [EC-994](#)
POWER - Wiring diagram [PG-5](#)
Power door lock [BL-11](#)
Power door mirror [GW-14](#)
Power steering fluid level [PS-8](#), [MA-35](#)
Power steering gear [PS-15](#)
Power steering hydraulic pressure [PS-10](#)
Power steering oil pump [PS-21](#)
Power steering pressure (PSP) sensor ... [EC-377](#), [EC-1091](#)
Power steering system bleeding [PS-8](#)
Power supply routing [PG-3](#)
Power transistor [EC-1314](#)
Power window [GW-7](#)
Power window main switch [GW-7](#)
PRE/SE - Wiring diagram [EC-337](#), [EC-343](#), [EC-1050](#), [EC-1056](#)
Precautions (General) [GI-3](#)
Pressure plate - See Clutch cover [CL-17](#), [CL-33](#)
Pressure test (A/T) [AT-67](#), [AT-453](#)
PS/SEN - Wiring diagram [EC-378](#), [EC-1092](#)

R

Radiator [CO-14](#)

ALPHABETICAL INDEX

Throttle position switch [AT-249](#), [AT-627](#)
Throwout bearing - See Clutch release bearing [CL-14](#),
[CL-31](#)
Tie-rod [PS-19](#)
Tie-rod ball joints [PS-19](#)
Tightening torque of standard bolts [GI-45](#)
Time control system [BCS-10](#)
Timing chain [EM-42](#), [EM-136](#)
Tire rotation [MA-32](#)
Tire size [GI-51](#)
TLID - Wiring diagram [BL-33](#)
Top tether strap child restraint [SB-10](#)
Torque converter installation [AT-265](#), [AT-645](#), [AT-740](#)
Torque convertor clutch solenoid valve [AT-530](#)
Tow truck towing [GI-43](#)
Towing point [GI-44](#)
TPS1 - Wiring diagram [EC-267](#), [EC-975](#)
TPS2 - Wiring diagram [EC-215](#), [EC-892](#)
TPS3 - Wiring diagram [EC-589](#), [EC-1301](#)
Transmission case (M/T) [MT-18](#), [MT-81](#)
Tread-FR&RR (Dimensions) [GI-50](#)
Trim [EI-28](#)
Trouble diagnoses [GI-11](#), [GI-24](#)
Trunk lid [EI-18](#)
Trunk lid finisher [EI-33](#)
Trunk lid opener - See Trunk lid [EI-18](#)
Trunk lid opener, electric [BL-33](#)
Trunk lid trim [EI-33](#)
Trunk room lamp [LT-36](#)
Trunk room trim [EI-33](#)
TURN - Wiring diagram [LT-30](#)
Turn signal lamp [LT-27](#)
Two trip detection logic [EC-51](#), [EC-697](#)

U

Under body [BL-120](#)

V

Vacuum hose (brake system) [BR-18](#)
Vacuum hose drawing (Engine control) [EC-779](#)
Valve clearance [EM-38](#), [EM-134](#)
Valve guide [EM-61](#), [EM-154](#), [EM-155](#)
Valve seat [EM-63](#), [EM-156](#)
Valve spring [EM-64](#), [EM-157](#)
Variable induction air control system (VIAS) [EC-1273](#),
[EC-1327](#)
Vehicle identification number [GI-48](#)
Vehicle recovery (freeing a stuck vehicle) [GI-44](#)
Vehicle security (theft warning) system [BL-65](#)
Vehicle speed sensor (VSS) [EC-371](#), [EC-1085](#)
VEHSEC - Wiring diagram [BL-72](#)
Vent mode switch [MTC-20](#)
VENT/V - Wiring diagram [EC-327](#), [EC-537](#), [EC-1040](#),
[EC-1244](#)
VIAS - Wiring diagram [EC-1329](#)
VIAS/V - Wiring diagram [EC-1274](#)
VIN registration [EC-91](#), [EC-749](#)

Viscosity number (SAE) [MA-14](#)

W

WARN - Wiring diagram [DI-29](#)
Warning chime [DI-41](#)
Warning lamps [DI-27](#)
Washer, front [WW-3](#)
Water pump [CO-10](#)
Water temperature gauge [DI-4](#)
Weatherstrip - See Exterior [EI-22](#)
Wheel alignment (front) [FSU-6](#)
Wheel alignment (rear) [RSU-6](#)
Wheel balance [MA-32](#)
Wheel bearing (front axle) [FAX-9](#)
Wheel bearing (front) [FAX-5](#)
Wheel bearing (rear) [RAX-5](#)
Wheel hub (front) [FAX-6](#), [FAX-9](#)
Wheel hub (rear) [RAX-6](#)
Wheel sensors (ABS) [BRC-44](#)
Wheel size [GI-51](#)
Wheelbase (Dimensions) [GI-50](#)
Width (Dimensions) [GI-50](#)
WINDOW - Wiring diagram [GW-9](#)
Window, back door [GW-12](#)
Window, door [GW-6](#), [GW-12](#)
Window, rear [GW-3](#)
Windshield [GW-3](#)
Windshield washer - See Front washer [WW-3](#)
Windshield wiper - See Front wiper [WW-3](#)
WIPER - Wiring diagram [WW-5](#)
Wiper and washer [WW-3](#)
Wiper, front [WW-3](#)
Wiring Diagram (Cell code) list [PG-40](#)
Wiring diagrams [GI-8](#), [GI-15](#)
Withdrawal lever (clutch) [CL-14](#), [CL-31](#)
Wrist pin - See Piston pin inspection [EM-71](#)