



INSTRUCTIONS

- 1) TO SECURE UNIT TO THE MOUNTING BRACKET, REMOVE 4 FEET FROM THE UNIT COMBINE IT WITH THE BRACKET USING 4 PROVIDED SCREWS.
- 2) SECURE UNIT UNDER THE TABLE USING 7 METAL SCREWS.
- 3) PLUG NECESSARY CABLES INTO PLUG INS
- 4) USE 4.5" CABLE TIE, TO SECURE THE CABLE TO THE MOUNTING SHELF. INSERT THROUGH THE HOLES ON THE BOTTOM OF THE UNIT.
- 5) USE CABLE CLAMPS TO SECURE CABLE TO THE DESK TOP WITH METAL SCREWS.
- 6) USE TWO BLANK SNAP IN MODULES, TO REPLACE OTHER SNAP INS.
- 7) PLACE EXTRA ACCESSORIES BACK INTO THE POLY BAG. SEAL THE BAG TO PROTECT PRODUCT.

This drawing, print, or document and subject matter disclosed herein are proprietary items to which ALTINEX, INC. retain the exclusive rights of dissemination, reproduction, manufacture, and/or sales. This drawing, print, or document is submitted in confidence by recipient alone unless permission for further disclosure is expressly granted in writing.	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES TOLERANCES	CUSTOMER		
	DECIMALS .00X ± .003 .100X ± .010	ANGULAR ±	DRAWN ALAEV 9-98 CHECK GULKAROV 12-98	ALTINEX 302 APOLLO ST. BREA, CA 92821 PHONE (714) 990-0877 FAX (714) 990-0740
	DO NOT SCALE DRAWING			TM1274 MANUAL ASSEMBLY INSTRUCTIONS
	MATERIAL SEE SPEC	DESIGN	SIZE D	NUMBER 400-0069-001
FINISH SEE SPEC	SCALE NONE	SHEET 1 OF 1		