

---

---

## SETTING UP THE SOFT DIP ON THE MULTI VIDEO SYSTEM

---

---

1. TURN POWER ON.
2. PUSH THE TEST BUTTON INSIDE THE CABINET.
3. THE FOLLOWING SCREEN WILL APPEAR.

**MOVE LEFT JOYSTICK UP/DOWN TO MOVE THE POINTER TO "SETTING UP THE SOFT DIP". PRESS "A" BUTTON TO SET.**

HARDWARE TEST  
SETTING UP THE HARD DIP  
SETTING UP THE SOFT DIP  
BOOKKEEPING  
SETTING UP THE CODE NUMBER  
SETTING UP THE CALENDAR  
EXIT

THE FOLLOWING SCREEN WILL BE DISPLAYED:

CABINET SET UP  
SLOT 1 (GAME TITLE)  
SLOT 2 (GAME TITLE)  
SLOT 3 (GAME TITLE)  
SLOT 4 (GAME TITLE)  
SLOT 5 (GAME TITLE)  
SLOT 6 (GAME TITLE)

4. SELECT THE GAME TITLE YOU WANT AND PRESS "A" BUTTON TO VIEW THE SOFT DIP SETTING OF EACH INDIVIDUAL GAME.

## ■ NEO TURF MASTERS SOFT DIP SETTINGS ■

Page 1 Initial Settings Screen

NEO TURF MASTERS	
▶ TIME	00m 30 s
HOLE(1st)	3
HOLE(continue)	3
MATCH PLAY HOLE	WIN + / LOS -
CONTINUE	ON
DIFFICULTY	LEVEL 4
▼NEXT PAGE	

Page 2 Initial Settings

NEO TURF MASTERS	
▶ PLAY MANUAL	ON
DEMO SOUND	WITH
CREDIT/LEVEL	ON/ON
LANGUAGE	ENGLISH

- How to operate: ① Use the Joystick to move cursor up or down to items you want to change.  
 ② Press A Button to proceed to new settings and set selections.  
 (Press B Button to return to previous settings.)

[TIME] Set the time allowed per shot. Factory Setting: 30 seconds (1 second - 29 minutes 59 seconds possible.)
[HOLE(1st)] Set the number of holes for the first 1 credit. Factory Setting: 3 Holes/credit (1 hole/credit - 99 holes/credit possible.)
[HOLE(continue)] Select the number of holes per continue. Factory Setting: 3 Holes/continue (1 hole/continue - 15 holes/continue possible.)
[HOLE PENALTY] Select penalty per hole. Bogey → Per → Give Up → No Penalty
[MATCH PLAY HOLE] Set the 1 hole gain or loss for winning or losing in 2 player match play. WIN +/LOS - → WIN 0/LOS 0 → WIN 0/LOS - → WIN +/LOS 0
[CONTINUE] Set the Continue Play option. ON → OFF
[DIFFICULTY] Set the game's difficulty level. Factory Setting: 4 (1-8 possible.)
[PLAY MANUAL] Turn on or off the play instructions. ON → OFF
[DEMO SOUND] Set sound during demonstration screens. WITH → WITHOUT
[CREDIT / LEVEL DISPLAY] Set credit and level display. ON/ON → ON/OFF → OFF/ON → OFF/OFF
[LANGUAGE] Change language. (Only for Europe or Asia.) ENGLISH → SPANISH → PORTUGUESE