


U5000 MONITOR



NOTE:

HORIZ. FREQUENCY IS SWITCHABLE BETWEEN 15KHZ AND 25KHZ. USUALLY USED IN THE 25KHZ MODE.

