

NISSAN ALTIMA

MODEL U13 SERIES

QUICK REFERENCE INDEX

GENERAL INFORMATION _____	GI
MAINTENANCE _____	MA
ENGINE MECHANICAL _____	EM
ENGINE LUBRICATION & _____ COOLING SYSTEMS	LC
ENGINE CONTROL SYSTEM _____	EC
ACCELERATOR CONTROL, FUEL & _____ EXHAUST SYSTEMS	FE
CLUTCH _____	CL
MANUAL TRANSAXLE _____	MT
AUTOMATIC TRANSAXLE _____	AT
FRONT AXLE & FRONT SUSPENSION _____	FA
REAR AXLE & REAR SUSPENSION _____	RA
BRAKE SYSTEM _____	BR
STEERING SYSTEM _____	ST
RESTRAINT SYSTEM _____	RS
BODY & TRIM _____	BT
HEATER & AIR CONDITIONER _____	HA
ELECTRICAL SYSTEM _____	EL
ALPHABETICAL INDEX _____	IDX

© 1996 NISSAN NORTH AMERICA, INC. Printed in U.S.A.

All rights reserved. No part of this Service Manual may be reproduced, stored in a retrieval system, or transmitted in any form, or by any means electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Nissan North America, Inc., Torrance, California.

FOREWORD

This manual contains maintenance and repair procedures for the 1997 Nissan ALTIMA.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.

Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.



NISSAN NORTH AMERICA, INC.

Technical Service Information Department
Torrance, California



PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

Your comments are important to NISSAN and will help us to improve our Service Manuals. Use this form to report any issues or comments you may have regarding our Service Manuals. Please photocopy this form and type or print your comments below. Mail or fax to:

Nissan North America, Inc.
Technical Service Information
39001 Sunrise Drive, P.O. Box 9200
Farmington Hills, MI USA 48331
FAX: (810) 488-3910

SERVICE MANUAL: Model: _____ **Year:** _____

PUBLICATION NO. (Please photocopy back cover): _____

VEHICLE INFORMATION VIN: _____ **Production Date:** _____

Please describe any issues or problems in detail:

Page number(s) _____ *Note: Please include a copy of each page, marked with your comments.*

Are the trouble diagnosis procedures logical and easy to use? (circle your answer) YES NO

If no, what page number(s)? _____ *Note: Please include a copy of each page, marked with your comments.*

Please describe the issue or problem in detail:

Is the organization of the manual clear and easy to follow? (circle your answer) YES NO

Please comment:

What information should be included in NISSAN Service Manuals to better support you in servicing or repairing customer vehicles?

DATE: _____ YOUR NAME: _____ POSITION: _____

DEALER: _____ DEALER NO.: _____ ADDRESS: _____

CITY: _____ STATE/PROV./COUNTRY: _____ ZIP/POSTAL CODE: _____

QUICK REFERENCE CHART: ALTIMA 1997

ENGINE TUNE-UP DATA

Engine model	KA24DE		
Firing order	1-3-4-2		
Idle speed	rpm		
M/T		700 ± 50	
A/T (in "N" position)		700 ± 50	
Ignition timing (degree B.T.D.C. at idle speed)	20° ± 2°		
CO% at idle	Idle mixture screw is preset and sealed at factory		
Valve clearance (Hot)	mm (in)		
Intake		0.31 - 0.39 (0.012 - 0.015)	
Exhaust		0.33 - 0.41 (0.013 - 0.016)	
Spark plug			
Type	BKR5E-11		
Gap	mm (in)	1.0 - 1.1 (0.039 - 0.043)	
Drive belt deflection (Cold)	mm (in)	Used belt	
		Limit	Deflection after adjustment
Generator & power steering oil pump		8 (0.31)	6 - 7 (0.24 - 0.28)
Air conditioner compressor		10 (0.39)	7 - 8 (0.28 - 0.31)
Applied pressed force	N (kg, lb)	98 (10, 22)	
Radiator cap relief pressure	kPa (kg/cm ² , psi)	78 - 98 (0.8 - 1.0, 11 - 14)	
Cooling system leakage testing pressure	kPa (kg/cm ² , psi)	167 (1.6, 23)	
Compression pressure	Standard	1,226 (12.5, 178)/300	
	Minimum	1,030 (10.5, 149)/300	
Tightening torque		N·m	kg·m
Spark plug		20 - 29	2.0 - 3.0
Oil pan drain plug		29 - 39	3.0 - 4.0
			ft·lb
			14 - 22
			22 - 29

REAR WHEEL ALIGNMENT (Unladen*)

Camber	Degree minute (Decimal degree)	Minimum	-2°00' (-2.00°)
		Nominal	-1°16' (-1.25°)
		Maximum	-0°30' (-0.50°)
Total toe-in Distance (A - B)	mm (in)	Minimum	1 (0.04)
		Nominal	2 (0.08)
		Maximum	3 (0.12)
Angle (left plus right)	Degree minute (Decimal degree)	Minimum	6' (0.10')
		Nominal	12' (0.20')
		Maximum	18' (0.30')

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.

BRAKE

Unit: mm (in)

Disc brake	
Pad minimum thickness	2.0 (0.079)*1, 1.5 (0.059)*2
Rotor repair limit Minimum thickness	20.0 (0.787)*1, 8.0 (0.315)*2
Drum brake	
Lining minimum thickness	1.5 (0.059)
Drum repair limit Maximum inner diameter	230.0 (9.06)
Pedal free height	M/T: 169 - 179 (6.65 - 7.05) A/T: 177 - 187 (6.97 - 7.36)
Pedal depressed height*3	90 (3.54)
Parking brake	
Number of notches*4	7 - 8

*1 Front disc brake
*2 Rear disc brake
*3 Under force of 490N (50kg, 110lb) with engine running
*4 At pulling force: 196N (20kg, 44lb)

FRONT WHEEL ALIGNMENT (Unladen*)

Camber	Degree minute (Decimal degree)	Minimum	-0°50' (-0.83°)
		Nominal	-0°05' (-0.08°)
		Maximum	0°40' (0.67°)
		Left and right difference	45' (0.75')
Caster	Degree minute (Decimal degree)	Minimum	1°55' (1.92°)
		Nominal	2°40' (2.67°)
		Maximum	3°25' (3.42°)
		Left and right difference	45' (0.75')
Kingpin inclination	Degree minute (Decimal degree)	Minimum	13°20' (13.33°)
		Nominal	14°05' (14.08°)
		Maximum	14°50' (14.83°)
Total toe-in Distance (A - B)	mm (in)	Minimum	0 (0)
		Nominal	1 (0.04)
		Maximum	2 (0.08)
Angle (left plus right)	Degree minute (Decimal degree)	Minimum	0' (0.00')
		Nominal	6' (0.10')
		Maximum	12' (0.20')
Wheel turning angle	Degree minute (Decimal degree)	Minimum	31°30' (31.50°)
		Nominal	34°30' (34.50°)
		Maximum	35°30' (35.50°)
Outside	Degree minute (Decimal degree)	Nominal	28°36' (28.60°)

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.

REFILL CAPACITIES

	Unit	Liter	US measure
Fuel tank		60	15-7/8 gal
Coolant	With reservoir tank	7.8	8-1/4 qt
	With oil filter	3.9	4-1/8 qt
Engine	Without oil filter	3.5	3-3/4 qt
	M/T	R55F50A	4.5 - 4.8
Transaxle	R55F50V	4.3 - 4.5	9-1/2 - 10-1/8 pt
	A/T	9.4	10 qt
Power steering system		0.9	1 qt
Air conditioning system	Lubricant	0.2	6.8 fl oz
	Refrigerant*	0.7 - 0.8 kg	1.54 - 1.76 lb

* R-134a

CLUTCH PEDAL

Unit: mm (in)

Pedal height	168 - 178 (6.61 - 7.01)
Pedal free play	1 - 3 (0.04 - 0.12)

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

The following is the information specified in Mode 6 of SAE J1979.

The test value is a parameter used to determine whether a system/circuit diagnostic test is “OK” or “NG” while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items.

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

: Applicable * : Not applicable

SRT item	Self-diagnostic test item	DTC	Test value (GST display)		Test limit	Application	Unit
			TID	CID			
CATALYST	Three way catalyst function	P0420	01H	01H	Max.	X	-
		P0420*1	02H	81H	Min.	X	-
EVAP SYSTEM	EVAP control system (Small leak)	P0440	05H	03H	Max.	X	-
	EVAP control system purge flow monitoring	P1447	06H	83H	Min.	X	mV
H02S	Heated oxygen sensor 1	P0130	09H	04H	Max.	X	ms
		P0130	0AH	84H	Min.	X	mV
		P0130	0BH	04H	Max.	X	mV
		P0130	0CH	04H	Max.	X	mV
		P0130	0DH	04H	Max.	X	s
	Heated oxygen sensor 2	P0136	19H	86H	Min.	X	mV/500ms
		P0136	1AH	86H	Min.	X	mV
		P0136	1BH	06H	Max.	X	mV
		P0136	1CH	06H	Max.	X	mV
		P0136	1DH	06H	Max.	X	mV
H02S HTR	Heated oxygen sensor 1 heater	P0135	29H	08H	Max.	X	mV
		P0135	2AH	88H	Min.	X	mV
	Heated oxygen sensor 2 heater	P0141	2DH	0AH	Max.	X	mV
		P0141	2EH	8AH	Min.	X	mV
EGR SYSTEM	EGR function	P0400	31H	8CH	Min.	X	°C
		P0400	32H	8CH	Min.	X	°C
		P0400	33H	8CH	Min.	X	°C
		P0400	34H	8CH	Min.	X	°C
		P0400	35H	0CH	Max.	X	°C
	EGRC-BPT valve function	P0402	36H	0CH	Max.	X	-
		P0402	37H	8CH	Min.	X	-

*1 : Models B15 GA16DE engine 1997MY only.