| Edition: Jar | nuary | 1999 |
|---------------------|--------|-----------|
| Revision: Ja | anuary | 1999 |
| Publication | No. SI | M9E-1R50U |

QUICK REFERENCE INDEX GENERAL INFORMATION — MAINTENANCE —— ENGINE MECHANICAL — ENGINE LUBRICATION & _____COOLING SYSTEMS **ENGINE CONTROL SYSTEM** — ACCELERATOR CONTROL, FUEL & _____EXHAUST SYSTEMS **CLUTCH-**MANUAL TRANSMISSION — **AUTOMATIC TRANSMISSION -**TRANSFER -PROPELLER SHAFT & DIFFERENTIAL CARRIER FRONT & REAR AXLE — FRONT & REAR SUSPENSION -**BRAKE SYSTEM -**STEERING SYSTEM —— RESTRAINT SYSTEM ——

BODY & TRIM

HEATER & AIR CONDITIONER —

ELECTRICAL SYSTEM ———

ALPHABETICAL INDEX ———

STARTING & CHARGING SYSTEM -

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

NISSAN PATHFINDER

MODEL R50 SERIES

This Service Manual is applicable for 1999 model years vehicles beginning with serial No. 350001~. The serial No. is shown on the Vehicle Identification Number plate.

© 1998 NISSAN MOTOR CO., LTD.

All rights reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Nissan Motor Company Ltd., Tokyo, Japan.

FOREWORD

This manual contains maintenance and repair procedures for the 1999 Nissan PATHFINDER.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither parsonal safety nor the vehicle's safety will be jeopardized by the service method selected.



Tokyo, Japan



NISSAN PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

Your comments are important to NISSAN and will help us to improve our Service Manuals.

Use this form to report any issues or comments you may have regarding our Service Manuals.

Please print this form and type or write your comments below. Mail or fax to:

Nissan North America, Inc. Technical Service Information 39001 Sunrise Drive, P.O. Box 9200 Farmington Hills, MI USA 48331

FAX: (248) 488-3910

| SERVICE MANUAL: | Model: | | Year: | |
|---------------------------------------|---------------------------|------------------------|----------------------|--------------------------------------|
| PUBLICATION NO. | (Please photocopy b | oack cover): | | |
| VEHICLE INFORMA | TION VIN: | | Production Date: | |
| • | issues or problems in Not | | by of each page, man | ked with your comments. |
| | | | | |
| • | • | ogical and easy to use | • | rer) YES NO rked with your comments. |
| | ` ' | etail: | | • |
| _ | | and easy to follow? (o | | YES NO |
| What information s repairing customer | | n NISSAN Service Mai | nuals to better supp | port you in servicing or |
| DATE: | YOUR NAME: | | POSI | TION: |
| DEALER: | DEALE | R NO.: | _ ADDRESS: | |
| CITY: | STATE/P | PROV./COUNTRY: | ZIP/POS | STAL CODE: |

NOTES

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

The following is the information specified in Mode 6 of SAE J1979.

The test value is a parameter used to determine whether a system/circuit diagnostic test is "OK" or "NG" while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items.

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

| SRT item Self | Self-diagnostic test item | DTC | Test value (GST display) | | Test limit | Conversion |
|--|---|-------|-----------------------------|-----|------------|----------------------|
| | · · | | TID | CID | | |
| CATALYST Three way catalyst function (Bank 1) Three way catalyst function (Bank 2) | | P0420 | 01H | 01H | Max. | 1/128 |
| | | P0430 | 03H | 02H | Max. | 1/128 |
| EVAP SYSTEM EVAP | EVAD (O -) | P0440 | 05H | 03H | Max. | 1/128mm ² |
| | EVAP control system (Small leak) | P1440 | 05H | 03H | Max. | 1/128mm ² |
| | EVAP control system purge flow monitoring | P1447 | 06H | 83H | Min. | 20mV |
| | | P0133 | 09H | 04H | Max. | 16ms |
| | | P0131 | 0AH | 84H | Min. | 10mV |
| | Heated oxygen sensor 1 (Bank 1) | P0130 | 0BH | 04H | Max. | 10mV |
| | | P0132 | 0CH | 04H | Max. | 10mV |
| | | P0134 | 0DH | 04H | Max. | 1s |
| | | P0153 | 11H | 05H | Max. | 16ms |
| | | P0151 | 12H | 85H | Min. | 10mV |
| | Heated oxygen sensor 1 (Bank 2) | P0150 | 13H | 05H | Max. | 10mV |
| HO2S | | P0152 | 14H | 05H | Max. | 10mV |
| HU25 | | P0154 | 15H | 05H | Max. | 1s |
| | | P0139 | 19H | 86H | Min. | 10mV/500ms |
| | Heated arrange ages 2 (Doub 4) | P0137 | 1AH | 86H | Min. | 10mV |
| H | Heated oxygen sensor 2 (Bank 1) | P0140 | 1BH | 06H | Max. | 10mV |
| | | P0138 | 1CH | 06H | Max. | 10mV |
| | | P0159 | 21H | 87H | Min. | 10mV/500ms |
| Heate | Liceted average concer 2 (Donk 2) | P0157 | 22H | 87H | Min. | 10mV |
| | Heated oxygen sensor 2 (Bank 2) | P0160 | 23H | 07H | Max. | 10mV |
| | | P0158 | 24H | 07H | Max. | 10mV |
| Heated oxygen sensor Ho2S HTR Heated oxygen sensor | Heated evergen concer 1 heater (Pank 1) | P0135 | 29H | 08H | Max. | 20mV |
| | Heated oxygen sensor 1 heater (Bank 1) | P0135 | 2AH | 88H | Min. | 20mV |
| | Heated evergen sensor 1 heater (Bank 2) | P0155 | 2BH | 09H | Max. | 20mV |
| | Heated oxygen sensor 1 heater (Bank 2) | P0155 | 2CH | 89H | Min. | 20mV |
| | Heated evergen concer 2 heater (Pank 1) | P0141 | 2DH | 0AH | Max. | 20mV |
| | Heated oxygen sensor 2 heater (Bank 1) | P0141 | 2EH | 8AH | Min. | 20mV |
| | Liested averses senses 2 hoster (Denk 2) | P0161 | 2FH | 0BH | Max. | 20mV |
| | Heated oxygen sensor 2 heater (Bank 2) | P0161 | 30H | 8BH | Min. | 20mV |
| EGR SYSTEM EGR | | P0400 | 31H | 8CH | Min. | 1°C |
| | | P0400 | 32H | 8CH | Min. | 1°C |
| | EGR function | P0400 | 33H | 8CH | Min. | 1°C |
| | | P0400 | 34H | 8CH | Min. | 1°C |
| | | P1402 | 35H | 0CH | Max. | 1°C |
| | FORC PRT value function | P0402 | 36H | 0CH | Max. | 1count |
| | EGRC-BPT valve function | P0402 | 37H | 8CH | Min. | 1count |