



Pacific 155 Shotshell Reloader

PARTS LISTING

A ...Powder Bushing
B ...Shot Bushing
190001...Base Casting
190002...Die Head Casting
190003...Measure Casting
190004...Charge Bar
190033...Deprime Punch Guide, 12 Ga.
190034...Deprime Punch Guide, 16 Ga.
190035...Deprime Punch Guide, 20 Ga.
190036...Deprime Punch Guide, 28 Ga.
190037...Deprime Punch Guide, 410 Ga.
380047...Primer Seating Spring
380048...Wad Pressure Spring
390009...Charge Bar Stop Pin
390010...Link Spacer
390011...Die Head Link
390012...Handle-Link Pin
390013...Handle
390014...Lower Clevis Link
390015...Upper Clevis Link
390016...Return Spring
390017...Return Spring Standoff Bolt
390018...Main Guide Post
390019...Size Die Body
390020...Die Body Lock Nut
050038...Primer Seater Assembly
380047...(spring sold separately)
390024...Wad Pressure Pad
390025...Wad Guide Bracket
390026...Wad Pressure Indicator
390029...Size Die Ring Cap, 12 Ga.
390030...Size Die Ring Cap, 16 Ga.
390031...Size Die Ring Cap, 20 Ga.
390032...Size Die Ring Cap, 28 Ga.
390033...Size Die Ring Cap, 410 Ga.
390038...Primer Seater Punch, 12 Ga.
390039...Primer Seater Punch, 16 Ga.
390040...Primer Seater Punch, 20 Ga.
390041...Primer Seater Punch, 28 Ga.
390042...Primer Seater Punch, 410 Ga.
390043...Wad Guide Cap, 12 Ga.
390044...Wad Guide Cap, 16 Ga.
390045...Wad Guide Cap, 20 Ga.
390046...Wad Guide, Cap, 28 Ga.
390047...Wad Guide Cap, 410 Ga.
390048...Wad Guide Body, 12 Ga.
390049...Wad Guide Body, 16 Ga.
390050...Wad Guide Body, 20 Ga.
390051...Wad Guide Body, 28 Ga.
390052...Wad Guide Body, 410 Ga.
390053...Drop Tube, 12 Ga.
390054...Drop Tube, 16 Ga.
390055...Drop Tube, 20 Ga.
390056...Drop Tube, 410 Ga.
390057...Shell Holder, 12 Ga.
390058...Shell Holder, 16 Ga.
390059...Shell Holder, 20 Ga.
390060...Shell Holder, 28 Ga.
390061...Shell Holder, 410 Ga.
390081...Wad Pressure Pad Clip
390082...Lower Guide Post Roll Pin
390083...Upper Guide Post Roll Pin
390085...Handle-Link Pin Clip

390087...Crimp Starter & Seater Punch Lock Nut
390088...Die Head Link Attaching Bolt
390089...Clevis Pivot Bolt Nut
390090...Handle & Post Pivot Bolt
390091...Handle & Post Pivot Bolt Nut
390092... $\frac{1}{4}$ x20x $\frac{5}{8}$ " Bolt
390093...Clevis Attaching Bolt
390094...Measure Casting Plate Screw
390095...10x32x $\frac{3}{8}$ " Screw
390096...Shell Holder Nut
390097... $\frac{3}{8}$ x 16 Lock Nut
390169...Measure Casting Plate
390178... $\frac{1}{4}$ "-20 Nut
390183...Measure Attaching Bolt, 28 & 410 Ga.
390188...Measure Attaching Bolt, 12, 16 & 20 Ga.
390198...Crimp Die Spring
390202...Crimp Die Bushing, 12, 16, 20 Ga.
390203...Crimp Die Bushing, 28 & 410 Ga.
390204...Crimp Plunger, 12 Ga.
390205...Crimp Plunger, 16 Ga.
390206...Crimp Plunger, 20 Ga.
390207...Crimp Plunger, 28 Ga.
390208...Crimp Plunger, 410 Ga.
390211...Drop Tube, 28 Ga.
390212...Crimp Die Body, 12 Ga. 2 $\frac{3}{4}$ "
390213...Crimp Die Body, 12 Ga. 3"
390214...Crimp Die Body, 16 Ga. 2 $\frac{3}{4}$ "
390215...Crimp Die Body, 20 Ga. 2 $\frac{3}{4}$ "
390216...Crimp Die Body, 20 Ga. 3"
390217...Crimp Die Body, 28 Ga.
390218...Crimp Die Body, 410 Ga. 2 $\frac{1}{2}$ "
390219...Crimp Die Body, 410 Ga. 3"
392011...10x32 Nut
392053...Eject Bolt
392101...Crimp Starter Rod
392102...Crimp Starter Bushing
480001...Measure Seal
480005...Post Cap
480006...Primer Catcher
480007...Spring Fingers, 12 Ga.
480008...Spring Fingers, 16 Ga.
480009...Spring Fingers, 20 Ga.
480010...Spring Fingers, 28 Ga.
480011...Spring Fingers, 410 Ga.
480086...Handle Grip
490002...Powder-Shot Hopper
490003...Hopper Cap
490311...Crimp Starter, 12 Ga. 8 Pt.
490312...Crimp Starter, 12 Ga. 6 Pt.
490313...Crimp Starter, 12 Ga. Paper
490314...Crimp Starter, 16 Ga. 8 Pt.
490315...Crimp Starter, 16 Ga. 6 Pt.
490316...Crimp Starter, 16 Ga. Paper
490317...Crimp Starter, 20 Ga. 8 Pt.
490318...Crimp Starter, 20 Ga. 6 Pt.
490319...Crimp Starter, 20 Ga. Paper
490320...Crimp Starter, 28 Ga. 6 Pt.
490321...Crimp Starter, 28 Ga. Paper
490322...Crimp Starter, 410 Ga. 6 Pt.
490323...Crimp Starter, 310 Ga. Paper

AUTOMATIC PRIMER FEED PARTS LIST

020003...Primer Tube Filler
050025...Primer Tube Assembly
190029...Stationary Plate
190030...Moveable Plate
380039...Return Spring
390096...Primer Feed Body Lock Nut
390126...Primer Feed Body
390193...Shoulder Bolt
390195...Flat Head Screw 10x32x $\frac{1}{2}$ "
390633...Primer Tube Filler Spring
480028...Primer Feed Stop Unit
Prices and/or specifications subject to change without notice.

For parts inquiries, call 1-800-338-3220