
































ALESIS

DM5

ELECTRONIC DRUM KIT

PARTS

 (15 3/4" x 1 1/2") MAIN TUBE (short) Z2010111	 (31 1/2" x 1 1/2") MAIN TUBE (long) Z2010112	 (14 3/4" x 1/2") SIDE TUBE (long) Z2010103	 (7 7/8" x 1/2") SIDE TUBE (short) Z2010501	 DRUM PAD Z2010300	 PLASTIC STAND Z2010307	 CYMBAL PAD Z20110	 CYMBAL CONNECTOR A Z2011005
[4]	[5]	[4]	[7]	[5]	[40]	[2]	[2]
 CYMBAL CONNECTOR B Z2011006	 PHILLIPS SCREW w WASHER Z2010601	 PHILLIPS SCREW Z2010510	 SCREW CAP Z2010615	 WASHER Z2010616 6.5mm	 FOOT PEDAL Z20104	 TECH SWITCH Z2010403	 PHILLIPS SCREW Z2010604 3mm
[2]	[8]	[2]	[2]	[2]	[1]	[1]	[3]
 WASHER Z2010412 4mm	 PHILLIPS SCREW w WASHER Z2010620	 KICK PEDAL Z2010408	 SIDE TUBE CONNECTOR Z2010511	 CONNECTOR Z2010502	 T-CONNECTOR Z2010513	 INSERT (large) Z2010504	 INSERT (small) Z2010505
[1]	[1]	[1]	[10]	[6]	[10]	[4]	[22]
 INSERT FOOT Z2010507	 HEX SCREW Z2010611	 HEX NUT Z2010612	 CABLE Z2010704	 DRUMSTICKS Z2010904	 WRENCH Z2010914	 RACK EARS MT1104440	
[4]	[70]	[70]	[10]	[2]	[1]	[2]	