



Your CDs, Your Voice.

PLAYMATE VOCALIST: CD PLAYER • VOCAL REDUCER • MICROPHONE PROCESSOR

Sing lead on any CD in your collection! The PlayMate Vocalist virtually eliminates lead vocals and includes a built-in CD player. Just plug in a microphone, replace the original vocal with yours, and add vocal effects to match the ambiance of the song. Independent controls let you change key, pitch, and tempo, so you can sing any song in your optimal range, plus practice in different tempos and keys. Singing is more fun than ever with the PlayMate Vocalist, the ultimate performance and practice tool for vocalists.