

The GT responds in the following order:

AAx  
Sx  
Lxx  
Px  
PAx  
TEx  
4Wx

**Appendix E: PC Command  
Quick Reference** ≡

TE <CR>	Return two-wire connect status
TE1 <CR>	Connect in two-wire
TE0 <CR>	Disconnect two-wire
4W <CR>	Return four-wire connect status
4W1 <CR>	Connect in four wire
4W0 <CR>	Disconnect in four wire
P <CR>	Return privacy status
P1 <CR>	Enables privacy
P0 <CR>	Disable privacy
L <CR>	Return current volume level
L+ <CR>	Increase volume level
L- <CR>	Decrease volume level
AA <CR>	Return current auto answer status
AA1 <CR>	Enable auto answer
AA0 <CR>	Disable auto answer
S <CR>	Return current setup status
S1 <CR>	Enable setup
S0 <CR>	Disable setup
PA <CR>	Return current phone add status
PA1 <CR>	Enable phone add
PA0 <CR>	Disable phone add
ST <CR>	Return all above status