

## Ceiling DocCam RS-232 On/Off Codes

### Description

This document describes the added Ceiling DocCam On/Off codes. The Ceiling DocCam must be labeled Rev 2.3 or higher for these codes to work.

### Code

All commands must be followed by an ASCII return character. RS-232: 4800bps, Even parity, 8bit data, 1stop bit. Please check the manual for complete RS-232 information.

Ceiling DocCam ON: WFCVL01

Ceiling DocCam OFF: WFCVL02

**Note:** *This code only turns off the Camera functions. The main board still retains power enabling the On command from both RS232 and IR*