

Channel Frequency Chart

CH Freq

01 72.05 MHz	11 72.55	21 74.7	31 75.65
02 72.1	12 72.6	22 74.75	32 75.7
03 72.15	13 72.65	23 75.25	33 75.75
04 72.2	14 72.7	24 75.3	34 75.8
05 72.25	15 72.75	25 75.35	35 75.85
06 72.3	16 72.8	26 75.4	36 75.9
07 72.35	17 72.85	27 75.45	37 75.95
08 72.4	18 72.9	28 75.5	
09 72.45	19 72.95	29 75.55	
10 72.5	20 74.65	30 75.6	

ATTN: JWB
From: Reekman