

Contents

How to use Digital-6 Plus.....	3
Tuning.....	6
Frequency Chart.....	9
Keypad Function.....	10
Keypad Lock.....	10
Reset to factory default settings.....	10
Battery Strength.....	10
How to set the battery type.....	11
The Battery low function.....	12
To check a channel frequency.....	12
Correcting Interference.....	12
To check a channel frequency.....	12
Recharging.....	13
Specifications.....	16
Notice.....	17
Compliance.....	18
Warranty.....	19
Contact Numbers.....	23

Digital-6 Plus User's Guide, August 2005 (Rev. 1.0)

© Copyright 1998 by Gentner Communications Corporation.
All rights reserved. Information in this manual is subject to
change without notice.

How to Use Digital-6 Plus

Power Source

The Digital-6 Plus receiver operates on two AA-size batteries (alkaline or rechargeable Ni-Cad/NiMH). To install the batteries, place your thumbs on either side of the pocket clip and slide the battery cover off. Note the polarity markings and insert the batteries as shown.

