

How to Use Digital-6 Plus

Operating Instructions:

Step 1

Plug the earphone into the earphone jack. The earphone cable also acts as the receiver antenna. Extend the cable fully for the best reception and least interference.

Step 2


Turn on the receiver by rotating the volume knob clockwise. The LCD screen will illuminate. This indicates that the receiver is ON.

WARNING!

To avoid harm to ears, keep all receivers OFF until the transmitter is operating at full power. Keep volume setting at low to mid-range at all times.

Step 3

Adjust the volume to the desired listening level



Step 4

To change the memory channel make sure that the keypad lock is turned off (see keypad lock for instruction). Select a memory channel by using the "UP" "DOWN" button to select any one of 6 memory channels. The current memory channel is displayed on the lower left corner of the LCD screen underneath the letter "M".