Flash Memory MP3 player with 32MB Flash Memory card

- Fully shock proof
 No moving/ rotating parts providing uninterrupted music playback
- Ultra-compact design
 Advanced micro-electronic circuitry for portability and outstanding performance, with an innovative design
- Music playing feature
 Shuffle, repeat one, repeat all, play list
- Equalizer feature for Rock and Pop mode
- Extended playing time up to 12 hours
- Multi-line LCD

 Multi-line display for name of song, artist, album, track number,
 elapsed time, bitrate, play mode when in playback mode
- Bookmark function
- Listen to the music while transferring the music file from the PC to the Flash Memory MP3 player
- RealNetwork "RealJuke box" included
- Headphone, AC/DC adaptor, parallel port cable, removable 32 MB Flash Memory Card included

















PHILIPS

Flash Memory MP3 player SA 101

Amplifier/system

Audio out : 5mW
 Equalizer feature for Rock and Pop music

Automatic power switch-off

• Digital volume control

• S/N ratio : >90dB • Frequency response : 20Hz – 20KHz

Resume and hold

Display

 16 x 112 dots matrix LCD capable of displaying twelve 8 x 16 characters

- 9 seven-segments capable of displaying track number, time and bitrate
- Indication for volume level, play mode, and battery level

Connections

Headphone/line out
DC in
!/O Interface
stereo, .14"
16", 4.5 V center '+'
!/O Interface
26-pin mini-connector

Power supply

Batteries : 2 x AAATypical playing time : 12 hours

• External supply : 110V to 4.5 V DC

General

Case : Metal top, plastic bottom
 Dimension : 2.76" W x 2.76" H x 0.67 D

Weight : TBCMaster pack quantity : 2

Accessories

- · AC/DC adaptor
- Stereo headphones
- Parallel port connection cable
- 32MB Flash Memory Card
- Real Networks' "Real Jukebox" CD-Rom

Optional accessories (contact your dealer or service centre)

Product highlights

· Fully shock proof

Uninterrupted playback of music even while you are jogging.

· Extended playing time

Innovative technology extends playing time to 12 hours (2x 'AAA' batteries).

· Play mode

Enjoy various track repeat (one/all/shuffle).

• Next/previous track search

Two-button control that puts you immediately at the start of the previous track or next track.

Hold

Prevents accidental interruption of play or changing of the setting.

Bookmarks

Ensures that the music or talking book starts or jumps precisely where the bookmark is inserted.

· Automatic power off

Automatically switches off the Flash Memory MP3 player at the end of the music.

"RealJuke box"

Manages and organizes collections of personal music, creation/ edition of playlist, encodes and decodes MP3 files, create custom compilations and playlists, transfer and manage contents on the portable player.

UPC: 0 37849 89328 9 Master pack UPC: 1 37849 89328 6

> Printed in Hong Kong 1999-09-01 Specifications subject to modification without notice © 1999 Koninklijke Philips Electronics N.V. All Rights Reserved

> > http://www.philipsusa.com



