

Wireless Microphone Tuner/Wired Microphone and Camcorder Combinations

As of 20th Dec. 2006

| Camcorders | | Camcorder interface for Microphone | | | | Applicable Shotgun Microphone | Applicable Wireless Tuner | | | |
|------------------------------------------------------------------------------------------------------------------------|------------------------|------------------------------------|---------------------|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|--|
| Model Name | Built-in Wireless Slot | DC Output for Wirelss Tuner | Mic Input Connector | Audio Input Connector | WRR-855A/855B (1 ch) for Slot-in | | WRR-855A/855B (1 ch) for mounting on rear position | WRR-861A/861B (1 ch) | WRR-862A/862B (2 ch) | |
| HDCAM Camcorders | | | | | | | | | | |
| HDW-F900R HDW-750/750P  | Yes | Yes | XLR-5pin x1 | XLR-3pin x2 | ECM-678 Requires XLR-3P - XLR-5P Cable(K-1502)  | Direct slot-in  | Requires A-8278-057-A Mount Bracket and BTA-801  | Requires A-8278-057-A Mount Bracket  | Requires A-8278-057-A Mount Bracket  | |
| HDW-730S  | Yes | Yes | XLR-3pin x1 | XLR-3pin x2 | ECM-678  | Direct slot-in  | Requires A-8278-057-A Mount Bracket and BTA-801  | Requires A-8278-057-A Mount Bracket  | Requires A-8278-057-A Mount Bracket  | |
| Digital Betacam Camcorders | | | | | | | | | | |
| DVW-970/970P  | Yes | Yes | XLR-3pin x1 | XLR-3pin x2 | ECM-678  | Direct slot-in  | Requires A-8278-057-A Mount Bracket and BTA-801  | Requires A-8278-057-A Mount Bracket  | Requires A-8278-057-A Mount Bracket  | |
| MPEG IMX Camcorders | | | | | | | | | | |
| MSW-970/970P  | Yes | Yes | XLR-3pin x1 | XLR-3pin x2 | ECM-678  | Direct slot-in  | Requires A-8278-057-A Mount Bracket and BTA-801  | Requires A-8278-057-A Mount Bracket  | Requires A-8278-057-A Mount Bracket  | |
| XDCAM Camcorders | | | | | | | | | | |
| PDW-510/510P PDW-530/530P  | Yes | Yes | XLR-3pin x1 | XLR-3pin x2 | ECM-678 ECM-674(*1)  | Direct slot-in  | Requires A-8278-057-A Mount Bracket and BTA-801  | Requires A-8278-057-A Mount Bracket  | Requires A-8278-057-A Mount Bracket  | |
| XDCAM HD Camcorders | | | | | | | | | | |
| PDW-F330 PDW-F350  | No | Yes | XLR-5pin x1 | XLR-3pin x2 | ECM-678 ECM-674(*1) ECM-673 Requires XLR-3P - XLR-5P Cable(K-1502)  | Requires CA-WR855 Mount Adaptor  | Requires A-8278-057-A Mount Bracket and BTA-801  | Requires A-8278-057-A Mount Bracket  | Requires A-8278-057-A Mount Bracket  | |
| DVCAM Camcorders | | | | | | | | | | |
| DSR-400/400P DSR-450WS/450WSP  | No | Yes | XLR-3pin x1 | XLR-3pin x2 | ECM-674(*1) ECM-673  | Requires CA-WR855 Mount Adaptor  | Requires A-8278-057-A Mount Bracket and BTA-801  | Requires A-8278-057-A Mount Bracket  | Requires A-8278-057-A Mount Bracket  | |
| DSR-250/250P  | No | Yes | XLR-3pin x1 | XLR-3pin x2 | ECM-678 ECM-674(*1) ECM-673  | -  | Requires A-8278-057-A Mount Bracket and BTA-801  | Requires A-8278-057-A Mount Bracket  | Requires A-8278-057-A Mount Bracket  | |

*1 : The ECM-674 can be driven by external DC power(40 to 52V) or battery(AA-size).