

(MB-496 BOARD)

*Grandy*

7-4. ACCESSORIES SUPPLIED

Ref. No. or Q'ty	Part No.	SP Description
R509	1-216-814-11	s RES, CHIP 270 5% 1/16W
R510	1-216-839-11	s RES, CHIP 33K 5% 1/16W
R511	1-216-844-11	s RES, CHIP 82K 5% 1/16W
R512	1-216-805-11	s RES, CHIP 47 5% 1/16W
R513	1-216-835-11	s RES, CHIP 15K 5% 1/16W
R514	1-216-842-11	s RES, CHIP 56K 5% 1/16W
R701	1-216-805-11	s RES, CHIP 47 5% 1/16W
R702	1-216-833-11	s RES, CHIP 10K 5% 1/16W
R703	1-216-832-11	s RES, CHIP 8.2K 5% 1/16W
R704	1-216-819-11	s RES, CHIP 680 5% 1/16W
R705	1-216-842-11	s RES, CHIP 56K 5% 1/16W
R706	1-216-839-11	s RES, CHIP 33K 5% 1/16W
R707	1-216-837-11	s RES, CHIP 22K 5% 1/16W
R708	1-216-851-11	s RES, CHIP 330K 5% 1/16W
R709	1-216-833-11	s RES, CHIP 10K 5% 1/16W
R710	1-216-809-11	s RES, CHIP 100 5% 1/16W
R711	1-216-797-11	s RES, CHIP 10 5% 1/16W
RY201	1-237-036-11	s RES, ADJ METAL 10K
RV501	1-237-035-11	s RES, ADJ METAL 5K
S501	1-571-624-21	s SWITCH, SLIDE
T131	1-406-783-21	s TRANSFORMER, DEMODULATOR
X101	1-577-689-11	s VIBRATOR, CRYSTAL 60.2MHz
X241	1-567-098-41	s CRYSTAL 32.76800MHz

Ref. No. or Q'ty	Part No.	SP Description
101	A-8265-089-B	s CASE ASSY, ATTACHMENT
102	X-3167-080-1	s BRACKET ASSY, FITTING
103	1-501-612-11	s ANTENNA
104	1-534-685-00	s CORD, MIC
105	1-560-155-51	s CONNECTOR (PLUG)
106	1-565-655-11	s CONNECTOR, CANON
107	2-540-028-01	s HOLDER, FITTING
108	3-180-979-01	o FASTENER
109	3-618-078-00	s RING, RETAINING, CE TYPE
110	3-701-444-11	s WASHER, 6
111	7-682-517-09	s SCREW #3 3X6
112	7-682-560-09	s SCREW #D 4X6
113	7-688-006-12	s W 6, MIDDLE
-	3-757-228-23	s MANUAL, INSTRUCTION

103.9

