Quich Check

П

ABC 2

DEF

GHI 4

ла 5

AUDIX® MESSAGING WALLET CARD

ACTIVITY MENU

Record and send messages

(record, edit, address, deliver) **Get and respond**

to messages (retrieve, sort/save, respond)

Create personal greetings

(record, edit, activate)

Check outgoing

messages (retrieve, sort/save,

review/modify, resend)

Change password/create lists/personal directories (create, review/modify, scan)

Scan messages quickly (and/or headers)

BASIC COMMANDS

 Help
 ★ 4 or ★ H

 Restart at activity menu
 ★ 7 or ★ R

 Wait
 ★ 9 or ★ W

 Undelete
 ★ * 8 or * * U

(may not be available with your system)

Hold message ★★4 or ★★H

in category

Log in again ****7** or **** R**

Skip call answer greeting 1

Transfer to an extension

* 8 or * T

Look up name/ extension * * 6 or * * N

Exit system

* * 9 or * * X

Transfer call to operator

* 0

Delete

Use while addressing:

Alternate addressing (switch between name/extension)


Use mailing list

* 2 or * A

* 3 or * D

* 5 or * L

PLAY-BACK CONTROLS



Press 3 to pause and 3 again to continue.

© Copyright 1999 Octel Communications Corporation, a subsidiary of Lucent Technologies. All rights reserved. All trademarks identified by @ and ^M are registered trademarks or trademarks respectively, of Octel Communications Corporation, a subsidiary of Lucent Technologies. All other trademarks are the properties of their respective owners. Printed in U.S.A.