

System Features	Operation Procedures

Please use this Operating Instructions Manual for basic operations. Refer to the Electronic Modular Switching System (EMSS) Control Unit Manual for additional features.

Notice

A series of the beep tone may sound periodically when the MEMORY switch is set to the "PROGRAM". This is a normal condition.

PANUG-001

Panasonic Company
Division of Matsushita Electric Corporation of America

One Panasonic Way, Secaucus, New Jersey 07094

Panasonic Company (West) of America
Division of Matsushita Electric Corporation of America

6550 Katella Avenue, Cypress, California 90630

























Panasonic Sales Company ("PSC")
Division of Matsushita Electric of Puerto Rico, Inc.

San Gabriel Industrial Park, 65th Infantry Avenue, KM 9.5, Carolina, P.R. 00630

Panasonic

MODEL NO. **KX-T7020**

Operating Instructions

Making Calls	
Press the  button or lift the handset first.	
Feature Description	Operation Procedures
Intercom Calling	Dials from station to station within the system.  or 
Individual Line Access	Selects any CO line directly.  → 
Automatic Line Access	Selects an unoccupied CO line automatically.  → 
System Speed Dialing	Dials the stored phone number by following simple operation.  → 
One-Touch Dialing	Dials the stored number by pressing only one button. Dialing: 
	Programming: 1. Set the memory switch to "PROGRAM". 2.  →  →  →  3. The memory switch must be adjusted so that it is in the "SET" position.
When a Line is Busy	
Automatic Call Back Busy (Camp-on)	Receives a notice that the busy line becomes free. Outside Calls:  →  →  → 
	Intercom Calls:  →  →  → 
Redial	Redials the last number dialed. Automatic redial can work in upgraded systems.  or  → 