## **CT Non-Display Handset**

To answer a call Lift receiver or press Spkr key to answer call handsfree

**To make a call** Lift receiver and dial 9 and telephone no. or press **Spkr** key and dial

number

To place a call on hold Press the Hold key

**To retrieve a held call**Press the green flashing line key

To transfer a call Press the Cnf/Trn key, dial extension number, announce call and replace

receiver

**To retrieve a call** Press the green flashing line key

**To park a call** Press Park key or **Cnf/Trn** #332, then enter Orbit number 900 – 919 and

replace receiver

**To retrieve a parked call** Press Park key or # 332 and orbit number 900 – 919 (You will be connected

to the call)

To set a call back on a

busy extension

Dial extension number, get busy tone and press 4 or pre-programmed ACB

key

**To redial last number** Press the **Redial** key (This will redial last number dialled internal or external)

To answer another extension that is ringing in your group

Press the **Pickup** key or dial #5#34

To answer another extension that is ringing outside of

your group

Lift receiver, and dial #5 and extension which is ringing

To make an all call page to any unused handsets

Lift receiver, dial #30 and make announcement

To programme personal speed

dials

Press **Redial** key, speed dial key, location number 100 -139, 9 + Tel number,

press redial key to store

To programme system speed

Dials from port 000

Press Redial key, speed dial key, location number

200-999, 9 and Tel number, redial key

**To use speed dial numbers** Press the **Speed dial** key and location e.g. 200 – 999 or 100 - 139

**To divert your calls immediately** Receiver down, press Internal key, dial #601, enter internal number to receive

calls, press spkr key

**To divert on busy**Receiver down, press Internal key, dial #602, enter internal number to receive

calls, press spkr key

**To divert on no answer** Receiver down, press Internal key, dial #603, enter internal number to receive

calls, press speed dial key, enter number of secs to ring 08 – 60, press redial

key and spkr key

**To divert on busy/no answer** Receiver down, press internal key, dial #604, enter internal number to receive

Calls, press speed dial key, enter numbers of secs to ring 08 – 60, press redial

Key and spkr key

**To cancel your divert** Receiver down, press Internal key, dial #601, press spkr key

**Conference calls** Receive / Make 1<sup>st</sup> call, press **Cnf/Trn** key, dial 2<sup>nd</sup> number, when they answer,

press Cnf/Trn key to join all 3 together

**To exit Conference** Press **Cnf/Trn** key and then hang up