

## DK Non-Display Handset

<b>To answer a call</b>	Lift receiver or press <b>Spkr</b> key to answer call handsfree
<b>To make a call</b>	Lift receiver and dial 9 and telephone no. or press <b>Spkr</b> key and dial number
<b>To place a call on hold</b>	Press the <b>Hold</b> key
<b>To retrieve a held call</b>	Press the green flashing line key
<b>To transfer a call</b>	Press the <b>Cnf/Trn</b> key, dial extension number, announce call and replace receiver
<b>To retrieve a call</b>	Press the green flashing line key
<b>To set a call back on a busy extension</b>	Dial extension number, get busy tone and press <b>4</b> or pre-programmed <b>ACB</b> key
<b>To redial last number</b>	Press the <b>Redial</b> key (This will redial last number dialled internal or external)
<b>To answer another extension that is ringing in your group</b>	Press the <b>Pickup</b> key or dial #5#34
<b>To answer another extension that is ringing outside of your group</b>	Lift receiver, and dial #5 and extension which is ringing
<b>To make an all call page to any unused handsets</b>	Lift receiver, dial #30 and make announcement
<b>To programme personal speed dials</b>	Press <b>Redial</b> key, speed dial key, location number 10 -49, 9 + Tel number, press redial key to store
<b>To programme system speed Dials from port 000</b>	Press <b>Redial</b> key, speed dial key, location number 600-999, 9 and Tel number, redial key
<b>To use speed dial numbers</b>	Press the <b>Speed dial</b> key and location e.g. 600 – 999 or 10 - 49
<b>To divert your calls immediately</b>	Receiver down, press Internal key, dial #601, enter internal number to receive calls, press spkr key
<b>To divert on busy</b>	Receiver down, press Internal key, dial #602, enter internal number to receive calls, press spkr key
<b>To divert on no answer</b>	Receiver down, press Internal key, dial #603, enter internal number to receive calls, press speed dial key, enter number of secs to ring 08 – 60, press redial key and spkr key
<b>To divert on busy/no answer</b>	Receiver down, press internal key, dial #604, enter internal number to receive Calls, press speed dial key, enter numbers of secs to ring 08 – 60, press redial Key and spkr key
<b>To cancel your divert</b>	Receiver down, press Internal key, dial #601, press spkr key
<b>Conference calls</b>	Receive / Make 1 <sup>st</sup> call, press <b>Cnf/Trn</b> key, dial 2 <sup>nd</sup> number, when they answer, press <b>Cnf/Trn</b> key to join all 3 together
<b>To exit Conference</b>	Press <b>Cnf/Trn</b> key and then hang up