310 E. LANARK AVENUE. LANARK. ILLINOIS 61046

PHONE 815-493-6360

(FAX 815-493-2371)

www.forsterproducts.com

HANDHELD OUTSIDE NECK TURNER INSTRUCTIONS

Case-neck turning is standard practice for all types of shooters these days. If your cases have .002" or more of wall variation, neck turning undeniably delivers you some of the greatest accuracy return on your investment in handloading time. The Forster Handheld Outside Neck Turner is easily adjusted to remove brass from the thick side of case neck walls. A case-holder handle is included.

FEATURES


- CARBIDE NECK THICKNESS CUTTER This long-life, smooth-cutting carbide is precision ground with special angles and reliefs designed for neck turning. The cutter approach angle allows turning right up to the case shoulder.
- MICROMETER ADJUSTMENT KNOB This knob makes it simple to make fine adjustments in either direction. Index marks at increments of .001" are clearly stamped on the knob of the tool, and adjustments to half-a-thousandth of an inch can easily be made.
- PRECISION GROUND PILOT (mandrel) Our standard pilots are precision ground .0020" to .0025" smaller than bullet diameter. This will produce a slip fit for most cases that have been drawn over a standard size expander. Standard size pilots are available in 28 sizes for bullet diameters ranging from .224" up to .513". Any special-size pilot is available on a special-grind basis. We ship special orders quickly. This service can provide you with an infinite number of ground pilot sizes, made to your specifications. A \$10 special grinding fee will be added to the price of the pilot.

Remember that very few changes will provide a more sensational improvement in accuracy than the act of turning eccentric case necks to a consistent wall thickness. At the point of ignition, your brass has to expand to allow bullet release. If the brass is thicker on one side than the other, the thin side releases the bullet first and causes a slight bullet to bore misalignment that can have disastrous effects on accuracy.

TIPS FOR PREPARING YOUR CASES

- Use older, less-favorite brass cases until you get a feel for neck turning.
- Full length or fully neck size and expand the cases before neck turning.
- Chamfer the inside of the case mouth, then clean the necks internally and externally.
- Purchase a good sizing lubricant such as Forster High Pressure Case Lube, to lightly lube the pilot.

INSTRUCTIONS FOR TURNING



Order # HOT100 — The Handheld Outside Neck Turner includes an anodized aluminum Body with Carbide Cutter, Micrometer Adjustment Knob, and a universal Case Handle. Precision ground pilots (mandrels) are available separately.

Insert the head of the case to be turned into the Case Handle (-101) and tighten the Knurled Screw to secure the case. A larger handle is available for 50 BMG caliber (HOT100-021).

Install the pilot (mandrel) in the Body (-011) and tighten the pilot set screw against the flat that is ground on the pilot's shank. The amount the pilot protrudes from the turning tool Body determines the length of the neck turning that will occur.

Put a small amount of Forster High Pressure Case Lube or any good case lube onto the pilot. Slip the case onto the pilot until the case mouth stops against the shoulder of the pilot.

The fit of the pilot to the case is very important. Specially ground pilots are available from Forster. Please supply three sized cases so that we may grind a pilot to be a perfect slip fit for your specific

reloading needs. A \$10 special grinding fee applies.

Turn the large, knurled Carbide Cutter Depth Adjustment Knob (-013) clockwise until the Carbide Cutter is almost touching the case neck. Loosen the pilot and position it so that the cutter will **almost** start to blend with the shoulder angle, then retighten the pilot set screw. **NOTE** — **Do not cut into the shoulder of the case. Doing so will weaken the case and can contribute to neck separations.** Your Hand Outside Neck Turner is now set for the length of the cut.

Next, set the depth of cut. Turn the Carbide Cutter Depth Adjustment Knob (-013) down until the cutter just barely contacts the case neck. Remove the case from the pilot and turn the Micrometer Adjustment Knob clockwise one half a graduation (.0005"). Your depth of cut adjustment is controlled by this Micrometer Adjustment Knob. The index marks stamped on this Micrometer Adjustment Knob advance or retract the cutter by .001" (one-thousandth of an inch). Your Hand Outside Neck Turner is now set to take a first cut.

The gold anodized Neck Turner Body (-011) may be held by hand or locked in a vise for best consistency. Guide the case neck onto the pilot while you turn the Case Holder clockwise. Turn it slowly enough to provide a smooth, even cut over the entire case neck's outside diameter. Turn the case until the case mouth stops against the pilot's step. Continue to turn the case clockwise as you remove the neck-turned case off of the pilot.

Make adjustments to the depth of cut by using the Micrometer Adjustment Knob. After your neck-wall thickness adjustment is correct, it is not necessary to lock the cutter in place, as it will hold its setting from case to case. If you do feel more comfortable locking the cutter in place, tighten the top button-head screw only. The front-slotted screw is for keeping tension on the Carbide Cutter. This should only be tightened if the cutter moves too freely while adjusting the depth of cut.

There is no definite tolerance for the correct neck thickness. Many reloaders feel that a .002" to .003" clearance between the outside diameter of the case neck and the chamber is optimal. We feel that it is best to just barely clean up the necks so that they are uniform. This will extend the life of your brass.

IMPORTANT OUTSIDE NECK TURNING POINTERS

- It is important to note that a .001" depth of cut adjustment alters your neck diameter by .002".
- When backing out the carbide cutter, the backlash must be removed from the Micrometer Adjustment Knob before the cutter starts backing out in thousandths.
- Use the Forster Case & Cartridge Inspector to check case neck wall thickness. It may be appropriate
 to turn each case twice at the same depth setting to ensure consistency among the neck walls.

Thank you for purchasing a Forster Precision Product. Please wear safety glasses.

Forster Catalogs are available upon request.