**ClearOne** 

# APPLICATION NOTE

Converge Console (Version 1.0.4) Converge Pro Firmware (Version 1.0.4)

CLEARONE DOCUMENT 801-151-800-05 (REVISION 1.0) September 2007.

# CONVERGE PRO EVENT SCHEDULER

### Purpose

This document explains setup issues related to the Event Scheduler for Converge Pro devices.

#### Introduction

The Converge Pro Event Scheduler allows actions to be scheduled and executed at predefined times. The actions can be onetime occurrences or a series of occurrences. Actions that can be scheduled and executed are Macro, Preset, Reset, Safety Mute, Strings, and System Checks. Events can only be set to run from the local Converge Pro device. Up to ten different events can be scheduled on a Converge Pro device.

### **Clock Setup**

Converge Pro devices have an internal real-time clock that must be set to ensure scheduled events execute at the appropriate time. The clock can be synchronized with time on the connected PC, or to the time on a network time server. To set the time, use the Site Properties dialog in Console (shown below) and follow this procedure:

eneral Management	TineLocal
Time	urrent Site Time: Offline
Cocol Time	Date Time Clock 09:06/2007 • 11:20:21 • Apply
C Network Time	Tree Server 7
Time Zone	I⊽ Use Daylight Savings
(GMT-07:00) Mo	untain Time (US & Canada)
Building City	
State	
Country	
Company	
Region	

1. Select Site Properties from the File menu in Console, or right-click anywhere in the Site View or Tree View panes and

select **Site Properties** from the shortcut menu that appears.

- 2. In the Site Properties dialog that appears, select the **Time/Local** tab.
- 3. In the Time section of the tab, select Local Time or Network Time for the clock synchronization source.
- 4. When **Local Time** is selected, the **Apply** button is activated; pressing it updates the date and time on all units in the current site.
- 5. When **Network Time** is selected, you must enter the IP address(es) for the time synchronization server(s). The date and time is updated for all units in the site when you press the **OK** button, and it is automatically synchronized with the specified server(s).
- 6. Enter location information in the Location section of the tab (optional).
- 7. Press **OK** to save the changes, then close the Site Properties dialog to synchronize the time.

## Using Event Scheduler

After the clock is set, open the Event Scheduler (shown below) and use the following procedure to schedule events:

	2 3	f III		1	<b>a</b> ¢		()	?							ClearO
election	Unit	Channel	Matrix	AEC Refe	erence	Macro	Gating	Control	String	Event Schedu	ier Datab	ase			
Site1 💌	Com	mand Fr	llana	č						,					
nt Unit	Com	mand EC	mor												
Converge840T-F5	Comm	hand Descr	iption						,A	rgument Descrip	tion				
ew Tree View	Exec	ute a Macr	0.					3	Mai	cro: Macro to exe	ecute. 1 to 25	5.			~
(30) Converge840T_E															
S Mic								3	8						~
S Input 1															
M Input 2	Type	DID	Comr	nand		Macro		Name							
nput 3		Y .	MAC	RO	-	1	-								
M Input 4															
Line	Time	Schedu	ıler												
input 5															
logut 7	Start D	ate / Time:													
loguet 9					C Sing	gle Event			<ul> <li>Ma</li> </ul>	aximum of 2	•	Times			
Telco By	Ī	09/04/2007	. (h												
Telco RX	1		-	-	<ul> <li>Eve</li> </ul>	nt Recur	rence		C Er	nd Date / Time:					
(0) Output					Recur	Verv									
Output 1	T	1-16-16 D	м 🚽		1		Hours	-		09/04/2007	-	-13:00 DM	-		
📲 🔘 Output 2	1	1.10.101		<u></u>	1.	-	Inders			0010 112001					Clear
- 🗐 Output 3															
Output 4	Sche	duled Ev	/ents											Ev	ent ID: 1
Output 5															
Output 6	ID	Command			Sta	rtTime		En	d Oc	End Time		Minutes	Hours	Days	Weeks
Output 7	1	# MACRO	01		09/	04/2007	01:16:15 P	vi 2				0	1	0	0
Cupul o	2														
	3														
	5														
Processing	6														
Processing	7														
Processing	1														
Processing Process A Process B Process C	8														
Process A Process B Process C Process D	8 9														
Processing Process A Process B Process B Process C Process D Fader	8 9 10														

- 1. Press the Event Scheduler Tab on the Tab Bar in Console.
- 2. Select the **Command** to run.
- 3. Select the Start Date and Time.
- 4. Select the **Occurrence** (a single event or a series of events). The series can be set from as little as every minute to every 12 weeks.
- 5. If a series is created, a series end must be set. The series ends after specified number of times or on a specific date.
- 6. Once the desired event has been setup press Apply to apply the event to the Converge Pro device.
- 7. If another event is desired repeat the above setup, for up to 10 scheduled events total.
- 8. Double clicking the event in the **Scheduled Event** list will populate the **Time Scheduler**, which allows the event to be edited.
- 9. Pressing the **Clear** button clears the highlighted event.
- 10. Pressing the Clear All Events button clears all events listed in the Scheduled Events list.

To prevent unexpected event execution and event execution failure when using Event Scheduler, follow these important recommendations:

- The real-time clock must be set before an event is scheduled. A timer is created for all programmed events based on the clock's current time, and once the timer is set, Converge Pro devices do not use the real-time clock for event execution.
- If the clock is set after an event is scheduled, the event's timer is not updated. The event will run based on elapsed time from the last time the event ran. When another event is scheduled, the timer will be updated to keep track of the new event and the existing event.
- If the real-time clock is set after an event is scheduled, either a new event will need to be scheduled or the existing event will need to be rescheduled for the event to run at the proper time.

• Events need to be spaced a minimum of one minute apart. If events are scheduled too closely together, some events may not run, and some events may run multiple times. Assume that Event 1 is scheduled to run every night at 12:00:00 am, and Event 2 is scheduled to run every Sunday at 12:00:02 am. On Sunday night, there may be a problem executing one or both events. On all other nights, Event 1 will execute properly. However, events that are scheduled to run at precisely the same time (hour, minute, and second) will execute properly. ClearOne recommends using at least a one-minute interval between all scheduled events.

Device Log - Converge8	40T-F5						
Events							
09/04/2007 15:46:59	Event 1 started	~					
00004/2007 4/2 40:00	Macro 1						
09/04/2007 15:46:00	Eveni z staneu Preset 1						
09/04/2007 15:49:00	Event 3 started						
	Safety Mute Off						
09/04/2007 15:50:00	Event 4 started						
09/04/2007 15:51:00	#30 SYSCHECKS 3FF						
	#30 SYSRESULT 1 0 No IP Address	Set					
09/04/2007 15:51:03	#30 SYSRESULT 81 Microphone Pa	sses					
	#30 SYSRESULT 4 1 Microphone Pa:	sses India Custos Charly Config					
	#30 SYSRESULT 20 2 Test not enab	led in System Check Config					
	#30 TE 1 1	·····					
09/04/2007 15:51:06	#30 SYSRESULT 2 0 No Telephone line: 0 V. 0 mA. 1						
	#30 TE 1 0 #30 CALL DUR 1 00:00:02						
	#30 CALEDON 1 00:00:02	<b>M</b>					
Refresh	Clear Sav	re Print					
Event Selection							
🔽 Reset	🔽 Default	V Telco On/Off					
Frrors	🔽 Safety Mute	🔽 Dial					
Access	Macro	Call Duration					
🔽 System Checks	V Preset						
Firmware Downlo	ad 🔽 Audio Clipping						
		Close					

• To confirm that an event executed at the expected time, use the device log. When an event executes, the device log automatically records the event (as shown in the example above). The log includes a date and time stamp created from the real-time clock on the Converge Pro Device upon which the event executed.