

MONITOR TROUBLESHOOTING GUIDE

K7500 SERIES

SYMPTOM

ACTION

Weak or no video: Adjust the CONTRAST (VR905) and BRIGHTNESS (VR906) controls on the customer control board. With the **AC** power off make sure that the cables going to and from the neck board are all plugged in. Make sure the signal input cable is connected to the monitor.

No raster: Adjust BRIGHTNESS control (VR906) on customer control board. With the **AC Power off** make sure all of the cables are plugged in, including the AC cord. Check the fuse.

Vertical rolling: Adjust the V-HOLD control (VR902) on the customer control board. Check signal input connector for loose or broken wires.

Horizontal tearing: Adjust the H-HOLD control (VR701), which is a blue trim pot located on the chassis. Make sure the wires on the signal input cable are not loose or broken.

Video shift left or right: Adjust the H-POS control (VR901) on the customer control board.

Video shift up or down: Adjust the V-POS control (VR903) on the customer control board.

Video too wide or

too narrow:

Adjust the WIDTH control (VR900) on the customer control board.

Video too tall or

too short:

Adjust the HEIGHT control (VR907) on the customer control board.

No red:

Check the red video input lead on the signal input cable.

No green:

Check the green video input lead on the signal input cable.

No blue:

Check the blue video input lead on the signal input cable.