
INSTRUCTION MANUAL



ELECTRA GAMES, INC. 2570 United Lane Elk Grove Village, Illinois 60007

INTRODUCTION

"Pace Car Pro" is the first racing game in which $\underline{\text{four}}$ players can share in the excitement of a simulated high speed race.

The game has been designed to provide the same excitement for one, two, three, or four players, since a "robot" pace car provides <u>built-in</u> competition. To add to the excitement, there are realistic motor sounds (one for each car), crash sounds, an infield that actually causes the cars to "slow" down, and a "joystick" control for each car that controls <u>speed</u>, <u>direction</u>, and braking.

When set for single coin per player pricing, Pace Car Pro has the potential to increase income. It is the first game with the capability of taking in one dollar per play.

Each "Pace Car Pro" game undergoes hours of testing before it is judged acceptable for shipment. Thorough component testing involving thermal cycling, final inspection and testing - 24 hour operative testing of individual electronic assemblies and the color television, and finally a 24 hour test for the complete game. Every game must pass all tests before it can be shipped.

The game has been designed with ease of servicing in mind. All electronic p.c. modules and the color television are accessible by removing the cabinet top. The entire game electronics is contained on two plug-in logic printed circuit erds, a plug-in power supply board, and a color adjust board.

Despite all testing and precautions taken, malfunctions sometimes occur. Refer to the trouble-shooting guide to isolate the problem, and contact the distributor from whom the game was purchased for repair or replacement instructions. "Do not attempt to perform repairs on any in-warranty printed electronics boards, as the warranty will be voided."

WARRANTY

Except as hereinafter stated, Electra Games, Inc., warrants the color television and the modular electronic printed circuit boards used in "Pace Car Pro" to be free from defects in material or workmanship under normal use. Our obligation under this warranty is limited to making good at our factory any parts thereof which shall within:

90 days - color television

I year - modular electronic printed circuit boards

after delivery of such product be returned to us, and which our examination shall disclose to our satisfaction to have been thus defective will be exchanged or repaired without charge to the owner; bowever, transportation costs incidental to replacement or exchange of such parts shall be borne by the owner.

This warranty does not extend (1) to any of our products which have been subject to misuse, neglect, accident, incorrect wiring not our own, improper installation, or to use in violation of instructions furnished by us, (2) to units which have been repaired or altered by anyone other than us, (3) to cases where the manufacturers date code or the serial number of the product has been removed, defaced, or changed.

This warranty is in lieu of all warranties expressed or implied, and no representative or person is authorized to assume for us any other hability in connection with the sales of our products.

ELECTRA GAMES, INC. 2570 United Lane Elk Grove Village, Illinois 60007

CABINET ACCESS INFORMATION:

The "Pace Car Pro" cabinet is constructed of solid core plywood and consists of three basic parts: the Base, Top, and Control Panel.

- 1) Access into the Base is thru the Bottom Access Door; the keys to this door are located in the Instruction Manual envelope.

 Access into the Base is necessary to reach the Cash Box, Coin Chute, Power Cord, or to remove the Control Panel.
- 2) Removal of the Top allows access to all of the Electronics Modules, Coin Equipment, and the Color Television. The keys to the Top are also located in the Instruction Manual envelope.
- 3) Removal of the Control Panel is only necessary for access to the "Joysticks" or for additional door opening clearance. For Control Panel removal instructions, see section entitled "Door Opening Clearance".

TOP REMOVAL:

Locate the two keys for the cabinet top (in instruction Manual envelope), and unlock top. (Top is unlocked with both keys in horizontal position.)

REFER TO FIGURE 1 FOR THE FOLLOWING:


- . Grip Cabinet top at lower front edges and lift up several inches (this will disengage the "U" channel which locks the Front Panel in position.)
- . Push the Top back several inches, until it clears the Front Panel, and then set it down, so that Top is again resting on Cabinet.
- . You should then move to rear of Cabinet and pull Cabinet Top back while holding it securely.

Note: When mounting Cabinet Top, the reverse procedure should be followed. The two bolts at lower rear of Top assembly must be aligned with the mating brackets at the rear of Base when mounting Top. (Refer to Figure 1 - C.)

INSPECTION AND PRELIMINARY SET-UP:

With the Top removed, a thorough inspection for shipping damage should be made.

inspect complete Cabinet (Base, Control Panel, and Top) for obvious damage. If any damage is discovered, contact the carrier immediately. Then contact the distributor from whom the game was purchased for repair or replacement instructions.



INSPECTION AND PRELIMINARY SET-UP - CONT'D .:

Inspect the Color Television for any obvious damage, then inspect the power supply unit (located behind the television). The power supply P. C. module should be connected and securely in position. (Refer to Figure 2.)

Inspect the Logic Module Chassis. Remove the Chassis Cover, and check that both Logic Boards (EG1000-A and EG1000-D) are securely in position, and connected into their respective edge connectors. (Refer to Figures 2 and 3.)

Check connections to the Color Adjust P. C. board, mounted on the Logic Module Chassis. (Refer to Figure 2.)

Check the Coin Mechanism to see that it is properly mounted. Insert several old and new coins, into the Coin Mechanism. No genuine coins should be rejected. Operate rejector mechanism and check for any "binding".





Figure 2



DISASSEMBLING SHIPPING PALLET:

The keys to the Bottom Access Door are located in the Instruction Manual envelope. Locate the keys and remove the Access Door.

Unbolt the game from the Shipping Fallet by removing four 3/8" bolts from inside Base of Cabinet - at bottom.

Install the four Adjustable Legs (located in Cash Box) into threaded "T" nuts in Cabinet Base. (See Figure 4.)

DOOR OPENING CLEARANCE:

Clearance dimensions of "Pace Car Pro" completely assembled are:

33" wide X 38 1/4" deep X 57" high

Note:

If game will not clear door opening, the Control Panel should be disassembled as follows:

Disconnect Control Cable (refer to Figures 2 and 4). Control Cable is connected to the Interconnect Printed Circuit Board.

While holding Control Panel, remove two 3/8" bolts which secure the Control Panel to the Cabinet Base.

Clearance dimensions of the game with Control Panel removed are:

33" wide X 30 1/4" deep X 57" high

Note:

If additional clearance is required, remove Cabinet Top. (Refer to "Top Removal" and Figure 1.)

Replace Control Panel by reversing procedure used to remove Panel. (Refer to Figures 2 and 4.) Be sure to re-connect Control Cable.

SETTING UP THE GAME:

Game must be leveled by adjusting the four legs previously in the cabinet best.

Note:


If Game is to be operated on a carpeted floor, adjust legs to a height sufficient to allow air circulation into the vent holes in the bottom of the Base.

SETTING UP THE GAME - CONT'D.:

Push the Power Cord Plug, located inside the Game "Base" thru the hole in the back of the base. (Strain relief on Power Cord restricts cord from being pulled entirely out of Base.)

Note:

Page Car Pro is shipped set to operated on 120 volt 50/60 Herz Power. To set-up for 240 volt 50/60 herz:



120 volt 50/60 Hz

240 volt 50/60 Hz

Plug the Power Cord into the proper receptacle (120 volt - unless modified as directed), and turn on Power Switch located at the lower rear of the basapproximately a 15 second warm-up period, the display snown in Figure . will appear on the cathode ray tube.

GAME OPERATION AND SEQUENCE:

Definitions:

Standby Condition - Game power on, no Credits established

Credit Condition - One or more Creaits established (one Credit =

one Quarter deposited.)

Play Condition - Start Button activated, Game in progress




Figure 4




Figure 5

GENERAL:

The Pace Car (green blip) serves a two-fold purpose:

- It performs the function of a "built-in" opponent making it possible for one person to play.
- 2) It operates as a Game Timer which determines the duration of each play (race).

The four opponent cars are the Red, Yellow, Violet, and Blue blips. These cars are controlled by the four color keyed "Joysticks" on the front panel. Each "Joystick" controls the <u>Speed</u>, <u>Direction</u>, and <u>Braking</u> of its respective car. The "Joystick" is mechanically biased to return to center position.

The four Lap Counters (color keyed to each car) show the progress of each car by advancing - one count - for each completed lap. One lap is completed when the car is moved counter-clockwise from the starting line, completely around the track and back to the starting line, (in Play Condition).

The Pace Car laps are indicated by "Hash" Marks displayed just below the four Lap Counters. The total pace car laps to be completed are shown at the beginning of the race, and then one is subtracted tor each lap completed by the Pace Car until the race ends.

STANDBY CONDITION:

The Pace Car is moving about the track in a counter-clockwise direction.

The four Opponent Cars (Red, Yellow, Violet, and Blue) are displayed " at to the left of the Starting Line.

The four Lap Counters show the results of the previous race.

The Pace Car Lap Indicator is not operational at "Standby"; therefore no Pace Car Laps are displayed.

If the "Joysticks" are moved, the four Cars will show some movement within a limited area.

CREDIT CONDITION:

One Quarter deposited - -

The Pace Car is moving about the track and now a Motor Spand is heard as the Pace Car moves.

CREDIT CONDITION CONT'D.:

Only the Red Car is displayed just to the left of the Starting Line, and an idling sound is heard. The four Lap Counters are re-set to "Zero". The Pace Car Lap Indicator shows six (6) laps to be completed. The "Joystick" allows movement within a limited area, the stick is held to the right (direction of race) the Motor Sound "Revs" to a higher patch.

PLAY CONDITION:

The Start Button is depressed - -

The Pace Car is stopped and is now displayed just behind the Red Car at the Starting Line, (which is now flashing on-and-off). The Lap Counters still resi "Zero" and the Pace Car Lap Indicator shows six (6) laps to complete.

The Red "Joystick" is held to the right with the Motor Sound racing: the Line stops flashing and the race begins.

With the Red "Joystick" held to the right, the Red Car begins to move to the right, picking up speed as it heads for the turn. As the Red Car comes into the turn the "Joystick" must be moved upward. The Red Car now follows the Track upward. In the diagonal stretch of the Track, the "Joystick" must be moved up and to the left. This procedure is followed for each stretch of Track; i.e. the "Joystick" is moved in the direction that the Car is to be moved. When the Red Car crosses the Start/. Finish Line for the first lap, the Red Lap Counter advances to "1", and one black "Hash" Mark is subtracted for the Pace Car. This action continues for six (6 laps.




Figure 6




Figure 7

PLAY CONDITION CONTIDE

At the end of the sixth lap, if the Pace Car Finishes first, all action "Freezes" for several seconds with the Pace Car at the Finish Line; the Game is then Re-set to "Standby Condition".

If the Red Car reaches the Finish Line before the Pace Car, all action "Freezes" for several seconds, with the Red Car at the Finish Line; except in this instance, the Game is automatically transferred into Extended Play Mode; the action stants again and continues for approximately 15 seconds, at the end of which the game is Re-set to "Standby Condition".

During "Play Condition", as the Car is moved about the Track, if contact is made between the Car and the "Grass" (green area), the car is "Slowed Down" substantially. The car must be kept in the Black Track area to operate at "Maximum speed".

When several Cars are played, if contact is made between Cars, a Crash Sound is activated and the Cars are "Bumped" Apart.

Each of the four Cars has its own Motor Sound, slightly different from the other three. The PaceCar Motor Sound is activated only when the Red Car races (Single Player Mode).

PRICING AND ADJUSTMENTS:

"Pace Car Pro" is shipped with the following factory settings:

Pricing - One player per quarter

Pace Car - Six laps and Minimum Speed (2 1:2 minute race)

PRICING:

The Game is shipped with a "Coin Mechanisms, inc." - Single Coin Outster Rejector. The Coin Mechanism can be replaced by a Nickle, Dime or Fireign Coin Mechanism.

There are Two Pricing Options: One Player per Coin, or Two Players per Coin.

The pricing switch on the EG1000-D digital logic board is shown set for Two Players per Coin" (see Figure 8). By setting the Fricing Switch to the "Ing Player per Coin" position, Pricing is automatically changed.

Two Pricing Labels are supplied with the Game. One Player/Quarter and Two Players/Quarter. Tape the appropriate label in position behind the Front Fanel. (See Figure 7.)




Figure 8

ADJUSTMENTS:

Pace Car laps - The Pace Car may be set-up to complete Six (6) or Eight (8) laps. The Game is shipped set for Six (6) laps. To set for Eight (8) laps, the Pace Car Lap Switch on the IG!000-D Digital Logic Board must be switched to the "Fight" lap position. (See Figure 8.)

Note:

Refer to Figure 9 for the following adjustments. Study carefully before making adjustments so as not to adjust the wrong control.

<u>Pace Car Speed</u> - The Pace Car Speed is adjustable so that the Game duration can be changed between 1 and 2 1/2 minutes. The Game is shipped set for 2 1/2 minutes. Control VR24 on the EG1000-A Analog Logic Board changes Pace Car Speed.

Sound Output - The Game has two Sound Output Controls:

VR21 - Controls the Output of all Sounds

VR22 - Controls the Output of the Pace Car Sound - only

The following adjustments should be changed only if necessary, since they are factory set and adjustment should not be required.

Horizontal Size of Cars -

VR-13 - Red Car

VR-14 - Yellow Car

VR-15 - Violet Car

VR-16 - Blue Car

(Adjust so that car width is slightly less than its height.)

Shape of Cars -

VR-9 - Red Car

VR-10 - Yellow Car

VR-II - Violet Car

VR-12 - Blue Car


(Should be adjusted after horizontal size is set.)

Vertical Position of all Four Cars at "Standby" - VR-19

To Adjust - 1) "Joysticks" must be in vertical "rest" position.

2) "Joystick" amplifiers (all four) should be adjusted.

Adjust VR-19 so that all Four Cars are positioned in the center to the Track near the Starting Line.



EG 1000-A ANALOG LOGIC BOARD

Herizantal Position of all Four Cars at "Standby" - VR-20

- To Adjust It "Joysticks" must be in the vertical rest position.
 - 2) "Joystick" amplifiers (all four) should be adjusted.

Adjust \sqrt{R} -20 so that the Two Cars closest to the "Checkered" Start Line are 1/2 inch from the line.

Face Car Positioning in the Diagonal Section of Track - VR-23 Adjust VR-23 so that Pace Car travels thru center of diagonal section of Track. (This setting may be affected by adjustment of Pace Car Speed VR-24.)

Anglifier Adjustment - Refer to Figure 10 for the following. The "Joystick" Anglifier Adjustment is factory set and normally require readjustment only when the the EG1000-A Analog Board is changed, or if any of the "Joysticks" are replaced. There are two controls for each car. The controls adjust the voltage at the output of the "Joystick" Amplifiers. The purpose of the adjustment is to minimize drift of each car in the vertical and horizontal direction when the "Joystick" is in the upright "rest" position, and to standardize the speed of the cars. The adjustment is relatively simple, when using the "Joystick" Amp Adjustment Board, which is available from your distributor.

To Perform the adjustments:

- 1) All "Joysticks" must be in the upright "rest" position. "Snap" the "Joystick to return it to center "rest" position. The "Joysticks" should not be moved while making these adjustments.
- 2) Game power should be "On" Game in "Standby Condition."
- 3) Observing correct polarity, connect the Black and #1 Red clip leads to C173, 250 mfd capacitor as shown in Figure 10. All adjustments will be made with those leads connected.
- 4) Connect the #2 Red clip lead to the Positive (top) side of C4 (1 mfd capacitor). (See Figure 10.) Adjust VR-1 until the center LED indicator is illuminated.
- 5) Move #2 Red clip lead to Positive (top) side of C5 (1 mfd capacitor).
 Adjust VR-2 until the center LED indicator is illuminated.

The Red "Joystick" amp is now adjusted.

- 6) Move the "2 Red clip lead to Positive (top) side of C31 (1 mfd capacitor). Adjust VR-3 until center LED indicator is illuminated.
- 7) Repeat with C32 and VR-4 to finish adjustment for Yellow "Joystick" amp.
- 8) Repeat with C88 and VR-5, then C89 and VR-6 for Violet "Joystick" amp.
- 9) Repeat with Cl13 and VR-7, then Cl14 and VR-8 for Blue "Joystick" amp.

"Joystick" Amplifier Adjustment, Cont'd. -

This completes the "Joystick" Amplifier Adjustment.

Horizontal Ramp Adjustment - The horizontal ramp control (VR-17) adjusts the reak voltage of the horizontal ramp. This control is factory set and should not be readjusted since Game operation will be adversely affected. Refer to Service Manual for further information.

<u>Vertical Ramp Adjustment</u> - The vertical ramp control (VR-18) adjusts the peak coltage of the vertical ramp. <u>This control is factory set and should not be readjusted, since Game operation will be adversely affected</u>. Refer to Service Manual for further information.

Game Display Bias Control - This control is located on EG1000-D Digital Logic Board. (Refer to Figure 8.) Adjusts horizontal and vertical sync input to the TV input. Adjust for best picture.

Game Display Centering - This control is located on EG1000-D Digital Logic Board. (Refer to Figure 8.) Centers the picture on the TV horizontally.

<u>Color Adjustments</u> - The three adjustments on the color adjust p. c. module control the color intensity of the red, blue, and green guns of the color television CPT (Cathode Ray Tube). These adjustments are factory pre-set and should not normally require adjustment. When Adjustment is necessary, adjust each control for rest color.

Game - TV Switch - The "Game-TV" Switch (See Figure 12) which is mounted on the left side of the color television, when facing the unit, makes it possible to display standard TV programming in TV Position of the switch. This feature is helpful when trouble-shooting the system. It also simplifies servicing, since the television may be serviced as a standard receiver.

Power Supply Adjustments - The Power Supply Module has two adjustme: 5 mode control and 20 vdc control. These adjustments are factory pre-set and should not be changed, since Game operation will be adversely affected. Refer to Service Manual for further information.

<u>Color Television</u> - The color television used in "Pace Car Pro" is a Sylvania Midel CX4161W all solid state unit. Other than <u>Contrast</u> and <u>Brightness</u> (located at til rear of set), adjustments to the TV in "Game Mode" are ineffective. In TV Mode, the TV operates normally and all TV controls are operative.




Figure 10 Joystick Amplifier Adjustment







Figure 11


Figure 12



..







								14.50	58				CONTRACTOR AS A	83 1950
504009	PRATORIES INC.	HELEASED FOR PRODUCTION.	î.						DO 2721		·	9	623	
S OF 5	ARCH LABOI		(18E)	7450	7420	() () () () () () () () () ()	74161	24161	74161	7420	\$74107		989 989 	
-	UNIVERSAL RESEARCH LABORATORIES FIX GROVE VILLAGE, ILL. 80807			SZ Z	(7400)	2 74 20	7404	7404	27404	57420	\$7420	274107	7427 2485	
EG-IOCCD	,c_1			[] [] [] [] [] [] [] [] [] []		7252	(7420)	S 4	17420	7420	[7400]	7493	(7460	
		! !	्राष्ट्र	(1047)	[2022]	25 S	7430	[5047] [5047] [5047]	7402	(24	\\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\	7493	☐ 198 ·	
		8	<u>⟨₹</u> 2)	[]	7410	26.25	7420	2.7402	[7402]	7420 878	[740]	740.4		
			(18)	(036)	2014	[7415 [7416	7416	27427	0172	(74) (7400	27420		
		28		574153	[_249c_]	2446	54.5	7420	2420	\$ 741C	7420	27420	i	
			₹3€>	72153	06W 5	7430	74161	7430	21400	27400	1430 \7430	7400	3	SIDE
				70167	7490	\$7400	74191	7404	57410	2462	>740C	174 04		ENT
			<u> </u>	5.742.5	7490	\$7420 67	7402	S#2		57460]	7400	§ 74C6	92	COMPONENT
E				44 45 7404 1.1466	2740c)	7416 094086	27402	27400 0047 00400 00400	74 10	7464	2400	>74C €		
i i				1404 1404	74107	\$\frac{2}{3}\text{\$\frac{2}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}{3}\text{\$\frac{2}\text{\$\frac{2}\text{\$\frac{2}\text{\$\frac{2}{3}\text{\$\frac{2}\text{\$\frac{2}	\$74107	7427 10 R64	\$7400	27407	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	7406		
									13302 13302 13302					
			8	7400	7462 8		[*							
j					[<u>v</u> :	+++	<u>.</u>	- ~ - @ G	# # # B	987				

* RED SELECTED FET.

504014

UNIVERSAL RESEARCH LABORATORIES INC. ELK GROVE VILLAGE, ILL 60007

EG-1000D SHEET 2 OF 5

-0704011000		
RELEASED FOR PRODUCTION,		 50 50
CCMPGNENT SIDE	1 1 1 1 1 1 1 1 1 1	Color Col
7.17		

