

SECTION **HRN**  
**HORN**

A  
B  
C  
D  
E

**CONTENTS**

<b>PRECAUTION .....</b>	<b>2</b>	<b>HORN .....</b>	<b>3</b>
<b>PRECAUTION .....</b>	<b>2</b>	Wiring Diagram .....	3
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	2	<b>ON-VEHICLE REPAIR .....</b>	<b>6</b>
<b>COMPONENT DIAGNOSIS .....</b>	<b>3</b>	<b>HORN .....</b>	<b>6</b>
		Removal and Installation .....	6

F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

HRN

## PRECAUTION

< PRECAUTION >

# PRECAUTION

## PRECAUTION

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000003303112

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

# HORN

< COMPONENT DIAGNOSIS >


## COMPONENT DIAGNOSIS

### HORN

#### Wiring Diagram

INFOID:0000000003288945

-  : WITH POWER DOOR LOCK SYSTEM
-  : WITH VEHICLE SECURITY SYSTEM
-  : WITH DUAL NOTE HORN
-  : WITH SINGLE NOTE HORN



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION

HORN

AWLWA0115GE

# HORN


< COMPONENT DIAGNOSIS >

## HORN CONNECTORS


Connector No.	M30
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	BR	HORN



Connector No.	M102
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
19	Y	-

Terminal No.	Color of Wire	Signal Name
19	Y	-



Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-

Terminal No.	Color of Wire	Signal Name
1	B	-

Terminal No.	Color of Wire	Signal Name
9	BR	-



Terminal No.	Color of Wire	Signal Name
19	Y	-



Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-

Terminal No.	Color of Wire	Signal Name
9	BR	-



Terminal No.	Color of Wire	Signal Name
19	Y	-




# HORN


< COMPONENT DIAGNOSIS >

A

Connector No.	H-1
Connector Name	HORN RELAY
Connector Color	-








B

Connector No.	E162
Connector Name	HORN
Connector Color	BLACK









C

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE







D

E

F

G

H

I

K

HRN

M

N

O

P

AWLIA0406GB

# HORN

< ON-VEHICLE REPAIR >

## ON-VEHICLE REPAIR

### HORN


#### Removal and Installation

INFOID:000000003303111

##### Horn (Single)

###### Removal

1. Remove the front grille. Refer to [EXT-18, "Removal and Installation"](#).
2. Disconnect horn connectors.
3. Remove horn bolt and remove horn from vehicle.




###### Installation

Installation is in the reverse order of removal.

##### Horn (Dual)

###### Removal

1. Disconnect horn connector (2).
2. Remove horn bolt (1).
3. Remove horn.



###### Installation

Installation is in the reverse order of removal.