




# VGA12

## 1X2 VGA DISTRIBUTION AMPLIFIER INSTALLATION AND OPERATION MANUAL





## IMPORTANT SAFETY INFORMATION



1. Save the carton and packing material even if the equipment has arrived in good condition. Should you ever need to ship the unit, use only the original factory packing.
2. Read all documentation before operating your equipment. Retain all documentation for future reference.
3. Follow all instructions printed on unit chassis for proper operation.
4. Do not spill water or other liquids into or on the unit, or operate the unit while standing in liquid.
5. Make sure power outlets conform to the power requirements listed on the back of the unit.
6. Do not use the unit if the electrical power cord is frayed or broken. The power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords and plugs, convenience receptacles, and the point where they exit from the appliance.
7. Always operate the unit with the AC ground wire connected to the electrical system ground. Precautions should be taken so that the means of grounding of a piece of equipment is not defeated.
8. Mains voltage must be correct and the same as that printed on the rear of the unit. Damage caused by connection to improper AC voltage is not covered by any warranty.
9. Have gain controls on amplifiers turned down during power-up to prevent speaker damage if there are high signal levels at the inputs.
10. Power down & disconnect units from mains voltage before making connections.
11. Never hold a power switch in the "ON" position if it won't stay there itself!
12. Do not use the unit near stoves, heat registers, radiators, or other heat producing devices.
13. Do not block fan intake or exhaust ports. Do not operate equipment on a surface or in an environment which may impede the normal flow of air around the unit, such as a bed, rug, weathersheet, carpet, or completely enclosed rack. If the unit is used in an extremely dusty or smoky environment, the unit should be periodically "blown free" of foreign matter.
14. Do not remove the cover. Removing the cover will expose you to potentially dangerous voltages. There are no user serviceable parts inside.
15. Do not drive the inputs with a signal level greater than that required to drive equipment to full output.
16. Do not connect the inputs / outputs of amplifiers or consoles to any other voltage source, such as a battery, mains source, or power supply, regardless of whether the amplifier or console is turned on or off.
17. Do not run the output of any amplifier channel back into another channel's input. Do not parallel- or series-connect an amplifier output with any other amplifier output. Australian Monitor Inc is not responsible for damage to loudspeakers for any reason.
18. Do not ground any red ("hot") terminal. Never connect a "hot" (red) output to ground or to another "hot" (red) output!
19. Non-use periods. The power cord of equipment should be unplugged from the outlet when left unused for a long period of time.
20. Service Information Equipment should be serviced by qualified service personnel when:
  - A. The power supply cord or the plug has been damaged.
  - B. Objects have fallen, or liquid has been spilled into the equipment
  - C. The equipment has been exposed to rain
  - D. The equipment does not appear to operate normally, or exhibits a marked change in performance
  - E. The equipment has been dropped, or the enclosure damaged.

THIS SAFETY INFORMATION IS OF A GENERAL NATURE AND MAY BE SUPERSEDED BY INSTRUCTIONS CONTAINED WITHIN THIS MANUAL



# INTRODUCTION AND CONTENTS

The AMAV VGA12 is a two output VGA distribution amplifier supporting resolutions of up to 2048x2048. Designed for the demanding commercial audio-visual market, the VGA12 provides video distribution in an elegant, slim line package. The VGA12 provides one VGA video input and two VGA video outputs, all featuring 15 pin high density D connectors. The VGA12 offers the flexibility and features demanded by any quality AV application.

INTRODUCTION	3
FRONT PANEL	4
REAR PANEL	5
OPERATIONS	6
SPECIFICATIONS	7

AUS, EUR, USA  
Copyright 23 Feb 2007



**CAUTION**  
RISK OF ELECTRIC SHOCK  
DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,  
DO NOT REMOVE COVER (OR BACK),  
NO USER SERVICEABLE PARTS INSIDE,  
REFER SERVICING TO QUALIFIED SERVICE PERSONAL.



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the products enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operational and maintenance (servicing) instructions in the literature accompanying the appliance.

Caution: To prevent electric shock do not use this (polarised) plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure. To prevent electric shock, match wide blade of plug to wide slot, fully insert.

## WARNING!

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK  
DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

# FRONT PANEL

## FRONT PANEL




1

### 1 POWER ON SWITCH

This power switch turns the unit on and off. The inbuilt LED will illuminate red to indicate that the switcher is ON and is receiving power

## REAR PANEL



### 1 VIDEO INPUT CONNECTOR

One video source input is provided, featuring:

- One VGA video input on a single 15 pin high density D connector

### 2 VIDEO OUTPUT CONNECTORS

Two video outputs are provided, each featuring:

- One VGA video output on a single 15 pin high density D connector

### 3 DC POWER INLET

The VGA12 switcher is fitted with a DC power plug-pack input connector. Please ensure that the plug-pack used is of an approved type and is of sufficient current carrying capacity with the correct voltage and connector polarity  $\ominus$   $\bullet$   $\oplus$

# OPERATION

Before making any connections to the VGA12, observe the following:

- > Ensure the mains voltage supply matches the label on the supplied plug-pack (+/- 10%)
- > Ensure that the power switch is OFF
- > Ensure that all system grounds (earth) are connected to a common point. Avoid powering equipment within a system from multiple power sources that may be separated by large distances

## OPERATION

- > Connect all video sources and destination equipment
- > Power up the VGA12 video distribution amplifier
- > Power up all source and destination audio-visual sources

# SPECIFICATIONS

VIDEO INPUTS	1x RGBHV, HD-15pin connector
VIDEO OUTPUTS	2x RGBHV, HD-15pin connectors
VIDEO BANDWIDTH	>1GHz (+/-0.5dB)
MAXIMUM VIDEO RESOLUTION	2048 x 2048
POWER	+12V DC, centre +ve, outer -ve, 150mA Max
DIMENSIONS H X W X D	25mm x 176mm x 80mm
SHIPPING DIMENSIONS H X W X D	75mm x 253mm x 160mm
SHIPPING WEIGHT	0.8 kg

## AUSTRALIA AND NEW ZEALAND

[www.australianmonitor.com.au](http://www.australianmonitor.com.au)

### SYDNEY

(NSW & ACT SALES)

1 Clyde Street  
Silverwater  
NSW 2128  
Private Bag 149  
Silverwater NSW 1811  
Phone: (02) 9647 1411  
Fax: (02) 9648 3698  
Email:  
[nsw@audiotelex.com.au](mailto:nsw@audiotelex.com.au)

### MELBOURNE

(VIC & TAS SALES)

22/277  
Middleborough Road  
Box Hill VIC 3128  
PO Box 151 Blackburn  
South VIC 3130  
Phone: (03) 9890 7477  
Fax: (03) 9890 7977  
Email:  
[vic@audiotelex.com.au](mailto:vic@audiotelex.com.au)

### BRISBANE

(QLD SALES)

42 Commercial Road  
Fortitude Valley  
QLD 4006  
PO Box 871 Fortitude  
Valley QLD 4006  
Phone: (07) 3852 1312  
Fax: (07) 3252 1237  
Email:  
[qld@audiotelex.com.au](mailto:qld@audiotelex.com.au)

### ADELAIDE

(SA & NT SALES)

31 Walsh Street  
Thebarton  
SA 5031  
PO Box 157  
Hindmarsh SA 5007  
Phone: (08) 8352 4444  
Fax: (08) 8352 4488  
Email:  
[sa@audiotelex.com.au](mailto:sa@audiotelex.com.au)

### PERTH

(WA SALES)

3/11 Howe Street  
Osborne Park WA 6017  
PO Box 1281  
Osborne Park  
BC WA 6916  
Phone: (08) 9204 0200  
Fax: (08) 9244 3738  
Email:  
[wa@audiotelex.com.au](mailto:wa@audiotelex.com.au)

### AUCKLAND

(NZ SALES)

9C Piermark Drive  
Albany 0752  
New Zealand  
PO Box 300-512  
Albany 0752  
Phone: (09) 415 9426  
Fax: (09) 415 9864  
Email:  
[sales@audiotelex.co.nz](mailto:sales@audiotelex.co.nz)

## EUROPE / ASIA / MIDDLE EAST

[www.australianmonitor.com.au](http://www.australianmonitor.com.au)

### INTERNATIONAL SALES

1 Clyde Street Silverwater NSW 2128 Australia  
Private Bag 149 Silverwater NSW 1811  
Phone: (02) 9647 1411  
Fax: (02) 9648 3698  
Email: [international@audiotelex.com.au](mailto:international@audiotelex.com.au)

## USA / SOUTH AMERICA

[www.australianmonitor.com](http://www.australianmonitor.com)

### SENNHEISER ELECTRONIC CORPORATION

1 Enterprise Drive  
Old Lyme CT 06371 USA  
Phone: 1 860 434 9190  
Fax: 1 860 434 1759  
Email: [jalexander@sennheiserusa.com](mailto:jalexander@sennheiserusa.com)