

**Lucent Technologies**  
Bell Labs Innovations



***CentreVu*<sup>®</sup> Call Management System**  
Release 3 Version 8  
Software Installation and Setup

585-210-941  
Comcode 108502360  
Issue 1  
December 1999

## Notice

Every effort was made to ensure that the information in this document was complete and accurate at the time of printing. However, information is subject to change.

## Your Responsibility for Your System's Security

Toll fraud is the unauthorized use of your telecommunications system by an unauthorized party, for example, persons other than your company's employees, agents, subcontractors, or persons working on your company's behalf. Note that there may be a risk of toll fraud associated with your telecommunications system and, if toll fraud occurs, it can result in substantial additional charges for your telecommunications services.

You and your system manager are responsible for the security of your system, such as programming and configuring your equipment to prevent unauthorized use. The system manager is also responsible for reading all installation, instruction, and system administration documents provided with this product in order to fully understand the features that can introduce risk of toll fraud and the steps that can be taken to reduce that risk. Lucent Technologies does not warrant that this product is immune from or will prevent unauthorized use of common-carrier telecommunication services or facilities accessed through or connected to it. Lucent Technologies will not be responsible for any charges that result from such unauthorized use.

## Lucent Technologies Fraud Intervention

If you *suspect that you are being victimized* by toll fraud and you need technical support or assistance, call Technical Service Center Toll Fraud Intervention Hotline at 1-800-643-2353.

## Canadian Department of Communications (DOC) Interference Information

This digital apparatus does not exceed the Class A limits for radio noise emissions set out in the radio interference regulations of the Canadian Department of Communications.

Le Présent Appareil Numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la class A prescrites dans le règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

## Trademarks

*CentreVu* and *DEFINITY* are registered trademarks of Lucent Technologies.

*3M* is a registered trademark of Minnesota Mining and Manufacturing.

*Enterprise*, *OpenWindows*, *Sun*, *Sun Microsystems*, *SunOS*, the *Sun* logo, the *SMCC* logo, *SunLink*, *SunSelect*, *Solaris*, *Solstice*, *Solstice DiskSuite*, *XGL*, and *Ultra* are trademarks or registered trademarks of Sun Microsystems, Inc.

*Exatape* is a trademark of Exabyte Corporation.

*INFORMIX* is a registered trademark of Informix Software, Inc.

*Maxell* is a registered trademark of Maxell, Inc.

*Motif* is a registered trademark of Open Software Foundation, Inc.

*OPEN LOOK* is a registered trademark of Novell, Inc.

*Sony* is a registered trademark of Sony Corporation.

*SPARC* trademarks, including the *SCD Compliant* Logo, are trademarks or registered trademarks of SPARC International, Inc. *SPARCstation*, *SPARCstorage*, *SPARCserver*, *SPARCengine*, *SPARCworks*, and *SPARCcompiler* are licensed exclusively to Sun Microsystems, Inc. Products bearing *SPARC* trademarks are based upon an architecture developed by Sun Microsystems, Inc.

*UNIX* is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

*XWindows* is a trademark of The Open Group.

All other product names mentioned herein are the trademarks of their respective owners.

## Ordering Information

**Call:** Lucent Technologies Publications Center  
Voice: 1-800-457-1235  
International Voice: +1-317-361-5353  
Fax: 1-800-457-1764  
International Fax: +1-317-361-5355

**Write:** Lucent Technologies Publications Center  
P.O. Box 4100  
Crawfordsville, IN 47933  
U.S.A.

**Order:** *CentreVu* CMS Software Installation and Setup  
Document No.585-210-941  
Comcode 108502360  
Issue 1, December 1999

For additional documents, refer to the section entitled "Related Documents" in the Preface.

You can be placed on a Standing Order list for this and other documents you may need. Standing Order will enable you to automatically receive updated versions of individual documents or document sets, billed to account information that you provide. For more information on Standing Orders, or to be put on a list to receive future issues of this document, please contact the Lucent Technologies Publications Center.

## Lucent Technologies National Customer Care Center

Lucent Technologies provides a telephone number for you to use to report problems or to ask questions about your call center. The support telephone number is 1-800-242-2121.

## Document Support Telephone Number

Lucent Technologies provides telephone numbers for you to use to report errors or to ask questions about the information in this document. The support telephone numbers are:

Voice: 1-888-584-6366 and  
International Voice: +1-317-322-6848.

## European Union Declaration of Conformity

Lucent Technologies Business Communications Systems declares that the equipment specified in this document conforms to the referenced European Union (EU) Directives and Harmonized Standards listed below:

EMC Directive 89/336/EEC  
Low Voltage Directive 73/23/EEC



The "CE" mark affixed to the equipment means that it conforms to the above Directives.

## Heritage Statement

Lucent Technologies—formed as a result of AT&T's planned restructuring—designs, builds, and delivers a wide range of public and private networks, communication systems and software, consumer and business telephone systems, and microelectronics components. The world-renowned Bell Laboratories is the research and development arm for the company.

## Comments

To comment on this document, return the comment card at the front of the document.

## Acknowledgment

This document was developed by the Lucent Technologies Information Development Organization for Global Learning Solutions.

# CentreVu® Call Management System R3V8 Software Installation and Setup

## Table of Contents

Preface . . . . .	P-1
Overview . . . . .	P-1
Reasons for Reissue . . . . .	P-1
Organization. . . . .	P-1
Conventions. . . . .	P-2
Related Documents . . . . .	P-2
1 Introduction . . . . .	1-1
Overview . . . . .	1-1
Supported Hardware Platforms . . . . .	1-1
Required and Optional Software . . . . .	1-1
Roles and Responsibilities . . . . .	1-3
CentreVu CMS Helplines. . . . .	1-5
Customer Support for U.S. and Canada . . . . .	1-5
Customer and Technician Support Outside of U.S. and Canada . . . . .	1-5
Technician Support for U.S. and Canada . . . . .	1-5
International Support . . . . .	1-5
2 Installing Software and Setting Up CMS . . . . .	2-1
Overview . . . . .	2-1
Summary of Procedures . . . . .	2-1
Remote Terminal Access Tips . . . . .	2-3
Prerequisites . . . . .	2-3
Installing the Solaris Operating System . . . . .	2-4
Overview . . . . .	2-4
Platform Considerations . . . . .	2-4
Before You Begin. . . . .	2-5
Booting from the Solaris 7 Software 3/99 CD . . . . .	2-5
Identifying the System . . . . .	2-7
Setting the Date and Time . . . . .	2-12
Selecting the Solaris 7 System Files . . . . .	2-14
Partitioning the Hard Disks . . . . .	2-18
Installing the Selected Options . . . . .	2-29
Assigning a Root Password . . . . .	2-31

Opening a Terminal Window . . . . .	2-32
Enabling Korn Shell and the Backspace Key. . . . .	2-33
Displaying and Setting the EEPROM Parameters . . . . .	2-33
Turning On the System Activity Recorder. . . . .	2-36
<b>Installing the Sun Online VTS 3.1 . . . . .</b>	<b>2-38</b>
Overview . . . . .	2-38
Platform Considerations . . . . .	2-38
Prerequisites . . . . .	2-38
Procedure. . . . .	2-38
<b>Installing Link and Port Packages. . . . .</b>	<b>2-40</b>
<b>Installing the SunLink HSI/S Software . . . . .</b>	<b>2-40</b>
Overview . . . . .	2-40
Platform Considerations. . . . .	2-40
Prerequisites . . . . .	2-40
Procedure. . . . .	2-40
<b>Installing the HSI/P Software . . . . .</b>	<b>2-42</b>
Overview . . . . .	2-42
Platform Considerations . . . . .	2-42
Prerequisites . . . . .	2-42
Procedure. . . . .	2-43
<b>Installing the SAI/P Adapter Drivers . . . . .</b>	<b>2-45</b>
Overview . . . . .	2-45
Platform Considerations . . . . .	2-45
Prerequisites . . . . .	2-45
Procedure. . . . .	2-45
<b>Installing the Aurora Port Drivers . . . . .</b>	<b>2-47</b>
Overview . . . . .	2-47
Platform Considerations. . . . .	2-47
Prerequisites . . . . .	2-47
Procedure. . . . .	2-47
<b>Installing the Bay Networks Annex NTS Drivers . . . . .</b>	<b>2-51</b>
Overview . . . . .	2-51
Platform Considerations. . . . .	2-51
Prerequisites . . . . .	2-51
Procedure. . . . .	2-51
<b>Setting Up the NTS Start-Up Files . . . . .</b>	<b>2-56</b>
<b>Installing the Solstice for Server Connect X.25 Package . . . . .</b>	<b>2-57</b>
Overview . . . . .	2-57
Platform Considerations. . . . .	2-57
Prerequisites . . . . .	2-57
Retrieving System Information . . . . .	2-58
Installing the Solstice for Server Connect X.25 Drivers . . . . .	2-58
Setting Up the X.25 License . . . . .	2-63
<b>Installing INFORMIX . . . . .</b>	<b>2-67</b>
Overview . . . . .	2-67
Platform Considerations . . . . .	2-67
Prerequisites . . . . .	2-67
Setting Up the INFORMIX Environment . . . . .	2-68
Installing the INFORMIX SQL 7.20 Package (Optional) . . . . .	2-68
Installing the INFORMIX SE 7.22 Package (Required) . . . . .	2-71
Installing the INFORMIX Runtime ESQ 9.14 Package (Required) . . . . .	2-73

Installing the INFORMIX ILS 2.11 Package (Required) . . . . .	2-76
Installing DiskSuite . . . . .	2-84
Installing the Solstice DiskSuite Software . . . . .	2-84
Overview . . . . .	2-84
Platform Considerations . . . . .	2-84
Prerequisites . . . . .	2-84
Procedure . . . . .	2-84
Installing the Sun Solaris Patches . . . . .	2-86
Overview . . . . .	2-86
Platform Considerations . . . . .	2-86
Prerequisites . . . . .	2-86
Procedure . . . . .	2-86
Changing Directory Permissions . . . . .	2-87
Setting Up Solstice DiskSuite. . . . .	2-88
Overview . . . . .	2-88
Platform Considerations . . . . .	2-88
Prerequisites . . . . .	2-88
Configuring DiskSuite on an unmirrored system . . . . .	2-88
Configuring DiskSuite on a mirrored system . . . . .	2-93
Checking for Disk Recognition Errors . . . . .	2-95
Installing CMS Packages. . . . .	2-103
Installing the CMS Supplemental Services Software . . . . .	2-103
Overview . . . . .	2-103
Platform Considerations . . . . .	2-103
Prerequisites . . . . .	2-103
Procedure . . . . .	2-103
Installing the CMS Software . . . . .	2-105
Overview . . . . .	2-105
Platform Considerations . . . . .	2-105
Prerequisites . . . . .	2-105
Procedure . . . . .	2-105
Installing the CMS Patches . . . . .	2-108
Overview . . . . .	2-108
Platform Considerations . . . . .	2-109
Prerequisites . . . . .	2-109
Procedure . . . . .	2-109
Installing the Open Database Connectivity Software . . . . .	2-111
Overview . . . . .	2-111
Platform Considerations . . . . .	2-111
Prerequisites . . . . .	2-111
Procedure . . . . .	2-111
Installing Visual Vectors Server Software . . . . .	2-115
Overview . . . . .	2-115
Platform Considerations . . . . .	2-115
Prerequisites . . . . .	2-115
Procedure . . . . .	2-115
Starting Visual Vectors Server Software . . . . .	2-116
Setting Up CMS. . . . .	2-117
Overview . . . . .	2-117

Platform Considerations . . . . .	2-117
Conventions . . . . .	2-117
Prerequisites . . . . .	2-117
Setting Authorizations . . . . .	2-118
Overview . . . . .	2-118
Procedure . . . . .	2-119
Setting Up Data Storage Parameters . . . . .	2-124
Overview . . . . .	2-124
Procedure . . . . .	2-124
Setting Up a LAN for Switch Connections . . . . .	2-127
Overview . . . . .	2-127
Prerequisites . . . . .	2-127
Sample Configurations . . . . .	2-128
Remote Switch Network . . . . .	2-130
High Availability Configuration . . . . .	2-131
Procedures . . . . .	2-131
Setting Up the CMS Application . . . . .	2-134
Overview . . . . .	2-134
Prerequisites . . . . .	2-134
Setup Methods . . . . .	2-135
Installing Feature Packages. . . . .	2-157
Installing the Forecasting Package . . . . .	2-157
Overview . . . . .	2-157
Prerequisites . . . . .	2-157
Procedure . . . . .	2-157
Installing the External Call History Package . . . . .	2-161
Overview . . . . .	2-161
Prerequisites . . . . .	2-161
Procedure . . . . .	2-162
Setting Up the Remote Console . . . . .	2-167
Overview . . . . .	2-167
Platform Considerations . . . . .	2-167
Administering the Remote Console Port . . . . .	2-167
Using the Remote Console Port . . . . .	2-168
Setting Up the NTS . . . . .	2-171
Overview . . . . .	2-171
Platform Considerations . . . . .	2-171
Prerequisites . . . . .	2-172
Procedure . . . . .	2-172
Creating an Alternate Boot Device . . . . .	2-179
Performing a CMSADM Backup . . . . .	2-181
Overview . . . . .	2-181
Platform Considerations . . . . .	2-182
Prerequisites . . . . .	2-182
Procedure . . . . .	2-183
<b>3 Turning the System Over to the Customer . . . . .</b>	<b>3-1</b>
Overview . . . . .	3-1

	Verifying the System Date and Time . . . . .	3-2
	Overview . . . . .	3-2
	Checking the Solaris System Date and Time . . . . .	3-2
	Setting the System Date and Time . . . . .	3-2
	Setting the System Country and Time Zones . . . . .	3-4
	Testing the Connection to the TSC or COE . . . . .	3-5
	Overview . . . . .	3-5
	Testing the Remote Access Port . . . . .	3-5
	Redirecting the Console to the Remote Console . . . . .	3-6
	Redirecting the Console Back to the Local Console . . . . .	3-8
	Testing the ACD Link . . . . .	3-9
	Overview . . . . .	3-9
	Prerequisites . . . . .	3-9
	Procedure . . . . .	3-9
	Testing the CMS Software . . . . .	3-10
	Overview . . . . .	3-10
	Prerequisites . . . . .	3-10
	Procedure . . . . .	3-10
	Assigning Customer Passwords . . . . .	3-14
	Overview . . . . .	3-14
	Procedure . . . . .	3-14
	Turning the System Over to the Customer . . . . .	3-15
	Overview . . . . .	3-15
	Procedure . . . . .	3-15
4	Maintaining the CMS Software . . . . .	4-1
	Overview . . . . .	4-1
	Remote Terminal Tip. . . . .	4-1
	Backing Up the CMS System . . . . .	4-2
	Overview . . . . .	4-2
	Performing a CMSADM Backup . . . . .	4-3
	Overview . . . . .	4-3
	Platform Considerations . . . . .	4-4
	Prerequisites . . . . .	4-4
	Procedure . . . . .	4-5
	Checking the Contents of the CMSADM Backup Tape. . . . .	4-9
	Procedure. . . . .	4-9
	Doing CMS Maintenance Backups . . . . .	4-10
	Adding the Informix SQL Package . . . . .	4-11
	Procedure . . . . .	4-11
5	Solving Installation-Related Problems . . . . .	5-1
	Overview . . . . .	5-1
	Troubleshooting a Solstice DiskSuite Software Installation . . . . .	5-2
	Identifying Problems . . . . .	5-2

Problems with CMS Administration Scripts. . . . .	5-3
Disk I/O Problems . . . . .	5-3
State Database Problems. . . . .	5-3
Metadevice Problems . . . . .	5-4
Problems with the /cms File System . . . . .	5-5
Common Error Messages . . . . .	5-7
Listing Pkgchk Errors. . . . .	5-10
Solving X.25 License Installation Problems . . . . .	5-11
Finding a Misplaced X.25 Password . . . . .	5-12
Checking Installed Solaris Patches . . . . .	5-12
Recognizing New Hardware Devices. . . . .	5-13
Glossary . . . . .	GL-1
Index . . . . .	IN-1

# Preface

## Overview

This document is written for technicians and Lucent Technologies call center customers who install and maintain Release 3, Version 8 of the *CentreVu* Call Management System (CMS) using the *Solaris*\* 7 operating system.

## Reasons for Reissue

This is the first issue of this document.

## Organization

This document includes the following chapters:

- **Chapter 1 — [Introduction](#)**  
Provides an overview of the supported CMS software, supported hardware platforms and required software.
- **Chapter 2 — [Installing Software and Setting Up CMS](#)**  
Outlines the software installation and setup procedures. These procedures are used by technicians at customer sites and personnel at the factory.
- **Chapter 3 — [Turning the System Over to the Customer](#)**  
Provides the procedures that a technician performs before system cutover and a worksheet that the technician fills out for the customer.
- **Chapter 4— [Maintaining the CMS Software](#)**  
Discusses file system backups and other maintenance procedures.
- **Chapter 5— [Solving Installation-Related Problems](#)**  
Discusses how to fix various software installation problems.

---

\**Solaris* is a registered trademark of Sun Microsystems, Inc.

## Conventions

The following conventions are used in this document:

- Unless specified otherwise, all information and procedures in this document apply to the *Sun SPARCserver* computers, the *Sun Ultra 5* computer, the *Sun Enterprise 3000* computer and the *Sun Enterprise 3500* computer.
- The term “CMS” in this document always implies “*CentreVu CMS*.”
- Commands you enter from the console are shown in `courier` font.
- Screens are shown to represent responses from the system. Because of display constraints in this document, some screen representations are not identical to the screens on your system.
- *Italic* text in screen displays represents variable information.
- Automatic Call Distribution (ACD) is a feature on the *DEFINITY* switch. The ACD feature is used to route incoming calls to groups of agents. When this document refers to “connecting to an ACD,” it refers to connecting to a switch that has ACD capabilities.

## Related Documents

The document set that supports the different CMS computers and the *DEFINITY* switches is being reorganized with this release. This section lists where you can find specific information about CMS. To order any of these documents, call the BCS Publications Center at 1-800-457-1235 or +1-317-361-5353.

Title	Document Number
<b>Installing CMS Computers</b>	
<i>CentreVu® Call Management System Sun® Enterprise™ 3500 Computer Hardware Installation</i>	585-215-873
<i>CentreVu® Call Management System Sun® Enterprise™ 3500 Computer Connectivity Diagram</i>	585-215-877
<i>CentreVu® Call Management System Sun® Ultra™ 5 Computer Hardware Installation</i>	585-215-871

Title	Document Number
<i>CentreVu® Call Management System Sun® Ultra™ 5 Computer Connectivity Diagram</i>	585-215-872
<i>CentreVu® Call Management System Release 3 Version 6 Sun® Enterprise™ 3000 Computer Hardware Installation</i>	585-215-867
<i>CentreVu® Call Management System Release 3 Version 6 Sun® Enterprise™ 3000 Computer Connectivity Diagram</i>	585-215-865
<i>CentreVu® Call Management System Release 3 Version 6 Sun® SPARCserver™ Computers Hardware Installation</i>	585-215-857
<i>CentreVu® Call Management System Release 3 Version 6 Sun® SPARCserver™ Computers Connectivity Diagram</i>	585-215-858
<i>CentreVu® Call Management System Release 3 Version 5 Sun® SPARCserver™ Installation and Maintenance</i>	585-215-827
<i>CentreVu® Call Management System Release 3 Version 5 Sun® SPARCserver™ Connectivity Diagram</i>	585-215-828
<b>Connecting and Administering the Switch</b>	
<i>CentreVu® Call Management System Switch Connections and Administration</i>	585-215-876
<b>Installing and Setting Up Terminals, Printers, and Modems</b>	
<i>CentreVu® Call Management System Terminals, Printers, and Modems</i>	585-215-874
<b>Maintaining and Troubleshooting a CMS Computer</b>	
<i>CentreVu® Call Management System Release 3 Version 8 Hardware Maintenance and Troubleshooting</i>	585-210-919
<i>CentreVu® Call Management System Sun® Enterprise™ 3500 Computer Maintenance and Troubleshooting</i>	585-215-875
<b>Upgrading a CMS Computer</b>	
<i>CentreVu® Call Management System Release 3 Version 8 Upgrades and Migrations</i>	585-210-913
<b>Administering a CMS Computer</b>	
<i>CentreVu® Call Management System Release 3 Version 8 Administration (Volumes 1 and 2)</i>	585-210-910
<i>CentreVu® Call Management System Release 3 Version 6 Administration (Volumes 1 and 2)</i>	585-215-850

Title	Document Number
<i>CentreVu® Call Management System Release 3 Version 5 Administration (Volumes 1 and 2)</i>	585-215-820
<b>Other Documents</b>	
<i>CentreVu® Call Management System Release 3 Version 8 Open Database Connectivity</i>	585-210-911
<i>CentreVu® Call Management System Release 3 Version 6 Open Database Connectivity</i>	585-215-852
<i>CentreVu® Call Management System Release 3 Version 8 External Call History Interface</i>	585-210-912
<i>CentreVu® Call Management System Release 3 Version 6 External Call History Interface</i>	585-215-854
<i>CentreVu® Call Management System Release 3 Version 6 Planning, Configuration, and Implementation</i>	585-215-879
<i>CentreVu® Call Management System Release 3 Version 5 Real-Time and Historical Reports</i>	585-215-821
<i>CentreVu® Call Management System Release 3 Version 5 External Call History Interface</i>	585-215-824
<i>CentreVu® Call Management System Release 3 Version 5 Open Database Connectivity</i>	585-215-839
<i>CentreVu® Call Management System Release 3 Version 5 Custom Reports</i>	585-215-822
<i>CentreVu® Call Management System Release 3 Version 5 Forecast</i>	585-215-825
<i>Lucent Call Center Release 8 Change Description</i>	585-210-925
<i>Lucent Call Center Release 8 Documentation CD-ROM</i>	585-210-926

# Introduction

## Overview

*CentreVu*® Call Management System (CMS) is a software application offered in association with the Automatic Call Distribution (ACD) feature of Lucent Technologies *DEFINITY*® switches. The CMS application provides monitoring and recording of ACD calls and agents handling these calls, and the use of Vector Directory Numbers (VDNs) for these calls to measure Call Center performance.

## Supported Hardware Platforms

CMS is supported on the following platforms:

- *Sun*\* *SPARCserver*† 5 computer
- *Sun* *SPARCserver* 10 computer
- *Sun* *SPARCserver* 20 computer
- *Sun* *Ultra*‡ 5 computer
- *Sun* *Enterprise*§ 3000 computer
- *Sun* *Enterprise* 3500 computer

## Required and Optional Software

CMS requires the following software packages (optional packages are noted):

- *Sun Solaris*¶ 7 operating system (Hardware: 3/99 version)
- Sun Validation Test Suite (VTS) 3.1
- High-Speed Serial Interface/Sbus (HSI/S) (optional, required for *Sun* *SPARCserver* or *Enterprise* systems that have an HSI/S card)
- High-Speed Serial Interface/PCI (HSI/P) (optional, required for *Sun* *Ultra* 5 systems that have an HSI/P card)
- Serial Asynchronous Interface/PCI (SAI/P) drivers (optional, required for *Sun* *Ultra* 5 systems that have an SAI/P card)
- Aurora Ports Card drivers (optional, *SPARCserver* only)

---

\**Sun* is a registered trademark of Sun Microsystems, Inc.

†*SPARCserver* is a trademark of SPARC International, Inc.

‡*Ultra* is a trademark of Sun Microsystems, Inc.

§*Enterprise* is a trademark of Sun Microsystems, Inc.

¶*Solaris* is a registered trademark of Sun Microsystems, Inc.

- Bay Networks Annex R10.0B (optional, required for systems using *Network Terminal Server*\* [NTS])
- *Solstice*† for Server Connect X.25 Version 9.1 drivers (optional, required for systems using an X.25 link to a switch)
- *INFORMIX*‡
  - Structured Query Language (SQL) 7.20 (optional)
  - Standard Engine (SE) 7.22
  - Runtime Enhanced SQL (ESQL) 9.14
  - International Language Supplement (ILS) 2.11
- *Solstice DiskSuite*§ 4.2 (contained on the Solaris Easy Access Server 2.0 CD)
- *Sun Solaris* patches
- CMS Supplemental Services
- CMS software
- CMS patches
- CMS Open Database Connectivity (ODBC) (optional)
- Visual Vectors Server software

---

\**Network Terminal Server* is a trademark of Sun Microsystems, Inc.

†*Solstice* is a trademark of Sun Microsystems, Inc.

‡*INFORMIX* is a registered trademark of Informix Software, Inc.

§*Solstice DiskSuite* is a trademark of Sun Microsystems, Inc.

## Roles and Responsibilities

This document is written for:

- Lucent Technologies on-site technicians
- Lucent Technologies Technical Service Center (TSC) personnel
- Lucent Technologies factory personnel
- CMS customer administrators.

The following table lists the major software installation tasks, who is responsible for performing each task, and the chapter where the task is described.

Task	On-Site Tech	TSC	Factory	Customer
<b>Chapter 2 — <a href="#">Installing Software and Setting Up CMS</a></b>				
<a href="#">“Installing the Solaris Operating System” on page 2-4</a>	X	X	X	
<a href="#">“Installing the Sun Online VTS 3.1” on page 2-38</a>	X	X	X	
<a href="#">“Installing Link and Port Packages” on page 2-40</a>	X	X	X	
<a href="#">“Installing INFORMIX” on page 2-67</a>	X	X	X	
<a href="#">“Installing DiskSuite” on page 2-84</a>	X	X	X	
<a href="#">“Installing CMS Packages” on page 2-103</a>	X	X	X	X (limited)
<a href="#">“Installing the Open Database Connectivity Software” on page 2-111</a>		X	X	
<a href="#">“Installing Visual Vectors Server Software” on page 2-115</a>	X	X	X	
<a href="#">“Setting Up CMS” on page 2-117</a>		X		
<a href="#">“Installing Feature Packages” on page 2-157</a>	X	X	X	
<a href="#">“Setting Up the Remote Console” on page 2-167</a>	X		X	
<a href="#">“Setting Up the NTS” on page 2-171</a>	X		X	
<a href="#">“Performing a CMSADM Backup” on page 2-181</a>				
<b>Chapter 3 — <a href="#">Turning the System Over to the Customer</a></b>				
Verifying the system date and time	X			
Testing the connection to the TSC		X		

Task	On-Site Tech	TSC	Factory	Customer
Testing the ACD link	X			
Testing the CMS software	X			
Assigning customer passwords				X
Turning the system over to the customer	X			
<b>Chapter 4 — <a href="#">Maintaining the CMS Software</a></b>				
Backing up the system	X			X
Restoring the system	X	X		X
Removing <i>INFORMIX</i> to add SQL	X	X		
<b>Chapter 5 — <a href="#">Solving Installation-Related Problems</a></b>				
Solving installation-related problems	X	X		

---

## CentreVu CMS Helplines

If an installation problem arises that requires assistance, customers or Lucent Technologies technicians may call the numbers shown below.

---

### Customer Support for U.S. and Canada

**1-800-242-2121**

By calling this number, the customer reports the problem and generates a trouble ticket so that the problem can be worked by the services organization.

The customer is prompted to identify the type of problem (ACD, hardware, or *CentreVu* CMS) and is connected to the appropriate service organization.

---

### Customer and Technician Support Outside of U.S. and Canada

For customer and technician support outside of the U.S. and Canada, contact your Lucent Technologies representative or distributor for more information.

---

### Technician Support for U.S. and Canada

**1-800-248-1234**

Lucent Technologies technicians can receive help during installations by using this number.

---

### International Support

For international support, contact your Lucent Technologies representative or distributor for more information.



# Installing Software and Setting Up CMS

## Overview

This chapter contains the procedures used to install and set up the *CentreVu*® Call Management System (CMS) software, and other required and optional software. If the software has already been installed at the factory, the only procedures required at the customer site include:

- [“Setting Up CMS” on Page 2-117](#)
- [“Installing Feature Packages” on Page 2-157](#)
- [“Performing a CMSADM Backup” on Page 2-181](#)

If the CMS software was not installed at the factory, use the procedures in this chapter to bring the CMS computer up to factory standards after a system reconfiguration or repair. See *CentreVu*® *CMS R3V8 Hardware Maintenance and Troubleshooting* (585-210-919) or *CentreVu*® *CMS Sun Enterprise*† *3500 Computer Maintenance and Troubleshooting* (585-215-875) for more information about field repairs.

## Summary of Procedures

The following table lists each of the factory software installation procedures for R3V8, including the computer models for which it applies (E3000, E3500, *Ultra*‡ 5, *SPARCserver*§) and if it is required or optional. All procedures must be performed in the sequence presented below.

Procedure	Computer Platform	Required/Optional
Installing the <i>Sun Solaris 7</i> operating system (3/99 version)	All	Required
Installing the <i>Sun Online Validation Test Suite (VTS) 3.1</i>	All	Required
Installing the <i>SunLink</i> * High-Speed Serial Interface/Sbus (HSI/S) Version 3.0 drivers	E3000 E3500 SPARCserver	Optional
Installing the High-Speed Serial Interface/PCI Bus (HSI/P) Adapter 2.0 drivers	Ultra 5	Optional
Installing the Serial Asynchronous Interface/PCI Bus (SAI/P) Adapter 1.0 drivers	Ultra 5	Optional
Installing the Aurora ports card drivers	SPARCserver	Optional

\**Sun* is a registered trademark of Sun Microsystems, Inc.

†*Enterprise* is a trademark of Sun Microsystems, Inc.

‡*Ultra* is a trademark of Sun Microsystems, Inc.

§*SPARCserver* is a registered trademark of SPARC International, Inc.

Procedure	Computer Platform	Required/Optional
Installing the Bay Networks Annex R10.0B drivers	All	Optional
Installing the <i>Solstice</i> <sup>†</sup> for Server Connect X.25 package	All	Optional
Installing the <i>INFORMIX</i> <sup>‡</sup> software: - Structured Query Language (SQL) Version 7.20 - Standard Engine (SE) Version 7.22 - Runtime Enhanced SQL (ESQL) Version 9.14 - International Language Supplement (ILS) Version 2.11	All All All All	Optional Required Required Required
Installing the <i>Solstice</i> DiskSuite 4.2 software	All	Required
Installing the <i>Sun Solaris</i> patches	All	Required
Setting up <i>Solstice</i> DiskSuite	All	Required
Installing the CMS Supplemental Services software	All	Required
Installing the CMS software	All	Required
Installing the CMS patches	All	As needed
Installing the Open Database Connectivity (ODBC) software	All	Optional
Setting up the CMS software	All	Required
Installing feature packages	All	Required
Setting up the remote console	All	Required
Setting up the NTS	All	Optional
Backing up the system	All	Required

\* *SunLink* is a registered trademark of Sun Microsystems, Inc.

† *Solstice* is a trademark of Sun Microsystems, Inc.

‡ *Informix* is a registered trademark of Informix Software, Inc.

---

## Remote Terminal Access Tips

- When executing commands that take a long time to complete, (such as `cpio` and `/olds` commands), use the `nohup` command to ensure that the command will complete without interruption in case the data line disconnects. An example using the `nohup` command is shown below:

```
nohup cpio -icmudf -C 10240 -I /dev/rmt/0c "/cms" | tee
```

- When system reboots are required, verify that your terminal type is set correctly after the reboot.
- 

## Prerequisites

- Before beginning these procedures, verify that all hardware components of the system, including port cards, external disk drives, and tape drives, are correctly installed. Otherwise, the system hardware will not be recognized during the software installation procedures.

---

# Installing the *Solaris* Operating System

---

## Overview

The *Solaris* installation program is a menu-driven, interactive program that guides you step by step through installing the *Solaris* software. It also has on-line help to answer your questions.

### ⇒ NOTE:

If the CMS computer you are installing requires disk mirroring, you must use information from this section and the *CentreVu® CMS Disk-Mirrored Systems R3V8* (585-210-940) document.

Procedures required to install the *Solaris 7* operating system on the CMS computer include:

- Booting from the *Solaris 7* Software (3/99) CD ([Page 2-5](#))
- Identifying the system ([Page 2-7](#))
- Setting the date and time ([Page 2-12](#))
- Selecting the *Solaris 7* system files ([Page 2-14](#))
- Partitioning the hard disks ([Page 2-18](#))
- Installing the selected options ([Page 2-29](#))
- Assigning a root password ([Page 2-31](#))
- Enabling Korn shell and the backspace key ([Page 2-33](#))
- Setting EEPROM parameters for the A and B ports ([Page 2-33](#))
- Turning on the system activity recorder ([Page 2-36](#))
- Changing directory permissions ([Page 2-87](#))
- Installing the Sun Online Validation Test Suite ([Page 2-38](#))

---

## Platform Considerations

- All platforms.

## Before You Begin

Before you begin the Installation procedures described in this chapter, perform the following tasks:

- Obtain the *Solaris 7* Software 3/99 CD
- Identify the host name of the system, which is designated by the Lucent Technologies' Technical Service Center [TSC])
- Identify the system's Internet Protocol (IP) address (this may be the factory default or an address in a customer's network)
- Identify the number and size of disk drives on the system
- Verify that all power cords are fully-connected to all hardware devices (such as disk drives and tape drives), and that power is applied to all hardware devices.

## Booting from the Solaris 7 Software 3/99 CD


This section describes how to boot the system from the *Solaris 7 Software* CD using the local console.

To perform this operation using a remote terminal, see *CentreVu® CMS R3V8 Hardware Maintenance and Troubleshooting* (585-210-919) or *CentreVu® CMS Sun® Enterprise™ 3500 Computer Maintenance and Troubleshooting* (585-215-875).

### ⇒ NOTE:

The screens in this section are representative of a typical installation. Not all screens will match your installation. When possible, the recommended selections are shown with boxes highlighting the selection.

1. Apply power to all of the external devices, such as disk drives and tape drives.
2. Turn on the system. Depending on the model, it can take several minutes for the system to boot up.
3. As the console shows that the system is booting up, press the `Stop` and `A` keys simultaneously. The system responds:



ok


4. Load the *Solaris 7* Software 3/99 CD into the CD-ROM drive.

5. Boot the system from the CD by entering the following:

```
boot cdrom
```


The CD boot process varies between platforms, and requires approximately 2 to 10 minutes to complete.

The Select Language and Locale screen appears:



6. Choose the Language and Locale selections that are appropriate for your location and then click Continue.


7. The *Solaris* Installation Program screen appears:



8. Select Continue.


## Identifying the System

The Identify This System screen appears:



1. Select Continue.


The Host Name screen appears:



2. Select the Host name box and enter the host name for the system. The host name for a specific system is designated by TSC

Provisioning personnel. Host names are case-sensitive and cannot start with a number. When finished, select Continue.


The Network Connectivity screen appears:



3. Select Yes, and then select Continue.

**⇒ NOTE:**

If the system is equipped with more than one network interface, the Primary Network Interface screen appears (otherwise, the IP Address screen appears):




4. If the Primary Network Interface screen appears, select “hme0” for an *Enterprise 3000*, *Enterprise 3500*, or *Ultra 5* computer, or “le0” for a *SPARCserver* computer, and then select Continue.

The IP Address screen appears:




5. Select the IP address box and enter the IP address. IP address 192.168.2.1 is the factory default. You should enter the factory default address unless there is an actual network address for this site. Select Continue when finished.

The Confirm Information screen appears:




6. Select Continue if the displayed information is correct. If you select Change, the program returns to the Host Name screen.

The Name Service screen appears:




7. Select None, and then select Continue.

The Confirm Information screen appears:



8. Select Continue if the displayed information is correct. If you select Change, the program returns to the Name Service screen.


The Subnets screen appears:



9. If this CMS computer is using LAN connectivity to the switch and is part of a subnet on the customer's network, you may need to select Yes to administer a subnet mask. If you select Yes, continue with Steps [10](#) and [11](#).

If you select No, continue with Setting the Date and Time.


10. After selecting Yes (if the system is part of a subnet), the Netmask screen appears:



11. Enter the desired subnet mask. The default of 255.255.255.0 is recommended. Select Continue.

## Setting the Date and Time

The Time Zone screen appears:




1. Select Geographic region, and then select Set.

The Geographic Region screen appears:



2. Select the region and time zone where this system is located, and then select Continue.


The Date and Time screen appears:



The image shows a window titled "Date and Time". Inside the window, there is a prompt: "> Accept the default date and time or enter new values." Below this, the current date and time are displayed as "Date and time: 1999-05-20 11:08". There are six input fields for manual entry: "Year (4 digits)" with "1999", "Month (1-12)" with "05", "Day (1-31)" with "20", "Hour (0-23)" with "11", and "Minute (0-59)" with "08". At the bottom of the window, there are two buttons: "Continue" on the left and "Help" on the right.

3. Select Continue to accept the displayed date and time, or if necessary, enter the correct date and time. When all the information is correct, select Continue.

The Confirm Information screen appears:




The image shows a window titled "Confirm Information". Inside the window, there is a prompt: "> Confirm the following information. If it is correct, choose Continue; to change any information choose Change." Below this, the information to be confirmed is displayed: "System part of a subnet: No", "Time zone: US/Mountain", and "Date and time: 1999-05-20 11:08:00". At the bottom of the window, there are three buttons: "Continue" on the left, "Change" in the middle, and "Help" on the right.

4. If the displayed information is correct, select Continue. If you select Change, the program returns to the Subnets screen.

The system date and time are now set. After a few minutes, the program continues with the selection of *Solaris 7* system files.


## Selecting the Solaris 7 System Files

If the system currently has an earlier version of Solaris installed, the first *Solaris* Interactive Installation screen appears after a few minutes (if this screen is not displayed, go to Step 2):




1. Select Initial.

The second *Solaris* Interactive Installation screen appears:




2. Select Continue.

The Allocate Client Services screen appears:




3. Select Continue.

The Select Languages screen appears. Select the languages you want to see displayed in the user interface. English is automatically installed by default.



4. When you have completed choosing your language selections, click Continue.

The Select Software screen appears:




5. Select End User System Support. Check to make sure that the Solaris 64 Bit Support box is *NOT* selected, and then select **Customize** (*NOT* Continue).

⇒ NOTE:


If you select Continue instead of Customize, the Disks screen (shown on [Page 2-18](#)) appears, which is incorrect. If this happens, select Go Back from the Disks screen.

The Customize Software screen appears:



6. Select the packages listed below. Start at the top of the list and make the package selections in the order shown below. When necessary, click on the triangular icons to expand and collapse package clusters. Do not exclude any packages that are already selected.
  - Basic Networking
  - On-Line Manual Pages
  - open the cluster for Open Windows Version 3 (**not** Open Windows Version 64) and select:
    - X Windows system online user man pages
  - Point-to-Point Protocol (**not** Point-to-Point Protocol 64)
  - open the cluster for Programming tools and libraries and select:
    - CCS tools bundled with SunOS
    - Solaris bundled tools
  - System Accounting
  - Terminal Information
7. When you have completed making the package selections, click OK.

The Software screen reappears.




8. Select Continue.

The *Solaris 7* software packages are now selected and will be installed after the disks are partitioned.

## Partitioning the Hard Disks

The Disks screen appears. Add all of the available disks into the “Selected Disks” column.




### ➤ NOTE:

In the above screen, all the disks equipped with the system should be listed as available. If not, you may have a connectivity or power problem. Check all cables and verify that the power is switched on for the disk drives.

The screen examples in this section may differ according to your system's disk configuration.

9. After all of the disks have been moved to the “Selected Disks” column, select Continue.

The Preserve Data screen appears:




⇒ **NOTE:**

The Preserve Data screen may not display if this is the first time the operating system has been installed on your machine.


10. Select Continue.

The Automatically Layout File Systems screen appears:




## 11. Select Manual Layout.

The File System and Disk Layout screen appears:



## 12. Select **Customize** (NOT Continue).

The Customize Disks screen appears:



☰ NOTE:

If all the disks on your system are not visible in the *Customize Disks* screen, use the sidebar at the bottom of the window to bring the partition columns for other system disks into view.

13. Disk partitioning should be done in cylinders rather than megabytes. To do this, select the cylinders icon for the first disk in the upper left-hand corner of the disk 1 column.

The Customize Disks by Cylinders screen for the first (boot) disk appears:

	Size	Start	End
0			
1			
2	8892	0	8891
3			
4			
5			
6			
7			

Allocated: 0 CYLS  
Free: 8892 CYLS  
Capacity: 8892 CYLS

14. Use the information from the [“Boot Disk Partition Table” on Page 2-23](#) to partition the boot disk by filling in the slice name and cylinder values for each partition. As you move the cursor to each new partition, the calculated cylinder values are displayed in the *Start* and *End* fields in the two columns at the right of the screen.

☰ NOTE:

The size of the overlap file system always defaults to the size of the entire disk. Do not change this value.

## Boot disk partition values

The boot disk cylinder values provided in the following table conform to the R3V8 disk partitioning specifications for all disk drives supported by R3V8.

### ⇒ NOTES FOR MIRRORED SYSTEMS:

When setting up disk partitions for mirrored Enterprise 3000 or 3500 systems, select the following disks (if feasible) to partition as the boot and alternate boot devices:

Enterprise 3000:

- boot - c0t0
- alternate boot - c0t1

Enterprise 3500:

- boot - c0t0
- alternate boot - c1t4

Be careful when you enter slice names for partition 0 on boot and alternate boot disks:

- For primary boot disks, the slice name for partition 0 is always “/”.
- For alternate boot disks on mirrored systems, the slice name for partition 0 must always remain blank.

**Boot Disk Partition Table:**

Slice	Slice Name	Disk Size (in cylinders)			
		4.2-GB SCSI (SPARCserver and E-3000)	8.4-GB EIDE (Ultra 5)	9.1-GB EIDE (Ultra 5)	9.1-GB SCSI (SPARCserver and E-3000) or FCAL (E-3500)
0	/  or  (blank) if alternate boot on mirrored systems	1023	2134	2032	616
1	(blank)	7	7	7	7
2	overlap*	3880	16706	17660	4924
3	(blank)	1879	12533	13540	3716
4	swap	971	2032	2081	585
5-7	(blank)				

\* *Overlap* partition sizes are automatically displayed in the Customize Disks screen during the Solaris installation. These values indicate the total number of cylinders for the disk drive models used in CMS R3V8. If the disk drive you are partitioning does not match one of these values, you have a non-standard disk. Escalate the issue to Lucent technical support.

The following example shows how the Customize Disks by Cylinders screen appears when the boot disk is a 4.3-GB IDE disk:

Customize Disks by Cylinders

		Recommended	Minimum
<input type="text" value="swap"/>		<input type="text" value="0"/>	<input type="text" value="0"/>

Disk: c0t0d0 8892 CYLS

		Size	Start	End
0	<input type="text" value="/"/>	2345		2344
1	<input type="text"/>	7	2345	2351
2	<input type="text" value="overlap"/>	8892	0	8891
3	<input type="text"/>	4320	2352	6671
4	<input type="text" value="swap"/>	2220	6672	8891
5	<input type="text"/>			
6	<input type="text"/>			
7	<input type="text"/>			

Allocated: 8892 CYLS  
 Free: 0 CYLS  
 Capacity: 8892 CYLS

15. Select OK after setting up the partitions for the boot disk.
  - The Customize Disks screen re-appears. If there are more disks, select the cylinders icon for the next disk to be partitioned; the Customize Disks by Cylinders screen appears for the selected disk.
  - If there is not a second disk, go to Step [18](#).
  
16. Use the information from the [“Non-boot Partition Table” on Page 2-25](#) table to input the cylinder values for each disk partition. As you move the cursor to each new partition, notice that the `Start` and `End` fields automatically display the computed cylinder values.

**Non-boot disk partition values**

The non-boot disk cylinder values provided in the following table conform to the R3V8 disk partitioning specifications for all disk drives supported by R3V8.

⇒ **NOTE:**

- All slice names remain blank, except for “overlap”.
- The size of the overlap file system always defaults to the size of the entire disk. Do not change this value.

**Non-boot Partition Table:**

Slice	Slice Name	Disk Size (in cylinders)		
		4.2-GB SCSI (SPARCserver and E-3000)	9.1-GB EIDE (Ultra 5)	9.1-GB SCSI (SPARCserver, E-3000) or FCAL (E-3500)
0	<i>(blank)</i>	2	2	2
1	<i>(blank)</i>	3878	17658	4922
2	overlap*	3880	17660	4924
3	<i>(blank)</i>			
4-7	<i>(blank)</i>			

\* *Overlap* partition sizes are automatically displayed in the Customize Disks screen during the Solaris installation. These values indicate the total number of cylinders for the disk drive models used in CMS R3V8. If the disk drive you are partitioning does not match one of these values, you have a non-standard disk. Escalate the issue to Lucent technical support.

Properly set up, the Customize Disks by Cylinders screen for a non-boot 4.2-GB SCSI disk would appear:

Customize Disks by Cylinders

Recommended  Minimum


Disk: c1t0d0 3880 CYLS

	Size	Start	End
0	<input type="text" value="2"/>	<input type="text"/>	<input type="text" value="1"/>
1	<input type="text" value="3878"/>	<input type="text" value="2"/>	<input type="text" value="3879"/>
2	<input type="text" value="overlap"/>	<input type="text" value="0"/>	<input type="text" value="3879"/>
3	<input type="text"/>	<input type="text"/>	<input type="text"/>
4	<input type="text"/>	<input type="text"/>	<input type="text"/>
5	<input type="text"/>	<input type="text"/>	<input type="text"/>
6	<input type="text"/>	<input type="text"/>	<input type="text"/>
7	<input type="text"/>	<input type="text"/>	<input type="text"/>

Allocated: 3880 CYLS  
 Free: 0 CYLS  
 Capacity: 3880 CYLS

17. Select OK.

The Customize Disks screen appears again:




**CAUTION:**

If there are more disks installed on your system, repeat Steps [16](#) through [17](#) for each additional disk. Use the scroll bar on the screen to display the additional disks. Go to Step [18](#) only when you have partitioned every disk on your system.


18. Select the OK button on the Customize Disks screen.

The File System and Disk Layout screen appears:



19. Select Continue.


The Mount Remote File Systems screen appears:



---

## 20. Select Continue.

The Profile screen appears:



### ⇒ NOTE:


If a previous Solaris 7 install has been performed on the system, you may receive a message indicating that the boot disk has been altered. This message can be disregarded; click OK to continue.

---

## Installing the Selected Options


### 1. Select Begin Installation.

The program responds:



## 2. Select Auto Reboot.

The disk partitioning process begins with the display of the Installing *Solaris* - Progress screen:



This process may take several hours, depending on the number of disks being partitioned, the hardware platform, and the speed of your CD-ROM drive. As the disks are partitioned and *Solaris 7* system files are copied to the disk, the status bar indicates the progress of the installation.

The progress screen may disappear during the process. However, the *Solaris* Install Console screen should remain in the upper left hand corner of your monitor screen and keep you posted on the progress of the installation.

When the installation finishes, the system reboots and the “create a root password” screen appears.

## Assigning a Root Password

When the installation completes, the machine reboots and responds:

```
On this screen you can create a root password.
```

```
A root password can contain any number of characters, but only the first eight characters in the password are significant. (For example, if you create 'alb2c3d4e5f6' as your root password, you can use 'alb2c3d4' to gain root access.)
```

```
You will be prompted to type the root password twice; for security, the password will not be displayed on the screen as you type it.
```

```
> If you do not want a root password, press RETURN twice.
```

```
Root password:
```

1. Enter the root password. Until it is time to turn the system over to the customer, it is recommended that you press Enter to assign a blank password. The program responds:

```
Re-enter your root password.
```

```
Press Return to continue.
```

2. Re-enter the root password or press Enter for a blank password. The program responds:

```
After 30 minutes of idle time on the system, your system state will automatically be saved to disk, and the system will power off.
```

```
Later, when you want to use the system again, and you turn the power back on, you system will be restored to its previous state, including all the programs you were running.
```

```
Do you want this automatic power-saving shutdown? (If this system is used as a server, answer n) [y,n,?]
```

3. Enter `n`

The system responds:

```
Do you want the system to ask about this again, when you
next reboot? (This gives you the chance to try it before
deciding whether to keep it.) [y,n,?]
```

4. Enter `n`

The login console is displayed. Enter `root` as user name, followed by your password (if you submitted one to the system).

5. The *Solaris* Welcome screen appears and prompts you to choose your default desktop. Select Common Desktop Environment and click OK. The Common Desktop Environment (CDE) is displayed.

---

## Opening a Terminal Window

A Terminal Window must be opened to allow keyboard input of commands at the system prompt. To open a terminal window, perform the following steps:

1. Use the mouse to move the cursor to an empty area of the desktop display and click the right button on the mouse.

The `Tools` menu is displayed.

2. From the `Tools` menu, select the `Terminal` option.

A terminal window opens with the active cursor at the prompt.

## Enabling Korn Shell and the Backspace Key

Enter the following commands to enable the Korn shell and the backspace key:

```
ksh -o vi
stty erase <Backspace>
```

where <Backspace> is entered by pressing the backspace key.

### ⇒ NOTE:

If you log off and log back in to the system, the Korn shell and the backspace key will not work unless you reenter these commands. After you install the *DiskSuite* software ([Page 2-84](#)) and reboot the system, these options will work automatically every time you log in.

## Displaying and Setting the EEPROM Parameters

This section describes how to set the firmware `eeprom` values for a CMS computer. You must first display the current settings to determine if the setting must be changed from the factory setting. To display the current settings, enter the following command:

```
eeprom | more
```

This will display the current `eeprom` settings. Compare these settings with the following table.

Option Name	Required Setting
#power-cycles	7
ansi-terminal?	true
auto-boot?	true
boot-command	boot
boot-device	disk
configuration-policy	component
diag-device	disk
diag-level	min
diag-switch?	false
fcode-debug?	false

Option Name	Required Setting
input-device	keyboard
keyboard-click?	false
load-base	16384
local-mac-address?	false
memory-interleave	max
mfg-mode	off
mfg-switch?	false
name	options
oem-banner?	false
oem-logo?	false
output-device	screen
pcia-probe-list	sb=1,2,3,4
pcib-probe-list	sb=1,2,3
powerfail-time	0
sbus-probe-default	d3120
sbus-probe-list	541230
screen-#columns	80
screen-#rows	34
scsi-initiator-id	7
security-#badlogins	0
selftest-#megs	1
security-mode	none
silent-mode?	false
sunmon-compat?	false
testarea	0
tpe-link-test?	true
ttya-ignore-cd	false
ttya-mode	9600,8,n,1,-
ttya-rts-dtr-off	true

Option Name	Required Setting
ttyb-ignore-cd	false
ttyb-mode	9600,8,n,1,-
ttyb-rts-dtr-off	true
use-nvramrc?	false
watchdog-reboot?	false

**⇒ NOTE:**

Not all options will display for all CMS computers. Check only those options that display for your computer. In addition, some options will show “data not available” messages. Ignore those options.

To change an eeprom option, use the following command:

```
eeprom <option_name>=<option_value>
```

For example, to set the ttyA port for 9600 bps, 8 bit characters, no parity, and 1 stop bit, you would enter:

```
eeprom ttya-mode=9600,8,n,1,-
```

**⇒ NOTE:**

The character “1” in the `ttya-mode` and `ttyb-mode` option settings is the number one, not the letter l.

## Turning On the System Activity Recorder

1. Enter `su - sys` (be sure to use a space between “-” and “sys”) to log in with the `sys` login id. The prompt changes to a `$`.
2. Enter `id` to confirm that you are using the `sys` id. The program responds:

```
uid=3(sys) gid=3(sys)
```

Enter the following commands to create and edit the `cron.sys` file:

```
cd /var/opt
crontab -l > cron.sys
vi cron.sys
```

The `cron.sys` file looks similar to the following:

```
#ident "@(#)sys 1.5      92/07/14 SMI" /* SVr4.0 1.2 */
#
# The sys crontab should be used to do performance collection.
# See cron and performance manual pages for details on startup.
#
# 0 * * * 0-6 /usr/lib/sa/sa1
# 20,40 8-17 * * 1-5 /usr/lib/sa/sa1
# 5 18 * * 1-5 /usr/lib/sa/sa2 -s 8:00 -e 18:01 -i 1200 -A
```

3. Remove the leading “#” characters that were used to comment out the last three lines in the file. That is, change the lines to look like the following:

```
#ident "@(#)sys 1.5      92/07/14 SMI" /* SVr4.0 1.2 */
#
# The sys crontab should be used to do performance collection.
# See cron and performance manual pages for details on startup.
#
0 * * * 0-6 /usr/lib/sa/sa1
20,40 8-17 * * 1-5 /usr/lib/sa/sa1
5 18 * * 1-5 /usr/lib/sa/sa2 -s 8:00 -e 18:01 -i 1200 -A
```

4. Enter `:wq` to save and quit the file.

5. Enter the following commands:

```
crontab -r
crontab cron.sys
```

6. Enter the following command to confirm that the changes you made are intact:

```
crontab -l
```

The program responds:

```
#ident "@(#)sys 1.5      92/07/14 SMI" /* SVr4.0 1.2 */
#
# The sys crontab should be used to do performance collection.
# See cron and performance manual pages for details on startup.
#
0 * * * 0-6 /usr/lib/sa/sa1
20,40 8-17 * * 1-5 /usr/lib/sa/sa1
5 18 * * 1-5 /usr/lib/sa/sa2 -s 8:00 -e 18:01 -i 1200 -A
```

7. Enter `exit` to leave superuser mode (you may have to do this twice).

The prompt changes back to the “#” character.

8. To remove the Solaris 7 installation CD, enter:

```
eject cdrom
```

# Installing the *Sun* Online VTS 3.1

## Overview

Installing the *Sun* Online VTS 3.1 software provides test facilities for the system.

## Platform Considerations

- All platforms.

## Prerequisites

- The *Solaris 7* operating system must be installed.
- Verify that you are logged in as *root* at the console.
- Obtain the “Software Supplement for the *Solaris 7* Operating Environment” CD.

## Procedure

1. Load the “Software Supplement for the *Solaris 7* Operating Environment 3/99” CD into the CD-ROM drive.
2. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD as shown below:

```
/cdrom/solaris_7_399_suppcd read only /setuid on  
(current time and date)
```

### 3. Enter the command:

```
/usr/sbin/pkgadd -d /cdrom/cdrom0/Product SUNWvts SUNWvtsmn
```

The program responds:

```
Processing package instance <SUNWvts> from
</cdrom/solaris_7_399_suppdc/Product>

SunVTS
.
.
## Checking for conflicts with packages already installed.
## Checking for setuid/setgid programs.

This package contains scripts which will be executed with
super-user permission during the process of installing this
package.

Do you want to continue with the installation of <SUNWvts>
[y,n,?]
```

### 4. Enter `y`

The program responds:

```
Installing SunVTS as <SUNWvts>

## Installing part 1 of 1.
Executing i.inetdconf class script...

Completed editing /etc/inetd.conf

Sending signal to inetd to read the modified conf file...

. . . . .

Installation of <SUNWvtsmn> was successful.

Processing package instance <SUNWvtsmn> from
</cdrom/solaris7_399_suppdc/Product>

. . . . .

Installation of <SUNWvtsmn> was successful.
```

### 5. Enter `eject cd` to eject the CD-ROM from the computer.

# Installing Link and Port Packages

Installing the link and port packages includes the following:

- Installing *Sunlink* HSI/S software
- Installing HSI/P software
- Installing SAI/P adapter drivers
- Installing Aurora ports card drivers
- Installing Bay Networks Annex NTS drivers
- Installing the *Solstice* for Server Connect X.25 package.

## Installing the SunLink HSI/S Software

### Overview

The *SunLink* HSI/S card(s) provides X.25 interface ports to the CMS computer. If your system does not have an HSI/S card, skip this section.

### Platform Considerations

- *Enterprise 3000*, *Enterprise 3500*, and *SPARCserver*.

### Prerequisites

- The *Solaris 7* operating system must be installed.
- The HSI/S card(s) must be installed before installing the software.
- Verify that you are logged in as *root* at the console.
- Obtain the “*SunLink* HSI/S 3.0” CD.

### Procedure

1. Load the “*SunLink* HSI/S 3.0 Adapter” CD into the CD-ROM drive.
2. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD, as shown below:

```
/cdrom/sunhsis_3_0 on /vol/dev/dsk/c0t2d0/sunhsis_3_0 read  
only/setuid on (current date and time)
```

### 3. Enter:

```
/usr/sbin/pkgadd -d /cdrom/cdrom0/Product
```

The program responds:

```
The following packages are available:
```

```
1 SUNWhsis      SunHSI/S Driver for SBUS
                  (sparc) 3.0,REV=1998.11.09

2 SUNWhsism     SunHSI/S Man Pages for SBUS
                  (sparc) 3.0,REV=1998.11.09

3 SUNWhsisu     SunHSI/S Utilities for SBUS
                  (sparc) 3.0,REV=1998.11.09
```

```
Select package(s) you wish to process
(or 'all' to process all packages. (default:all
[?,??,q]:
```

### 4. Press Enter

```
Processing package instance <SUNWhsis> from
</cdrom/sunhsis_3_0/Product>
```

```
SunHSI/S Driver for SBus
```

```
. . . . .
```

```
This package contains scripts which will be executed with
super-userpermission during the process of installing this
package.
```

```
Do you want to continue with the installation of <SUNWhsis>
[y,n,?]
```

---

5. Enter: `y`

The program proceeds to install the `SUNWhsis`, `SUNWhsism` and `SUNWhsisu` packages. When the installation is finished, the program returns to the installation menu and prompts:

```
Select package(s) you wish to process (or 'all'
to process all packages). (default: all)
[?,??,q]:
```

6. Enter: `q`

7. Enter: `eject cdrom`

---

## Installing the HSI/P Software

### Overview

The HSI/P card(s) provides interface ports to the CMS computer. If your system does not have an HSI/P card, skip this section.

### Platform Considerations

- *Ultra 5* only.

### Prerequisites

- The *Solaris 7* operating system must be installed.
- The HSI/P card(s) must be installed before installing the software.
- Verify that you are logged in as *root* at the console.
- Obtain the “SunHSI/P Adapter 2.0” CD.

**Procedure**

1. Load the “SunHSI/P Adapter 2.0” CD into the CD-ROM drive.
2. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD, as shown below:

```

/cdrom/sunhsip_2_0 on /vol/dev/dsk/c0t2d0/sunhsip_2_0 read only
on (current time and date)

```

3. Enter:

```
/usr/sbin/pkgadd -d /cdrom/cdrom0/Product SUNWhsip
```

```
The following packages are available:
```

```

1  SUNWhsip      SunHSI/P Driver for PCI
                      (sparc) 2.0,REV=1998.10.22
2  SUNWhsipm    SunHSI/P Man Pages for PCI
                      (sparc) 2.0,REV=1998.10.22
3  SUNWhsipu    SunHSI/P Utilities for PCI
                      (sparc) 2.0,REV=1998.10.22

```

```
Select package(s) you wish to process (or 'all' to process
all packages). (default: all) [?,??,q]:
```

4. Press Enter

The program responds:

```
Processing package instance <SUNWhsip> from
</cdrom/sunhsip_2_0/Product>
```

```
SunHSI/P Driver for PCI
(sparc) 2.0,REV=1998.10.22
```

```
.....
```

```
This package contains scripts which will be executed with
super-user permission during the process of installing this
package.
```

```
Do you want to continue with the
installation of <SUNWhsip> [y,n,?]
```

5. Enter: `y`

The program proceeds to install the `SUNWhsip`, `SUNWhsipm` and `SUNWhsipu` packages. When the installation is finished, the program returns to the installation menu and prompts:

```
Select package(s) you wish to process (or  
'all' to process all packages). (default:  
all) [?,??,q]:
```

6. Enter `q`:

7. Enter: `eject cdrom`

# Installing the SAI/P Adapter Drivers

## Overview

The SAI/P card/cards provides serial asynchronous interface ports to the CMS computer. If your system does not have an SAI/P card, go the next procedure.

## Platform Considerations

- *Ultra 5* only

## Prerequisites

- The *Solaris 7* operating system must be installed.
- The SAI/P card(s) must be installed before installing the software.
- Verify that you are logged in as *root* at the console.
- Obtain the “SunSAI/P Adapter 2.0” CD and load it in the CD-ROM drive.

## Procedure

1. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD as shown below:

```
/cdrom/sunsaip_2_0 on /vol/dev/dsk/c0t2d0/sunsaip_2_0
read only on (current date and time)
```

2. Enter:

```
/usr/sbin/pkgadd -d /cdrom/cdrom0/Product/saip_2
```

The program responds with a list of available packages:

```
The following packages are available:
```

```
1  SUNWsaip      Serial Asynchronous Interface Driver (PCI)
                        (sparc) 2.0,REV=1998.10.19
2  SUNWsaipu     Serial Asynchronous Interface Utilities (PCI)
                        (sparc) 2.0,REV=1998.10.19
```

```
Select package(s) you wish to process (or 'all' to process
all packages). (default: all) [?,?,q]:
```

3. Press: Enter

The program responds:

```
This package contains scripts which will be executed
with super-user permission during the process of
installing this package.
```

```
Do you want to continue with the installation of
<SUNWsaip> [y,n,?]
```

4. Enter: y

The program installs the SAI/P driver packages and returns to the installation menu.

5. Enter: q

6. Enter: eject cdrom

# Installing the Aurora Port Drivers

## Overview

The following procedures are used to install the Aurora ports card drivers.

## Platform Considerations

- *SPARCserver only*

## Prerequisites

- The *Solaris 7* operating system must be installed.
- Verify that you are logged in as *root* at the console.
- Obtain the “Aurora Drivers” CD.

## Procedure

1. Load the “Aurora Drivers” CD into the CD-ROM drive.
2. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD as shown below:

```
. . .  
/cdrom/aurora_drivers on /vol/dev/dsk/c0t2d0/aurora_drivers  
read only on (current date and time)
```

3. Add the Aurora package by entering the following:

```
/usr/sbin/pkgadd -d /cdrom/cdrom0
```

The program responds:

```
The following packages are available:  
1  AURAacs  Aurora 40X, 80X, WMS 2000/3000 Base Driver  
          (sparc) 6.14  
2  AURAacsa Aurora 40X, 80X, WMS 2000/3000 Asynchronous Drive:  
          (sparc) 3.14  
3  AURAsio16 Aurora 1600SE device driver  
          (sparc) 5.13  
Select package(s) you wish to process (or 'all' to process  
all packages). (default: all) [?,??,q]:
```

4. Select 1 and 2 to install the 8-port card drivers, select 3 to install the 16-port card drivers, or press Enter to select both sets of drivers.

⇒ NOTE:

Do *not* try to install the 16-port card drivers and then install the 8-port card drivers; you will get errors during installation. The following screens show the installation for both sets of drivers. If you select one or the other, your installation screens will differ.

The program responds:

```
Processing package instance <AURAacs> from
</cdrom/aurora_drivers>
Aurora 40X, 80X, WMS 2000/3000 Base Driver
(sparc) 6.14
.
.
This package contains scripts which will be executed with
super-user permission during the process of installing this
package.

Do you want to continue with the installation of <AURAacs>
[y,n,?]
```

5. Enter *y*

The program responds:

```
Installing Aurora 40X, 80X, WMS 2000/3000 Base Driver
as <AURAacs>
## Installing part 1 of 1.
/etc/rc2.d/S91AURAacs
.
.
[ verifying class <sed> ]
## Executing postinstall script.

Installation of <AURAacs> successful.

There are 2 more packages to be installed.

Do you want to continue with installation [y,n,?]
```

## 6. Enter `y`

The program responds:

```
Processing package instance <AURAacsa> from
</cdrom/aurora_drivers>
Aurora 40X, 80X, WMS 2000/3000 Asynchronous Driver
(sparc) 3.14
.
.
Using </opt> as the package base directory.
## Processing package information.
## Processing system information.
## Verifying package dependencies.
Do you want to continue with the installation of <AURAacsa>
[y,n,?]
```

## 7. Enter `y`

The program responds:

```
## Verifying disk space requirements.
## Checking for conflicts with packages already installed.
## Checking for setuid/setgid programs.

This package contains scripts which will be executed with super-
user permission during the process of installing this package.

Do you want to continue with the installation of <AURAacsa>
[y,n,?]
```

## 8. Enter `y`

The program responds:

```
Installing Aurora 40X, 80X, WMS 2000/3000 Asynchronous Driver as
<AURAacsa>
## Installing part 1 of 1.
/etc/rc2.d/S92AURAacsa
.
.
## Executing postinstall script.

Installation of <AURAacsa> successful.

There is 1 more package to be installed.

Do you want to continue with installation [y,n,?]
```

9. Enter `y`

The program responds:

```
Processing package instance <AURAsio16> from </cdrom/aurora_driv
Aurora 1600SE device driver
(sparc) 5.13
.
.
This package contains scripts which will be executed
with super-user permission during the process of
installing this package.

Do you want to continue with the installation of
<AURAsio16> [y,n,?]
```

10. Enter `y`

The program responds:

```
Installing Aurora 1600SE device driver as <AURAsio16>
## Installing part 1 of 1.
/kernel/drv/sio16
.
.
Installation of <AURAsio16> successful.

The following packages are available:

 1  AURAacs   Aurora 40X, 80X, WMS 2000/3000 Base Driver
      (sparc) 6.14
 2  AURAacsa Aurora 40X, 80X, WMS 2000/3000 Asynchronous Drive:
      (sparc) 3.14
 3  AURAsio16 Aurora 1600SE device driver
      (sparc) 5.13

Select package(s) you wish to process (or 'all' to process
all packages). (default: all) [?,?,q]:
```

11. Enter `q`12. Enter `eject cdrom`

# Installing the Bay Networks Annex NTS Drivers

## Overview

This procedure installs the NTS drivers. If your system is not using an NTS, skip this section

### ⇒ NOTE:

If you are reinstalling the NTS drivers, the options presented will differ slightly.

## Platform Considerations

- All platforms.

## Prerequisites

- The *Solaris 7* operating system must be installed.
- Verify that you are logged in as *root* at the console.
- Obtain the “Annex Communication Server R10.0(B) Annex Host Tools” CD.

## Procedure

1. Load the “Annex Communication Server R10.0(B) Annex Host Tools” CD.
2. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD, as shown below:

```
. . .  
/cdrom/baynet_annex_system on /vol/dev/dsk/c0t2d0/baynet_annex_  
system read only on (current date and time)
```

3. Enter:

```
/cdrom/cdrom0/install
```

---

**4. The program responds:**

```
Do you want to continue (y/n/q=quit) [y]:
```

**5. Press Enter**

The program responds:

```
After installing one product you will be asked if you want
to install the other product.
```

```
Indicate desired action:
```

- 1) Install Comm.Server Software
- 2) Install Annex Manager
- 3) Quit

```
Enter desired action [1]:
```

**6. Press Enter**

The program responds:

```
Enter the name of the Comm. Server Software installation
directory.
```

```
Directory name [/usr/annex/cs_R10.0B]:
```

**7. Press Enter**

The program responds:

```
Comm. Server Software Installation Script
```

```
This installation shell script will examine your system and
possibly ask you questions to generate the needed configuration
to allow you to compile the Comm. Server host utilities.
```

```
.
Type carriage return to continue. Your cursor should be here-->
```

**8. Press Enter**

The program responds:

```
Where do you want the Annex utilities installed?
Utility directory [/usr/annex]:
```

## 9. Press Enter

The program responds:

```
BFS directory [/usr/spool/erpcd/bfs]:
```

## 10. Press Enter

The program responds:

```
Do you wish to install manual pages at this time? [y]:
```

## 11. Press Enter

The program responds:

```
On-line manual pages will be installed in the appropriate  
subdirectory (i.e., ANNEX and index) of the manual base  
directory.
```

```
What is the the manual page base directory? (q=quit)  
[/usr/man]:
```

## 12. Press Enter

The program responds:

```
Available installation options are:  
  1. Install binary images only (7MB)  
  2. Install source code only, but do not compile (11MB)  
  3. Get both binary images and source code, but do not  
  compile (13MB)  
  4. Quit  
  
Enter installation choice [1]:
```

## 13. Press Enter

The program responds:

```
Are you ready to continue (y/q=quit) [y]:
```

## 14. Press Enter

The program responds:

- ```
1) Com-Server Annex 3
2) Com-Server MicroAnnex
3) Install all images
```

```
Please select the annex model(s) you will be using.
You can specify a list separated by spaces or 'N' for none:
```

## 15. Select the Install all images option.

The program responds:

```
To save room on your system, the above directories can be
removed. You may want to enter "?" at the prompt below to get
more help.
```

```
Remove these directories (y/n) [n]:
```

## 16. Enter y

The program responds:

```
TWhat is your default security regime:
```

- ```
1) acp
2) native UNIX
3) SecureID
4) safeword
5) kerberos
6) deny (access will be denied)
7) none (access is unconditionally granted)
8) radius
```

```
Enter security regime [1]:
```

## 17. Enter 7 to select the none option. The program responds:

```
Do you want the restrictions to apply to PPP and SLIP? [n]:
```

18. Press Enter

The program responds:

```
Do you want the erpcd daemon to provide access control (y/n)
[y]:
```

19. Enter: n

The program responds:

```
Copies of the following files have been updated:
    service annex-initd
Do you want to install any of these files (y/n) [y]
```

20. Press Enter. The program responds:

```
Copy file save/modified/service to /etc/services
(y/n) [y]:
```

21. Press Enter

The program responds:

```
Copy file save/modified/annex-initd
/etc/rc2.d/annex-initd
(y/n) [y]:
```

22. Press Enter

The program responds:

```
No more system files to create or update

Do you want to start-up the new version of the erpcd
daemon? (y/n) [y]:
```

## 23. Press Enter

The program responds:

```
Starting-up the new version of the erpcd daemon.
Comm.Server Software Installation Script

Do you wish to install the Annex Manager (y/n/q=quit) [y]:
```

## 24. Enter: n

The program responds with the system prompt.

## Setting Up the NTS Start-Up Files

The following commands create symbolic links to `S99annex-initd` and other important files and then check to verify that the files were linked successfully.

1. On a single command line, enter:

```
echo "/etc/rc2.d/annex-initd start" >
/etc/rc2.d/S99annex-initd
```

1. Enter:

```
chmod 744 /etc/rc2.d/annex-initd
chmod 744 /etc/rc2.d/S99annex-initd
```

2. Enter:

```
ls -l /etc/rc2.d/annex-initd
ls -l /etc/rc2.d/S99annex-initd
```

After each `ls` command, review the first column of the output to verify that file permissions are set correctly. The correct file permissions will exhibit the following format:

```
- r w x r - - r - -
```

3. Enter:

```
ln -s /usr/annex/na /usr/bin/na
ln -s /usr/annex/rtelnet /usr/bin/rtelnet
ln -s /usr/annex/aprint /usr/bin/aprint
```

---

4. Enter:

```
ls -l /usr/bin/na
```

```
ls -l /usr/bin/rtelnet
```

```
ls -l /usr/bin/aprint
```

After each command, review the output and verify that the symbolic links are set correctly. If the symbolic links are set correctly, the `ls` command output will indicate the link at the end of each line. For example, the `ls -l /usr/bin/na` command will generate the following output:

```
-rwxr--r--  1 root  other 563072 (current date) usr/bin/na -> usr/annex/na
```

5. Enter: `eject cdrom`

---

## Installing the *Solstice* for Server Connect X.25 Package

### Overview

This procedure installs the X.25 drivers used for connections to the switch. If the CMS computer is using LAN connectivity for TCP/IP instead of X.25 connectivity to the switch, skip this section.

### Platform Considerations

- All platforms.

### Prerequisites

- The *Solaris 7* operating system must be installed.
- Verify that you are logged in as *root* at the console.
- Obtain the “*Solstice* for Server Connect, Version - March 1997” CD.
- Obtain the 21-character password for your X.25 license.

If the password for your X.25 license is not included with your CD, you must contact *Sun* directly. See the Proof of License Certificate that is included with the CD for procedures you must follow to obtain your password. Note that the only way *Sun* will deliver this password is with a FAX or by electronic mail.

## Retrieving System Information

If you already know your `hostname`, `hostid`, and X.25 license password, fill in the table below, skip this procedure, and go to the [“Installing the Solstice for Server Connect X.25 Package”](#) procedure. If you do not already know your `hostname` and `hostid`, use this procedure to determine that information:

1. Enter the command: `showrev`

The program displays something similar to the following:

```

Hostname: XXXXXXXX
Hostid: XXXXXXXX
Release: 5.7
Kernel architecture: sun4u
Application architecture: sparc
Hardware provider: Sun_Microsystems
Domain:
Kernel version: SunOS 5.7
Generic <number & date>

```

2. Identify the `Hostname` and `Hostid` (similar to that shown in bold on the previous screen). Use the following table to record this information, along with your X.25 password.

Hostname	
Hostid	
X.25 Password	

## Installing the Solstice for Server Connect X.25 Drivers

1. Load the “*Solstice* for Server Connect, Version - March 1997” CD into the CD-ROM drive.
2. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD, as shown below:

```

. . .
. . .
. . .
/cdrom/server_connect_397 on /vol/dev/dsk/c0t2d0/server_connect_
397 read only on (current date and time)

```

## 3. Change directories by entering:

```
cd /cdrom/cdrom0/products
```

## 4. Enter:

```
/usr/sbin/pkgadd -d x25/Image/sparc
```

The program responds:

```
The following packages are available:
```

```
1  SUNWl1c2a    LLC2 kernel modules and include files for Solaris/SPARC
              (sparc) 9.1
2  SUNWl1c2b    LLC2 user programs and man pages for Solaris/SPARC
              (sparc) 9.1
3  SUNWx25a     X.25 kernel modules and include files for Solaris/SPARC
              (sparc) 9.1
4  SUNWx25b     X.25 user programs and libraries for Solaris/SPARC
              (sparc) 9.1
5  SUNWx25h     Solstice X.25 9.1 documentation in HTML
              (all) 1.1
```

```
Select package(s) you wish to process (or 'all' to process
all packages). (default: all) [?,??,q]:
```

## 5. Enter 1 2 3 4

The program responds:

```
Processing package instance <SUNWl1c2a> from
</cdrom/server_connect_397/products/x25/Image/sparc>
```

```
.....
.....
.....
```

```
This package contains scripts which will be executed with super-user
permission during the process of installing this package.
```

```
Do you want to continue with the installation of <SUNWl1c2a> [y,n,?]
```

---

**6. Enter `y`**

The program responds:

```
Installing llc2a
,
,
,
The following files are already installed on the system and are being
used by another package:
*/opt/SUNWconn/man <attribute change only>
*/opt/SUNWconn/man/man7 <attribute change only>

* - conflict with a file which does not belong to any package.

Do you want to install these conflicting files [y,n,?,q]
```

**7. Enter `y`**

The program responds:

```
Installing LLC2 kernel modules and include files for Solaris/SPARC as <SUNWllc2a>
## Installing part 1 of 1.
.....
.....
.....

This package contains scripts which will be executed with super-user
permission during the process of installing this package.

Do you want to continue with the installation of <SUNWx25a> [y,n,?]
```

**8. Enter `y`**

The program responds:

```
Installing X.25 kernel modules and include files for Solaris/SPARC as <SUNWx25a>
## Installing part 1 of 1.
.....
.....
.....

This package contains scripts which will be executed with super-user
permission during the process of installing this package.

Do you want to continue with the installation of <SUNWx25b> [y,n,?]
```

9. Enter `y`

The program responds:

```
Installing X.25 user programs and libraries for Solaris/SPARC as <SUNWx25b>
## Installing part 1 of 1.
.....
Installation of <SUNWx25b> was successful.

The following packages are available:
 1  SUNWl1c2a  LLC2 kernel modules and include files for Solaris/SPARC
      (sparc) 9.1
 2  SUNWl1c2b  LLC2 user programs and man pages for Solaris/SPARC
      (sparc) 9.1
 3  SUNWx25a   X.25 kernel modules and include files for Solaris/SPARC
      (sparc) 9.1
 4  SUNWx25b   X.25 user programs and libraries for Solaris/SPARC
      (sparc) 9.1
 5  SUNWx25h   Solstice X.25 9.1 documentation in HTML
      (all) 1.1

Select package(s) you wish to process (or 'all' to process
all packages). (default: all) [?,??,q]:
```

10. Enter `q`

The program responds with the system prompt.

## 11. Enter:

```
/usr/sbin/pkgadd -d licenses/Image/sparc SUNWcclit SUNWlicsw
```

The program responds:

```
Processing package instance <SUNWcclit> from
</cdrom/server_connect_397/products/Image/sparc>

.....

This package contains scripts which will be executed with super-user
permission during the process of installing this package.

Do you want to continue with the installation of <SUNWcclit> [y,n,?]
```

12. Enter `y`

The program responds:

```
Installing Solstice Connect Center license
information as <SUNWcclit>

## Installing part 1 of 1.
      .....
      .....
This package contains scripts which will be executed
with super-user permission during the process of
installing this package.

Do you want to continue with the installation of
<SUNWlicsw> [y,n,?]
```

13. Enter `y`

The program responds:

```
Installing FlexLM License System as <SUNWlicsw>

## Installing preinstall script.
## Installing part 1 of 1.
      .....
      .....
Installation of <SUNWlicsw> was successful.
#
```

14. Move to the root directory by entering `cd`15. Enter `eject cd`

The X.25 license must now be setup.

## Setting Up the X.25 License

### ⚠ CAUTION:

*Do **not** change the host name of your computer after installing the X.25 license. Changing the system's host name disables the X.25 software license.*

1. Enter the command:

```
/etc/opt/licenses/lit_tty
```

The program responds:

```
Select Product

[ ] Solstice Frame Relay 2.0 for SPARC
[ ] Solstice Frame Relay 2.0 for x86
[ ] Solstice PPP 3.0.1 for SPARC
[ ] Solstice PPP 3.0.1 for x86
[ ] Solstice OSI (Stack) 8.1 for SPARC
[ ] Solstice OSI (Stack) 8.1 for x86
[ ] Solstice FTAM 8.0.2 for SPARC
[ ] Solstice FTAM 8.0.2 for x86
[x] Solstice x.25 for Solaris 2 SPARC 9.1
[ ] Solstice x.25 for Solaris 2 x86 9.1
[ ] Solstice x.400 MTA 9.0 for SPARC
[ ] Solstice x.400 Message Store 9.0 for SPARC
[ ] Solstice SMTP/x.400 Internet Adaptor 9.0 for SPARC

Page 1 of 2
[ ] Exit - Save Licenses          [ ] Exit - Don't Save License
** x=select product and go to license screen **
** Return=next product **
** n=Next Page    p=Previous Page$
```

2. Press Enter repeatedly (do not use the Tab or arrow keys) until the cursor moves to the brackets in front of the line that reads Solstice X.25 for Solaris 2 SPARC 9.1.

3. Enter an `x` in the brackets. The program responds:

```
Solstice X.25 for Solaris 2 SPARC
9.1

Servers: [x] 1 [ ] 3 [ ] 5  **x=select. Tab=next count. Return=server name**

    SERVER NAME                                HOST ID
1: <hostname>                                <hostid>

Phone Number List [ ] USA:      (+1) 800-872-4786
Expiration Date:
Rights to Use: 1                  Data Checksum: aa
Password:                          Password Checksum: xx

Done setting Up This License [x]      Cancel This License [ ]

** x=select/deselect Return=next field **
```

4. Enter an `x` in the brackets between `Servers:` and `1`. Press Enter.
5. Enter the SERVER NAME (Hostname) as recorded earlier in the section "[Retrieving System Information](#)." Press Enter.
6. Enter the HOST ID (Hostid) as recorded earlier in the section "[Retrieving System Information](#)." Press Enter.
7. Pressing Enter, position the cursor on the `Rights to Use:` field. Enter a `1`, and press Enter.
8. With the cursor on the `Password:` field, enter the 21-character password, and press Enter.
9. Before you continue, compare the `Data Checksum` and `Password Checksum` values shown on this screen (in the example on [Page 2-65](#), `ce` and `77`). If the `Rights to Use` and the X.25 password were entered correctly, these checksum values should match the checksum values that are printed on your license information that you received by FAX or electronic mail. These checksum values are identified on your license as the `DC` and `PC` values, and are found just to the right of your password.

10. Enter an `x` in the brackets for the Done Setting Up This License [ ] field.

The program displays a popup screen similar to the following:

```

Solstice X.25 for Solaris 2 SPARC
9.1

Server: [ ] me**
SEI [ ] D
1: pl [ ] 70

Licence information successfully entered for
Solstice X.25 for Solaris 2 SPARC 9.1
Type Any Key to Continue. . .

Phone:
Expiration Date:
Rights to Use: 1 Data Checksum: ce
Password: 08BDAD0311158CDAE0E6E Password Checksum: 77

```

11. Press any key to continue

12. Pressing Enter, move the cursor to the [ ] Exit - Save Licenses field. Enter an `x` in that field.

The program responds:

```

Select Product

[ ] SunLink X.25 8.0.2 for Solaris 2 SPARC 8.0.2
[ ] Solstice Frame Relay 2.0 for SPARC

Licenses are being installed.
Please wait . . .

[ ] Solstice x.400 Message Store 9.0 for SPARC
[ ] Solstice SMTP/x.400 Internet Adaptor 9.0 for SPARC

Page 1 of 2
[x] Exit - Save Licenses [ ] Exit - Don't Save Licenses
** x=select product and go to license screen **
** Return=next product **
** n=Next Page p=Previous Page$

```

When the license installation completes, the program responds:

```

Licenses are being installed.
Please wait . . .

[ ] Solstice x.400 Message Store 9.0 for SPARC
[ ] Solstice SMTP/x.400 Internet Adaptor 9.0 for SPARC

                                     Page 1 of 2
[ ] Exit - Save Licenses           [ ] Exit - Don't Save Licenses
** x=select product and go to license screen **
** Return=next product **
** n=Next Page    p=Previous Page
License Successfully Installed for:
Solstice X.25 for Solaris 2 SPARC 9.1
The license daemon log file is located in /tmp/license_log
Now Execute the Script
/etc/opt/license/LIC_CONFIG_SCRIPT
On Any Other Servers Containing the Product Software
#

```

Disregard the `Now Execute the Script` statement on this screen. This has already been done. The licensing of the X.25 software is complete.

13. Check the `/tmp/license_log` file to verify that the license was installed correctly. The following is an example of a successful log file.

```

16:21:22 (lmgrd) FLEXlm (v4.1) started on cmshost (Sun) (11/5/98)
16:21:22 (lmgrd) FLEXlm Copyright 1988-1994, Globetrotter Software, Inc
16:21:22 (lmgrd) License file: "/etc/opt/licenses/licenses_combined"
16:21:22 (lmgrd) Starting vendor daemons ...
16:21:22 (lmgrd) Started lic.SUNW
16:21:24 (lic.SUNW) Not logging IN messages
16:21:24 (lic.SUNW) Not logging OUT messages
16:21:24 (lic.SUNW) Not logging QUEUED messages
16:21:24 (lic.SUNW) Server started on cmshost for: solstice_x.25

```

---

# Installing *INFORMIX*

---

## Overview

Installing the *INFORMIX* software for R3V8 consists of the following tasks:

- Set the environment
  - Install the *INFORMIX* Structured Query Language (SQL) 7.20 package (optional)
  - Install the *INFORMIX* Standard Engine (SE) 7.22 package (required)
  - Install the *INFORMIX* Runtime ESQL 9.14 package (required)
  - Install the *INFORMIX* International Language Supplement (ILS) 2.11 package (required).
- 

## Platform Considerations

- All platforms.
- 

## Prerequisites

- The *Solaris 7* operating system must be installed.
- Verify that you are logged in as *root* at the console.
- Obtain the “*INFORMIX* SQL Version 7.20” CD, License serial number (S/N), and Serial Number Key (optional).
- Obtain the “*INFORMIX* SE Version 7.22” CD, License S/N, and Serial Number Key (required).
- Obtain the “Runtime ESQL 9.14” CD, License S/N, and Serial Number Key (required).
- Obtain the “*INFORMIX* ILS Version 2.11” CD (required).

## Setting Up the *INFORMIX* Environment

1. Set the terminal type by entering:

```
TERM=sun-cmd
export TERM
```

2. Add a new group and user to the system by entering:

```
groupadd -g 100 informix
useradd -g informix -u 100 -m -d /opt/informix
informix
```

3. Set the environment variables by entering:

```
INFORMIXDIR=/opt/informix
export INFORMIXDIR
PATH=$PATH:$INFORMIXDIR/bin
export PATH
```

The *INFORMIX* installation environment is now set.

## Installing the *INFORMIX SQL* 7.20 Package (Optional)

This software package is required only if you are using custom reports. If you do not need this package, skip this section and go to the [“Installing the \*INFORMIX SE 7.22 Package \(Required\)\*”](#) section on [Page 2-71](#).

1. Use the following table to record the Serial Number and Serial Number Key for this *INFORMIX* package.

Serial Number	
Serial Number Key	

2. Load the “*INFORMIX SQL 7.20*” CD into the CD-ROM drive.

3. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD, as shown below:

```
. . .
. . .
. . .
/cdrom/unnamed_cdrom on /vol/dev/dsk/c0t2d0/unnamed_cdrom read
only on (current date and time)
```

4. Change to the *INFORMIX* directory by entering:

```
cd $INFORMIXDIR
```

5. To verify that you are in the *INFORMIX* directory, enter:

```
pwd
```

The system should respond:

```
/opt/informix
```

6. Enter the following command to copy the *INFORMIX* SQL files from the CD-ROM to the current directory:

```
tar xvf /cdrom/cdrom0/sql.tar
```

The program responds:

```
x installsql, XXX bytes, XX tape blocks
x bin/cace, XXX bytes, XX tape blocks
. . . . .
. . . . .
. . . . .
x gls/lc11/os/sv.lc, XXX bytes, XX tape blocks
```

7. Start the *INFORMIX* SQL package installation by entering:

```
./installsql
```

The program responds:

```
INFORMIX-SQL Version 7.20.UC1
Copyright (C) 1984-1996 Informix Software, Inc.

Installation Script

This installation procedure must be run by root (super-
user). It will change the owner, group, and mode of all
files of this package in this directory. There must be a
user "informix" and a group "informix" known to the system.

Press RETURN to continue,
or the interrupt key (usually CTRL-C or DEL) to abort.
```

8. Press Enter to continue with the installation procedure. The program responds:

```
Enter your serial number (e.g.,INF#R999999) >
```

9. Enter the 11-character License S/N (serial number) that is on your license. The program responds:

```
Enter your serial number KEY (uppercase letters only) >
```

10. Enter the 6-character Serial Number Key that is on your license. The program responds:

```
WARNING!
```

```
      This software, and its authorized use and number of
users, are subject to the applicable license agreement with
Informix Software, Inc. If the number of users exceeds the
licensed number, the excess users may be prevented from using
the software. UNAUTHORIZED USE OR COPYING MAY SUBJECT YOU AND
YOUR COMPANY TO SEVERE CIVIL AND CRIMINAL LIABILITIES.
```

```
Press RETURN to continue,
or the interrupt key (usually CTRL-C or DEL) to abort.
```

- Press Enter to continue with the installation procedure. The program responds:

```

Installing directory .
. . . . .
. . . . .
. . . . .
Installation of INFORMIX-SQL complete.
#

```

- Enter `eject cd`

## Installing the *INFORMIX SE* 7.22 Package (Required)

- Use the following table to record the Serial Number and Serial Number Key for this INFORMIX package.

Serial Number	
Serial Number Key	

- Load the “*INFORMIX SE* Version 7.22” CD into the CD-ROM drive.

After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD as shown below:

```

. . .
. . .
. . .
/cdrom/unnamed_cdrom on /vol/dev/dsk/c0t2d0/unnamed_cdrom read
only on (current date and time)

```

- Change to the *INFORMIX* directory by entering:

```
cd $INFORMIXDIR
```

- To verify that you are in the *INFORMIX* directory, enter `pwd`. The system should respond:

```
/opt/informix
```

5. Enter the following command to copy the *INFORMIX* SE files from the CD-ROM to the current directory:

```
tar xvf /cdrom/cdrom0/se.tar
```

The program responds:

```
x installse, XXX bytes, XX tape blocks
x bin/secheck, XXX bytes, XX tape blocks
. . . . .
. . . . .
. . . . .
x gls/lc11/os/sv.lc, XXX bytes, XX tape blocks
#
```

6. Enter the following to start the installation of the *INFORMIX* SE software package:

```
./installse
```

The program responds:

```
INFORMIX-SE Version 7.22.UC1
Copyright (C) 1984-1996 Informix Software, Inc.

Installation Script

This installation procedure must be run by root (super-user).
It will change the owner, group, and mode of all files of this
package in this directory. There must be a user "informix" and
a group "informix" known to the system.

Press RETURN to continue,
or the interrupt key (usually CTRL-C or DEL) to abort.
```

7. Press Enter to continue with the installation procedure. The program responds:

```
Enter your serial number (e.g., INF#R999999) >
```

8. Enter the 11-character License S/N (serial number) that is on your license. The program responds:

```
Enter your serial number KEY (uppercase letters only) >
```

- Enter the 6-character Serial Number Key that is on your license. The program responds:

WARNING!

This software, and its authorized use and number of users, are subject to the applicable license agreement with Informix Software, Inc. If the number of users exceeds the licensed number, the excess users may be prevented from using the software. UNAUTHORIZED USE OR COPYING MAY SUBJECT YOU AND YOUR COMPANY TO SEVERE CIVIL AND CRIMINAL LIABILITIES.

Press RETURN to continue,  
or the interrupt key (usually CTRL-C or DEL) to abort.

- Press Enter to continue with the installation. The program responds:

```
Installing directory .
. . . . .
. . . . .
. . . . .
Installation of INFORMIX-SE complete.
#
```

- Enter: `eject cdrom`

## Installing the *INFORMIX* Runtime ESQL 9.14 Package (Required)

- Use the following table to record the Serial Number and Serial Number Key for this *INFORMIX* package.

Serial Number	
Serial Number Key	

- Verify that the “*INFORMIX* ESQL Version 9.14” CD is already loaded in the CD-ROM drive.
- After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD, as shown below:

```
/cdrom/unnamed_cdrom on /vol/dev/dsk/c0t2d0/unnamed_cdrom read
only on (current date and time)
```

4. Change to the *INFORMIX* directory by entering:

```
cd $INFORMIXDIR
```

5. To verify that you are in the *INFORMIX* directory, enter

```
pwd
```

6. The system should respond:

```
/opt/informix
```

7. Enter the following command to copy the *INFORMIX* ESQL files from the CD-ROM to the current directory:

```
tar xvf /cdrom/cdrom0/conn.tar
```

The program responds:

```
x conncontent.tar, 22489600 bytes, 43925 tape blocks
x installconn, 10704 bytes, 21 tape blocks
```

8. Enter the following to start the installation of the *INFORMIX* ESQL software package:

```
./installconn
```

The program responds:

```
INFORMIX-Connect Version 2.02.UC4
Copyright (C) 1984-1998 Informix Software, Inc.
cat: cannot open /opt/informix/etc/ClientSDK-cr
```

```
Your existing INFORMIX shared libraries, if any, will be
replaced and upgraded.
Are you sure? [yes/no]
```

9. Ignore the "cat" message, and enter *y*. The program responds:

```
Is I-Connect being installed along with Informix Dynamic
Server with Universal Data Option (Release 9, requires to
be run as user "informix")?
(yes or no)
```

---

10. Enter `n`. The program responds:

```
Extracting files from conncontent file...

Installing I-Connect as user "root"...

Installation Script

Installation Script Requirements:
- A user "informix" and a group "informix" must be known
  to the system.
- The product source files must have been loaded by user
  root

- This installation procedure must be run by user root.
This script will change the owner, group, and mode of
many of the files of this package in this directory.
Press RETURN to continue, or the interrupt key
(usually CTRL-C or DEL) to abort.
```

11. Press Enter to continue with the installation procedure. The program responds:

```
Enter your serial number (e.g.,INF#R999999) >
```

12. Enter the 11-character License S/N (serial number) that is on your license. The program responds:

```
Enter your serial number KEY (uppercase letters only) >
```

13. Enter the 6-character Serial Number Key that is on your license. The program responds:

```
WARNING!
```

```
      This software, and its authorized use and number of
users, are subject to the applicable license agreement with
Informix Software, Inc. If the number of users exceeds the
licensed number, the excess users may be prevented from using
the software.  UNAUTHORIZED USE OR COPYING MAY SUBJECT YOU AND
YOUR COMPANY TO SEVERE CIVIL AND CRIMINAL LIABILITIES.
```

```
Press RETURN to continue,
or the interrupt key (usually CTRL-C or DEL) to abort.
```

14. Press Enter to continue with the installation procedure. The program responds:

```
Installing directory .  
.....  
.....  
.....  
Installation of INFORMIX-Connect complete.  
#
```

15. Enter `eject cdrom` to eject the CD-ROM from the computer.
16. Remove the CD-ROM from the disk tray and place the CD-ROM back in its case. You must now install the *INFORMIX* ILS software.

## Installing the *INFORMIX* ILS 2.11 Package (Required)

1. Load the "*INFORMIX ILS Version 2.11*" CD into the CD-ROM drive.
2. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD, as shown below:

```
.....  
.....  
.....  
/cdrom/volume_1 on /vol/dev/dsk/c0t2d0/volume_1 read only  
on (current date and time)
```

3. Change to the *INFORMIX* directory by entering:  
`cd $INFORMIXDIR`
4. To verify that you are in the *INFORMIX* directory, enter `pwd`. The system should respond:

```
/opt/informix
```

5. Enter the following command to start the *INFORMIX* ILS installation program:

```
sh /cdrom/cdrom0/install
```

The program responds:

```
INTERNATIONAL LANGUAGE SUPPLEMENT USER INTERFACE LANGUAGE

(1) English           (5) Russian
(2) German            (6) Polish
(3) French            (7) Czech
(4) Spanish           (8) Slovak

(9) Help
(10) Exit

Select installer language?
```

6. Enter the number that corresponds with the language you wish to use during the installation program (for example, enter 1 to select English). If you select a language other than English, you must also select a display character set. After you make that selection, the program responds:

```
INFORMIX INTERNATIONAL LANGUAGE SUPPLEMENT (ILS)
INSTALLER FOR ALL UNIX PLATFORMS

Choose install type:
(1) Express Install
    Installs everything relating to one or more languages.

(2) Custom Install
    You specify exactly what you want to install.

Other options:
(3) Help
    Displays information on the contents of this package,
    and explains the options on this screen.

(4) Exit
    Exit this installer.

(E)nglish (D)eutsch/German (F)rancais/French e(S)panol/Spanish
(R)ussian (P)oliski/Polish (C)ekych/Czech s(L)ovyoch/Slovak

Enter one choice, and hit ENTER:
```

7. Enter 2 to select Custom Install. The program responds:

```

                                Custom Install
                                -----

(1) User interface
    Installs a localised user interface for Servers and Tools.

(2) Locale
    Installs locales by language, territory and code page.

(3) Operating System locales
    Installs operating system equivalent locales.

(4) Code set conversion
    Installs code set conversion files between code pages.

(5) Help                                (6) GLS source install [Enabled]
(7) Previous Screen                    (8) Exit

(E)nglish (D)eutsch/German (F)rancais/French e(S)panol/Spanish
(R)ussian (P)oliski/Polish (C)ekych/Czech   s(L)ovych/Slovak

Select the components to install:

```

8. Enter 2 4 to select the Locale and Code set conversion options. The program responds:

```

LOCALES - LANGUAGES

Install locales and associated character maps for what languages?

(1) Arabic          (11) Greek          (21) Romanian
(2) Bulgarian      (12) Hebrew         (22) Russian
(3) Chinese         (13) Icelandic     (23) Serbo-Croatian
(4) Czech           (14) Italian        (24) Slovak
(5) Danish          (15) Japanese       (25) Spanish
(6) Dutch           (16) Korean         (26) Swedish
(7) English         (17) Latvian        (27) Thai
(8) Finnish         (18) Norwegian     (28) Turkish
(9) French          (19) Polish         (29) Ukrainian
(10) German         (20) Portuguese

(30) Help           (31) All Of The Above
(32) Custom Screen (33) Exit

(E)nglish (D)eutsch/German (F)rancais/French e(S)panol/Spanish
(R)ussian (P)oliski/Polish (C)ekych/Czech   s(L)ovych/Slovak

Enter one or more choices, separated with spaces, and hit ENTER:

```

9. Enter 7 15 to select English and Japanese. The program responds:

```
LOCALES - TERRITORIES
```

```
Install English language locales for what territories?
```

- (1) Australia
- (2) United Kingdom
- (3) United States
  
- (4) Help
- (5) All Of The Above
- (6) Custom Screen
- (7) Exit

```
(E)nglish (D)eutsch/German (F)rancais/French e(S)panol/Spanish  
(R)ussian (P)oliski/Polish (C)ekych/Czech s(L)ovych/Slovak
```

```
Enter one or more choices, separated with spaces, and hit ENTER:
```

10. Enter 3 to select United States. The program responds

```
LOCALE - CODESETS
```

```
Install English language locales for what codesets?
```

- (1) ISO 8859-1
- (2) DOS Code Page 850
- (3) Windows CP 1252
- (4) UNICODE
- (5) UTF8
  
- (6) Help
- (7) All Of The Above
- (8) Custom Screen
- (9) Exit

```
(E)nglish (D)eutsch/German (F)rancais/French e(S)panol/Spanish  
(R)ussian (P)oliski/Polish (C)ekych/Czech s(L)ovych/Slovak
```

```
Enter one or more choices, separated with spaces, and hit ENTER:
```

---

**11. Enter 5 to select UTF8. The program responds:**

```
LOCALE - CODESETS

Install Japanese language locales for what codesets?

(1) Standard-Shift-JIS
(2) Shift-JIS+JISX0212
(3) UJIS/EUC
(4) UTF8

(4) Help                (5) All Of The Above
(6) Custom Screen      (7) Exit

(E)nglish (D)eutsch/German (F)rancais/French e(S)panol/Spanish
(R)ussian (P)oliski/Polish (C)ekych/Czech s(L)ovych/Slovak

Enter one or more choices, separated with spaces, and hit ENTER:
```

**12. Enter 4 to select UTF8. The program responds:**

```
CODESET CONVERSION REGIONS

Choose the regions for which you require codeset conversion tables.

(1) Arabic                (7) Japanese
(2) Baltic                (8) Korean
(3) Cyrillic              (9) Simplified Chinese
(4) Eastern European     (10) Trad. Chinese
(5) Greek                 (11) Turkish
(6) Hebrew                (12) Western European

(13) Help                 (14) All Of The Above
(15) Custom Screen       (16) Exit

(E)nglish (D)eutsch/German (F)rancais/French e(S)panol/Spanish
(R)ussian (P)oliski/Polish (C)ekych/Czech s(L)ovych/Slovak

Enter one or more choices, separated with spaces, and hit ENTER:
```

13. Enter 7 12 to select Japanese and Western Europe. The program responds:

CODESET CONVERSION TABLES - CODESETS

Install Japanese codeset conversion tables for what codesets?

- (1) Shift-JIS+JISX0212
- (2) Standard-Shift-JIS
- (3) UJIS/EUC
- (4) UNICODE
- (5) UTF8

- (6) Help
- (7) All Of The Above
- (8) Custom Screen
- (9) Exit

(E)nglish (D)eutsch/German (F)rancais/French e(S)panol/Spanish  
(R)ussian (P)oliski/Polish (C)ekych/Czech s(L)ovych/Slovak

Select two or more options. All available combinations of the selected options will be installed.

14. Enter 1 2 5 to select Shift-JIS+JISX0212, Standard-Shift-JIS, and UTF8. The program responds:

CODESET CONVERSION TABLES - CODESETS

Install Western European codeset conversion tables for what codesets?

- (1) ASCII 7-bit
- (2) DOS Code Page 437
- (3) DOS Code Page 850
- (4) DOS Code Page 860
- (5) DOS Code Page 863
- (6) DOS Code Page 865
- (7) EBCDIC
- (8) HP-Roman8
- (9) IBM CCSID 00273
- (10) IBM CCSID 00277
- (11) IBM CCSID 00278
- (12) IBM CCSID 00280
- (13) IBM CCSID 00284
- (14) IBM CCSID 00285
- (15) IBM CCSID 00297
- (16) IBM CCSID 00500
- (17) IBM CCSID 871
- (18) ISO-7-Danish
- (19) ISO-7-German
- (20) ISO 8859-1
- (21) UNICODE
- (22) UTF8
- (23) Windows CP 1252

- (24) Help
- (25) All Of The Above
- (26) Custom Screen
- (27) Exit

(E)nglish (D)eutsch/German (F)rancais/French e(S)panol/Spanish  
(R)ussian (P)oliski/Polish (C)ekych/Czech s(L)ovych/Slovak

Select two or more options. All available combinations of the selected options will be installed.

15. Enter 20 22 to select ISO 8859-1 and UTF8. The program responds

```
SUMMARY: You have chosen to install the following
```

```
-----  
Installing locales:
```

```
English           United States     UTF8
```

```
Japanese          Japan             UTF8
```

```
Installing codeset conversion tables:
```

```
Japanese          Shift-JIS+JISX0212  
                  Standard-Shift-JIS  
                  UTF8
```

```
Western European ISO 8859-1  
                  UTF8
```

```
Hit ENTER to confirm or 'q' to return to main menu.
```

16. Press Enter to begin installation. The program responds:

```
Installing international software Please wait...
```

```
Installing gls...
```

```
Installation complete.
```

```
See $INFORMIXDIR/ils.log for a list of installed files.
```

```
See $INFORMIXDIR/release/README and
```

```
$INFORMIXDIR/release/ILS_COMPAT for further information.
```

```
Hit ENTER to return to main menu...
```

17. Press Enter. The program responds:

```

                                INFORMIX INTERNATIONAL LANGUAGE SUPPLEMENT (ILS)
                                INSTALLER FOR ALL UNIX PLATFORMS

Choose install type:
  (1) Express Install
      Installs everything relating to one or more languages.

  (2) Custom Install
      You specify exactly what you want to install.
Other options:
  (3) Help
      Displays information on the contents of this package,
      and explains the options on this screen.
  (4) Exit
      Exit this installer.

(E)nglish (D)eutsch/German (F)rancais/French e(S)panol/Spanish
(R)ussian (P)oliski/Polish (C)ekych/Czech   s(L)ovych/Slovak

Enter one choice, and hit ENTER:
```

18. Enter 4 to exit the installation program. The program responds:

```
Exiting the International Language Supplement installer.
```

19. Enter `eject cdrom` to eject the CD-ROM from the computer.

20. Remove the CD-ROM from the disk tray and place the CD-ROM back in its case.

## Installing *DiskSuite*

Installing *DiskSuite* includes the following:

- Installing *Solstice DiskSuite* software
  - Installing *Sun Solaris* patches
  - Setting up *Solstice DiskSuite*.
- 

## Installing the *Solstice DiskSuite* Software

### Overview

The *Solstice DiskSuite* software package allows the disks of the system to be managed as if they were a single file system.

### Platform Considerations

- All platforms.

### Prerequisites

- The *Solaris 7* operating system must be installed.
- Verify that you are logged in as *root* at the console.
- Obtain the “*Solaris Easy Access Server 2.0*” CD.
- You must have partitioned the hard disks for the *Solstice DiskSuite* system as specified in [“Partitioning the Hard Disks” on Page 2-18](#).

### Procedure

1. Load the “*Solaris Easy Access Server 2.0*” CD into the CD-ROM drive.
2. Enter `cd` to move to the root directory.

3. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD as shown below:

```
.  
.  
/cdrom/solaris_easy_access_server_2_0 on /vol/dsk/c0t2d0/disk  
read only on (current date and time)
```

4. Enter:

```
/usr/sbin/pkgadd -d /cdrom/cdrom0/products/DiskSuite_4.2/sparc SUNWmd
```

The program responds:

```
This package contains scripts which will be executed with  
super-user permissions duringthe process of installing this  
package.
```

```
Do you want to continue with installation of  
<SUNWmd> [y. n, ?]
```

5. Enter `y`. The program responds:

```
Installing Sosltime DiskSuite as <SUNWmd>  
....  
##Installation of <SUNWmd>was successful.
```

6. Enter `eject cd`

# Installing the *Sun Solaris* Patches

## Overview

The *Sun Solaris* patches are delivered with the CMS software.

## Platform Considerations

- All platforms.

## Prerequisites

- The *Solaris 7* operating system must be installed.
- All *Solaris* packages must be installed (HSI/S, HSI/P, SAI/P, X.25) as required by your particular system configuration.
- The *Solstice DiskSuite* software must be installed.
- Verify that you are logged in as *root* at the console.
- Obtain the “*CentreVu* Call Management System” CD

## Procedure

1. Load the “*CentreVu* Call Management System” CD into the CD-ROM drive.
2. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD as shown below:

```
/cdrom/cms on /vol/dev/dsk/c0t2d0/cms read only on  
(current date and time)
```

3. Begin the installation by entering the following:

```
/usr/sbin/pkgadd -d /cdrom/cdrom0 spatches
```

The program responds:

```
This package contains scripts which will be executed with  
super-user permission during the process of installing  
this package.
```

```
Do you want to continue with the installation of  
<spatches> [y,n,?]
```

4. Enter `y` to continue. The program responds:

```
Installing CMS Supplied Solaris Patches as <spatches>
. . .
Installation of <spatches> was successful.
```

5. To continue installing the patches, enter:

```
/tmp/patches/install_patches | tee -a /var/sadm/spatch.log
```

The program responds:

```
Generating list of files to be patched...
Verifying sufficient filesystem capacity (exhaustive method)
Installing patch packages...

Patch number 103461-18 has been successfully installed.
See /var/sadm/patch/103461-18/log for details

Patch packages installed:
    SUNWmfrun
```

The program generates various lists of files to be patched. This can take from 30 minutes to several hours to process, depending on the number of patches and the CMS computer. When it finishes, the program displays the system prompt.

6. Reboot the system by entering:

```
/usr/sbin/shutdown -y -i6 -g0
```

7. Log in as *root*. The *Sun Solaris* patches are installed and the system kernel has been rebuilt.

Do *not* remove the “CentreVu Call Management System” CD from the CD-ROM drive.

---

## Changing Directory Permissions

1. To change directory permissions for the `etc` directory, enter:

```
installf SUNWcsr /etc d 0755 root sys
```

# Setting Up *Solstice* *DiskSuite*

## Overview

This procedure configures *Solstice* DiskSuite for the system.

### ⇒ NOTE:

Separate procedures are provided for unmirrored and mirrored systems. For more information about disk-mirrored CMS systems, see *CentreVu® CMS Disk-Mirrored Systems* (585-210-940).

## Platform Considerations

- All platforms

## Prerequisites

- The *Solaris 7* operating system must be installed
- The *Solstice DiskSuite* software must be installed
- The *Solaris* patches must be installed
- Verify that you are logged in as *root* at the console
- The “*CentreVu* Call Management System” CD should be loaded in the CD-ROM drive

## Configuring DiskSuite on an unmirrored system

This procedure configures DiskSuite on an unmirrored system.

1. Enter:

```
stty erase <Ctrl-H>
```

(where *<ctrl-H>* means “press/hold Control as you press H”)

The `stty` command sets up your backspace key as an actual backspace. If you do not enter this command, you will have to use the Delete key as a backspace.

2. Enter the following commands:

```
mkdir /olds
cp /cdrom/cdrom0/cms/reloc/rdonly/olds_install/* /olds
cd /olds
chmod +x /olds/olds
```

3. Create system files for the *Solstice DiskSuite* software by entering these commands:

```
PATH=$PATH:/usr/opt/SUNWmd/sbin
export PATH
/olds/olds -check_disks
```

The system responds:

```
scsi=c1
number of external scsi controllers with disks is = 1
number of disks is = 2
checking device: c0t0d0
Warning: Current Disk has mounted partitions.
checking device: c0t2d0
device: c0t2d0 will not be used
checking device: c1t0d0
checking device: c[0-3]t1[0-9]d0
device: c[0-3]t1[0-9]d0 will not be used
valid disks are c0t0d0 c1t0d0
Warning: Current Disk has mounted partitions.
disk:c0t0d0 is partitioned ok
disk:c1t0d0 is partitioned ok
Success, checking disks.
```

 **NOTE:**

If this command fails, see “[Troubleshooting a Solstice DiskSuite Software Installation](#)” in Chapter 5, “[Solving Installation-Related Problems](#)”.

4. Enter the following:

```
/olds/olds -mk_files
```

The system responds:

```
scsi=c1
number of external scsi controllers with disks is = 1
number of disks is = 2
Success, creating md.tab.new and/or vfstab.new.
```

5. When the system prompt reappears, verify that all the disk drives on your system have been recognized. To do that, enter:

```
cat /olds/md.tab.new
```

Find the `#/cms` section; it should reflect the precise number of disk drives on your system. The example shown below shows two disk drives on the system:

```
#state database replicas
mddb00 c0t0d0s1
mddb01 c1t0d0s0

#/cms
d19 2 1 /dev/rdisk/c0t0d0s3 1 /dev/rdisk/c1t0d0s1
d21 -m d19
```

6. If everything appears to be correct, continue with Step 7.

If there is a discrepancy in the number of disks, check for disk recognition errors using the procedure, [“Checking for Disk Recognition Errors” on Page 2-95](#).

7. Save the original `vfstab` and `md.tab` files with the following commands:

```
cp /etc/vfstab /etc/vfstab.orig
cp /etc/opt/SUNWmd/md.tab /etc/opt/SUNWmd/md.tab.orig
```

## 8. Enter:

```
/olds/olds -metadb
```

The program responds:

```
scsi=c1
number of external scsi controllers with disks is = 1
number of disks is = 2
checking device: c0t0d0
Warning: Current Disk has mounted partitions.
checking device: c0t2d0
device: c0t2d0 will not be used
checking device: c1t0d0
checking device: c[0-3]t1[0-9]d0
device: c[0-3]t1[0-9]d0 will not be used
valid disks are c0t0d0 c1t0d0
Warning: Current Disk has mounted partitions.
disk:c0t0d0 is partitioned ok
disk:c1t0d0 is partitioned ok
Success, setting up metadb replicas.
```

## 9. Enter:

```
/olds/olds -setup
```

The `olds -setup` command may take some time. It should take about 1 minute of run time for each gigabyte of hard disk space on your system.

If all of the commands succeed, the system responds with a series of lines reflecting the structure of your disk system. Those lines will look something like the following (the specific disk names will vary from system to system):

```
scsi=c1
number of external scsi controllers with disks is = 1
number of disks is = 2
checking device: c0t0d0
Warning: Current Disk has mounted partitions.
checking device: c0t2d0
device: c0t2d0 will not be used
checking device: c1t0d0
checking device: c[0-3]t1[0-9]d0
device: c[0-3]t1[0-9]d0 will not be used
valid disks are c0t0d0 c1t0d0
Warning: Current Disk has mounted partitions.
disk:c0t0d0 is partitioned ok
disk:c1t0d0 is partitioned ok
d19: Concat/Stripe is setup
.
.
```

The program begins to construct the new file system. When the “Success...” message displays and the system prompt reappears, the file system is complete and you are ready to continue with the installation. The program responds:

```
/dev/md/rdisk/d19:14422590 sectors in 15262 cylinders of 15 tracks, 63
sectors
    7042.3MB in 954 cyl groups (16 c/g, 7.38MB/g, 3584 i/g)
super-block backups (for fsck -F ufs -o b=#) at:
    32, 15216, 30400, 45584, 60768, 75952, 91136, 106320, 121504, 136688,
    167056, 182240, 197424, 212608, 227792, 241952, 257136, 272320, 287504,
    .
    .
    .
14198416, 14213600, 14228784, 14243968, 14259152, 14273312, 14288496,
14303680, 14318864, 14334048, 14349232, 14364416, 14379600, 14394784,
14409968,
ufs fsck: sanity check: /dev/md/rdisk/d19 okay
Success, system set up successfully
```

If these commands fail, make a note of the error message and see the [“Solving Installation-Related Problems” on page 5-1](#)”.

## Configuring DiskSuite on a mirrored system

10. To create and mount /cms, enter:

```
mkdir /cms  
mount /cms
```

11. Enter: `eject cdrom`

This procedure configures DiskSuite on a unmirrored Enterprise 3000 or 3500 system.

1. Enter:

```
stty erase <Ctrl-H>
```

(where `<ctrl-H>` means “press/hold Control as you press H”)

The `stty` command sets up your backspace key as an actual backspace. If you do not enter this command, you will have to use the Delete key as a backspace.

2. Enter the following commands:

```
mkdir /olds  
cp /cdrom/cdrom0/cms/reloc/rdonly/olds_install/* /olds  
cd /olds  
chmod +x /olds/olds
```

3. To alter the path, enter:

```
export PATH=$PATH:/usr/opt/SUNWmd/sbin/:/olds
```

4. Enter:

```
olds -mirrored -check_disks
```

5. Enter:

```
olds -mirrored -mk_files
```

6. Enter:

```
olds -mirrored -metadbs
```

7. Enter:

```
olds -mirrored -setroot
```

8. To reboot, enter:

```
/usr/sbin/shutdown -y -g0 -i0
```

When the ok prompt is displayed, enter:

```
boot -r
```

When the reboot is finished, log in as root.

9. To setup the /cms metadevices, enter the following commands:

```
export PATH=$PATH:/olds:/usr/opt/SUNWmd/sbin
```

```
olds -mirrored -setup
```

The system should respond:

```
Success, /cms mirrored successfully
```

10. Enter the following commands:

```
mkdir /cms
```

```
mount /cms
```

11. To verify the DiskSuite configuration, enter:

```
df -k
```

The output format should be similar to the following example:

Filesystem	kbytes	used	avail	capacity	Mounted
/dv/md/dsk/d13	xxxxx	xxxxx	xxxxx	xx%	/
proc	xxxxx	xxxxx	xxxxx	xx%	/proc
fd	xxxxx	xxxxx	xxxxx	xx%	/dev/fd
/dev/md/dsk/d21	xxxxx	xxxxx	xxxxx	xx%	/cms

To confirm that DiskSuite has administered all of the disks, verify that the "/dev/md/dsk/d21" line is present in the output.

## Checking for Disk Recognition Errors

The procedures in the section will help you to diagnose problems with unrecognized disk drives. This procedure is different for the different hardware platforms.

### CAUTION:

*Use this procedure only if the DiskSuite scripts indicate there is a disk recognition error. Do NOT do this as part of the normal installation procedure.*

## Disk Recognition Errors on *Ultra 5*

1. Reboot the system with an `init 0` command. The system reboots and displays the `ok` prompt.
2. Turn off the system unit.
3. Turn off the system monitor.
4. Turn off all external devices (such as disk drives, tapes drives, and NTSs) starting with the device closest to the system unit and working toward the farthest device.
5. Check all external device connections to verify that they are secure. Also check the SCSI IDs on the disk drives to verify that no two drives have the same ID.
6. Turn on the power to the system units in the opposite order in which you powered them off. That is, power on the external devices first, working your way toward the system unit. Then power on the system unit itself and, finally, the system monitor.

When you power on the system unit, the system begins to boot. Interrupt the boot by pressing the  and  keys simultaneously. The system responds with the `ok` prompt.

7. Enter:

```
setenv auto-boot? false
```

This keeps the system from rebooting when you do a reset.

8. Enter:

```
reset-all
```

The system resets and responds with the `ok` prompt.

9. To verify that the system sees all IDE devices, enter:

```
probe-ide
```

The program responds similar to the following:

```
Device 0 ( Primary Master )
        ATA Model: ST34342A

Device 1 ( Primary Slave )
        Not present

Device 2 ( Secondary Master )
        Removeable ATAPI Model: CRD-8240B

Device 3 ( Secondary Slave )
        Removeable ATAPI Model:
```

10. To verify that the system sees all SCSI devices, enter:

```
probe-scsi-all
```

The program responds similar to the following:

```
/pci@1f,0/pci@1/pci@1/SUNW,ispw@4
Target 0
  Unit 0 Disk          QUANTUM VK4550J SUN4.2G8610
Target 4
  Unit 0 Removeable Tape  TANDBERG SLR5          0906
```

11. Verify that all of the disk drives are recognized. If the devices are still not recognized, see *CentreVu® CMS R3V8 Hardware Maintenance and Troubleshooting* (585-210-919) for more information.

12. When you have verified that the system is recognizing all of its disk drives, enter:

```
setenv auto-boot? true
```

 **CAUTION:**

*If you fail to enter this command, future reboots will stop at the boot prompt instead of proceeding through the normal boot-up.*

13. Enter `boot -r`. The system reboots.
14. Log in as `root`.
15. Repeat the procedures described in [“Configuring DiskSuite on an unmirrored system” on Page 2-88](#), or [“Configuring DiskSuite on a mirrored system” on Page 2-93](#).

## Disk Recognition Errors on Enterprise 3500

1. Reboot the system with an `init 0` command. The system reboots and displays the `ok` prompt.
2. Turn off the system unit.
3. Turn off the system monitor.
4. Turn off all external devices (such as disk drives, tapes drives, and NTSs) starting with the device closest to the system unit and working toward the farthest device.
5. Check all external device connections to verify that they are secure. Also check the SCSI IDs on the disk drives to verify that no two drives have the same ID.
6. Turn on the power to the system units in the opposite order in which you powered them off. That is, power on the external devices first, working your way toward the system unit. Then power on the system unit itself and, finally, the system monitor.

When you power on the system unit, the system begins to boot. Interrupt the boot by pressing the `Stop` and `A` keys simultaneously. The system responds with the `ok` prompt.

7. Enter the following:  

```
setenv auto-boot? false
```

This keeps the system from rebooting when you do a reset.
8. Enter the following:  

```
reset-all
```

The system resets and responds with the `ok` prompt.

9. To verify that the system sees all SCSI devices, enter the following:

```
probe-scsi-all
```

The program responds similar to the following:

```
/sbus@3,0/SUNW,fas@3,8800000
Target 5
  Unit 0   Removeable Tape      EXABYTE  EXB-89008E030203V37f
                                           0060055614
Target 6
  Unit 0   Removeable Read Only device  TOSHIBA
                                           XM6201TASUN32XCD110312/12/97
```

10. Verify that all of the SCSI devices are recognized. If the devices are still not recognized, see *CentreVu® CMS Sun® Enterprise™ 3500 Computer Maintenance and Troubleshooting (585-215-875)* for more information.

11. To verify that the system sees all the fiber channel disk drives, enter:

```
probe-fcal-all
```

The program responds similar to the following:

```
/sbus@2,0/SUNW,socal@d,10000/sf@1,0

/sbus@2,0/SUNW,socal@d,10000/sf@0,0

WWN 20050800209a80fe  Loopid 1
WWN 21000020370e7255  Loopid ef
Disk      SEAGATE ST19171FCSUN9.06117E9822U939
```

12. Verify that all of the fiber channel disk drives are recognized. If the disk drives are still not recognized, see *CentreVu® CMS Sun® Enterprise™ 3500 Computer Maintenance and Troubleshooting (585-215-875)* for more information.

13. When you have verified that the system is recognizing all of its devices, enter:

```
setenv auto-boot? true
```

 **CAUTION:**

*If you fail to enter this command, future reboots will stop at the boot prompt instead of proceeding through the normal boot-up.*

14. Enter `boot -r`. The system reboots.
15. Log in as *root*.
16. Repeat the procedures described in [“Configuring DiskSuite on an unmirrored system” on Page 2-88](#) or [“Configuring DiskSuite on a mirrored system” on Page 2-93](#).

## Disk Recognition Errors on Enterprise 3000

1. Reboot the system with an `init 0` command. The system reboots and displays the `ok` prompt.
2. Turn off the system unit.
3. Turn off the system monitor.
4. Turn off all external devices (such as disk drives, tapes drives, and NTSSs) starting with the device closest to the system unit and working toward the farthest device.
5. Check all external device connections to verify that they are secure. Also check the SCSI IDs on the disk drives to verify that no two drives have the same ID.
6. Turn on the power to the system units in the opposite order in which you powered them off. That is, power on the external devices first, working your way toward the system unit. Then power on the system unit itself and, finally, the system monitor.

When you power on the system unit, the system begins to boot. Interrupt the boot by pressing the  and  keys simultaneously. The system responds with the `ok` prompt.

## 7. Enter:

```
setenv auto-boot? false
```

This keeps the system from rebooting when you do a reset.

## 8. Enter:

```
reset-all
```

The system resets and responds with the `ok` prompt.

## 9. To verify that the system sees all SCSI devices, enter the following:

```
probe-scsi-all
```

The program responds similar to the following:

```
/iommu@f,e0000000/sbus@f.e0001000/esp@3,200000
Target 1
  Unit 0 Disk SEAGATE ST14801 SUN04246266 Copyright (C) 1991
Target 3
  Unit 0 Disk SEAGATE ST14801 SUN04246266 Copyright (C) 1991
. . . . .
. . . . .
Target 6
  Unit 0 Disk Removable Read Only Device SONY CD-ROM CDU-8012
```

10. Verify that all of the disk drives are recognized. If the devices are still not recognized, see *CentreVu® CMS Hardware Maintenance and Troubleshooting* (585-215-861) for more information.

When you have verified that the system is recognizing all of its disk drives, enter the following:

```
setenv auto-boot? true
```

 **CAUTION:**

*If you fail to enter this command, future reboots will stop at the boot prompt instead of proceeding through the normal boot-up.*

11. Enter `boot -r`. The system reboots.
12. Log in as `root`.
13. Repeat the procedures described in [“Configuring DiskSuite on an unmirrored system” on Page 2-88](#) or [“Configuring DiskSuite on a mirrored system” on Page 2-93](#).

## Disk Recognition Errors on SPARCserver

1. Reboot the system with an `init 0` command. The system reboots and displays the `ok` prompt.
2. Turn off the system unit.
3. Turn off the system monitor.
4. Turn off all external devices (such as disk drives, tapes drives, and NTSs) starting with the device closest to the system unit and working toward the farthest device.
5. Check all external device connections to verify that they are secure. Also check the SCSI IDs on the disk drives to verify that no two drives have the same ID.
6. Turn on the power to the system units in the opposite order in which you powered them off. That is, power on the external devices first, working your way toward the system unit. Then power on the system unit itself and, finally, the system monitor.

When you power on the system unit, the system begins to boot. Interrupt the boot by pressing the `Stop` and `A` keys simultaneously. The system responds with the `ok` prompt.

7. Enter:  

```
setenv auto-boot? false
```

This keeps the system from rebooting when you do a reset.

8. Enter:

```
reset
```

The system resets and responds with the `ok` prompt.

9. To verify that the system sees all SCSI devices, enter the following:

```
probe-scsi-all
```

The program responds similar to the following:

```
/iommu@0,10000000/sbus@0,10001000/espdma@5,8400000/esp@5,8800000
Target 3
  Unit 0  Disk      IBM          DORS32160SUN2.1GWA7A96210Z5218
                0933          000116
Target 4
  Unit 0          Removeable Tape  46H6081  07H1118
                TANDBERG TDC 4200  =07:08CREATED053195
Target 6
  Unit 0  Removeable Read Only device  TOSHIBA XM5401...
```

10. Verify that all of the disk drives are recognized. If the devices are still not recognized, see *CentreVu® CMS R3V8 Hardware Maintenance and Troubleshooting* (585-210-919) for more information.

11. When you have verified that the system is recognizing all of its disk drives, enter the following:

```
setenv auto-boot? true
```

 **CAUTION:**

*If you fail to enter this command, future reboots will stop at the boot prompt instead of proceeding through the normal boot-up.*

12. Enter `boot -r`. The system reboots.

13. Log in as *root*.

14. Repeat the procedures described in [“Configuring DiskSuite on an unmirrored system” on Page 2-88](#) or [“Configuring DiskSuite on a mirrored system” on Page 2-93](#).

# Installing CMS Packages

Installing the CMS packages includes:

- Installing the CMS Supplemental Services software
  - Installing CMS software
  - Installing CMS patches
  - Installing the Open Database Connectivity (ODBC) software.
- 

## Installing the CMS Supplemental Services Software

### Overview

This procedure installs the CMS R3V8 Supplemental Services software.

### Platform Considerations

- All platforms.

### Prerequisites

- The *Solaris 7* operating system must be installed.
- Verify that you are logged in as *root* at the console.
- Obtain the “CentreVu CMS Supplemental Services R3V8” CD.
- Record the version number printed on the “CentreVu CMS Supplemental Services R3V8” CD, which is required for input during the procedure.

### Procedure

1. Enter `who -r` to determine the computer state. You should see a message similar to the following:

```
.      run-level 3 <date and time> 3    0 S
```

2. If the computer is *not* in run-level 3, enter the following:

```
/usr/sbin/shutdown -y -i6 -g0
```

3. After the shutdown, log back in as *root*.
4. To download the Installation Manager package from the CD, enter:

```
/usr/sbin/pkgadd -d /cdrom/cdrom0 LUim
```

The program responds:

```
Processing package instance <LUim> from </cdrom/cvx>

Lucent Installation Manager
(sparc) 0.43

Copyright (c) 1998 Lucent Technologies
All Rights Reserved

## Processing package information.
## Processing system information.

Installation of <LUim> was successful.
```

5. Enter

```
/opt/LUim/bin/install 2>&l|tee -a /opt/LUim.log
```

The program responds:

```
Installing OrbixMT
link shared library libDSImt.so
.....

Installation of <LUorbutil> was successful.
```

6. Use the CD version number to replace the *rXvXXX.X* character in the following setup command:

```
/opt/cc/install/ahl.rXvXXX.X/bin/setup
```

7. Enter: `eject cdrom`

# Installing the CMS Software

## Overview

This procedure install the CMS software.

## Platform Considerations

- All platforms

## Prerequisites

- The *Solaris 7* operating system must be installed.
- All the preceding factory software installation requirements in this chapter must be completed.
- Verify that you are logged in as *root* at the console.
- The “*CentreVu* Call Management System” CD should already be loaded in the CD-ROM drive.

## Procedure

1. Enter `who -r` to determine the computer’s state. You should see a message similar to the following:

```
run-level 3 <date and time> 3 0 S
```

2. If the computer is *not* in run-level 3, enter the following:

```
/usr/sbin/shutdown -y -i6 -g0
```

3. After the shutdown, log back in as *root*.
4. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD as shown below:

```
. . .  
/cdrom/cms on /vol/dev/dsk/c0t2d0/cms read only on  
(current date and time)
```

5. Add the CMS package by entering the following:

```
/usr/sbin/pkgadd -d /cdrom/cdrom0 cms
```

The program responds:

```
Processing package instance <cms> from </cdrom/cms>

Lucent Technologies CentreVu(R) Call Management System
(sparc) r3v8xx.x

.
.
* /var/crash <attribute change only>
* /var/crash/cms2 <attribute change only>
  /var/spool/cron/crontabs/root

* - conflict with a file which does not belong to any
package.

Do you want to install these conflicting
files [y,n,?,q]
```

6. Enter `y`. The program responds:

```
## Checking for setuid/setgid programs.

The following files are being installed with setuid and/or
setgid permissions:
  /cms/bin/mqpeek <setuid root>
  /cms/bin/spi <setuid root>
  /cms/perfbins/memsnap2 <setuid root setgid root>
  /cms/toolsbin/chk_ext <setuid root>
  /cms/toolsbin/cmsu <setuid root>
  /cms/toolsbin/initSimConf <setuid root setgid root>
  /cms/toolsbin/psx <setuid root setgid root>
  /cms/toolsbin/setSimLink <setuid root setgid root>
  /cms/toolsbin/shmdump <setgid sys>
  /usr/spool/lp/cmstermDSR <setuid root setgid lp>

Do you want to install these as setuid/setgid files
[y,n,?q]
```

---

**7. Enter `y`**

The program responds:

```
This package contains scripts which will be executed with super-  
user permission during the process of installing this package.
```

```
Do you want to continue with the installation of <cms>  
[y,n,?]
```

**8. Enter `y`**

The program responds:

```
Installing Lucent Technologies CentreVu(R) Call Management  
System as <cms>
```

```
## Executing preinstall script.  
Creating cms group id  
Creating cms user id  
6 blocks  
Assigning a new password for cms  
New password:
```

**9. Enter the password for the cms login. The program responds:**

```
Re-enter new password:
```

**10. Re-enter the password for cms. The program responds:**

```
Creating cmssvc user id  
6 blocks  
Assigning a new password for cmssvc  
New password:
```

**11. Enter the password for the cmssvc login. Please note that the cmssvc login is used only by services; protect the cmssvc password. The program responds:**

```
Re-enter new password:
```

12. Reenter the password for `cmssvc`. The program responds:

```
## Installing part 1 of 1.  
/usr/elog <symbolic link>  
/cms/aas/db/acd1/baas_db.log  
/cms/aas/db/acd2/baas_db.log
```

The program takes up to 40 minutes to download the CMS software from the CD-ROM to the hard disk and to initialize the customer CMS data. A list of files is displayed as the software is downloaded. When the installation is finished, the program responds:

```
Installation of <cms> was successful.
```

```
The machine must now be rebooted in order to ensure  
sane operation. Execute shutdown -y -i6 -g0 and wait for the  
"console login" prompt.
```

13. To begin the shutdown, enter:

```
/usr/sbin/shutdown -y -i6 -g0
```

14. When the system is back up, log in as *root*.

---

## Installing the CMS Patches

### Overview

There are three occasions when you may have to install CMS patches:

- During a factory installation
- Immediately after upgrading CMS
- As a bug fix.

If you are loading patches just after upgrading your system, it is best to turn CMS off until you have the patches installed. The reason is because the prerequisites for patch installation differ with the patch. Some require that CMS be off, others require that data collection be off, and still others require CMS to be in single-user mode. To be absolutely safe, and to help the upgrade proceed as quickly as possible, turn CMS off.

If you are loading patches as a factory installation or a bug fix without upgrading your base load, you may install the patches without turning CMS off. Each patch will let you know if you need to do anything special to accomplish the load.

The readme file for CMS lists CMS run level requirements for the patch.

### ⇒ NOTE:

The features must be authorized on your system before patches can be installed. Call 1-800-242-2121 to have authorizations installed. We recommend that you always install all available patches. If you believe you should not be installing a particular patch, call the National Customer Care Center at 1-800-242-2121, or consult with your Lucent distributor or representative, before deciding to skip it.

## Platform Considerations

- All platforms.

## Prerequisites

- The *Solaris 7* operating system must be installed.
- All the preceding factory software installation requirements in this chapter must be completed.
- Verify that you are logged in as *root* at the console.
- You must have the current `cmssvc` password.
- The “*CentreVu* Call Management System” CD should already be loaded in the CD-ROM drive.

## Procedure

1. Enter `cmssvc` to access the CMS Services menu:

```
Lucent Technologies CentreVu(R) Call Management System Services Menu

Select a command from the list below.
  1) auth_display  Display feature authorizations
  2) auth_set     Authorize capabilities/capacities
  3) run_cms      Turn CentreVu CMS on or off
  4) setup        Set up the initial configuration
  5) swinfo       Display switch information
  6) swsetup      Change switch information
  7) patch_inst   Install a single CMS patch from CD
  8) patch_rmv   Backout an installed CMS patch
  9) load_all     Install all CMS patches found on CD
 10) back_all    Backout all installed CMS patches from machine
Enter choice (1-10) or q to quit:
```

2. Enter `2` to select the `auth_set` option. The authorizations must be set before you can install the patches. Use the default or minimum values for now. The actual values will be entered later in another procedure.
3. Enter `cmssvc` to access the CMS Services menu.
4. Enter `9` to select the `load_all` option to load all of the patches. Enter `7` to select the `patch_inst` option if you want to load one patch at a time.
5. If no patches are found on the CD, the program responds:

```
No CMS patches found on the CD.  
Please check the CD and try again.
```

Continue with [Step 7](#).

6. If patches are found on the CD-ROM, enter `y` if you are loading all of the patches, or enter the patch number if you are loading only one patch. The system installs the patch or patches. As it does so, it displays messages similar to the following for each patch installed:

```
@(#) installpatch 1.0 96/04/01  
cmspx-s  
Generating list of files to be patched...  
Creating patch archive area...  
Saving a copy of existing files to be patched...  
xxxx blocks  
      File compression used  
Installing patch packages...  
  
Doing pkgadd of cmspx-s package:  
Installation of <cmspx-s> was successful.  
  
Patch packages installed:  
      cmspx-s  
  
Patch installation completed.
```

7. Enter: `eject cdrom`

# Installing the Open Database Connectivity Software

## Overview

Use the following procedures to install the *OpenLink*\* ODBC software. For more information about the ODBC feature, see *CentreVu® CMS R3V8 Open Database Connectivity* (585-210-911).

## Platform Considerations

- All platforms.

## Prerequisites

- The *Solaris 7* operating system must be installed
- All the preceding factory software installation requirements in this chapter must be completed
- Obtain the “*CentreVu CMS OPENLINK ODBC Version 1.5 Driver*” CD.
- Verify that you are logged in as *root* at the console

## Procedure

1. Load the “*CentreVu CMS OPENLINK ODBC Version 1.5 Driver*” CD.
2. After about 15 seconds, enter `mount` to verify the name of the CD-ROM. The program responds with a list of devices and file systems currently mounted. The last line should display the installed CD as shown below:

```
      . . .  
      . . .  
/cdrom/odbc_driver on /vol/dev/dsk/c0t2d0/odbc_driver  
read only on (current date and time)
```

3. To create the *OpenLink* directory and change to the new directory, enter the following commands:

```
mkdir /usr/openlink  
cd /usr/openlink
```

4. To copy the ODBC files from the CD-ROM, enter:

```
cp /cdrom/cdrom0/server/inf7.2x/* .
```

---

\**OpenLink* is a trademark of OpenLink Software.

- To install the ODBC files on the system, enter:

```
./install.sh
```

The program responds:

```
Extracting (inf5sol.taz) ..
Extracting (inf7sol.taz) ..
Extracting (odbcsql.taz) ..
Extracting (rqbsql.taz) ...

Enter the name of the user that will own
the programs:
```

- At the blinking prompt, enter `root` as the name of the user who will own the programs. The program responds:

```
Enter the name of the group that will own
the programs:
```

- At the blinking prompt, enter `root` as the name of the group that will own the programs. The program responds:

```
Registering ...
oplrqb is now registered to Lucent Technologies BC
This is a 5 concurrent users license
that will not expire.

TCP/IP Port to use? [8000]
```

- Press Enter.

The program responds:

```
Log File? [www_sv.log]
```

- Press Enter.

The program responds:

```
Log all requests (y/n)? [n]
```

10. Press Enter.

The program responds:

```
Administrator account? [admin]
```

11. Press Enter.

The program responds:

```
Administrator's password? [admin]
```

12. Press Enter.

The program responds:

```
-n Press return to proceed to the next phase of the  
install process:
```

13. Press Enter.

The program displays the *OpenLink Session Rules Book Configuration Utility* menu.

```
Choose an item or type q to quit : q
```

14. Enter: q

The program responds:

```
End of installation.
```

15. Enter:

```
/cms/dc/odbc/odbc_init
```

The program responds:

```
ODBC is already initialized.
```

```
Usage: odbc_init [-l 0-7 OR -d 0-1 OR -r 0-1].
```

16. To verify that the ODBC Request Broker is active on the server, enter:

```
ps -ef | grep oplrqb
```

One of the output lines should show the `oplrqb` process running from the `/usr/openlink/bin` directory:

```
root 3354 3351 0 11:49:43 ?          0:00 /usr/openlink/bin/oplrqb -f
+configfile /cms/dc/odbc/cmsrqb_init +loglevel 5 +l
```

17. Enter: `eject cdrom`

# Installing Visual Vectors Server Software

## Overview

This procedure installs the CentreVu Visual Vectors Server Software.

## Platform Considerations

- All platforms.

## Prerequisites

- The *Solaris 7* operating system must be installed
- All the preceding factory software installation requirements in this chapter must be completed
- Verify that you are logged in as *root* at the console
- Obtain the “CentreVu® Visual Vector Server Software” CD.

## Procedure

1. Load the *CentreVu®* Visual Vector Server Software CD.

2. Enter:

```
pkgadd -d /cdrom/cdrom0 LUfaas
```

```
#
```

3. The system displays information about the CD contents. If this is the first time that Visual Vectors has been installed then the following message is displayed:

```
# The selected base directory </cms/aas> must exist before
installation is attempted.
Do you want this directory created now [y,n,?,q],
Using </cms/aas> as the package base directory?
```

4. Enter: y

As the various packages are installed onto the system you may receive the following message:

```
# * - conflict with a file that does not belong to any package. I
you want to install these conflicting files [y,n,?,q]
```

---

5. Enter: `y`

The system may also display the following message:

```
# This package contains scripts which will be executed with
super-user permission during the process of installing this
package.
Do you want to continue with the installation of Lufaas [y,n,q]
```

6. Enter: `y`

7. The program installs the software and responds:

```
# Installation of <Lufaas> was successful.
```

8. Enter: `setupaas`

9. Select option **1** from the displayed setup menu.

10. Enter the number of allowable concurrent logins. The maximum login number must not exceed the number of licenses which have been purchased.

---

## Starting Visual Vectors Server Software

1. Enter: `setupaas`

The setup menu is displayed.

2. Select option **2** from the displayed setup menu.

The turn on/stop menu is displayed.

3. Select option **1** to start the program.

4. Visual Vectors Server software is now set up and running on the server.

---

# Setting Up CMS

---

## Overview

This section describes:

- Setting authorizations
- Setting up data storage parameters
- Setting up a local area network (LAN) connection to the switch (required only for *DEFINITY* R7 switches, or later)
- Setting up the CMS application.

TSC personnel verify authorizations, set up data storage parameters, and set up the CMS application remotely. On-site technicians should call the TSC to coordinate this process.

---

## Platform Considerations

- All platforms.
- 

## Conventions

Throughout the setup, you will be prompted to enter values specific to the system being installed. These values differ between switch releases. For each question, an appropriate range of values is displayed. These values represent the limits of each range.

---

## Prerequisites

The TSC should verify that the on-site technicians have completed the following tasks:

- Connected the console to the CMS computer
- Connected the CMS computer to the TSC's Remote Maintenance Center (remote console)
- Connected additional terminals and printers to the NTS ports.

- Connected the link between the CMS computer and the switch

⇒ NOTE:

If the hardware link or the Automatic Call Distribution (ACD) feature and CMS is not properly administered, the CMS software cannot communicate with the switch. For switch administration procedures, see *CentreVu® CMS Switch Connections and Administration* (585-215-876).

- Connected the NTS and the CMS computer to the network hub unit. See *CentreVu® CMS R3V6 Sun® SPARCserver™ Computers Connectivity Diagram* (585-215-858), *CentreVu® CMS R3V6 Sun® Enterprise™ 3000 Computer Connectivity Diagram* (585-215-865), *CentreVu® CMS Sun® Enterprise™ 3500 Computer Hardware Connectivity Diagram* (585-215-877), or *CentreVu® CMS Sun® Ultra™ 5 Computer Connectivity Diagram* (585-215-872).

## Setting Authorizations

### Overview

Before setting up CMS, TSC personnel need to set authorizations for CMS features purchased by the customer. Authorizations apply to all administered ACDs.

You can use the `auth_set` option in the CMS Services menu (`cmssvc`) to do the following:

- Set the purchased version of CMS
- Authorize the following packages and features:
  - Forecasting (if the package is not already installed)
  - Vectoring (if no administered ACDs use vectoring)
  - Graphics
  - External Call History (if the package is not already installed)
  - Expert Agent Selection (EAS) (if no administered ACDs use EAS)
  - External Application
  - Vector Directory Numbers (VDNs)

- *CentreVu* Supervisor
- *CentreVu* Report Designer.

- Change the number of agents, ACDs, or Supervisor logins.

## Procedure

1. Access the CMS Services menu by entering the following command:

```
cmssvc
```

The program responds:

```
Lucent Technologies CentreVu(R) Call Management System Services
Menu
```

```
Select a command from the list below.
```

- 1) `auth_display` Display feature authorizations
- 2) `auth_set` Authorize capabilities/capacities
- 3) `run_cms` Turn CentreVu CMS on or off
- 4) `setup` Set up the initial configuration
- 5) `swinfo` Display switch information
- 6) `swsetup` Change switch information
- 7) `patch_inst` Install a single CMS patch from
- 8) `patch_rmv` Backout an installed CMS patch
- 9) `load_all` Install all CMS patches found on CD
- 10) `back_all` Backout all installed CMS patches from machine

```
Enter choice (1-10) or q to quit:
```

2. Enter `2` to select the `auth_set` option. The program responds:

```
Password:
```

3. Enter the appropriate password. This password is available only to authorized personnel.

### NOTE:

Some of the following questions may not appear if the authorization cannot be changed at this time.

The program responds:

```
Is this an upgrade? (y/n):
```

**⇒ NOTE:**

This question occurs the first time you run `auth_set` on the system.

If this is not an upgrade and you enter `n`, the program responds:

```
Purchased version is R3V8. Is this correct? (y/n):
```

4. Enter `y`.

**⇒ NOTE:**

The program uses the above information to populate the “Purchased CMS Release” field of the *System Setup:Switch Setup* screen.

The program continues with the following questions:

```
Authorize installation of forecasting package? (y/n):(default: n)
```

5. Enter `y` if the customer purchased Forecasting; otherwise, press Enter. The program responds:

```
Authorize installation of vectoring package? (y/n): (default: n)
```

6. Enter `y` if the customer purchased vectoring; otherwise, press Enter. The program responds:

```
Authorize use of graphics feature? (y/n): (default: n)
```

7. Enter `y` if the customer purchased Graphics; otherwise, press Enter. The program responds:

```
Authorize use of external call history feature? (y/n): (default: n)
```

8. Enter `y` if the customer purchased the External Call History feature; otherwise, press Enter. The program responds (if the vectoring package is authorized):

```
Authorize use of expert agent selection feature? (y/n): (default: n)
```

9. Enter `y` if the customer purchased the Expert Agent Selection feature; otherwise, press Enter. The program responds:

```
Authorize use of external application feature? (y/n):  
(default: n)
```

10. Enter `y` if the customer purchased the External Application feature; otherwise, press Enter. The program responds:

```
Authorize use of more than 2000 VDNs (yes turns off VDN  
permission checking)? (y/n): (default: n)
```

11. Enter `y` if the customer needs to use more than 2000 VDNs; otherwise, press Enter. The program responds:

```
Enter the number of simultaneous Lucent Technologies CentreVu(R)  
Supervisor logins the customer has purchased  
(2-250): (default: X)
```

12. Enter the number of simultaneous logins purchased. The program responds:

```
Has the customer purchased Lucent Technologies CentreVu(R)  
Report Designer? (y/n): (default: n)
```

13. Enter `y` if the customer purchased report designer; otherwise, press Enter. The program responds:

```
Enter the maximum number of split/skill members that can be
administered (1-10000): (default: 1)
```

14. Enter the maximum possible number of split or skill members that the customer might use based on the switch agent size purchased.

For R3V8, “split or skill members” are defined as the number of CMS-measured agent-split and agent-skill combinations logged in at the same time. Each split an agent logs into is an agent-split combination. Each skill assigned to an agent while logged in is an agent-skill combination. The recommended numbers for Expert Agent Selection (EAS) and non-EAS systems are shown in the following table.

Switch Agent Size Range Purchased	Number of Split or Skill Members	
	Non-EAS	EAS
0-12	100	500
0-25	100	500
0-50	200	1000
0-75	300	1500
0-100	400	2000
0-200	800	4000
0-300	1200	6000
0-400	1600	8000
0-500	2000	10000
0-600	2400	10000
0-max. agents	10000	10000

**⇒ NOTE:**

The minimum size configuration for CMS is 0-25; that is the reason groups 0-12 and 0-25 have the same provisioning. You should also note that the customer will be able to limit the split or skill random access memory (RAM) allocation to the size actually needed for the current configuration of agents and splits or skills. That is accomplished by the “Total split/skill members summed over all splits/skills” field, which is accessed through the `setup` option of the `cmssvc` command.

The program responds:

```
Enter the maximum number of ACDs that can be installed (1-8):  
(default: 1)
```

15. Enter the number of ACDs the customer purchased.

The prompt displays and all authorizations have been set.

16. Verify that authorizations were set by entering the following:

```
tail /cms/install/logdir/admin.log
```

The `admin.log` file contains information relating to CMS administration procedures. The file should display the following message:

```
Capabilities/capacities authorized <date/time>
```

You can also verify the authorizations by using the `auth_display` option of the `cmssvc` command.

# Setting Up Data Storage Parameters

## Overview

TSC personnel modify specific data storage parameters on the CMS computer so that the CMS application can operate properly. The `storage.def` file contains these data storage parameters, which are installed with a set of standard default values.

Review the default data storage values for each authorized ACD. The default values are found on the line immediately below each storage parameter, and many of them can be edited to meet the needs of individual customers. Use the values determined by the Account Executive, System Consultant, and Design Center based on the customer configuration.

## Procedure

1. Change to the CMS installation directory by entering the following:

```
cd /cms/install/cms_install
```

2. Enter:

```
vi storage.def
```

### NOTE:

If you delete or damage the `storage.def` file, you can find a copy of this file (`storage.sk1`) in the same directory.

3. The defaults storage parameters are listed below in the order in which they appear in the `storage.def` file.

- # Intrahour interval (15, 30, 60 minutes):  
30
- # Week start day (Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday):  
Sunday
- # Week end day (Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday):  
Saturday
- # Daily start time (regular time):  
12:00 AM

- # Daily stop time (data will be collected for seconds of last minute):  
11:59 PM
- # Number of agent login/logout records (0-999999):  
10000
- # Number of agent trace records:  
10000
- # Number of call records (0-5000 internal or 0-99999 external):  
0
- # Number of exceptions records (1-2000):  
250
- # Days of intrahour for splits (1-62):  
31
- # Days of daily splits (1-1825):  
387
- # Weeks of weekly splits (1-520):  
0
- # Months of monthly splits (1-120):  
0
- # Days of intrahour for agents (1-62):  
31
- # Days of daily agents (1-1825):  
387
- # Weeks of weekly agents (1-520):  
0
- # Months of monthly agents (1-120):  
0
- # Days of intrahour for trunk groups (1-62):  
31
- # Days of daily trunk groups (1-1825):  
387

- # Weeks of weekly trunk groups (1-520):  
0
- # Months of monthly trunk groups (1-120):  
0
- # Days of intrahour for trunks (1-62):  
31
- # Days of daily trunks (1-1825):  
387
- # Weeks of weekly trunks (1-520):  
0
- # Months of monthly trunks (1-120):  
0
- # Days of intrahour for call work codes (1-62):  
0
- # Days of daily call work codes (1-1825):  
0
- # Weeks of weekly call work codes (1-520):  
0
- # Months of monthly call work codes (1-120):  
0
- # Days of intrahour for vectors (1-62):  
31
- # Days of daily vectors (1-1825):  
387
- # Weeks of weekly vectors (1-520):  
0
- # Months of monthly vectors (1-120):  
0
- # Days of intrahour for VDNs (1-62):  
31

- # Days of daily VDNs (1-1825):  
387
- # Weeks of weekly VDNs (1-520):  
0
- # Months of monthly VDNs (1-120):  
0

4. After entering the appropriate values, enter:

```
:wq
```

After the CMS application is running, the system administrator can change the data storage parameters using the Data Storage Allocation window and the Storage Intervals window in the CMS System Setup menu. For more information about changing ACD data storage parameters, see the CMS System Setup chapter in *CentreVu® CMS R3V8 Administration* (585-210-910).

---

## Setting Up a LAN for Switch Connections

### Overview

This section contains information about setting up a LAN connection between the CMS computer and a switch. This type of connection is used only with *DEFINITY* ECS Release 7 or later. To set up a LAN connection to the switch, you must coordinate the administration done on the CMS computer with the administration done on the switch and, if required, within the customer's own data network. In this section, there are sample configurations of "closed" CMS-switch networks and "open" CMS-switch networks.

For more information about LAN configurations, see *CentreVu CMS Switch Connections and Administration* (585-215-876)

### Prerequisites


- Verify that you are logged in as *root*.
- The computer must be in run-level 3 (check this with the command `who -r`).
- CMS must be turned off.
- All file systems must be mounted.

## Sample Configurations

The CMS computer can connect to a switch in a number of ways. This section shows some examples of how this can be done.


### Private Network

In a private network, the CMS computer is directly connected to the switch, and neither is part of another network. The following figure shows the default IP addressing scheme that is recommended for use in a private network.




## Public Network

In a public network, the default IP addressing can still be used unless the customer wants to set up a different scheme. The following figure shows a typical public network.




## Remote Switch Network

Since one CMS computer may connect to several switches, you can connect to a remote switch using a LAN. The following figure shows two ways that a remote switch can connect to a CMS computer.



## High Availability Configuration



## Procedures

To set up a network connection to a LAN-enabled switch and other CMS computer peripherals, you must do the following:

- Edit the `/etc/hosts` file.
- Set up a second network interface.
- Edit the `/etc/defaultrouter` file.

## Editing the /etc/hosts File

1. Edit the `/etc/hosts` file by entering the following:  

```
vi /etc/hosts
```
2. Add a new line in this file for each ACD/switch that will connect to this computer using TCP/IP. You must enter the IP address and the host name.

```
192.168.2.1      cms
192.168.2.2      switch
192.168.2.101   cmsterm1
192.168.2.102   cmsterm2
```

This example shows the recommended default IP addressing scheme for a closed network. There is one switch/ACD and two NTS units (cmsterm1 and cmsterm2).

3. Press the Esc key to leave the edit mode.
4. Enter `:w!` to overwrite the existing file.
5. Enter `:q` to quit editing the file.

## Setting Up a Second Network Interface

If the CMS computer has two network interfaces (the native ethernet card and a *SunSwift* or FSBE network card), you must set up the second network interface. The primary network interface was set up during the *Solaris* installation.

1. Edit the `/etc/hosts` file by entering the following:  

```
vi /etc/hosts
```
2. Add a new line in this file for each ACD/switch that will connect to this computer using TCP/IP. You must enter the IP address and the host name.

```
192.168.2.1      cms
192.168.2.2      switch1
x.x.x.x          switch2
192.168.2.3      cms_1
192.168.2.101   cmsterm1
192.168.2.102   cmsterm2
```

This example shows the recommended default IP addressing scheme for a second network interface. The host name for the second network interface is the CMS computer hostname with “\_1” as a suffix.

3. Press the Esc key to leave the edit mode.
4. Enter `:w!` to overwrite the existing file.
5. Enter `:q` to quit editing the file.
6. Create a new host name file for the second network interface by entering one of the following:
  - On an *Enterprise 3000* or *Enterprise 3500* with a second FSBE card, enter the following:

```
vi /etc/hostname.le0
```
  - On a *SPARCserver* with a second FSBE card, enter the following:

```
vi /etc/hostname.le1
```
  - On an *Enterprise 3000*, *Enterprise 3500*, or *Ultra 5* with a second *SunSwift* card, enter the following:

```
vi /etc/hostname.hme1
```
  - On a *SPARCserver* with a second *SunSwift* card, enter the following:

```
vi /etc/hostname.hme0
```
7. Add a line to this new file with the host name you added to the `/etc/hosts` file. For example:

cms\_1

8. Press the Esc key to leave the edit mode.
9. Enter `:wq` to write and quit editing the file.

## Editing the `/etc/defaultrouter` File

If the connection between the CMS computer and the switch is going through a customer's network, you will have to set up a default network router.

1. Create a default router file by entering the following:

```
vi /etc/defaultrouter
```

2. Add a line to this new file with the IP address for the default system router on the customer's network. This address must be obtained from the customer. For example:

```
192.168.2.254
```

3. Press the Esc key to leave the edit mode.
4. Enter `:wq` to write and quit editing the file.

## Setting Up the CMS Application

### Overview

Use the procedures in this section to set up the CMS application.

### Prerequisites

- Verify that you are logged in as *root*.
- The computer must be in run-level 3 (check this with the command `who -r`).
- CMS must be turned off.
- If using TCP/IP to connect to an ACD, the switch LAN setup must be done as described on [Page 2-127](#).
- All file systems must be mounted.

## Setup Methods

You can set up the CMS feature package using one of two methods:

- a. **Interactively from a terminal** — Using the interactive option, the program prompts you for the necessary information to set up the CMS application (for example, system type, number of agents, trunks, vectors, VDNs, and so on).

To set up the CMS application using this option, see "[Setting Up CMS Interactively from a Terminal](#)" in this chapter.

- b. **UNIX\* System flat file** — Using the flat file option, you edit a *UNIX* System flat file containing the necessary information (for example, system type, number of agents, trunks, vectors, VDNs, and so on) to set up the CMS application. When you execute the program, it runs in the background and uses the *UNIX* System flat file data to set up the CMS application. To set up the CMS application using this option, see "[Setting Up CMS Using a UNIX Flat File](#)" in this chapter.

## Setting Up CMS Interactively from a Terminal

### Overview:

Using the interactive option, the program prompts you for the necessary information.

### Procedure:

1. If you are not sure of the device path, do the following:
  - a. Insert a tape into the tape drive.
  - b. In another xterm window, enter the following commands:
    - `mt -f /dev/rmt/1c status`
    - `mt -f /dev/rmt/0c status`

The correct device path will show information similar to the following:

```
Tandberg 2.5 Gig QIC tape drive:
sense key(0x0)= No Additional Sense   residual= 0
retries= 0      file no= 0   block no= 0
```

---

\**UNIX* is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

2. Access the CMS Services menu by entering the following:

```
cmssvc
```

The program responds:

```
Lucent Technologies CentreVu(R) Call Management System Services Menu
```

```
Select a command from the list below.
```

```
1) auth_display Display feature authorizations
2) auth_set      Authorize capabilities/capacities
3) run_cms      Turn CentreVu CMS on or off
4) setup        Set up the initial configuration
5) swinfo       Display switch information
6) swsetup      Change switch information
7) patch_inst   Install a single CMS patch from CD
8) patch_rmv    Backout an installed CMS patch
9) load_all     Install all CMS patches found on CD
10) back_all    Backout all installed CMS patches from machine
Enter choice (1-10) or q to quit:
```

3. Enter 4 to select the `setup` option.

 **NOTE:**

If system setup has already been done, the program responds:

```
Warning!!! Setup has already been performed.
Running this command will remove all CMS data in the database.
Do you wish to proceed and re-configure CMS? (y/n): (default: n)
```

4. Enter `y` to continue with the setup, or enter `n` to exit setup. If you enter `y`, the program responds:

```
Select the language for this server:
```

```
All languages are ISO Latin except Japanese. Selection of the
server language assumes that existing customer data is
compatible. (Upgrade from any ISO Latin language to any ISO
Latin language or from Japanese to Japanese is supported).
```

- 1) English
- 2) Dutch
- 3) French
- 4) German
- 5) Italian
- 6) Portuguese
- 7) Spanish
- 8) Japanese

```
Enter choice (1-8): (default: 1)
```

5. Enter the number for the language used on this system. If setup has been done previously, the customer CMS data is now initialized, which can take up to 30 minutes. When finished, the program responds:

```
Enter a name for this UNIX system (up to 256 characters):
(default: XXXXXX)
```

6. Enter the host name of the computer. This name was assigned during the factory installation procedures and is used by the TSC to maintain and identify this specific system. The program responds:

```
Select the type of backup device you are using
  1) SCSI QIC-150 cartridge tape - 150MB tape
  2) 40.0 Gbyte 8mm tape
  3) 14.0 Gbyte 8mm tape
  4) 5.0 Gbyte 8mm tape
  5) SCSI QIC-2.5 cartridge tape - 2.5GB tape
  6) SCSI 4-8 SLR cartridge tape - 4GB tape (8GB compressed)
Enter choice (1-6):
```

7. Enter the number to specify the type of cartridge tape you are using as the backup device. The program responds:

```
Enter the default backup device path:
(default: /dev/rmt/0c)
```

Enter the default backup device path.

The correct device path will show information similar to the following:

```
Tandberg 2.5 Gig QIC tape drive:
sense key(0x0)= No Additional Sense   residual= 0   retries
file no= 0   block no= 0
```

8. After you enter the correct device path, the program responds:

```
Enter number of ACDs being administered (1-8):
```

9. Enter the number of ACDs to be administered. This number may be less than the number of ACDs authorized. The program responds:

```
Information for ACD 1
```

```
Enter switch name (up to 20 characters):
```

10. Enter the name for the switch associated with ACD 1. The program responds:

```
Select the model of switch for this ACD
```

- 1) Definity-G3V2
- 2) Definity-G3V3
- 3) Definity-G3V4
- 4) Definity-G3V5
- 5) Definity-R6/R7
- 6) Definity-R8

```
Enter choice (1-6):
```

11. Enter the number that represents the switch model associated with this ACD. Use the following table to determine the correct switch model. See *CentreVu® CMS Switch Connections and Administration* (585-215-876) for additional information.

If the switch release is...	...then enter this switch model choice
G3V2	Definity-G3V2
G3V3	Definity-G3V3
G3V4	Definity-G3V4
ECS Release 5 ECS Release 6.1 ECS Release 6.2 ECS Release 6.3 as bugfix load*	Definity-G3V5
ECS Release 6.3 with R3V6 features† ECS Release 7	Definity ECS R6/R7
ECS Release 8	Definity-R8

\*Does not include *CentreVu Advocate* or *CentreVu Virtual Routing*.

†Includes *CentreVu Advocate* and *CentreVu Virtual Routing*.

If the switch supports vectoring and vectoring is authorized, the following message appears; otherwise, go to [Step 14](#):

```
Is Vectoring enabled on the switch? (y/n):
```

- Enter *y* if vectoring is enabled on this switch; otherwise, enter *n*. The following message appears if vectoring is enabled, the switch supports EAS, and EAS is authorized. If the message does not appear, go to [Step 14](#).

```
Is Expert Agent Selection enabled on the switch? (y/n):
```

- Enter *y* if EAS is enabled on this switch; otherwise, enter *n*. The program responds:

```
Does the Central Office have disconnect supervision?  
(y/n): (default: y)
```

14. Enter `y` if the CMS is located in the U.S., then go to Step [16](#). If you answer `n`, the program responds:

```
ACD calls shorter than the Phantom Abandon Call Timer value
will be counted as abandoned.
Enter the Phantom Abandon Call Timer value in seconds
(1-10): (default:10)
```

15. Enter the Phantom Abandon Call Timer value.

**⇒ NOTE:**

The Phantom Abandon Call Timer value can be changed through the `cmssvc` menu using the `swsetup` option.

The program responds:

```
Enter the local port assigned to switch. (1-64):
```

**⇒ NOTE:**

The local and remote port assignments must be symmetrical between the switch and the CMS. For example, if the CMS local port is 1 and the remote port is 10, the switch local port must be 10 and the remote port must be 1.

16. Enter the local port or channel number on the switch. The program responds:

```
Enter the remote port assigned to switch (1-64):
```

17. Enter the remote port or channel number on the switch.

You must now select how the CMS platform is connected to the *DEFINITY* switch for message transport. The program responds:

```
Select the transport to the switch
  1) X.25
  2) TCP/IP
Enter choice (1-2):
```

18. If you enter **1** to select X.25, the program continues with Step [22](#).

If you enter **2** to select TCP/IP, which is available with *DEFINITY* ECS Release 7 or later, the program continues with Step [19](#).

19. The program responds:

```
Enter DEFINITY ECS host name or IP Address:
```

20. Enter the host name or IP address of the *DEFINITY* ECS that is connected to this ACD. If you enter a host name that has not been added to the computer's `/etc/hosts` file, the program responds:

```
Switch_name has not been administered in a DNS or
/etc/hosts file. The DNS or /etc/hosts file must be
corrected or the link to the switch will not work.
```

See the switch LAN setup on [Page 2-127](#) for more information about setting up the hosts file. The program continues:

```
Enter DEFINITY ECS TCP port number (5001-5999):
(default: 5001)
```

21. Press Enter to use the default TCP port number 5001. This number must match the port number administered on the *DEFINITY* switch. The procedure continues with Step [24](#).
22. If you selected x.25 transport to the switch at Step 18, continue here. The program responds (for example):

```
Select the device used for x.25 connectivity to the switch
1) Serial Port A
2) Serial Port B
3) HSI link 0
4) HSI link 1
5) HSI link 2
6) HSI link 3
7) HSI link 4
8) HSI link 5
9) HSI link 6
10) HSI link 7
11) Software loopback link 0
12) Software loopback link 1
Enter choice (1-12):
```

23. Enter the number that corresponds to the device used for x.25 connectivity.

**⇒ NOTE:**

Except for the loopback links, which are for testing only, the choices on the menu correspond to the hardware connections that can be made between the CMS and the switch.

If you choose a serial port, but you have a High-Speed Serial Interface (HSI) card, you receive an error message:

```
Choose one of the HSI links for your x.25
connectivity.
Re-enter your selection.
```

If you choose an HSI link but do not have an HSI card, you receive an error message:

```
Without an HSI card you must use serial port X for  
your x.25 connectivity.  
Re-enter your selection.
```

If you choose a loopback link, the program responds:

```
This choice is used for testing only. If  
you make this selection, you will not be able to collect  
data from your ACD. Is this what you want  
to do (y/n)?
```

If you choose `y`, the selection takes effect. If you choose `n`, the system redisplay the menu.

24. Once you have selected an appropriate link transport device, the program responds:

```
Number of splits/skills (0-XXX):
```

25. Enter the number of splits/skills in this ACD. The program responds:

```
Total split/skill members, summed over all splits/skills  
(0-XXXX):
```

26. Enter the maximum number of split/skill members that will be logged into this ACD simultaneously, considering shift overlap.
- For non-EAS, sum all agent-split combinations, counting each split an agent will log into (maximum is 4) as a split member.
  - For EAS, sum all agent-skill combinations that will be logged in at the same time, counting the maximum number of skills the supervisors expect to assign to each agent (up to 20) during a shift.

If it is not possible to sum the number of splits/skills for each agent, you can determine the capacity needed by multiplying the total number of agents by the average number of splits/skills per agent.

The program responds:

```
Number of shifts (1-4):
```

27. Enter the number of shifts. The program responds:

```
Enter the start time for shift 1 (hh:mmXM):
```

28. Enter the start time for shift 1; for example, 08:00am. The program responds:

```
Enter the stop time for shift 1 (hh:mmXM):  
:
```

29. Enter the stop time for shift 1; for example, 05:00pm. The program responds:

```
Number of agents logged into all splits/skills during  
shift 1 (0-XXX):
```

30. Enter the number of agents logged in during the shift.

**⇒ NOTE:**

Steps [28](#) through [30](#) repeat for the number of shifts entered in Step [27](#).

When all shifts have been set up, the program responds:

```
Number of trunk groups (0-XXX):
```

31. Enter the number of trunk groups associated with this ACD. The program responds:

```
Number of trunks (0-XXXX):
```

32. Enter the number of trunks associated with this ACD. The program responds:

```
Number of unmeasured facilities (0-XXXX):
```

33. Enter the number of unmeasured trunk facilities associated with this ACD. If the switch supports call work codes, the program responds:

```
Number of call work codes (X-XXXX):
```

34. Enter the number of call work codes. The program responds:

```
Updating database  
.....
```

After a few minutes, if vectoring is enabled on the switch (that is, if a *y* was entered in Step [12](#)), the program responds:

```
Enter number of vectors (0-XXXX):
```

35. Enter the number of vectors. The program responds:

```
Enter number of VDNs (0-XXXX):
```

36. Enter the number of VDNs.

The program repeats Steps [10](#) through [35](#) for each ACD entered in Step [9](#). After you define the last ACD, the program continues:

```
Updating database.  
  
Computing space requirements and file system space  
availability.  
  
Setup completed successfully.
```

If the setup determines that you do not have enough file space, you will get the following warning message:

```
Failed to find sufficient file space for CMS data.  
  
WARNING: You do not currently have sufficient file space  
for your existing CMS data. At this point you should turn  
on CMS, go to the "Data Storage Allocation" screen, and  
verify/modify the administration, or go to the "Free  
Allocation" screen and verify/modify your existing free  
space.  
  
Setup completed with warnings.
```

If the setup was ok, then you will see the following message:

```
Setup completed successfully
```

37. Verify that the installation completed successfully by entering the following:

```
tail /cms/install/logdir/admin.log
```

All failure messages are logged in this file. The CMS software is successfully set up when you see a message similar to the following:

```
File systems/space available:
  /cms      12994480

File systems/current blocks free:
  /cms      12994480
/cms: VDN,TKGRP,VECTOR,TRUNK,AGENT_LOG_REC,
AGENT_TRACE_REC,SPLIT,AGENT,EXCEPTIONS_REC,WORKCODE
Number of calls to fill_fs():12
Setup completed successfully <data/time>
```

You may edit this file and add comments about the packages that were installed or authorized.

If you need to install additional CMS-related feature packages (Forecasting or External Call History), go to [“Installing Feature Packages” on Page 2-157](#).

If you are not installing any other feature packages, do the following to turn on CMS:

1. Access the CMS Services menu by entering `cmssvc`. The menu appears.
2. Enter `3` to select the `run_cms` option.
3. Enter `1` to turn on CMS.

## Setting Up CMS Using a UNIX Flat File

Setting up the CMS feature package using a *UNIX* flat file consists of editing a copy of the `cms.inst.skl` file and starting the install program.

### NOTE:

This procedure is not necessary if you already performed the CMS setup interactively.

**Editing the File:**

1. Change to the CMS installation directory by entering the following:

```
cd /cms/install/cms_install
```

2. Make a copy of the CMS installation file by entering the following:

```
cp cms.inst.sk1 cms.install
```

3. Change permissions on the copied CMS installation file by entering the following:

```
chmod 644 cms.install
```

4. Edit the copied CMS installation file by entering the following:

```
vi cms.install
```

The file contains a series of questions and value ranges for the ACD/switch configuration. The following pages show a sample file with example values in bold.

**⇒ NOTE:**

When selecting a switch model in the file, refer to the table on [Page 2-139](#).

```
# Enter a name for this UNIX system (up to 256 characters):
cms3
# Select the type of backup device you are using
#   1) SCSI QIC-150 cartridge tape - 150MB tape
#   2) 40.0 Gbyte 8mm tape
#   3) 14.0 Gbyte 8mm tape
#   4) 5.0 Gbyte 8mm tape
#   5) SCSI QIC-2.5 cartridge tape - 2.5GB tape
#   6) SCSI 4-8 SLR cartridge tape - 4GB tape 8GB compressed)
# Enter choice (1-6):
5
# Default backup device paths based on device type:
# Device                               Default backup path
# SCSI QIC-150 cartridge tape - 150MB tape /dev/rmt/0
# 40.0 Gbyte 8mm tape                    /dev/rmt/0c
# 14.0 Gbyte 8mm tape                    /dev/rmt/0c
# 5.0 Gbyte 8mm tape                     /dev/rmt/0
# SCSI QIC-2.5 cartridge tape - 2.5GB tape /dev/rmt/0c
# SCSI 4-8 SLR cartridge tape - 4GB tape (8GB compressed)
/dev/rmt/0c
# Enter the default backup device path:
/dev/rmt/0c
# Enter number of ACDs being administered (1-8):
3
# The following information is required per ACD:
# Information for ACD 1:
# Enter switch name (up to 20 characters):
# Select the model of switch for this ACD
#   1) Definity-G3V2
#   2) Definity-G3V3
#   3) Definity-G3V4
#   4) Definity-G3V5
#   5) Definity-R6/R7
#   6) Definity-R8
# Enter choice (1-6):
6
# Is Vectoring enabled on the switch? (y/n):
Y
# Is Expert Agent Selection enabled on the switch? (y/n):
Y
# Does the Central Office have disconnect supervision? (y/n):
Y
# If the Central Office has disconnect supervision, enter 0.
# Otherwise, ACD calls shorter than the Phantom Abandon |
# Call Timer value will be counted as abandoned.
# Enter the Phantom Abandon Call Timer value in seconds (0-10):
0
# Enter the local port assigned to switch (1-64):
1
# Enter the remote port assigned to switch (1-64):
1
```

```
# TCP/IP transport is only available with DEFINITY R7 and
# later switch models.
# Select the transport to the switch
#   1) X.25
#   2) TCP/IP
# Enter choice (1-2):
2

# Skip the next question if you did not enter choice 1.
# These are used for X.25 connections only.
# Select the device used for x.25 connectivity to the switch
#   1) Serial port A
#   2) Serial port B
#   3) HSI link 0
#   4) HSI link 1
#   5) HSI link 2
#   6) HSI link 3
#   7) HSI link 4
#   8) HSI link 5
#   9) HSI link 6
#  10) HSI link 7
#  11) Software loopback link 0
#  12) Software loopback link 1
# Enter choice (1-12):

# Skip the next question if you did not enter choices 11 - 12.
# These are used for testing only. If you select one of these,
# you will not be able to collect data from your ACD.
# Are you sure you want to do this? (y/n):

# Skip the next two questions if you did not enter choice 2
# (TCP/IP). These are used for TCP/IP connections only.
# If a host name is entered, the host name must be administered
# in a DNS or /etc/hosts file or the link to the switch
# will not work.
# Enter DEFINITY host name or IP Address:
192.168.2.2
# Enter DEFINITY TCP port number (5001-5999):
5001
# Maximum number of splits/skills based on switch type:
# Release(s)                               Value
# Definity-G3V2/Definity-G3V3/Definity-G3V4    255
# Definity-G3V5/Definity-R6/R7                 600
# Definity-R8                                  999
# Number of splits/skills (0-Maximum):
# Maximum number of split/skill members based on switch type:
# Release(s)                               Value
# Definity-G3V2/Definity-G3V3/Definity-G3V4    5200
# Definity-G3V5/Definity-R6/R7/Definity-R8    10000
# Total split/skill members, summed over all
# splits/skills (0-Maximum):
1000
```

```

# Number of shifts (1-4):
1
# Enter the start time for shift 1 (hh:mmXM):
08:00AM
# Enter the stop time for shift 1 (hh:mmXM):
05:00PM
# Number of agents logged into all splits/skills during
# shift 1 (1-Maximum):
100
# Enter the start time for shift 2 (hh:mmXM):

# Enter the stop time for shift 2 (hh:mmXM):

# Number of agents logged into all splits/skills during
# shift 2 (1-Maximum):

# Enter the start time for shift 3 (hh:mmXM):

# Enter the stop time for shift 3 (hh:mmXM):

# Number of agents logged into all splits/skills during
# shift 3 (1-Maximum):

# Enter the start time for shift 4 (hh:mmXM):

# Enter the stop time for shift 4 (hh:mmXM):

# Number of agents logged into all splits/skills during
# shift 4 (1-Maximum):

# Maximum number of trunk groups based on switch type:
# Release(s)                               Value
# Definity-G3V2/Definity-G3V3/Definity-G3V4    666
# Definity-G3V5/Definity-R6/R7/Definity-R8     666
# Number of trunk groups (0-Maximum):
20
# Maximum number of trunks based on switch type:
# Release(s)                               Value
# Definity-G3V2/Definity-G3V3/Definity-G3V4    4000
# Definity-G3V5/Definity-R6/R7/Definity-R8     4000
# Number of trunks (0-Maximum):
100

```

5. Enter the appropriate values for your configuration. As shown in bold in the examples, the entries must be added on the blank lines after each question.

 **CAUTION:**

*Use the computer's host name for the UNIX system name. The computer's host name was assigned during the factory installation.*

```

#Number of unmeasured facilities (0 to (Maximum trunks - Number of trunks)):
10
# Minimum number of call work codes based on switch type:
# Release(s)                               Value
# Definity-G3V2/Definity-G3V3/Definity-G3V4    1
# Definity-G3V5/Definity-R6/R7/Definity-R8    1
# Maximum number of call work codes based on switch type:
# Release(s)                               Value
# Definity-G3V2/Definity-G3V3/Definity-G3V4    1999
# Definity-G3V5/Definity-R6/R7/Definity-R8    1999
# Number of call work codes (Minimum-Maximum):
100
# Maximum number of vectors based on switch type:
# Release(s)                               Value
# Definity-G3V2/Definity-G3V3/Definity-G3V4    512
# Definity-G3V5/Definity-R6/R7                512
# Definity-R8                                999
# Enter number of vectors (0-Maximum):
20
# Maximum number of VDNs based on switch type:
# Release(s)                               Value
# Definity-G3V2/Definity-G3V3/Definity-G3V4    2000
# Definity-G3V5                                2000
# Definity-R6/R7                              8000
# Definity-R8                                20000
# Enter number of VDNs (0-Maximum):
10

# Information for ACD 2:

```

*(The file repeats the preceding statements for ACDs 2 through 8;  
enter data for only the required number of ACDs.)*

After you have entered all the appropriate values, enter `:wq` to write and quit the file.

## Running Setup with a Flat File

1. Enter `cd` to change to the root directory.
2. Access the CMS Services menu by entering:  
`cmssvc`

The program responds:

```
Lucent Technologies CentreVu(R) Call Management System Services
Menu

Select a command from the list below.
 1) auth_display Display feature authorizations
 2) auth_set     Authorize capabilities/capacities
 3) run_cms      Turn CentreVu CMS on or off
 4) setup        Set up the initial configuration
 5) swinfo       Display switch information
 6) swsetup      Change switch information
 7) patch_inst   Install a single CMS patch from CD
 8) patch_rmv    Backout an installed CMS patch
 9) load_all     Install all CMS patches found on CD
10) back_all     Backout all installed CMS patches from machine

Enter choice (1-10) or q to quit:
```

3. Enter 4 to select the `setup` option. If setup has been done previously, the program responds:

```
Warning!!! Setup has already been performed.
Running this command will remove all CMS data in the database.
Do you wish to proceed and re-configure CMS? (y/n): (default: n)
```

---

4. Enter `y`. The program responds:

```
Select the language for this server:
```

```
All languages are ISO Latin except Japanese. Selection of the
server language assumes that existing customer data is
compatible. (Upgrade from any ISO Latin language to any ISO
Latin language or from Japanese to Japanese is supported).
```

- 1) English
- 2) Dutch
- 3) French
- 4) German
- 5) Italian
- 6) Portuguese
- 7) Spanish
- 8) Japanese

```
Enter choice (1-8): (default: 1)
```

5. Enter the number for the language used on this system. The program responds:

```
The input will be read from
```

- 1) the terminal
- 2) a flat file

```
Enter choice (1-2):
```

6. Enter `2` to select the `flat file` option. The program responds:

```
*** The rest of this command is running in the background ***
```

7. Verify that the installation completed successfully by entering the following:

```
tail -f /cms/install/logdir/admin.log
```

The `-f` option in the `tail` command updates the console as messages are written to the `admin.log` file. All failure messages are logged in this file. The CMS software is successfully set up when you see a message similar to the following:

```
File systems/space available:
  /cms      12994480

File systems/current blocks free:
  /cms      12994480
/cms: VDN,TKGRP,VECTOR,TRUNK,AGENT_LOG_REC,
AGENT_TRACE_REC,SPLIT,AGENT,EXCEPTIONS_REC,WORKCODE,
CALL_REC,
Number of calls to fill_fs():12
Setup completed successfully <data/time>
```

You may edit this file and add comments about the packages that were installed or authorized.

8. Press Delete to break out of the `tail -f` command.

If you need to install additional CMS-related feature packages (Forecasting or External Call History), go to [“Installing Feature Packages” on Page 2-157](#).

If you are not installing any other feature packages, do the following to turn on CMS:

1. Access the CMS Services menu by entering `cmssvc`.  
The menu appears.
2. Enter `3` to select the `run_cms` option.
3. Enter `1` to turn on CMS.  
CMS turns on.

---

# Installing Feature Packages

Use the procedures in this section to install the following feature packages:

- Forecasting
- External Call History (ECH).

Customers can install these CMS feature packages if they have been authorized during CMS setup.

---

## Installing the Forecasting Package

### Overview

Use the procedure in this section to install the Forecasting feature package.

### Prerequisites

- Verify that you are logged in as *root*.
- The computer must be in run-level 3 (check this with the command `who -r`).
- All file systems must be mounted.
- CMS must be turned off.

### Procedure

1. Access the CMS Services menu by entering the following command:

```
cms svc
```

The program responds:

```
Lucent Technologies CentreVu(R) Call Management System Services
Menu

Select a command from the list below.

 1) auth_display Display feature authorizations
 2) auth_set     Authorize capabilities/capacities
 3) run_cms      Turn CentreVu CMS on or off
 4) setup        Set up the initial configuration
 5) swinfo       Display switch information
 6) swsetup      Change switch information
 7) patch_inst   Install a single CMS patch from CD
 8) patch_rmv    Backout an installed CMS patch
 9) load_all     Install all CMS patches found on CD
10) back_all     Backout all installed CMS patches from machine

Enter choice (1-10) or q to quit:
```

2. Enter 1 to select the `auth_display` option. The system lists the current authorizations (for example):

```

                                Version purchased:  R3V8
                                Capability/Capacity  Authorization
                                -----
                                vectoring            authorized
                                forecasting           authorized
                                graphics              authorized
                                external call history authorized
                                expert agent selection authorized
                                external application  authorized
                                More than 2000 VDNs measured authorized
                                Lucent Technologies CentreVu(R) Supervisor authorized
                                Lucent Technologies CentreVu(R) Report Designer authorized
                                Maximum number of split/skill members 10000
                                Maximum number of ACDs 2
                                Simultaneous CentreVu Supervisor logins 250
```

3. Verify that the system is authorized to install the Forecasting package.

**⇒ NOTE:**

If Forecasting is not authorized but should be, go to [“Setting Authorizations” on Page 2-118](#).

4. Access the CMS Administration menu by entering:

```
cmsadm
```

The program responds:

```
Lucent Technologies CentreVu(R) Call Management System
Administration Menu
Select a command from the list below.
1) acd_create   Define a new ACD
2) acd_remove  Remove all administration and data for an ACD
3) backup      Filesystem backup
4) pkg_install Install a feature package
5) pkg_remove  Remove a feature package
6) run_cms     Turn CentreVu CMS on or off
7) port_admin  Administer Modems, Terminals, and Printers

Enter choice (1-10) or q to quit:
```

5. Select the `pkg_install` option. The program responds:

```
The CMS Features that can be installed are
1) forecasting
2) external call history
Enter choice (1-2) or q to quit:
```

 **NOTE:**

The `pkg_install` option menu displays only those feature packages that are authorized but not yet installed.

6. Enter the number that corresponds to the Forecasting package. The program responds:

```
Creating database tables
.....
```

When creation of the Forecasting database tables is completed, the program responds:

```
Computing space requirements and file system space
availability.
```

```
Forecasting package installed.
```

If the program determines that you do not have enough file space, you will get the following warning message:

```
Failed to find sufficient file space for CMS data.
```

```
WARNING: You do not currently have sufficient file space
for your existing CMS data. At this point you should turn
on CMS, go to the "Data Storage Allocation" screen, and
verify/modify the administration, or go to the "Free
Allocation" screen and verify/modify your existing free
space.
```

```
Forecasting package installed with warnings.
```

7. Verify that the installation completed successfully by entering the following:

```
tail /cms/install/logdir/admin.log
```

The Forecasting package is successfully installed when you see this message:

```
.
.
Forecasting package installed (date/time )
```

You may edit this file in order to add comments about the packages that were installed or authorized.

If you need to install External Call History, go to ["Installing the External Call History Package" on Page 2-161](#).

---

When you are finished installing feature packages, do the following to turn on CMS:

1. Access the CMS Services menu by entering `cmssvc`.

The menu appears.

2. Enter `3` to select the `run_cms` option.

3. Enter `1` to turn on CMS.

CMS turns on.

---

## Installing the External Call History Package

### Overview

Use these procedures to install the External Call History feature package.

### Prerequisites

- The customer must have a separate computer for the storage and reporting of call records.
- Both the storage machine and the CMS machine must be administered in *UNIX-to-UNIX* copy (UUCP).
- If the storage machine is not running the *UNIX* system, use a DOS version of UUCP.
- Verify that you are logged in as *root*.
- The computer must be in run-level 3 (check this with the command `who -r`).
- All file systems must be mounted.
- CMS must be turned off.

#### NOTE:

Once the External Call History package is installed, you will no longer be able to access any call record data from CMS. For more information about administering the UUCP link port on an NTS, see *CentreVu® CMS R3V8 External Call History Interface* (585-210-912).

## Procedure

1. Access the CMS Services menu by entering:

```
cmssvc
```

The program responds:

```
Lucent Technologies CentreVu(R) Call Management System Services
Menu

Select a command from the list below.
 1) auth_display Display feature authorizations
 2) auth_set     Authorize capabilities/capacities
 3) run_cms     Turn CentreVu CMS on or off
 4) setup       Set up the initial configuration
 5) swinfo      Display switch information
 6) swsetup     Change switch information
 7) patch_inst  Install a single CMS patch from CD
 8) patch_rmv  Backout an installed CMS patch
 9) load_all    Install all CMS patches found on CD
10) back_all   Backout all installed CMS patches from machine
Enter choice (1-10) or q to quit:
```

2. Enter 1 to select the `auth_display` option. The program responds by displaying the current authorizations (for example):

```

                                Version purchased:  R3VX
                                Capability/Capacity  Authorization
                                -----
                                vectoring            authorized
                                forecasting          installed
                                graphics             authorized
                                external call history authorized
                                expert agent selection authorized
                                external application  authorized
                                More than 2000 VDNs measured authorized
                                Lucent Technologies CentreVu(R) Supervisor authorized
                                Lucent Technologies CentreVu(R) Report Designer authorized
                                Maximum number of split/skill members 10000
                                Maximum number of ACDs 2
                                Simultaneous CentreVu Supervisor logins 250
```

3. Verify that the system is authorized for the External Call History package.

### ⇒ NOTE:

If External Call History is not authorized but should be, go to [“Setting Authorizations” on Page 2-118](#).

4. Access the CMS Administration menu by entering:

```
cmsadm
```

The program responds:

```
Lucent Technologies CentreVu(R) Call Management System
Administration Menu
Select a command from the list below.
1) acd_create   Define a new ACD
2)  acd_remove  Remove all administration and data for an ACD
3) backup      Filesystem backup
4) pkg_install  Install a feature package
5) pkg_remove  Remove a feature package
6) run_cms     Turn CentreVu CMS on or off
7) port_admin  Administer Modems, Terminals, and Printers

Enter choice (1-10) or q to quit:
```

5. Select the `pkg_install` option. The program responds:

```
The CMS Features that can be installed are
 1) forecasting
 2) external call history
Enter choice (1-2) or q to quit:
```

 **NOTE:**

The system displays only feature packages that are authorized but not yet installed.

6. Enter the number that corresponds to the External Call History package (in this example, 2). The program responds:

```
Enter name of computer to which to send call records
(up to 256 characters):
```

7. Enter the name of the computer where call records will be collected. The program responds:

```
Enter full path of the program to transmit the external  
call history files: (default: /cms/dc/chr/uucp_copy)
```

8. Press Enter. The program responds:

```
Enter full path of the program to check the external call  
history file transmission: (default:  
/cms/dc/chr/uucp_check)
```

9. Press Enter. The program responds:

```
Enter password for nuucp login on computer (up to 8  
characters)
```

10. Enter the password for `nuucp` of the receiving computer that was administered in `uucp`. The program responds:

```
Enter CMS port for connection to computer (s_pdevxxx):
```

11. Enter the CMS port administered for the Call History Reporting machine. This port can either be on one of the 64-port NTS patch panels or on one of the 8- or 16-port NTSs. For more information on administering the ports on the NTS, see *CentreVu® CMS Terminals, Printers, and Modems* (585-215-874). The program responds:

```
Select a speed for this connection  
1) 19200  
2) 38400  
Enter choice (1-2):
```

12. Enter the speed that the connection between the CMS and Call History Reporting machine will be using. The program responds:

```
Number of call segments to buffer for ACD xxxxxx (0-99999):
```

13. Enter the number of call records to be held in the buffer if the Call History machine cannot accept the data. (This step reserves disk space; therefore, sufficient disk space must be available.)

**⇒ NOTE:**

This step is repeated for each administered A.

The program responds:

```
Computing space requirements and file system space
availability.
```

```
External Call History package installed.
```

If the setup determines that you do not have enough file space, you will get the following warning message:

```
Failed to find sufficient file space for CMS data.
```

```
WARNING: You do not currently have sufficient file space
for your existing CMS data. At this point you should turn
on CMS, go to the "Data Storage Allocation" screen, and
verify/modify the administration, or go to the "Free
Allocation" screen and verify/modify your existing free
space.
```

```
External call history package installed with warnings.
```

14. Verify that the installation completed successfully by entering:

```
tail /cms/install/logdir/admin.log
```

If the External Call History package is installed successfully, the program responds:

```
External Call History package installed (date/time )
```

You may edit this file in order to add comments about the packages that were installed or authorized.

If you need to install Forecasting, go to [“Installing the Forecasting Package” on Page 2-157](#).

If you are not installing any other feature packages, do the following to turn on CMS:

1. Access the CMS Services menu by entering `cmssvc`.

The menu appears.

2. Enter `3` to select the `run_cms` option.

3. Enter `1` to turn on CMS.

CMS turns on.

# Setting Up the Remote Console

## Overview

This section describes how to redirect the remote console port using the *Solaris* software package. Redirecting the console allows the TSC to dial in and do remote maintenance. The port used for remote console access differs depending on the hardware platform:

Hardware Platform	Port A	Port B
<i>SPARCserver Enterprise 3000</i> <i>Enterprise 3500</i>	Remote Console	Switch Link
<i>Ultra 5</i>	Switch Link	Remote Console

## Platform Considerations

- All platforms.

## Administering the Remote Console Port

To administer the remote console port on the back of the CMS computer, do the following:

1. Remove the current port administration by entering:

```
/cms/install/bin/abccadm -r ttyX
```

(where X is "a" or "b")

The program responds:

```
ttyX is currently set to be incoming
```

```
Are you sure you want to change it? [y,n,?]
```

2. Enter `y`. The program responds:

```
ttyX administration removed
```

3. Enter the following to administer the remote console port:

```
/cms/install/bin/abcmadm -i -b 9600 ttyX
```

(where X is “a” or “b”)

The program responds:

```
ttyX set to incoming port 9600 baud  
#
```

The remote console port has been administered.

## Using the Remote Console Port

Use the remote console port functions on a CMS computer by:

- redirecting the console from the local console to the remote console
- redirecting the console back to the local console

1. Dial in from the remote console to the remote console modem on the CMS computer and log in as *root*.
2. Remove the port monitor by entering:

```
/cms/install/bin/abcmadm -r ttyX
```

(where X is “a” or “b”)

The program responds:

```
ttyX is currently set to be incoming  
Are you sure you want to change it? [y,n,?]
```

3. Enter `y`. The program responds:

```
ttyX administration removed
```

4. Redirect the console to the remote console port by entering the following:

```
/cms/install/bin/abccadm -c -b 9600 ttyX
```

The program responds:

```
This change requires a reboot to take affect
```

```
Are you ready to reboot? [y,n,?]
```

5. Enter `y`. The system will automatically reboot, and the remote console port will come up as the console.

As the system reboots, shut down messages appear on the local console. When the system starts to come back up, the local console should go blank and the system boot diagnostics should appear on the remote console. When the system is restarted, a login prompt should appear on the remote console.

6. Log in to the remote console as *root*. An *OpenWindows* login window should appear on the local console.

 **CAUTION:**

*If you enter Control-D from the remote console to exit the system without first redirecting control back to the local console, you may lock yourself from using the console locally or remotely.*

7. Redirect the console back to the local console by entering:

```
/cms/install/bin/abccadm -c local
```

The program responds:

```
Console set to local
```

```
This change requires a reboot to take affect
```

```
Are you ready to reboot? [y,n,?]
```

8. Enter `y`. The system automatically reboots and the remote console port comes up as a regular dial-in port with the `login:` prompt displayed.

As the system reboots, the shutting-down messages appears on the remote console. When the system starts to come back up, the system boot diagnostics should appear on the local console. After the system reboots, a login prompt should appear on the local console.

9. Log into the local console as `root`.

The console has been redirected from the remote console to the local console.

---

# Setting Up the NTS

---

## Overview

Each Network Terminal Server (NTS) needs to be set up so it will be recognized on the network. The following networking items need to be set up:

- Internet address
- Subnet mask
- Preferred load host internet address (the address of one or more CMS computer)
- Broadcast address
- Type of IP packet encapsulation.

 NOTE:

This procedure needs to be completed on each NTS being installed. If you set up more than one NTS for the system, the IP addresses must be unique (see the table in Prerequisites section, below).

---

## Platform Considerations

- All platforms.

## Prerequisites

Obtain the network IP address and NTS IP address for each NTS you are administering. The NTS number depends on the total number of ports required for the system and the type of NTS.

Device	IP Address*	Network Name
Host Computer	192.168.2.1	<i>hostname</i>
First NTS	192.168.2.101	cmsterm1
Second NTS	192.168.2.102	cmsterm2
Third NTS	192.168.2.103	cmsterm3
<i>Nth</i> NTS	192.168.2.1xx	cmstermX

\* The IP addresses shown here are the factory defaults. Use the actual system addresses if available.

## Procedure

1. Edit the *hosts* file by entering the following:

```
vi /etc/hosts
```


2. Add a separate line in this file for each NTS that corresponds to the addresses from the Prerequisites table. The following is an example hosts file:

```
192.168.2.1      cmshost
192.168.2.101   cmsterm1
192.168.2.102   cmsterm2
192.168.2.103   cmsterm3
192.168.2.104   cmsterm4
```

This example shows the default IP address for the CMS computer and the factory defaults for the NTS units.

3. Press the Esc key to leave the edit mode.
4. Enter `:w!` to overwrite the existing file.
5. Enter `:q` to quit editing the file.

6. Connect the power cord to the NTS (see the following figure).



7. Connect the 10-T transceiver to the Network Transceiver Port on the back panel of the NTS.
8. Connect the network hub unit to the NTS (10-T transceiver) using a UTP network cable.
9. Connect a dumb terminal to the Console Port on the rear of the NTS using the console cable and adapter that came with the NTS. On the 8- and 16-port NTSSs, the Console Port is port #1.

You will need the following for the 8- and 16-port units:

- Console Cable
- Adapter - comcode 407361823
- Null Modem - comcode 407122043.


You will need the following for the 64-port unit:

- Console Cable
- Adapter - part number 06-988-260-20.

**⇒ NOTE:**

The terminal options should be set to 9600 bps, 8 bits, no parity or space parity, and a stop bit.

10. Turn on the NTS, and within 15 seconds push the Test Switch on the front of the NTS (see the following figure).



11. The NTS goes through its hardware diagnostics, and the following prompt should appear:

```
Monitor::
```

12. Enter the `erase` command.

**⇒ NOTE:**

There are two types of information that can be erased:

- EEPROM (configuration information)
- FLASH (self-boot image).

If only one type of information is present, the program begins to erase it. If there are two types of information, the program prompts you to select the information you want to erase. Erase both the EEPROM and the FLASH information.

The program responds:

```
Erase
  1) EEPROM (i.e., Configuration Information)
  2) FLASH (i.e., Self Boot Image)
Enter 1 or 2::
```

13. Enter `1` to erase EEPROM. The program responds:

```
Erase all non-volatile EEPROM memory? (y/n) [n]::
```

14. Enter `y`. The program responds:

```
Erasing xxxx bytes of non-volatile memory. Please wait....
.....
Erased xxxx bytes of non-volatile memory complete.
Monitor::
```

15. Repeat Steps [12](#) through [14](#), but select `2` (FLASH) to erase the FLASH information.

16. After you have completed the `erase` command, enter `addr`. The program responds:

```
Enter Internet address [<uninitialized>]::
```

17. Enter the IP address for this NTS. This should follow the IP address structure outlined earlier in the [Prerequisites](#) on [Page 2-172](#). The program responds:

```
Internet address : xxx.xxx.xxx.xxx  
Enter Subnet mask [255.255.255.0]::
```

18. Enter the appropriate Subnet mask, or press Enter to accept the default. The program responds:

```
Subnet mask: xxx.xxx.xxx.xxx  
Enter preferred load host Internet address [<any host>]::
```

19. Enter the IP address of the CMS computer. The program responds:

```
Preferred load host address xxx.xxx.xxx.xxx  
Enter Broadcast address [0.0.0.0]::
```

20. Press Enter to accept the default broadcast message address. The program responds:

```
Enter Preferred dump address [0.0.0.0]:)
```

21. Enter the IP address of the CMS computer. The program responds:

```
Preferred dump address: xxx.xxx.xxx.xxx  
Select type of IP packet encapsulation (ieee802/ethernet)  
[<ethernet>] ::
```

22. Press Enter to accept the default IP packet encapsulation. The program returns to the `monitor:` prompt if you have a 64-port NTS. Continue with Step [24](#).

The program responds with the following question if you have an 8- or 16-port NTS:

```
Type of IP packet encapsulation: <ethernet>
Load Broadcast Y/N [Y]::
```

23. Enter `N`. The program returns to the `monitor:` prompt.
24. Enter the `boot` command at the monitor prompt to reinitialize the NTS with the new parameters. The program responds:

```
Enter boot file name [oper.42.enet]::
```

**⇒ NOTE:**

The boot file name differs depending on the type of NTS. For the 8- and 16-port NTS, the boot file name is:

```
[ (ip) "oper.52.enet", (mop) "OPER_52_ENET.SYS" ]
```

For the 64- port NTS, the boot file name is:

```
oper.42.enet
```

25. Press Enter to accept the default boot file name. The program responds:

```
Requesting boot file "oper.42.enet".
Unanswered requests shown as '?',
                               transmission errors as '*'.

Booting file: oper.42.enet from 192.168.2.1

Loading image from 192.168.2.1
.....
```

The periods (dots) continue to appear as the NTS is initialized and set up.

 **NOTE:**

If the program displays "SELF" instead of the IP address (192.168.2.1 is the factory default; your IP address may be different), it means that you did not erase EEPROM. Go back to Step [12](#) to erase EEPROM.

When the initialization finishes, the program responds:

```
annex::
```

26. Disconnect the dumb terminal from the NTS.  
The NTS has been administered.

## Creating an Alternate Boot Device

This procedure creates an alternate boot device. This procedure is required only for mirrored systems.

1. Log in as root and Enter:

```
ls -l/dev/rdisk/<newbootdev>
```

where <newbootdev> is the device to be used as the alternate boot disk. This disk should already be partitioned as an alternate boot device, according to the partitioning instructions provided in [“Partitioning the Hard Disks” on Page 2-18](#).

The system responds (for example):

```
lrwxrwxrwx 1 root  root  54 Nov 9 /dev/redsk/c0t1d0s0 ->
../../../../devices/sbus@3,0/SUNW,fas@3,8800000/sd@1,0:a,raw
```

2. Identify and record the device definition from the output generated in Step 1. The device definition is the character sequence that starts after "/devices" and ends before ":a,raw". In the example provided above, the device definition is:

```
sbus@3,0/SUNW,fas@3,8800000/sd@1,0
```

3. Enter:

```
/usr/sbin/shutdown -y -g0 -i0
```

The system displays the ok prompt.

4. To create a device alias for the alternate boot device, enter:

```
nvalias bootdevice2 <device definition>
```

where <device definition> is the character sequence recorded in Step 2.

5. At the ok prompt, enter:

```
devalias
```

The output should include a line that is similar to the following example:

```
Bootdevice2/sbus@3,0/SUNW,fas@3,8800000/sd@1,0
```

6. To test the alternate boot device, enter:

```
bootdevice2
```

When the computer restarts, login as root at the console login.

7. Reboot once again to return system control to the regular boot disk:

```
/usr/sbin/shutdown -y -g0 -i6
```

8. To set up a "cron job" for chkDisk, enter:

```
crontab -e
```

The `crontab` file is displayed in editor mode.

9. Add the following line to the end of the `crontab` file:

```
15 0 * * * /olds/chkDisks>/dev/null 2>&1
```

10. To save and quit the file, enter:

```
:wq
```

11. Enter:

```
chmod +x /olds/chkDisks
```

The alternate boot disk is now set up.

# Performing a CMSADM Backup

The CMSADM file system backup saves all of the file systems on the computer onto a tape.

## Overview

The CMSADM file system backup includes the following:

- *Solaris 7* system files and programs
- CMS programs and data
- Non-CMS customer data placed on the computer (in addition to the CMS data).

The CMSADM file system backup should be done at the following times:

- After the system has been set up in the factory

This backup contains the default factory configuration. These tapes should be saved if the system must be reinstalled in the field.

- After the CMS is provisioned

This backup contains the *Solaris* system files and programs and CMS configuration data placed on the computer by TSC provisioning personnel. These tapes should also be saved and not reused.

In addition, field technicians should perform a CMS full maintenance backup before they turn a new system over to the customer. See *CentreVu® CMS R3V8 Administration* (585-210-910) for more information.

- Before and after the CMS software is upgraded (usually done by a field technician)
- Once a month (performed by the customer).

### CAUTION:

*The customer must use a new set of backup tapes for this CMSADM File System backup. The customer must **NOT** use the original set of factory or provisioning backup tapes.*

The number of cartridge tapes required to complete a CMSADM file system backup depends on the amount of data on the system and the capacity of the backup tape. The program estimates the number of tapes required and informs the user.

## Platform Considerations

- All platforms.

## Prerequisites

- Before starting the backup procedures described in this section, log in as *root*, and enter `lp /etc/vfstab`. The output from the printer is necessary when doing a system restore. Bundle the printout of the `/etc/vfstab` file with the system backup tape(s) for future reference.
- Verify that the computer is in a *Solaris* multi-user state (2 or 3). To check if you are in the multi-user state, enter `who -r`.

### CAUTION:

Verify that you are using the correct tape for the tape drive on your system. Many of the tape cartridges look alike, and using the wrong tape can damage the tape drive mechanism and tape heads. The following table lists the different model of tape drives, the accompanying tape cartridge model identification, and the CMS computers that use the tape drives.

Tape Drive	Tape Cartridge	CMS Computers
20/40-GB 8mm	<i>Exatape</i> <sup>*</sup> 170m AME	<i>Enterprise 3500</i>
SLR5 4/8-GB QIC	<i>Sony</i> <sup>†</sup> SLR	<i>Ultra 5</i>
14-GB 8mm	<i>Exatape</i> 160mm AME	<i>Enterprise 3000</i>
5-GB 8mm	<i>Exatape</i> 112mm AME	<i>Enterprise 3000</i>
2.5-GB QIC	<i>3M</i> <sup>‡</sup>	<i>SPARCserver</i>
150 MB	<i>Maxell</i> <sup>§</sup> DC6320	<i>SPARCserver</i>

<sup>\*</sup>*Exatape* is a trademark of *Exabyte* Corporation.

<sup>†</sup>*Sony* is a registered trademark of Sony Corporation.

<sup>‡</sup>*3M* is a registered trademark of Minnesota Mining and Manufacturing.

<sup>§</sup>*Maxell* is a registered trademark of Maxell, Inc.

## Procedure

1. Enter `cmsadm` to access the CMS Administration menu. The CMS Administration menu appears:

```
Lucent Technologies CentreVu(R) Call Management System
Administration Menu
Select a command from the list below.
1) acd_create  Define a new ACD
2)  acd_remove  Remove all administration and data for an ACD
3)  backup      Filesystem backup
4)  pkg_install Install a feature package
5)  pkg_remove  Remove a feature package
6)  run_cms     Turn CentreVu CMS on or off
7)  port_admin  Administer Modems, Terminals, and Printers

Enter choice (1-10) or q to quit:
```

2. Enter `3` to select the `backup` option.

The program responds:

```
Select the tape drive type:
1) 150MB cartridge tape
2) 14.0 Gbyte 8mm tape
3) 5.0 Gbyte 8mm tape
4) 2.5 Gbyte cartridge tape
5) 4.0 - 8.0 Gbyte cartridge tape
6) 40.0 Gbyte 8mm tape

Enter choice (1-6):
```

3. Enter the number for the tape drive installed on your system. The system responds:

```
Calculating approximate number of tapes required. Please
wait.
```

The system calculates the approximate the number of tapes required for the backup. Please note that this is an approximation, and more tapes may be needed once the backup is under way.

If the number of tapes required is one, the system responds:

```
The backup will need approximately 1 tape.
```

```
Please insert the first cartridge tape into </dev/rmt/X>.
```

```
Press ENTER when ready:
```

If the number of tapes required is more than one, the system responds:

```
The backup will need approximately <X> tapes.
```

```
Be sure to number the cartridge tapes consecutively in the  
order they will be inserted.
```

```
Please insert the first cartridge tape into </dev/rmt/x>.
```

```
Press ENTER when ready:
```

4. To begin the backup, insert the cartridge tape, wait for the tape to rewind and reposition, and then press Enter.

If CMS is turned on, the system responds:

```
The backup is about to begin. CMS is currently on.
```

```
CMS will be turned off automatically during that portion  
of the backup which needs CMS off.
```

```
Press ENTER to proceed or Del to quit:
```

5. To continue the backup, press Enter. A CMSADM backup may take several hours, depending on the speed of the system and the tape drive.

If only one tape is required, the system responds:

```
Backing up files...
.....
.....
(dots continue to display as the system is backed up)
.....
XXXXXX blocks
Tape verification
XXXXXX blocks

Please label the backup tape(s) with the date and the
current CMS version (r3vXxx.x)
```

If only one tape was required, continue with Step [9](#). If more than one tape is required, the system responds:

```
Backing up files...
.....
.....
(dots continue to display as the system is backed up)
.....
End of medium on "output".
Please remove the current tape, number it, insert tape
number X, and press ENTER
```

 **CAUTION:**

*Label all tapes with the tape number and the date of the backup.  
Set the tape write-protect switch to read-only.*

6. Insert the next tape and press Enter to continue. When you insert the next tape, allow it to rewind and reposition before you press Enter. Repeat this step for any additional tapes.

After the system completes the backup, the system responds:

```
XXXXXXXX blocks
Tape Verification
Insert the first tape
Press Return to proceed:
```

7. Insert the first tape and press Enter to continue. After the tape is verified, the system responds:

```
End of medium on "input".
Please insert tape number X and press Return
```

8. Remove the first tape and insert the second tape. After the tape rewinds and repositions, press Enter to continue. Repeat this step for each additional tape.

After the last tape is verified, the system responds:

```
XXXXXXXX blocks
Please label the backup tape(s) with the date and the
current CMS version (r3vXxx.x)
```

9. Wait for the tape drive light-emitting diode (LED) to stop blinking before you remove the tape. The CMSADM file system backup is complete.

 **CAUTION:**

*Label all tapes with the tape number and the date of the backup.  
Set the tape write-protect switch to read-only.*

# Turning the System Over to the Customer

## Overview

This chapter describes how to test the *CentreVu*® Call Management System (CMS) software to ensure that the application is working properly before the system is turned over to the customer. Perform these procedures after:

- Completing the initial computer installation and CMS setup
- Completing a CMS software package upgrade.

Before you begin the procedures described in this chapter, the switch technicians must:

- Connect the CMS computer to the switch.
- Translate the switch with the CMS feature enabled.
- Connect the switch to an active link.

The procedures in this chapter include:

- Verifying system date and time
- Testing the connection between the computer and the Technical Service Center (TSC) or Center of Excellence (COE)
- Testing the link configuration between the computer and the switch
- Testing the CMS software
- Instructing the customer to change/assign their login passwords
- Turning the system over to the customer.

---

# Verifying the System Date and Time

---

## Overview

This section describes how to verify that the *Solaris* operating system time and the current local time are the same.

---

## Checking the *Solaris* System Date and Time

Verify that the system time is correct by entering `date`.

If the system time is correct, go to the [“Testing the Connection to the TSC or COE” on page 3-5](#). Otherwise, continue with [“Setting the System Date and Time”](#) and [“Setting the System Country and Time Zones.”](#)

---

## Setting the System Date and Time

1. Log in as *root*.
2. Change to an OpenBoot mode by entering the following:

```
/usr/sbin/shutdown -i0 -g0 -y
```

**⇒ NOTE:**

The `-i0` portion of the `shutdown` command string changes the system to an OpenBoot mode.

3. At the `ok` prompt, enter the following:

```
boot -s
```

The system responds as follows:

```
.  
.
Resetting.....
Type Ctrl-d to proceed with normal startup
(or give root password for system maintenance):
```

4. Enter the *root* password. The system responds:

```
Entering System Maintenance Mode
```

5. At the prompt, enter the command `date mmddHHMM[[cc]yy]` to set the time and date. For example:
  - **mm (month):** Enter the month (numeric). Range: 01-12 (01=January, 02=February, and so on).
  - **dd (day):** Enter the day of the month. Range: 01-31.
  - **HH (Hour):** Enter the current hour of the day, military time. Range: 00-23.
  - **MM (minute):** Enter the minute of the hour. Range: 00-59.
  - **cc (century):** Enter the century minus 1 (for example, 20 for the 21st century).
  - **yy (year):** Enter the last two digits of the current year (for example, 98 for 1998).
6. Continue with the "[Setting the System Country and Time Zones](#)" section.

## Setting the System Country and Time Zones

1. Edit the `/etc/default/init` file and set the `TZ` variable to equal the appropriate value in the `/usr/share/lib/zoneinfo` directory, as shown in the following example:

```
# vi /etc/default/init
<contents of the file is displayed>
# @(#)init.dfl 1.2 92/11/26
#
# This file is /etc/default/init. /etc/TIMEZONE is a symlink to this file.
# This file looks like a shell script, but it is not. To maintain
# compatibility with old versions of /etc/TIMEZONE, some shell constructs
# (i.e., export commands) are allowed in this file, but are ignored.
#
# Lines of this file should be of the form VAR=value, where VAR is one of
# TZ, LANG, or any of the LC_* environment variables.
#
TZ=US/Mountain ← This is the line you modify.
```

As an example for Mountain Standard Time, the `TZ` variable can be set to `MST` or `US/Mountain`. The entry in the `init` file is essentially a relative path name from the `/usr/share/lib/zoneinfo` directory. `MST` is a file in the `/usr/share/lib/zoneinfo` directory, and `Mountain` is a file in the `/usr/share/lib/zoneinfo/US` directory.

2. Write the read-only file using the `:w!` command.
3. Quit the file using the `:q` command.
4. Reboot the machine by entering `init 6`.

# Testing the Connection to the TSC or COE

## Overview

The information in this section is used to verify that the TSC or COE can connect to the CMS computer. This connection allows the TSC or COE to do remote maintenance.

## Testing the Remote Access Port

This section describes how to redirect the remote console port using the *Solaris* software package. Redirecting the console allows the TSC or COE to dial in and do remote maintenance. The port used for remote console access differs depending on the hardware platform:

Hardware Platform	Port A	Port B
<i>SPARCserver</i> <sup>*</sup> <i>Enterprise</i> <sup>†</sup> 3000 <i>Enterprise</i> 3500	Remote Console	Switch Link
<i>Ultra</i> <sup>‡</sup> 5	Switch Link	Remote Console

<sup>\*</sup>*SPARCserver* is a trademark of SPARC International, Inc.

<sup>†</sup>*Enterprise* is a trademark of Sun Microsystems, Inc.

<sup>‡</sup>*Ultra* is a trademark of Sun Microsystems, Inc.

Test the remote console port on the back of the computer by redirecting the console from the local console to the remote console, and then redirecting the console from the remote console back to the local console.

## Redirecting the Console to the Remote Console

1. Dial in from the remote console to the remote console modem (port A on a *SPARCserver*, *Enterprise 3000*, or *Enterprise 3500*; port B on an *Ultra 5*), and log in as *root*.
2. Remove the port monitor by entering the following:

```
/cms/install/bin/abcmadm -r ttyX (where X is a or b)
```

The program responds as follows:

```
ttyX is currently set to be incoming
Are you sure you want to change it? [y,n,?]
```

3. Enter *y*. The program responds as follows:

```
ttyX administration removed
```

4. To check the speed of the modem, enter the following:

```
/cms/install/bin/abcmadm -k
```

### NOTE:

All remote access ports have a default speed of 9600 bps.

5. Redirect the console to the remote console port by entering the following:

```
/cms/install/bin/abcmadm -c -b 9600 ttyX (where X is a or b)
```

The program responds as follows:

```
This change requires a reboot to take affect
Are you ready to reboot? [y,n,?]
```

6. Enter `y`. The program responds as follows:

```
Starting port monitor.  
Setting console parameters.  
Proceeding to reboot.
```

The system automatically reboots. As the system reboots, shutting down, reset, and rebooting messages appear on the local console. When the system starts to come back up, the local console should go blank, and the system boot diagnostics should appear on the remote console. After the system reboots, a `console login:` prompt should appear on the remote console.

7. Log in to the remote console as `root`. At this time, an XDM login window for the *OpenWindows*\* interface appears on the local console.

 **CAUTION:**

*If you enter Control-D from the remote console to exit the system without first redirecting control back to the local console, you may lock yourself from using the console locally or remotely.*

---

\**OpenWindows* is a trademark of Sun Microsystems, Inc.

## Redirecting the Console Back to the Local Console

1. Redirect the console back to the local console by entering the following:

```
/cms/install/bin/abccadm -c local
```

The program responds as follows:

```
Console set to local
```

```
This change requires a reboot to take affect
```

```
Are you ready to reboot? [y,n,?]
```

2. Enter `y`. The system automatically reboots and the remote console port comes up as the console. As the system reboots, shutting down messages appear on the remote console. When the system starts to come back up, the system boot diagnostics should appear on the local console. After the system reboots, a `console login:` prompt should appear on the local console. A `login:` prompt should appear on the remote console.
3. Log in to the local console as `root`.
4. Log in to the remote console as `root`.

The console has been redirected from the remote console back to the local console.

---

# Testing the ACD Link

---

## Overview

The following procedure should be completed by the on-site technician after the CMS software has been installed or upgraded to verify the link from the CMS computer to the switch that is using the Automatic Call Distribution (ACD) feature.

---

## Prerequisites

- The Common Desktop Environment (CDE) must be active.
  - CMS must be turned on.
- 

## Procedure

1. In one of the windows at a console, log into the system by using a CMS administrator's login ID (`su - cms`). Supply the correct password if prompted.
2. Access the CMS main menu by typing `cms` and entering the correct terminal type.

The CMS Main Menu has indicators that show if the link to the ACD is active. The link indicator consists of the "caret" ("^" and "v") at the right side of the banner line. There should be one caret for each ACD, and all should be pointed up (^). If you have four ACDs, for example, the link indicator should look like this: `^^^`. That means that all four ACDs are up and running.

3. To further test the ACD link, select Maintenance from the CMS Main Menu.
4. Select Connection Status from the Maintenance menu. The Connection Status should display the following:
  - The name of the ACD
  - That the application is in data transfer
  - That the session is in data transfer
  - That the connection is operational
  - The date, time, and any errors.
5. Return to the CMS Main Menu by pressing the **Exit** screen-labeled key (SLK) once.

---

# Testing the CMS Software

---

## Overview

The following procedure should be completed by the on-site technician after the CMS software has been installed or upgraded to verify the sanity of CMS software.

**⇒ NOTE:**

If any of the steps in this test fail, see the [“Solving Installation-Related Problems”](#) chapter and try to solve the problem associated with the step that failed. If you encounter a problem that you cannot solve, escalate the problem through normal procedures.

---

## Prerequisites

- The Common Desktop Environment (CDE) must be active
- CMS must be turned on.

---

## Procedure

1. Test the Real-Time Reports subsystem by doing the following from the CMS Main Menu:
  - a. Select the `Reports` option.
  - b. Select the `Real-time` option.
  - c. Select the `Split/Skill` option.
  - d. Select the `Split Status` or `Skill Status` option.
  - e. Verify that the `Split/Skill Status Report Input` window appears.
  - f. Enter a valid split number in the `Split:` or `Skill:` field.
  - g. Select the `Run` action list item, and run the report.
  - h. Verify that the `Split` or `Skill Status Report` window appears.

If the switch link is down, the report fields will be blank and the status line will read “Switch link down.”
  - i. Press the `Commands` SLK.
  - j. Select the `Print window` option to send the report to the printer.

- k. Look at the message line near the bottom of the window, and verify that there is a confirmation message about sending the report to the printer.
    - l. Verify that the report printed by checking the printer for the report.
    - m. Return to the CMS Main Menu screen by pressing the **Exit** SLK twice.
  2. Test the Historical Reports subsystem by doing the following from the CMS Main Menu:
    - a. Select the `Reports` option.
    - b. Select the `Historical` option.
    - c. Select the `Split/Skill` option.
    - d. Select the `Status` option.
    - e. Verify that the Split/Skill Status Report Input window appears.
    - f. Enter a valid split number in the `Split/Skill:` field.
    - g. Enter `-1` in the `Date:` field.
    - h. Select the `Run` action list item, and run the report.
    - i. Verify that the report window appears and that the information is displayed in the appropriate fields.

 **NOTE:**

If no historical data exists, the fields in the report window should be blank.

- j. Return to the CMS Main Menu by pressing the **Exit** SLK twice.
  3. Test the Dictionary subsystem by doing the following from the CMS Main Menu:
    - a. Select the `Dictionary` option.
    - b. Select the `Login Identifications` option.
    - c. Enter a "\*" character in the `Login ID:` field.
    - d. Select the `List all` action list item to list all the login IDs.
    - e. Verify that the logins are displayed (on a new system, the fields will be blank).
    - f. Return to the CMS Main Menu by pressing the **Exit** SLK twice.

4. Test the Exceptions subsystem by doing the following from the CMS Main Menu:
  - a. Select the `Exceptions` option.
  - b. Select the `Real-time Exception Log` option.
  - c. Verify that the window is accessible.

 **NOTE:**

For a new installation, this window may be blank.

- d. Return to the CMS Main Menu by pressing the `Exit` SLK once.
5. Test the Call Center Administration subsystem from the CMS Main Menu:
  - a. Select the `Call Center Administration` option.
  - b. Select the `Call Work Codes` option.
  - c. Press Enter.
  - d. Select the `List all` action list item, and list all the call work codes currently defined.
  - e. Verify that the displayed information is correct (on a new system, the fields will be blank).
  - f. Return to the CMS Main Menu by pressing the `Exit` SLK twice.
6. Test the Custom Reports subsystem by doing the following from the CMS Main Menu:
  - a. Select the `Custom Reports` option.
  - b. Select the `Real-time` option, and verify that the names of existing custom reports are listed. If there are no reports, you receive a message saying the submenu is empty.
  - c. Return to the CMS Main Menu by pressing the `Exit` SLK once.

7. Test the User Permissions subsystem by doing the following from the CMS Main Menu:
  - a. Select the `User Permissions` option.
  - b. Select the `User Data` option.
  - c. Verify that the User Data Input window appears.
  - d. Return to the CMS Main Menu by pressing the `Exit` SLK once.
8. Test the System Setup subsystem by doing the following from the CMS Main Menu:
  - a. Select the `System Setup` option.
  - b. Select the `CMS state` option.
  - c. Verify that CMS is operating in the `Multi-user` mode.
  - d. Return to the CMS Main Menu by pressing the `Exit` SLK once.
9. Test the Maintenance subsystem by doing the following from the CMS Main Menu:
  - a. Select the `Maintenance` option.
  - b. Select the `Printer Administration` option.
  - c. Enter a valid printer name in the `CMS printer name:` field.
  - d. Select the `List all` action list item, and list the printer parameters.
  - e. Verify that the printer has been administered correctly.
  - f. Return to the CMS Main Menu by pressing the `Exit` SLK twice.
10. If the Graphics feature package has been enabled, test the Graphics subsystem by doing this from the CMS Main Menu:
  - a. Select the `Graphics` option.
  - b. Verify that a Real-time Graphics screen can be accessed.
  - c. Return to the CMS Main Menu by pressing the `Exit` SLK once.
11. At each CMS terminal, log in as `cms` and choose the correct terminal type to verify that the terminals are working properly. To log off, select the `Logout` option from the CMS Main Menu.

---

# Assigning Customer Passwords

---

## Overview

This section describes how the customer needs to assign passwords to each of their logins on the CMS computer. Prior to testing the CMS software, the customer must assign passwords to each of the following logins:

- root
- cms
- any other administration logins that have been added for a customer.

**⇒ NOTE:**

Have the customer record the passwords for each login on the provided “System Acceptance Worksheet” at the end of this chapter. The technician should NOT know these passwords.

---

## Procedure

1. Log in as *root*.
2. At the system prompt, have the customer enter the following:

```
passwd <login>
```

where *<login>* is *root*, *cms*, and so on. The system responds as follows:

```
New password:
```

3. Have the customer enter the new password. The system responds as follows:

```
Re-enter new password:
```

4. Have the customer enter the password again.
5. Repeat this procedure for each customer login.

---

# Turning the System Over to the Customer

---

## Overview

This section contains the final check before turning the system over to the customer.

---

## Procedure

1. There are two sets of backup tapes delivered with a new system: the original set from the factory, and the set created after provisioning has been completed. Set these tapes to write-protect mode and store them in a safe place.
2. After the on-site installation is complete, back up the system by following the procedures outlined in [“Performing a CMSADM Backup” on page 2-181](#).

 **CAUTION:**

*Use a new set of backup tapes for this CMSADM File System backup. Do **NOT** use the original set of factory backup tapes or provisioning backup tapes. Make sure that the customer has extra backup tapes for their CMS computer.*

3. If you have not already done so, back up the customer's historical data by doing a full maintenance backup from the Maintenance subsystem in CMS. See the “Backup Strategy” section of *CentreVu® CMS R3V8 Administration* (585-210-910).
4. Give the customer all of the CMS documentation, software CDs, and X.25 license information.
5. Copy and complete the Customer System Acceptance Worksheet from the following page, attach the indicated printouts and screen dumps, and give the resulting package to the customer's CMS administrator. Have the customer enter their logins and passwords. The technician should NOT know the customer login passwords.

 **CAUTION:**

*For system security, the CMS administrator should store written passwords, INFORMIX\* serial numbers and key license information, and X.25 license information in a secure place.*

---

\*INFORMIX is a registered trademark of Informix Software, Inc.

**Customer System Acceptance Worksheet**

**r Passwords for system login IDs:**

Login ID:     root     Password: \_\_\_\_\_  
 Login ID: \_\_\_\_\_ Password: \_\_\_\_\_  
 Login ID: \_\_\_\_\_ Password: \_\_\_\_\_  
 Login ID: \_\_\_\_\_ Password: \_\_\_\_\_

**r CMS administrator login IDs and passwords:**

Login ID:     cms     Password: \_\_\_\_\_  
 Login ID: \_\_\_\_\_ Password: \_\_\_\_\_  
 Login ID: \_\_\_\_\_ Password: \_\_\_\_\_  
 Login ID: \_\_\_\_\_ Password: \_\_\_\_\_

**r df -t results** (attach screen dump showing df -t command results, or record results here):

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

**r X.25 Password:**

Enter the X.25 password: \_\_\_\_\_

**r Printer administration:**

Print out the CMS Maintenance - Printer Administration - List all window

**r Free Space Allocation:**

Print out the CMS System Setup - Free Space Allocation window

**r Data Storage Allocation parameters:**

Print out the CMS System Setup - Data Storage Allocation window for each ACD

**r Storage Intervals parameters:**

Print out the CMS System Setup - Storage Intervals window for each ACD

# Maintaining the CMS Software

## Overview

This chapter provides the procedures used to maintain the *CentreVu*® Call Management System (CMS) software. Refer to *CentreVu*® *Call Management System R3V8 Hardware Maintenance and Troubleshooting* (585-210-919) or *CentreVu*® *Call Management System Sun\* Enterprise† 3500 Computer Maintenance and Troubleshooting* (585-215-875) for additional maintenance information.

This chapter describes the following maintenance procedures:

- Backing up the CMS system
- Installing *the INFORMIX‡* Structured Query Language (SQL) package.

### ⇒ NOTE:

Personnel at the Technical Service Center (TSC) will need assistance from an on-site technician or the customer's CMS administrator in order to perform most of the procedures in this chapter.

## Remote Terminal Tip

When executing commands remotely that may take a long time to complete (such as `cpio` and `/olds` commands), use the `nohup` command to ensure that the command will complete without interruption in case the data line disconnects. An example using the `nohup` command is shown below:

```
nohup cpio -icmudf -C 10240 -I /dev/rmt/0c "/cms" | tee
```

---

\**Sun* is a registered trademark of Sun Microsystems, Inc.

†*Enterprise* is a trademark of Sun Microsystems, Inc.

‡*INFORMIX* is a registered trademark of Informix Software, Inc.

---

# Backing Up the CMS System

---

## Overview

CMS provides two basic types of backups:

- CMS Administration (CMSADM) File System Backup
- CMS Maintenance Backup — Full and Incremental.

For more information about backups and restores, see *CentreVu® Call Management System R3V8 Administration* (585-210-910).

If you are restoring software after a system failure or disk crash, see *CentreVu® Call Management System R3V8 Hardware Maintenance and Troubleshooting* (585-210-919) or *CentreVu® Call Management System Sun® Enterprise™ 3500 Computer Maintenance and Troubleshooting* (585-215-875) for the correct restore procedures.

 **CAUTION:**

*Use a designated set of backup tapes when doing a backup. Do not use the original set of factory or provisioning backup tapes.*

# Performing a CMSADM Backup

The CMSADM file system backup saves all of the file systems on the computer onto a tape.

## Overview

The CMSADM file system backup includes the following:

- *Solaris 7* system files and programs
- CMS programs and data
- Non-CMS customer data placed on the computer (in addition to the CMS data).

The CMSADM file system backup should be done at the following times:

- After the system has been set up in the factory

This backup contains the default factory configuration. These tapes should be saved if the system must be reinstalled in the field.

- After the CMS is provisioned

This backup contains the *Solaris* system files and programs and CMS configuration data placed on the computer by TSC provisioning personnel. These tapes should also be saved and not reused.

In addition, field technicians should perform a CMS full maintenance backup before they turn a new system over to the customer. See *CentreVu® CMS R3V8 Administration* (585-210-910) for more information.

- Before and after the CMS software is upgraded (usually done by a field technician)
- Once a month (performed by the customer).

### CAUTION:

*The customer must use a new set of backup tapes for this CMSADM File System backup. The customer must **NOT** use the original set of factory or provisioning backup tapes.*

The number of cartridge tapes required to complete a CMSADM file system backup depends on the amount of data on the system and the capacity of the backup tape. The program estimates the number of tapes required and informs the user.

## Platform Considerations

- All platforms.

## Prerequisites

- Before starting the backup procedures described in this section, log in as *root*, and enter `lp /etc/vfstab`. The output from the printer is necessary when doing a system restore. Bundle the printout of the `/etc/vfstab` file with the system backup tape(s) for future reference.
- Verify that the computer is in a *Solaris* multi-user state (2 or 3). To check if you are in the multi-user state, enter `who -r`.

### CAUTION:

Verify that you are using the correct tape for the tape drive on your system. Many of the tape cartridges look alike, and using the wrong tape can damage the tape drive mechanism and tape heads. The following table lists the different model of tape drives, the accompanying tape cartridge model identification, and the CMS computers that use the tape drives.

Tape Drive	Tape Cartridge	CMS Computers
20/40-GB 8mm	<i>Exatape</i> * 170m AME	<i>Enterprise 3500</i>
SLR5 4/8-GB QIC	<i>Sony</i> † SLR	<i>Ultra 5</i>
14-GB 8mm	<i>Exatape</i> 160mm AME	<i>Enterprise 3000</i>
5-GB 8mm	<i>Exatape</i> 112mm AME	<i>Enterprise 3000</i>
2.5-GB QIC	<i>3M</i> ‡	<i>SPARCserver</i>
150 MB	<i>Maxell</i> § DC6320	<i>SPARCserver</i>

\**Exatape* is a trademark of *Exabyte* Corporation.

†*Sony* is a registered trademark of *Sony* Corporation.

‡*3M* is a registered trademark of *Minnesota Mining and Manufacturing*.

§*Maxell* is a registered trademark of *Maxell, Inc.*

## Procedure

1. Enter `cmsadm` to access the CMS Administration menu. The CMS Administration menu appears:

```
Lucent Technologies CentreVu(R) Call Management System
Administration Menu
Select a command from the list below.
1) acd_create  Define a new ACD
2) acd_remove  Remove all administration and data for an ACD
3) backup      Filesystem backup
4) pkg_install  Install a feature package
5) pkg_remove  Remove a feature package
6) run_cms     Turn CentreVu CMS on or off
7) port_admin  Administer Modems, Terminals, and Printers

Enter choice (1-10) or q to quit:
```

2. Enter `3` to select the `backup` option.

The program responds:

```
Select the tape drive type:
1) 150MB cartridge tape
2) 14.0 Gbyte 8mm tape
3) 5.0 Gbyte 8mm tape
4) 2.5 Gbyte cartridge tape
5) 4.0 - 8.0 Gbyte cartridge tape
6) 40.0 Gbyte 8mm tape

Enter choice (1-6):
```

3. Enter the number for the tape drive installed on your system. The system responds:

```
Calculating approximate number of tapes required. Please
wait.
```

The system calculates the approximate the number of tapes required for the backup. Please note that this is an approximation, and more tapes may be needed once the backup is under way.

If the number of tapes required is one, the system responds:

```
The backup will need approximately 1 tape.
```

```
Please insert the first cartridge tape into </dev/rmt/X>.
```

```
Press ENTER when ready:
```

If the number of tapes required is more than one, the system responds:

```
The backup will need approximately <X> tapes.
```

```
Be sure to number the cartridge tapes consecutively in the  
order they will be inserted.
```

```
Please insert the first cartridge tape into </dev/rmt/x>.
```

```
Press ENTER when ready:
```

4. To begin the backup, insert the cartridge tape, wait for the tape to rewind and reposition, and then press Enter.

If CMS is turned on, the system responds:

```
The backup is about to begin. CMS is currently on.
```

```
CMS will be turned off automatically during that portion  
of the backup which needs CMS off.
```

```
Press ENTER to proceed or Del to quit:
```

5. To continue the backup, press Enter. A CMSADM backup may take several hours, depending on the speed of the system and the tape drive.

If only one tape is required, the system responds:

```

Backing up files...

.....
.....
(dots continue to display as the system is backed up)
.....
XXXXXX blocks
Tape verification
XXXXXX blocks

Please label the backup tape(s) with the date and the
current CMS version (r3vXxx.x)
    
```

If only one tape was required, continue with Step [9](#). If more than one tape is required, the system responds:

```

Backing up files...

.....
.....
(dots continue to display as the system is backed up)
.....
End of medium on "output".
Please remove the current tape, number it, insert tape
number X, and press ENTER
    
```

 **CAUTION:**

*Label all tapes with the tape number and the date of the backup.  
Set the tape write-protect switch to read-only.*

6. Insert the next tape and press Enter to continue. When you insert the next tape, allow it to rewind and reposition before you press Enter. Repeat this step for any additional tapes.

After the system completes the backup, the system responds:

```
XXXXXXXX blocks  
Tape Verification  
Insert the first tape  
Press Return to proceed:
```

7. Insert the first tape and press Enter to continue. After the tape is verified, the system responds:

```
End of medium on "input".  
Please insert tape number X and press Return
```

8. Remove the first tape and insert the second tape. After the tape rewinds and repositions, press Enter to continue. Repeat this step for each additional tape.

After the last tape is verified, the system responds:

```
XXXXXXXX blocks  
Please label the backup tape(s) with the date and the  
current CMS version (r3vXxx.x)
```

9. Wait for the tape drive light-emitting diode (LED) to stop blinking before you remove the tape. The CMSADM file system backup is complete.

 **CAUTION:**

*Label all tapes with the tape number and the date of the backup.  
Set the tape write-protect switch to read-only.*

## Checking the Contents of the CMSADM Backup Tape

### Procedure

To determine if the a backup tape has saved the correct information, or to see if a particular file has been saved, you can list the files on the backup tape.

**⇒ NOTE:**

It can take a long time to display the file names on the backup tape.

1. Insert the first backup tape.
2. To list the files on the tape, enter the following command on a single line:

```
nohup cpio -ivct -C 10240 -I /dev/rmt/0c -M "Insert  
tape %d and press Enter" | tee
```

The system displays a list of files.

3. If you are not sure of the device path, enter the following commands:

```
mt -f /dev/rmt/0c status  
mt -f /dev/rmt/1c status
```

The correct device path will show information similar to the following:

```
Tandberg 2.5 Gig QIC tape drive:  
sense key(0x0)= No Additional Sense residual= 0 retries= 0  
file no= 0    block no= 0
```

4. After you have seen the files you are looking for, or have confirmed that data on the tape is accurate, press Delete to stop the display.

## Doing CMS Maintenance Backups

CMS maintenance backups save only CMS data (administration and historical). The CMS data for each Automatic Call Distribution (ACD) should be backed up:

- After the CMS is provisioned
- After the CMS software is upgraded
- On a daily or weekly basis.

You can do these backups within CMS using the “Maintenance: Back Up Data” window. See the “Maintenance” chapter in *CentreVu® CMS R3V8 Administration* (585-210-910).

---

## Adding the *Informix SQL* Package

This procedure installs a new Informix SQL package on a system where the Informix SE (Standard Engine) and ILS (International Language Supplement) packages are already installed.

Before you begin, obtain the “*INFORMIX-SQL*” CD, and the serial number and serial number key for the Informix SQL and Informix SE software packages. The serial number information is printed on the Informix software CDs.

---

### Procedure

1. Enter:

```
rm /opt/informix/etc/.snfile
```

2. Install the Informix SQL package, as described in “Installing INFORMIX SQL” on page 2-83.

3. When the Informix SQL installation is complete and the system returns to the prompt, enter:

```
cd /opt/informix
```

4. Enter:

```
./installse
```

The program responds:

```
Press RETURN to continue or the interrupt key  
(usually CTRL-C or DEL) to abort.
```

5. Press Enter.

6. When prompted, enter:

- the product serial number
- the product serial number key

The program responds:

```
Press RETURN to continue or the interrupt key  
(usually CTRL-C or DEL) to abort.
```

7. Press Enter.

When the installation is finished, the system returns to the prompt.

8. Enter:

```
./installcon
```

The program responds:

```
Your existing INFORMIX shared libraries, if any,  
will be replaced and upgraded.
```

```
Are you sure? [yes/no]
```

9. Enter: y

The program responds:

```
Is I-Connect being installed along with Informix  
Dynamic Server with Universal Data Option (Release  
9, requires to be run as user "informix")?
```

```
(yes or no)
```

10. Enter: n

The program responds:

```
WARNING! This software and its authorized use...  
.....
```

```
Press RETURN to continue or the interrupt key  
(usually CTRL-C or DEL) to abort.
```

11. Press Enter.

12. When prompted, enter:

- the product serial number
- the product serial number key

After the serial number information is provided, the program responds:

```
Press RETURN to continue or the interrupt key  
(usually CTRL-C or DEL) to abort.
```

13. Press Enter.

When the installation is finished, the system returns to the prompt.

14. Enter: eject cdrom

# Solving Installation-Related Problems

## Overview

This chapter provides information to assist in solving related which may occur during CMS installation. The following installation-related problems are described:

- Troubleshoot a *Solstice DiskSuite*<sup>\*</sup> Software Installation
- Fix a *Solaris*<sup>†</sup> Patch Installation
- [Listing Pkgchk Errors](#)
- [Solving X.25 License Installation Problems](#)
- Check Installed *Solaris* Patches
- Recognize New Hardware Devices.

### ⇒ NOTE:

When executing commands remotely that may take a long time to complete (such as `cpio` and `/olds` commands), use the `nohup` command to ensure that the command will complete without interruption in case the data line disconnects. An example using the `nohup` command is shown below:

```
nohup cpio -icmudf -C 10240 -I /dev/rmt/0c "/cms" | tee
```

---

<sup>\*</sup>*Solstice DiskSuite* is a registered trademark of Sun Microsystems Inc.

<sup>†</sup>*Solaris* is a registered trademark of Sun Microsystems, Inc.

## Troubleshooting a *Solstice DiskSuite* Software Installation

The *Solstice DiskSuite* software package allows multiple disk partitions to be logically combined to create a single large partition. Using the *Solstice DiskSuite* package allows CMS databases to span multiple disks as it increases in size.


To troubleshoot problems with the *Solstice DiskSuite* software or the `/cms` file system, you must understand two basic concepts of *Solstice DiskSuite* operation: **state databases** and **metadevices**.

A state database contains the *Solstice DiskSuite* configuration information for the system, and is stored on a raw disk partition created for that purpose. At boot time, the operating system accesses the state database to configure the system. Typically, a system contains multiple copies of the state database.

A metadevice is a logical device that consists of a set of physical disk partitions. A system controlled by *Solstice DiskSuite* software can contain any number of metadevices; the state database contains a record of which disk partitions belong to which metadevices. Once a metadevice has been set up, the underlying disk partitions can be accessed only through the metadevice.

For a complete description of *Solstice DiskSuite* software and its basic technical concepts, see the *Solstice DiskSuite Administration Guide*, published by Sun Microsystems, Inc.

CMS uses the *Solstice DiskSuite* software to set up three state databases, and to create a single metadevice containing all the disk partitions used to store CMS data. The following illustration depicts this concept.



## Identifying Problems

Use the procedures and hints in this section to help identify and resolve problems with the CMS scripts that administer *Solstice DiskSuite* software, with the physical disks, with the state databases, with the metadevice, or with the `/cms` file system.

## Problems with CMS Administration Scripts

Use the `pkginfo -l SUNWmd` command to verify that the *Solstice DiskSuite* software is installed.

If it has not been installed, you may have to reinstall the operating system and repartition your disks. Once the software has been installed, you must use the `olds` script to set up the environment so CMS can access the disks. For a step-by-step description of installing *Solstice DiskSuite* software and using the `olds` script, see the [“Installing Software and Setting Up CMS”](#) chapter. If you receive an error message from the `olds` script, see [“Common Error Messages” on Page 5-7](#).

## Disk I/O Problems

Check the system console and the `/var/adm/messages` log for messages that indicate problems with a specific hard disk. If a disk is generating errors, it may need to be replaced. For procedures related to recovering from disk crashes and replacing hard disk drives, see *CentreVu® CMS R3V8 Hardware Maintenance and Troubleshooting* (585-210-919) or *CentreVu® CMS Sun® Enterprise\* 3500 Computer Maintenance and Troubleshooting* (585-215-875).

## State Database Problems

Check the system console and the `/var/adm/messages` log for messages that indicate problems with a state database. Be aware that on a multiple-disk system, there should always be two copies of the state database on the first internal disk drive, and a third copy on the second internal disk drive. On a single-disk system, there should be three copies of the state database on the single disk.

Use the `/usr/opt/SUNWmd/sbin/metadb -i` command to check the status of the state database.

If the response indicates a state database problem, you must remove and re-create the state database that is causing the problem. Follow these steps:

1. Check whether the error is caused by an underlying disk problem. If it is, recover or replace the disk. See *CentreVu® CMS R3V8 Hardware Maintenance and Troubleshooting* (585-210-919) or *CentreVu® CMS Sun® Enterprise† 3500 Computer Maintenance and Troubleshooting* (585-215-875) for additional details.

---

\*Enterprise is a trademark of Sun Microsystems, Inc.

†Enterprise is a trademark of Sun Microsystems, Inc.

2. If you find no disk problem, or if the state database problem persists after the disk has been repaired, use the `metadb` command to remove and re-create the state database causing the problem. For example, use the following commands:

```
/usr/opt/SUNWmd/sbin/metadb -d mddb01
```

```
/usr/opt/SUNWmd/sbin/metadb -a mddb01
```

## Metadevice Problems

Use the `/usr/opt/SUNWmd/sbin/metastat` command to verify that the metadevice is set up correctly. The program responds as follows:

```
d19: Concat/Stripe
  Size: 1819440 blocks
  Stripe 0:
    Device                Start Block  Dbase
    c0t3d0s3                0           No
```

To verify the metadevice setup, you must examine the response to the command. You are looking for two things:

- a. All your disk drives must be accounted for.

You can verify that simply by checking the Size figure (it should roughly equal the total capacity of all your disks) and counting the number of devices listed (there should be a “Stripe” section for every drive). If some of your drives seem to be missing, verify that all your drives are plugged in and turned on, and that each external drive has a unique target number.

- b. The device names must reflect the appropriate slice numbers.

The slice numbers are represented by the final two characters of the device name. A properly set up `/cms` file system begins with slice 3 of the first internal disk, and slice 1 of each of the remaining disk drives. Consequently, the device name of the first internal disk drive must end with s3 (for example, `c0t0d0s3`); all other device names must end in s1 (for example, `c2t1d0s1`).

If there is any discrepancy between the output of the `metastat` command and the configuration required to run CMS, you will have to set up your disk drives again.

## Problems with the /cms File System

Use the following steps to check the `/cms` file system for errors:

1. Log in as `root`.
2. Enter the following:

```
vi /etc/vfstab
```

The file will appear similar to the following:

```
#device      device      mount      FS      fsck  mount  mount
#to mount    to fsck     point      type    pass  at boot options
#
#/dev/dsk/c1d0s2 /dev/rdisk/c1d0s2 /usr      ufs     1      yes    -
fd          -          /dev/fd fd      -      no     -
/proc      -          /proc  proc   -      no     -
/dev/dsk/c0t3d0s4 -          -        swap   -      no     -
/dev/dsk/c0t3d0s0 /dev/rdisk/c0t3d0s0 /          ufs     1      no     -
/dev/md/dsk/d19 /dev/md/rdisk/d19 /cms      ufs     2      yes    -
```

3. Add a pound sign (#) at the beginning of the `/dev/md/dsk/d19` line. This “comments out” that line.
4. Write and quit the file.
5. Reboot the system by entering `init 6`.
6. When the system is back up, log in as `root`.
7. Check the `/cms` file system by entering the following:

```
fsck -y /dev/md/rdisk/d19
```

The file will look similar to the following:

```
** /dev/md/rdisk/d19
** Last Mounted on /cms
** Phase 1 - Check Blocks and Sizes
** Phase 2 - Check Pathnames
** Phase 3 - Check Connectivity
** Phase 4 - Check Reference Counts
** Phase 5 - Check Cyl groups
1952 files, 156146 used, 698956 free (516 frags, 87305 blocks, 0.0%
fragmentation)
```

8. Enter the following:

```
vi /etc/vfstab
```

The file will appear similar to the following:

```
#device      device      mount      FS      fsck  mount  mount
#to mount    to fsck     point      type    pass  at boot options
#
#/dev/dsk/c1d0s2 /dev/rdisk/c1d0s2 /usr      ufs     1      yes    -
fd -         /dev/fd fd -      no     -
/proc -       /proc  proc -      no     -
/dev/dsk/c0t3d0s4 -        -        swap -     no     -
/dev/dsk/c0t3d0s0 /dev/rdisk/c0t3d0s0 /         ufs     1      no     -
#/dev/md/dsk/d19 /dev/md/rdisk/d19 /cms     ufs     2      yes    -
```

9. Delete the pound sign (#) at the beginning of the `/dev/md/dsk/d19` line. This “uncomments” that line.

10. Write and quit the file.

11. Mount the CMS file system by entering:

```
mount /cms
```

If you have trouble mounting `/cms`:

- Verify that the `/cms` directory exists by entering:
 

```
ls -ld /cms
```
- If `/cms` does not exist, use the following to create it:
 

```
mkdir /cms
```
- Use the `metastat` command to determine the metadvice being used. Then verify that the entry for `/cms` in the `/etc/vfstab` file is correct. If you find any errors, correct them.

## Common Error Messages

This section presents, in alphabetical order, the messages commonly associated with installing and setting up the *Solstice DiskSuite* software to work with a CMS system. Each message is accompanied by its probable cause and the likely solution.

Message	Cause	Solution
/cms: Deadlock situation detected/avoided	Both CMS and the operating system are trying to access the swap file, leading to a deadlock.	Turn off CMS, deactivate all the swap files residing on /cms ( <code>swap -d /cms/swap</code> ), and reenter the command. Remember to reactivate the swap files when the <code>growfs</code> command completes ( <code>swap -a /cms/swap</code> ).
device: c0t6d0 will not be used	Warning that c0t6d0 will not be set up for <i>Solstice DiskSuite</i> .	Since c0t6d0 is the CD-ROM drive, that is not a problem.
device: <i>devicename</i> cannot be setup, or does not exist...	The disk you are trying to attach is turned off, does not exist, or was removed from the system.	Power-up the disk drive, or verify the correct name for the disk, or attach the disk to the system and reboot with a <code>boot -r</code> command from the open boot prompt.
Disk <i>devicename</i> already attached, exiting...	You are trying to attach a disk that is already attached.	Verify the name of the disk. Look at the target number on the back of the disk drive if possible, or consult the device documentation.
disk: <i>devicename</i> partition 1 is not partitioned correctly	You need to repartition disk <i>devicename</i> .	Use the <code>format</code> command. See <i>CentreVu® CMS R3V8 Hardware Maintenance and Troubleshooting</i> (585-210-919) or <i>CentreVu® CMS Sun® Enterprise™ 3500 Computer Maintenance and Troubleshooting</i> (585-215-875).
DiskSuite must be installed	You must install the <i>Solstice DiskSuite</i> software package.	See <a href="#">“Installing the Solstice DiskSuite Software” on Page 2-84</a> .
In order to attach disk, /cms must already be mounted, exiting...	The /cms file system was not mounted.	Execute a <code>mount /cms</code> command and rerun the command that failed.

Message	Cause	Solution
metadb: <i>systemname:</i> <i>devicename:</i> has a metadvice database replica	There are already state database replicas existing on the indicated system and device.	No further action is required.
metainit: <i>systemname:</i> /etc/opt/SUNWmd/md .tab line 12: d19: unit already set up	An initial setup of the file system has already been performed.	<p>If you are trying to attach a new disk, execute an <code>olds -setup</code> command for that device. To attach device <code>c0t2d0</code>, for example, you would enter <code>/olds/olds -setup c0t2d0</code>. If you need to do an initial setup, use these commands:</p> <pre data-bbox="781 662 1257 878">/olds/olds -cleanup &lt;reboot when command completes&gt; /olds/olds -check_disks /olds/olds -mk_files /olds/olds -metadbs /olds/olds -setup</pre> <p>Then restore all your swap files and their <code>/etc/vfstab</code> entries.</p>
metainit: syntax error	This is the <code>olds</code> general failure message. The most likely cause is that the <code>/etc/opt/SUNWmd.tab</code> file disagrees with your configuration. (The file, for example, says you have seven disks in a given metadvice, but your configuration only has six.)	Verify that <code>/etc/opt/SUNWmd.tab</code> is accurate. As a last resort, use an old <code>md.tab</code> file or do an initial <code>olds</code> setup.
newfs of cms metadvice failed	There is an internal problem with one of your disks.	Enter a <code>/usr/opt/SUNWmd/sbin/metaclear d19</code> command, and then rerun the <code>olds -setup</code> script. If the same error recurs after doing this, repartition your disks or call Lucent Technologies National Customer Care Center at 1-800-242-2121.

Message	Cause	Solution
prtvtoc: /dev/rdisk/c0t6d0: Device busy	This message usually implies that the device probed by the script is not to be used as a disk because it is a read-only disk (that is, a CD-ROM drive).	This is not a problem.
Warning: Current Disk has mounted partitions	The format command is warning you that it is probing a mounted disk. A probe, however, is a nondestructive task that poses no danger to your data.	Ignore this message.
You must be root in order to run this command	Superuser privileges are necessary to run this script because most of the commands are related to system administration.	Log in as <i>root</i> .
You need to have at least one disk set up, before attaching one, exiting...	You tried to use olds to attach a disk, but the metadvice has not yet been set up.	To set it up, run the <code>olds -setup</code> command without arguments.
/etc/system has been updated since the last reboot; cms cannot run without an up-to-date /etc/system file	This message displays when you try to turn CMS on, but the <code>/etc/system</code> file is not up to date.	The system must be rebooted using <code>/usr/sbin/shutdown -y -i6 -g0</code> .

## Listing Pkgchk Errors

The `pkgchk -n cms` command lists some common error messages that do not indicate an actual problem. The error messages in the following table can be ignored.

Location	Error Message	Occurs
/cms/install/logdir/admin.log	group name <root> expected <cms> actual.	After the installation and before setup.
/usr/lib/cms/pbxtrcflags	pathname does not exist.	After the installation and before setup.
/cms/env/cms_mon/State_tbl	group name <bin> expected <other>actual.	After the setup and before running cms.
/cms/install/logdir/admin.log	group name <root> expected <cms>actual.	After the setup and before running cms.
/usr/lib/cms/pbxtrcflags	pathname does not exist.	After the setup and before running cms.
/cms/env/cms_mon/State_tbl	group name <bin> expected <cms> actual.	After running cms.
/cms/install/logdir/admin.log	group name <root> expected <cms> actual.	After running cms.
/usr/lib/cms/pbxtrcflags	group name <bin> expected <cms> actual.	After running cms.

## Solving X.25 License Installation Problems

Error messages are generated by the license system if you have problems during the installation.

Message	Cause	Solution
DEMO mode supports only one SERVER host!	An attempt was made to configure a demonstration version of the software for more than one server.	Call <i>Sun</i> license support to obtain a permanent version of the X.25 license.
hostname: Wrong hostid, exiting	The hostid is wrong for the host name. This can happen if the boot ROM or motherboard is replaced.	Call <i>Sun</i> license support and obtain a new X.25 license key for this new hostid name.
Starting the X.25 software - please wait X.25 : Creating link XX.... X.25 : link XX has been started Unable to get license, X.25 exiting The network failed to come up correctly.	<ul style="list-style-type: none"> <li>- The X.25 license password was entered incorrectly</li> <li>- The password was generated for the wrong hostid or hostname</li> <li>- The license manager process (lmgrd) did not start when you started CMS.</li> </ul>	<ul style="list-style-type: none"> <li>- Enter the password correctly</li> <li>- Call Sun to reissue the password for the correct hostid or hostname</li> <li>- Check the license manager with the <code>ps - ef   grep lmgrd</code> command. If the lmgrd process is not running, restart the license manager with <code>/etc/rc2.d/S85lmgrd start</code>.</li> </ul>

## Finding a Misplaced X.25 Password

If you are reinstalling the X.25 software and license, and have misplaced your X.25 password, enter the following command to display the password:

```
cat /etc/opt/licenses/licenses_combined
```

If this file no longer exists, check the customer acceptance worksheet in the [“Turning the System Over to the Customer”](#) chapter. If you still cannot find the password, you must call *Sun* license support and obtain your X.25 password again.

## Checking Installed *Solaris* Patches

To verify that the correct *Solaris* patches are installed, do the following:

1. Enter the following:

```
showrev -p
```

The system responds as follows:

```
Patch: 105084-02  Obsoletes:  Packages: SUNWx25a.2 9.1,PATCH=02,  
SUNWx25b.2 9.1,PATCH=02  
Patch: 105256-01  Obsoletes:  Packages: SUNWcsu  
Patch: 103582-14  Obsoletes:  Packages: SUNWcsu, SUNWcsr  
Patch: 103594-10  Obsoletes:  Packages: SUNWcsu  
.  
.  
.
```

2. Check the list to verify that all the *Solaris* patches you need are installed. For more information about *Solaris* patches, see the [“Maintaining the CMS Software”](#) and [“Installing Software and Setting Up CMS”](#) chapters.

---

## Recognizing New Hardware Devices

During a *Solaris* installation, externally powered devices, such as disk drives and tape drives, may not be recognized if they are not connected to power or not powered up. This is also true if you add a new port board to the computer as part of an upgrade or addition.

If you discover that a hardware device is not being recognized, you must either reboot from the CD-ROM and reinstall *Solaris*, or do the following:

1. Enter `init 0` to reboot the system.
2. Enter `boot -r` to force the system to recognize the new components.
3. When the system reboots, log in as *root*.



# Glossary

<b>Access Permissions</b>	Permissions assigned to a Call Management System (CMS) user so that the user can access different subsystems in CMS or administer specific elements (splits/skills, trunks, vectors, and so on) of Automatic Call Distribution (ACD). Access permissions are specified as <b>read</b> or <b>write</b> permission. Read permission allows the CMS user to access and view data (for example, run reports or view the Dictionary subsystem). Write permission allows the CMS user to add, modify, or delete data and execute processes.
<b>ACD</b>	See Automatic Call Distribution (ACD)
<b>Acknowledgment</b>	A window that requires the user to confirm an action or to acknowledge a system message (for example, system going down, warning, or fatal error for the user window). This window cannot be moved, sized, or scrolled and disappears only when the user confirms the message.
<b>Action List</b>	A menu in the upper right corner of most user windows. The menu lists the actions available for that particular user window (for example, add, modify, delete, and so on). The user selects an action after entering necessary data in the window.
<b>Add Package</b>	A <i>Solaris</i> <sup>*</sup> operating system command ( <code>pkgadd</code> ) that allows you to add an additional software package.
<b>ADU</b>	See Asynchronous Data Unit (ADU)
<b>Agent</b>	A person who answers calls to an extension in an ACD split. This person is known to CMS by a login identification keyed into a voice terminal.
<b>Agent Login ID</b>	A 1- to 4-digit number (Generic 2) or a 1- to 9-digit number (Generic 3) entered by the agent at the ACD extension to activate the position. Agent logins are required for all CMS-measured ACD agents.
<b>Agent Skill</b>	The different types of calls a particular agent can handle. An agent can be assigned up to four skills. These skills are assigned as either primary or secondary skills. See “Primary Skill” or “Secondary Skill” definitions in this Glossary.
<b>Agent State</b>	A feature of agent call handling that allows agents to change their availability to the system (for example, ACW, AVAIL, ACD).

---

<sup>\*</sup>*Solaris* is a registered trademark of Sun Microsystems, Inc.

---

<b>Automatic Call Distribution (ACD)</b>	<p>A switch feature. ACD is software that channels high-volume incoming call traffic to agent groups (splits or skills).</p> <p>Also an agent state where the extension is engaged in an ACD call (with the agent either talking to the caller or the call waiting on hold).</p>
<b>Backup</b>	<p>The process of protecting data by writing the contents of the disk to a tape that can be removed from the computer and stored safely. A spare copy of data or software that you keep in case the original is damaged or lost. CMS provides three different types of backups: CMSADM File System Backup, CMS Full Maintenance Backup, and CMS Incremental Maintenance Backup.</p>
<b>Boot</b>	<p>To load the system software into memory and start it running.</p>
<b>Bus</b>	<p>A signal route to which several items of a computer system may be connected in parallel so that signals can be passed between them.</p> <p>In general, a multiconductor electrical path used to transfer information over a common connection from any of several sources to any of several destinations.</p>
<b>Cables</b>	<p>Wires or bundles of wires configured with adapters or connectors at each end and used to connect two or more hardware devices.</p>
<b>CLI Call Level Interface</b>	<p>A database programming interface from the Structured Query Language (SQL) Access Group, an SQL membership organization. Under CLI, SQL statements are passed directly to the server without being recompiled.</p>
<b>Call Management System Query Language (CMS-QL)</b>	<p>A relational database management (operating) system used to organize most of CMS's data. Automatically comes with CMS and runs in the background.</p>
<b>Call Vectoring</b>	<p>A highly flexible method for processing ACD calls using Vector Directory Numbers (VDNs) and vectors as processing points between trunk groups and splits or skills. Call vectoring permits treatment of calls that is independent of splits or skills.</p>
<b>Cartridge Tape</b>	<p>A 0.25-inch (6.35-mm) magnetic tape used in the tape drive of the Desktop Backup Pack and External Storage Module to read and write data.</p>
<b>CentreVu® CMS</b>	<p><i>CentreVu</i> Call Management System (CMS). A software product used by business customers that have a Lucent Technologies telecommunications switch and receive a large volume of telephone calls that are processed through the Automatic Call Distribution (ACD) feature of the switch.</p>

---

<b>CMS</b>	Call Management System. See <i>CentreVu</i> ® CMS.
<b>CMSADM</b>	Call Management System Administration. The part of the CMS software that allows a user to administer features of CMS. See also “CMSSVC.”
<b>CMSADM file system backup</b>	A backup that saves all the file systems on the machine which includes <i>Solaris 7</i> system and programs, CMS programs and data, and non-CMS data you place on the computer in addition to the CMS data. See the “Backup” definition for more details.
<b>CMSSVC</b>	Call Management System Services. The part of the CMS software product that allows a user to manage CMS system services. See also “CMSADM.”
<b>Command</b>	A command is an instruction used to tell the computer to perform a function or to carry out an activity.
<b>Common Desktop Environment</b>	A desktop user interface for <i>Solaris</i> . This replaces OpenWindows.
<b>Configuration</b>	Configuration is the way that the computer is set up to allow for particular uses or situations.
<b>Copy</b>	Copy means to duplicate information.
<b>Custom Reports</b>	Real-time or historical reports that have been customized from standard reports or created from original design.
<b>Daemon</b>	Pronounced “demon.” A <i>UNIX</i> * program that executes in the background ready to perform an operation when required. Usually unattended processes initiated at start-up, such as print spoolers, e-mail handlers or schedulers.
<b>Data Collection Off</b>	CMS is not collecting ACD data. If you turn off data collection, CMS will not collect data on current call activity.
<b>Database</b>	A group of files that store ACD data according to a specific time frame: current and previous intrahour real-time data and intrahour, daily, weekly, and monthly historical data.

---

\**UNIX* is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

---

<b>Database Item</b>	A name for a specific type of data stored in one of the CMS databases. A database item may store ACD identifiers (split numbers or names, login IDs, VDNs, and so on) or statistical data on ACD performance (number of ACD calls, wait time for calls in queue, current states of individual agents, and so on).
<b>Database Tables</b>	Tables that CMS uses to collect, store, and retrieve ACD data. Standard CMS items (database items) are names of columns in the CMS database tables.
<b>Device</b>	The term used to refer to the peripheral itself; for example, a hard disk or a tape drive. A peripheral is sometimes referred to as a subdevice or an Logical Unit (LU).
<b>Disk</b>	A round platter, or set of platters, coated with magnetic medium and organized into concentric tracks for storing data.
<b>DSIMM</b>	Dynamic random access memory Single In-line Memory Module. A small printed circuit card that contains Dynamic Random Access Memory (DRAM)
<b>EAD</b>	See Expert Agent Distribution (EAD)
<b>EAS</b>	See Expert Agent Selection (EAS)
<b>ECC</b>	See Error Correction Codes (ECC)
<b>EIA</b>	Electronic Industries Association. An organization that sets standards for consumer products and electronic components.
<b>Error Correction Code (ECC)</b>	A code that protects the customer's system and data from single bit soft errors that can occur frequently depending on the environment.
<b>Error Message</b>	An error message is a response from a program indicating that a problem has arisen or something unexpected has happened, requiring your attention.
<b>Ethernet</b>	A type of network hardware that allows communication between systems connected directly together by transceiver taps, transceiver cables, and a coaxial cable. Also implemented using twisted-pair telecommunications wire and cable.
<b>Ethernet Address</b>	A unique number assigned to each system when it is manufactured. The Ethernet address of your system is displayed on the banner screen that appears when you power on your system.

<b>Exception</b>	A type of activity on the ACD which falls outside of the limits the customer has defined. An exceptional condition is defined in the CMS Exceptions subsystem, and usually indicates abnormal or unacceptable performance on the ACD (by agents, splits or skills, VDNs, vectors, trunks, or trunk groups).
<b>Expert Agent Distribution (EAD)</b>	A call queued for a skill will go to the most idle agent (primary skill agent). Agents who are idle and have secondary agent skills will receive the call queued for a skill if there are no primary agents available.
<b>Expert Agent Selection (EAS)</b>	An optional feature that bases call distribution on agent skill (such as language capability). EAS matches the skills required to handle a call to an agent who has at least one of the skills required.
<b>Forecast Reports</b>	These reports display expected call traffic and agent or trunk group requirements for the customer's call center for a particular day or period in the future.
<b>Gigabyte (GB)</b>	One gigabyte equals $2^{30}$ bytes (1073741824 bytes).
<b>Hand-Shaking Logic</b>	A format used to initiate a data connection between two data module devices.
<b>Hard Disk</b>	A device that stores operating systems, programs, and data files.
<b>High Speed Serial Interface (HSI)</b>	The HSI controller card is a 4-port serial communications card. Each of the four ports is used for a single physical X.25 link. It is an add-on package that is needed by CMS for multiple ACDs.
<b>Historical Database</b>	Contains intrahour records for up to 62 days in the past, daily records for up to 5 years in the past, and weekly or monthly records for up to 10 years for each CMS-measured agent, split or skill, trunk, trunk group, vector, and VDN.
<b>Historical Reports</b>	Reports that display past ACD data for various agent, split or skill, trunk, trunk group, vector, or VDN activities.
<b>Host Computer</b>	A computer that is attached to a network and provides services other than simply acting as a store-and-forward processor or communication switch. The <i>Sun</i> <sup>*</sup> <i>SPARCserver</i> <sup>†</sup> or <i>Sun Enterprise</i> <sup>‡</sup> 3000 computer is your host computer and hosts the CMS application software.

---

\**Sun* is a registered trademark of Sun Microsystems, Inc.

†*SPARCserver* is a trademark of SPARC International, Inc.

‡*Enterprise* is a trademark of Sun Microsystems, Inc.

---

<b>Host Name</b>	A name that you (or your system administrator) assign to your system unit to uniquely identify it to the <i>Solaris 7</i> operating system (and also to the network).
<b>Hung System</b>	A system that does not respond to input from the keyboard or mouse.
<b>ITU</b>	See International Telecommunications Union (ITU)
<b>INFORMIX*</b>	A relational database management system used to organize CMS data. An add-on software package needed by CMS.
<b>Install</b>	The procedures used to set up the hardware and software of a computer, terminal, printer, and modem so that they can be used. Installing often includes customizing the system for a particular situation or user.
<b>Interface</b>	A common boundary between two systems or pieces of equipment.
<b>International Telecommunications Union (ITU)</b>	Formerly the Consultative Committee for International Telephony and Telegraphy (CCITT). An international organization that sets communications standards.
<b>Internet Protocol (IP)</b>	An integral part of the internet communication protocol system (see Transmission Control Protocol/Internet Protocol [TCP/IP]). The IP provides the routing mechanism of the TCP/IP. See also Network Address.
<b>LAPB</b>	See Link Access Procedure Balanced (LAPB)
<b>Link Access Procedure Balanced (LAPB)</b>	The ITU standard error correction protocol used on most current X.25 packet switching networks.
<b>Link</b>	A transmitter-receiver channel or system that connects two locations.
<b>Log In</b>	The process of gaining access to a system by entering a user name and, optionally, a password.
<b>Log Out</b>	The process of exiting from a system.
<b>Logical Unit</b>	The term used to refer to a peripheral device such as a disk drive.
<b>Measured</b>	A term that means an ACD element (agent, split or skill, trunk, trunk group, vector, VDN) has been identified to CMS for collection of data.

---

\**INFORMIX* is a registered trademark of Informix Software, Inc.

---

<b>Megabyte (MB)</b>	One megabyte equals $2^{20}$ bytes (1048576 bytes).
<b>Menu</b>	A list of items from which the user can select one. A menu cannot be moved or sized and does not count in the user window count.
<b>Multi-user Mode</b>	A mode of CMS in which any administered CMS user can log into CMS. Data continues to be collected if data collection is “on.”
<b>Network Address</b>	A unique number assigned to each system on a network, consisting of the network number and the system number. Also known as Internet Address or Internet Protocol (IP) address.
<b>Network Hub</b>	Hardware that connects a computer to a Network Terminal Server (NTS).
<b>Network Terminal Server (NTS)</b>	A hardware terminal that connects to the Network Hub via cabling. The NTS provides 50-pin switch champ connectors used to attach 64 serial devices using the patch panel cables and patch panels.
<b>Network Terminal Server Patch Panel</b>	Hardware that has ports for connecting serial peripheral devices (for example, printers, terminals and modems). The NTS patch panel connects to the NTS via PBX-Champ cabling.
<b>Non-Volatile Random Access Memory (NVRAM)</b>	A random access memory (RAM) system that holds its contents when external power is lost.
<b>NTS</b>	See Network Terminal Server (NTS)
<b>NVRAM</b>	See Non-Volatile Random Access Memory (NVRAM)
<b>Open Window</b>	A window that remains open because the user has not yet closed it with the “Exit” Screen Label Key (SLK). An open window becomes the current window when it initially appears on the screen or when the user makes it the current window using the “Current” SLK.
<b>Operating System (OS)</b>	The software that controls and allocates the resources, such as memory, disk storage, and the screen display for the computer.
<b>Partitions</b>	Sections of the hard disk that are used to store an operating system and data files or programs. By dividing the disk into partitions, you can use the space allocated in a more efficient and organized manner.

---

<b>Password</b>	A character string that is associated with a user name. Provides security for a user account. Desktop computers require you to type a password when you log into the system, so that no unauthorized person can use your system.
<b>Port (I/O Port)</b>	A designation of the location of a circuit that provides an interface between the system and lines and/or trunks.
<b>Primary Skill</b>	An agent will handle calls to many skills before calls to secondary skills. See “Agent Skill” in this Glossary.
<b>Primary Window</b>	The first window opened in response to a menu selection. A primary window may also generate another user window (secondary window). A primary window can be moved, sized, or scrolled, and counts in the window count.
<b>Printer</b>	A physical device that takes electronic signals, interprets them, and prints them on paper.
<b>Processor Interface (PI)</b>	A hardware device on the Generic 3i switches that prepares and sends architecture messages to other switches or application adjuncts.
<b>QIC</b>	Quarter-Inch Cartridge
<b>Recommended Standard (RS)</b>	Any one of several Electronic Industries Association (EIA) standards commonly used in U.S. electronic applications.
<b>Refresh Rate</b>	The number of seconds CMS should wait for each update of the real-time report data. A user’s fastest allowable refresh rate is defined in the User Permissions — User Data window as a minimum refresh rate. The default refresh rate when a user brings up the report input window is the administered minimum refresh rate plus 15 seconds.
<b>RISC</b>	Reduced Instruction Set Computer. A computer architecture that reduces chip complexity by using a simpler instruction set. RISC keeps instruction size constant, bans the indirect addressing mode, and retains only those instructions that can be overlapped and made to execute in one machine cycle or less.
<b>RS</b>	See Recommended Standard (RS)
<b>RS-422</b>	A balanced electrical interface (for example, RS-422 has a positive and a negative voltage). This interface is used by the HSI card.

---

<b>RS-449</b>	A 37-pin physical interface used by the HSI card.
<b>SBus</b>	The Input/Output bus for the <i>Sun SPARCserver</i> and <i>Enterprise</i> computers. Provides slots for additional cards (for example, HSI Controller Card).
<b>SBus Expansion Subsystem</b>	A peripheral device attached to a computer system. The SBus expansion subsystem provides three additional SBus slots and space for two optional SCSI hard disk drives. The SBus expansion subsystem consists of the following: the SBus expansion chassis, the expansion adapter card (in the computer system), and the SBus expansion subsystem cable.
<b>Screen Labeled Key (SLK)</b>	The first eight function keys at the top of the keyboard that correspond to the screen labels at the bottom of the terminal screen. The screen labels indicate the function each key performs.
<b>SCSI</b>	See Small Computer System Interface
<b>SCSI Bus</b>	An industry standard peripheral bus that is used to connect intelligent peripherals to a computer. It uses a daisy-chained cabling arrangement that originates at the Host Adapter to interconnect up to seven intelligent peripheral controllers on the bus. The <i>Sun SPARCserver</i> computer uses a fast SCSI-2 implementation.
<b>SCSI ID</b>	Each tap on the SCSI bus is required to have a unique identification or address, which is the SCSI ID. The ID is set by a switch located on each controller. In a Lucent Technologies' implementation, the Host Adapter card (with a SCSI ID of 7) is preset. The remainder can be set with external devices "push buttons." Users never have to open a chassis or touch a circuit-board switch.
<b>SCSI Single-Ended Bus</b>	A version of the SCSI bus designed to minimize cost and space. Cable lengths up to 6 meters are supported. It is not compatible with the differential version of the SCSI bus.
<b>Secondary Skill</b>	An agent will handle secondary skill calls after primary skill calls. See "Agent Skill" in this Glossary.
<b>Secondary Window</b>	A user window that is generated from a primary window. Secondary windows can be moved, sized, or scrolled and do not count in the user window count.
<b>Serial Asynchronous Interface/PCI</b>	A card that provides access to eight serial ports by connecting to an eight-port patch panel.

---

<b>Single-User Mode</b>	A CMS mode in which only one person can log into CMS. Data collection continues if data collection is “on.” This mode is required to change some CMS administration.
<b>Skill</b>	In relationship to the call center, think of skill as a specific customer need or requirement, or perhaps a business need of the call center.
<b>SQL</b>	See Structured Query Language (SQL)
<b>Slot</b>	An electronic connection designed to receive a module or a printed circuit board (such as a Single In-line Memory Module [SIMM] or a frame buffer board).
<b>Small Computer System Interface (SCSI)</b>	A hardware interface that allows the connection of peripheral devices (such as hard disks, tape drives and CD-ROM drives) to a computer system.
<b>Split</b>	A group of extensions that receive special-purpose calls in an efficient, cost-effective manner. Normally, calls to a split arrive over one or a few trunk groups.
<b>Storage Device</b>	A hardware device that can receive data and retain it for subsequent retrieval. Such devices cover a wide range of capacities and speeds of access.
<b>Structured Query Language (SQL)</b>	A language used to interrogate and process data in a relational database. SQL commands can be used to interactively work with a database or can be embedded within a programming language to interface to a database.
<b>Submenu</b>	A menu that appears as a result of a menu selection. All menu selections followed by a “>” have submenus.
<b>Subsystem</b>	Each CMS main menu selection (for example, Reports, Dictionary, System Setup, Exceptions, and so on), along with Timetable and Shortcut, is referred to as a subsystem of the Call Management System throughout this document.
<b>Sun Enterprise System</b>	A series of host computer systems manufactured by Sun Microsystems Inc. The <i>Sun Enterprise</i> 3000 or 3500 computer is a platform used to support CentreVu® CMS R3V6 and later versions as a replacement for the discontinued <i>Sun SPARCserver 10/20</i> platforms.

---

<b>Sun SPARCserver Computer</b>	A host computer that is attached to a network and provides services other than simply acting as a store-and-forward processor or communication switch. For CMS R3V6, the <i>Sun SPARCserver 5</i> is available for new installations. See <i>Sun Enterprise</i> systems above for replacement information.
<b>Super-user</b>	A user with full access privileges on a system, unlike a regular user whose access to files and accounts is limited.
<b>Switch</b>	A private switch system providing voice-only or voice and data communications services (including access to public and private networks) for a group of terminals within a customer's premises.
<b>Syntax</b>	The format of a command line.
<b>System</b>	A general term for a computer and its software and data.
<b>Tap</b>	A tap is any intelligent (microprocessor-based) controller connected to the SCSI bus.
<b>Tape Cartridge</b>	A magnetic piece of hardware that is used as a storage unit for data. The SCSI QIC-150, SCSI QIC 2.5-GB, SCSI 4-8 SLR, 8mm 5-GB, 8mm 14-GB, and 8mm 20/40-GB tape cartridges are used to back up and copy data for the platform.
<b>TCP/IP</b>	See Transmission Control Protocol/Internet Protocol (TCP/IP)
<b>TSC</b>	Technical Service Center. The Lucent organization that provides technical support for Lucent products.
<b>Transmission Control Protocol/Internet Protocol (TCP/IP)</b>	A communications protocol that provides interworking between dissimilar systems. It is the de facto standard for <i>UNIX</i> systems.
<b>Trunk</b>	A telephone line that carries calls between two switches, between a Central Office (CO) and a switch, or between a CO and a phone.
<b>Trunk Group</b>	A group of trunks that are assigned the same dialing digits — either a phone number or a Direct Inward Dialing (DID) prefix.
<b>UNIX System</b>	The operating system on the computer on which CMS runs. A user can access the <i>UNIX</i> system from the "Commands" SLK. <i>SUN</i> uses <i>Solaris</i> as its <i>UNIX</i> operating system.

---

<b>User ID</b>	The login ID for a CMS user.
<b>User Name</b>	A combination of letters, and possibly numbers, that identifies a user to the system.
<b>User Window</b>	A window the user can move, size, or scroll. It may contain input fields, reports, or help information.
<b>VDN</b>	See Vector Directory Number (VDN)
<b>Vector</b>	A list of steps that process calls in a user-defined manner. The steps in a vector can send calls to splits, play announcements and/or music, disconnect calls, give calls a busy signal, or route calls to other destinations. Calls enter vector processing by way of VDNs, which may have received calls from assigned trunk groups, from other vectors, or from extensions connected to the switch.
<b>Vector Directory Number (VDN)</b>	An extension number that is used in ACD software to permit calls to connect to a vector for processing. A VDN is not assigned an equipment location; it is assigned to a vector. A VDN can connect calls to a vector when the calls arrive over an assigned automatic-in trunk group or when calls arrive over a dial-repeating (DID) trunk group, and the final digits match the VDN. The VDN by itself may be dialed to access the vector from any extension connected to the switch.
<b>Write Permission</b>	A mode of CMS that allows the CMS user to add, modify, or delete data and execute processes. Write permission is granted from the User Permissions subsystem.
<b>X.25</b>	An ITU communications protocol standard for packet switching networks that typically operates at 56 Kbps or less. An add-on software package that allows CMS to communicate with the switch using X.25 protocol.

# Index

## A

Acceptance	
Procedures . . . . .	3-15
Worksheet . . . . .	3-16
ACD Link . . . . .	3-9
Administer	
NTS . . . . .	2-171
Remote Console Port . . . . .	2-167
Switch LAN . . . . .	2-127
TCP/IP . . . . .	2-127
Administration Log . . . . .	2-123
Assigning Customer Passwords . . . . .	3-14
Audience . . . . .	P-1, 1-3
Aurora Ports Card Drivers . . . . .	2-47
Authorizations	
EAS . . . . .	2-118
External Call History . . . . .	2-118
Feature Packages . . . . .	2-118
Forecasting . . . . .	2-118
Graphics . . . . .	2-118
Set . . . . .	2-118

## B

Backup	
CMS Maintenance Backup . . . . .	4-10
CMSADM File System Backup . . . . .	2-181, 4-3
Bay Networks Annex NTS Drivers . . . . .	2-51

## C

Checking Installed <i>Solaris</i> Patches . . . . .	5-12
CMS	
Checking Installed <i>Solaris</i> Patches . . . . .	5-12
Install Software . . . . .	2-105
Maintenance Backup . . . . .	4-10
Patches . . . . .	2-108
Setup . . . . .	2-134
Interactively from a Terminal . . . . .	2-135
Using <i>UNIX</i> System Flat File . . . . .	2-148
Software Installation . . . . .	2-105
Software Testing . . . . .	3-10
Supplemental Services . . . . .	2-103
Test Procedures . . . . .	3-9, 3-10
Testing . . . . .	3-10
Conventions . . . . .	P-2
Customer Support . . . . .	1-5
Customer Turnover . . . . .	3-1
Acceptance Procedures . . . . .	3-15
Acceptance Worksheet . . . . .	3-16
Assigning Customer Passwords . . . . .	3-14
System Country and Time Zones . . . . .	3-4
Testing ACD Link . . . . .	3-9
Testing CMS Software . . . . .	3-10

Customer Turnover, (continued)	
Testing Connection to TSC . . . . .	3-5
Verifying System Date and Time . . . . .	3-2

## D

Data Storage Parameters . . . . .	2-124
Date and Time	
Change . . . . .	2-12
Check . . . . .	3-2
Default Router . . . . .	2-134
Devices not Recognized . . . . .	5-13
Disk	
I/O Problems . . . . .	5-3
Partitioning . . . . .	2-18
Recognition Errors . . . . .	2-95
Documents . . . . .	P-2

## E

EAS . . . . .	2-118
Editing /etc/defaultrouter File . . . . .	2-134
Editing /etc/hosts File . . . . .	2-132
EEPROM Parameters . . . . .	2-33
Error Messages . . . . .	5-7
External Call History	
Authorize . . . . .	2-118
Install . . . . .	2-161

## F

Feature Authorizations . . . . .	2-118
Feature Packages . . . . .	2-161
External Call History . . . . .	2-161
Forecasting . . . . .	2-157
Graphics . . . . .	2-118
Set Authorizations . . . . .	2-118
Finding Misplaced X.25 Password . . . . .	5-12
Flat File	
CMS Setup . . . . .	2-148
Example of . . . . .	2-150, 2-151
Forecasting	
Authorize . . . . .	2-118
Install . . . . .	2-157

## G

Glossary . . . . .	GL-1
Graphics . . . . .	2-118

## H

Helplines . . . . .	1-5
Hosts File . . . . .	2-132
HSI/P . . . . .	2-42
HSI/S . . . . .	2-40

I	P
<i>INFORMIX</i>	Partitioning
ILS 2.11 . . . . . 2-76	Hard Disks . . . . . 2-18
Install . . . . . 2-67	Values . . . . . 2-22
Install ILS 2.11 . . . . . 2-76	Passwords . . . . . 2-31, 3-14
Install Runtime ESQ 9.14 . . . . . 2-73	Patches
Install SE 7.22 . . . . . 2-71	CMS . . . . . 2-108
Install SQL 7.20 . . . . . 2-68	Solaris . . . . . 2-86
Runtime ESQ 9.14 . . . . . 2-73	Pkgchk
SE 7.22 . . . . . 2-71	Command . . . . . 5-10
Setting Up the Environment . . . . . 2-68	Errors . . . . . 5-10
SQL 7.20 . . . . . 2-68	Publications Center . . . . . P-2
Install	
External Call History . . . . . 2-161	
Feature Packages . . . . . 2-157, 2-161	
Forecasting . . . . . 2-157	
HSI/P Software . . . . . 2-42	
HSI/S Software . . . . . 2-40	
<i>INFORMIX</i> ILS 2.11 . . . . . 2-76	
<i>INFORMIX</i> Runtime ESQ 9.14 . . . . . 2-73	
<i>INFORMIX</i> SE 7.22 . . . . . 2-71	
<i>INFORMIX</i> SQL 7.20 . . . . . 2-68	
NTS Drivers . . . . . 2-51	
ODBC . . . . . 2-111	
SAI/P Software . . . . . 2-45	
Installation-Related Problems . . . . . 5-1	
Checking Installed <i>Solaris</i> Patches . . . . . 5-12	
Solve X.25 License Install Problems . . . . . 5-11	
Using Pkgchk Command . . . . . 5-10	
International Support . . . . . 1-5	
IP Addresses for NTS . . . . . 2-172	
	<b>R</b>
	Reasons for Reissue . . . . . P-1
	Recognition Errors on Disk . . . . . 2-95
	Redirect Remote Console Port . . . . . 2-167, 3-5
	Related Documents . . . . . P-2
	Remote Access Port
	Redirecting To Local . . . . . 3-8
	Remote Console
	Administer the Port . . . . . 2-167
	Redirecting the Port . . . . . 2-167, 3-5
	Setting Up the Software . . . . . 2-167
	Test . . . . . 2-168
	Responsibilities . . . . . 1-3
	Roles . . . . . 1-3
	Root Password . . . . . 2-31
	<b>S</b>
	SAI/P . . . . . 2-45
	Set
	Authorizations . . . . . 2-118
	Date and Time . . . . . 2-12
	Set Up
	CMS . . . . . 2-134
	Interactively from a Terminal . . . . . 2-135
	Using a <i>UNIX</i> System Flat File . . . . . 2-148
	Data Storage Parameters . . . . . 2-124
	NTS . . . . . 2-171
	Remote Console . . . . . 2-167
	Switch LAN . . . . . 2-127
	TCP/IP . . . . . 2-127
	Setting Up Network Interface . . . . . 2-132
	Setup Methods
	Interactively from a Terminal . . . . . 2-135
	Using a <i>UNIX</i> System Flat File . . . . . 2-148
	Setup Scripts
	<i>Solstice DiskSuite</i> . . . . . 2-88
	Software
	Required . . . . . 1-1
	Software Installation
	Aurora Ports Card Drivers . . . . . 2-47
	Bay Networks Annex NTS Drivers . . . . . 2-51
<b>L</b>	
LAN	
Overview . . . . . 2-127	
Private Network . . . . . 2-128	
Public Network . . . . . 2-129	
Remote Switch Network . . . . . 2-130	
Link . . . . . 3-9	
Local Console . . . . . 3-8	
<b>M</b>	
Maintenance . . . . . 4-1	
CMS Maintenance Backup . . . . . 4-10	
Metadevice Problems . . . . . 5-4	
Missing Devices . . . . . 5-13	
<b>N</b>	
Network Interface . . . . . 2-132	
NTS	
Administer . . . . . 2-171	
Install Drivers . . . . . 2-51	

Software Installation, (continued)	
CMS	2-105
CMS Patches	2-108
CMS Supplemental Services	2-103
Factory Procedures	2-1
Feature Packages	2-157
HSI/P	2-42
<i>INFORMIX</i>	2-67
<i>INFORMIX</i> Environment	2-68
<i>INFORMIX</i> ILS 2.11	2-76
<i>INFORMIX</i> Runtime ESQ 9.14	2-73
<i>INFORMIX</i> SE 7.22	2-71
<i>INFORMIX</i> SQL 7.20	2-68
ODBC	2-111
SAI/P	2-45
Setting Up Remote Console	2-167
<i>Solaris</i>	2-4
<i>Solaris</i> Patches	2-86
<i>Solstice DiskSuite</i>	2-84
<i>Solstice DiskSuite</i> Setup Scripts	2-88
<i>Solstice</i> for Server Connect X.25 Driver	2-57
Summary	2-1
Sun Online Validation Test Suite (VTS)	2-38
SunLink HSI/S	2-40
X.25 License	2-63
<i>Solaris</i>	
Assigning Root Password	2-31
Booting From CD-ROM	2-5
Checking Installed Patches	5-12
EEPROM Parameters	2-33
Enabling Korn Shell and the Backspace Key	2-33
Identifying the System	2-7
Installing	2-4
Installing Selected Options	2-29
Partitioning Hard Disks	2-18
Patches	2-86
Setting Date and Time	2-12
System Activity Recorder	2-36
<i>Solstice DiskSuite</i>	
Install	2-84
Setup Scripts	2-88
Troubleshooting	5-2
<i>Solstice</i> for Server Connect X.25 Driver	2-57
State Database Problems	5-3
storage.def file	2-124
Sun Online Validation Test Suite (VTS)	2-38
SunLink HSI/S	2-40
Support	1-5
Switch	
Link	2-127, 3-9
TCP/IP	2-127
System	
Acceptance Worksheet	3-16
Country and Time Zones	3-4
Date and Time	3-2

## T

TCP/IP	2-127
Technical Support	1-5
Technician Support	1-5
Test Procedures	3-9, 3-10
Testing Connection to TSC	3-5
Time and Date	
Change	2-12
Check	3-2
Time Zones	3-4
Troubleshooting	5-1
/cms File System	5-5
Checking Installed <i>Solaris</i> Patches	5-12
CMS Administration Scripts	5-3
Disk I/O Problems	5-3
Finding Misplaced X.25 Password	5-12
Metadevice Problems	5-4
No Power on Peripherals	5-13
Pkgchk Errors	5-10
Problems with CMS Administration Scripts	5-3
Recognizing New Hardware	5-13
<i>Solstice DiskSuite</i>	5-2
State Database Problems	5-3
X.25 License Installation Problems	5-11
Turnover to Customer	3-1

## V

vector.def file	2-124
VTS	2-38

## X

X.25	
Driver	2-57
License Installation Problems	5-11
License Password	2-57, 5-12
Solve License Install Problems	5-11



# How Are We Doing?

Document Title: **CentreVu Call Management System R3V8**

Software Installation and Setup

Document No.: 585-210-941

Issue 1

Date: December 1999

Lucent Technologies welcomes your feedback on this document. Your comments are of great value in helping us to improve our documentation.

1. Please rate the effectiveness of this document in the following areas:

	Excellent	Good	Fair	Poor	Not Applicable
Ease of Use					////////////////////
Clarity					////////////////////
Completeness					////////////////////
Accuracy					////////////////////
Organization					////////////////////
Appearance					////////////////////
Examples					////////////////////
Illustration					
Overall Satisfaction					////////////////////

2. Please check the ways you feel we could improve this document:

- |  |   |
|--|---|
| <input type="checkbox"/> Improve the overview/introduction | <input type="checkbox"/> Make it more concise/brief                 |
| <input type="checkbox"/> Improve the table of contents     | <input type="checkbox"/> Add more step-by-step procedures/tutorials |
| <input type="checkbox"/> Improve the organization          | <input type="checkbox"/> Add more troubleshooting information       |
| <input type="checkbox"/> Include more figures              | <input type="checkbox"/> Make it less technical                     |
| <input type="checkbox"/> Add more examples                 | <input type="checkbox"/> Add more/better quick reference aids       |
| <input type="checkbox"/> Add more detail                   | <input type="checkbox"/> Improve the index                          |

Please provide details for the suggested improvement. \_\_\_\_\_  
 \_\_\_\_\_

3. What did you like most about this document?

\_\_\_\_\_  
 \_\_\_\_\_

4. Feel free to write any comments below or on an attached sheet.

\_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

If we may contact you concerning your comments, please complete the following:

Name: \_\_\_\_\_ Telephone Number: (\_\_\_\_) \_\_\_\_\_

Company/Organization: \_\_\_\_\_ Date: \_\_\_\_\_

When you have completed this form, please fold, tape, and return to address on back or you can fax the form to: 303-538-2195.

