





Betacam SX™ Camcorder

DNW-7/9WS/90/90WS



The Digital Camcorders for superior System Performance

Sony Betacam® and Betacam SP® camcorders set the international standard for workhorse field acquisition equipment: excellent picture quality, reliable performance and compact design allowing a generation of ENG and EFP crews to more creatively shoot on location.

Today, digital technology is bringing revolutionary changes and advantages to the broadcast industry. Computerized non-linear editing and digital signal compression have radically increased studio editing power—and transmission speed, networking interface and hard disk storage capacity are becoming critical new innovations in newsroom, post production and broadcast operations. New all-digital acquisition tools are needed to realize the full potential of the digital revolution. Sony has the solution: Betacam SX^{TM} digital camcorders.

The digital recording format used in Betacam SX camcorders is based on MPEG2 4:2:2 Profile at Main Level that maintains digital component broadcast-quality pictures from camera through post production and On-air playback.

The Betacam SX camcorder range offers an unprecedented combination of advantages for ENG and EFP applications. In size and weight, it is exceptionally compact—incorporating a built-in Color Playback capability, optional Slot-in Wireless Microphone Receiver and Internal Light System to improve mobility and lighten the load of crews working in the field.

Sony Betacam SX camcorders are designed to add important digital acquisition benefits to the news acquisition process, where saving time is critically important. In performance, reliability and



The Betacam SX format represents the next generation of Betacam technology, drawing on Sony's long experience of serving the ever-changing, real-world needs of the broadcast community. It combines the proven performance of 1/2-inch analog Betacam SP format with the digital technology leadership of the D-1, D-2 and Digital Betacam® formats.

Broadcast Picture Quality

with MPEG2 4:2:2 Profile at Main Level

The Betacam SX format records 8-bit, 4:2:2 component digital signals using an advanced compression algorithm. Betacam SX recordings maintain high-quality pictures with virtually no visible artifacts, at a compression ratio of 10:1 that allows cost-effective digital non-linear editing and archival storage.


The Betacam SX format also preserves 507 active lines per frame along with vertical blanking signal information. The Betacam SX recording format yields superior picture quality, with excellent luminance detail and improved color resolution. Its 10:1 compression ratio allows either high-speed transmission or simultaneous 2-channel transmission of different video source signals within a limited band width, resulting in reduced transmission fees and facilitating the use of contribution links at a reasonable cost.

General	Tape width Tape material Recording/playing time Tape speed Track pitch Tracks per frame Longitudinal tracks Video ancillary data Extension data	
Video	Compression Compression ratio Active lines per frame Sampling frequency	MPEG2 4:2:2P@ML Approx. 10:1 507 lines (525/60), 608 lines (625/50) Y: 13.5MHz R-Y/B-Y: 6.75MHz 8 bits/sample
Audio	Compression Sampling frequency Quantization Channels	None 48kHz 16 bits/sample 4

Betacam SX in Action: the Robust Tape Format

The robust tape format of Betacam SX records 8-bit, 4:2:2 component digital video signals and supports four channels of 16-bit/48kHz digital audio. Its powerful ECC (Error Correction Code) automatically compensates for

off-tape data errors caused by burst errors during recording and playback. This ensures virtually dropoutfree acquisition of important program material.



Playback Capability of Analog Betacam and Betacam SP Formats

The Betacam SX format is designed to provide playback capability of tapes made on/for current analog systems. This capability provides a logical, cost-efficient migration path towards a totally digital environment.

Analog Playback Capability

The 1/2-inch tape size used by Betacam SX format is the same size 1/2 inch cassette as current Betacam and Betacam SP equipment, giving Betacam SX playback capability of analog Betacam and Betacam SP recordings made on oxide or metal tape. Using advanced Hybrid Recorders that combine video tape transports with hard disk drive flexibility, the Betacam SX system allows analog Betacam and Betacam SP archive material to be accessed and digitized for non-linear editing.

Wide Range of Recording Media

Current BCT-MA and UVWT Series Betacam SP metal tape cassettes can be used for Betacam SX recording, assuring wide availability of recording media. For superior digital performance at reduced cost, a new metal particle tape has also been developed for Betacam SX recording.

VTR	Betacam		Betacam SP		Betacam SX	
Tape	REC	PB	REC	PB	REC	PB
Betacam	yes	yes	yes	yes	no	yes
Betacam SP (oxide)	no	yes*	yes	yes	no	yes
(metal)	no	no	yes	yes	yes	yes
Betacam SX (metal)	no	no	no	no	yes	yes

Analog and Digital Interfaces

Betacam SX products provide both analog and digital interfaces, allowing new digital products to integrate with analog systems in the studio and in the field.

The Cost Efficiencies


of Betacam SX Products


Betacam SX equipment is designed to deliver unsurpassed digital picture and sound performance—and also to achieve—significant long-term saving in both media and hardware costs, compared to previous generations analog VTRs.

Lower Tape Running Costs

The advanced signal compression technology of the Betacam SX format has brought the important advantage of longer tape recording times: up to 60 minutes on a single S-cassette.

Powerful error correction capability means Betacam SX can handle a high bit-rate signal within narrow tracks, allowing the development of low-cost, high-quality Betacam SX tape. Compared to conventional Betacam SP tapes, tape consumption can actually be reduced by one-half. ENG acquisition and archival tape costs will be significantly reduced, while superior picture quality is maintained.





Reduced Maintenance Costs

Betacam SX equipment also incorporates an Automatic Alignment System that maximizes accurate tape recording and reproduction of digital data. An Automatic RF Equalizer optimizes the gain and phase of off-tape RF signals. These automatic systems minimize the need for time-consuming manual equalization and servo system adjustments, which can lower maintenance costs.

Betacam SX:

The Key to the Digital Newsroom

Betacam SX format is Sony's key approach to the digital newsroom.

The compression has been carefully designed to maintain high picture quality during every phase of end-to-end broadcast news operations, from camera through post production and On-air playback.

The compression algorithm of MPEG2 4:2:2 Profile at Main Level is universally employed within the full Betacam SX

product range, as well as by the digital, disk-based A/V Servers in the Sony system. This means that throughout the total newsroom system, no encoding/decoding is needed, so picture quality is not compromised.

The Right Media in the Right Application

Sony expertise in every aspect of video technology has led to careful evaluation of the running costs, recording times, mobility factors, and industry-wide compatibility of both tape and disk media.

In the Betacam SX system, tape is employed for camcorder applications where low running costs, longer recording time, physical robustness, and higher mobility are required—and disk media is used for in-house applications where high-speed random access and non-linear operations are mandated. As part of a total system approach, Sony Betacam SX camcorders bring the acquisition process into the digital age. They are designed to let you move ahead today—without compromising the full functionality and cost efficiency that are needed in tomorrow's digital world.



The Betacam SX

Camcorder Line-up

The Betacam SX line-up includes the DNW-7, 9WS, 90 and 90WS camcorders.

DNW-7: This Betacam SX camcorder is equipped with 2/3-inch 400K Power HAD™ 1000 IT CCDs. It incorporates 10-bit/28MHz full digital signal processing in the camera section and Betacam SX digital recording in the VTR section. The DNW-7 brings cost-effective, fully digital operation to day to day ENG acquisition assignments and EFP shooting applications.



DNW-9WS: This Betacam SX camcorder is switchable between 4:3 standard and 16:9 widescreen ratios. It is equipped with 2/3-inch 520K switchable 16:9/4:3 Widescreen Power HAD 1000 IT CCDs. It incorporates 10-bit/36MHz full digital signal processing in the camera section and Betacam SX digital recording in the VTR section. The DNW-9WS is the newest member of the line-up of Betacam SX camcorders. It's high technology design provides an excellent cost performance ratio.



DNW-90: This Betacam SX camcorder is equipped with 2/3-inch 520K Power HAD 1000 FIT CCDs. It incorporates 10-bit/36MHz full digital signal processing in the camera section and Betacam SX digital recording in the VTR section. Its superior low-light shooting capability and spectacular digital image quality make it the high-performance choice for both high-end ENG and EFP shooting situations.



DNW-90WS: This Betacam SX camcorder is switchable between 4:3 standard and 16:9 widescreen ratios. It is equipped with 2/3-inch 520K switchable 16:9/4:3 Widescreen Power HAD 1000 FIT CCDs. The DNW-90WS gives superior-quality digital recording in both screen aspect ratios, and makes it easy to bridge the transition from 4:3 world to the growing world of widescreen 16:9.




Compact and Lightweight Design, Approximately 6kg

Betacam SX camcorders are designed to bring both superior digital performance and high mobility to single camcorder operations in the field, even when shooting under difficult conditions. The smaller recording head drum developed by Sony has made possible a design more compact than conventional analog Betacam SP camcorders, with a shorter overall length and lower center of gravity for excellent balance.

The DNW-7/9WS/90/90WS weighs approximately 6kg. (13 lb. 3 oz.) including battery, tape and lens.

Reduced Weight and Fewer Elements in the Total Crew Package

Betacam SX camcorders are not only smaller and lighter, they also achieve further reductions in the total shooting system needed by news acquisition crews. Betacam SX camcorders provide full-color playback without an external adapter—and a recording time of up to 60 minutes on a single S-cassette, so fewer tapes are required. They can incorporate an optional Slot-in Wireless Microphone Receiver and Internal Light System, even further saving on the equipment load that must be carried in the field.



Longer Recording Time, Up to 60 Minutes on a Single Cassette

Betacam SX camcorders combine the performance of digital recording with the convenience of an efficient data-handling format that allows up to 60 minutes of recording on a single 1/2-inch S-cassette. Compared to conventional analog Betacam SP equipment, Betacam SX camcorders can reduce tape consumption by half.

<Tape Recording Time List>

Models	Betacam SP Recording Time (min)	Betacam SX Recording Time (min)
BCT-5MA	6	12
BCT-10MA	12	22
BCT-20MA	24	42
BCT-30MA	36	62
UVWT-10MA	12	22
UVWT-20MA	24	42
UVWT-30MA	36	62
BCT-12SX	-	12
BCT-22SX	-	22
BCT-32SX	-	32
BCT-60SX	-	60

Use of Current Metal Particle Tape

Conventional Betacam SP metal particle tape (BCT-MA/UVWT) can be used in Betacam SX camcorders. With Betacam SX camcorders, recording time is double the stated duration of the tape.



16:9/4:3 Switchable (DNW-9WS/90WS)

The DNW-9WS and the DNW-90WS are equipped with 2/3-inch 520K switchable 16:9/4:3 Widescreen Power HAD 1000 CCDs. They offer superior quality digital recording in both aspect ratios.

Wide Selection of Viewfinders

The DNW-7 and DNW-90 are equipped with a lightweight 1.5-inch monochrome viewfinder; the DNW-9WS and the DNW-90WS come with a wide 2-inch monochrome viewfinder, allowing easy focusing even in 16:9 widescreen mode. There is also an optional 1.35-inch color viewfinder available, the BVF-VC10W. Using this color viewfinder allows color playback through the camcorder viewfinder, as Betacam SX camcorders do not require an external



adapter. And when shooting with the BVF-VC10W, color objects are more clearly identifiable.

BVF-VC10W

Comprehensive Menu Control

Setup parameters are well organized in a two-layer menu system, categorized as User Menus and Engineer Menus. User Menus allow access to only the standard setup functions needed by operators. Engineer Menus allow access to all camcorder setup functions. Menu pages are visible in the camcorder



viewfinder and may also be displayed on a monitor screen through the video outputs. The setup control system is easily operated using a rotary switch on the camcorder.

Precision Audio Level Adjustment

The audio level of the front microphone can be easily and precisely adjusted by using the rotary switch located under the lens tele-converter of the camcorder. Positioning the rotary switch in this location helps to prevent an operator's hands from accidentally touching the lens or entering the frame.

Setup Card for Uniform Camcorder Settings

The Betacam SX camcorder family allows a large number of setup parameters to be stored on a removable Setup Card. These setup cards allow operators to set up camcorders more quickly, easily and accurately in the field. Several different camcorder settings



can be stored on Setup Cards prepared in the studio. Setup Cards also aid in matching the setup of multiple camcorders, when shooting in several remote locations or when time passes between shooting assignments on a single story or production.

Low Acoustic Noise

A sophisticated noise barrier is incorporated in the VTR section to reduce acoustic emission and to prevent transport noise pickup by the onboard microphone during shooting.

Color Filters

Betacam SX camcorders are equipped with four types of color filter: 3200K, 5600K + 1/8ND, 5600K and 5600K + 1/64ND.



Turbo Gain: High Sensitivity

The Turbo Gain function of Betacam SX camcorders quickly raises the gain level to +42 dB at the touch of a button on the side of the camcorder, allowing immediate exposure in extremely low light conditions. By combining DPR Plus (Dual Pixel Readout Plus) technology with a conventional

electronic gain-up function, a high signal-to-noise ratio is obtained with only a small loss of resolution in the Turbo Gain mode. The maximum gain level of the Turbo Gain mode is +36 dB/+42 dB selectable.

*DPR Plus: A technology that can increase sensitivity by a factor of four times normal sensitivity by reading out an electric charge of four adjacent CCD pixels.

Diagnostic Information for Easy Maintenance

The DNW-7/9WS/90/90WS models incorporate a sophisticated diagnostic system to detect malfunctions within the camcorder. Digital signal processing improves the ability to specify the precise



location and nature of a fault; camera faults are indicated by warning lights in the viewfinder, and VTR faults are indicated on the camcorder LCD display.

TruEye™ Process

In conventional RGB analog digital processing, some non-linear signal processing occurs after gamma correction, such as knee and white clip. This can result in hue errors—a phenomenon that is particularly obvious in extreme highlight conditions. This significant problem is virtually eliminated by the TruEye process which manages video signal data according to three factors: Brightness, hue and saturation, so that color reproduction, even with very wide dynamic ranges can approach the faithfulness of the human eye. With TruEye processing active, the factory preset value of the knee

point (in case of DCC OFF mode) is shifted from 98% to 85% for more faithful reproduction.



DynaLatitude™

Based on a TruEye system, the Betacam SX camcorders further offer a unique new feature called DynaLatitude Function that adaptively manages the contrast of each pixel according to a histogram of video signal level distribution.

DynaLatitude brings a new dimension to the technology of Dynamic Contrast Control (DCC), that controls the extensive range of video signals. DynaLatitude optimizes video level distribution to expand the limited contrast range of video signals. DynaLatitude is switchable in four steps: LOW, MID, HIGH and OFF—via a menu control system and a graphic display in the viewfinder.





Auto Tracing White Balance (ATW)

LA BOOK IS

DNW-7/9WS/90/90WS camcorders are all equipped with Auto Tracing White Balance (ATW) capability, which enables automatic adjustment of white balance according to the overall scene lighting conditions. When lighting conditions change quickly—for example,



moving from indoors to outdoors—white balance is rapidly readjusted with this ATW function.

Comprehensive LCD Display

The extensive LCD displays on Betacam SX camcorders provide critical information on VTR operating status. Time code, CTL and User-bit data, Tape Remaining and Battery Capacity are displayed via a bargraph meter. A digital audio peak meter allows precise adjustment of audio recording level



Stereo Audio Line Output (5-pin XLR)



The 5-pin XLR connector on Betacam SX camcorders carries two audio output channels. Either CH-1/2 or CH-3/4 can be selected through the VTR menu.

User-Friendly Controls

Betacam SX camcorders are carefully designed for simple operation. Switches are located in similar positions on both Betacam SX and Betacam SP camcorders, so operators accustomed to using Sony analog equipment will immediately find these new digital camcorders familiar and easy to use.

Fail-Safe Audio Recording

Through the VTR menu, four channels of audio can be assigned according to the user's needs. When Parallel mode is selected, the same signals are recorded by CH-1/CH-3 and CH-2/CH-4. In Separate mode, CH-3 automatically records the front microphone and CH-4 records the wireless microphone. This function ensures the microphone will not accidentally miss the audio recording; even if the external microphone is not connected. Audio from the front microphone and the output of the wireless microphone will still be captured on audio channels 3 and 4.

NEW AC Adaptor

The optional AC-DN1 AC Adapter supplies power directly



to Betacam SX camcorders to provide uninterrupted shooting capability in situations such as special events or extended conference sessions. The AC-DN1 can also be used to charge the Lithium-Ion batteries in an emergency.

6-pin Remote Interface

Remote control of the basic functions and adjustments of Betacam SX camcorders can be accomplished by connecting the RM-B150 Remote Control Unit via a 6-pin remote interface.

TC REGEN Function

A time code regenerator is included with the DNW-7/9WS/90/90WS, providing continuous time code recording in the REGEN mode so time code editing can begin immediately after shooting.

Multiple Tally Functions

In addition to tally functions on the front and back of the camcorder, these new Betacam SX models have a camera tally on the viewfinder at the side of the eyepad, so the operator can see the tally even when looking into the viewfinder from a distance.

Superimposed Camera ID on Color Bars

For easy confirmation of which camcorder was used for an individual recording, a Camera ID can be superimposed on color bars. The Camera ID is set using the system control menu.



Test Output

The DNW-7/9WS/90/90WS all incorporate a test output port, providing composite video, red, green or blue signals for camera testing.



Slot-In Wireless Microphone Receiver (Built-in UHF Synthesizer Receiver Unit)

The optional WRR-855A Wireless Microphone Receiver can be fitted directly into all four Betacam SX camcorders using


a slot-in mechanism that gives a cable less interface between the camcorder and the receiver. This system increases mobility by



maintaining compact overall dimensions even when the receiver is attached to the camcorder.

Internal Light System

An optional Anton/Bauer® Ultralight® can be directly attached to the camcorder using a standard lighting connector and a specially designed very short cable. This internal light system can be powered from the camcorder's Lithium-Ion battery, Lighting on/off can be controlled manually or automatically synchronized with the REC. Start function of the camcorder.





Lithium-Ion Battery

Lithium-Ion batteries provide higher capacity in a smaller, lighter size. Betacam SX camcorders will operate for more than two hours using a fully charged BP-L60/A Lithium-Ion Battery; using a BP-L90/A Lithium-Ion Battery, three hours of recording can be

achieved. Lithium-Ion batteries can be attached directly to the camcorder using the V-shoe attachment, which facilitates quick, easy battery changes. With an optional adapter, current NP-1B and BP-90A Ni-Cd batteries can also be used, allowing users to take advantage of existing battery and charging equipment for greater system flexibility.



Redesigned Cassette Compartment

The cassette compartment does not pop up during cassette loading and ejecting, which helps to prevent damage to the cassette compartment mechanism. Cassettes are loaded vertically through a narrower entry that helps to keep out dust particles. The window on the cassette case has been repositioned, so it is easier for the operator to see how much tape remaining for



Record/Review Function

Recordings can be quickly checked by pressing the RETURN button on the side of the lens while the camcorder is in the REC. Pause mode. The tape automatically rewinds for about two

seconds, the end of the last scene will be played back, and the tape will stop precisely at its previous position. Pressing the RETURN button and holding it longer can extend the tape rewind time up to a maximum of approximately ten seconds.



Genlock Capability/Camera Return

Genlock capability is incorporated within the DNW-7/9WS/90/90WS, allowing these camcorders to be integrated in multi-camera systems. Camera Return video can also be accessed through the same connector.

Color Playback without External Adapters as well as Viewfinder Playback on Location

Betacam SX camcorders allow full color playback together with two audio channels without an external adapter, and makes it easy to verify recording results and send recordings to the studio via microwave transmission. Recordings can also be reviewed in the camcorder viewfinder while monitoring audio via an earphone or the speaker built in to the side of the camcorder.

Variable Speed Electronic Shutter



recording.

In order to capture clear images of high-speed moving subjects without motion blur, Betacam SX models have several shutter speeds available: 1/100, 1/125, 1/250, 1/500, 1/1000 and 1/2000 of a second.

Camcorder Performance Features in a Sony Betacam SX System

Data on Tape to Enhance the Edit Search **Process**

Betacam SX camcorders allow automatic or manual recording of shooting data on tape. Data such as Date, Time, Shot ID, Cassette Number and Shot Number can all be recorded during the shooting process. Shot Data can be used to retrieve material during editing.

Good Shot Marker and REC. Start Marker

Betacam SX camcorders provide an innovative function to speed the editing process which increases the ability to identify good takes while shooting in the field. A REC. Start Marker is automatically placed on the tape each

time the VTR Start button is pressed while the VTR is in standby mode. A Good Shot Marker can be added at any time by pressing the RETURN button on the side of the lens while in recording mode.





When tapes are played back with DNW-A220/A225, these Digital Portable Editors can scan through the tape and detect all the REC. Start Markers and Good Shot Markers recorded on the tape. After detecting the markers, a list of all the markers

is displayed on the LCD screen, allowing easy cueing to any marker.

During the Play, Shuttle, Jog and Still, these portable editors can memorize additional markers called Virtual Shot Markers, entered by the operators. Using this list of markers, tedious searching process will be completely eliminated from tape-to-tape news editing.



Shot Marker List



Shot Marker Log

When tapes are copied onto DNW-A100/A50/A45 Digital Video Hybrid Recorders' built-in hard drive, these markers will appear highlighted as picture stamps on the GUI of the DNE-50/700 Digital News Editing System. Using picture stamps also helps to eliminate tedious searching from nonlinear news editing and saves hard disk space by



downloading only the scenes selected by editors. This Shot Marker Handling functions of the Betacam SX helps to speed-up the newsroom operation.

CA-701 Camcorder Adapter

4-Channel Audio Input and SDI Output Capability

The optional CA-701 Camcorder Adapter can be attached to the DNW-7/9WS/90/90WS via the camcorder's built-in 40-pin connector, enabling simultaneous 4-channel audio recording by providing access to audio channels 3 and 4. In addition, two SDI outputs are provided,

allowing direct connection to the other digital equipment via a single coaxial cable. Full component digital signals to standard ITU-

R.601 are available.

General	Power requirements: Power consumption: Operating temperature: Storage temperature: Humidity: Mass: Dimensions (W/H/D):	Approx. DC 12V +5.0V/-1.0V Approx. 7W 0°C to +40°C (+32°F to +104°F) -20°C to +60°C (-4°F to +140°F) 25% to 85% (relative humidity) Approx. 1.0kg (2 lb 3 oz) 157x195x65mm (6¹/xx7³/x25½ inches)
Connectors	AUDIO IN: AUDIO OUT: DC IN: DC OUT HEADPHONE: SDI OUT: CAMERA:	XLR-3-31 type (x2) XLR 5-pin male (stereo) XLR 4-pin male, 11 to 17V 4-pin, 11 to 17V, max. 0.1A Stereo standard phone jack BNC (x2), 0.8Vp-p, 75Ω 40-pin (DNW-7/9WS/90/90WS)
Supplied accessories	Operation manual (1) Maintenance manual (1)	



CA-702 Camcorder Adapter

External Input and Analog Component/SDI Output Capability

The optional CA-702 Camcorder Adapter can be attached to the DNW-7/9WS/90/90WS via a camcorder's built-in 40-pin connector. With this adapter fitted, the Betacam SX camcorders can record an external analog component signal and BNC output connector to feed a SDI signal to an external VTR. Through this connector, the camera signal can be recorded with a BVW-50 Betacam SP portable VTR or DVW-250 Digital Betacam portable VTR. This feature has many applications in field acquisition.

General	Power consumption: Mass: Dimensions (W/H/D):	MAX. 5.5W Approx. 0.9kg(2 lb) 165x195x65mm(6 ¹ / ₂ x7 ³ / ₄ x2 ⁵ / ₈ inches)
Connectors	DC IN: DC OUT: SDI/Composite IN: SDI OUT: EARPHONE: VTR:	XLR 4-pin 4-pin BNC (x1) BNC (x1) Mini-jack CCZ 26-pin
Supplied accessories	Operation manual (1) Maintenance manual (1)	



CA-755 Camcorder Adapter

Studio Camera Integration with Triax System

The DNW-7/9WS/90/90WS can be easily integrated into a studio setup with other portable cameras using a Triax system. The optional CA-755 Camera Adapter can be directly attached via the built-in 40-pin connector; precise camera setup parameters such as gamma, detail, iris control, electronic shutter on/off, shutter speed, etc., can then be remotely controlled from the CCU-550 Camera Control Unit or from a Remote Control Panel attached to the CCU-550.

General Power consumption: Mass: Dimensions (W/H/D): Connectors DC IN: RET OUT:	XLR 4-pin, 11.5V to 17V			
Connectors DC IN:	XLR 4-pin, 11.5V to 17V			
DET OUT:				
KET OUT.	BNC (x1), 1.0Vp-p, 75Ω			
RETURN CONTROL:	6-pin			
EARPHONE:	Mini-jack, 8Ω			
CAMERA	40-pin (DNW-7/9WS/90/90WS)			
CCU:	KINGS type			
INCOM/PGM:	Headset XLR 5-pin			
Supplied accessories Operation manual (1))			
Maintenance manua	Maintenance manual (1)			
Cable clamp (1)	Cable clamp (1)			
M3/M4 screws for ca	M3/M4 screws for cable clamp (2x2)			
Optional accessories Extention board EX-4	154			





Setup Card (Package of four Setup Cards and a soft case) **BSC-1-Pack**



Battery Case for an optional NP-1B NiCd Battery **DC-L1**



Rechargeable Lithium-ion Battery **BP-L90A**

Battery Charger for four BP-L60/A and BP-L90/A BC-L100



Battery Charger for two BP-L40 and L60/A and BP-L90/A $\,$ BC-L50





Battery Charger for four NP-1B Batteries **BC-1WD**



AC Adapter AC-DN1



AC Adapter AC-550



Slot-in Wireless Microphone Receiver WRR-855A



Interface Box VA-DN1



Remote Control Unit RM-P9



Camera Control Unit **CCU-550**



5-inch Viewfinder **BVF-55**



Return Video Selector CAC-6



Tripod Adapter VCT-14



Viewfinder Rotation Bracket **BKW-401**



Viewfinder Eye-piece
High magnification : A-8262-537-A
Low magnification : A-8262-538-A
Standard magnification with special compensation for operations : A-8267-737-A



Viewfinder Eye-piece (High performance (x3): A-8314-798-A



1.35-inch 16:9 Color Viewfinder **BVF-VC10W**



1.5-inch 4:3 B/W Viewfinder BVF-V10 (supplied with DNW-7/90)



Video Head Cleaning Cassette **BCT-5CLN**



2.0-inch 16:9 B/W Viewfinder **BVF-V20W** (supplied with DNW-9WS/90WS)




Betacam SX Video Cassette BCT-12SX/22SX/32SX/60SX



Carrying Case
LC-DN7



Video Head Cleaning Cassette BCT-D12CL



DNW-7/9WS/90/90WS Camcorders

Wow & flutter Head room Emphasis (DN/C * The specifica Camera Section Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum illumi	input -1/2) but output output output	29W Approx. 120 min (with BP-L60A) Approx. 165 min (with BP-L90A)	31.5W 0 °C to +40 °C (-20 °C to +60 °C 25 % to 85 % (r Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) BNC (x1), 1.5 BNC (x1), 0.5 to XLR-3-31 type (x2), -60 dBu/ +4 dBu : BNC (x1), 1.0Vp-p,	g (13 lb 3 oz) 5.0V/-1.0V 31W 32 °F to +104 °F) (-4 °F to +140 °F) elative humidity) Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) 0Vp-p. 75 Ω 018Vp-p, 10 kΩ selectable, high impedance, balanced	32W Approx. 105 min (with BP-L60A) Approx. 160 min (with BP-L90A)		
Operating weight Power requirements Power consumption Operating temperature Storage temperature Humidity Continuous operating time Signal inputs Signal outputs Signal out	input -1/2) but output output output	Approx. 120 min (with BP-L60A)	Approx. 6.0K DC 12V + 31.5W 0 °C to +40 °C (+ -20 °C to +60 °C 25 % to 85 % (r Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) BNC (x1), 1. BNC (x1), 0.5 tc XLR-3-31 type (x2), -60 dBu/ +4 dBu s BNC (x1), 1.0Vp-p,	g (13 lb 3 oz) 5.0V/-1.0V 31W 32 °F to +104 °F) (-4 °F to +140 °F) elative humidity) Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) 0Vp-p. 75 Ω 018Vp-p, 10 kΩ selectable, high impedance, balanced	Approx. 105 min (with BP-L60A)		
Power requirements Power consumption Operating temperature Storage temperature Humidity Continuous operating time Signal inputs Signal outputs Video output Video output Video output Video lest outp Time code output Time code output Time code output Time code output Time code inpi Time code inpi Time code output Time code inpi Ti	input -1/2) but output output output	Approx. 120 min (with BP-L60A)	31.5W 0 °C to +40 °C (+ -20 °C to +60 °C 25 % to 85 % (n Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) BNC (x1), 0.5 to XLR-3-31 type (x2), -60 dBu/ +4 dBu s XLR-3-31 type (x2), -60 dBu/ +4 dBu s BNC (x1), 1.0Vp-p,	31W 32 °F to +104 °F) (-4 °F to +140 °F) elative humidity) Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) 0Vp-p. 75 Ω 018Vp-p, 10 kΩ selectable, high impedance, balanced	Approx. 105 min (with BP-L60A)		
Power consumption	input -1/2) but output output output	Approx. 120 min (with BP-L60A)	31.5W 0 °C to +40 °C (-20 °C to +60 °C 25 % to 85 % (r Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) BNC (x1), 1.5 BNC (x1), 0.5 to XLR-3-31 type (x2), -60 dBu/ +4 dBu : BNC (x1), 1.0Vp-p,	31W 32 °F to +104 °F) (-4 °F to +140 °F) elative humidity) Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) 0Vp-p, 75 Ω 0 18Vp-p, 10 kΩ selectable, high impedance, balanced	Approx. 105 min (with BP-L60A)		
Operating temperature Storage temperature Humidity Continuous operating time Signal inputs Signal outputs Signal outputs Signal outputs Video output Video test outp Time code outp Earphone Audio output Dight DC input DC output DC output DC output DC output VTR section General Recording form Tape speed Playback/Recc Fast forward time Rewind time Recommender Sampling frequent Quantization Fror correction Video performance Video performance Sampling frequent Virange performance Virange performance Sampling frequent Virange performance Virange performance Virange performance Sampling frequent Virange performance Virange	input -1/2) but output output output	Approx. 120 min (with BP-L60A)	0 °C to +40 °C (+ -20 °C to +40 °C (+ -20 °C to +60 °C 25 % to 85 % (r Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) BNC (x1), 1. BNC (x1), 0.5 to XLR-3-31 type (x2), -60 dBu/ +4 dBu s BNC (x1), 1.0 Vp-p,	32 °F to +104 °F) (-4 °F to +140 °F) elative humidity) Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) 00-18Vp-p, 75 Ω 18Vp-p, 10 kΩ selectable, high impedance, balanced	Approx. 105 min (with BP-L60A)		
Storage temperature	input -1/2) but output output output		-20 °C to +60 °C 25 % to 85 % (n Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) BNC (x1), 0.5 tc XLR-3-31 type (x2), -60 dBu/ +4 dBu XLR-3-31 type (x2), -60 dBu/ +4 dBu BNC (x1), 1.0 Vp-p,	(-4 °F to +140 °F) elative humidity) Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) 0Vp-p. 75 Ω 018Vp-p, 10 kΩ selectable, high impedance, balanced			
Humidity Continuous operating time	input -1/2) but output output output		25 % to 85 % (n Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) BNC (x1), 1. BNC (x1), 0.5 to XLR-3-31 type (x2), -60 dBu/ +4 dBu s BNC (x1), 1.0 yp-p,	elative humidity) Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) 0Vp-p., 75 Ω 0 18Vp-p., 10 kΩ selectable, high impedance, balanced			
Signal inputs	input -1/2) but output output output		Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) BNC (x1), 1. BNC (x1), 0.5 tc XLR-3-31 type (x2), -60 dBu/ +4 dBu: XLR-3-31 type (x2), -60 dBu/ +4 dBu: BNC (x1), 1.0 Vp-p,	Approx. 110 min (with BP-L60A) Approx. 165 min (with BP-L90A) 0Vp-p, 75 Ω 18Vp-p, 10 kΩ selectable, high impedance, balanced			
Time code inproduction	input -1/2) but output output output		BNC (x1), 0.5 to XLR-3-31 type (x2), -60 dBu/ +4 dBu s XLR-3-31 type (x2), -60 dBu/ +4 dBu s BNC (x1), 1.0Vp-p,	0 18Vp-p, 10 kΩ selectable, high impedance, balanced			
Audio (CH-1/2) Mic Input Wideo output Video test output Earphone Audio output Emboure Audio output Emboure Audio output Emboure Video test output VTR section Recording form Tape speed Playback/Recorder Fast forward in Rewind time Recommended Sampling freque Quantization Error correction Video performance Vir. Yif. Yif. Yif. Yif. Yif. Yif. Yif. Yif	output output		XLR-3-31 type (x2), -60 dBu/ +4 dBu s XLR-3-31 type (x2), -60 dBu/ +4 dBu s BNC (x1), 1.0Vp-p,	selectable, high impedance, balanced			
Mic input	out output output output		XLR-3-31 type (x2), -60 dBu/ +4 dBu s BNC (x1), 1.0Vp-p,				
Video output	output output out		BNC (x1), 1.0Vp-p,	XLR-3-31 type (x2), -00 dBuf +4 dBu selectable, high impedance, balanced XLR-3-31 type (x2), -60 dBuf +4 dBu selectable, high impedance, balanced			
Video test outp Time code outp Earphone	output output out			XLR-3-31 type (x2), -60 dBu/ +4 dBu selectable, high impedance, balanced BNC (x1), 1.0Vp-p, 75 Ω, sync negative			
Time code out Earphone	output		BNC (x1), 1.0Vp-p, 75 Ω, sync negative BNC (x1), 1.0Vp-p, 75 Ω, sync negative BNC (x1), 1.0Vp-p, 75 Ω				
Earphone	but						
Audio output			BNC (X1), 1.0Vp-p, 73 ¥2 Mini-jack				
Camera			XLR 5-pin m				
Light				pin			
DC			6-1	oin			
TR section General Recording forn Tape speed Playback/Recc Fast forward tir Rewind time Recommender Sampling frequ Quantization Fror correction Video performance United the second of the second o			2-pin, DC 12				
VTR section General Recording forn Tape speed Playback/Reco Fast forward life Rewind time Recommended Sampling freed Quantization Error correction Video performance Vifey yellow for the factor (2T pu y/R-Y/B-Y dela Digital audo performance Sampling freed Quantization Frequency res Distortion (at II) Wow & flutter Head room Emphasis (ONC * The specificat Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum Illumi			XLR 4-pin (for the				
General Recording form Tape speed Playback/Reco Fast forward tilm Rewind time Recommender Sampling frequent Quantization From Correction Fast Commender Sampling frequent Plays Year Year Year Year Year Year Year Year			4-pin (for wireless micro	phone receiver), DC12V			
Tape speed Playback/Recc Fast forward tir Rewind time Recommender Sampling frequ Quantization Fror correction Video performance Digital audo performance Sampling frequ Quantization Frequency res Dynamic range i Distortion (at 1 i emphasis ON, ret Cross talk (at 1 kt Wow & flutter Head room Emphasis (ON/C * The specifica Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum illumi	6			- CV			
Playback/Recc Fast forward in Rewind time Recommender Sampling frequency responses of the Variable Author of Tenguency responses of the Variable Author of Tengu			Betaca				
Fast forward til Rewind time Recommender Sampling frequent Quantization From Correction From Correction From Correction From Correction Frequency responsible from Frequency responsible frequency f			59.575 mm/s				
Rewind time Recommender Sampling frequ Quantization Error correction Video performance Undeo performance Sampling frequ Quantization Frequency res Dynamic range to Distortion (at 11 emphasis ON, rel Cross talk (at 1 kt Wow & flutter Head room Emphasis (ON/C * The specificat Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum illumi		Max. 60 min. with BCT-605X cassette					
Recommender Sampling free Quantization Error correction Video performance Frequency responsibility ViR-YiP-Y dela Digital audo performance Sampling free Quantization Frequency responsibility Distortion (at 11) emphasis (ON/C *The specification Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum Illumi		Approx. 5.5 min. with BCT-605X Approx. 5 min. with BCT-605Y					
Sampling frequency Quantization Fror correction Video performance Video performance Sampling frequency Extractor (27 pt yrR-Y/B-Y dela Sampling frequency responsible solvent frequency fr		Approx. 5 min. with BCT-60SX Sony Betacam SX cassette (BCT-60SX series), Sony Betacam SP cassette (BCT-30MA series/UVWT-30MA series)					
Quantization Video performance Video policitation Video performance Video		Sony Betacam or cassette (Borrook series), sony 6.75 MHz. Y: 13.5 MHz, Y/B-Y: 6.75 MHz					
Video performance K-factor (2T pt ViR-YIB-Y dela Digital audo performance Sampling frequency responsible of the Virginian of		1. 13.3 WILE, 170-1. 0.73 WILE					
Dgital audo performance Sampling free Quantization Frequency res Dynamic range i Distortion (at 1 i emphasis ON, ret Cross talk (at 1 kk Wow & flutter Head room Emphasis (ON/C * The specifica Camera Section Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum illumi			Reed-Solo				
Digital audio performance Augustization Frequency resp Distortion (at 11 emphasis (ON/C The augustian of th	T pulse)		1 % c	r less			
Quantization Frequency res Dynamic range i Distortion (at 11 emphasis ON, ret Cross talk (at 1 kt Wow & flutter Head room Emphasis (ON/C **The specifica* Camera section Camera Pickup device Picture elemen Optical system Built-in filiters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k; Minimum illumi		15ns or less					
Frequency resign Dynamic range in Distortion (at 11 emphasis ON, retermine the Cross talk (at 11 the Mown & flutter Head room Emphasis (ON/C * The specification of the Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum Illumi		48 kHz (synchronized with video)					
Dynamic range i Distortion (at rie emphasis of the Wow & flutter Head room Emphasis (ON/C * The specifica Camera section Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum illumi		16bits/sample					
Distortion (at 11 in emphasis ON, rel Cross talk (at 1 kf Wow & flutter Head room Emphasis (ON/C * The specifica Camera Section Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000lk, Minimum illumi							
emphasis ON, ret Cross talk (a1 k Wow & flutter Head room Emphasis (ON/C "The specifica Camera Section Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum illumi		More than 85 dB Less than 0.08 %					
Cross talk (at 1 kt Wow & flutter Head room Emphasis (OM/C **The specifica* Camera section Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum illumi							
Wow & flutter Head room Emphasis (DN/C * The specifica Camera Section Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum illumi	at 1 kHz, reference level)		Less tha	n -70 dB			
Emphasis (ON/C The specifica Camera section Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum illumi		Below measurable limit					
*The specificat Camera section Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum illumi		20 dB					
Camera section Camera Pickup device Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum illumi	ON/OFF selectable)	T1=50 µs, T2=15 µs					
Pickup device Picture elemen Optical system Built-in filiters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k; Minimum illumi	ifications given abo	ve were measured via CA-701 Camera Ad	laptor.				
Picture elemen Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000lk, Minimum illumi							
Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000ix, Minimum Illumi	vice	3-chip 2/3-inch Power HAD 1000 IT CCD	3-chip 2/3-inch Power HAD 1000 16:9/4:3 Widescreen IT CCD	3-chip 2/3-inch Power HAD 1000 FIT CCD	3-chip 2/3-inch Power HAD 1000 16:9/4:3 Widescreen FIT CCD		
Optical system Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000ix, Minimum illumi	ments	811 (H) x 508 (V)	10.774.3 WIGGGGGGTTT GGD	1038 (H) x 504 (V)	13.714.3 WIGGSCIGGITTI COD		
Built-in filters Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000k, Minimum Illumi		611 (ri) x 306 (v) F1.4 prism system					
Shutter speed Gain Selection Clear scan Lens mount Sensitivity (2000ix, Minimum Illumi		1:CLEAR 2:500K+1/8hD 3:5600K 4:5600K+1/64ND					
Clear scan Lens mount Sensitivity (2000ix, Minimum illumi			1/100, 1/125, 1/250, 1/500, 1/1000, 1/2000 (s)				
Lens mount Sensitivity (2000k, Minimum illumi	ction	-3, 0, -	+3, +6, +9, +12, +18, +24, +30, +36, +42 dE	3, (select in camera setup menu for L/M/I	H/TURBO)		
Sensitivity (2000lx, Minimum illumi		CLS: 60.3 to 10156 Hz (260 steps)	CLS: 60.1 to 7000 Hz (260 steps)	ECS: 30.4 to 5	7000 Hz (260 steps) 58.3 Hz (248 steps)		
Minimum illumi		54-	Special bay				
		F10		F9			
		Approx. 0.3 lx Approx. 0.35 lx (F1.4 lens, +42 dB Turbo Gain) (F1.4 lens, +42 dB Turbo Gain)					
Video S/N ratio Vertical resolut	ratio (typical)		(without EVS) 400 TV line				
Registration	ratio (typical)		0.05 % (all zone				
Geometric dist	solution		Below measurable				
Warm-up time	solution		2 s				
	solution n distortion	60 % (Typical)	70 % (Typical) 55 % (Typical)	70 % (Typical)	70 % (Typical) 55 % (Typical)		
Viewfinder CRT	solution n distortion	1.5-inch monochrome	2-inch monochrome	1.5-inch monochrome	2-inch monochrome		
Controls	solution in distortion ime		BRIGHT control, CONTRAST control, PEAKIN		ches		
Horizontal resolu	solution in distortion ime	600 TV lines	450 TV lines 600 TV lines	600 TV lines	450 TV lines 600 TV lines		
Microphone	solution in distortion ime depth at 5 MHz		Ultra-directions	al (detachable)			
Supplied accessories	solution in distortion ime depth at 5 MHz		Manual Part 1 (1), Operation Manual (1)				

©1998 Sony Corporation. All rights reserved. Reproduction in whole or in part without Sony's written permission is prohibited. Features and specifications subject to change without notice.

All non-metric weights and measures are approximate.

Anton/Bauer and Ultralight are registered trademarks of Anton/Bauer, Inc.

Betacam, Betacam SP and Digital BETACAM are registered trademarks of Sony Corporation.

Betacam SX and Power HAD are trademarks of Sony Corporation.

All other trademarks are property of their respective owners.

Distributed by