	QUICK REFERENCE INDEX				
Edition: August 2004 A GENERAL INFORMATION		GI	General Information		
Revision: July 2005 Publication No. SM5E-1A34U1	В	ENGINE	EM	Engine Mechanical	
Publication No. SMSE-1A3401			LU	Engine Lubrication System	
			CO	Engine Cooling System	
			EC	Engine Control System	
			FL	Fuel System	
			EX	Exhaust System	
			ACC	Accelerator Control System	
	С	TRANSMISSION/	CL	Clutch	
		TRANSAXLE	MT	Manual Transaxle	
			AT	Automatic Transaxle	
	D	DRIVELINE/AXLE	FAX	Front Axle	
			RAX	Rear Axle	
	Е	SUSPENSION	FSU	Front Suspension	
			RSU	Rear Suspension	
			WT	Road Wheels & Tires	
	F	BRAKES	BR	Brake System	
			PB	Parking Brake System	
			BRC	Brake Control System	
NISSAN	G	STEERING	PS	Power Steering System	
BAAVIRAA	Н	RESTRAINTS	SB	Seat Belts	
MAXIMA			SRS	Supplemental Restraint System (SRS)	
	T	BODY	BL	Body, Lock & Security System	
MODEL A34 SERIES			GW	Glasses, Window System & Mirrors	
			RF	Roof	
			El	Exterior & Interior	
			IP	Instrument Panel	
			SE	Seat	
	J	AIR CONDITIONER	ATC	Automatic Air Conditioner	
	K	ELECTRICAL	SC	Starting & Charging System	
			LT	Lighting System	
			DI	Driver Information System	
			WW	Wiper, Washer & Horn	
			BCS	Body Control System	
			LAN	LAN System	
			AV	Audio Visual, Navigation & Telephone System	
			ACS	Auto Cruise Control System	
			PG	Power Supply, Ground & Circuit Elements	
	L	MAINTENANCE	MA	Maintenance	

Alphabetical Index

#### © 2005 NISSAN NORTH AMERICA, INC.

**M INDEX** 

All rights reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, photo-copying, recording or otherwise, without the prior written permission of Nissan North America, Inc., Gardena, California.

# **FOREWORD**

This manual contains maintenance and repair procedures for the 2005 NISSAN MAXIMA.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

# IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.





#### PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

Your comments are important to NISSAN and will help us to improve our Service Manuals. Use this form to report any issues or comments you may have regarding our Service Manuals. Please print this form and type or write your comments below. Mail or fax to:

> Nissan North America, Inc. **Technical Service Information** 39001 Sunrise Drive, P.O. Box 9200 Farmington Hills, MI USA 48331

FAX: (248) 488-3910

SERVICE MANUA	L: Model:	Year:						
PUBLICATION NO	D. (Refer to Quick Reference Index	):						
	Please describe any Service Manual issues or problems in detail:							
Page number(s)	Note: Please inc	clude a copy of each page, marked with your comments.						
Are the trouble di	iagnosis procedures logical and e	asy to use? (circle your answer) YES NO						
		include a copy of each page, marked with your comments.						
. •								
_	n of the manual clear and easy to	· · · · · · · · · · · · · · · · · · ·						
What information repairing custome		ervice Manuals to better support you in servicing or						
DATE:	YOUR NAME:	POSITION:						
DEALER:	DEALER NO.:	ADDRESS:						
CITY:	STATE/PROV./COUN	ITRY: ZIP/POSTAL CODE:						

### **QUICK REFERENCE CHART: MAXIMA**

PFP:00000

**Engine Tune-Up Data** 

ELS001CY

Cylinder arrangement				V	7-6
Displacement				3,498 cm <sup>3</sup> (213.45 in <sup>3</sup> )	
Bore and stroke				95.5 x 81.4 mm (3.760 x 3.205 in)	
Valve arrangement				DC	HC
Firing order				1-2-3	-4-5-6
Number of piston ring	ne .	Compression		:	2
Number of pistorring	js	Oil			1
Number of main bear	rings				4
Compression ratio				10	.0:1
		Standard		1,275 kPa (13.0 cm <sup>2</sup>	<sup>2</sup> , 185 psi) / 300 rpm
Compression pressur	re	Minimum		981 kPa (10.0 cm <sup>2</sup>	, 142 psi) / 300 rpm
		Differential limit betw	een cylinders	98 kPa (1.0 cm <sup>2</sup>	, 14 psi) / 300 rpm
Cylinder number		FRONT SEM713A			
Valve timing (IVTC - 0	OFF)	DDC PBICO187E			
		1			Unit: degree
а	b	С	d	е	f
a					·

#### Radiator

Unit: kPa (kg/cm<sup>2</sup>, psi)

Cap relief pressure	Standard	78 – 98 (0.8 – 1.0, 11 – 14)
Out relief pressure	Limit	59 (0.6, 9)
Leakage test pressure		157 (1.6, 23)

#### **Engine Idle Speed and Ignition Timing**

Target idle speed	No lood*1 /in Down position)	M/T: 625 ± 50 rpm	
raiget fule speed	No load*1 (in P or N position)	5-speed A/T: 675 ± 50 rpm	
Air conditioning: ON	Air conditioning: ON In P or N position		
Ignition timing In P or N position		15° ± 5° BTDC	


\*1: Under the following conditions:

· Air conditioner switch: OFF

• Electric load: OFF (Lights, heater fan & rear window defogger)

• Steering wheel: Kept in straight-ahead position

#### **Drive Belt Deflection and Tension**



						LLIA0060E
	Deflection adjustment		Unit: mm (in) Tension adjustment*		Unit: N (kg, lb)	
	Us	ed belt	Now bolt	Used belt		Now bolt
	Limit	After adjustment	New belt	Limit	After adjustment	New belt
Alternator and air conditioning compressor	7 (0.28)	4.2 - 4.6 (0.17 - 0.18)	3.7 - 4.1 (0.15 - 0.16)	294 (30, 66)	730 - 818 (74.5 - 83.5, 164 - 184)	838 - 926 (85.5 - 94.5, 188 - 208)
Power steering pump	11 (0.43)	7.3 - 8.0 (0.29 - 0.30)	6.5 - 7.2 (0.26 - 0.28)	196 (20, 44)	495 - 583 (50.5 - 59.5, 111 - 131)	603 - 691 (61.5 - 70.5, 135.6 - 155.4)
Applied pushing force	98 N (10 kg, 22 lb)			_		

<sup>\*:</sup> If belt tension gauge cannot be installed at check points shown, check drive belt tension at different location on the belt.


#### **Spark Plugs (Double-Platinum Tipped)**

Make	NGK
Standard type	PLFR5A-11
Hot type	PLFR4A-11
Cold type	PLFR6A-11
Gap (nominal)	1.1 mm (0.043 in)

## Front Wheel Alignment (Unladen\*1)

ELS001E6

Tire size		225/55R17	245/45R18	
Camber	Minimum	-1°00′ (-1.00°) -0°15′ (-0.25°)		
degree minute (decimal degree)	Nominal			
	Maximum	0°30′	0°30′ (0.50°)	
	Left and right difference	0° 45′ (0.75°) or less		
Caster	Minimum 2°05′ (2.		(2.08°)	
degree minute (decimal degree)	Nominal	Nominal 2°50′ (2.83°)		
	Maximum 3°35′ (3.58°)			
	Left and right difference	0° 45′ (0.75°) or less		
Kingpin inclination	Minimum 13°50′ (13.83			
degree minute (decimal degree)	Nominal 14°35′ (		(14.58°)	
	Maximum	15°20′ (15.33°)		



Total toe-in		Minimum	-0.5 (-	-0.020)
	Distance (A – B) mm (in)	Nominal	0.5 (0	0.020)
		Maximum	1.5 (0	0.059)
		Minimum	-	_
	Angle (left plus right) degree minute (decimal degree)	Nominal	2′ (0.03°)	
		Maximum	_	
Wheel turning angle	Inside degree minute (decimal degree)	Minimum	32°00′ (32.0°)	31°00′ (31.0°)
full turn*2		Nominal	35°30′ (35.5°)	34°30′ (34.5°)
		Maximum	36°30′ (36.5°)	35°30′ (35.5°)
	Outside degree minute (decimal degree)	Nominal	29°30′ (29.0°)	28°30′ (28.5°)


<sup>\*1:</sup> Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

<sup>\*2:</sup> On power steering models, wheel turning force (at circumference of steering wheel) of 98 to 147 N (10 to 15 kg-f, 22 to 33 lb-f) with engine at idle.

# Rear Wheel Alignment (Unladen\*)

ELS001E7

	Minimum	-0° 08' (-0.13°)
Camber Degree minute (Decimal degree)	Nominal	-0° 38′ (-0.63°)
3	Maximum	-0° 68′ (-1.13°)



		Minimum	2.3 (0.091)
	Distance (A – B) mm (in)	Nominal	3.8 (0.150)
Total toe-in be m		Maximum	5.3 (0.209)
	Distance difference	Minimum	-2.0 (-0.079)
	between RH and LH side	Nominal	0 (0)
	mm (in)	Maximum	2.0 (0.079)
		Minimum	0° 6′ (0.10°)
	Angle (left plus right)  Degree minute (Decimal degree)	Nominal	0° 10′ (0.17°)
	Bogroo minute (Beelmar degree)	Maximum	0° 14′ (0.23°)

<sup>\*:</sup> Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

Brake

Unit: mm (in)

ELS001D1

			Orne min (iii)
Brake model			CLZ25VE disc brake
	Cylinder bore diameter		57.2 (2.25)
Front brake	Pad Length × width × thicknes	SS	111.0 × 62.5 × 9.5 (4.37 × 2.46 × 0.37)
	Rotor outer diameter × th	ickness	320 × 28 (12.60 × 1.10)
	Brake model		AD9A disc brake
	Cylinder bore diameter		34.9 (1.374)
Rear brake	Pad Length × width × thicknes	SS	83.0 × 33.0 × 8.5 (3.27 × 1.30 × 0.33)
	Rotor outer diameter × th	ickness	292 × 9 (11.50 × 0.35)
Master cylinder	Cylinder bore diameter		23.81 (15/16)
Control valve	Screw in type		30 × 0.4 (1.18 × 0.02)
	Booster model		M215T
Brake booster	Dia la serie de	Primary	230 (9.06)
	Diaphragm diameter	Secondary	205 (8.07)
Recommended brake fluid			Genuine NISSAN Super Heavy Duty Brake Fluid, or equivalent DOT 3 (US FMVSS No. 116)


#### **Disc Brake - Repair Limits**

Unit: mm (in)

Brake model		CLZ25VE	AD9A
Pad wear limit	Minimum thickness	2.0 (0.079)	2.0 (0.079)
Rotor repair limit	Maximum runout	0.07 (0.0028)	0.05 (0.0020)
	Minimum thickness	26.0 (1.02)	8.0 (0.31)
	Maximum uneven wear (measured at 8 positions)	0.015 (0.0006) or less	

#### **Brake Pedal**

Unit: mm (in)



N·m (kg-m, ft-lb)

WFIA0022E

Free height "H"*	M/T	164.1 - 174.1 (6.46 - 6.85)
Free height. Fr	A/T	173.1 - 183.1 (6.81 - 7.21)
Clearance "C1" and "C2" between pedal stopper and threaded end of stop lamp switch or ASCD switch		0.74 - 1.96 (0.029 - 0.077)

<sup>\*:</sup> Measured from surface of dash reinforcement panel to surface of pedal pad

### **Refill Capacities**

ELS001D2

Description		Capacity (approximate)			
		Liter	US measure	Imp measure	
Fuel		75.6	20 gal	16 5/8 gal	
Engine oil Drain and refill	With oil filter change	4.2	4 1/2 qt	3 3/4 qt	
	Without oil filter change	4.0	4 1/4 qt	3 1/2 qt	
Dry engine (engine overhaul)		4.6	4 7/8 qt	4 qt	
Cooling system	With reservoir at MAX level	8.5	2 1/4 gal	1 7/8 gal	
Manual transaxle fluid (MTF)		2.2	2 3/8 qt	2 qt	
Transaxle fluid (ATF)	5 A/T	7.3	7 3/4 qt	6 3/8 qt	
Power steering fluid (PSF)		1.0	2 1/8 pt	1 3/4 pt	
Air conditioning system refrigerant		0.55 ± 0.25 kg	1.21 ± 0.055 lb	1.21 ± 0.055 lb	
Air conditioning system lubricant		150 m ℓ	5.03 fl oz	5.3 fl oz	