Cobalt[™] **Co**₄ Instrument Microphone



COBALT™

WIRED

MICROPHONES

General Product Description

Designed to yield outstanding performance in applications requiring the miking of acoustic and electric instruments, as well as vocal performances. Excellent for stage or studio, the Co4's versatility will make it a "must have" in any microphone mix.

Microphone Use and Placement

Please note that miking techniques are a matter of personal preference. These are merely guidelines to assist in the placement of the microphone to gain optimal performance.

	Out and Discount	
Usage	Optimal Placement	
Electric Guitar	Place microphone approximately 1-2" from and at	
and Bass	a 90° degree angle to the speaker cone.	
Guitar Amplifier	To reduce boominess, move the microphone off	
	axis to the cone from 90° to 45°, or move mic	
	from center of cone to either edge.	
Tom-Toms	On double headed Toms place mic over the top of	
	drum 1-3" and at a 45° angle to the drum surface	
	and 1-2" in from the drum edge. On single headed	
	Toms use above method or place mic inside Tom	
	from underneath at a 90° angle from the center of	
	head, 3-5", away.	
Snare Drum	Place mic 1-3" above the heads, 1-2" in from the	
· · · · · · · · · · · · · · · · · · ·	rim. Aim each mic at the top heads angled down	
	about 45°. If the drum rings, tape deadening	
	material to the head or use damping rings.	
	For more "snare" sound place a 2nd mic	
	underneath aimed up at the bottom of head.	
Cumbala	·	
Cymbals	Place microphone one to two feet above the	
	top of cymbals.	
High-Hat	Place 5 inches above outside edge at a	
	45° down angle.	
Brass	6-24" away, and on axis with the bell of	
	the instrument.	
Acoustic Guitar	Place mic 6-12" from where finger board	
	joins the body.	





Specifications


Element	Dynamic Neodymium magnet structure
Frequency Response	50 Hz to 18 kHz
Polar Pattern	Cardioid
Impedance	Low-Z balanced (600 Ohms)
Sensitivity	
Open Circuit Voltage	2.2 mV/Pascal @ 1.0kHz
Microphone Connector	3-pin, XLR-type
Polarity	Pin 2 positive, referenced to pin 3 with positive pressure on diaphragm
Finish	Durable polyurethane paint
Materials	Die cast zinc housing
Dimensions	
Length	5.8 in. (148 mm)
Diameter	.92 in. (23 mm)
Shank	.46 in. (12 mm)
Weight	
Net	12 oz. (340 grams)
Accessories included	Stand adaptor (black)


Standard Placement & Use Guidelines

- 1. Always point the microphone at the desired source of sound, and away from any unwanted sources.
- 2. The microphone should be located close to the sound source to minimize interference from other potential sound sources.
- 3. Use the 3-to-1 rule when using multiple microphones. Place each microphone three times farther from other microphones as from the desired sound source.
- 4. Minimize over-handling of the microphone to reduce unwanted mechanical noise.
- 5. Working close to the microphone will increase the bass tone and also provide increased gain-before-feedback.

Warranty

Telex/EV wired microphones are guaranteed against malfunction from any cause for a period of one (1) year from the date of original purchase. This limited warranty does not cover cables, cable connectors, or switches. If your Telex/EV product fails within this period, contact our Technical Assistance group at 1–800–392–3497 or toll free at 1–800–685–2606 for details on repair, replacement, or refund. For customers outside the U.S., please call the number listed in the bottom left column of this document.







Step up to Electro-Voice®

USA
Canada
Switzerland
Germany
France
Australia
Hong Kong
Japan
Singapore
Mexico
UK

12000 Portland Ave South, Burnsville, MN 55337, Phone: 952-884-4051, FAX: 952-884-0043
705 Progress Avenue, Unit 46, Scarborough, Ontario, Canada, M1H2X1, Phone: 416-431-4975, 800-881-1685, FAX: 416-431-4588
Ketlenstrasse 11, CH-2563 IPSACH, Switzerland, Phone: 41(32-331-6833, FAX: 41/32-331-1221
Hirschberger Ring 45, D94315, Straubing, Germany, Phone: 49 9421-706 392, Fax: 49 9421-706 287
Parc de Courcerin, Allee Lech Walesa, Lognes, 77185 Marne La Vallee, France, Phone: 33/1-6480-0090, FAX: 33/1-6480-4538
Unit 23, Block C, Slough Business Park, Slough Avenue, Silverwater, N.S.W. 2128, Australia, Phone: 61/2-9648-3455, FAX: 61/2-9648-5585
Unit E & F, 21/F, Luk Hop Industrial Bidg., 8 Luk Hop St., San PO Kong, Kowloon, Hong Kong, Phone: 852-2351-3628, FAX: 852-2351-3329
2-5-60 Izumi, Suginami-ku, Tokyo, Japan 168, Phone: 81-3-3325-7900, FAX: 81-3-3325-7789
3015A Ubi Rd 1, 05-10, Kampong Ubi Industrial Estate, Singapore 408705, Phone: 65-746-8760, FAX: 65-746-1206
Av. Parque Chapultepee #66-201, Col. El. Parque Edo. Mex. 53390, Phone: (52) 5358-5434, FAX: (52) 5358-5588
4, The Willows Centre, Willow Lane, Mitcham, Surrey CR4 4NX, UK, Phone: 41 81 640 9600, FAX: 44 181 646 7084
12000 Portland Ave South, Burnsville, MN 55337, Phone: 952-887-7424, FAX: 952-887-9212

U.S.A. and Canada only.

For customer orders, contact the Customer Service department at 800/392-3497 Fax: 800/955-6831

For warranty repair or service information, contact the Service Repair department at 800/685-2606

For technical assistance, contact Technical Support at 800/392-3497

Specifications subject to change without notice.

Designed in the U.S.A. Made in Taiwan.