

Elite SCREENS

Portable Floor Pull-Up Screen

Elite ez Cinema Series


FOR MODELS: F60NWV / F72NWV / F84NWV / F100NWV /
F84NWH / F100NWH

USER'S GUIDE





MATTE WHITE


PARTS IDENTIFICATION:





Precautions:

 Warning! Physical injuries can result from operation errors and damage to the screen if the following precautions are not taken seriously.

 Do not place screen near or beside a fireplace or high temperature objects such as a gas stove to avoid damage to the screen or prevent a fire.



 Place the screen beyond the reach of children.



Operation instructions:

Installation:


The screen should be installed in an area free of very strong wind and away from any fire activity such as a fireworks display.

Extending base feet:

Locate the base feet on the bottom of the box cover of each end and rotate the footboard until it forms a right angle between the footboard and the cover box.


Open the box cover:

Unlock the buckles on both sides of the box to open the box cover. Then, hold the box with one hand and remove the supporting rod with your other hand.




Installing the supporting rod:

First, make sure that the hanging hook is facing the front face of the screen, then insert the square end of the supporting rod at the fixing plate as shown below.




Pull out the screen:

Hold the pull hook at the upper scroll with one hand to pull the screen gently and hang it on the hanging hook.




Uphold the screen:

First loosen the locking sleeve, and then hold the small supporting rod with the left hand so as to slowly support it upwards till the screen is fully stretched or to the desired position.




Adjusting the screen:

When the screen has been stretched to the desired position, fix the small supporting rod with the left hand and rotate the locking sleeve clockwise while holding it tightly with the right hand till the rod is properly locked.




Screen completely assembled



Preparing screen for storage


1. Pulling down the screen:

First, hold the small supporting rod with the left hand and loosen the locking sleeve counter-clockwise with the right hand. Then pull the small supporting rod upwards about one centimeter and bring down the supporting rod downwards slowly.




2. Retract the screen:

Remove the hanging hook from the pull hook, and then hold the pull hook to roll the screen gently into the box.




3. Pulling out the supporting rod:

Retreat the small supporting rod and tighten it with the locking sleeve, and then take out the supporting rod from the fixing plate.




4. Storing the supporting rod:

Properly place the supporting rod in the middle of the box to avoid in unbalanced position.




5. Draw the base feet back:

Slightly lift one end of the box and turn the two feet at the bottom of the box till they are in a parallel line with the box.



6. Storing the screen:

The recommended place for storage would be a corner spot or in a close, but the ultimate choice is up to you.



The following points should be noted to assure the sound performance of the screen

1. Never use your hand to touch the screen surface
2. Never scrabble on the screen
3. Don't scratch the screen with hard pieces.
4. Please use clean cotton cloth or soft fur brushes to remove the dust on the screen.

Warranty Policy - Manual, Tripod, Pull-up Floor, and Fixed Frame Screens

- One (1) year warranty parts and labor from purchase date as follows (except for refurbished units as specified below):
- **Refurbished units** carry a **90-day** parts and labor warranty.
- **Demo units or open box items** are **AS IS** items and do not carry a warranty.
- Each party will be responsible for one way shipping during the warranty period.
- **DOA (Defective On Arrival): Must be reported within 7 business days of receipt.** A RMA (Return Merchandise Authorization) number must be issued in order to process a replacement. Elite Screens will replace the DOA (Defective On Arrival) unit with a brand new replacement *(see exceptions below) after the DOA unit is received and/or confirmed defective. Once the product is received, Elite Screens will send out a new *unit to the customer by ground service (subject to inventory availability). Should a problem be reported after the 7-day grace period, the item must be shipped to us for warranty repair.
- **Missing Parts** must be reported within the 7-day (DOA) grace period. If reported after 7 days, customer will be only be responsible for shipping and handling fees. If reported after 30 days of receipt, customer is responsible for cost of the parts and shipping & handling fees.

Please visit link below for full warranty information

<http://www.elitescreens.com/services.html>

*A new or refurbished replacement will be sent out to the customer depending on the type of purchase (new or refurbished) or based on stock availability.

Fill this in!!

For the convenience of service, record the following information in the space below. The serial number can be located on the packaging box or inside the screen's box.

Screen Model:

Serial Number:

Date of Purchase:

Dealer / Reseller Purchased from:

*Elite*SCREENS

Tel: 562-483-8198

www.elitescreens.com

service@elitescreens.com